




SEW
EURODRIVE

Operating Instructions



AC Motors

DR..71 – 315, DRN80 – 315



Contents

1	General information	9
1.1	About this documentation	9
1.2	Structure of the safety notes	9
1.2.1	Meaning of signal words	9
1.2.2	Structure of section-related safety notes	9
1.2.3	Structure of embedded safety notes	10
1.3	Rights to claim under limited warranty	11
1.4	Exclusion of liability	11
1.5	Product names and trademarks	11
1.6	Copyright notice	11
2	Safety notes	12
2.1	Preliminary information	12
2.2	General information	12
2.3	Target group	13
2.4	Functional safety	14
2.5	Designated use	15
2.6	Other applicable documentation	16
2.6.1	DR..71 – 315, DRN80 – 315 AC motors	16
2.7	Transport/storage	16
2.8	Installation	17
2.9	Electrical connection	17
2.10	Startup/operation	18
2.10.1	Surface temperature during operation	18
3	Motor structure	19
3.1	Basic structure of DR..71 – 132/DRN80 – 132S	19
3.2	Basic structure of DR..160 – 180, DRN132M – 180	20
3.3	Basic structure of DR..200 – 225, DRN200 – 225	21
3.4	Basic structure of DR..250 – 280, DRN250 – 280	22
3.5	Basic structure of DR..315, DRN315	23
3.6	Nameplate	24
3.6.1	DRE.. motor nameplate	24
3.6.2	DRE.. global nameplate	25
3.6.3	"Use with variable speed drive only" marking	25
3.6.4	Type designation.....	26
3.7	Additional features	28
3.7.1	Output variants.....	28
3.7.2	Mechanical attachments	28
3.7.3	Temperature sensor / temperature detection.....	28
3.7.4	Encoder.....	29
3.7.5	Connection alternatives	29
3.7.6	Ventilation	30
3.7.7	Bearing.....	30
3.7.8	Condition monitoring.....	30
3.7.9	Other additional features.....	30

3.7.10	Explosion-proof motors	31
4	Mechanical installation	32
4.1	Before you start	32
4.2	Extended storage of motors	33
4.2.1	Drying the motor	33
4.3	Motor installation notes	35
4.3.1	Installation in damp locations or outdoors.....	35
4.4	Installation tolerances	36
4.5	Assembling the input elements	36
4.6	HR/HF manual brake release	37
4.6.1	HF manual brake release.....	37
4.6.2	Retrofitting HR/HF manual brake release	38
4.7	Non-SEW encoder mounting	39
4.8	Mounting the XV.A encoder mounting adapter on DR..71 – 225, DRN80 – 225 motors	39
4.9	Mounting an encoder with EV.A / AV.A mounting adapter to DR..250 – 280, DRN250 – 280 motors	41
4.9.1	XH.A encoder mounting adapter.....	42
4.10	Turning the terminal box	43
4.11	Retrofitting (option /F.A) or modifying (option /F.B) motor feet	45
4.12	Accessory equipment	46
4.12.1	Air filter LF.....	46
4.12.2	Mounting adapter for measuring nipple	48
4.12.3	2nd shaft end with optional cover	49
5	Electrical installation.....	51
5.1	Additional regulations	51
5.2	Wiring diagrams and terminal assignment diagrams	51
5.3	Wiring notes	52
5.3.1	Protecting the brake control system against interference	52
5.3.2	Protecting the motor protection devices against interference	52
5.4	Special aspects for operation with a frequency inverter	52
5.4.1	Motors with frequency inverters from SEW-EURODRIVE	52
5.4.2	Motor with non-SEW inverter	53
5.5	Exterior grounding at the terminal box, LF grounding	55
5.6	Improving the grounding (EMC), HF grounding	56
5.6.1	Sizes DR..71S/M, DR..80S/M and DRN80 with HF(+LF) grounding	57
5.6.2	Sizes DR..90M/L, DRN90 with HF(+LF) grounding	57
5.6.3	Sizes DR..100M, DRN100 with HF(+LF) grounding	58
5.6.4	Sizes DR..100L – 132, DRN100 – 132S with HF(+LF) grounding	58
5.6.5	Sizes DR..160 – 315, DRN132M – 315 with HF(+LF) grounding	59
5.7	Special aspects in switching operation	60
5.8	Special aspects of torque motors and low-speed motors	60
5.9	Special aspects of single-phase motors	61
5.9.1	Connecting the single-phase motor	62
5.10	Ambient conditions during operation	63
5.10.1	Ambient temperature	63

5.10.2	Installation altitude	63
5.10.3	Hazardous radiation.....	63
5.10.4	Hazardous gases, vapors and dusts.....	63
5.11	Notes regarding the connection of the motor	64
5.12	Connecting the motor via terminal block	65
5.12.1	According to wiring diagram R13.....	65
5.12.2	According to wiring diagram R76.....	66
5.12.3	According to wiring diagram R72.....	67
5.12.4	Connection variants via terminal block	68
5.13	Connecting the motor plug connector	74
5.13.1	IS plug connector.....	74
5.13.2	AB., AD., AM., AK., AC., AS.. plug connectors	78
5.14	Connecting the motor via terminal strip	79
5.14.1	KCC terminal strip.....	79
5.14.2	KC1 terminal strip	80
5.15	Connecting the brake	81
5.15.1	Connecting the brake control	81
5.15.2	Connecting the DUB diagnostics unit	82
5.16	Optional equipment	83
5.16.1	Temperature sensor /TF	83
5.16.2	TH winding thermostats	84
5.16.3	/KY temperature sensor (KTY84 – 130).....	85
5.16.4	Temperature sensor /PT (PT100).....	86
5.16.5	V forced cooling fan	87
5.16.6	UWU52A switched-mode power supply.....	88
5.16.7	Overview of mount-on encoders	89
5.16.8	Overview of built-in encoders and visual feedback.....	90
5.16.9	Installation notes for encoders	92
5.16.10	Anti-condensation heating	93
6	Startup.....	94
6.1	Before startup	95
6.2	Motors with reinforced bearing	95
6.3	Altering the blocking direction on motors with a backstop	96
6.3.1	Basic structure of DR..71 – 80, DRN80 with backstop	96
6.3.2	Basic structure of DR..90 – 315, DRN90 – 315 with backstop	96
6.3.3	Changing the blocking direction.....	97
7	Inspection/maintenance.....	99
7.1	Inspection and maintenance intervals	101
7.1.1	Connection cables	101
7.2	Bearing lubrication	102
7.2.1	Bearing lubrication for DR..71 – 225, DRN80 – 225.....	102
7.2.2	Bearing lubrication for DR../DRN250 – 315.....	102
7.3	Reinforced bearings	103
7.4	Corrosion protection	103
7.5	Motor and brake maintenance – preliminary work	104

7.5.1	Removing the rotary encoder from DR..71 – 132, DRN80 – 132S	104
7.5.2	Removing the rotary encoder from DR..160 – 280, DRN132M – 280	105
7.5.3	Removing the rotary encoder from DR..160 – 315, DRN132M – 315 with /V forced cooling fan option.....	106
7.5.4	Removing the rotary encoder from DR..315, DRN315	107
7.5.5	Installing/removing incremental encoders, absolute encoders and special encoders with XV.A mounting adapter to/from DR..71 – 225, DRN80 – 225	109
7.5.6	Removing/installing incremental encoders, absolute encoders and special encoders with EV.A / AV.A mounting adapter to/from DR..250 – 280, DRN250 – 280	110
7.5.7	Installing/removing incremental encoders, absolute encoders and special encoders with EV.A / AV.A mounting adapter to/from DR..250 – 280, DRN250 – 280 with /V forced cooling fan option	113
7.5.8	Installing/removing hollow shaft encoders from/to XH.. mounting adapter of DR..71 – 225, DRN80 – 225	114
7.6	Inspection/maintenance of DR..71 – 315, DRN80 – 315 motors	116
7.6.1	Basic structure of DR..71 – 132/DRN80 – 132S.....	116
7.6.2	Basic structure of DR..160 – 180, DRN132M – 180	117
7.6.3	Basic structure of DR..200 – 225, DRN200 – 225	118
7.6.4	Basic structure of DR..250 – 280, DRN250 – 280	119
7.6.5	Basic structure of DR..315, DRN315	120
7.6.6	Inspection steps for DR..71 – 315, DRN80 – 315 motors.....	121
7.7	Inspection/maintenance of DR..71 – 315, DRN80 – 315 brakemotors	123
7.7.1	Basic structure of DR..71 – 80, DRN80 brakemotors	123
7.7.2	Basic structure of DR..90 – 132, DRN90 – 132S brakemotors.....	124
7.7.3	Basic structure of DR..160 – 280, DRN132M – 280 brakemotors	125
7.7.4	DR.315 brakemotor – basic structure	126
7.7.5	Inspection steps for DR..71 – 315, DRN80 – 315 brakemotors.....	127
7.7.6	Basic structure of BE05 – BE2 brakes (DR..71 – 80, DRN80)	130
7.7.7	Basic structure of BE1 – BE11 brakes (DR..90 – 160, DRN90 – 132S).....	130
7.7.8	Basic structure of BE20 brakes (DR..160 – 180, DRN132M – 180)	131
7.7.9	Basic structure of BE30 – BE32 brakes (DR..180 – 225, DRN180 – 225)	131
7.7.10	Basic structure of BE60 – BE122 brakes (DR..250 – 315, DRN250 – 315)	132
7.7.11	Setting the working air gap of BE05 – BE122 brakes	133
7.7.12	Replacing the brake disk of BE05 – BE122 brakes	135
7.7.13	Changing the braking torque of BE05 – BE122 brakes	137
7.7.14	Changing the brake spring of BE05 – BE122 brakes	138
7.7.15	Changing the magnet body of BE05 – BE122 brakes	140
7.7.16	Changing the brake of DR..71 – 80, DRN80 motors.....	142
7.7.17	Changing the brakes for DR..90 – 225, DRN90 – 225.....	143
7.7.18	Changing the brakes for DR..250 – 315, DRN250 – 315.....	145
7.8	Inspection/maintenance – DUB	146
7.8.1	Basic structure of DUB on DR..90 – 100 motors with BE2 brakes	146
7.8.2	Basic structure of DUB on DR..90 – 315 motors with BE5 – BE122 brakes.....	147

7.8.3	Inspection/maintenance of the DUB for function monitoring.....	148
7.8.4	Inspection/maintenance of the DUB for wear monitoring.....	149
7.8.5	Inspection/maintenance of the DUB for function and wear monitoring	149
8	Technical data	150
8.1	Work done, working air gap, braking torques	150
8.2	Braking torque assignment	152
8.2.1	Motor sizes DR..71 – 100, DRN80 – 100.....	152
8.2.2	Motor sizes DR..112 – 225, DRN112 – 225.....	152
8.2.3	Motor sizes DR..250 – 280, DRN250 – 280.....	153
8.2.4	Motor sizes DR..315, DRN315.....	153
8.3	Operating currents	154
8.3.1	Brake BE05, BE1, BE2	154
8.3.2	Brakes BE5, BE11, BE20, BE30, BE32, BE60, BE62	155
8.3.3	Brake BE120, BE122	156
8.4	Resistors	157
8.4.1	Brake BE05, BE1, BE2, BE5	157
8.4.2	Brakes BE11, BE20, BE30, BE32, BE60, BE62	158
8.4.3	Resistance measurement BE05, BE1, BE2, BE5, BE30, BE32, BE60, BE62	158
8.4.4	Brake BE120, BE122	160
8.4.5	Resistance measurement BE120, BE122.....	160
8.5	Brake control system	161
8.5.1	Permitted combinations	161
8.5.2	Wiring space of the motor	163
8.5.3	Control cabinet.....	164
8.6	Permitted rolling bearing types	165
8.6.1	Rolling bearing types for motor sizes DR..71 – 315, DRN80 – 315.....	165
8.6.2	Motors with /ERF reinforced bearings for motor sizes DR..250 – 315, DRN250 – 315	165
8.6.3	/NIB current-insulated rolling bearings for motor sizes DR..200 – 315, DRN200 – 315	165
8.7	Lubricant tables	166
8.7.1	Lubricant table for rolling bearings.....	166
8.8	Order information for lubricants and anti-corrosion agents	166
8.9	Encoders	167
8.9.1	ES7. and EG7.	167
8.9.2	EH7.....	167
8.9.3	AS7Y and AG7Y	168
8.9.4	AS7W and AG7W	169
8.9.5	AH7Y.....	170
8.9.6	EI7. B	171
8.9.7	EV2.	171
8.10	Markings on the nameplate	172
8.11	Characteristic values of functional safety	173
8.11.1	Characteristic safety values of the brakes BE05 – BE122.....	173
8.11.2	Safety characteristics of safety-rated encoders	174

8.12	S1 duty cycle DRK.. single-phase motor	175
9	Malfunctions	176
9.1	Motor malfunctions	177
9.2	Brake malfunctions	179
9.3	Malfunctions when operated with a frequency inverter	181
9.4	Customer service	182
9.5	Disposal	182
10	Appendix	183
10.1	Wiring diagrams	183
10.1.1	Delta and star connection in wiring diagram R13	183
10.1.2	Delta connection with wiring diagram R72 (68192 xx 09).....	184
10.1.3	Star connection with wiring diagram R76 (68043 xx 06).....	185
10.1.4	Motor protection with TF or TH for DR..71 – 280, DRN80 – 280	186
10.1.5	Motor protection using TF or TH with DR..315, DRN315.....	187
10.1.6	EI7.B built-in encoder	188
10.1.7	Brake control BGE; BG; BSG; BUR.....	190
10.1.8	BSR brake control.....	192
10.1.9	BMP3.1 brake control in the terminal box	195
10.1.10	V forced cooling fan	196
10.1.11	DRK... single-phase motor.....	198
10.2	Auxiliary terminals 1 and 2	199
11	Address list.....	200
	Index	210

1 General information

1.1 About this documentation

This documentation is an integral part of the product. The documentation is intended for all employees who perform assembly, installation, startup, and service work on the product.

Make sure this documentation is accessible and legible. Ensure that persons responsible for the machinery and its operation as well as persons who work on the device independently have read through the documentation carefully and understood it. If you are unclear about any of the information in this documentation or require further information, please contact SEW-EURODRIVE.

1.2 Structure of the safety notes

1.2.1 Meaning of signal words

The following table shows the grading and meaning of the signal words for safety notes.

Signal word	Meaning	Consequences if disregarded
▲ DANGER	Imminent hazard	Severe or fatal injuries.
▲ WARNING	Possible dangerous situation	Severe or fatal injuries
▲ CAUTION	Possible dangerous situation	Minor injuries
NOTICE	Possible damage to property	Damage to the drive system or its environment.
INFORMATION	Useful information or tip: Simplifies handling of the drive system.	

1.2.2 Structure of section-related safety notes

Section-related safety notes do not apply to a specific action but to several actions pertaining to one subject. The hazard symbols used either indicate a general hazard or a specific hazard.

Section-related safety notes are structured as follows:



SIGNAL WORD







Type and source of hazard.

Possible consequence(s) if disregarded.

- Measure(s) to prevent the hazard.

Meaning of the hazard symbols

The hazard symbols in the safety notes have the following meaning:

Hazard symbol	Meaning
	General hazard
	Warning of dangerous electrical voltage
	Warning of hot surfaces
	Warning of risk of crushing
	Warning of suspended load
	Warning of automatic restart

1.2.3 Structure of embedded safety notes

Embedded safety notes are directly integrated into the instructions just before the description of the dangerous action.

Embedded safety notes are structured as follows:

- **▲ SIGNAL WORD** Type and source of hazard.
Possible consequence(s) if disregarded.
 - Measure(s) to prevent the hazard.

1.3 Rights to claim under limited warranty

A requirement of fault-free operation and fulfillment of any rights to claim under limited warranty is that you adhere to the information in the documentation. Read the documentation before you start working with the product.

1.4 Exclusion of liability

You must comply with the information contained in this documentation to ensure safe operation and to achieve the specified product characteristics and performance features. SEW-EURODRIVE assumes no liability for injury to persons or damage to equipment or property resulting from non-observance of these operating instructions. In such cases, any liability for defects is excluded.

1.5 Product names and trademarks

All product names included in this documentation are trademarks or registered trademarks of the respective titleholders.

1.6 Copyright notice

© 2014 SEW-EURODRIVE. All rights reserved.

Unauthorized reproduction, modification, distribution or any other use of the whole or any part of this documentation is strictly prohibited.

2 Safety notes

The following basic safety notes must be read carefully to prevent injury to persons and damage to property. The user must ensure that the basic safety notes are read and observed. Make sure that persons responsible for the system and its operation, as well as persons who work independently on the unit, have read through the operating instructions carefully and understood them. If you are unclear about any of the information in this documentation, or if you require further information, please contact SEW-EURODRIVE.

2.1 Preliminary information

The following safety notes are primarily concerned with the use of the following components: DR../DRN.. AC motors. If you use gearmotors, please also refer to the safety notes in the corresponding operating instructions for:

- Gear unit

Also observe the supplementary safety notes in the individual sections of this documentation.

2.2 General information



▲ WARNING

Danger of fatal injury during operation as the motors and gearmotors can have live, bare (in the event of open connectors/terminal boxes) and movable or rotating parts as well as hot surfaces.

Severe or fatal injuries

- All work related to transport, storage, installation, assembly, connection, startup, maintenance and repair may only be carried out by qualified personnel.
- For transport, storage, installation, assembly, connection, startup, maintenance and repair it is important that you adhere to the information in the following documents:
 - Warning and safety signs on the motor/gearmotor
 - All the project planning documents, startup instructions and wiring diagrams related to the drive
 - System-specific regulations and requirements
 - National/regional safety and accident prevention regulations.
- Never install damaged products.
- Never operate or energize the unit without the necessary protection covers or housing.
- Use the unit only for its intended purpose.
- Make sure the unit is installed and operated properly.

This documentation provides additional information.

2.3 Target group

Any mechanical work may only be performed by adequately qualified personnel. Qualified personnel in the context of this documentation are persons familiar with the design, mechanical installation, troubleshooting and servicing of the product who possess the following qualifications:

- Training in mechanical engineering, e.g. as a mechanic or mechatronics technician (final examinations must have been passed).
- They are familiar with these operating instructions.

Any electronic work may only be performed by adequately qualified electricians. Qualified electricians in the context of this documentation are persons familiar with electrical installation, startup, troubleshooting and servicing of the product who possess the following qualifications:

- Training in electrical engineering, e.g. as an electrician, electronics or mechatronics technician (final examinations must have been passed).
- They are familiar with these operating instructions.

All work in the areas of transportation, storage, operation and waste disposal must be carried out by persons who are trained appropriately.

All qualified personnel must wear appropriate protective clothing.

2.4 Functional safety



SEW-EURODRIVE drives can be supplied with safety-rated components.

Inverters, encoders or brakes, or other accessories, can be integrated into the AC motor as safety-related components either individually or in combination.

SEW-EURODRIVE indicates such an integration by the FS mark and a number on the nameplate of the motor.

The number is a code that indicates which components in the drive are safety-related. See the following code table for all products:

Functional safety	Inverters	Motor monitoring (e.g. motor protection)	Encoders	Brakes	Brake monitoring (e.g., function)	Manual brake release
01	x					
02				x		
03		x				
04			x			
05	x			x		
06	x	x				
07	x		x			
08				x		x
09				x	x	
10		x		x		
11			x	x		
12		x	x			
13	x		x	x		
14	x	x	x			
15			x	x		x
16			x	x	x	
17		x	x	x		
18	x	x		x		x
19	x		x	x		x
20	x	x		x	x	
21	x		x	x	x	
22	x	x	x	x		
23	x	x	x	x		x
24	x	x	x	x	x	
25	x	x	x	x	x	x
26				x	x	x
27			x	x	x	x
28		x		x		x
29		x		x	x	
30		x		x	x	x
31		x	x	x		x
32		x	x	x	x	
33		x	x	x	x	x
34	x			x		x
35	x			x	x	
36	x			x	x	x
37	x		x	x	x	x
38	x	x		x		
39	x	x		x	x	x

If the FS logo on the nameplate contains the code "FS 11," for example, the motor is equipped with a combination of a safety-rated brake and safety-rated encoder.

If the drive bears the FS mark on the nameplate, you must adhere to the information in the following documents:

- The "Safety-Rated Encoders – Functional Safety for DR.71 – 225, 315 AC Motors" addendum to the operating instructions
- The "Safety-Rated Brakes– Functional Safety for DR.71 – 225 AC Motors" addendum to the operating instructions
- "Safety-Rated Drive System" system manual

To determine the safety level for systems and machines yourself, refer to the characteristic safety values of the following components in chapter "Technical data":

- Characteristic safety values for brakes: $B10_d$ values
- Characteristic safety values for encoders: $MTTF_d$ values

The characteristic safety values of SEW components are also available on the SEW homepage on the Internet and in the SEW library for the Sistema software of the Institute for Occupational Safety and Health of the German Social Accident Insurance (IFA, formerly BGIA).

2.5 Designated use

DR../DRN.. AC motors are intended for industrial systems.

When installed in machines, startup (i.e. start of designated operation) is prohibited until it is determined that the machine complies with the local laws and directives. In the individual area of application, you must especially observe the Machinery Directive 2006/42/EC as well as the EMC Directive 2004/108/EC. The EMC test specifications EN 61000-4-2, EN 61000-4-3, EN 61000-4-4, EN 61000-4-6 and EN 61000-6-2 form the basis for this.

Use in potentially explosive areas is prohibited, unless specifically designated otherwise.

Air-cooled motors/gearmotors are dimensioned for ambient temperatures of -20 °C to +40 °C and installation altitudes ≤ 1000 m above sea level. Note that information on the nameplate may differ. It is essential that the operating conditions for the unit comply with the nameplate information.

2.6 Other applicable documentation

2.6.1 DR..71 – 315, DRN80 – 315 AC motors

The following publications and documents should also be observed:

- Wiring diagrams provided with the motor
- "Gear Unit Series R..7, F..7, K..7, K..9, S..7, SPIROPLAN® W" operating instructions for gearmotors
- "AC Motors" catalog and/or
- "DRN.. AC Motors" addendum to the catalog
- DR.. gearmotor catalogs
- If required, "Functional Safety for AC Motors DR.71 – 225, 315 – Brakes" addendum to the operating instructions
- If required, "Functional Safety for AC Motors DR.71 – 225, 315 – Encoders" addendum to the operating instructions
- If required, "MOVIMOT® MM..D Functional Safety" manual

2.7 Transport/storage

Inspect the shipment for any damage that may have occurred in transit as soon as you receive the delivery. Report any transport damage to the shipping company immediately. You may need to suspend startup.

Tighten the eyebolts securely. They are designed to only carry the weight of the gear unit/motor/gearmotor; do not attach any additional loads.

The installed lifting eyebolts are in accordance with DIN 580. The loads and regulations specified in that document must always be observed. If the gear unit/motor/gearmotor is equipped with two eyebolts, then both of these should be used for transportation. In this case, the tension force vector of the slings must not exceed a 45° angle in accordance with DIN 580.

Use suitable, sufficiently rated handling equipment if required. Reattach these in the case of further transportation.

Store the gear unit/motor/gearmotor in a dry, dust-free environment if it is not to be installed straight away. You must not store the gear unit/motor/gearmotor outdoors or on the fan guard. The gear unit/motor/gearmotor can be stored for up to 9 months without requiring any special measures before startup.

2.8 Installation

Make sure that the supports are even, the foot and flange mounting is correct and if there is direct coupling, align with precision. Resonances between the rotational frequency and the double line frequency caused by the structure are to be avoided. Release the brake (if installed), turn rotor manually, check for unusual grinding noise. Check the direction of rotation in decoupled state.

Only install or remove belt pulleys and couplings using suitable devices (heat up) and cover with a touch guard. Avoid improper belt tension.

Make the pipe connections that may eventually be required. Mounting positions with shaft ends pointing upwards should be equipped with a cover to prevent foreign objects from falling into the fan. Ensure that ventilation openings are not obstructed and that exhaust air, including air from adjacent units, cannot be drawn in again straight away.

Observe the notes in chapter Mechanical Installation (→ 32).

2.9 Electrical connection

All work may only be carried out by qualified specialists. During work, the low-voltage machine must be at standstill, enabled and safeguarded against an accidental restart. This also applies to auxiliary circuits (e.g. anti-condensation heating or forced cooling fan).

Ensure that the unit is de-energized.

Exceeding the tolerances in EN 60034-1 (VDE 0530, part 1) – voltage + 5%, frequency + 2%, curve shape, symmetry – increases heating and influences electromagnetic compatibility. Also observe the standard EN 50110 (and, if applicable, other national regulations, such as DIN VDE 0105 for Germany).

Observe the wiring information and differing data on the nameplate as well as the wiring diagram in the terminal box.

The connection should be a permanent, secure electrical connection (no protruding wire ends); use the cable end pieces intended for this purpose. Establish a secure protective earth connection. When the motor is connected, the distances to non-insulated and live parts must not be shorter than the minimum values according to IEC 60664 and national regulations. With low voltage, the distances should be no shorter than the following values, in compliance with IEC 60664:

Nominal voltage V_N	Distance
$\leq 500 \text{ V}$	3 mm
$\leq 690 \text{ V}$	5.5 mm

The connection box must be free from foreign objects, dirt and moisture. Close unused cable entry openings and the box itself so they are dust and water proof. Secure key for test run without output elements. When operating low-voltage machines with brakes, check that the brake is functioning correctly before startup.

Observe the notes in the "Electrical Installation" chapter.

2.10 Startup/operation

Whenever changes to normal operation occur in the gear unit/motor/gearmotor, such as increased temperatures, noise, vibrations, determine the cause. Consult the manufacturer if required. Never deactivate protection devices, even in test mode. Switch off the motor if you are not sure.

Regularly clean air ducts in dusty or dirty environments.

2.10.1 Surface temperature during operation



▲ CAUTION

The surfaces of the drive can be very hot during operation.

Risk of burns.

- Make sure that hot surfaces cannot be touched unintentionally or during normal operation. Install covers or warning signs according to regulations.
 - Let the unit cool down before you start working on it.
-


3 Motor structure

INFORMATION



The following figures are block diagrams. Their purpose is to make it easier to assign components to the spare parts lists. Deviations are possible depending on the motor size and version.


3.1 Basic structure of DR..71 – 132/DRN80 – 132S



13369217931

[1] Rotor	[30] Oil seal	[106] Oil seal	[123] Hex head screw
[2] Retaining ring	[32] Retaining ring	[107] Oil flinger	[129] Screw plug with O-ring
[3] Key	[35] Fan guard	[108] Nameplate	[131] Gasket for cover
[7] Flanged endshield	[36] Fan	[109] Grooved pin	[132] Terminal box cover
[9] Screw plug	[41] Shim washer	[111] Gasket for lower part	[134] Screw plug with O-ring
[10] Retaining ring	[42] B-side endshield	[112] Terminal box lower part	[156] Information sign
[11] Deep groove ball bearing	[44] Deep groove ball bearing	[113] Pan head screw	[262] Connection terminal, complete
[12] Retaining ring	[90] Bed plate	[115] Terminal board	[392] Gasket
[13] Cap screw	[91] Hex nut	[116] Terminal yoke	[705] Canopy
[16] Stator	[93] Pan head screw	[117] Hex head screw	[706] Spacer
[22] Hex head screw	[100] Hex nut	[118] Lock washer	[707] Pan head screw
[24] Eyebolt	[103] Stud	[119] Pan head screw	

3.2 Basic structure of DR..160 – 180, DRN132M – 180



18014399036804619

[1] Rotor	[31] Key	[108] Nameplate	[132] Terminal box cover
[2] Retaining ring	[32] Retaining ring	[109] Grooved pin	[134] Screw plug with O-ring
[3] Key	[35] Fan guard	[111] Gasket for lower part	[137] Screw
[7] Flange	[36] Fan	[112] Terminal box lower part	[139] Hex head screw
[9] Screw plug	[41] Cup spring	[113] Screw	[140] Washer
[10] Retaining ring	[42] B-side endshield	[115] Terminal board	[153] Terminal strip, complete
[11] Deep groove ball bearing	[44] Deep groove ball bearing	[116] Serrated lock washer	[156] Information sign
[12] Retaining ring	[90] Foot	[117] Stud	[219] Hex nut
[14] Washer	[91] Hex nut	[118] Washer	[262] Retaining plate
[15] Hex head screw	[93] Washer	[119] Cap screw	[390] O-ring
[16] Stator	[94] Cap screw	[121] Grooved pin	[616] Retaining plate
[17] Hex nut	[100] Hex nut	[123] Hex head screw	[705] Canopy
[19] Cap screw	[103] Stud	[128] Serrated lock washer	[706] Spacer
[22] Hex head screw	[104] Supporting ring	[129] Screw plug with O-ring	[707] Hex head screw
[24] Eyebolt	[106] Oil seal	[131] Gasket for cover	[715] Hex head screw
[30] Sealing ring	[107] Oil flinger		


3



3

3


3.4 Basic structure of DR..250 – 280, DRN250 – 280



9007206690410123

[1] Rotor	[32] Retaining ring	[108] Nameplate	[134] Screw plug
[2] Retaining ring	[35] Fan guard	[109] Grooved pin	[137] Screw
[3] Key	[36] Fan	[111] Gasket for lower part	[139] Hex head screw
[7] Flange	[40] Retaining ring	[112] Terminal box lower part	[140] Washer
[9] Screw plug	[42] B-side endshield	[113] Cap screw	[156] Information sign
[11] Deep groove ball bearing	[43] Supporting ring	[115] Terminal board	[159] Connection piece
[15] Cap screw	[44] Deep groove ball bearing	[116] Serrated lock washer	[160] Connection piece gasket
[16] Stator	[90] Foot	[117] Stud	[161] Hex head screw
[19] Cap screw	[93] Washer	[118] Washer	[219] Hex nut
[21] Oil seal flange	[94] Cap screw	[119] Hex head screw	[262] Connection terminal
[22] Hex head screw	[100] Hex nut	[123] Hex head screw	[705] Canopy
[24] Eyebolt	[103] Stud	[128] Serrated lock washer	[706] Spacer bolt
[25] Cap screw	[105] Compression spring	[129] Screw plug	[707] Hex head screw
[26] Shield ring	[106] Oil seal	[131] Gasket for cover	[715] Hex head screw
[30] Oil seal	[107] Oil flinger	[132] Terminal box cover	[1453] Screw plug
[31] Key			

3.5 Basic structure of DR..315, DRN315



27021598116221579


[1] Rotor	[32] Retaining ring	[111] Gasket for lower part	[156] Information sign
[2] Retaining ring	[35] Fan guard	[112] Terminal box lower part	[219] Hex nut
[3] Key	[36] Fan	[113] Cap screw	[250] Oil seal
[7] Flange	[40] Retaining ring	[115] Terminal board	[452] Terminal strip
[9] Screw plug	[42] B-side endshield	[116] Serrated lock washer	[454] Mounting rail
[11] Rolling bearing	[43] Supporting ring	[117] Stud	[604] Lubrication ring
[15] Cap screw	[44] Rolling bearing	[118] Washer	[606] Grease nipple
[16] Stator	[90] Foot	[119] Hex head screw	[607] Grease nipple
[17] Hex nut	[93] Washer	[123] Hex head screw	[608] Oil seal flange
[19] Cap screw	[94] Cap screw	[128] Serrated lock washer	[609] Hex head screw
[21] Oil seal flange	[100] Hex nut	[129] Screw plug	[633] End bracket
[22] Hex head screw	[103] Stud	[131] Gasket for cover	[634] End plate
[24] Eyebolt	[105] Cup spring	[132] Terminal box cover	[705] Canopy
[25] Cap screw	[106] Oil seal	[134] Screw plug	[706] Spacer bolt
[26] Shield ring	[107] Oil flinger	[139] Hex head screw	[707] Hex head screw
[30] Oil seal	[108] Nameplate	[140] Washer	[715] Hex nut
[31] Key	[109] Grooved pin	[151] Cap screw	[716] Washer

3.6 Nameplate

The marks (→ 172) on the upper edge of the nameplate are only present when the motor has been certified accordingly or when it includes the relevant components.

3.6.1 DRE.. motor nameplate


The following figure shows an example of a nameplate:



13201624459

- [1] Serial number
- [2] Nominal frequency
- [3] Nominal current/operating mode
- [4] Power factor for AC motors
- [5] Temperature class
- [6] Nominal speed
- [7] Weight
- [8] Number of phases and underlying rating and power standards (IEC 60034-X and/or equivalent national standard).
- [9] IE class and nominal efficiency for motors included in the scope of the standard IEC 60034-30
- [10] IP degree of protection according to IEC 60034-5
- [11] Nominal voltage
- [12] Nominal current

3.6.2 DRE.. global nameplate



9007207468121227

3.6.3 "Use with variable speed drive only" marking

Motors with this marking may, according to Commission Regulation 640/2009, only be operated with a frequency inverter (VSD = Variable Speed Drive).



13229219723

3.6.4 Type designation

DR../DRN.. AC brakemotor type designation

The following diagram shows a type designation example:

AC motor of the DR../DRN.. series		
Series	DR	
Type identifier	S	E, P, N, U, K, M, L
Size	71	80, 90, 100, 112, 132, 160, 180, 200, 225, 250, 280, 315
Mounting position	S	K, M, L, MC, LC, SJ, MJ, LJ, ME, SE, H, LS
Number of poles	4	2, 6, 12, 4/2, 8/2, 8/4
Output options		
Output options	–	/FI, /FF, /FT, /FL, /FG, /FM, /FE, /FY, /FC, /F., /F.A, /F.B
Mechanical attachments		
Brakes	–	BE05, BE1, BE2, BE5, BE11, BE20, BE30, BE32, BE60, BE62, BE120, BE122,
Manual brake release	–	HF, HR
Backstop	–	/RS
Decentralized installation	–	/MI, /MO, /MSW, /MM03, /MM05, /MM07, /MM11, /MM15, /MM22, /MM30, /MM40
Temperature sensor / temperature detection		
Thermal motor protection	–	/TF, /TH
Temperature detection	–	/KT, /PT
Encoders		
Built-in encoder	–	/EI7. B, /EI7C FS..
Add-on encoder DR..71 – 132	–	/ES7., /AS7., /EV2., /AV1.
Add-on encoder DR..160 – 280	–	/EG7., /AG7., /EV2., /AV1.
Add-on encoder DR..315	–	/EH7., /AH7.
Mounting adapter	–	/ES7A, /EG7A, /XV.A, /XH.A
Storage		
Isolated bearing	–	/NIB
Relubrication	–	/NS
Increased overhung load	–	/ERF
Connection alternatives		
Connection alternatives	–	/IS, /ISU, /AB., /AC., /AD., /AK., /AM., /AS., /KCC, /KC1, /IV
Ventilation		
Low noise fan guard	–	/LN
Fan guard	–	/C, /LF
Fan	–	/Z, /AL, /U, /OL
Forced cooling fan	–	/N, /VE
Additional options		
Condition monitoring	–	/DUB, /DUE (in preparation)
2nd shaft end	–	/2W
Reinforced winding insulation	–	/RI, /RI2
Condensation drain hole	–	/DH

Designation of the motors

Designation	
DRS..	Standard motor, Standard Efficiency IE1
DRE..	Energy-efficient motor, High Efficiency IE2
DRP..	Energy-efficient motor, Premium Efficiency IE3
DRN..	Energy-efficient motor, Premium Efficiency IE3
DRL..	Asynchronous servomotor
DRK..	Single-phase operation with running capacitor
DRM..	Torque motor: AC motor for operation at speed $n = 0$
DR..J	Line start permanent magnet motor
71 – 315	Sizes: 71 / 80 / 90 / 100 / 112 / 132 / 160 / 180 / 200 / 225 / 315
K, S, M, L, MC, LC ME, SE, H, LS	Lengths
2, 4, 6, 8/2, 8/4, 4/2, 12	Number of poles

3.7 Additional features

3.7.1 Output variants

Designation	Option
/FI	IEC foot-mounted motor with specification of shaft height
/F.A, /F.B	Universal foot-mounted variant with specification of shaft height
/FG	7-series integral motor, as stand-alone motor
/FF	IEC flange-mounted motor with bore
/FT	IEC flange-mounted motor with threads
/FL	General flange-mounted motor (other than IEC)
/FM	7 series integral gearmotor with IEC feet, with specification of shaft height if required
/FE	IEC flange-mounted motor with bore holes and IEC feet, with specification of shaft height
/FY	IEC flange-mounted motor with thread and IEC feet, with specification of shaft height if required
/FK	General flange-mounted motor (other than IEC) with feet, with specification of shaft height if required
/FC	C-face flange-mounted motor, dimensions in inch

3.7.2 Mechanical attachments

Designation	Option
BE..	Spring-loaded brake with specification of size
HR	Manual brake release of the brake, automatic disengaging function
HF	Manual brake release, lockable
/RS	Backstop
/MSW	MOVI-SWITCH®
/MI	Motor identification module for MOVIMOT®
/MM03 – MM40	MOVIMOT®
/MO	MOVIMOT® option(s)

3.7.3 Temperature sensor / temperature detection

Designation	Option
/TF	Temperature sensor (PTC thermistor or PTC resistor)
/TH	Thermostat (bimetallic switch)
/KY	1 KTY84 – 130 sensor
/PT	1 / 3 PT100 sensor(s)

3.7.4 Encoder

Designation	Option
/ES7S /EG7S /EH7S /EV7S	Mounted speed sensor with sin/cos interface
/ES7R /EG7R /EH7R	Mounted speed sensor with TTL (RS-422) interface, V = 9 – 26 V
/EI7C B	Built-in incremental encoder with HTL interface
/EI7C FS..	Safety-rated incremental encoder (marked with FS logo on the motor nameplate) For detailed information, see "Safety-Rated Encoders – Functional Safety for AC Motors DR.71 – 315" addendum to the operating instructions
/EI76 B /EI72 B /EI71 B	Built-in incremental encoder with HTL interface and 6 / 2 / 1 period(s)
/AS7W /AG7W	Mounted absolute encoder, RS-485 interface (multi-turn)
/AS7Y /AG7Y /AH7Y	Mounted absolute encoder, SSI interface (multi-turn)
/ES7A /EG7A	Mounting adapter for speed sensors
/EV2T /EV2R /EV2S /EV2C	Mounted incremental encoder with solid shaft
/XV.A	Mounting adapter for non-SEW speed sensors
/XV..	Mounted non-SEW speed sensors

3.7.5 Connection alternatives

Designation	Option
/IS	Integrated plug connector
/ASE.	HAN 10ES plug connector on terminal box with single locking latch (cage clamp contacts on the motor side)
/ASB.	HAN 10ES plug connector on terminal box with double locking latch (cage clamp contacts on the motor side)
/ACE.	HAN 10E plug connector on terminal box with single locking latch (crimp contacts on the motor side)
/ACB.	HAN 10E plug connector on terminal box with double locking latch (crimp contacts on the motor side)
/AME. /ABE. /ADE. /AKE.	HAN Modular 10B plug connector on terminal box with single locking latch (crimp contacts on the motor side)
/AMB. /ABB. /ADB. /AKB.	HAN Modular 10B plug connector on terminal box with double locking latch (crimp contacts on the motor side)
/KCC	6 or 10-pole terminal strip with cage clamp contacts
/KC1	C1 profile compliant connection of the electrified monorail drive (VDI guideline 3643). Alternative for a compact connection area.

Designation	Option
/IV	Other industrial plug connectors according to customer specifications

3.7.6 Ventilation

Designation	Option
/V	Forced cooling fan
/VH	Radial fan on fan guard
/Z	Additional inertia (flywheel fan)
/AL	Metal fan
/U	Non-ventilated (without fan)
/OL	non-ventilated (closed B end)
/C	Protection canopy for fan guard
/LF	Air filter
/LN	Low noise fan guard

3.7.7 Bearing

Designation	Option
/NS	Lubrication device
/ERF	Reinforced bearings on A-side with roller bearing
/NIB	Insulated bearing B-side

3.7.8 Condition monitoring

Designation	Option
/DUB	Diagnostic unit brake = brake monitoring
/DUE	Diagnostic unit eddy current = function and wear monitoring (in preparation)

3.7.9 Other additional features

Designation	Option
/DH	Condensation drain hole
/RI	Reinforced winding insulation
/RI2	Reinforced winding insulation with increased resistance against partial discharge
/2W	Second shaft end on the motor/brakemotor

3.7.10 Explosion-proof motors

Designation	Option
/2GD	Motors according to 94/9/EC, category 2 (gas / dust)
/3GD	Motors according to 94/9/EC, category 3 (gas / dust)
/3D	Motors according to 94/9/EC, category 3 (dust)
/VE	Forced cooling fan for motors according to 94/9/EC, category 3 (gas / dust)

Explosion-proof motors are dealt with in separate operating instructions.

4 Mechanical installation

INFORMATION



Observe the safety notes in chapter 2 of these operating instructions for the mechanical installation.

If the nameplate of the drive bears the FS mark, also comply with the information on mechanical installation in the associated addenda to the operating instructions and/or the associated manual.

4.1 Before you start



NOTICE

The mounting position for installation must correspond to the specifications on the nameplate.

Only install the drive if the following conditions are met:

- The data on the nameplate of the drive corresponds with the voltage supply system or with the output voltage of the frequency inverter
- The drive is undamaged (no damage caused by transportation or storage)
- All transport protection has been removed
- You are certain that the following requirements have been met:
 - Ambient temperature between -20°C and +40°C

Note that the temperature range of the gear unit may also be restricted (see gear unit operating instructions)

Note that information on the nameplate may differ. It is essential that the operating conditions for the unit comply with the nameplate information.

- No oil, acid, gas, vapors, radiation, etc.
- Installation altitude max. 1000 m above sea level
- Observe chapter Installation altitude (→ 63).


- Note the limitations for encoders
- Special design: Drive configured in accordance with the ambient conditions.

The above mentioned information refers to standard orders. The conditions might be different when you order drives other than the standard. Observe any differing conditions in the order confirmation.

4.2 Extended storage of motors

- Note that the service life of the lubricant in the ball bearings is reduced by 10% per year after the first year of storage.
- Before startup, you should re-lubricate the lubrication devices on motors that have been in storage for longer than 5 years. Observe the information on the motor lubricant plate.
- Check whether the motor has absorbed moisture as a result of being stored for a long time. Measure the insulation resistance for this purpose (measuring voltage 500 V).

The insulation resistance (see following figure) varies greatly depending on the temperature. The motor must be dried if the insulation resistance is not adequate.



173323019

4.2.1 Drying the motor

Heating the motor either with warm air or via an isolation transformer:

- With warm air
DR.. motors with rotor designation "J" may be dried with warm air only.


⚠ WARNING



The motor shaft may be subject to torque when drying via isolation transformer.
Possible injury.


- DR.. motors with rotor designation "J" may be dried with warm air only.

Connection with wiring diagram R13:



2336250251


[1] Transformer

Connection with wiring diagram R72:

2343045259

[1] Motor terminal boards

[2] Transformer

Connection with wiring diagram R76:

2343047179

[1] Motor terminal boards

[2] Transformer

The drying process is finished when the minimum insulation resistance has been exceeded.

In the terminal box, make sure that:

- The inside is clean and dry
- The connections and fixing parts are free from corrosion
- The gasket and sealing surfaces are in good condition
- The cable glands are tight, otherwise clean or replace them
- Using an isolation transformer
 - Connect the windings in series (see following figures)
 - Auxiliary AC voltage supply max. 10% of the nominal voltage with max. 20% of the rated current

4.3 Motor installation notes



⚠ CAUTION

Sharp edges due to open keyway.

Minor injuries.

- Insert key in keyway.
- Pull protective sleeve over shaft.



NOTICE

Improper assembly may damage the drive and corresponding components.

Possible damage to property.

- Observe the following notes.
- Motor shaft ends must be thoroughly cleaned of anti-corrosion agents, contamination or similar (use a commercially available solvent). Do not allow the solvent to penetrate the bearings or sealing rings – this could damage the material.
- Only install the gearmotor in the specified mounting position on a level, vibration-free and torsionally rigid support structure.
- Align the motor and the driven machine carefully in order to prevent the output shaft from being exposed to unacceptable strain. Observe the permitted overhung and axial forces.
- Do not jolt or hammer the shaft end.
- Use an appropriate cover, e.g. motor option /C "Canopy", to prevent objects or fluids entering motors in vertical mounting positions (M4/V1).
- Check that there is sufficient clearance around the motor to provide for adequate cooling, and that the motor does not suck in warm air from other devices.
- Balance components for subsequent mounting on the shaft with a half key (motor shafts are balanced with a half key).
- **Existing condensation drain holes are sealed with closing plugs. If contaminated, the condensation drain holes must be checked for proper functioning on a regular basis and cleaned if required.**
- If using brakemotors with manual brake release, screw in either the hand lever (with self-reengaging manual brake release) or the set screw (with lockable manual brake release).
- Protect shaft again against corrosion, if necessary.



INFORMATION

To install motors with a foot made of aluminum, you have to use washers with at least twice the bolt diameter. Use bolts of strength class 8.8. Do not exceed the tightening torque according to VDI 2230-1.

4.3.1 Installation in damp locations or outdoors

- Use suitable cable glands for the incoming cable (use reducing adapters if necessary) according to the installation instructions.
- If possible, arrange the terminal box in such a way that the cable entries are pointing downwards.

- Seal the cable entry properly.
- Clean the sealing surfaces of the terminal box and the terminal box cover carefully before re-assembly; replace embrittled gaskets.
- If required, touch up the corrosion protection (especially at the eyebolts).
- Check the degree of protection.
- Protect the shaft against corrosion using a suitable anti-corrosion agent.

4.4 Installation tolerances

Shaft end	Flanges
Diameter tolerance according to EN 50347 <ul style="list-style-type: none"> • ISO j6 with $\varnothing \leq 28$ mm • ISO k6 with $\varnothing \geq 38$ mm up to ≤ 48 mm • ISO m6 at $\varnothing \geq 55$ mm • Center bore in accordance with DIN 332, shape DR.. 	Centering shoulder tolerance in accordance with EN 50347 <ul style="list-style-type: none"> • ISO j6 with $\varnothing \leq 250$ mm • ISO h6 with $\varnothing \geq 300$ mm

4.5 Assembling the input elements

Drive components that are installed on the motor shaft end, e.g. pinions, must be warmed up prior to assembly in order to prevent damage, e.g. to the encoder of stand-alone motors.

4.6 HR/HF manual brake release

4.6.1 HF manual brake release

You can use the optional lockable HF manual brake release to continuously mechanically release the BE.. brake with a set screw and a releasing lever.

On delivery, the set screw is inserted far enough to not fall out and to not affect the brake performance. The set screw is self-locking with a nylon coat in order to prevent it from unintended further penetration or from falling out.

Proceed as follows to activate the lockable HF manual brake release:

- Screw in the set screw until there is no more clearance at the releasing lever. Additionally, screw in the set screw by another 1/4 or 1/2 revolution in order to manually release the brake.

Proceed as follows to loosen the lockable HF manual brake release:

- Loosen the set screw at least until the floating clearance (see chapter Retrofitting HR/HF manual brake release (→ 38)) of the manual brake release has completely returned.



⚠ WARNING

Lacking functionality of the manual brake release due to improper brake installation, e.g. set screw inserted too far.

Severe or fatal injuries.

- Only qualified staff may perform work on the brake.
- Check the brake for proper function prior to startup.

4.6.2 Retrofitting HR/HF manual brake release




⚠ WARNING

Risk of crushing if the drive starts up unintentionally.
Severe or fatal injuries.

- Isolate the motor, brake, and forced cooling fan, if installed, from the power supply before starting work, safeguarding them against unintentional re-start.
- Carefully observe the following steps!

1. Remove the following:
 - Forced cooling fan and incremental encoder (if installed)
See chapter "Motor and brake maintenance – preliminary work" (→ 104)
 - Flange cover or fan guard [35], circlip [32] and fan [36]
2. Installing manual brake release:
 - **For BE05 – BE11:**
 - Remove the sealing ring [95]
 - Screw in and glue studs [56], insert sealing ring for manual brake release [95] and hammer in parallel pin [59].
 - Mount releasing lever [53], conical springs [57] and adjusting nuts [58].
3. Use adjusting nuts to set the floating clearance "s" between the conical springs (pressed flat) and the adjusting nuts (see the following figure).

The floating clearance "s" is necessary so that the pressure plate can move up as the brake lining wears. Otherwise, reliable braking is not guaranteed.



177241867

Brakes	Floating clearance s mm
BE05, BE1, BE2, BE5	1.5
BE11, BE20, BE30, BE32, BE 60, BE62, BE120, BE122	2

4. Reassemble the removed parts.


4.7 Non-SEW encoder mounting

If a drive was ordered with non-SEW encoder, SEW-EURODRIVE will deliver the drive with enclosed coupling. You must not connect the coupling for operation without non-SEW encoder.

4.8 Mounting the XV.A encoder mounting adapter on DR..71 – 225, DRN80 – 225 motors

If you have ordered the XV.A encoder mounting adapter, the adapter and the coupling are enclosed with the motor upon delivery and must be installed by the customer.

The following figure shows how to assemble the coupling and the adapter:



3633163787

[22] Screw	[361] Cover
[170] Forced cooling fan guard	[269] Grommet
[212] Fan guard with encoder mount	[A] Adapter
[220] Encoders	[B] Retaining screw
[225] Intermediate flange (not with XV1A)	[C] Central retaining screw
[232] Screws (only for XV1A and XV2A)	[D] Coupling (spread or solid shaft coupling)
[251] Conical spring washers (only for XV1A and XV2A)	[E] Retaining screw
	[F] Screw


1. If available, remove extended fan guard [361] or forced cooling fan guard [170].
2. **For XV2A and XV4A:** Remove intermediate flange [225].
3. Screw the coupling [D] using the screw [C] into the encoder bore on the motor shaft.
DR..71 – 132, DRN80 – 132S: Tighten the screw [C] with a tightening torque of 3 Nm [26.6 lb-in].
DR..160 – 225, DRN132M – 225: Tighten the screw [C] with a tightening torque of 8 Nm [70.8 lb-in].
4. Mount the adapter [A] onto the encoder [220] and tighten the retaining screw [B] with a tightening torque of 3 Nm [26.6 lb-in].

5. **For XV2A and XV4A:** Mount the intermediate flange [225] with the screw [F] with a tightening torque of 3 Nm [26.6 lb-in].
6. Mount the encoder together with the adapter on the coupling [D] and tighten the retaining screw [E] with a tightening torque of 3 Nm [26.6 lb-in].
7. **For XV1A and XV2A:** Arrange conical spring washers [251] with retaining screws [232] and place in annular groove of the encoder [220] and tighten with a tightening torque of 3 Nm (26.6 lb-in).
8. **For XV3A and XV4A:** Installation by the customer via the bores in the encoder plate.

4.9 Mounting an encoder with EV.A / AV.A mounting adapter to DR..250 – 280, DRN250 – 280 motors

If you have ordered the EV.A / AV.A encoder mounting adapter, the coupling is enclosed with the motor upon delivery and must be installed by the customer.

The following figure shows an example of how the coupling is installed:



9007206970704907

[22] Screw	[361] Extended fan guard (normal/long)
[33] Washer	[1458] Screw
[34] Screw	[1459] Cage nut
[35] Fan guard	[1460] Serrated lock washer
[220] Encoders	[1461] Washer
[225] Intermediate flange (optional)	[1462] Screw
[226] Screw	[1489] Ground strap
[232] Screws (enclosed with .V1A and .V2A)	[1496] Serrated lock washer
[233] Coupling	[1497] Washer
[251] Conical spring washers (enclosed with .V1A and .V2A)	[1498] Screw
[269] Grommet	[A] Encoder mounting adapter

1. Remove extended fan guard [361], if installed. Loosen screws [34].
 - **With /V forced cooling fan option:** Remove forced cooling fan guard [170]. Loosen screws [22].
2. Push the coupling [233] with diameter 14 mm onto the pin of the encoder mounting adapter [A]. Tighten the screw of the coupling clamping hub [233] with 3 Nm (26.6 lb-in) through the slots in the encoder mounting adapter [A].
3. **With option EV2/3/4/5/7A, AV2/3/4/5/7A:** Mount the intermediate flange [225] to the encoder mounting adapter [A] with screws [226]. The tightening torque must be 3 Nm (26.6 lb-in).
4. Mount the conical spring washers [251] to the encoder mounting adapter [A] with screws [232]. Do not tighten the screws [232] yet.

5. Mount the encoder [220] to the encoder mounting adapter [A] or intermediate flange [225]. Insert the encoder shaft [220] into the coupling [233]. Insert the conical spring washers into the socket of the encoder [220] and tighten the screws [232] with 3 Nm (26.6 lb-in). Tighten the screw of the coupling clamping hub [233] on the encoder end with 3 Nm (26.6 lb-in).
6. Pull the cable of the encoder [220] through the cable grommet [269]. Insert the cable grommet [269] into the extended fan guard [361].
 - **With /V forced cooling fan option:** Insert the cable grommet into the forced cooling fan guard [170].
7. Mount the extended fan guard to the fan guard with screws [34] and washers [33].
 - **With /V forced cooling fan option:** Mount the forced cooling fan guard [170] with screws [22].


4.9.1 XH.A encoder mounting adapter

The XH1A, XH7A and XH8A encoder mounting adapters for hollow shaft encoders are premounted on delivery.

Proceed according to chapter "Motor and brake maintenance – preliminary work" (→ 104) to mount the encoder.

4.10 Turning the terminal box

The following figure shows the structure of the terminal box variant with terminal board:



7362206987

- | | |
|--|--|
| [111] Gasket | [a] Terminal |
| [119] Retaining screws
for terminal box (4 x) | [b] Retaining screws
for auxiliary terminal (2 x) |
| [123] Retaining screws
for terminal box (4 x) | [c] Retaining plate |
| [131] Gasket | |

Proceed as follows to turn the terminal box:

1. Loosen the screws [123] from the terminal box cover and remove the cover.
2. Remove terminals [a], if installed.
3. Remove the retaining screws [119] of the terminal box.
4. Clean the sealing surfaces at the stator shoulder, the bottom and the cover of terminal box.
5. Check the gaskets [111 and 131] for damages and replace them if necessary.
6. Position the terminal box as desired. Refer to the appendix for the arrangement of the auxiliary terminals.
7. Tighten the screws on the terminal box lower part with the following tightening torques:
 - **DR..71 – 132, DRN80 – 132S:** 5 Nm (44.3 lb-in)
 - **DR..160 – 225, DRN132M – 225:** 25.5 Nm (225.7 lb-in)


Do not forget the retaining plate [c], if present.
8. Tighten the screws on the terminal box cover with the following tightening torques:
 - **DR..71 – 132, DRN80 – 132S:** 4 Nm (35.4 lb-in)
 - **DR..160, DRN132M/L:** 10.3 Nm (91.2 lb-in)

- **DR..180 – 225, DRN160 – 225 (aluminum variant):** 10.3 Nm (91.2 lb-in)
- **DR..180 – 225, DRN160 – 225 (gray-cast iron variant):** 25.5 Nm (225.7 lb-in)

Make sure the gasket is seated properly.

4.11 Retrofitting (option /F.A) or modifying (option /F.B) motor feet

The following figure shows a DR..280 motor with option /F.A (retrofit feet).



9007207281681547


[16] Stator
[90] Foot

[1457] Set screw
Remove the paint from the marked surfaces

The tapped holes of the foot mounting surfaces are closed with set screws [1457]. The contact surfaces at the feet [90] and stator [16] are painted.


1. Remove the set screws [1457]. Only remove the set screws from those threads into which you will screw in the foot screws [94].
2. Remove the paint from the contact surfaces of the stator [16] (see marking in the "Example illustration of DR..280" above). SEW-EURODRIVE recommends using a chisel or flat scraper for this purpose. Remove the paint only from those surfaces to which the feet will be mounted. Refer to the illustration "Terminal box positions" below for selecting the contact surfaces. A thin corrosion protection agent can be applied to the contact surfaces once the paint has been removed.

The possible terminal box positions are shown below:



9007211165643403

3. Remove the paint from the contact surfaces of the feet [90] (see marking in the "Example illustration of DR..280" above). SEW-EURODRIVE recommends using a chisel or flat scraper for this purpose. A thin corrosion protection agent can be applied to the contact surfaces once the paint has been removed.
4. Attach the feet [90] to the motor using the screws [94] and washers [93]. The tightening torque for the screws [94] must be 410 Nm (3628 lb-in). The screws are microencapsulated. This is why you have to screw in and tighten the screws quickly.
5. If necessary, you can apply paint or corrosion protection at the parting line after attaching the feet [90].



7741968395

[16] Stator
[90] Foot

[93] Washer
[94] Screw

When re-installing the feet in another position, observe the following:

- After removing the screws [94], check them for damage, e.g. to the thread.
- Remove the old microencapsulation.
- Clean the thread of the screws [94].
- Apply a high-strength thread locker to the screw threads before inserting the screws [94] again.
- The set screws removed from the new mounting position can be reused in the bores at the old mounting position. If necessary, you can apply paint or a corrosion protection agent to the bare joining surfaces on the stator, after screwing the set screws [1457] into the open tapped holes in the stator [16].

4.12 Accessory equipment

4.12.1 Air filter LF

The air filter, a kind of fleece mat, is mounted in front of the fan grille. It can be easily removed and mounted again for cleaning purposes.

The air filter avoids that dust and other particles drawn in by the air are distributed. It also prevents the ducts between the cooling fins from becoming clogged with dust.

In very dusty environments, the air filter protects the cooling fins from dirt or from becoming clogged.

The air filter must be cleaned or replaced depending on the amount of dust in the environment. No maintenance intervals can be specified due to the individuality of each drive and the environment where it is installed.


Technical data	Air filter
Certifications	All certifications
Ambient temperature	-40 °C to +100 °C
Suitable for the following motor sizes:	DR.71 – 132
Filter material	Viledon PSB290SG4 fleece

4.12.2 Mounting adapter for measuring nipple

Depending on the respective order specifications, SEW-EURODRIVE delivers the drives as follows:

- with bore
- with bore and enclosed measuring nipples

The following figure shows a motor with bores and inserted measuring nipples [1]:



2706206475

[1] Bore with inserted measuring nipples

Proceed as follows to connect the customer measuring device:

- Remove the protective plugs from the bores.
- Insert the measuring nipple in the bores of the motor and screw in the measuring nipple with a tightening torque of 15 Nm (133 lb-in).
- Plug the mounting adapter of the measuring unit into the measuring nipple.

4.12.3 2nd shaft end with optional cover

SEW-EURODRIVE delivers the optional equipment "Second shaft end" with inserted key (additionally secured with adhesive tape) as standard. No cover is supplied as standard. The cover can be ordered optionally for sizes DR..71 – 280, DRN80 – 280.

INFORMATION




The motor may only be operated when the key has been suitably secured.

The following figure shows the dimensions of the covers:

Sizes DR..71 – 132, DRN80 – 132S, DR..250 – 280, DRN..
250 – 280

Sizes DR..160 – 225, DRN132M – 225

Sizes DR..160 – 225, DRN132M – 225 (optional)



3519591947

[4] Keyway
[34] Tapping screw
[79] Cap

[83] Hex head screw
[361] Extended fan guard
[1553] Cage nut

LB/LBS Length of the motor/brake-motor

1) Refer to the catalog for dimensions

Dimensions

Motor size		DA	EA	L1	L2	L3	L4	X
DR..	DRN..							
DR..71	–	11	23	2	–	2	–	91.5
DR..71 /BE	–				–		–	88
DR..80	DRN..80	14	30	2	–	2	–	95.5
DR..80 /BE	DRN..80 /BE				–		–	94.5
DR..90	DRN..90	14	30	2	–	2	–	88.5
DR..90 /BE	DRN..90 /BE				–		–	81
DR..100	DRN..100	14	30	2	–	2	–	87.5
DR..100 /BE	DRN..100 /BE				–		–	81
DR..112 – 132	DRN..112 – 132S	19	40	3.5	–	3.5	–	125
DR..112 – 132 /BE	DRN..112 – 132S /BE				–		–	120.5
DR..160	DRN..132M/L	28	60	4	122	3.5	124	193
DR..160 /BE	DRN..132M/L /BE							187
DR..180	DRN..160 – 180	38	80	4	122	3.5	122	233
DR..180 /BE	DRN..160 – 180 /BE							236
DR..200 – 225	DRN..200 – 225	48	110	5	122	5	122	230
DR..200 – 225 /BE	DRN..200 – 225 /BE							246
DR..250 – 280	DRN..250 – 280	55	110	3	–	3	–	243.5
DR..250 – 280 /BE	DRN..250 – 280 /BE							

5 Electrical installation

If the motor includes safety-relevant components, observe the following safety note:



⚠ WARNING

Disabling functional safety devices.

Severe or fatal injuries.

- Only qualified personnel is allowed to carry out work on functional safety components.
- Any work on functional safety components must be carried out strictly in accordance with the specifications in the operating instructions at hand and the respective addendum to the operating instructions. Else, the right to claim under warranty will become invalid.



⚠ WARNING

Risk of injury due to electric shock.

Severe or fatal injuries.

- Observe the following notes.
- It is essential to comply with the safety notes in chapter 2 during installation!
- Switch contacts in utilization category AC-3 to EN 60947-4-1 must be used for switching the motor and the brake.
- Use switch contacts in utilization category DC-3 according to EN 60947-4-1 for switching the brake with DC 24 V.
- When motors are powered by inverters, you must adhere to the wiring instructions issued by the inverter manufacturer.
- Observe the operating instructions of the inverter.

5.1 Additional regulations

The generally applicable installation regulations for low-voltage electric equipment (such as DIN IEC 60364, DIN EN 50110) must be complied with when setting up electrical machinery.

5.2 Wiring diagrams and terminal assignment diagrams

Connect the motor only as shown in the wiring diagram(s) included with the motor. Do not connect or start up the motor if the wiring diagram is missing. The applicable wiring diagrams are available from SEW-EURODRIVE free of charge.

5.3 Wiring notes

Adhere to the safety notes during installation.

5.3.1 Protecting the brake control system against interference

Brake cables must always be routed separately from other unshielded power cables with phased currents to prevent interference with brake control. In particular, power cables with phased currents include:

- Output cables from frequency inverters and servo inverters, soft-start units and brake units
- Incoming cables for braking resistors and similar options

For line-operated motors and when using AC and DC circuit cut-off, the connection between the brake rectifier and the external switch contact must be in a different power cable that is separate from the motor power supply.

5.3.2 Protecting the motor protection devices against interference

Adhere to the following points to protect SEW motor protection devices (TF temperature sensors) against interference:

- You may route separately shielded supply cables together with switched-mode power cables in one cable.
- Do not route unshielded supply cables together with switched-mode power lines in one cable.

5.4 Special aspects for operation with a frequency inverter


When motors are powered from inverters, you must observe the wiring instructions issued by the inverter manufacturer. You must also observe the operating instructions for the frequency inverter.

5.4.1 Motors with frequency inverters from SEW-EURODRIVE

We have tested operation of the motor on SEW-EURODRIVE frequency inverters. The required electric strength values of the motors were confirmed and the startup routines adjusted to the motor data. You can operate the DR../DRN.. motor with any frequency inverter from SEW-EURODRIVE. To do this, start up the motor as described in the operating instructions for the frequency inverter.

5.4.2 Motor with non-SEW inverter

Operating SEW-EURODRIVE motors on non-SEW frequency inverters is permitted if the pulse voltages at the motor terminals indicated in the following figure are not exceeded.



9007203235332235

- [1] Permitted pulse voltage for DR../DRN.. AC motors with reinforced insulation and increased resistance against partial discharge (/RI2)
- [2] Permitted pulse voltage for DR../DRN.. AC motors with reinforced insulation (/RI)
- [3] Permitted pulse voltage according to NEMA MG1 part 31, $V_N \leq 500$ V
- [4] Permitted pulse voltage according to IEC 60034-25, limit value curve A for nominal voltage $V_N \leq 500$ V, star connection
- [5] Permitted pulse voltage according to IEC 60034-25, limit value curve A for nominal voltage $V_N \leq 500$ V, delta connection
- [6] Permitted pulse voltage according to IEC 60034-17
- [7] Voltage rise time
- [8] Permitted pulse voltage

The insulation class depends on the voltage.

- ≤ 500 V = standard insulation
- ≤ 600 V = /RI
- > 600 V = /RI2

**INFORMATION**

Compliance with the limit values must be checked and taken into account as follows:

- The supply voltage level at the non-SEW inverter
 - The threshold of the brake chopper voltage
 - The operating mode of the motor (motoring operation/regenerative operation)
- If the permitted pulse voltage is exceeded, limiting measures, such as filters, chokes, or special motor cables must be used. Contact the manufacturer of the frequency inverter for more information.
-

5.5 Exterior grounding at the terminal box, LF grounding

In addition to the interior PE connection, a LF (low frequency) grounding cable can be attached to the outside of the terminal box. LF grounding is not installed as standard.

LF grounding can be ordered as completely pre-installed at the factory. For DR..71 – 132, DRN80 – 132S motors, this requires a brake or gray cast iron terminal box. For DR..160 – 225, DRN132M – 225 motors, this option can be combined with all terminal box types.


The option can be combined with HF grounding (→ 56).

INFORMATION



All parts of the LF grounding kit are made from stainless steel.


DR..71 – 132, DRN80 – 132S



8024328587

[1] LF grounding at the terminal box

DR..160 – 225, DRN132M – 225



8026938379

[1] LF grounding at the terminal box

5.6 Improving the grounding (EMC), HF grounding

For improved, low-impedance grounding at high frequencies, we recommend using the following connections: SEW-EURODRIVE recommends using corrosion-resistant connection elements.

HF-ground is not installed as standard.

The HF-ground option can be combined with LF grounding at the terminal box.

If you require LF grounding in addition to HF-ground, you can connect the conductor to the same point.

The HF-ground option can be ordered as follows:

- Completely pre-installed at the factory, or as
- "Grounding terminal" kit for customer installation; part numbers listed in the following table.

Motor size	Part number of "Grounding terminal" kit
DR..71S/M	1363 3953
DR..80S/M, DRN80	
DR..90M/L, DRN90	
DR..100M, DRN100	
DR..100L – 132, DRN100 – 132S with aluminum terminal box	1363 3945
DR..160 – 225, DRN132M – 225 with aluminum terminal box	

INFORMATION



All parts of the kit are made from stainless steel.

INFORMATION




For further information regarding the grounding, refer to the SEW publication "Drive Engineering – Practical Implementation, EMC in Drive Engineering."

INFORMATION



If 2 or more ground straps are used, you have to attach them with a longer screw. The specified tightening torques refer to a strap thickness of $t \leq 3$ mm.


5.6.1 Sizes DR..71S/M, DR..80S/M and DRN80 with HF(+LF) grounding



8026768011

- | | |
|--|---|
| [1] Use of the pre-cast bore at the stator housing | [4] Ground strap (not included in the scope of delivery) |
| [2] Serrated lock washer | [5] Self-tapping screw DIN 7500 M6 x 16, tightening torque 10 Nm (88.5 lb-in) |
| [3] Washer 7093 | |


5.6.2 Sizes DR..90M/L, DRN90 with HF(+LF) grounding



8026773131

- | | |
|--|---|
| [1] Use of the pre-cast bore at the stator housing | [4] Ground strap (not included in the scope of delivery) |
| [2] Serrated lock washer | [5] Self-tapping screw DIN 7500 M6 x 16, tightening torque 10 Nm (88.5 lb-in) |
| [3] Washer 7093 | |


5.6.3 Sizes DR..100M, DRN100 with HF(+LF) grounding



18014402064551947

- | | |
|--|---|
| [1] Use of the pre-cast bore at the stator housing | [4] Ground strap (not included in the scope of delivery) |
| [2] Serrated lock washer | [5] Self-tapping screw DIN 7500 M6 x 16, tightening torque 10 Nm (88.5 lb-in) |
| [3] Washer 7093 | |


5.6.4 Sizes DR..100L – 132, DRN100 – 132S with HF(+LF) grounding



18014402064551947

- | | |
|---|---|
| [1] Use of tapped hole for lifting eyes | [4] Ground strap (not included in the scope of delivery) |
| [2] Serrated lock washer DIN 6798 | [5] Hex head screw ISO 4017 M8 x 18, tightening torque 10 Nm (88.5 lb-in) |
| [3] Washer 7089 / 7090 | |

5.6.5 Sizes DR..160 – 315, DRN132M – 315 with HF(+LF) grounding



9007202821668107

- [1] Use of the tapped holes at the terminal box
- [2] Serrated lock washer DIN 6798
- [3] Washer 7089 / 7090
- [4] Ground strap (not included in the scope of delivery)
- [5]
 - Hex head screw ISO 4017 M8 x 18 (with aluminum terminal boxes of sizes DR..160 – 225, DRN132M – 225), tightening torque 10 Nm (88.5 lb-in)
 - Hex head screw ISO 4017 M10 x 25 (with gray cast iron terminal boxes of sizes DR..160 – 225, DRN132M – 225), tightening torque 10 Nm (88.5 lb-in)
 - Hex head screw ISO 4017 M12 x 30 (terminal boxes of size DR../DRN250 – 315), tightening torque 15.5 Nm (137.2 lb-in)


5.7 Special aspects in switching operation

When the motors are used in switching operation, possible interference of the switch-gear must be excluded by ensuring suitable wiring. According to EN 60204 (electrical equipment of machines), motor windings must have interference suppression to protect the numerical or programmable logic controllers. As it is primarily switching operations that cause interference, SEW-EURODRIVE recommends installing protective circuit in the switching devices.

If the drive has been delivered with a suppressor circuit in the motor, you must observe the provided wiring diagram.

5.8 Special aspects of torque motors and low-speed motors

Due to the design of torque motors and low-speed motors, very high induction voltages may be generated when they are switched off. Consequently, SEW-EURODRIVE recommends using the varistor circuit shown below for protection. The size of the varistors depends, among other factors, on the starting frequency – note the project planning.




2454566155

5.9 Special aspects of single-phase motors

Scope of delivery and motor design

DRK.. AC motors are delivered with installed running capacitor in the terminal box. Starting relay, centrifugal switch and start-up capacitor are not supplied.



[112]	Terminal box	[277]/ [1667]	Capacitor
[1660]	Gasket	[132]	Terminal box cover
[1659]	Adapter piece	[123]	Screw
[131]	Gasket		

5.9.1 Connecting the single-phase motor




⚠ WARNING

Electric shock due to charged capacitor.

Severe or fatal injuries

- After disconnection from the power supply, wait 5 seconds before opening the terminal box.

The DRK.. single-phase motor is delivered with one or two installed and connected running capacitors. The data specified in the chapter Technical Data (→  175) apply.




INFORMATION

If a running capacitor installed by SEW-EURODRIVE must be replaced, only use capacitors with the same technical data.



INFORMATION

A full-load start using only the running capacitors is not possible.

Parts which are not supplied must be ordered from specialist retailers and must be connected according to the corresponding instructions and wiring diagrams (→  198).

Proceed as follows during connection:

- Remove terminal box cover [132]
- Remove adapter piece [1659] with the running capacitors [277]/[1667]
- Connection according to supplied wiring diagrams.

5.10 Ambient conditions during operation

5.10.1 Ambient temperature

The temperature range of -20 °C to +40 °C must be ensured unless specified otherwise on the nameplate. Motors approved for use in higher or lower ambient temperatures have specific designations on the nameplate.

5.10.2 Installation altitude

The rated data specified on the nameplate applies to an installation altitude of maximum 1000 m above sea level. Installation altitudes of more than 1000 m above sea level must be taken into account for project planning of motors and gearmotors.

5.10.3 Hazardous radiation

Motors must not be subjected to hazardous radiation (such as ionizing radiation). Consult SEW-EURODRIVE, if necessary.

5.10.4 Hazardous gases, vapors and dusts

The DR../DRN.. AC motors are equipped with gaskets that are suitable for the designated use.

If the motor is operated in environments with high environmental impact, such as increased ozone values, the DR../DRN.. motors can be optionally equipped with gaskets of a higher quality. If you have doubts regarding the stability of the gaskets in connection with the respective environmental impacts, consult SEW-EURODRIVE.

5.11 Notes regarding the connection of the motor**INFORMATION**

It is essential to comply with the valid wiring diagram. Do not connect or start up the motor if this wiring diagram is missing. The applicable wiring diagrams are available from SEW-EURODRIVE free of charge.

INFORMATION

The terminal box must be free from foreign objects, dirt and humidity. Unused cable entry openings and the terminal box itself must be closed so they are dust and water-proof.


Observe the following points when connecting the motor:

- Check cable cross section
- Arrange terminal links correctly
- Screw on the connections and the PE conductor correctly
- Make sure that the connection cables are not cramped to avoid damage to the cable insulation.
- Observe air gaps, see chapter "Electrical connection"
- In the terminal box: Check winding connections and tighten them if necessary
- Perform the connection in accordance with the enclosed wiring diagram
- Avoid protruding wire ends
- Connect the motor according to the prescribed direction of rotation

5.12 Connecting the motor via terminal block

5.12.1 According to wiring diagram R13


Arrangement of terminal links for Δ connection



9007199493673739


Arrangement of terminal links for Δ connection

Motor sizes DR..71 – 280, DRN80 – 280:
(Single-sided supply)



9007199493672075

Motor sizes DR../DRN250 – 315:
(Double-sided supply)



9007199734852747

[1] Terminal link
[2] Terminal stud
[3] Flange nut

[4] Terminal board
[5] Customer connection
[6] Customer connection with split connection cable


INFORMATION




For DR../DRN250 – 315 motors, SEW-EURODRIVE recommends a double-sided supply for load currents higher than

- M12: 250 A
- M16: 315 A

5.12.2 According to wiring diagram R76

Arrangement of terminal links for Δ connection

2319075083

Arrangement of terminal links for Y connection

2336359819

[1] Terminal link
[2] Terminal stud
[3] Flange nut

[4] Terminal board
[5] Customer connection

INFORMATION



Three winding lead ends must be rewired to change from high to low voltage:


The lines designated U3 (T7), V3 (T8) and W3 (T9) must be reconnected.

- U3 (T7) from U2 (T4) to U1 (T1)
- V3 (T8) from V2 (T5) to V1 (T2)
- W3 (T9) from W2 (T6) to W1 (T3)

→ Changing from low to high voltage is carried out in reverse order. In both cases, the customer connection is made to U1 (T1), V1 (T2) and W1 (T3). You can change the direction of rotation by interchanging 2 supply cables.

5.12.3 According to wiring diagram R72

Arrangement of terminal links for Δ connection



5.12.4 Connection variants via terminal block

The motors are supplied and connected in different ways depending on the electrical design. Arrange the cables and terminal links as shown in the wiring diagram and screw them on firmly. Observe the tightening torques specified in the following tables.

Motor sizes DR..71 – 100, DRN80 – 100:							
Terminal stud	Tightening torque of hex nut	Connection	Design	Connection type	Scope of delivery	PE connecting screw	PE design
Ø		Cross section				Ø	
M4	1.6 Nm (14.2 lb-in)	≤ 1.5 mm ² (AWG 16)	1a	Solid wire Conductor end sleeve	Pre-assembled terminal links	M5	4
		≤ 6 mm ² (AWG 10)	1b	Ring cable lug	Pre-assembled terminal links		
		≤ 6 mm ² (AWG 10)	2	Ring cable lug	Small connection accessories enclosed in bag		
M5	2.0 Nm (17.7 lb-in)	≤ 2.5 mm ² (AWG 14)	1a	Solid wire Conductor end sleeve	Pre-assembled terminal links		
		≤ 16 mm ² (AWG 6)	1b	Ring cable lug	Pre-assembled terminal links		
		≤ 16 mm ² (AWG 6)	2	Ring cable lug	Small connection accessories enclosed in bag		
M6	3.0 Nm (26.5 lb-in)	≤ 35 mm ² (AWG 2)	3	Ring cable lug	Small connection accessories enclosed in bag		

Motor sizes DR..112 – 132, DRN112 – 132S							
Terminal stud	Tightening torque of hex nut	Connection at customer site	Design	Connection type	Scope of delivery	PE connecting screw	PE design
Ø		Cross section				Ø	
M5	2.0 Nm (17.7 lb-in)	≤ 2.5 mm ² (AWG 14)	1a	Solid wire Conductor end sleeve	Pre-assembled terminal links	M5	4
		≤ 16 mm ² (AWG 6)	1b	Ring cable lug	Pre-assembled terminal links		
		≤ 16 mm ² (AWG 6)	2	Ring cable lug	Small connection accessories enclosed in bag		
M6	3.0 Nm (26.5 lb-in)	≤ 35 mm ² (AWG 2)	3	Ring cable lug	Small connection accessories enclosed in bag		

Motor sizes DR..160, DRN132M/L							
Terminal stud	Tightening torque of hex nut	Connection at customer site	Design	Connection type	Scope of delivery	PE terminal stud	PE design
Ø		Cross section				Ø	
M6	3.0 Nm (26.5 lb-in)	≤ 35 mm ² (AWG 2)	3	Ring cable lug	Small connection accessories enclosed in bag	M8	5
M8	6.0 Nm (53.1 lb-in)	≤ 70 mm ² (AWG 2/0)	3	Ring cable lug	Small connection accessories enclosed in bag	M10	5


Motor sizes DR...180 – 225, DRN160 – 225							
Terminal stud	Tightening torque of hex nut	Connection at customer site	Design	Connection type	Scope of delivery	PE terminal stud	PE design
Ø		Cross section				Ø	
M8	6.0 Nm (88.5 lb-in)	≤ 70 mm ² (AWG 3/0)	3	Ring cable lug	Small connection accessories enclosed in bag	M8	5
M10	10 Nm (88.5 lb-in)	≤ 95 mm ² (AWG 3/0)	3	Ring cable lug	Small connection accessories enclosed in bag	M10	5
M12	15.5 Nm (137.2 lb-in)	≤ 95 mm ² (AWG 3/0)	3	Ring cable lug	Small connection accessories enclosed in bag	M10	5

Motor size DR../DRN250 – 280							
Terminal stud	Tightening torque of hex nut	Connection at customer site	Design	Connection type	Scope of delivery	PE terminal stud	PE design
Ø		Cross section				Ø	
M10	10 Nm (88.5 lb-in)	≤ 95 mm ² (AWG 3/0)	3	Ring cable lug	Small connection accessories enclosed in bag	M12	5
M12	15.5 Nm (137.2 lb-in)	≤ 95 mm ² (AWG 3/0)	3	Ring cable lug	Small connection accessories enclosed in bag	M12	5

Motor size DR../DRN315							
Terminal stud	Tightening torque of hex nut	Connection at customer site	Design	Connection type	Scope of delivery	PE terminal stud	PE design
Ø		Cross section				Ø	
M12	15.5 Nm (137.2 lb-in)	≤ 95 mm ² (AWG 3/0)	3	Ring cable lug	Connection parts pre-assembled	M12	5
M16	30 Nm (265.5 lb-in)	≤ 120 mm ² (AWG 4/0)					

The designs in bold print apply to S1 operation for the standard voltages and standard frequencies according to the data in the catalog. Other variants may have different connections, for example, different terminal stud diameters and/or a different scope of delivery.

Variant 1a:




18014398598348939

- [1] External connection
- [2] Terminal stud
- [3] Flange nut

- [4] Terminal link
- [5] Terminal washer
- [6] Winding connection with Stocko connection terminal


Variant 1b:



9007199343605771

- | | | | |
|-----|---|-----|--|
| [1] | External connection with ring cable lug, according to DIN 46237 or DIN 46234, for example | [4] | Terminal link |
| [2] | Terminal stud | [5] | Terminal washer |
| [3] | Flange nut | [6] | Winding connection with Stocko connection terminal |


Variant 2



9007199440180363

- | | | | |
|-----|---|-----|--------------------|
| [1] | Terminal board | [5] | Bottom nut |
| [2] | Flange nut | [6] | Terminal washer |
| [3] | Terminal link | [7] | Winding connection |
| [4] | External connection with ring cable lug, according to DIN 46237 or DIN 46234, for example | | |


Variant 3



199641099

- | | | | |
|-----|---|-----|--|
| [1] | External connection with ring cable lug, according to DIN 46237 or DIN 46234, for example | [5] | Terminal link |
| [2] | Terminal stud | [6] | Bottom nut |
| [3] | Upper nut | [7] | Winding connection with ring cable lug |
| [4] | Washer | [8] | Serrated lock washer |


Variant 4




9007200394347659

- | | | | |
|-----|---------------|-----|----------------|
| [1] | Terminal box | [4] | Lock washer |
| [2] | Terminal clip | [5] | Hex head screw |
| [3] | PE conductor | | |

Variant 5



- [1] Hex nut
- [2] Washer
- [3] PE conductor on cable lug




- [4] Serrated lock washer
- [5] Stud
- [6] Terminal box

1139608587

5.13 Connecting the motor plug connector

5.13.1 IS plug connector



1009070219

The lower part of the IS plug connector is completely wired ex factory including the additional feature such as brake rectifier. The IS plug connector top is included in the scope of delivery and must be connected according to the specifications in the wiring diagram.



⚠ WARNING

No grounding due to incorrect installation.

Severe or fatal injuries.

- It is essential to comply with the safety notes in chapter 2 during installation.
- Tighten the retaining screws of the IS plug connector properly with 2 Nm (17.7 lb-in) as these screws also act as protective earth contacts.

The IS plug connector has CSA approval up to 600 V. Note for application according to CSA regulations: Tighten the M3 terminal screws to a torque of 0.5 Nm (4.4 lb-in). See the following table for American Wire Gauge (AWG) cable cross sections.

Cable cross section

Make sure the type of line corresponds to the applicable regulations. The rated currents are specified on the nameplate. The cable cross sections that can be used are listed in the following table.

Without variable terminal link	With variable terminal link	Link cable	Double assignment (motor and brake/SR)
0.25 – 4.0 mm ²	0.25 – 2.5 mm ²	max. 1.5 mm ²	max. 1 x 2.5 and 1 x 1.5 mm ²
AWG 24 – 12	AWG 24 – 14	max. AWG 16	max. 1 x AWG 14 and 1 x AWG 16

Wiring the upper section of the plug connector

- Loosen the housing cover screws:
 - Remove the housing cover
- Loosen the screws from the upper section of the plug connection:
 - Remove upper connector section from the cover
- Strip the insulation off the connection cable:
 - Strip off about 9 mm of insulation
- Pass the cable through the cable gland

Wiring up as shown in wiring diagram R83

- Connect the lines as shown in the wiring diagram:
 - Tighten the clamping screws carefully.
- Install the plug connector (see chapter Installing the connector (→ 77))


Wiring up as shown in wiring diagram R81

For ∇ Δ startup:

- Connect with 6 lines:
 - Tighten the clamping screws carefully.
 - Motor contactors in the control cabinet
- Install the plug connector (see chapter Installing the connector (→ 77))

For ∇ or Δ operation:

- Connect as shown in the wiring diagram
- Install the variable terminal link as shown in the following figures according to the required motor operation (∇ or Δ).
- Install the plug connector (see chapter Installing the connector (→ 77))




798606859



798608523

*Brake control system BSR – preparing the variable terminal link***For \curvearrowright operation:**


On the \curvearrowright side of the variable terminal link as shown in the following figure: Remove only the bare metal pin of the marked prong horizontally – touch guard!



798779147

For \triangle operation:


On the \triangle side of the variable terminal link as shown in the following figure: Completely remove two prongs horizontally.



798777483

Wiring according to the R81 wiring diagram for \curvearrowright or \triangle operation with double terminal assignment

- At terminal for double assignment:
 - Connect the link cable
- When operation is as required:
 - Insert the link cable in the variable terminal link
- Installing the variable terminal link
- At terminal for double assignment:
 - Connect the motor lead above the variable terminal link
- Connect the other lines as shown in the wiring diagram
- Install the plug connector (see chapter Installing the connector (→ 77))




798780811

Installing the plug connector


The housing cover of the IS plug connector can be screwed onto the lower housing part depending on the required position of the cable lead. The upper section of the plug connector shown in the following figure must first be installed in the housing cover so it will match the position of the lower section of the plug connector:

- Define the required mounting position
- Install the upper section of the plug connector into the housing cover in accordance with the mounting position
- Close the plug connector
- Tighten the cable gland





798978827

Mounting position of the upper section of the plug connector in the housing cover



798785163

5.13.2 AB..., AD..., AM..., AK..., AC..., AS.. plug connectors



1009065611

The installed AB..., AD..., AM..., AK..., AC.. and AS plug connector systems are based on the plug connector systems made by Harting.

- AB..., AD..., AM..., AK.. Han Modular®
- AC..., AS.. Han 10E / 10ES

The connectors are located at the side of the terminal box. They are locked either using two clamps or one clamp on the terminal box.

UL approval has been granted for the plug connectors.

The mating connector (sleeve housing) with socket contacts is not included in the scope of delivery.


The degree of protection is only applied when the mating connector is mounted and locked.

5.14 Connecting the motor via terminal strip

5.14.1 KCC terminal strip


- Perform the connection in accordance with the enclosed wiring diagram
- Check the maximum cable cross section:
 - 4 mm² (AWG 12) rigid
 - 4 mm² (AWG 12) flexible
 - 2.5 mm² (AWG 14) flexible with conductor end sleeve
- In the terminal box: Check winding connections and tighten them if necessary
- Strip 10 – 12 mm of insulation

Arrangement of terminal links for Δ connection



18014399506064139



Arrangement of terminal links for Δ connection





18014399506066059

5.14.2 KC1 terminal strip

- Perform the connection in accordance with the enclosed wiring diagram
- Check the maximum cable cross section:
 - 2.5 mm² (AWG 14) rigid
 - 2.5 mm² (AWG 14) flexible
 - 1.5 mm² (AWG 16) flexible with conductor end sleeve
- Strip 8 – 9 mm of insulation

Arrangement of terminal links for Δ connection

9007200257397387

Arrangement of terminal links for Δ connection

9007200257399307

5.15 Connecting the brake

The brake is released electrically. The brake is applied mechanically when the voltage is switched off.



⚠ WARNING

Risk of crushing if the hoist falls.

Severe or fatal injuries.

- Comply with the applicable regulations issued by the relevant employer's liability insurance association regarding phase failure protection and the associated circuit/circuit modification.
- Connect the brake according to the provided wiring diagram.
- In view of the DC voltage to be switched and the high level of current load, it is essential to use either special brake contactors or AC contactors with contacts in utilization category AC-3 according to EN 60947-4-1.




5.15.1 Connecting the brake control

The DC disk brake is powered by a brake control system with protection circuit. It is located in the terminal box/IS lower part or must be installed in the control cabinet.

- Check the cable cross sections – braking currents (see chapter Technical data (→ 150))
- Connect the brake control according to the provided wiring diagram
- For motors in thermal class 180 (H), the brake rectifier and brake control systems are usually installed in the control cabinet. If you have ordered a brakemotor with insulating plate, it will be delivered with the terminal box isolated thermally from the brakemotor. In this case, the brake rectifier and brake control can be installed in the terminal box. The insulating plate increases the height of the terminal box by 9 mm.

5.15.2 Connecting the DUB diagnostics unit

Connect the diagnostics unit as shown in the wiring connection diagram(s) provided with the motor. The maximum permitted connection voltage is AC 250 V with a maximum current of 6 A. With low voltage the maximum voltage is AC 24 V or DC 24 V with max. 0.1 A. A subsequent change to low voltage is not permitted.

Function monitoring	Wear monitoring	Function and wear monitoring
 <p>1145889675</p>	 <p>1145887755</p>	 <p>1145885835</p>
<p>[1] Brake</p> <p>[2] Microswitch MP321-1MS</p>	<p>[1] Brake</p> <p>[2] Microswitch MP321-1MS</p>	<p>[1] Brake</p> <p>[2] Microswitch MP321-1MS</p> <p>[3] Function monitoring</p> <p>[4] Wear monitoring</p>

5.16 Optional equipment

Connect the optional equipment as shown in the wiring diagrams provided with the motor. **Do not connect or start up any optional equipment if the wiring diagram is missing.** You can obtain the valid wiring diagrams free of charge from SEW-EURODRIVE.

5.16.1 Temperature sensor /TF



NOTICE

Damage of the temperature sensor due to excessive heat.

Possible damage to the drive system.

- Do not apply voltages > 30 V to the TF temperature sensor.

The PTC thermistors comply with DIN 44082.

Resistance measurement (measuring instrument with $V \leq 2.5 \text{ V}$ or $I < 1 \text{ mA}$):

- Standard measured values: $20 - 500 \Omega$, hot resistance > 4000Ω

When using the temperature sensor for thermal monitoring, the evaluation function must be activated to maintain reliable isolation of the temperature sensor circuit. If the temperature reaches an excessive level, the thermal protection function must be brought into effect immediately.

If there is a 2nd terminal box for the TF temperature sensor, this is where you must connect the temperature sensor.


Observe the provided wiring diagram for the connection of the TF temperature sensor. If the wiring diagram is missing, you can obtain it from SEW-EURODRIVE free of charge.



INFORMATION

The temperature sensor TF may not be subjected to voltages > 30 V.

The figure below shows the characteristic curve of the TF in relation to the nominal response temperature (referred to as T_{NF}).



5470153483

5.16.2 TH winding thermostats

The thermostats are connected in series and open when the permitted winding temperature is exceeded. They can be connected in the drive monitoring loop.

	V_{AC}	V_{DC}	
Voltage U in V	250	60	24
Current ($\cos \phi = 1.0$) in A	2.5	1.0	1.6
Current ($\cos \phi = 0.6$) in A	1.6		
Contact resistance max. 1Ω at DC $5 \text{ V} / 1 \text{ mA}$			

5.16.3 /KY temperature sensor (KTY84 – 130)




NOTICE

Excessive self-heating of the temperature sensor can damage the insulation of the temperature sensor and the motor winding.

Possible damage to the drive system.

- Avoid currents > 4 mA in the circuit of the KTY.
- Observe the correct connection of KTY to ensure correct evaluation of the temperature sensor. Ensure correct polarity.

The characteristic curve in the following figure shows the resistance curve subject to the motor temperature with a measuring current of 2 mA and correct pole connection.



1140975115

Technical data	KTY84 – 130
Connection	Red (+) Blue (-)
Total resistance at 20 – 25°C	540 Ω < R < 640 Ω
Test current	< 3 mA

5.16.4 Temperature sensor /PT (PT100)




NOTICE

Excessive self-heating of the temperature sensor can damage the insulation of the temperature sensor and the motor winding.

Possible damage to the drive system.

- Avoid currents > 4 mA in the circuit of the PT100.
- Observe the correct connection of PT100 to ensure correct evaluation of the temperature sensor. Ensure correct polarity.

The characteristic curve in the following figure shows the resistance curve subject to the motor temperature.



1145838347

Technical data	PT100
Connection	Red/white
Resistance at 20 – 25°C per PT100	107 Ω < R < 110 Ω
Test current	< 3 mA

5.16.5 V forced cooling fan

- Connection in separate terminal box
- Max. connection cross section $3 \times 1.5 \text{ mm}^2$ (3 × AWG 15)
- Cable gland M16 × 1.5

Motor size	Operating mode/connection	Frequency Hz	Voltage V
DR..71 – 132, DRN80 – 132S	1 ~ AC ¹⁾ (Δ)	50	100 – 127
DR..71 – 132, DRN80 – 132S	3 ~ AC 人	50	175 – 220
DR..71 – 132, DRN80 – 132S	3 ~ AC Δ	50	100 – 127
DR..71 – 180, DRN80 – 180	1 ~ AC ¹⁾ (Δ)	50	230 – 277
DR..71 – 315, DRN80 – 315	3 ~ AC 人	50	346 – 500
DR..71 – 315, DRN80 – 315	3 ~ AC Δ	50	200 – 290

1) Steinmetz circuit

Motor size	Operating mode/connection	Frequency Hz	Voltage V
DR..71 – 132, DRN80 – 132S	1 ~ AC ¹⁾ (Δ)	60	100 – 135
DR..71 – 132, DRN80 – 132S	3 ~ AC 人	60	175 – 230
DR..71 – 132, DRN80 – 132S	3 ~ AC Δ	60	100 – 135
DR..71 – 180, DRN80 – 180	1 ~ AC ¹⁾ (Δ)	60	230 – 277
DR..71 – 315, DRN80 – 315	3 ~ AC 人	60	380 – 575
DR..71 – 315, DRN80 – 315	3 ~ AC Δ	60	220 – 330

1) Steinmetz circuit

Motor size	Operating mode/connection	Voltage V
DR..71 – 132, DRN80 – 132S	DC 24 V	24

INFORMATION




For information on how to connect the V forced cooling fan, refer to the wiring diagram (→ 196).

5.16.6 UWU52A switched-mode power supply

The forced cooling fan type V for DC 24 V includes the UWU52A switched-mode power supply, if you have ordered it. It can be ordered using the part number from SEW-EURODRIVE even after the order has been placed.

The following figure depicts the UWU52A switched-mode power supply:



576533259

Input:	AC 110 – 240 V; 1.04 – 0.61 A; 50/60 Hz DC 110 – 300 V; 0.65 – 0.23 A
Output:	DC 24 V; 2.5 A (40 °C) DC 24 V; 2.0 A (55 °C)
Connection:	Screw terminals 1.5 – 2.5 mm ² , separable
Degree of protection:	IP20; attachment to EN 60715 TH35 mounting rail in the control cabinet
Part number:	0188 1817

5.16.7 Overview of mount-on encoders

Refer to the wiring connection diagrams on information on how to connect add-on encoders:

Encoders	Motor size	Encoder type	Mounting type	Supply in V _{DC}	Signal	Wiring diagram
ES7S	DR..71 – 132 DRN80 – 132S	Incremental	Shaft-centered	7 – 30	1 V _{ss} sin/cos	68180xx08
ES7R	DR..71 – 132 DRN80 – 132S	Incremental	Shaft-centered	7 – 30	TTL (RS-422)	68179xx08
ES7C	DR..71 – 132 DRN80 – 132S	Incremental	Shaft-centered	4.5 – 30	HTL / TTL (RS-422)	68 179xx08
AS7W	DR..71 – 132 DRN80 – 132S	Absolute value	Shaft-centered	7 – 30	1 V _{ss} sin/cos	68181xx08
AS7Y	DR..71 – 132 DRN80 – 132S	Absolute value	Shaft-centered	7 – 30	1 V _{ss} sin/cos + SSI	68182xx07
EG7S	DR..160 – 280 DRN132M – 280	Incremental	Shaft-centered	7 – 30	1 V _{ss} sin/cos	68180xx08
EG7R	DR..160 – 280 DRN132M – 280	Incremental	Shaft-centered	7 – 30	TTL (RS-422)	68179xx08
EG7C	DR..160 – 280 DRN132M – 280	Incremental	Shaft-centered	4.5 – 30	HTL / TTL (RS-422)	68179 xx08
AG7W	DR..160 – 280 DRN132M – 280	Absolute value	Shaft-centered	7 – 30	1 V _{ss} sin/cos	68181xx08
AG7Y	DR..160 – 280 DRN132M – 280	Absolute value	Shaft-centered	7 – 30	1 V _{ss} sin/cos + SSI	68182xx07
EH7S	DR..315 DRN315	Incremental	Shaft-centered	10 – 30	1 V _{ss} sin/cos	08511xx08
EH7C	DR..315 DRN315	Incremental	Shaft-centered	10 – 30	HTL	08511xx08
EH7R	DR..315 DRN315	Incremental	Shaft-centered	10 – 30	TTL (RS-422)	08511xx08
EH7T	DR..315 DRN315	Incremental	Shaft-centered	5	TTL (RS-422)	08511xx08
AH7Y	DR..315 DRN315	Absolute value	Shaft-centered	9 – 30	TTL (RS-422) + SSI	08259xx07
AV1H	DR..160 – 280 DRN132M – 280	Absolute value	Flange centered	7 – 12	Hiperface® / 1 V _{ss} sin/cos	–
AV1Y	DR..160 – 280 DRN132M – 280	Absolute value	Flange centered	10 – 30	1 V _{ss} sin/cos + SSI	–

21258996/EN – 11/2014

Encoders	Motor size	Encoder type	Mounting type	Supply in V_{DC}	Signal	Wiring diagram
EV2C	DR..160 – 280 DRN132M – 280	Incremental	Flange centered	9 – 26	HTL	–
EV2S	DR..160 – 280 DRN132M – 280	Incremental	Flange centered	9 – 26	1 V_{ss} sin/cos	–
EV2R	DR..160 – 280 DRN132M – 280	Incremental	Flange centered	9 – 26	TTL (RS 422)	–
EV2T	DR..160 – 280 DRN132M – 280	Incremental	Flange centered	5	TTL (RS 422)	–

INFORMATION



- Maximum oscillation load for encoders $\leq 10 \text{ g} \approx 100 \text{ m/s}^2$ (10 Hz to 2 kHz)
- Shock resistance = $100 \text{ g} \approx 1000 \text{ m/s}^2$ for DR..71 – 132, DRN80 – 132S motors
- Shock resistance = $200 \text{ g} \approx 2000 \text{ m/s}^2$ for DR..160 – 315, DRN132M – 315 motors

5.16.8 Overview of built-in encoders and visual feedback

INFORMATION



For information on how to connect the built-in encoder, refer to the wiring diagram.

- Observe chapter "Wiring diagrams" for connection via terminal strip.
- Observe the enclosed wiring diagram for connection via M12 connectors.

Encoders	Motor size	Supply in V_{DC}	Signals
EI71 B ¹⁾	DR..71 – 132 DRN80 – 132S	9 – 30	HTL 1 period/revolution
EI72 B ¹⁾			HTL 2 periods/revolution
EI76 B ¹⁾			HTL 6 periods/revolution
EI7C B ¹⁾			HTL 24 periods/revolution

1) B after the type designation mark indicates the unit generation of the encoder in the documentation. It is not indicated on the nameplate.

EI7. B – visual feedback

The EI7.B encoders use 2 bi-colored LEDs (red + green each) for visual feedback on the operating state.

LED H1 (at cable output of the encoder) – status and errors

The green LED indicates the status or the configuration of the encoder. It flashes. The flashing frequency indicates the set number of periods.

LED H1 green	
Frequency	Status/configuration
LED off	Encoder without voltage or faulty
0.6 Hz	EI71 (1 period per revolution)
1.2 Hz	EI71 (2 periods per revolution)
3 Hz	EI76 (6 periods per revolution)
15 Hz	EI7C (24 periods per revolution)
LED lit continuously	Encoder defective

The red LED is lit when the encoder detects an error.

LED H1 red	
Flash code	Meaning
10 s with 1 Hz and 2 s continuous	No valid number of periods can be set
Other	Output driver signals a fault (e.g. short circuit or overtemperature)

The H2 LED display gives visual feedback on the signal track status.

LED color	Track A	Track B	Track A	Track B
Orange (green and red)	0	0	1	1
Red	0	1	1	0
Green	1	0	0	1
Off	1	1	0	0

5.16.9 Installation notes for encoders

When connecting the encoders to the inverters, observe the provided wiring diagrams and the information in these operating instructions as well as the operating instructions/wiring diagrams of the respective inverter and the operating instructions/wiring diagrams provided with the non-SEW encoder if applicable.

Proceed according to chapter "Motor and brake maintenance" to connect the encoders mechanically. Observe the following notes:

- Maximum line length (inverter to encoder):
 - 100 m with a capacitance per unit length \leq conductor – shield ≤ 110 nF/km
 - 100 m with a capacitance per unit length \leq conductor – conductor ≤ 85 nF/km
- Core cross section: $0.20 - 0.5 \text{ mm}^2$ (AWG 24 – 20); recommendation $\geq 0.25 \text{ mm}^2$
- Use shielded cable with twisted pair conductors and apply shield over large area on both ends:
 - In the cable gland of the encoder connection cover or in the encoder plug
 - To the inverter on the electronics shield clamp and to the housing of the D-sub connector
- Install the encoder cables separately from the power cables, keeping a distance of at least 200 mm.
- Compare the operating voltage with the permitted operating voltage range on the encoder nameplate. Deviations in the operating voltage may overheat and damage the encoder.
- SEW-EURODRIVE recommends using stabilized voltage sources and isolated supply systems for encoders or other sensor assemblies and active assemblies such as switches and light barriers.
- Supplies with voltage transients and interferences higher than the supply voltage U_B are not permitted.
- Observe the clamping area of 5 to 10 mm of the cable gland of the connection cover. If you use cables with a different cross section, you have to replace the provided cable gland with another EMC-compatible cable gland.
- The cable glands for the cable entry must meet the following conditions:
 - Cramping area is suitable for the respective cable
 - The IP degree of protection of the encoder connection is at least as high as the IP degree of protection of the actual encoder
 - The cable is suitable for the respective ambient temperature range.
- Check the flawless state and the proper seat of the connection cover gasket.
- Tighten the screws of the connection cover with a tightening torque of 2 Nm (17.7 lb-in).

5.16.10 Anti-condensation heating

To protect a shutdown motor from freezing up (rotor blockage) or condensation inside the motor, it can be equipped with an optional anti-condensation heating. The anti-condensation heating consists of strip heaters that are integrated in the winding head and supplied with voltage when the motor is switched off. The motor is heated by the current flowing through the strip heaters.

The strip heaters are controlled according to the following principle:

Motor switched off → anti-condensation heating activated

Motor switched on → anti-condensation heating deactivated

Observe the permitted voltage according to the nameplate and the enclosed terminal assignment diagram.

6 Startup

INFORMATION



- Observe the safety notes in chapter 2 during installation.
- In case of problems, refer to the chapter "Malfunctions" (→ 176).

If the motor includes safety-rated components, observe the following safety note:



▲ WARNING

Disabling functional safety devices.

Severe or fatal injuries.

- Only qualified specialists are allowed to carry out work on functional safety components.
- Any work on functional safety components must be carried out strictly in accordance with the specifications in the operating instructions at hand and the respective addendum to the operating instructions. Otherwise, the right to claim under warranty will become invalid.



▲ WARNING

Risk of injury due to electric shock.

Severe or fatal injuries!

- Note the following information.
- Use switch contacts in utilization category AC-3 according to EN 60947-4-1 for switching the motor.
- When motors are powered by inverters, you must adhere to the wiring instructions issued by the inverter manufacturer.
- Observe the operating instructions of the inverter.



▲ CAUTION

The surface temperatures on the drive can be very high during operation.

Danger of burns

- Let motor cool down before beginning work.



NOTICE

Limit the maximum speed at the inverter. For information on the procedure, refer to the documentation of the inverter.



NOTICE

The maximum limit torque (M_{pk}) and the maximum current (I_{max}) may not be exceeded, not even for acceleration.

Possible damage to property.

- Limit the maximum current at the inverter.

INFORMATION



When using the DR..250/280 or DRN250 – 280 AC motor with the BE brake and an encoder, note the following:

- The brake must be used as a holding brake only.
- The brake may only be applied when the speed is ≤ 20 rpm. For higher speeds, please contact SEW-EURODRIVE.
- Emergency switching off from a higher motor speed is allowed.

6.1 Before startup

Before startup, make sure that:

- The drive is undamaged and not blocked
- Any transport locks have been removed
- The measures stipulated in chapter "Extended storage of motors" (→ 33) are performed after extended storage periods
- All connections have been made properly
- The direction of rotation of the motor/gearmotor is correct
 - Motor rotating clockwise: U, V, W (T1, T2, T3) to L1, L2, L3
- All protective covers have been properly installed
- All motor protection equipment is active and set for the rated motor current
- There are no other sources of danger
- The lockable manual brake release is permitted
- Loose elements like keys are appropriately secured

6.2 Motors with reinforced bearing




NOTICE

Motors with a reinforced bearing must not be operated without an overhung load. Otherwise you risk damaging the bearings.

6.3 Altering the blocking direction on motors with a backstop


6.3.1 Basic structure of DR..71 – 80, DRN80 with backstop



9007200397599243

- | | | |
|-------------------------|--------------------------------|-----------------|
| [35] Fan guard | [44] Deep grooved ball bearing | [77] Screw |
| [36] Fan | [48] Spacing ring | [78] Label |
| [37] Sealing ring | [62] Retaining ring | [190] Felt ring |
| [41] Cup spring | [74] Sprag ring, complete | [392] Gasket |
| [42] Backstop endshield | [75] Sealing flange | |

6.3.2 Basic structure of DR..90 – 315, DRN90 – 315 with backstop



9007200397597323

- | | | |
|-------------------|---------------------------|----------------------------------|
| [35] Fan guard | [62] Retaining ring | [702] Backstop housing, complete |
| [36] Fan | [74] Sprag ring, complete | [703] Cap screw |
| [37] Sealing ring | [78] Label | |
| [48] Spacing ring | [190] Felt ring | |

6.3.3 Changing the blocking direction

A backstop is used to block/preclude a direction of rotation of the motor. The direction of rotation is indicated by an arrow on the fan guard of the motor or on the gearmotor housing.

Observe the direction of rotation of the end shaft and the number of stages when you mount the motor to the gear unit. Do not start up the motor in blocking direction (ensure correct connection of power supply with motor). For inspection purposes, you can operate the backstop one time with half the motor voltage in the blocking direction:



▲ WARNING

Risk of crushing if the drive starts up unintentionally.

Severe or fatal injuries.

- Before starting work, isolate the motor and, if installed, the forced cooling fan from the power supply.
- Safeguard against accidental startup.
- Carefully observe the following steps!

Proceed as follows to change the blocking direction:

1. Remove forced cooling fan and rotary encoder, if installed.
See chapter "Motor and brake maintenance – preliminary work" (→ 104)
2. Remove flange cover or fan guard [35]
3. **For the DR..71 – 80, DRN80:** Remove the sealing flange [75].
For the DR../DRN90 – 315: Completely remove the backstop housing [702].
4. Loosen the retaining ring [62].
5. Remove the sprag ring [74] via screws in the forcing threads or using a puller.
6. Spacing ring [48], if provided, remains installed.
7. Turn around the sprag ring [74], check the old grease and replace according to the specifications below and reinstall the sprag ring.
8. Install retaining ring [62].
9. **For the DR..71 – 80, DRN80:** Apply Hylomar to cover sealing flange [75] and install it. Replace felt ring [190] and sealing ring [37], if required.
For the DR../DRN90 – 315: Replace seal [901], felt ring [190] and sealing ring [37], if required, and install the backstop housing [702].
10. Reinstall the removed parts.
11. Replace the label indicating the direction of rotation.

Lubricating the backstop

The backstop is greased at the factory with the corrosion protection low-viscosity grease Mobil LBZ. If you want to use another grease, make sure it complies with NLGI class 00/000 with a base oil viscosity of 42 mm²/s at 40°C on a lithium saponified and mineral oil base. The application temperature range is from -50°C to +90°C. See the following table for the amount of grease required:

DR.. motor type	71	80	90/100	112/132	160	180	200/225	250/280	315
DRN.. motor type	–	80	90/100	112/132S	132M/L	160/180	200/225	250/280	315
Amount of grease in g	9	11	15	20	30	45	80	80	120

The tolerance regarding the grease level is ± 30%.

7 Inspection/maintenance



▲ WARNING

Risk of crushing if the hoist falls or in the event of uncontrolled unit behavior.
Severe or fatal injuries.

- Secure or lower hoist drives (danger of falling)
- Safeguard and/or protect the driven machine against touching
- Isolate the motor, brake, and forced cooling fan, if installed, from the power supply before starting work, safeguarding them against unintentional restart.
- Only use genuine spare parts in accordance with the valid spare parts list.
- Always install a new brake controller at the same time as replacing the brake coil.

If the motor includes safety-rated components, observe the following safety note:



▲ WARNING

Disabling functional safety devices.
Severe or fatal injuries.

- Only qualified specialists are allowed to carry out work on functional safety components.
- Any work on functional safety components must be carried out by strictly observing the specifications in the operating instructions at hand and the respective addendum to the operating instructions. Otherwise, the right to claim under warranty will become invalid.



▲ CAUTION

The surfaces on the drive can be very high during operation.
Danger of burns

- Let motor cool down before beginning work.



NOTICE

For assembly, the ambient temperature and the oil seals themselves may not be colder than 0°C; otherwise the oil seals might be damaged.



INFORMATION

Apply grease with a grease depot (Klüber Petamo GHY133N) to the sealing lip of the oil seal before assembly.



INFORMATION

Friction disks in the brakemotor may only be replaced by SEW-EURODRIVE service staff.

Only SEWEURODRIVE, repair workshops, or plants that have the necessary expertise may repair or modify the motor/brakemotor.

Before re-startup of the motor, make sure that all regulations are complied with and document this with a label on the motor or a written test report.

Always perform safety and functional tests following all maintenance and repair work (thermal protection).

7.1 Inspection and maintenance intervals

The following table lists the inspection and maintenance intervals:

Unit / unit part	Frequency	What to do?
BE brake	<ul style="list-style-type: none"> If used as a working brake: At least every 3000 operating hours¹⁾ If used as a holding brake: Every 2 to 4 years, depending on operating conditions¹⁾ 	Inspect the brake <ul style="list-style-type: none"> • Measure the brake disc thickness • Brake disc, lining • Measure and set working air gap • Pressure plate • Driver/gearing • Pressure rings • Vacuum up the abraded matter • Inspect the switch contacts and change if necessary (e.g. in case of burn-out)
Motor	<ul style="list-style-type: none"> Every 10000 operating hours^{2) 3)} 	Inspect the motor: <ul style="list-style-type: none"> • Check rolling bearings and change if necessary • Replace the oil seal • Clean the cooling air passages
Drive	<ul style="list-style-type: none"> Different ³⁾ 	<ul style="list-style-type: none"> • Touch up or renew the surface/anticorrosion coating • Check and clean the air filter. • If applicable, clean condensation drain hole at the bottom of the fan guard • Clean clogged bores

1) The amount of wear depends on many factors and may be high. The machine designer must calculate the required inspection/maintenance intervals individually in accordance with the project planning documents (e.g. "Project Planning for Drives").

2) For the DR../DRN250 – 315 with relubrication device, please note the shortened relubrication periods in the "Bearing lubrication DR../DRN250 – 315" chapter.

3) The interval depends on outer influences and can be very short, e.g. in the event of high dust concentration in the environment.

If you open the motor during inspection/maintenance, you have to clean it before you close it.

7.1.1 Connection cables

Check the connection cable for damage at regular intervals and replace if necessary.


7.2 Bearing lubrication

7.2.1 Bearing lubrication for DR..71 – 225, DRN80 – 225

In standard design, the bearings are lubricated for life.

7.2.2 Bearing lubrication for DR../DRN250 – 315

Motors of sizes 250, 280, and 315 can be equipped with a relubrication device. The following figure shows the positions of the lubrication devices.



375353099

[1] Lubrication device in type A in accordance with DIN 71412

Under normal operating conditions and at an ambient temperature between -20 °C to +40 °C, SEW-EURODRIVE uses ESSO Polyrex EM (K2P-20 DIN 51825), a polyurea-based mineral high-performance, high-temperature grease for initial lubrication.

For motors in the low temperature range up to -40 °C SEW-EURODRIVE uses SKF GXN, which is also a polyurea-based mineral grease.

Relubrication

You can purchase the lubricants in 400 g cartridges from SEW-EURODRIVE. For order information, refer to the chapter "Lubricant tables for rolling bearings of SEW motors".

INFORMATION



Only mix lubricants of the same thickness type, the same base oil and the same consistency (NLGI class)!

Grease the motor bearings in accordance with the information on the lubricant plate. The used grease collects inside the motor and should be removed every 6 to 8 relubrication cycles during an inspection. Each time you relubricate, ensure that the bearing is two-thirds full.

After relubricating the motors, you should startup slowly, if possible, so that the grease is distributed evenly.

Re-lubrication period

The table below lists the bearing relubrication intervals for the following conditions:

- Ambient temperature -20°C to +40°C
- 4-pole speed
- Normal load

At greater speeds, higher loads or higher ambient temperatures, the re-lubrication intervals are shorter. Use 1.5 times the quantity for the initial filling.

Motor type	Horizontal mounting position		Vertical mounting position	
	Duration	Quantity	Duration	Quantity
DR../DRN250 – 315 /NS	5000 h	50 g	3000 h	70 g
DR../DRN250 – 315 /ERF /NS	3000 h	50 g	2000 h	70 g

7.3 Reinforced bearings

In the /ERF (reinforced bearing) option, cylindrical rolling bearings are installed on the A-side.

NOTICE



Bearings might be damaged due to missing overhung load.

The drive system might be damaged.

- Do not operate cylindrical roller bearings without overhung load.

The reinforced bearings are only offered with the /NS (relubrication) option so as to facilitate optimal lubrication of the bearing. Please observe the notes on bearing lubrication in chapter Bearing lubrication for DR../DRN250 – 315 (→ 102).

7.4 Corrosion protection

If a drive is equipped with the /KS corrosion protection option and IP56 or IP66, you have to replace the Hylomar at the studs.

7.5 Motor and brake maintenance – preliminary work

WARNING




Risk of crushing if the drive starts up unintentionally.

Severe or fatal injuries.

- Before starting work, isolate the motor, brake, and if installed, the forced cooling fan from the power supply.
- Safeguard against accidental startup.

7.5.1 Removing the rotary encoder from DR..71 – 132, DRN80 – 132S

The following figure illustrates the disassembly procedure using the ES7. rotary encoder as an example:



3475618443

[34]	Tapping screw	[367]	Retaining screw
[35]	Fan guard	[619]	Encoder cover
[220]	Encoder	[733]	Screws
[361]	Extended fan guard	[A]	Screws
[362]	Torque arm	[B]	Cone

Removing ES7. and AS7. encoders

1. Remove the cover [361].
2. Unscrew and remove the connection cover [619]. Do not disconnect the encoder connection cable.
3. Loosen screws [733].
4. Unscrew the central retaining screw [367] by about 2 to 3 turns and unfasten the spread shaft cone by tapping lightly on the screw head.
Do not lose the cone [B].
5. Carefully remove the expansion anchor of the torque bracket [362] from the cover grid and the encoder from the rotor.


Re-assembly

Proceed as follows to re-assemble the encoder:

1. Tighten the central retaining screw [367] with a tightening torque of 2.9 Nm (25.7 lb-in).
2. Tighten the screw [733] in the expansion anchor with a maximum tightening torque of 2.0 Nm (17.7 lb-in).
3. Assemble the encoder cover [619] and tighten the screws [A] with a tightening torque of 2 Nm (17.7 lb-in).
4. Install the extended fan guard [361] with the screws [34].

7.5.2 Removing the rotary encoder from DR..160 – 280, DRN132M – 280

The following figure illustrates the disassembly procedure using the EG7. rotary encoder as an example:



9007201646566283

[1]	Rotor	[367]	Retaining screw
[34]	Tapping screw	[619]	Connection cover
[35]	Fan guard	[657]	Canopy
[220]	Encoder	[706]	Spacer bolt
[232]	Screws	[707]	Screws
[361]	Extended fan guard	[715]	Screws
		[A]	Screws

Removing EG7. and AG7. encoders


1. Loosen the screws [22] and remove the forced cooling fan guard [170].
2. Remove the cable grommet [269] with encoder cable from the forced cooling fan guard [170].
3. Loosen the screws [232] and [936] and remove the torque bracket [935].
4. Loosen the retaining screw [220] on the encoder and remove the encoder from the rotor [1].

Re-assembly

1. Place the encoder onto the rotor [1] and attach it in the bore using the central retaining screw of the encoder [A]. The tightening torque must be 8 Nm (70.8 lb-in).
2. Place the torque bracket [935] on the spacer bushings [934] and tighten the screws [936] with 11 Nm (97.4 lb-in).
3. Attach the torque arm of the encoder [A] to the torque bracket [935] using the screws [232]. The tightening torque must be 6 Nm (53.1 lb-in).
4. Pull the cable of the encoder [220] through the cable grommet [269]. Insert the cable grommet [269] into the forced cooling fan guard [170].
5. Mount the forced cooling fan guard [170] and tighten the screws [22] with 28 Nm (247.8 lb-in).

7.5.3 Removing the rotary encoder from DR..160 – 315, DRN132M – 315 with /V forced cooling fan option

The following figure illustrates the disassembly procedure using the EG7. rotary encoder as an example:



[22]	Screw	[935]	Torque arm
[170]	Forced cooling fan guard	[936]	Screw
[232]	Screws	[934]	Spacer bushing
[269]	Grommet	[A]	Encoder

Removing EG7. and AG7. encoders


1. Loosen the screws [22] and remove the forced cooling fan guard [170].
2. Remove the cable grommet [269] with encoder cable from the forced cooling fan guard [170].
3. Loosen the screws [232] and [936] and remove the torque bracket [935].
4. Loosen the retaining screw [220] on the encoder and remove the encoder from the rotor [1].

Re-assembly

1. Place the encoder onto the rotor [1] and attach it in the bore using the central retaining screw of the encoder [A]. The tightening torque must be 8 Nm (70.8 lb-in).
2. Place the torque bracket [935] on the spacer bushings [934] and tighten the screws [936] with 11 Nm (97.4 lb-in).
3. Attach the torque arm of the encoder [A] to the torque bracket [935] using the screws [232]. The tightening torque must be 6 Nm (53.1 lb-in).
4. Pull the cable of the encoder [220] through the cable grommet [269]. Insert the cable grommet [269] into the forced cooling fan guard [170].
5. Mount the forced cooling fan guard [170] and tighten the screws [22] with 28 Nm (247.8 lb-in).

7.5.4 Removing the rotary encoder from DR..315, DRN315

The following figure illustrates the disassembly procedure using the EH7. and AH7. rotary encoders as an example:



9007199662370443

[35]	Fan guard	[659]	Screw
[220]	Encoder	[734]	Nut
[367]	Retaining screw	[748]	Screw
[657]	Cover plate		

Removing EH7. encoders

1. Remove the cover plate [657] by loosening the screws [659].
2. Separate the encoder [220] from the fan guard by loosening the nut [734].
3. Loosen the retaining screw [367] on the encoder and remove the encoder [220] from the rotor [1].

Removing AH7. encoders

1. Remove the protection cover [657] by loosening the screws [659].
2. Separate the encoder [220] from the fan guard by loosening the screws [748].
3. Loosen the retaining screw [367] on the encoder and remove the encoder [220] from the shaft.

Re-assembly


1. Mount fan guard [35].
2. Push the encoder [220] on the shaft and fasten it with the retaining screw [367] applying a tightening torque according to the following table:

Encoders	Tightening torque
EH7.	0.7 Nm (6.2 lb-in)
AH7.	3.0 Nm (26.6 lb-in)

3. Install the screw [748] and the nut [734].
4. Install the cover plate [657].

7.5.5 Installing/removing incremental encoders, absolute encoders and special encoders with XV.A mounting adapter to/from DR..71 – 225, DRN80 – 225

The following figure illustrates the disassembly procedure using a non-SEW encoder as an example:



9007202887906699

[22]	Screw	[361]	Extended fan guard (normal/long)
[170]	Forced cooling fan guard	[269]	Grommet
[212]	Fan guard with encoder mount	[A]	Adapter
[220]	Encoder	[B]	Clamping screw
[225]	Intermediate flange (not with XV1A)	[D]	Coupling (spread- or solid shaft coupling)
[232]	Screws (enclosed with XV1A and XV2A)	[E]	Clamping screw
[251]	Conical spring washers (enclosed with XV1A and XV2A)		

Removing EV., AV., and XV. encoders


1. Remove the extended fan guard [361] by loosening the screws [22] or remove forced-cooling fan guard [170].
2. Loosen the retaining screws [232] and turn the conical spring washers [251] outwards.
3. Loosen the clamping screw [E] of the coupling.
4. Remove the adapter [A] and the encoder [220].

Re-assembly

1. Proceed according to chapter "Connecting XV.A encoder mounting adapter to DR.. 71 – 225, DRN80 – 225 motors (→ 39)" to mount the encoder.

7.5.6 Removing/installing incremental encoders, absolute encoders and special encoders with EV.A / AV.A mounting adapter to/from DR..250 – 280, DRN250 – 280

The following figure illustrates the disassembly procedure using a non-SEW encoder as an example:



9007206970704907

[22]	Screw	[361]	Extended fan guard (normal/long)
[33]	Washer	[1458]	Screw
[34]	Screw	[1459]	Cage nut
[35]	Fan guard	[1460]	Serrated lock washer
[220]	Encoder	[1461]	Washer
[225]	Intermediate flange (optional)	[1462]	Screw
[226]	Screw	[1489]	Ground strap
[232]	Screws (enclosed with .V1A and .V2A)	[1496]	Serrated lock washer
[233]	Coupling	[1497]	Washer
[251]	Conical spring washers (enclosed with .V1A and .V2A)	[1498]	Screw
[269]	Grommet	[A]	Encoder mounting adapter

Removing the encoder mounting adapter

1. Loosen the screws [34] and washers [33] at the extended fan guard. Remove the extended fan guard [361].
2. Remove the encoder. For more details, see chapter "Removing the encoder." (→ 111)
3. Loosen the ground strap of the encoder mounting adapter [A] with serrated lock washer [1496], washers [1497], and screw [1498].
4. Loosen the screws [22] and remove the fan guard [35].

5. Loosen the encoder mounting adapter [A] with screw [1458] in the encoder bore of the rotor and remove it.

If the encoder mounting adapter cannot easily be removed: Screw in an M6 set screw with 20 – 35 mm length into the rotor bore (bore for screw [1458]) and tighten it finger-tight. Screw in a set screw M8 with > 10 mm length or a screw M8 with min. 80 mm length into the same bore and push out the encoder mounting adapter [A] from the rotor [1]. Then remove the set screw M6 from the rotor again.

Removing EV.., AV.. encoders

1. Loosen the screws [34] and remove the extended fan guard [361].
2. Remove the cable grommet [269] with encoder cable from the extended fan guard [361].
3. Loosen the screws [232] and turn the conical spring washers of the encoder [220] outwards. Loosen the screw of the coupling clamping hub [233] on the encoder end through the slots in the encoder mounting adapter [A].
4. Remove the encoder [220] from the encoder mounting adapter [A] or intermediate flange [225].

Re-assembly


1. Proceed as described in chapter "Installing the EV.A / AV.A encoder mounting adapter on DR..250 – 280, DRN250 – 280 motors" (→ 41) to mount the encoder.

INFORMATION



When re-installing the fan guard [35], make sure that the torque is supported:


The damping elements [1486] on both sides of the encoder mounting adapter [A] must engage with the ventilation grid (see figure below). The torque plate [935] must protrude from the grid to the left and to the right of the damping element.



9007207498780299

7.5.7 Installing/removing incremental encoders, absolute encoders and special encoders with EV.A / AV.A mounting adapter to/from DR..250 – 280, DRN250 – 280 with /V forced cooling fan option

The following figure illustrates the disassembly procedure using a non-SEW encoder as an example:



7715965835

[22]	Screw	[269]	Grommet
[170]	Forced cooling fan guard	[934]	Spacer bushing
[220]	Encoder	[935]	Torque bracket
[225]	Intermediate flange (optional)	[936]	Screw
[226]	Screw	[1458]	Screw
[232]	Screws (enclosed with .V1A and .V2A)	[1463]	Screw
[233]	Coupling	[A]	Encoder mounting adapter
[251]	Conical spring washers (enclosed with .V1A and .V2A)		

Removing the encoder mounting adapter

1. Loosen the screws [22] and remove the forced cooling fan guard [170].
2. Remove the cable grommet [269] from the fan guard [170].
3. Loosen the screws [232] and turn the conical spring washers [251] to the side. Loosen the screw of the coupling clamping hub [233] on the encoder end and remove the encoder [220]. The intermediate flange [225] and screws [226] can remain at the encoder mounting adapter [A].
4. Loosen the screws [1458] and [936] and remove the encoder mounting adapter [A]. The torque brackets [935] and screws [1463] can remain at the encoder mounting adapter [A].
 - If the encoder mounting adapter [A] cannot easily be removed: Screw in a set screw M6 with 20 – 35 mm length into the rotor bore (bore for screw [1458]) and tighten it finger-tight. Screw in a set screw M8 with > 10 mm length or a screw M8 with min. 80 mm length into the same bore and push out the encoder mounting adapter [A] from the rotor [1]. Then remove the set screw M6 from the rotor again.

Removing EV..., AV..., and XV. encoders

1. Loosen the screws [22] and remove the forced cooling fan guard [170].
2. Remove the cable grommet [269] with encoder cable from the forced cooling fan guard [170].
3. Turn the conical spring washers of the encoder [220] outwards and loosen the screws [232]. Loosen the screw of the coupling clamping hub [233] on the encoder end.
4. Remove the encoder [220] from the encoder mounting adapter [A] or intermediate flange [225].


Re-assembly

1. Proceed as described in chapter "Installing the EV.A / AV.A encoder mounting adapter on DR..250 – 280, DRN250 – 280 motors" (→ 41) to mount the encoder.


7.5.8 Installing/removing hollow shaft encoders from/to XH.. mounting adapter of DR..71 – 225, DRN80 – 225

The following figure illustrates the disassembly procedure using a non-SEW encoder as an example:

Encoder mounting via XH1A mounting adapter



Encoder mounting via XH7A and XH8A mounting adapter



3633161867

- | | |
|-------|--------------------------|
| [1] | Rotor |
| [33] | Tapping screw |
| [34] | Washer |
| [35] | Fan guard |
| [170] | Forced cooling fan guard |
| [220] | Encoder |
| [269] | Grommet |
| [361] | Extended fan guard |

- | | |
|-----|---------------------------|
| [A] | Retaining screw |
| [B] | Encoder cover |
| [C] | Screw for torque bracket |
| [D] | Nut of the torque bracket |
| [E] | Screw |
| [F] | Clamping ring |
| [G] | Nut of the torque bracket |

Removing hollow shaft encoders from XH1A mounting adapter

1. Remove cover [361] or forced cooling fan guard [170].
2. Loosen encoder cover [B] via screws [C].
3. Remove screw [A].
4. Loosen screw and nut of the torque bracket [D] and remove torque arm.
5. Remove encoder [220] from rotor [1].

Removing hollow shaft encoders from XH7A and XH8A mounting adapter

1. Remove cover [361] or forced cooling fan guard [170].
2. Loosen screw [E] on clamping ring [F].
3. Remove nut of torque bracket [G].
4. Remove encoder [220] from rotor [1].

Reinstalling hollow shaft encoders to XH1A mounting adapter


1. Push encoder [220] on rotor [1].
2. Mount torque bracket via screws [D].
3. Fasten encoder [220] via screw [A] with a tightening torque of 2.9 Nm (25.7 lb-in).
4. Fasten encoder cover [B] via screws [C] with a tightening torque of 3 Nm (26.6 lb-in).
5. Install cover [361] or forced cooling fan guard [170].

Reinstalling hollow shaft encoders to XH7A and XH8A mounting adapter

1. Push encoder [220] on rotor [1].
2. Mount torque bracket via nut [D] with a tightening torque of 10.3 Nm (91.2 lb-in).
3. Fasten clamping ring [F] via screw [E] with a tightening torque of 5 Nm (44.3 lb-in).
4. Install cover [361] or forced cooling fan guard [170].

7.6 Inspection/maintenance of DR..71 – 315, DRN80 – 315 motors


7.6.1 Basic structure of DR..71 – 132/DRN80 – 132S



13369217931

[1] Rotor	[30] Oil seal	[106] Oil seal	[123] Hex head screw
[2] Retaining ring	[32] Retaining ring	[107] Oil flinger	[129] Screw plug with O-ring
[3] Key	[35] Fan guard	[108] Nameplate	[131] Gasket for cover
[7] Flanged endshield	[36] Fan	[109] Grooved pin	[132] Terminal box cover
[9] Screw plug	[41] Shim washer	[111] Gasket for lower part	[134] Screw plug with O-ring
[10] Retaining ring	[42] B-side endshield	[112] Terminal box lower part	[156] Information sign
[11] Deep groove ball bearing	[44] Deep groove ball bearing	[113] Pan head screw	[262] Connection terminal, complete
[12] Retaining ring	[90] Bed plate	[115] Terminal board	[392] Gasket
[13] Cap screw	[91] Hex nut	[116] Terminal yoke	[705] Canopy
[16] Stator	[93] Pan head screw	[117] Hex head screw	[706] Spacer
[22] Hex head screw	[100] Hex nut	[118] Lock washer	[707] Pan head screw
[24] Eyebolt	[103] Stud	[119] Pan head screw	


7.6.2 Basic structure of DR..160 – 180, DRN132M – 180



18014399036804619

[1] Rotor	[31] Key	[108] Nameplate	[132] Terminal box cover
[2] Retaining ring	[32] Retaining ring	[109] Grooved pin	[134] Screw plug with O-ring
[3] Key	[35] Fan guard	[111] Gasket for lower part	[137] Screw
[7] Flange	[36] Fan	[112] Terminal box lower part	[139] Hex head screw
[9] Screw plug	[41] Cup spring	[113] Screw	[140] Washer
[10] Retaining ring	[42] B-side endshield	[115] Terminal board	[153] Terminal strip, complete
[11] Deep groove ball bearing	[44] Deep groove ball bearing	[116] Serrated lock washer	[156] Information sign
[12] Retaining ring	[90] Foot	[117] Stud	[219] Hex nut
[14] Washer	[91] Hex nut	[118] Washer	[262] O-ring
[15] Hex head screw	[93] Washer	[119] Cap screw	[390] Retaining plate
[16] Stator	[94] Cap screw	[121] Grooved pin	[616] Canopy
[17] Hex nut	[100] Hex nut	[123] Hex head screw	[705] Spacer
[19] Cap screw	[103] Stud	[128] Serrated lock washer	[706] Hex head screw
[22] Hex head screw	[104] Supporting ring	[129] Screw plug with O-ring	[715] Hex head screw
[24] Eyebolt	[106] Oil seal	[131] Gasket for cover	
[30] Sealing ring	[107] Oil flinger		


7.6.3 Basic structure of DR..200 – 225, DRN200 – 225



9007200332597387

[1] Rotor	[31] Key	[107] Oil flinger	[132] Terminal box cover
[2] Retaining ring	[32] Retaining ring	[108] Nameplate	[134] Screw plug
[3] Key	[35] Fan guard	[109] Grooved pin	[137] Screw
[7] Flange	[36] Fan	[111] Gasket for lower part	[139] Hex head screw
[9] Screw plug	[40] Retaining ring	[112] Terminal box lower part	[140] Washer
[11] Deep groove ball bearing	[42] B-side endshield	[113] Cap screw	[156] Information sign
[15] Hex head screw	[43] Supporting ring	[115] Terminal board	[219] Hex nut
[16] Stator	[44] Deep groove ball bearing	[116] Serrated lock washer	[262] Connection terminal
[19] Cap screw	[90] Foot	[117] Stud	[390] O-ring
[21] Oil seal flange	[93] Washer	[118] Washer	[616] Retaining plate
[22] Hex head screw	[94] Cap screw	[119] Cap screw	[705] Canopy
[24] Eyebolt	[100] Hex nut	[123] Hex head screw	[706] Spacer bolt
[25] Cap screw	[103] Stud	[128] Serrated lock washer	[707] Hex head screw
[26] Shield ring	[105] Cup spring	[129] Screw plug	[715] Hex head screw
[30] Oil seal	[106] Oil seal	[131] Gasket for cover	


7.6.4 Basic structure of DR..250 – 280, DRN250 – 280



9007206690410123

[1] Rotor	[32] Retaining ring	[108] Nameplate	[134] Screw plug
[2] Retaining ring	[35] Fan guard	[109] Grooved pin	[137] Screw
[3] Key	[36] Fan	[111] Gasket for lower part	[139] Hex head screw
[7] Flange	[40] Retaining ring	[112] Terminal box lower part	[140] Washer
[9] Screw plug	[42] B-side endshield	[113] Cap screw	[156] Information sign
[11] Deep groove ball bearing	[43] Supporting ring	[115] Terminal board	[159] Connection piece
[15] Cap screw	[44] Deep groove ball bearing	[116] Serrated lock washer	[160] Connection piece gasket
[16] Stator	[90] Foot	[117] Stud	[161] Hex head screw
[19] Cap screw	[93] Washer	[118] Washer	[219] Hex nut
[21] Oil seal flange	[94] Cap screw	[119] Hex head screw	[262] Connection terminal
[22] Hex head screw	[100] Hex nut	[123] Hex head screw	[705] Canopy
[24] Eyebolt	[103] Stud	[128] Serrated lock washer	[706] Spacer bolt
[25] Cap screw	[105] Compression spring	[129] Screw plug	[707] Hex head screw
[26] Shield ring	[106] Oil seal	[131] Gasket for cover	[715] Hex head screw
[30] Oil seal	[107] Oil flinger	[132] Terminal box cover	[1453] Screw plug
[31] Key			

7.6.5 Basic structure of DR..315, DRN315



27021598116221579

[1] Rotor	[32] Retaining ring	[111] Gasket for lower part	[156] Information sign
[2] Retaining ring	[35] Fan guard	[112] Terminal box lower part	[219] Hex nut
[3] Key	[36] Fan	[113] Cap screw	[250] Oil seal
[7] Flange	[40] Retaining ring	[115] Terminal board	[452] Terminal strip
[9] Screw plug	[42] B-side endshield	[116] Serrated lock washer	[454] Mounting rail
[11] Rolling bearing	[43] Supporting ring	[117] Stud	[604] Lubrication ring
[15] Cap screw	[44] Rolling bearing	[118] Washer	[606] Grease nipple
[16] Stator	[90] Foot	[119] Hex head screw	[607] Grease nipple
[17] Hex nut	[93] Washer	[123] Hex head screw	[608] Oil seal flange
[19] Cap screw	[94] Cap screw	[128] Serrated lock washer	[609] Hex head screw
[21] Oil seal flange	[100] Hex nut	[129] Screw plug	[633] End bracket
[22] Hex head screw	[103] Stud	[131] Gasket for cover	[634] End plate
[24] Eyebolt	[105] Cup spring	[132] Terminal box cover	[705] Canopy
[25] Cap screw	[106] Oil seal	[134] Screw plug	[706] Spacer bolt
[26] Shield ring	[107] Oil flinger	[139] Hex head screw	[707] Hex head screw
[30] Oil seal	[108] Nameplate	[140] Washer	[715] Hex nut
[31] Key	[109] Grooved pin	[151] Cap screw	[716] Washer

7.6.6 Inspection steps for DR..71 – 315, DRN80 – 315 motors



▲ WARNING

Risk of crushing if the drive starts up unintentionally.

Severe or fatal injuries.


- Isolate the motor and forced cooling fan, if installed, from the power supply before starting work, safeguarding them against unintentional re-start.
- Carefully observe the following steps!

1. Remove forced cooling fan and rotary encoder, if installed.
See chapter "Motor and brake maintenance – preliminary work" (→ 104)
2. With gearmotors: Remove the motor from the gear unit.
Remove pinion and oil flinger [107].
3. Remove fan guard [35] and fan [36].
4. Remove stator:
 - **Sizes DR..71 – 132, DRN80 – 132S:** Remove cap screws [13] from flanged endshield [7] and B-side endshield [42]. Remove stator [16] from flanged endshield [7].
 - **Sizes DR..160 – 180, DRN132M – 180:** Loosen cap screws [19] and remove B-side endshield [42]. Loosen hex head screw [15] and remove stator from flanged endshield.
 - **Sizes DR..200 – 225, DRN200 – 225**
 - Loosen hex head screw [15] and remove the flanged endshield [7] from the stator.
 - Loosen hex head screw [19] and remove the complete rotor [1] together with the B-side endshield [42].
 - Loosen hex head screw [25] and remove the complete rotor [1] from the B-side endshield [42].
 - **Sizes DR..250 – 280, DRN250 – 280 without option /ERF or /NS**
 - Loosen cap screws [15] and remove the flange [7].
 - Loosen cap screws [19] and remove the B-side endshield [42] together with the rotor [1].
 - Loosen cap screws [25] and remove the B-side endshield [42] from the rotor [1].
 - **Sizes DR..250 – 280, DRN250 – 280 with option /ERF or /NS or DR../DRN315**
 - Unfasten cap screws [19] and [25], and remove B-side endshield [42].
 - Loosen cap screws [15] and remove the flange [7] together with the rotor [1].
 - Loosen hex head screws [609] and remove the flange [7] from the rotor [1].
 - Before disassembly, protect the oil seal seat from damage using adhesive tape or a protective sleeve.
5. Visual inspection: Are there traces of gear oil or condensation inside the stator?
 - If not, proceed to step 8.
 - If there is condensation, continue with 6.
 - If there is gear oil, have the motor repaired by a specialist workshop

6. If there is condensation inside the stator:
 - With gearmotors: Remove the motor from the gear unit.
 - With motors without a gear unit: Remove the A-flange
 - Remove the rotor [1].
7. Clean the winding, dry it and check it electrically (see chapter "Drying the motor" (→ 133)).
8. Replace the rolling bearing [11] [44] with permitted rolling bearing types.
See the "Permitted rolling bearing types" (→ 165) chapter.
9. **DR..250 – 280, DRN250 – 280 with option /ERF or /NS or DR../DRN315**
 - Fill the bearing with grease until it is two-thirds full. See the "Bearing lubrication" (→ 102) chapter.
 - Note: Place the oil seal flange [608] and [21] onto the rotor shaft before installing the bearings.
 - Starting on the A-side, mount the motor vertically.
 - Place the cup springs [105] and lubrication ring [604] into the bearing bore of the flange [7].
 - Hang the rotor [1] onto the B-side thread, and guide into the flange [7].
 - Fasten the oil seal flange [608] to the flange [7] using the hex head screws [609].
10. Reseal the shaft:
 - A-side: Replace the oil seal [106].
 - B-side: Replace oil seal [30].
Coat the sealing lip with grease (Klüber Petamo GHY 133).
11. Reseal the stator seat:
 - Seal the sealing surface with duroplastic sealing compound
(operating temperature -40°C to $+180^{\circ}\text{C}$), e.g. "SEW L Spezial," part number ???.
 - For sizes **DR..71 – 132, DRN80 – 132S**: Replace sealing [392].
12. Install the motor and optional equipment.

7.7 Inspection/maintenance of DR..71 – 315, DRN80 – 315 brakemotors


7.7.1 Basic structure of DR..71 – 80, DRN80 brakemotors



9007199428941963

[1] Motor with brake endshield	[54] Magnet body, complete	[67] Counter spring
[22] Hex head screw	[56] Stud	[68] Brake disk
[35] Fan guard	[57] Conical spring	[62] Retaining ring
[36] Fan	[58] Adjusting nut	[70] Driver
[49] Pressure plate	[59] Parallel pin	[71] Key
[50] Brake spring	[60] Stud 3x	[95] Sealing ring
[11] Complete magnet body	[61] Hex nut	[718] Damping plate
[51] Hand lever	[65] Pressure ring	
[53] Releasing lever	[66] Sealing strip	


7.7.2 Basic structure of DR..90 – 132, DRN90 – 132S brakemotors



9007199434722955

[1]	Motor with brake endshield	[53]	Releasing lever	[70]	Driver
[22]	Hex head screw	[56]	Stud	[71]	Key
[32]	Retaining ring	[57]	Conical spring	[95]	Sealing ring
[35]	Fan guard	[58]	Adjusting nut	[550]	Pre-assembled brake
[36]	Fan	[59]	Parallel pin	[900]	Screw
[51]	Hand lever	[62]	Retaining ring	[901]	Gasket


7.7.3 Basic structure of DR..160 – 280, DRN132M – 280 brakemotors



9007199781964683

[1] Motor with brake end-shield	[51] Hand lever	[70] Driver
[22] Hex head screw	[53] Releasing lever	[71] Key
[31] Key	[55] Closing piece	[95] Sealing ring
[32] Retaining ring	[56] Stud	[550] Pre-assembled brake
[35] Fan guard	[57] Conical spring	[698] Connector complete (only for BE20 – BE122)
[36] Fan	[58] Adjusting nut	[900] Screw
[47] O-ring	[62] Retaining ring	[901] O-ring

7.7.4 DR.315 brakemotor – basic structure



[1] Motor with brake endshield	[53] Releasing lever	[71] Key
[22] Hex head screw	[55] Closing piece	[255] Conical seat
[31] Key	[56] Stud	[256] Spherical washer
[32] Retaining ring	[57] Conical spring	[550] Pre-assembled brake
[35] Fan guard	[58] Adjusting nut	[900] Screw
[36] Fan	[62] Retaining ring	[901] Gasket
[37] V-ring	[64] Set screw	
[47] O-ring	[70] Driver	

7.7.5 Inspection steps for DR..71 – 315, DRN80 – 315 brakemotors



▲ WARNING

Risk of crushing if the drive starts up unintentionally.

Severe or fatal injuries.

- Isolate the motor, brake, and forced cooling fan, if installed, from the power supply before starting work, safeguarding them against unintentional re-start.
- Carefully observe the following steps!

1. Remove forced cooling fan and rotary encoder, if installed.
See chapter "Motor and brake maintenance – preliminary work" (→ 104)
2. With gearmotors: Remove the motor from the gear unit.
Remove pinion and oil flinger [107].
3. Remove fan guard [35] and fan [36].
4. Remove stator:
 - **Sizes DR..71 – 132, DRN80 – 132S:** Remove cap screws [13] from flanged endshield [7] and B-side endshield [42]. Remove stator [16] from flanged endshield [7].
 - **Sizes DR..160 – 180, DRN132M – 180:** Loosen hex head screw [19] and remove B-side endshield [42]. Loosen hex head screw [15] and remove stator from flanged endshield.
 - **Sizes DR..200 – 225, DRN200 – 225**
 - Loosen hex head screw [15] and remove the flanged endshield [7] from the stator.
 - Loosen hex head screw [19] and remove the complete rotor [1] together with the B-side endshield [42].
 - Loosen hex head screw [25] and remove the complete rotor [1] from the B-side endshield [42].
 - **Sizes DR..250 – 280, DRN250 – 280 without option /ERF or /NS**
 - Loosen cap screws [15] and remove the flange [7].
 - Loosen cap screws [19] and remove the B-side endshield [42] together with the rotor [1].
 - Loosen cap screws [25] and remove the B-side endshield [42] from the rotor [1].
 - **Sizes DR..250 – 280, DRN250 – 280 with option /ERF or /NS or DR../DRN315**
 - Unfasten cap screws [19] and [25], and remove B-side endshield [42].
 - Loosen cap screws [15] and remove the flange [7] together with the rotor [1].
 - Loosen hex head screws [609] and remove the flange [7] from the rotor [1].
 - Before disassembly, protect the oil seal seat from damage using adhesive tape or a protective sleeve.
5. Remove the brake cable:
 - **BE05 – 11:** Remove the terminal box cover and unfasten the brake cable from the rectifier.
 - **BE20 – 122:** Loosen locking screws of the brake plug connector [698] and remove plug connector.

6. Push the brake off the stator and carefully lift it off.
7. Pull the stator back by about 3 to 4 cm.
8. Visual inspection: Are there traces of gear oil or condensation inside the stator?
 - If not, proceed with step 11.
 - If there is condensation, continue with 9.
 - If there is gear oil, have the motor repaired by a specialist workshop
9. If there is condensation inside the stator:
 - With gearmotors: remove the motor from the gear unit
 - With motors without a gear unit: Remove the A-flange
 - Remove the rotor [1]
10. Clean the winding, dry it and check it electrically (see chapter "Drying the motor" (→ 33)).
11. Replace the rolling bearing [11] [44] with permitted rolling bearing types.
See the "Permitted rolling bearing types" chapter (→ 165).
12. **DR..250 – 280, DRN250 – 280 with option /ERF or /NS or DR../DRN315**
 - Fill the bearing with grease until it is two-thirds full. See the "Bearing lubrication" (→ 102) chapter.
 - Note: Place the oil seal flange [608] and [21] onto the rotor shaft before installing the bearings.
 - Starting on the A-side, mount the motor vertically.
 - Place the cup springs [105] and lubrication ring [604] into the bearing bore of the flange [7].
 - Hang the rotor [1] onto the B-side thread, and guide into the flange [7].
 - Fasten the oil seal flange [608] to the flange [7] using the hex head screws [609].
 - Screw in the stator [16] and flange [7] with screws [15].
Note: Protect the end turns from damage.
 - Before mounting the B-side endshield, screw in the M8 set screw approximately 200 mm into the oil seal flange [21].
 - Before mounting the B-side endshield [42], feed the set screw in through a bore for the screw [25]. Screw in the B-side endshield and stator [16] using cap screws [19] and hex nuts [17]. Lift the oil seal flange [21] with the set screw, and fasten using 2 screws [25]. Remove the set screw and screw in the remaining screws [25].
 - Renew oil seals
 - A-side: Change the oil seals [106]. For gearmotors, change the oil flinger [107] and the oil seal [250].
With gearmotors, fill about two-thirds of the space between the two oil seals with grease (Klüber Petamo GHY133).
 - B-side: Insert the oil seal [30], and coat the sealing lip with the same grease.
13. Reseal the shaft:
 - A-side: Replace the oil seal [106]
 - B-side: Replace oil seal [30]
Coat the sealing lip with grease (Klüber Petamo GHY 133).


14. Reseal the stator seat:

- Seal the sealing surface with duroplastic sealing compound (operating temperature -40°C to +180°C), e.g. "SEW L Spezial."
- For sizes **DR..71 – 132, DRN80 – 132S**: Replace sealing [392].

15. **Motor sizes DR..160 – 280, DRN132M – 280**: Replace the O-ring [901] between the B-side endshield [42] and the pre-assembled brake [550]. Install the pre-assembled brake [550]

16. Install the motor, brake and optional equipment.


7.7.6 Basic structure of BE05 – BE2 brakes (DR..71 – 80, DRN80)



18014399037859723

[42] Brake endshield	[61] Hex nut	[73] Washer
[49] Pressure plate	[65] Pressure ring	[276] Brake spring (blue)
[50] Brake spring (normal)	[66] Sealing strip	[718] Damping plate
[54] Magnet body, complete	[67] Counter spring	
[60] Stud 3x	[68] Brake disk	


7.7.7 Basic structure of BE1 – BE11 brakes (DR..90 – 160, DRN90 – 132S)



18014398683684619

[49] Pressure plate	[61] Hex nut	[68] Brake disk
[50] Brake spring (normal)	[65] Pressure ring	[276] Brake spring (blue)
[54] Magnet body, complete	[66] Sealing strip	[702] Friction disk
[60] Stud 3x	[67] Counter spring	[718] Damping plate


7.7.8 Basic structure of BE20 brakes (DR..160 – 180, DRN132M – 180)



9007200415803275

[28] Closing cap	[61] Hex nut	[69] Circular spring
[49] Pressure plate, complete	[65] Pressure ring	[276] Brake spring (blue)
[50] Brake spring (normal)	[66] Sealing strip	[702] Friction disk
[54] Magnet body, complete	[67] Counter spring	
[60] Stud 3x	[68] Brake disk	


7.7.9 Basic structure of BE30 – BE32 brakes (DR..180 – 225, DRN180 – 225)



18014399663204747

[28] Closing cap	[60] Stud 3x	[69] Circular spring
[49] Pressure plate	[61] Hex nut	[276] Brake spring (blue)
[50] Brake spring (normal)	[66] Sealing strip	[718] Friction disk
[51] Brake plate	[67] Setting sleeve	
[54] Magnet body	[68] Brake disk	

7.7.10 Basic structure of BE60 – BE122 brakes (DR..250 – 315, DRN250 – 315)



18014398863076107

[28]	Closing cap	[61]	Hex nut	[69b]	Circular spring (BE122 only)
[49]	Pressure plate	[66]	Sealing strip	[276]	Brake spring
[50]	Brake spring	[67]	Counter spring	[702]	Friction disk
[52b]	Brake plate (BE122 only)	[68]	Brake disk	[732]	Cover plate
[54]	Magnet body, complete	[68b]	Brake disk (BE12 only)	[733]	Screw
[60]	Stud 3x	[69]	Circular spring		

7.7.11 Setting the working air gap of BE05 – BE122 brakes

⚠ WARNING




Risk of crushing if the drive starts up unintentionally.

Severe or fatal injuries.

- Isolate the motor, brake, and forced cooling fan, if installed, from the power supply before starting work, safeguarding them against unintentional re-start.
- Carefully observe the following steps!

1. Remove the following:
 - Forced cooling fan and rotary encoder, if installed.
See chapter "Motor and brake maintenance – preliminary work" (→ 104)
 - Flange cover or fan guard [35]
2. Push the rubber sealing strip [66] aside
 - Release the clamping strap, if necessary
 - Vacuum up the abraded matter
3. Measure the brake disc [68]:
 - Minimum brake disc thickness; see chapter "Technical Data" (→ 150).
 - If necessary, replace brake disk according to chapter Replacing the brake disk of BE05 – BE122 brakes (→ 135).
4. **BE30 – 122:** Unfasten the setting sleeve [67] by turning it towards the B-side end-shield
5. Measure the working air gap A (see following figure)
(use a feeler gauge and measure at three points offset by 120°):
 - **For BE05 – 11:** between pressure plate [49] and damping plate [718]
 - **For BE20 – 122:** between pressure plate [49] and magnet body [54]




18014398689460619

- **BE050 – 20:** Tighten the hex nuts [61] until the working air gap is set correctly; see chapter "Technical Data."
- **BE30 – 62:** Tighten the hex nuts [61] until the working air gap is 0.25 mm.
- **BE120 – 122:** Tighten the hex nuts [61] until the working air gap is 0.30 mm.
- **If you are mounting the BE32 in a vertical position, set the 3 springs of the brake plate to the following measurement:**

Mounting position	X in mm
Brake at the top	7.3
Brake at the bottom	7.3

- **If you are mounting the BE62 – 122 brakes in a vertical position, set the 3 springs on the brake plate as follows:**

Mounting position	X in mm
Brake at the top	10.0
Brake at the bottom	10.0



- [49] Pressure plate [68b] Brake disk (BE32, BE62, BE122)
 [52b] Brake plate (BE32, BE62, BE122) [900] Hex nut
 [68] Brake disk

7. **BE30 – 122:** Fasten the setting sleeves [67] against the magnet body with screws until the appropriate working air gap is set; see chapter "Technical data (→ 150)".
8. Install the sealing strip back in place and re-install the dismantled parts.

7.7.12 Replacing the brake disk of BE05 – BE122 brakes

In addition to the brake elements listed in column "BE brake," see chapter "Inspection and maintenance intervals" (→ 101); check the hex nuts [61] for wear when you replace the brake disk. You must always replace the hex nuts [61] when you replace the brake disk.



▲ WARNING

Risk of crushing if the drive starts up unintentionally.
Severe or fatal injuries.

- Isolate the motor, brake, and forced cooling fan, if installed, from the power supply before starting work, safeguarding them against unintentional re-start.
- Carefully observe the following steps!

INFORMATION



- The brake of DR..71 – 80, DRN80 motor sizes cannot be removed from the motor because the BE brake is directly installed on the brake endshield of the motor.
- The brake of DR..90 – 315, DRN90 – 315 motor sizes cannot be removed from the motor for replacing the brake disk because the BE brake is pre-installed on the brake endshield of the motor with a friction disk.

1. Remove the following:

- Forced cooling fan and rotary encoder, if installed.
See chapter "Motor and brake maintenance – preliminary work" (→ 104).
- Flange cover or fan guard [35], circlip [32/62] and fan [36]

2. Remove the brake cable

- **BE05 – 11:** Remove the terminal box cover and unfasten the brake cable from the rectifier.
- **BE20 – 122:** Loosen locking screws of the brake plug connector [698] and remove plug connector.

3. Remove the rubber sealing strip [66]

4. Remove manual brake release if installed.

- Adjusting nuts [58], conical springs [57], studs [56], releasing lever [53], dowel pin [59] (if installed), conical seat [255], spherical washer [256]

5. Loosen hex nuts [61], carefully pull off the magnet body [54] (brake cable!) and take out the brake springs [50].

6. **BE05 – 11:** Remove the damping plate [718], pressure plate [49] and brake disk [68]

BE20, BE30, BE60, BE120: Remove pressure plate [49] and brake disk [68]

BE32, BE62, BE122: Remove pressure plate [49], brake disks [68] and [68b]

7. Clean the brake components.

8. Install a new brake disk(s).

9. Re-install the brake components,

- Except for the fan and the fan guard, because the working air gap has to be set first; see chapter "Setting the working air gap of BE05 – BE122 brakes" (→ 133)".

10. In case of manual brake release: Use the adjusting nuts to adjust the floating clearance "s" between the conical springs (pressed flat) and the adjusting nuts (see following figure).




▲ WARNING

No braking due to incorrectly set floating clearance "s."

Severe or fatal injuries.

- Set the floating clearance "s" correctly according to the following figure and table so that the pressure plate can move up as the brake lining wears.



177241867

Brakes	Floating clearance s in mm
BE05, BE1, BE2, BE5	1.5
BE11, BE20, BE30, BE32, BE60, BE62, BE120, BE122	2

11. Put the sealing strip in place and re-install the dismantled parts.

INFORMATION



- The lockable manual brake release (type HF) is already released if a resistance is encountered when operating the set screw.
- The self-reengaging manual brake release (type HR) can be operated with normal hand pressure.
- In brakemotors with self-reengaging manual brake release, the hand lever must be removed after startup/maintenance! A holding fixture is provided for storing the lever on the outside of the motor.

INFORMATION




Note: After replacement of the brake disk, the maximum braking torque is reached only after several cycles.

7.7.13 Changing the braking torque of BE05 – BE122 brakes

The braking torque can be altered in stages.

- By changing the type and number of brake springs
- By changing the complete magnet body (only possible for BE05 and BE1)
- By changing the brake (from motor size DR..90, DRN90).
- By changing to a double-disk brake (BE30 only)

For the possible braking torque steps, please refer to chapter "Technical Data" (→  150).

7.7.14 Changing the brake spring of BE05 – BE122 brakes

**▲ WARNING**

Risk of crushing if the drive starts up unintentionally.

Severe or fatal injuries.

- Isolate the motor, brake, and forced cooling fan, if installed, from the power supply before starting work, safeguarding them against unintentional re-start.
- Carefully observe the following steps!

1. Remove the following:

- Forced cooling fan and rotary encoder, if installed.

See chapter "Motor and brake maintenance – preliminary work" (→ 104).

- Flange cover or fan guard [35], circlip [32/62] and fan [36]

2. Remove the brake cable

- **BE05 – 11:** Remove the terminal box cover and unfasten the brake cable from the rectifier.
- **BE20 – 122:** Loosen locking screws of the brake plug connector [698] and remove plug connector.

3. Remove the sealing strip [66] and the manual brake release:

- Adjusting nuts [58], conical springs [57], studs [56], releasing lever [53], dowel pin [59] (if installed), conical seat [255], spherical washer [256]

4. Unfasten hex nuts [61] and pull off the magnet body [54]

- By approx. 50 mm (2.0 in) (watch the brake cable)

5. Change or add brake springs [50/276/265]

- Position the brake springs symmetrically

6. Re-install the brake components,

- Except for the fan and the fan guard, because the working air gap has to be set first; see chapter "Setting the working air gap of BE05 – BE122 brakes (→ 133)".


7. In case of manual brake release: Use the adjusting nuts to adjust the floating clearance "s" between the conical springs (pressed flat) and the adjusting nuts (see following figure).

**▲ WARNING**

No braking due to incorrectly set floating clearance "s."

Severe or fatal injuries.

- Set the floating clearance "s" correctly according to the following figure and table so that the pressure plate can move up as the brake lining wears.



177241867

Brakes	Floating clearance s in mm
BE05, BE1, BE2, BE5	1.5
BE11, BE20, BE30, BE32, BE60, BE62, BE120, BE122	2

8. Put the sealing strip in place and re-install the dismantled parts.

INFORMATION



Replace adjusting nuts [58] and hex nuts [61] if the removal procedure is repeated.

7.7.15 Changing the magnet body of BE05 – BE122 brakes

**▲ WARNING**

Risk of crushing if the drive starts up unintentionally.

Severe or fatal injuries.

- Isolate the motor, brake, and forced cooling fan, if installed, from the power supply before starting work, safeguarding them against unintentional re-start.
- Carefully observe the following steps!

1. Remove the following:

- Forced cooling fan and rotary encoder, if installed.

See chapter "Motor and brake maintenance – preliminary work" (→ 104)

- Flange cover or fan guard [35], circlip [32/62] and fan [36]

2. Remove the sealing strip [66] and the manual brake release:

- Adjusting nuts [58], conical springs [57], studs [56], releasing lever [53], spiral dowel pin [59]

3. Remove the brake cable

- **BE05 – 11:** Remove the terminal box cover and unfasten the brake cable from the rectifier.
- **BE20 – 122:** Loosen locking screws of the brake plug connector [698] and remove plug connector.

4. Unfasten hex nuts [61], remove complete magnet body [54], remove brake springs [50/276].

5. Install new magnet body with brake springs. For the possible braking torque steps, please refer to chapter "Technical Data" (→ 150).

6. Re-install the brake components,

- Except for the fan and the fan guard, because the working air gap has to be set first; see chapter "Setting the working air gap of BE05 – BE122 brakes" (→ 133).


7. In case of manual brake release: Use the adjusting nuts to adjust the floating clearance "s" between the conical springs (pressed flat) and the adjusting nuts (see following figure).

**▲ WARNING**

No braking due to incorrectly set floating clearance "s."

Severe or fatal injuries.

- Set the floating clearance "s" correctly according to the following figure and table so that the pressure plate can move up as the brake lining wears.



177241867

Brakes	Floating clearance s in mm
BE05, BE1, BE2, BE5	1.5
BE11, BE20, BE30, BE32, BE60, BE62, BE120, BE122	2

8. Put the sealing strip in place and re-install the dismantled parts.
9. Replace brake control in the event of an interturn short circuit or a short circuit to frame.

INFORMATION



Replace adjusting nuts [58] and hex nuts [61] if the removal procedure is repeated.

7.7.16 Changing the brake of DR..71 – 80, DRN80 motors

**▲ WARNING**

Risk of crushing if the drive starts up unintentionally.

Severe or fatal injuries.

- Isolate the motor, brake, and forced cooling fan, if installed, from the power supply before starting work, safeguarding them against unintentional re-start.
- Carefully observe the following steps!

1. Remove the following:

- Forced cooling fan and rotary encoder, if installed.

See chapter "Motor and brake maintenance – preliminary work" (→ 104)

- Flange cover or fan guard [35], circlip [32/62] and fan [36]

2. Remove the terminal box cover and loosen the brake cable from the rectifier. If necessary, attach trailing wire to brake cables.

3. Loosen machine screws [13] and remove brake endshield with brake from stator.

4. Insert the brake cable of the new brake into the terminal box.

5. Install the new brake, observing the alignment of the cams of the brake endshield.

6. Reseal the shaft:

- Replace the sealing ring [95]
- Apply grease to the sealing lip (see chapter "Order information for lubricants and anti-corrosion agents" (→ 166)).


7. In case of manual brake release: Use the adjusting nuts to adjust the floating clearance "s" between the conical springs (pressed flat) and the adjusting nuts (see following figure).

**▲ WARNING**

No braking due to incorrectly set floating clearance "s."

Severe or fatal injuries.

- Set the floating clearance "s" correctly according to the following figure and table so that the pressure plate can move up as the brake lining wears.



177241867

Brakes	Floating clearance s in mm
BE05, BE1, BE2	1.5

7.7.17 Changing the brakes for DR..90 – 225, DRN90 – 225



▲ WARNING

Risk of crushing if the drive starts up unintentionally.

Severe or fatal injuries.

- Isolate the motor, brake, and forced cooling fan, if installed, from the power supply before starting work, safeguarding them against unintentional re-start.
- Carefully observe the following steps!

1. Remove the following:
 - Forced cooling fan and rotary encoder, if installed.
See chapter "Motor and brake maintenance – preliminary work" (→ 104)
 - Flange cover or fan guard [35], circlip [32/62] and fan [36]
2. Remove the brake cable
 - **BE05 – 11:** Remove the terminal box cover and unfasten the brake cable from the rectifier.
 - **BE20 – 32:** Loosen locking screws of the brake plug connector [698] and remove plug connector.
3. Unfasten screws [900] and remove brake from brake endshield.
4. **DR..90 – 132, DRN90 – 132S:** Pay attention to the alignment of the gasket [901].
5. Connect the brake cables of the new brake.
6. Install the new brake, observing the alignment of the cams of the friction disk.
7. Reseal the shaft:
 - Replace the sealing ring [95]
 - Apply grease to the sealing lip (see chapter "Order information for lubricants and anti-corrosion agents" (→ 166)).
8. In case of manual brake release: Use the adjusting nuts to adjust the floating clearance "s" between the conical springs (pressed flat) and the adjusting nuts (see following figure).




▲ WARNING

No braking due to incorrectly set floating clearance "s."

Severe or fatal injuries.

- Set the floating clearance "s" correctly according to the following figure and table so that the pressure plate can move up as the brake lining wears.



177241867

Brakes	Floating clearance s in mm
BE05, BE1, BE2, BE5	1.5
BE11, BE20, BE30, BE32	2

7.7.18 Changing the brakes for DR..250 – 315, DRN250 – 315



⚠ WARNING

Risk of crushing if the drive starts up unintentionally.

Severe or fatal injuries.

- Isolate the motor, brake, and forced cooling fan, if installed, from the power supply before starting work, safeguarding them against unintentional re-start.
- Carefully observe the following steps!

1. Remove the following:

- Forced cooling fan and rotary encoder, if installed.

See chapter "Motor and brake maintenance – preliminary work" (→ 104)

- Flange cover or fan guard [35], circlip [32/62] and fan [36]

2. **BE60 – 62:** Remove the brake cable

- Remove the terminal box cover and unfasten the brake cable from the rectifier.
- Connect the brake cables of the new brake

3. **BE120 – 122:** Unfasten brake connector.

4. Unfasten screws [900] and remove brake from brake endshield.

5. Install the new brake, observing the alignment of the cams of the friction disk.

6. Reseal the shaft:

- Replace the sealing ring [95]
- Apply grease to the sealing lip (see chapter "Order information for lubricants and anti-corrosion agents" (→ 166)).


7. In case of manual brake release: Use the adjusting nuts to adjust the floating clearance "s" between the conical springs (pressed flat) and the adjusting nuts (see following figure).

⚠ WARNING

No braking due to incorrectly set floating clearance "s."

Severe or fatal injuries.

- Set the floating clearance "s" correctly according to the following figure and table so that the pressure plate can move up as the brake lining wears.




177241867

Brakes	Floating clearance s in mm
BE60, BE62, BE120, BE122	2

7.8 Inspection/maintenance – DUB


7.8.1 Basic structure of DUB on DR..90 – 100 motors with BE2 brakes



9007200340056843

[49] Pressure plate for DUB	[556] Angle bracket	[561] Stud
[66] Sealing strip for DUB	[557] Stud	[562] Washer
[112] Terminal box lower part	[558] Hex head screw	[945] Countersunk screw
[379] Screw fitting	[559] Pan head screw	[946] Mounting plate complete
[555] Microswitch	[560] Hex head screw	

7.8.2 Basic structure of DUB on DR..90 – 315 motors with BE5 – BE122 brakes



1085317771

[49] Pressure plate for DUB	[556] Angle bracket	[561] Stud
[66] Sealing strip for DUB	[557] Stud	[562] Washer
[112] Terminal box lower part	[558] Hex head screw	
[379] Screw fitting	[559] Pan head screw	
[555] Microswitch	[560] Hex head screw	

7.8.3 Inspection/maintenance of the DUB for function monitoring

**▲ WARNING**

Risk of crushing if the drive starts up unintentionally.

Severe or fatal injuries.

- Isolate the motor and forced cooling fan, if installed, from the power supply before starting work, safeguarding them against unintentional re-start.
- Carefully observe the following steps!

1. Check and, if necessary, adjust the working air gap according to chapter "Setting the working air gap for BE.. brake."
2. Screw the hex head screw [560] against the actuator of the microswitch [555] until it trips (brown-blue contacts closed.)
Apply the hex nut [561] while screwing it in to eliminate the longitudinal play from the thread.
3. Turn hex head screw [560] back until microswitch [555] switches back (contacts brown-blue open).
4. To ensure operational reliability, turn hex head screw [560] further back by one-sixth of a revolution (0.1 mm)
5. Tighten hex nut [561], while doing so, hold hex head screw [560] to keep it in the correct position.
6. Switch the brake on and off several times. Check whether the microswitch opens and closes reliably in any motor shaft position. Therefore, change the position of the motor shaft manually several times.

7.8.4 Inspection/maintenance of the DUB for wear monitoring



▲ WARNING

Risk of crushing if the drive starts up unintentionally.

Severe or fatal injuries.

- Isolate the motor and forced cooling fan, if installed, from the power supply before starting work, safeguarding them against unintentional re-start.
- Carefully observe the following steps!

1. Check and, if necessary, adjust the working air gap according to chapter "Setting the working air gap for BE.. brake."
2. Screw the hex head screw [560] against the actuator of the microswitch [555] until it trips (brown-blue contacts closed.)
Apply the hex nut [561] while screwing it in to eliminate the longitudinal play from the thread.
3. **For BE2 – 5:** Loosen hex head screw [560] by a 3/4 revolution towards the microswitch [555] (with BE2 by about 0.375 mm / with BE5 by about 0.6 mm).
For BE11 – 122: Loosen hex head screw [560] towards the microswitch [555] by a whole revolution (about 0.8 mm).
4. Tighten hex nut [561], while doing so, hold hex head screw [560] to keep it in the correct position.
5. If the brake lining reaches the wear limit, the microswitch automatically switches back (contacts brown-blue open) and activates a relay or a signal.

7.8.5 Inspection/maintenance of the DUB for function and wear monitoring

If two DUB are connected to one brake, both monitoring statuses can be realized. In this case, set the DUB for wear monitoring before you set the DUB for function monitoring.

8 Technical data

8.1 Work done, working air gap, braking torques

If you use encoders and brakes with functional safety technology, the values for the maximum working air gaps and the work done until maintenance are reduced. For the new values, refer to the "Safety-Rated Encoders – Functional Safety for AC Motors DR.71–225, 315" addendum to the operating instructions.

Brakes type	Work done until maintenance	Working air gap		Brake disk min.	Part number damping plate/pole sheet	Braking torque settings				
		min. ¹⁾	max.			Brake torque	Type and number of brake springs			Purchase order number for brake springs
		10 ⁶ J	mm	mm			Normal	Blue	White	
BE05	120	0.25	0.6	9.0	13740563	5.0 (44) 3.5 (31) 2.5 (22) 1.8 (16)	3 – – –	– 6 4 3	– – – –	0135017X 13741373
BE1	120	0.25	0.6	9.0	13740563	10 (88.5) 7.0 (62) 5.0 (44)	6 4 3	– 2 –	– – –	0135017X 13741373
BE2	180	0.25	0.6	9.0	13740199	20 (177) 14 (124) 10 (88.5) 7.0 (62) 5.0 (44)	6 2 2 – –	– 4 2 4 3	– – – – –	13740245 13740520
BE5	390	0.25	0.9	9.0	13740695	55 (487) 40 (354) 28 (248)	6 2 2	– 4 2	– – –	13740709 13747738
						20 (177) 14 (124)	– –	– –	6 4	
BE11	640	0.3	1.2	10.0	1374 171 3	110 (974) 80 (708) 55 (487) 40 (354)	6 2 2 –	– 4 2 4	– – – –	13741837 13741845
					13741713 + 13746995	28 (248) 20 (177)	– –	3 –	– 4	
										13741837 13747789
BE20	1000	0.3	1.2	10.0	–	200 (1770) 150 (1328) 110 (974) 80 (708) 55 (487)	6 4 3 3 –	– 2 3 – 4	– – – – –	13743228 13742485
					1374 675 8	40 (354)	–	3	–	
BE30	1500	0.3	1.2	10.0	–	300 (2655) 200 (1770) 150 (1328) 100 (885) 75 (667)	8 4 4 – –	– 4 – 8 6	– – – – –	01874551 13744356
BE32	1500	0.4	1.2	10.0	–	600 (5310) 500 (4425) 400 (3540) 300 (2655) 200 (1770) 150 (1328)	8 6 4 4 – –	– 2 4 – 8 6	– – – – – –	01874551 13744356
					13746731	100 (885)	–	4	–	
BE60	2500	0.3	1.2	10.0	–	600 (5310) 500 (4425) 400 (3540) 300 (2655) 200 (1770)	8 6 4 4 –	– 2 4 – 8	– – – – –	01868381 13745204
BE62	2500	0.4	1.2	10.0	–	1200 (10621) 1000 (8851) 800 (7081) 600 (5310) 400 (3540)	8 6 4 4 –	– 2 4 – 8	– – – – –	01868381 13745204

Brakes type	Work done until maintenance	Working air gap		Brake disk	Part number damping plate/pole sheet	Braking torque settings					
		min. ¹⁾	max.	min.		Brake torque	Type and number of brake springs			Purchase order number for brake springs	
	10 ⁶ J	mm		mm		Nm (lb-in)	Normal	Blue	White	Normal	Blue/white
BE120	390	0.6	1.2	12.0	—	1000 (8851)	8	—	—	13608770	13608312
						800 (7081)	6	2	—		
						600 (5310)	4	4	—		
						400 (3540)	4	—	—		
BE122	300	0.8	1.2	12.0	—	2000 (17701)	8	—	—	13608770	13608312
						1600 (14161)	6	2	—		
						1200 (10621)	4	4	—		
						800 (7081)	4	—	—		

1) When checking the working air gap, note: Parallelism tolerances on the brake disk may give rise to deviations of ± 0.15 mm after a test run.

The following table shows the brake spring layout:

BE05 – 11:					
6 springs	3 + 3 springs	4 + 2 springs	2 + 2 springs	4 springs	3 springs
BE20:					
6 springs	4 + 2 springs	3 + 3 springs	4 springs	3 springs	
BE30 – 122:					
8 springs	6 + 2 springs	4 + 4 springs	6 springs	4 springs	

INFORMATION



Due to the pivoted mounting position/pivoting angle selected, the work done by the brake is reduced to 50% of the values specified here.

8.2 Braking torque assignment

8.2.1 Motor sizes DR..71 – 100, DRN80 – 100

Motor type	Brake type	Braking torque steps in Nm (lb-in)										
DR..71	BE05	1.8 (16)	2.5 (22)	3.5 (31)	5.0 (44)							
	BE1				5.0 (44)	7.0 (62)	10 (88)					
DR..80 DRN80	BE05	1.8 (16)	2.5 (22)	3.5 (31)	5.0 (44)							
	BE1				5.0 (44)	7.0 (62)	10 (88)					
	BE2				5.0 (44)	7.0 (62)	10	14 (124)	20 (177)			
DR..90 DRN90	BE1				5.0 (44)	7.0 (62)	10 (88)					
	BE2				5.0 (44)	7.0 (62)	10 (88)	14 (124)	20 (177)			
	BE5							14 (124)	20 (177)	28 (248)	40 (354)	55 (487)
DR..100 DRN100	BE2				5.0 (44)	7.0 (62)	10	14 (124)	20 (177)			
	BE5							14 (124)	20 (177)	28 (248)	40 (354)	55 (487)

8.2.2 Motor sizes DR..112 – 225, DRN112 – 225

Motor type	Brake type	Braking torque steps in Nm (lb-in)										
DR..112 DRN112	BE5	14 (124)	20 (180)	28 (248)	40 (354)	55 (487)						
	BE11			20 (180)	40 (354)	55 (487)	80 (708)	110 (974)				
DR..132 DRN132S	BE5			28 (248)	40 (354)	55 (487)						
	BE11			20 (180)	40 (354)	55 (487)	80 (708)	110 (974)				
DR..160 DRN132M/L	BE11			20 (180)	40 (354)	55 (487)	80 (708)	110 (974)				
	BE20				40 (354)	55 (487)	80 (708)	110 (974)	150 (1328)	200 (1770)		
DR..180 DRN160 – 180	BE20				40 (354)	55 (487)	80 (708)	110 (974)	150 (1328)	200 (1770)		
	BE30						75 (667)	100 (885)	150 (1328)	200 (1770)	300 (2655)	
	BE32							100 (885)	150 (974)	200 (1770)	300 (2655)	400 (3540) 500 (4425) 600 (5310)
DR..200/225 DRN200 – 225	BE30						75 (667)	100 (885)	150 (974)	200 (1770)	300 (2655)	
	BE32							100 (885)	150 (1328)	200 (1770)	300 (2655)	400 (3540) 500 (4425) 600 (5310)

8.2.3 Motor sizes DR..250 – 280, DRN250 – 280

Motor type	Brake type	Braking torque steps in Nm (lb-in)								
DR..250/280 DRN250 – 280	BE60	200	300	400 (3540)	500 (4425)	600 (5310)				
	BE62			400 (3540)		600 (5310)	800 (7081)	1000 (8851)	1200 (10621)	
	BE120			400 (3540)		600 (5310)	800 (7081)	1000 (8851)		
	BE122						800 (7081)		1200 (10621)	1600 (14161)

8.2.4 Motor sizes DR..315, DRN315

Motor type	Brake type	Braking torque steps in Nm (lb-in)								
DR..315 DRN315	BE120	400 (3540)	600 (5310)	800 (7081)	1000 (8851)					
	BE122			800 (7081)		1200 (10621)	1600 (14161)	2000 (17701)		

8.3 Operating currents

8.3.1 Brake BE05, BE1, BE2

The current values I_H (holding current) listed in the tables are r.m.s. values. Measure the r.m.s. values using only the appropriate measuring instruments. The inrush current (accelerator current) I_B only flows for a short time (ca. 160 ms) when the brake is released. There is no increased inrush current if a BG or BMS brake rectifier is used or if there is a direct DC voltage supply (only possible with brakes up to size BE2).

	BE05, BE1	BE2
Max. braking torque in Nm (lb-in)	5/10 (44/88)	20 (177)
Braking power in W (hp)	32 (0.043)	43 (0.058)
Inrush current ratio I_B/I_H	4	4

Nominal voltage V_N		BE05, BE1		BE2	
V_{AC}	V_{DC}	I_H A_{AC}	I_{DC} A_{DC}	I_H A_{AC}	I_G A_{DC}
24 (23-26)	10	2.25	2.90	2.95	3.80
60 (57-63)	24	0.90	1.17	1.18	1.53
120 (111-123)	48	0.45	0.59	0.59	0.77
147 (139-154)	60	0.36	0.47	0.48	0.61
184 (174-193)	80	0.29	0.37	0.38	0.49
208 (194-217)	90	0.26	0.33	0.34	0.43
230 (218-243)	96	0.23	0.30	0.30	0.39
254 (244-273)	110	0.20	0.27	0.27	0.35
290 (274-306)	125	0.18	0.24	0.24	0.31
330 (307-343)	140	0.16	0.21	0.21	0.28
360 (344-379)	160	0.14	0.19	0.19	0.25
400 (380-431)	180	0.13	0.17	0.17	0.22
460 (432-484)	200	0.11	0.15	0.15	0.19
500 (485-542)	220	0.10	0.13	0.14	0.18
575 (543-600)	250	0.09	0.12	0.12	0.16

Key

I_B	Acceleration current – brief inrush current
I_H	Holding current r.m.s. value in the supply cable to the SEW brake rectifier
I_{DC}	Direct current with direct DC voltage supply
V_N	Nominal voltage (nominal voltage range)

8.3.2 Brakes BE5, BE11, BE20, BE30, BE32, BE60, BE62

The current values I_H (holding current) listed in the tables are r.m.s. values. Measure the r.m.s. values using only the appropriate measuring instruments. The inrush current (accelerator current) I_B only flows for a short time (ca. 160 ms) when the brake is released. A separate voltage supply is not possible.

	BE5	BE11	BE20	BE30, BE32	BE60, BE62
Max. braking torque in Nm (lb-in)	55 (487)	110 (974)	200 (1770)	300/600 (2655/5310)	600/1200 (5310/10620)
Braking power in W (hp)	49 (0.066)	77 (0.10)	100 (0.13)	130 (0.13)	195 (0.26)
Inrush current ratio I_B/I_H	5.7	6.6	7	10	9.2

Nominal voltage V_N		BE5	BE11	BE20	BE30, BE32	BE60, BE62
V_{AC}	V_{DC}	I_H A_{AC}	I_H A_{AC}	I_H A_{AC}	I_H A_{AC}	I_H A_{AC}
60 (57-63)	24	1.28	2.05	2.55	–	–
120 (111-123)	48	0.64	1.04	1.28	1.66	–
147 (139-154)	60	0.51	0.83	1.02	1.33	–
184 (174-193)	80	0.41	0.66	0.81	1.05	–
208 (194-217)	90	0.37	0.59	0.72	0.94	1.50
230 (218-243)	96	0.33	0.52	0.65	0.84	1.35
254 (244-273)	110	0.29	0.47	0.58	0.75	1.20
290 (274-306)	125	0.26	0.42	0.51	0.67	1.12
330 (307-343)	140	0.23	0.37	0.46	0.59	0.97
360 (344-379)	160	0.21	0.33	0.41	0.53	0.86
400 (380-431)	180	0.18	0.30	0.37	0.47	0.77
460 (432-484)	200	0.16	0.27	0.33	0.42	0.68
500 (485-542)	220	0.15	0.24	0.29	0.38	0.60
575 (543-600)	250	0.13	0.22	0.26	0.34	0.54

Key

- I_B Acceleration current – brief inrush current
- I_H Holding current r.m.s. value in the supply cable to the SEW brake rectifier
- I_{DC} Direct current with direct DC voltage supply
- V_N Nominal voltage (nominal voltage range)

8.3.3 Brake BE120, BE122

The current values I_H (holding current) listed in the tables are r.m.s. values. Measure the r.m.s. values using only the appropriate measuring instruments. The inrush current (acceleration current) I_B only flows for a short time (max. 400 ms) when the brake is released. A separate voltage supply is not possible.

	BE120	BE122
Max. braking torque in Nm (lb-in)	1000 (8851)	2000 (17701)
Braking power in W (hp)	250 (0.34)	250 (0.34)
Inrush current ratio I_B/I_H	4.9	4.9

Nominal voltage V_N		BE120	BE122
V_{AC}	V_{DC}	I_H A_{AC}	I_H A_{AC}
230 (218-243)	-	1.80	1.80
254 (244-273)	-	1.60	1.60
290 (274-306)	-	1.43	1.43
360 (344-379)	-	1.14	1.14
400 (380-431)	-	1.02	1.02
460 (432-484)	-	0.91	0.91
500 (485-542)	-	0.81	0.81
575 (543-600)	-	0.72	0.72

Key

- I_B Acceleration current – brief inrush current
- I_H Holding current r.m.s. value in the supply cable to the SEW brake rectifier
- I_{DC} Direct current with direct DC voltage supply
- V_N Nominal voltage (nominal voltage range)

8.4 Resistors

8.4.1 Brake BE05, BE1, BE2, BE5

	BE05, BE1	BE2	BE5
Max. braking torque in Nm (lb-in)	5/10 (44/88)	20 (177)	55 (487)
Braking power in W (hp)	3.2 (0.043)	43 (0.058)	49 (0.066)
Inrush current ratio I_B/I_H	4	4	5.7

Nominal voltage V_N		BE05, BE1		BE2		BE5	
V_{AC}	V_{DC}	R_B	R_T	R_B	R_T	R_B	R_T
24 (23-26)	10	0.77	2.35	0.57	1.74	–	–
60 (57-63)	24	4.85	14.8	3.60	11.0	2.20	10.5
120 (111-123)	48	19.4	59.0	14.4	44.0	8.70	42.0
147 (139-159)	60	30.5	94.0	23.0	69.0	13.8	66
184 (174-193)	80	48.5	148	36.0	110	22.0	105
208 (194-217)	90	61.0	187	45.5	139	27.5	132
230 (218-243)	96	77.0	235	58.0	174	34.5	166
254 (244-273)	110	97.0	296	72.0	220	43.5	210
290 (274-306)	125	122	372	91	275	55.0	265
330 (307-343)	140	154	469	115	350	69.0	330
360 (344-379)	160	194	590	144	440	87.0	420
400 (380-431)	180	244	743	182	550	110	530
460 (432-484)	200	308	935	230	690	138	660
500 (485-542)	220	387	1178	290	870	174	830
575 (543-600)	250	488	1483	365	1100	220	1050

8.4.2 Brakes BE11, BE20, BE30, BE32, BE60, BE62


	BE11	BE20	BE30, BE32	BE60, BE62
Max. braking torque in Nm (lb-in)	110 (974)	200 (1770)	300/600 (2655/5310)	600/1200 (5310/10620)
Braking power in W (hp)	77 (0.10)	100 (0.13)	130 (0.17)	195 (0.26)
Inrush current ratio I_B/I_H	6.6	7.5	8.5	9.2

Nominal voltage V_N		BE11		BE20		BE30, BE32		BE60, BE62	
V_{AC}	V_{DC}	R_B	R_T	R_B	R_T	R_B	R_T	R_B	R_T
60 (57-63)	24	1.22	7.0	0.9	5.7	—	—	—	—
120 (111-123)	48	4.90	28.0	3.4	22.8	2.3	17.2	—	—
147 (139-159)	60	7.7	44.0	5.4	36.1	3.7	27.3	—	—
184 (174-193)	80	12.3	70	8.5	57.2	5.8	43.2	—	—
208 (194-217)	90	15.5	88	10.7	72.0	7.3	54.4	4.0	32.6
230 (218-243)	96	19.5	111	13.5	90.6	9.2	68.5	5.0	41.0
254 (244-273)	110	24.5	139	17.0	114.1	11.6	86.2	6.3	51.6
290 (274-306)	125	31.0	175	21.4	14.6	14.6	108.6	7.9	65.0
330 (307-343)	140	39.0	220	26.9	180.8	18.4	136.7	10.0	81.8
360 (344-379)	160	49	280	33.9	228	23.1	172.1	12.6	103
400 (380-431)	180	62	350	42.7	287	29.1	217	15.8	130
460 (432-484)	200	78	440	53.7	361	36.6	273	19.9	163
500 (485-542)	220	98	550	67.7	454	46.1	343	25.1	205
575 (543-600)	250	123	700	85.2	570	58.0	423	31.6	259

8.4.3 Resistance measurement BE05, BE1, BE2, BE5, BE30, BE32, BE60, BE62

Cut-off in the AC circuit


The following illustration shows how to measure resistance with cut-off in the AC circuit.



9007199497350795

Cut-off in the DC and AC circuits

The following illustration shows how to measure resistance with cut-off in the DC and AC circuits.



18014398752093451

BS accelerator coil
TS coil section
 R_B Accelerator coil resistance at 20 °C in Ω
 R_T Coil section resistance at 20 °C in Ω
 V_N nominal voltage (nominal voltage range)

RD red
WH white
BU blue

INFORMATION



When measuring the resistance of the coil section R_T or the accelerator coil R_B , remove the white conductor from the brake rectifier; if it remains connected, the internal resistance of the brake rectifier will cause erroneous results.


8.4.4 Brake BE120, BE122

		BE120, BE122	
Max. braking torque in Nm (lb-in)		1000/2000 (8851/17701)	
Braking power in W (hp)		250 (0.34)	
Inrush current ratio I_B/I_H		4.9	

Nominal voltage V_N		BE120, BE122	
V_{AC}	V_{DC}	R_B	R_T
230 (218-243)	—	8.0	29.9
254 (244-273)	—	10.1	37.6
290 (274-306)	—	12.7	47.4
360 (344-379)	—	20.1	75.1
400 (380-431)	—	25.3	94.6
460 (432-484)	—	31.8	119.0
500 (485-542)	—	40.1	149.9
575 (543-600)	—	50.5	188.7

8.4.5 Resistance measurement BE120, BE122

The following illustration shows how to measure resistance with BMP 3.1.



409000587

BS accelerator coil
 TS coil section
 R_B Accelerator coil resistance at 20 °C in Ω
 R_T Coil section resistance at 20 °C in Ω
 V_N nominal voltage (nominal voltage range)



INFORMATION

When measuring the resistance of the coil section R_T or the accelerator coil R_B , remove the white conductor from the brake rectifier; if it remains connected, the internal resistance of the brake rectifier will cause erroneous results.

8.5 Brake control system

8.5.1 Permitted combinations

The table below shows the standard and optional combinations of brakes and brake rectifiers.

		BE05	BE1	BE2	BE5	BE11	BE20	BE30, BE32	BE60, BE62	BE120, BE122
BG	BG 1.4	X ³	X ³	X ³	–	–	–	–	–	–
	BG 1.5	X ¹	X ¹	X ¹	•	–	–	–	–	–
	Size 3	X ²	X ²	X ²	–	–	–	–	–	–
BGE	BGE 1.4	o	o	o	X ³	X ³	X ³	X ³	X ³	–
	BGE 1.5	•	•	•	X ¹	X ¹	X ¹	X ¹	X	–
	BGE 3	•	•	•	X ²	X ²	X ²	X ²	X	–
BS	BS 24	X	X	X	•	–	–	–	–	–
BMS	BMS 1.4	o	o	o	–	–	–	–	–	–
	BMS 1.5	•	•	•	–	–	–	–	–	–
	BMS 3	•	•	•	–	–	–	–	–	–
BME	BME 1.4	o	o	o	o	o	o	o	o	–
	BME 1.5	•	•	•	•	•	•	•	X	–
	BME 3	•	•	•	•	•	•	•	X	–
BMH	BMH 1.4	o	o	o	o	o	o	o	–	–
	BMH 1.5	•	•	•	•	•	•	•	–	–
	BMH 3	•	•	•	•	•	•	•	–	–
BMK	BMK 1.4	o	o	o	o	o	o	o	o	–
	BMK 1.5	•	•	•	•	•	•	•	–	–
	BMK 3	•	•	•	•	•	•	•	–	–
BMP	BMP 1.4	o	o	o	o	o	o	o	o	–
	BMP 1.5	•	•	•	•	•	•	•	–	–
	BMP 3	•	•	•	•	•	•	•	–	–
	BMP 3.1	–	–	–	–	–	–	–	–	X
BMV	BMV 5	•	•	•	•	•	•	–	–	–
BSG	BSG	•	•	•	X	X	X	–	–	–

		BE05	BE1	BE2	BE5	BE11	BE20	BE30, BE32	BE60, BE62	BE120, BE122
BSR	BGE 1.4 + SR 15	o	o	o	o	o	o	o	o	–
	BGE 3 + SR 11	•	•	•	•	•	–	–	–	–
	BGE 3 + SR 15	•	•	•	•	•	•	•	–	–
	BGE 1.5 + SR 11	•	•	•	•	•	–	–	–	–
	BGE 1.5 + SR 15	•	•	•	•	•	•	•	–	–
BUR	BGE 3 + UR 11	•	•	•	•	–	–	–	–	–
	BGE 1.5 + UR 15	•	•	•	•	•	•	•	–	–

X Standard design

X¹ Standard design with nominal brake voltage of 150 - 500 V_{AC}

X² Standard design with nominal brake voltage of 24/42 - 150 V_{AC}

X³ Standard design with nominal brake voltage of 575 V_{AC}

• Optional

o Option for nominal brake voltage of 575 V_{AC}

– Not permitted

8.5.2 Wiring space of the motor

The following table lists the technical data of brake control systems for installation in the motor wiring space and the assignments with regard to motor size and connection technology. The different housings have different colors (= color code) to make them easier to distinguish.

Type	Function	Voltage	Holding current I_{Hmax} in A	Type	Part number	Color code
BG	One-way rectifier	AC 150 – 500 V	1.5	BG 1.5	8253846	Black
		AC 24 – 500 V	3.0	BG 3	8253862	Brown
BGE	One-way rectifier with electronic switching	AC 150 – 500 V	1.5	BGE 1.5	8253854	Red
		AC 42 – 150 V	3.0	BGE 3	8253870	Blue
BSR	Half-wave rectifier + current relay for switch-off in the DC circuit	AC 150 – 500 V	1.0	BGE 1.5 + SR 11	8253854 8267618	
			1.0	BGE 1.5 + SR 15	8253854 8267626	
		AC 42 – 150 V	1.0	BGE 3 + SR11	8253870 8267618	
			1.0	BGE 3 + SR15	8253870 8267626	
BUR	Half-wave rectifier + voltage relay for switch-off in the DC circuit	AC 150 – 500 V	1.0	BGE 1.5 + UR 15	8253854 8267596	
		AC 42 – 150 V	1.0	BGE 3 + UR 11	8253870 8267588	
BS	Varistor protection circuit	DC 24 V	5.0	BS24	8267634	Water blue
BSG	Electronic switching	DC 24 V	5.0	BSG	8254591	White
BMP	Half-wave rectifier with electronic switching, integrated voltage relay for switch-off in the DC circuit	AC 230 – 575 V	2.8	BMP 3.1 ¹⁾	8295077	

1) Only sizes 280M, 315

8.5.3 Control cabinet

The following table lists the technical data of brake control systems for installation in the control cabinet and the assignments with regard to motor size and connection technology. The different housings have different colors (= color code) to make them easier to distinguish.

Type	Function	Voltage	Holding current I_{Hmax} in A	Type	Part number	Color code
BMS	One-way rectifier as BG	AC 230 – 575 V	1.0	BMS 1.4	8298300	Black
		AC 150 – 500 V	1.5	BMS 1.5	8258023	Black
		AC 42 – 150 V	3.0	BMS 3	8258031	Brown
BME	One-way rectifier with electronic switching as BGE	AC 230 – 575 V	1.0	BME 1.4	8298319	Red
		AC 150 – 500 V	1.5	BME 1.5	8257221	Red
		AC 42 – 150 V	3.0	BME 3	825723X	Blue
BMH	One-way rectifier with electronic switching and heating function	AC 230 – 575 V	1.0	BMH 1.4	8298343	Green
		AC 150 – 500 V	1.5	BMH 1.5	825818X	Green
		AC 42 – 150 V	3	BMH 3	8258198	Yellow
BMP	One-way rectifier with electronic switching, integrated voltage relay for switch-off in the DC circuit	AC 230 – 575 V	1.0	BMP 1.4	8298327	White
		AC 150 – 500 V	1.5	BMP 1.5	8256853	White
		AC 42 – 150 V	3.0	BMP 3	8265666	Light blue
		AC 230 – 575 V	2.8	BMP 3.1 ¹⁾	8295077	
BMK	One-way rectifier with electronic switch mode, DC 24 V control input and separation in the DC circuit	AC 230 – 575 V	1.0	BMK 1.4	8298335	Water blue
		AC 150 – 500 V	1.5	BMK 1.5	8264635	Water blue
		AC 42 – 150 V	3.0	BMK 3	8265674	Bright red
BMV	Brake control unit with electronic switching, DC 24 V control input and fast switch-off	DC 24 V	5.0	BMV 5	13000063	White

1) Only sizes 280M, 315

8.6 Permitted rolling bearing types

8.6.1 Rolling bearing types for motor sizes DR..71 – 315, DRN80 – 315

Motor type	A-side bearing		B-side bearing	
	IEC motor	Gearmotor	AC motor	Brakemotor
DR..71	6204-2Z-J-C3	6303-2Z-J-C3	6203-2Z-J-C3	6203-2RS-J-C3
DR..80, DRN80	6205-2Z-J-C3	6304-2Z-J-C3	6304-2Z-J-C3	6304-2RS-J-C3
DR..90 – 100, DRN90 – 100	6306-2Z-J-C3		6205-2Z-J-C3	6205-2RS-J-C3
DR..112 – 132, DRN112 – 132S	6308-2Z-J-C3		6207-2Z-J-C3	6207-2RS-J-C3
DR..160, DRN132M/L	6309-2Z-J-C3		6209-2Z-J-C3	6209-2RS-J-C3
DR..180, DRN180	6312-2Z-J-C3		6213-2Z-J-C3	6213-2RS-J-C3
DR..200 – 225, DRN200 – 225	6314-2Z-J-C3		6314-2Z-J-C3	6314-2RS-J-C3
DR..250 – 280, DRN250 – 280	6317-2Z-J-C4		6315-2Z-J-C3	6315-2RS-J-C3
DR..315K, DRN315S	6319-J-C3	6319-J-C3	6319-J-C3	6319-J-C3
DR..315S, DRN315M		6322-J-C3		6322-J-C3
DR..315M, DRN315L				
DR..315L, DRN315H				

8.6.2 Motors with /ERF reinforced bearings for motor sizes DR..250 – 315, DRN250 – 315

Motor type	A-side bearing	B-side bearing	
		IEC motor	Gearmotor
DR..250 – 280, DRN250 – 280	NU317E-C3	6315-2Z-J-C3	
DR..315K, DRN315S	NU319E	6319-J-C3	6319-J-C3
DR..315S, DRN315M			6322-J-C3
DR..315M, DRN315L			
DR..315L, DRN315H			

8.6.3 /NIB current-insulated rolling bearings for motor sizes DR..200 – 315, DRN200 – 315

Motor type	B-side bearing	
	AC motor	Brakemotor
DR..200 – 225, DRN200 – 225	6314-J-C3-EI	6314-J-C3-EI
DR..250 – 280, DRN250 – 280	6315-Z-J-C3-EI	6315-Z-J-C3-EI
DR..315K, DRN315S	6319-J-C3-EI	6319-J-C3
DR..315S, DRN315M		6322-J-C3
DR..315M, DRN315L		
DR..315L, DRN315H		

8.7 Lubricant tables

8.7.1 Lubricant table for rolling bearings

INFORMATION



Using the wrong bearing greases could cause bearing damage.

Motors with sealed bearings

The bearings are 2Z or 2RS closed bearings and cannot be relubricated. This option is available for sizes DR..71 – 280, DRN80 – 280.

	Ambient temperature	Manufacturer	Type	DIN designation
Motor roller bearings	-20°C – +80°C	Esso	Polyrex EM ¹⁾	K2P-20
	+20°C – +100°C	Klüber	Barrierta L55/2 ²⁾	KX2U
	-40°C – +60°C	Kyodo Yushi	Multemp SRL ²⁾	K2N-40

1) Mineral lubricant (= Mineral-based rolling bearing grease)

2) Synthetic lubricant (= Synthetic-based roller bearing grease)

Motors with open bearings

The motors in sizes DR.250 – 315 have open bearings and can be equipped with a relubrication device.

	Ambient temperature	Manufacturer	Type	DIN designation
Motor roller bearings	-20°C – +80°C	Esso	Polyrex EM ¹⁾	K2P-20
	-40°C – +60°C	SKF	GXN ¹⁾	K2N-40

1) Mineral lubricant (= Mineral-based rolling bearing grease)

8.8 Order information for lubricants and anti-corrosion agents

Lubricants and anti-corrosion agents may be obtained directly from SEW-EURODRIVE using the following purchase order numbers.

Use	Manufacturer	Type	Quantity	Purchase order number
Lubricant for rolling bearings	Esso	Polyrex EM	400 g	09101470
	SKF	GXN	400 g	09101276
Lubricant for sealing rings	Klüber	Petamo GHY 133	10 g	04963458
Anti-corrosion agent and lubricant	SEW-EURODRIVE	NOCO [®] fluid	5.5 g	09107819

8.9 Encoders

8.9.1 ES7. and EG7.

Encoder type		ES7S	EG7S	ES7R	EG7R	ES7C	EG7C
For motors		DR..71 – 132 DRN80 – 132S	DR..160 – 280 DRN132M – 280	DR..71 – 132 DRN80 – 132S	DR..160 – 280 DRN132M – 280	DR..71 – 132 DRN80 – 132S	DR..160 – 280 DRN132M – 280
Supply voltage	U _B	DC 7 V – 30 V		DC 7 – 30 V		DC 4.75 – 30 V	
Max. current consumption	I _{in}	140 mA _{RMS}		160 mA _{RMS}		250 mA _{RMS}	
Max. pulse frequency	f _{max}	150 kHz		120 kHz		120 kHz	
Periods per revolution	A, B	1024		1024		1024	
	C	1		1		1	
Output amplitude per track	U _{high}	1 V _{SS}		≥ DC 2.5 V		≥ DC 2.5 V	
	U _{low}			≤ DC 0.5 V		≤ DC 1.1 V	
Signal output		Sin/Cos		TTL		HTL	
Output current per track	I _{out}	10 mA _{RMS}		25 mA _{RMS}		60 mA _{RMS}	
Pulse duty factor		Sin/Cos		1: 1 ± 10%		1: 1 ± 10%	
Phase angle A : B		90° ± 3°		90° ± 20°		90° ± 20°	
Vibration resistance		≤ 100 m/s²		≤ 100 m/s²	≤ 200 m/s²	≤ 100 m/s²	
Shock resistance		≤ 1000 m/s²	≤ 2000 m/s²	≤ 1000 m/s²	≤ 2000 m/s²	≤ 1000 m/s²	≤ 2000 m/s²
Maximum speed	n _{max}	6000 rpm		6000 rpm		6000 rpm	
Degree of protection		IP66		IP66		IP66	
Connection		Terminal box on incremental encoder					

8.9.2 EH7.

Encoder type		EH7R	EH7T	EH7C	EH7S
For motors		DR..315 DRN315			
Supply voltage	U_B	DC 10 V – 30 V	DC 5 V	DC 10 V - 30 V	
Max. current consumption	I_{in}	140 mA		225 mA	140 mA
Max. pulse frequency f_{max}	kHz	300			180
Periods per revolution	A, B	1024			
	C	1			
Output amplitude	U_{high}	≥ 2.5 V		$V_B - 3 V$	1 V _{SS}
	U_{low}	≤ 0.5 V		≤ 2.5 V	
Signal output		TTL (RS-422)		HTL	Sin/Cos
Output current per track	I_{out}	20 mA		30 mA	10 mA
Pulse duty factor		1: 1 ± 20%			90° ± 10°
Phase angle A : B		90° ± 20°			-
Vibration resistance at 10 Hz – 2 kHz		≤ 100 m/s ² (EN 60088-2-6)			
Shock resistance		≤ 2000 m/s ² (EN 60088-2-27)			
Maximum speed n_{max}	rpm	6000, 2500 at 60°C			
Degree of protection		IP65 (EN 60529)			
Connection		12-pin plug connector			

8.9.3 AS7Y and AG7Y

Encoder type		AS7Y	AG7Y
For motors		DR..71 – 132 DRN80 – 132S	DR..160 – 280 DRN132M – 280
Supply voltage	U_B	DC 7 – 30 V	
Max. current consumption	I_{in}	150 mA _{RMS}	
Max. pulse frequency	f_{max}	200 kHz	
Periods per revolution	A, B	2048	
	C	-	
Output amplitude per track	U_{high}	1 V _{SS}	
	U_{low}		
Signal output		Sin/Cos	
Output current per track	I_{out}	10 mA _{RMS}	
Pulse duty factor		Sin/Cos	
Phase angle A : B		90° ± 3°	
Scanning code		Gray Code	
Single-turn resolution		4096 increments/revolution	
Multi-turn resolution		4096 revolutions	
Data transmission		synchronous-serial	
Serial data output		Driver to EIA RS-422	
Serial pulse input		Recommended receiver to EIA RS-422	
Clock frequency		Permitted range: 100 – 2000 kHz (max. 100 m cable length with 300 kHz)	
Clock-pulse space period		12 – 30 µs	
Vibration resistance		≤ 100 m/s ²	
Shock resistance		≤ 1000 m/s ²	≤ 2000 m/s ²
Maximum speed	n_{max}	6000 rpm	
Degree of protection		IP66	
Connection		Terminal strip in pluggable connection cover	

8.9.4 AS7W and AG7W

Encoder type		AS7W	AG7W
For motors		DR..71 – 132 DRN80 – 132S	DR..160 – 280 DRN132M – 280
Supply voltage	U_B	DC 7 – 30 V	
Max. current consumption	I_{in}	140 mA _{RMS}	
Max. pulse frequency	f_{max}	200 kHz	
Periods per revolution	A, B	2048	
	C	–	
Output amplitude per track	U_{high}	1 V _{SS}	
	U_{low}		
Signal output		Sin/Cos	
Output current per track	I_{out}	10 mA _{RMS}	
Pulse duty factor		Sin/Cos	
Phase angle A : B		90° ± 3°	
Scanning code		Binary code	
Single-turn resolution		8192 increments/revolution	
Multi-turn resolution		65536 revolutions	
Data transmission		RS485	
Serial data output		Driver to EIA RS-485	
Serial pulse input		Recommended driver to EIA RS-422	
Clock frequency		9600 Bd	
Clock-pulse space period		–	–
Vibration resistance		≤ 100 m/s ²	≤ 200 m/s ²
Shock resistance		≤ 1000 m/s ²	≤ 2000 m/s ²
Maximum speed	n_{max}	6000 rpm	
Degree of protection		IP66	
Connection		Terminal strip in pluggable connection cover	

8.9.5 AH7Y

Encoder type		AH7Y
For motors		DR..315 DRN315
Supply voltage	U_B	DC 9 V – 30 V
Max. current consumption	I_{in}	160 mA
Periods per revolution	A, B	2048
	C	–
Output amplitude	U_{high}	$\geq 2.5 V_{SS}$
	U_{low}	$\leq 0.5 V_{SS}$
Max. pulse frequency		120 kHz
Signal output		TTL (RS-422)
Output current per track	I_{out}	20 mA
Pulse duty factor		1: 1 \pm 20%
Phase angle A : B		90° \pm 20°
Absolute encoder scanning code		Gray Code
Single-turn resolution		4096 increments/revolution
Multi-turn resolution		4096 revolutions
Data transmission of absolute value		Synchronous, serial (SSI)
Serial data output		Driver to EIA RS-485
Serial pulse input		Optocoupler, recommended driver to EIA RS-485
Clock frequency		Permitted range: 100 – 800 kHz (max. 100 m cable length with 300 kHz)
Clock-pulse space period		12 ms – 30 ms
Vibration resistance at 10 Hz – 2 kHz		$\leq 100 \text{ m/s}^2$ (EN 60088-2-6)
Shock resistance		$\leq 2000 \text{ m/s}^2$ (EN 60088-2-27)
Maximum speed n_{max}	n_{max}	3500 rpm
Degree of protection		IP56 (EN 60529)
Connection		Terminal strip on encoder

8.9.6 EI7. B

Encoder type		EI7C	EI76	EI72	EI71	
For motors		DR..71 – 132 DRN80 – 132S				
Supply voltage	U _B	DC 9 – 30 V				
Max. current consumption (with no load)	I _{max}	120 mA _{RMS}				
Max. pulse frequency at n _{max}	f _{max}	1.44 kHz				
Periods per revolution	A, B	24	6	2	1	
(Signal tracks)	C	–				
Output amplitude per track	U _{high}	≥ V _B -3.5 V				
	U _{low}	≤ 3 V				
Signal output		HTL				
Maximum output current per track	I _{out_max}	60 mA _{RMS}				
Pulse duty factor (DIN IEC 60469-1) t = t _{log_1} /((t _{period})) n = constant		30 – 70% (typically: 50%)				
Phase offset A: B Φ _{phase, A:B} n = constant		70°– 110° (typically: 90°)				
Vibration resistance		10 g (98.1 m/s ²); 5 – 2000 Hz (EN 60068-2-6:2008)				
Shock resistance		100 g (981 m/s ²); 6 ms (EN 60068-2-27:2009)				
Reliable magnetic interference field on the outer contour of the motor	B _{extmax} H _{extmax}	25 mT 20 kA/m				
Maximum speed	n _{max}	3600 rpm				
Degree of protection		IP66				
Connection		Terminal strip in the terminal box or M12 (4- or 8-pin)				

8.9.7 EV2.

Encoder type		EV2T	EV2S	EV2R	EV2C
For motors		DR..71 – DR..225 DRN80 – 225			
Supply voltage	U _B	DC 5 V	DC 9 V – 26 V		
Max. current consumption	I _{in}	160 mA _{RMS}	120 mA _{RMS}	160 mA _{RMS}	250 mA _{RMS}
Max. pulse frequency	f _{max}	120 kHz			
Periods per revolution	A, B	1024			
	C	1			
Output amplitude per track	U _{high}	≥ 2.5 V	1 V _{SS}	≥ 2.5 V	≥ V _B - 3.5 V
	U _{low}	≤ 0.5 V		≤ 0.5 V	≤ 3 V
Signal output		TTL	Sin/Cos	TTL	HTL
Output current per track	I _{out}	25 mA _{RMS}	10 mA _{RMS}	25 mA _{RMS}	60 mA _{RMS}
Pulse duty factor		1: 1 ± 20%	Sin/Cos	1: 1 ± 20%	
Phase angle A : B		90° ± 20°	90°	90° ± 20°	
Data memory		–			
Vibration resistance		≤ 100 m/s ²			
Shock resistance		≤ 1000 m/s ²	≤ 3000 m/s ²	≤ 1000 m/s ²	
Maximum speed	n _{max}	6000 rpm			
Weight	m	0.36 kg			
Degree of protection		IP66			
Connection		Terminal box on incremental encoder			

8.10 Markings on the nameplate

The following table lists all markings that can occur on a nameplate and an explanation of what they mean:

Characteristics	Meaning
	CE mark to state compliance with European guidelines, such as the Low Voltage Directive
	ATEX mark to state compliance with the European Directive 94/9/EC
	UR logo to confirm that UL (Underwriters Laboratory) is informed about the registered components; register number by UL: E189357
	DoE mark to confirm compliance with US-American efficiency limit values for AC motors.
	UL logo to confirm that a component is UL (Underwriters Laboratory) tested, also valid for CSA in conjunction with the register number
	CSA mark to confirm the Canadian Standard Association (CSA) and the market conformity of AC motors
	CSAe mark to confirm compliance with the Canadian efficiency limit values for AC motors
	CCC logo to confirm the adherence to the Chinese regulation for small appliances
	VIK mark to confirm the compliance with the directive of the German Association of Industrial Machines (V.I.K.)
	FS mark with code number to identify functional safety relevant components
	EAC mark (EurAsian Conformity) Confirms compliance with the regulations of the economic and customs union of Russia, Belarus and Kazakhstan.

8.11 Characteristic values of functional safety

8.11.1 Characteristic safety values of the brakes BE05 – BE122

Definition of the characteristic safety value $B10_d$:

The value $B10_d$ specifies the number of cycles at which 10% of components have failed dangerously (definition according to standard EN ISO 13849-1). Failed dangerously means in this context that the brake is not applied when required. This means the brake does not deliver the necessary braking torque.

Size	$B10_d$ Switching cycles
BE05	16,000,000
BE1	12,000,000
BE2	8,000,000
BE5	6,000,000
BE11	3,000,000
BE20	2,000,000
BE30	1,500,000
BE32	1,500,000
BE60	1,000,000
BE62	1,000,000
BE120	250,000
BE122	250,000

In addition to the brakes listed above, SEW also offers safety-rated brakes up to size 32. For detailed information, refer to the addendum to the operating instructions "Safety-Rated Brakes – Functional Safety for AC Motors."

8.11.2 Safety characteristics of safety-rated encoders

Definition of the characteristic safety value $MTTF_d$:

The value $MTTF_d$ (Mean Time To Failure) specifies the mean time to dangerous failure / component fault.

Motor size	Designation	$MTTF_d^{1)}$	Service life
		In years	
DR..71 – 132 DRN80 – 132S	ES7S	61	20
	AS7W	41	20
	AS7Y	41	20
	EI7C FS	202	20
DR..160 – 315 DRN132M – 315	EG7S	61	20
	AG7W	41	20
	AG7Y	41	20

1) Referring to an ambient temperature of 40°C

8.12 S1 duty cycle DRK.. single-phase motor

The following section describes the data for DRK.. single-phase motor in S1 continuous duty

The specified starting torques result from the connection of a running capacitor or a running capacitor with start-up capacitor connected in parallel respectively.

S1 duty at 1500 / 1800 rpm (230 V)									
Motor type		P _N	n _N	I _N	cos φ	C _B	M _A / M _N with C _B	C _A for M _A /M _N	
	Hz	kW	rpm	A		μF		100%	150%
DRK71S4	50	0.18	1450	1.53	0.81	20	0.5	14	25
	60		1755	1.38	0.87	18	0.45	14	25
DRK71M4	50	0.25	1455	2.05	0.80	25	0.45	16	35
	60		1760	1.80	0.89	25	0.5	14	30
DRK80S4	50	0.37	1420	2.40	0.98	18	0.5	12	25
	60		1730	2.45	0.94	15	0.45	12	20
DRK80M4	50	0.55	1430	3.45	0.97	25	0.5	12	30
	60		1740	3.45	0.94	20	0.5	12	25
DRK90M4	50	0.75	1430	4.75	0.93	15+15	0.5	20	40
	60		1740	4.80	0.90	25	0.5	18	35
DRK90L4	50	1.1	1415	6.6	0.97	20+25	0.5	30	70
	60		1725	6.8	0.93	15+20	0.55	30	50

C_B Running capacitor

C_A Start-up capacitor

9 Malfunctions**▲ WARNING**

Risk of crushing if the drive starts up unintentionally.

Severe or fatal injuries.

- De-energize the motor before you start working on the unit.
- Secure the motor against unintended power-up.

**▲ CAUTION**

The surfaces of the drive can be very hot during operation.

Risk of burns.

- Let the motor cool down before you start your work.

**NOTICE**

Improper troubleshooting measures may damage the drive.

Possible damage to property.

- Note the following information.
- Use only genuine spare parts in accordance with the valid parts list!
- Strictly observe the safety notes in the individual chapters.

9.1 Motor malfunctions

Fault	Possible cause	Measure
Motor does not start up	Supply cable interrupted	Check the connections and (intermediate) terminal points, correct if necessary
	Brake does not release	See chapter "Brake malfunctions"
	Supply cable fuse has blown	Replace fuse
	Motor protection (switch) has triggered	Check that the motor protection (switch) is set correctly; current specification is on the name-plate
	Motor protection does not trip	Check motor protection control
	Malfunction in control or in the control process	Observe the switching sequence; correct if necessary
Motor only starts with difficulty or does not start at all	Motor power designed for delta connection but connected in star	Correct the connection from star to delta; follow the wiring diagram
	Motor power designed for star-star connection but only connected in star	Correct the connection from star to star-star; follow the wiring diagram
	Voltage or frequency differs considerably from the setpoint, at least when switching on the motor	Provide better power supply system; reduce the power supply load; Check cross section of supply cable, replace with cable of larger cross section if necessary
Motor does not start in star connection, only in delta connection	Star connection does not provide sufficient torque	If the delta inrush current is not too high (observe the regulations of the power supplier), start up directly in delta; Check the project planning and use a larger motor or special design if necessary. Consult SEW-EURODRIVE.
	Contact fault on star/delta switch	Check the switch, replace if necessary; Check the connections
Incorrect direction of rotation	Motor connected incorrectly	Swap two phases of the motor supply cable
Motor hums and has high current consumption	Brake does not release	See chapter "Brake malfunctions"
	Winding defective	Send motor to specialist workshop for repair
	Rotor rubbing	
Fuses blow or motor protection trips immediately	Short circuit in the motor supply cable	Eliminate short circuit
	Supply cables connected incorrectly	Correct the wiring, observe the wiring diagram
	Short circuit in the motor	Send motor to specialist workshop for repair
	Ground fault on motor	
Severe speed loss under load	Motor overload	Measure power, check project planning and use larger motor or reduce load if necessary
	Voltage drops	Check cross section of supply cable, replace with cable of larger cross section if necessary

Fault	Possible cause	Measure
Motor heats up excessively (measure temperature)	Overload	Measure power, check project planning and use larger motor or reduce load if necessary
	Insufficient cooling	Provide for cooling air supply or clear cooling air passages, retrofit forced cooling fan if necessary. Check the air filter, clean or replace if necessary
	Ambient temperature too high	Observe the permitted temperature range, reduce the load if necessary
	Motor in delta connection instead of star connection as intended	Correct the wiring, observe the wiring diagram
	Loose contact in supply cable (one phase missing)	Tighten loose contact, check connections, observe wiring diagram
	Fuse blown	Look for and rectify cause (see above); replace fuse
	Line voltage deviates from the rated motor voltage by more than 5% (range A) / 10% (range B).	Adjust motor to line voltage
	Nominal duty cycle (S1 to S10, DIN 57530) exceeded, e.g. caused by excessive starting frequency	Adjust the nominal duty cycle of the motor to the required operating conditions; consult a professional to determine the proper drive, if necessary
Excessively loud	Ball bearing compressed, dirty or damaged	Re-align motor and the driven machine, inspect rolling bearing and replace if necessary. See chapter "Permitted rolling bearing types" (→ 165).
	Vibration of rotating parts	Look for the cause, possibly an imbalance; correct the cause, observe method for balancing
	Foreign objects in cooling air ducts	Clean cooling air ducts
	For DR.. motors with rotor designation "J": Load too high	Reduce load

9.2 Brake malfunctions

Fault	Possible cause	Measure
Brake does not re-release	Incorrect voltage on brake control unit	Apply the correct voltage; brake voltage specified on the nameplate
	Brake control unit failed	Install a new brake control, check resistors and insulation of the brake coils (see "Resistors" chapter for resistance values) Check switchgear, replace if necessary
	Max. permitted working air gap exceeded because brake lining worn down	Measure and set working air gap. See the following chapters: <ul style="list-style-type: none"> Setting the working air gap of BE05 – BE122 brakes (→ 133) Setting the working air gap of BE120 – BE122 brakes If the brake disk is too thin, replace the brake disk. See the following chapters: <ul style="list-style-type: none"> Replacing the brake disk of BE05 – BE122 brakes (→ 135) Replacing the brake disk of BE120 – BE122 brakes
	Voltage drop along supply cable > 10%	Provide correct connection voltage: brake voltage specifications on the nameplate. Check the cross section of the brake supply cable; increase cross section if necessary
	Inadequate cooling, brake overheats	Provide for cooling air supply or clear cooling air passages, check air filter, clean or replace if necessary. Replace type BG brake rectifier with type BGE
	Brake coil has interturn short circuit or a short circuit to frame	Check resistors and insulation of the brake coils (see "Resistors" chapter for resistance values); Replace complete brake and brake control (specialist workshop), Check switchgear, replace if necessary
	Rectifier defective	Replace rectifier and brake coil; it may be more economical to replace the complete brake

Fault	Possible cause	Measure
Brake does not brake	Working air gap not correct	<p>Measure and set working air gap.</p> <p>See the following chapters:</p> <ul style="list-style-type: none"> • Setting the working air gap of BE05 – BE122 brakes (→ 133) • Setting the working air gap of BE120 – BE122 brakes <p>If the brake disk is too thin, replace the brake disk.</p> <p>See the following chapters:</p> <ul style="list-style-type: none"> • Replacing the brake disk of BE05 – BE122 brakes (→ 135) • Replacing the brake disk of BE120 – BE122 brakes
	Brake lining worn	<p>Replace entire brake disk.</p> <p>See the following chapters:</p> <ul style="list-style-type: none"> • Replacing the brake disk of BE05 – BE122 brakes (→ 135) • Replacing the brake disk of BE120 – BE122 brakes
	Incorrect braking torque	<p>Check the project planning and change the braking torque if necessary; see chapter "Work done, working air gap, braking torques" (→ 150)</p> <ul style="list-style-type: none"> • by changing the type and number of brake springs. <p>See the following chapters:</p> <ul style="list-style-type: none"> – Changing the braking torque of BE05 – BE122 brakes (→ 137) – Changing the braking torque of BE120 – BE122 brakes <ul style="list-style-type: none"> • by selecting a different brake <p>See chapter "Braking torque assignment" (→ 152)</p>

Fault	Possible cause	Measure
Brake does not brake	Working air gap so large that setting nuts for the manual brake release come into contact	Set the working air gap. See the following chapters: <ul style="list-style-type: none"> Setting the working air gap of BE05 – BE122 brakes (→ 133) Setting the working air gap of BE120 – BE122 brakes
	Manual brake release device not set correctly	Set the adjusting nuts for the manual brake release correctly See the following chapters: <ul style="list-style-type: none"> Changing the braking torque of BE05 – BE122 brakes (→ 137) Changing the braking torque of BE120 – BE122 brakes
	Brake locked by manual brake release HF	Loosen the set screw, remove if necessary
Brake is applied with time lag	Brake is switched only on AC voltage side	Switch both the DC and AC circuits (e.g. by retrofitting a SR current relay to BSR or a UR voltage relay to BUR); observe wiring diagram
Noises in vicinity of brake	Gearing wear on the brake disk or the driver caused by jolting startup	Check the project planning, replace the brake disk if necessary See the following chapters: <ul style="list-style-type: none"> Replacing the brake disk of BE05 – BE122 brakes (→ 135) Replacing the brake disk of BE120 – BE122 brakes Have a specialist workshop replace the driver
	Alternating torques due to incorrectly set frequency inverter	Check correct setting of frequency inverter according to its operating instructions, correct if necessary.

9.3 Malfunctions when operated with a frequency inverter

The symptoms described in chapter "Motor malfunctions" may also occur when the motor is operated with a frequency inverter. Please refer to the frequency inverter operating instructions for the meaning of the problems that occur and to find information about rectifying the problems.

9.4 Customer service

Please have the following information available if you require customer service assistance:

- Nameplate data (complete)
- Nature and extent of the problem
- Time the failure occurred and any accompanying circumstances
- Assumed cause
- Ambient conditions e.g.:
 - Ambient temperature
 - Humidity
 - Installation altitude
 - Dirt
 - etc.

9.5 Disposal

Dispose of the motors in accordance with the material structure and the regulations in force:

- Iron
- Aluminum
- Copper
- Plastics
- Electronic components
- Oil and grease (not mixed with solvents)

10 Appendix

10.1 Wiring diagrams

INFORMATION




The motor should be connected as shown in the connection wiring diagram or the terminal assignment diagram, which are supplied with the motor. The following chapter only shows a selection of the common types of connections. You can obtain the relevant wiring diagrams free of charge from SEW-EURODRIVE.

10.1.1 Delta and star connection in wiring diagram R13

For all motors with one speed, direct on-line or Δ start-up.

Delta connection

The following figure shows Δ connection for low voltage.




9007199497344139

- [1] Motor winding
[2] Motor terminal board

- [3] Incoming cables

Star connection

The following figure shows \star connection for high voltage.



9007199497339147

- [1] Motor winding
[2] Motor terminal board

- [3] Incoming cables


Direction of rotation reversal: Swap connection of 2 incoming cables, L1 – L2

10.1.2 Delta connection with wiring diagram R72 (68192 xx 09)

For all motors with one speed and direct power-on.

Delta connection, Double-delta connection

The following figure shows \triangle connection for high voltages and $\triangle \triangle$ connection for low voltages.



- [1] Motor winding
 [2] Motor terminal board
 [3] Incoming cables


Direction of rotation reversal: Swap connection of 2 incoming cables, L1 – L2

10.1.3 Star connection with wiring diagram R76 (68043 xx 06)

For all motors with one speed and direct power-on.

Star connection, double-star connection

The following figure shows Δ connection for high voltages and Δ Δ connection for low voltages.



[1] Motor winding

[2] Motor terminal board

[3] Incoming cables

[4] Star point connected in motor

Direction of rotation reversal: Swap connection of 2 incoming cables, L1 - L2


10.1.4 Motor protection with TF or TH for DR..71 – 280, DRN80 – 280

TF/TH

The following figures show the connection of motor protection with TF PTC thermistor sensors or TH bimetallic thermostats.

Either a two-pole connection terminal or a five-pole terminal strip is available for connecting to the trip switch.


Example: TF/TH to a two-pole terminal strip



9007199728684427

1b	2b
TF/TH	TF/TH

Example: 2xTF/TH to a five-pole terminal strip




18014398983427083

1b	2b	3b	4b	5b
1.TF/TH	1.TF/TH	2nd TF/TH	2nd TF/TH	–


2xTF/TH with anti-condensation heating

The following illustration shows the connection of the motor protection with 2 TF PTC thermistor sensors or TH bimetallic thermostats and Hx anti-condensation heating.



9007199728684427

1b	2b
Hx	Hx



18014398983427083

1b	2b	3b	4b	5b
1.TF/TH	1.TF/TH	2nd TF/TH	2nd TF/TH	–


10.1.5 Motor protection using TF or TH with DR..315, DRN315

TF/TH

The following figures show the connection of motor protection with TF PTC thermistor sensors or TH bimetallic thermostats.


Depending on the version, an "x-pole" terminal strip is available for connection to the trip switch.

Example: TF/TH to terminal strip



473405707

Example: 2xTF/TH to terminal strip




473410187

10.1.6 EI7.B built-in encoder

Connection via terminal strip

The encoder is equipped with a 10-pole terminal strip for connection:



8324612747

INFORMATION



The ranges 1a – 10a, 1c – 4c und 1d – 4d have been pre-configured by SEW-EURODRIVE. The must not be changed.

Range 1b – 10b is intended for customer adjustments.

Basic connection:

Connections 1a – 10a, 1c – 4c and 1d – 4d lead to the encoder or to the motor.

Connections 1b – 10b lead to the cable gland.

	1	2	3	4	5	6	7	8	9	10	1	2	3	4	
a	TF1 ¹⁾	TF1 ¹⁾	TF2 ¹⁾ Opt.	TF2 ¹⁾ Opt.	+UB ¹⁾ (GY)	GND ¹⁾ (PK)	A ¹⁾ (BN)	\bar{A} ¹⁾ (WH)	\bar{B} ¹⁾ (YE)	B ¹⁾ (GN)	see below				c
b	TF1	TF1	TF2 Opt.	TF2 Opt.	+UB	GND	A	\bar{A}	B	\bar{B}	see below				d

1) Pre-configured by SEW-EURODRIVE. Do not alter the setting!

Pin assignment EI7C B				
1	2	3	4	
GND ¹⁾ (BU)	n. c. ¹⁾	n. c. ¹⁾	n. c. ¹⁾	c
EI7C ¹⁾ (RD)	n. c. ¹⁾	n. c. ¹⁾	n. c. ¹⁾	d

1) Pre-configured by SEW-EURODRIVE. Do not alter the setting!

Pin assignment EI76 B				
1	2	3	4	
GND ¹⁾ (BU)	n. c. ¹⁾	n. c. ¹⁾	n. c. ¹⁾	c
n. c. ¹⁾	EI76 ¹⁾ (RD)	n. c. ¹⁾	n. c. ¹⁾	d



Pin assignment EI72 B				
1	2	3	4	
GND ¹⁾ (BU)	n. c. ¹⁾	n. c. ¹⁾	n. c. ¹⁾	c
n. c. ¹⁾	n. c. ¹⁾	EI72 ¹⁾ (RD)	n. c. ¹⁾	d

1) Pre-configured by SEW-EURODRIVE. Do not alter the setting!

Pin assignment EI71 B				
1	2	3	4	
GND ¹⁾ (BU)	n. c. ¹⁾	n. c. ¹⁾	n. c. ¹⁾	c
n. c. ¹⁾	n. c. ¹⁾	n. c. ¹⁾	EI71 ¹⁾ (RD)	d

Connection via M12 plug connector

A 8-pin or a 4-pin M12 plug connector is available for the connection.

4-pole M12 plug connector AVSE		8-pole M12 plug connector AVRE	
<ul style="list-style-type: none"> • A coded • Male 	Pin 1: $+U_B$	<ul style="list-style-type: none"> • A coded • Male 	Pin 1: $+U_B$
	Pin 2: B		Pin 2: GND
	Pin 3: GND		Pin 3: A
	Pin 4: A		Pin 4: \bar{A}
			Pin 5: B
			Pin 6: \bar{B}
			Pin 7: TF1
			Pin 8: TF1

10.1.7 Brake control BGE; BG; BSG; BUR

BE brake

BGE, BG, BSG, BUR brake control;

Apply voltage to release the brake (see nameplate).

Contact rating of the brake control: AC3 in accordance with EN 60947-4-1.



The voltage can be distributed as follows:

- Through a separate supply cable
- From the motor terminal board

This does not apply to pole-changing and frequency-controlled motors.

BG / BGE

The following illustration shows the wiring for BG and BGE brake rectifiers for the AC-side shut-off as well as the DC and AC-side shutoff.




242604811

[1] Brake coil

BSG

The following illustration shows the DC 24 V connection of the BSG control unit



242606475

[1] Brake coil

BUR




▲ WARNING

Malfunction caused by incorrect connection for frequency operation.
Possible damage to the drive system.

- Do not connect the brake to the terminal board of the motor.

The following figure shows the wiring for BUR brake control:



242608139

[1] Brake coil
[2] UR11/UR15 voltage relay

BN = UR 11 (42 – 150 V)
BK = UR 15 (150 – 500 V)

10.1.8 BSR brake control

BE brake

BSR brake control

Brake voltage = Phase-to-neutral voltage

The white connecting leads are the ends of a converter loop and, depending on the motor connection, must be connected to the motor terminal block instead of the Δ or \wedge bridge prior startup.


Factory set to star in wiring diagram R13

The following illustration shows the factory wiring for the BSR brake control

Example

Motor: AC 230 V / AC 400 V

Brake: AC 230 V



9007199497340811

- [1] Brake coil
[2] SR11/15 current relay


Factory set to start in wiring diagram R76

The following illustration shows the factory wiring for the BSR brake control

Example

Motor: AC 230 V / AC 460 V

Brake: AC 230 V



2319077003

- [1] Motor terminal board
- [2] Incoming cables
- [3] Brake coil
- [4] SR11/15 current relay
- [5] Auxiliary terminal


Alternative connection: Factory set to double-star with wiring diagram R76

The following illustration shows the factory wiring for the BSR brake control

Example

Motor: AC 230 V / AC 460 V

Brake: AC 230 V



2337824139

- [1] Motor terminal board
- [2] Incoming cables
- [3] Brake coil
- [4] SR11/15 current relay
- [5] Auxiliary terminal

10.1.9 BMP3.1 brake control in the terminal box

Brake BE120, BE122

BMP3.1 brake control



Apply voltage to release the brake (see nameplate).

Contact rating of the brake control: AC3 in accordance with EN 60947-4-1.

Separate supply cables are required for the voltage supply.

BMP3.1

The following illustration shows the wiring for the BMP3.1 brake rectifier for the AC-side shut-off as well as the DC and AC-side shutoff.




365750411

[1] Brake coil

10.1.10 V forced cooling fan

Delta-Steinmetz


The following figure shows the wiring of the V forced cooling fan for delta-Steinmetz connection for 1-phase operation



9007199778089483

Star connection


The following figure shows the wiring of the V forced cooling fan for star connection.



9007199778091147

Delta connection


The following figure shows the wiring of the V forced cooling fan for delta connection.



9007199778092811

DC 24 V connection

The following figure shows the wiring of the V forced cooling fan for DC 24 V.



2393384075

- [1] Forced cooling fan
- [2] Terminal strip

- A Factory wiring
- B Customer side


INFORMATION



Observe the polarity.

10.1.11 DRK... single-phase motor


ER10 wiring diagram



11919510027

- | | |
|---------------------------------------|---|
| [1] Motor winding | [6] Starting capacitor, switchable |
| [2] Motor terminal | [7] Running capacitor |
| [3] Incoming cables | [8] Further running capacitors (if available) |
| [4] Counterclockwise rotation | [9] All-pole power switch |
| [5] CW rotation, connected at factory | |

ER11 wiring diagram



11919511947


- | | |
|-------------------------------|---------------------------------------|
| [1] Motor winding | [5] CW rotation, connected at factory |
| [2] Motor terminal board | [6] Starting capacitor, switchable |
| [3] Incoming cables | [7] Running capacitor |
| [4] Counterclockwise rotation | [8] All-pole power switch |

10.2 Auxiliary terminals 1 and 2

The following figure shows the arrangement of the auxiliary terminals for the different terminal box positions.

Terminal box position 2 and X, here X¹⁾

Terminal box position 1 and 3, here 3



3572208523

1) If auxiliary terminal 2 is not provided, you can install auxiliary terminal 1 in the same position.

- | | |
|-----------------------------|-----------------------------|
| [1] Terminal box position 1 | [X] Terminal box position X |
| [2] Terminal box system 2 | [A] Auxiliary terminal 1 |
| [3] Terminal box system 3 | [B] Auxiliary terminal 2 |

Regardless of the terminal box position, auxiliary terminal 1 must always be mounted parallel to the terminal board.

The terminal structure can vary depending on the terminal box design.

11 Address list

Germany			
Headquarters Production Sales	Bruchsal	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 D-76646 Bruchsal P.O. Box Postfach 3023 • D-76642 Bruchsal	Tel. +49 7251 75-0 Fax +49 7251 75-1970 http://www.sew-eurodrive.de sew@sew-eurodrive.de
Production / Industrial Gears	Bruchsal	SEW-EURODRIVE GmbH & Co KG Christian-Pähr-Str.10 D-76646 Bruchsal	Tel. +49 7251 75-0 Fax +49 7251 75-2970
Service Competence Center	Mechanics / Mechatronics	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 1 D-76676 Graben-Neudorf	Tel. +49 7251 75-1710 Fax +49 7251 75-1711 sc-mitte@sew-eurodrive.de
	Electronics	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 D-76646 Bruchsal	Tel. +49 7251 75-1780 Fax +49 7251 75-1769 sc-elektronik@sew-eurodrive.de
Drive Technology Center	North	SEW-EURODRIVE GmbH & Co KG Alte Ricklinger Straße 40-42 D-30823 Garbsen (near Hannover)	Tel. +49 5137 8798-30 Fax +49 5137 8798-55 sc-nord@sew-eurodrive.de
	East	SEW-EURODRIVE GmbH & Co KG Dänkritzter Weg 1 D-08393 Meerane (near Zwickau)	Tel. +49 3764 7606-0 Fax +49 3764 7606-30 sc-ost@sew-eurodrive.de
	South	SEW-EURODRIVE GmbH & Co KG Domagkstraße 5 D-85551 Kirchheim (near München)	Tel. +49 89 909552-10 Fax +49 89 909552-50 sc-sued@sew-eurodrive.de
	West	SEW-EURODRIVE GmbH & Co KG Siemensstraße 1 D-40764 Langenfeld (near Düsseldorf)	Tel. +49 2173 8507-30 Fax +49 2173 8507-55 sc-west@sew-eurodrive.de
	Drive Service Hotline / 24 Hour Service		+49 800 SEWHELP +49 800 7394357
	Additional addresses for service in Germany provided on request.		
France			
Production Sales Service	Haguenau	SEW-USOCOME 48-54 route de Soufflenheim B. P. 20185 F-67506 Haguenau Cedex	Tel. +33 3 88 73 67 00 Fax +33 3 88 73 66 00 http://www.usocom.com sew@usocom.com
Production	Forbach	SEW-USOCOME Zone industrielle Technopôle Forbach Sud B. P. 30269 F-57604 Forbach Cedex	Tel. +33 3 87 29 38 00
Assembly Sales Service	Bordeaux	SEW-USOCOME Parc d'activités de Magellan 62 avenue de Magellan - B. P. 182 F-33607 Pessac Cedex	Tel. +33 5 57 26 39 00 Fax +33 5 57 26 39 09
	Lyon	SEW-USOCOME Parc d'affaires Roosevelt Rue Jacques Tati F-69120 Vaulx en Velin	Tel. +33 4 72 15 37 00 Fax +33 4 72 15 37 15
	Nantes	SEW-USOCOME Parc d'activités de la forêt 4 rue des Fontenelles F-44140 Le Bignon	Tel. +33 2 40 78 42 00 Fax +33 2 40 78 42 20
	Paris	SEW-USOCOME Zone industrielle 2 rue Denis Papin F-77390 Verneuil l'Etang	Tel. +33 1 64 42 40 80 Fax +33 1 64 42 40 88
Additional addresses for service in France provided on request.			
Algeria			
Sales	Algiers	REDUCOM Sarl 16, rue des Frères Zaghroune Bellevue 16200 El Harrach Alger	Tel. +213 21 8214-91 Fax +213 21 8222-84 info@reducom-dz.com http://www.reducom-dz.com

Argentina			
Assembly Sales	Buenos Aires	SEW EURODRIVE ARGENTINA S.A. Ruta Panamericana Km 37.5, Lote 35 (B1619IEA) Centro Industrial Garín Prov. de Buenos Aires	Tel. +54 3327 4572-84 Fax +54 3327 4572-21 sewar@sew-eurodrive.com.ar http://www.sew-eurodrive.com.ar
Australia			
Assembly Sales Service	Melbourne	SEW-EURODRIVE PTY. LTD. 27 Beverage Drive Tullamarine, Victoria 3043	Tel. +61 3 9933-1000 Fax +61 3 9933-1003 http://www.sew-eurodrive.com.au enquires@sew-eurodrive.com.au
	Sydney	SEW-EURODRIVE PTY. LTD. 9, Sleigh Place, Wetherill Park New South Wales, 2164	Tel. +61 2 9725-9900 Fax +61 2 9725-9905 enquires@sew-eurodrive.com.au
Austria			
Assembly Sales Service	Wien	SEW-EURODRIVE Ges.m.b.H. Richard-Strauss-Strasse 24 A-1230 Wien	Tel. +43 1 617 55 00-0 Fax +43 1 617 55 00-30 http://www.sew-eurodrive.at sew@sew-eurodrive.at
Belarus			
Sales	Minsk	SEW-EURODRIVE BY RybalkoStr. 26 BY-220033 Minsk	Tel.+375 17 298 47 56 / 298 47 58 Fax +375 17 298 47 54 http://www.sew.by sales@sew.by
Belgium			
Assembly Sales Service	Brussels	SEW-EURODRIVE n.v./s.a. Researchpark Haasrode 1060 Evenementenlaan 7 BE-3001 Leuven	Tel. +32 16 386-311 Fax +32 16 386-336 http://www.sew-eurodrive.be info@sew-eurodrive.be
Service Competence Center	Industrial Gears	SEW-EURODRIVE n.v./s.a. Rue de Parc Industriel, 31 BE-6900 Marche-en-Famenne	Tel. +32 84 219-878 Fax +32 84 219-879 http://www.sew-eurodrive.be service-wallonie@sew-eurodrive.be
Brazil			
Production Sales Service	São Paulo	SEW-EURODRIVE Brasil Ltda. Avenida Amâncio Gaiolli, 152 - Rodovia Presi- dente Dutra Km 208 Guarulhos - 07251-250 - SP SAT - SEW ATENDE - 0800 7700496	Tel. +55 11 2489-9133 Fax +55 11 2480-3328 http://www.sew-eurodrive.com.br sew@sew.com.br
Assembly Sales Service	Rio Claro	SEW-EURODRIVE Brasil Ltda. Rodovia Washington Luiz, Km 172 Condomínio Industrial Conpark Caixa Postal: 327 13501-600 – Rio Claro / SP	Tel. +55 19 3522-3100 Fax +55 19 3524-6653 montadora.rc@sew.com.br
	Joinville	SEW-EURODRIVE Brasil Ltda. Rua Dona Francisca, 12.346 – Pirabeiraba 89239-270 – Joinville / SC	Tel. +55 47 3027-6886 Fax +55 47 3027-6888 filial.sc@sew.com.br
	Indaiatuba	SEW-EURODRIVE Brasil Ltda. Estrada Municipal Jose Rubim, 205 Rodovia Santos Dumont Km 49 13347-510 - Indaiatuba / SP	Tel. +55 19 3835-8000 sew@sew.com.br
Bulgaria			
Sales	Sofia	BEVER-DRIVE GmbH Bogdanovetz Str.1 BG-1606 Sofia	Tel. +359 2 9151160 Fax +359 2 9151166 bever@bever.bg
Cameroon			
Sales	Douala	Electro-Services Rue Drouot Akwa B.P. 2024 Douala	Tel. +237 33 431137 Fax +237 33 431137 electrojemba@yahoo.fr

Canada			
Assembly Sales Service	Toronto	SEW-EURODRIVE CO. OF CANADA LTD. 210 Walker Drive Bramalea, ON L6T 3W1	Tel. +1 905 791-1553 Fax +1 905 791-2999 http://www.sew-eurodrive.ca l.watson@sew-eurodrive.ca
	Vancouver	SEW-EURODRIVE CO. OF CANADA LTD. Tilbury Industrial Park 7188 Honeyman Street Delta, BC V4G 1G1	Tel. +1 604 946-5535 Fax +1 604 946-2513 b.wake@sew-eurodrive.ca
	Montreal	SEW-EURODRIVE CO. OF CANADA LTD. 2555 Rue Leger Lasalle, PQ H8N 2V9	Tel. +1 514 367-1124 Fax +1 514 367-3677 a.peluso@sew-eurodrive.ca
	Additional addresses for service in Canada provided on request.		
Chile			
Assembly Sales Service	Santiago	SEW-EURODRIVE CHILE LTDA. Las Encinas 1295 Parque Industrial Valle Grande LAMP RCH-Santiago de Chile P.O. Box Casilla 23 Correo Quilicura - Santiago - Chile	Tel. +56 2 75770-00 Fax +56 2 75770-01 http://www.sew-eurodrive.cl ventas@sew-eurodrive.cl
China			
Production Assembly Sales Service	Tianjin	SEW-EURODRIVE (Tianjin) Co., Ltd. No. 46, 7th Avenue, TEDA Tianjin 300457	Tel. +86 22 25322612 Fax +86 22 25323273 info@sew-eurodrive.cn http://www.sew-eurodrive.cn
Assembly Sales Service	Suzhou	SEW-EURODRIVE (Suzhou) Co., Ltd. 333, Suhong Middle Road Suzhou Industrial Park Jiangsu Province, 215021	Tel. +86 512 62581781 Fax +86 512 62581783 suzhou@sew-eurodrive.cn
	Guangzhou	SEW-EURODRIVE (Guangzhou) Co., Ltd. No. 9, JunDa Road East Section of GETDD Guangzhou 510530	Tel. +86 20 82267890 Fax +86 20 82267922 guangzhou@sew-eurodrive.cn
	Shenyang	SEW-EURODRIVE (Shenyang) Co., Ltd. 10A-2, 6th Road Shenyang Economic Technological Development Area Shenyang, 110141	Tel. +86 24 25382538 Fax +86 24 25382580 shenyang@sew-eurodrive.cn
	Wuhan	SEW-EURODRIVE (Wuhan) Co., Ltd. 10A-2, 6th Road No. 59, the 4th Quanli Road, WEDA 430056 Wuhan	Tel. +86 27 84478388 Fax +86 27 84478389 wuhan@sew-eurodrive.cn
	Xi'An	SEW-EURODRIVE (Xi'An) Co., Ltd. No. 12 Jinye 2nd Road Xi'An High-Technology Industrial Development Zone Xi'An 710065	Tel. +86 29 68686262 Fax +86 29 68686311 xian@sew-eurodrive.cn
Additional addresses for service in China provided on request.			
Colombia			
Assembly Sales Service	Bogotá	SEW-EURODRIVE COLOMBIA LTDA. Calle 22 No. 132-60 Bodega 6, Manzana B Santafé de Bogotá	Tel. +57 1 54750-50 Fax +57 1 54750-44 http://www.sew-eurodrive.com.co sew@sew-eurodrive.com.co
Croatia			
Sales Service	Zagreb	KOMPEKS d. o. o. Zeleni dol 10 HR 10 000 Zagreb	Tel. +385 1 4613-158 Fax +385 1 4613-158 kompeks@inet.hr
Czech Republic			
Sales Assembly Service	Hostivice	SEW-EURODRIVE CZ s.r.o. Floriánova 2459 253 01 Hostivice	Tel. +420 255 709 601 Fax +420 235 350 613 http://www.sew-eurodrive.cz sew@sew-eurodrive.cz

Czech Republic			
	Drive Service Hot-line / 24 Hour Service	HOT-LINE +420 800 739 739 (800 SEW SEW)	Servis: Tel. +420 255 709 632 Fax +420 235 358 218 servis@sew-eurodrive.cz
Denmark			
Assembly Sales Service	Copenhagen	SEW-EURODRIVE A/S Geminivej 28-30 DK-2670 Greve	Tel. +45 43 9585-00 Fax +45 43 9585-09 http://www.sew-eurodrive.dk sew@sew-eurodrive.dk
Egypt			
Sales Service	Cairo	Copam Egypt for Engineering & Agencies 33 El Hegaz ST, Heliopolis, Cairo	Tel. +20 2 22566-299 +1 23143088 Fax +20 2 22594-757 http://www.copam-egypt.com/ copam@datum.com.eg
Estonia			
Sales	Tallin	ALAS-KUUL AS Reti tee 4 EE-75301 Peetri küla, Rae vald, Harjumaa	Tel. +372 6593230 Fax +372 6593231 veiko.soots@alas-kuul.ee
Finland			
Assembly Sales Service	Hollola	SEW-EURODRIVE OY Vesimäentie 4 FIN-15860 Hollola 2	Tel. +358 201 589-300 Fax +358 3 780-6211 http://www.sew-eurodrive.fi sew@sew.fi
Service	Hollola	SEW-EURODRIVE OY Keskikankaantie 21 FIN-15860 Hollola	Tel. +358 201 589-300 Fax +358 3 780-6211 http://www.sew-eurodrive.fi sew@sew.fi
Production Assembly	Karkkila	SEW Industrial Gears Oy Valurinkatu 6, PL 8 FI-03600 Karkkila, 03601 Karkkila	Tel. +358 201 589-300 Fax +358 201 589-310 sew@sew.fi http://www.sew-eurodrive.fi
Gabon			
Sales	Libreville	ESG Electro Services Gabun Feu Rouge Lalala 1889 Libreville Gabun	Tel. +241 741059 Fax +241 741059 esg_services@yahoo.fr
Great Britain			
Assembly Sales Service	Normanton	SEW-EURODRIVE Ltd. DeVilliers Way Trident Park Normanton West Yorkshire WF6 1GX	Tel. +44 1924 893-855 Fax +44 1924 893-702 http://www.sew-eurodrive.co.uk info@sew-eurodrive.co.uk
	Drive Service Hotline / 24 Hour Service		Tel. 01924 896911
Greece			
Sales	Athens	Christ. Boznos & Son S.A. 12, K. Mavromichali Street P.O. Box 80136 GR-18545 Piraeus	Tel. +30 2 1042 251-34 Fax +30 2 1042 251-59 http://www.boznos.gr info@boznos.gr
Hong Kong			
Assembly Sales Service	Hong Kong	SEW-EURODRIVE LTD. Unit No. 801-806, 8th Floor Hong Leong Industrial Complex No. 4, Wang Kwong Road Kowloon, Hong Kong	Tel. +852 36902200 Fax +852 36902211 contact@sew-eurodrive.hk
Hungary			
Sales Service	Budapest	SEW-EURODRIVE Kft. H-1037 Budapest Kunigunda u. 18	Tel. +36 1 437 06-58 Fax +36 1 437 06-50 http://www.sew-eurodrive.hu office@sew-eurodrive.hu

India			
Registered Office Assembly Sales Service	Vadodara	SEW-EURODRIVE India Private Limited Plot No. 4, GIDC POR Ramangamdi • Vadodara - 391 243 Gujarat	Tel. +91 265 3045200, +91 265 2831086 Fax +91 265 3045300, +91 265 2831087 http://www.seweurodriveindia.com salesvadodara@seweurodriveindia.com
Assembly Sales Service	Chennai	SEW-EURODRIVE India Private Limited Plot No. K3/1, Sipcot Industrial Park Phase II Mambakkam Village Sriperumbudur - 602105 Kancheepuram Dist, Tamil Nadu	Tel. +91 44 37188888 Fax +91 44 37188811 saleschennai@seweurodriveindia.com
Ireland			
Sales Service	Dublin	Alpertor Engineering Ltd. 48 Moyle Road Dublin Industrial Estate Glasnevin, Dublin 11	Tel. +353 1 830-6277 Fax +353 1 830-6458 info@alperton.ie http://www.alperton.ie
Israel			
Sales	Tel-Aviv	Liraz Handasa Ltd. Ahofer Str 34B / 228 58858 Holon	Tel. +972 3 5599511 Fax +972 3 5599512 http://www.liraz-handasa.co.il office@liraz-handasa.co.il
Italy			
Assembly Sales Service	Solaro	SEW-EURODRIVE di R. Blicke & Co.s.a.s. Via Bernini, 14 I-20020 Solaro (Milano)	Tel. +39 02 96 9801 Fax +39 02 96 980 999 http://www.sew-eurodrive.it sewit@sew-eurodrive.it
Ivory Coast			
Sales	Abidjan	SICA Société Industrielle & Commerciale pour l'Afrique 165, Boulevard de Marseille 26 BP 1173 Abidjan 26	Tel. +225 21 25 79 44 Fax +225 21 25 88 28 sicamot@aviso.ci
Japan			
Assembly Sales Service	Iwata	SEW-EURODRIVE JAPAN CO., LTD 250-1, Shimoman-no, Iwata Shizuoka 438-0818	Tel. +81 538 373811 Fax +81 538 373855 http://www.sew-eurodrive.co.jp sewjapan@sew-eurodrive.co.jp
Kazakhstan			
Sales	Almaty	TOO "СЕВ-ЕВРОДРАЙВ" пр.Райымбека, 348 050061 г. Алматы Республика Казахстан	Тел. +7 (727) 334 1880 Факс +7 (727) 334 1881 http://www.sew-eurodrive.kz sew@sew-eurodrive.kz
Kenya			
Sales	Nairobi	Barico Maintenances Ltd Kamutaga Place Commercial Street Industrial Area P.O.BOX 52217 - 00200 Nairobi	Tel. +254 20 6537094/5 Fax +254 20 6537096 info@barico.co.ke
Latvia			
Sales	Riga	SIA Alas-Kuul Katlakalna 11C LV-1073 Riga	Tel. +371 6 7139253 Fax +371 6 7139386 http://www.alas-kuul.com info@alas-kuul.com
Lebanon			
Sales Lebanon	Beirut	Gabriel Acar & Fils sarl B. P. 80484 Bourj Hammoud, Beirut After Sales Service	Tel. +961 1 510 532 Fax +961 1 494 971 ssacar@inco.com.lb service@medrives.com

Lebanon			
Sales Jordan / Kuwait / Saudi Arabia / Syria	Beirut	Middle East Drives S.A.L. (offshore) Sin El Fil. B. P. 55-378 Beirut After Sales Service	Tel. +961 1 494 786 Fax +961 1 494 971 info@medrives.com http://www.medrives.com service@medrives.com
Lithuania			
Sales	Alytus	UAB Irseva Statybininku 106C LT-63431 Alytus	Tel. +370 315 79204 Fax +370 315 56175 irmantas@irseva.lt http://www.sew-eurodrive.lt
Luxembourg			
Assembly Sales Service	Brussels	SEW-EURODRIVE n.v./s.a. Researchpark Haasrode 1060 Evenementenlaan 7 BE-3001 Leuven	Tel. +32 16 386-311 Fax +32 16 386-336 http://www.sew-eurodrive.lu info@sew-eurodrive.be
Madagascar			
Sales	Antananarivo	Ocean Trade BP21bis. Andraharo Antananarivo. 101 Madagascar	Tel. +261 20 2330303 Fax +261 20 2330330 oceantrabp@moov.mg
Malaysia			
Assembly Sales Service	Johor	SEW-EURODRIVE SDN BHD No. 95, Jalan Seroja 39, Taman Johor Jaya 81000 Johor Bahru, Johor West Malaysia	Tel. +60 7 3549409 Fax +60 7 3541404 sales@sew-eurodrive.com.my
Mexico			
Assembly Sales Service	Quéretaro	SEW-EURODRIVE MEXICO SA DE CV SEM-981118-M93 Tequisquiapan No. 102 Parque Industrial Quéretaro C.P. 76220 Quéretaro, México	Tel. +52 442 1030-300 Fax +52 442 1030-301 http://www.sew-eurodrive.com.mx scmexico@seweurodrive.com.mx
Mongolia			
Sales	Ulan Bator	SEW-EURODRIVE Representative Office Mongolia Olympic street 8, 2nd floor Juulchin corp bldg., Sukhbaatar district, Ulaanbaatar 14253	Tel. +976-70009997 Fax +976-70009997 http://www.sew-eurodrive.mn sew@sew-eurodrive.mn
Morocco			
Sales Service	Mohammedia	SEW-EURODRIVE SARL 2 bis, Rue Al Jahid 28810 Mohammedia	Tel. +212 523 32 27 80/81 Fax +212 523 32 27 89 sew@sew-eurodrive.ma http://www.sew-eurodrive.ma
Namibia			
Sales	Swakopmund	DB Mining & Industrial Services Einstein Street Strauss Industrial Park Unit1 Swakopmund	Tel. +264 64 462 738 Fax +264 64 462 734 sales@dbmining.in.na
Netherlands			
Assembly Sales Service	Rotterdam	SEW-EURODRIVE B.V. Industrieweg 175 NL-3044 AS Rotterdam Postbus 10085 NL-3004 AB Rotterdam	Tel. +31 10 4463-700 Fax +31 10 4155-552 Service: 0800-SEWHELP http://www.sew-eurodrive.nl info@sew-eurodrive.nl

New Zealand			
Assembly Sales Service	Auckland	SEW-EURODRIVE NEW ZEALAND LTD. P.O. Box 58-428 82 Greenmount drive East Tamaki Auckland	Tel. +64 9 2745627 Fax +64 9 2740165 http://www.sew-eurodrive.co.nz sales@sew-eurodrive.co.nz
	Christchurch	SEW-EURODRIVE NEW ZEALAND LTD. 10 Settlers Crescent, Ferrymead Christchurch	Tel. +64 3 384-6251 Fax +64 3 384-6455 sales@sew-eurodrive.co.nz
Nigeria			
Sales	Lagos	EISNL Engineering Solutions and Drives Ltd Plot 9, Block A, Ikeja Industrial Estate (Ogba Scheme) Adeniyi Jones St. End Off ACME Road, Ogba, Ikeja, Lagos Nigeria	Tel. +234 (0)1 217 4332 team.sew@eisnl.com http://www.eisnl.com
Norway			
Assembly Sales Service	Moss	SEW-EURODRIVE A/S Solgaard skog 71 N-1599 Moss	Tel. +47 69 24 10 20 Fax +47 69 24 10 40 http://www.sew-eurodrive.no sew@sew-eurodrive.no
Pakistan			
Sales	Karachi	Industrial Power Drives Al-Fatah Chamber A/3, 1st Floor Central Commercial Area, Sultan Ahmed Shah Road, Block 7/8, Karachi	Tel. +92 21 452 9369 Fax +92-21-454 7365 seweurodrive@cyber.net.pk
Paraguay			
Sales	Fernando de la Mora	SEW-EURODRIVE PARAGUAY S.R.L De la Victoria 112, Esquina nueva Asunción Departamento Central Fernando de la Mora, Barrio Bernardino	Tel. +595 991 519695 Fax +595 21 3285539 sew-py@sew-eurodrive.com.py
Peru			
Assembly Sales Service	Lima	SEW DEL PERU MOTORES REDUCTORES S.A.C. Los Calderos, 120-124 Urbanizacion Industrial Vulcano, ATE, Lima	Tel. +51 1 3495280 Fax +51 1 3493002 http://www.sew-eurodrive.com.pe sewperu@sew-eurodrive.com.pe
Poland			
Assembly Sales Service	Lodz	SEW-EURODRIVE Polska Sp.z.o.o. ul. Techniczna 5 PL-92-518 Łódź	Tel. +48 42 676 53 00 Fax +48 42 676 53 49 http://www.sew-eurodrive.pl sew@sew-eurodrive.pl
	Service	Tel. +48 42 6765332 / 42 6765343 Fax +48 42 6765346	Linia serwisowa Hotline 24H Tel. +48 602 739 739 (+48 602 SEW SEW) serwis@sew-eurodrive.pl
Portugal			
Assembly Sales Service	Coimbra	SEW-EURODRIVE, LDA. Apartado 15 P-3050-901 Mealhada	Tel. +351 231 20 9670 Fax +351 231 20 3685 http://www.sew-eurodrive.pt infosew@sew-eurodrive.pt
Romania			
Sales Service	Bucharest	Sialco Trading SRL str. Brazilia nr. 36 011783 Bucuresti	Tel. +40 21 230-1328 Fax +40 21 230-7170 sialco@sialco.ro
Russia			
Assembly Sales Service	St. Petersburg	ZAO SEW-EURODRIVE P.O. Box 36 RUS-195220 St. Petersburg	Tel. +7 812 3332522 +7 812 5357142 Fax +7 812 3332523 http://www.sew-eurodrive.ru sew@sew-eurodrive.ru

Senegal			
Sales	Dakar	SENEMECA Mécanique Générale Km 8, Route de Rufisque B.P. 3251, Dakar	Tel. +221 338 494 770 Fax +221 338 494 771 senemeca@sentoosn http://www.senemeca.com
Serbia			
Sales	Beograd	DIPAR d.o.o. Ustanicka 128a PC Košum, IV sprat SRB-11000 Beograd	Tel. +381 11 347 3244 / +381 11 288 0393 Fax +381 11 347 1337 office@dipar.rs
Singapore			
Assembly Sales Service	Singapore	SEW-EURODRIVE PTE. LTD. No 9, Tuas Drive 2 Jurong Industrial Estate Singapore 638644	Tel. +65 68621701 Fax +65 68612827 http://www.sew-eurodrive.com.sg sewsingapore@sew-eurodrive.com
Slovakia			
Sales	Bratislava	SEW-Eurodrive SK s.r.o. Rybničná 40 SK-831 06 Bratislava	Tel. +421 2 33595 202 Fax +421 2 33595 200 sew@sew-eurodrive.sk http://www.sew-eurodrive.sk
	Žilina	SEW-Eurodrive SK s.r.o. Industry Park - PChZ ulica M.R.Štefánika 71 SK-010 01 Žilina	Tel. +421 41 700 2513 Fax +421 41 700 2514 sew@sew-eurodrive.sk
	Banská Bystrica	SEW-Eurodrive SK s.r.o. Rudlovská cesta 85 SK-974 11 Banská Bystrica	Tel. +421 48 414 6564 Fax +421 48 414 6566 sew@sew-eurodrive.sk
	Košice	SEW-Eurodrive SK s.r.o. Slovenská ulica 26 SK-040 01 Košice	Tel. +421 55 671 2245 Fax +421 55 671 2254 sew@sew-eurodrive.sk
Slovenia			
Sales Service	Celje	Pakman - Pogonska Tehnika d.o.o. Ul. XIV. divizije 14 SLO - 3000 Celje	Tel. +386 3 490 83-20 Fax +386 3 490 83-21 pakman@siol.net
South Africa			
Assembly Sales Service	Johannesburg	SEW-EURODRIVE (PROPRIETARY) LIMITED Eurodrive House Cnr. Adcock Ingram and Aerodrome Roads Aeroton Ext. 2 Johannesburg 2013 P.O.Box 90004 Bertsham 2013	Tel. +27 11 248-7000 Fax +27 11 494-3104 http://www.sew.co.za info@sew.co.za
	Cape Town	SEW-EURODRIVE (PROPRIETARY) LIMITED Rainbow Park Cnr. Racecourse & Omuramba Road Montague Gardens Cape Town P.O.Box 36556 Chempet 7442 Cape Town	Tel. +27 21 552-9820 Fax +27 21 552-9830 Telex 576 062 bgriffiths@sew.co.za
	Durban	SEW-EURODRIVE (PROPRIETARY) LIMITED 48 Prospecton Road Isipingo Durban P.O. Box 10433, Ashwood 3605	Tel. +27 31 902 3815 Fax +27 31 902 3826 cdejager@sew.co.za
	Nelspruit	SEW-EURODRIVE (PTY) LTD. 7 Christie Crescent Vintonia P.O.Box 1942 Nelspruit 1200	Tel. +27 13 752-8007 Fax +27 13 752-8008 robermeyer@sew.co.za

South Korea			
Assembly Sales Service	Ansan	SEW-EURODRIVE KOREA CO., LTD. B 601-4, Banweol Industrial Estate #1048-4, Shingil-Dong, Danwon-Gu, Ansan-City, Kyunggi-Do Zip 425-839	Tel. +82 31 492-8051 Fax +82 31 492-8056 http://www.sew-korea.co.kr master.korea@sew-eurodrive.com
	Busan	SEW-EURODRIVE KOREA Co., Ltd. No. 1720 - 11, Songjeong - dong Gangseo-ku Busan 618-270	Tel. +82 51 832-0204 Fax +82 51 832-0230 master@sew-korea.co.kr
Spain			
Assembly Sales Service	Bilbao	SEW-EURODRIVE ESPAÑA, S.L. Parque Tecnológico, Edificio, 302 E-48170 Zamudio (Vizcaya)	Tel. +34 94 43184-70 Fax +34 94 43184-71 http://www.sew-eurodrive.es sew.spain@sew-eurodrive.es
Swaziland			
Sales	Manzini	C G Trading Co. (Pty) Ltd PO Box 2960 Manzini M200	Tel. +268 2 518 6343 Fax +268 2 518 5033 engineering@cgtrading.co.sz
Sweden			
Assembly Sales Service	Jönköping	SEW-EURODRIVE AB Gnejsvägen 6-8 S-55303 Jönköping Box 3100 S-55003 Jönköping	Tel. +46 36 3442 00 Fax +46 36 3442 80 http://www.sew-eurodrive.se jonkoping@sew.se
Switzerland			
Assembly Sales Service	Basel	Alfred Imhof A.G. Jurastrasse 10 CH-4142 Münchenstein bei Basel	Tel. +41 61 417 1717 Fax +41 61 417 1700 http://www.imhof-sew.ch info@imhof-sew.ch
Tanzania			
Sales	Dar es Salaam	SEW-EURODRIVE PTY LIMITED TANZANIA Plot 52, Regent Estate PO Box 106274 Dar Es Salaam	Tel. +255 0 22 277 5780 Fax +255 0 22 277 5788 uroos@sew.co.tz
Thailand			
Assembly Sales Service	Chonburi	SEW-EURODRIVE (Thailand) Ltd. 700/456, Moo.7, Donhuaroh Muang Chonburi 20000	Tel. +66 38 454281 Fax +66 38 454288 sewthailand@sew-eurodrive.com
Tunisia			
Sales	Tunis	T. M.S. Technic Marketing Service Zone Industrielle Mghira 2 Lot No. 39 2082 Fouchana	Tel. +216 79 40 88 77 Fax +216 79 40 88 66 http://www.tms.com.tn tms@tms.com.tn
Turkey			
Assembly Sales Service	Kocaeli-Gebze	SEW-EURODRIVE Sistemleri San. Ve TIC. Ltd. Sti Gebze Organize Sanayi Böl. 400 Sok No. 401 41480 Gebze Kocaeli	Tel. +90-262-9991000-04 Fax +90-262-9991009 http://www.sew-eurodrive.com.tr sew@sew-eurodrive.com.tr
Ukraine			
Assembly Sales Service	Dnipropetrovsk	ООО «СЕВ-Евродрайв» ул.Рабочая, 23-В, офис 409 49008 Днепропетровск	Тел. +380 56 370 3211 Факс. +380 56 372 2078 http://www.sew-eurodrive.ua sew@sew-eurodrive.ua
United Arab Emirates			
Sales Service	Sharjah	Copam Middle East (FZC) Sharjah Airport International Free Zone P.O. Box 120709 Sharjah	Tel. +971 6 5578-488 Fax +971 6 5578-499 copam_me@eim.ae

USA			
Production Assembly Sales Service	Southeast Region	SEW-EURODRIVE INC. 1295 Old Spartanburg Highway P.O. Box 518 Lyman, S.C. 29365	Tel. +1 864 439-7537 Fax Sales +1 864 439-7830 Fax Manufacturing +1 864 439-9948 Fax Assembly +1 864 439-0566 Fax Confidential/HR +1 864 949-5557 http://www.seweurodrive.com cslyman@seweurodrive.com
		SEW-EURODRIVE INC. Pureland Ind. Complex 2107 High Hill Road, P.O. Box 481 Bridgeport, New Jersey 08014	Tel. +1 856 467-2277 Fax +1 856 845-3179 csbridgeport@seweurodrive.com
		SEW-EURODRIVE INC. 2001 West Main Street Troy, Ohio 45373	Tel. +1 937 335-0036 Fax +1 937 332-0038 cstroy@seweurodrive.com
		SEW-EURODRIVE INC. 3950 Platinum Way Dallas, Texas 75237	Tel. +1 214 330-4824 Fax +1 214 330-4724 csdallas@seweurodrive.com
		SEW-EURODRIVE INC. 30599 San Antonio St. Hayward, CA 94544	Tel. +1 510 487-3560 Fax +1 510 487-6433 cshayward@seweurodrive.com
Additional addresses for service in the USA provided on request.			
Venezuela			
Assembly Sales Service	Valencia	SEW-EURODRIVE Venezuela S.A. Av. Norte Sur No. 3, Galpon 84-319 Zona Industrial Municipal Norte Valencia, Estado Carabobo	Tel. +58 241 832-9804 Fax +58 241 838-6275 http://www.sew-eurodrive.com.ve ventas@sew-eurodrive.com.ve sewfinanzas@cantv.net
Vietnam			
Sales	Ho Chi Minh City	All sectors except harbor and offshore: Nam Trung Co., Ltd 250 Binh Duong Avenue, Thu Dau Mot Town, Binh Duong Province HCM office: 91 Tran Minh Quyen Street District 10, Ho Chi Minh City	Tel. +84 8 8301026 Fax +84 8 8392223 namtrungco@hcm.vnn.vn truongtantam@namtrung.com.vn khanh-nguyen@namtrung.com.vn
		Harbor and offshore: DUC VIET INT LTD Industrial Trading and Engineering Services A75/6B/12 Bach Dang Street, Ward 02, Tan Binh District, 70000 Ho Chi Minh City	Tel. +84 8 62969 609 Fax +84 8 62938 842 totien@ducvietint.com
	Hanoi	Nam Trung Co., Ltd R.205B Tung Duc Building 22 Lang ha Street Dong Da District, Hanoi City	Tel. +84 4 37730342 Fax +84 4 37762445 namtrunghn@hn.vnn.vn
Zambia			
Sales	Kitwe	EC Mining Limited Plots No. 5293 & 5294,Tangaanyika Road, Off Mutentemuko Road, Heavy Industrial Park, P.O.BOX 2337 Kitwe	Tel. +260 212 210 642 Fax +260 212 210 645 sales@ecmining.com http://www.ecmining.com

Index

Numerical

2nd shaft end 49

A

AB., AD., AM., AK., AC., AS plug connectors 78
 Add-on encoder 89
 AG7 89
 AH7 89
 Ambient conditions 63
 Hazardous radiation 63
 Ambient temperature 63
 Anti-condensation heating 93
 AS7 89
 Assembly 35
 Measuring nipple 48
 Tolerances 36
 XH.A encoder mounting adapter 42
 XV.A encoder mounting adapter 39
 Auxiliary terminals, arrangement 199

B

Backstop 96
 BE – 11 130
 BE05 – 2 130
 BE20 131
 BE30 – 32 131
 BE60 – 122 132
 Bearing lubrication 102
 Bearings
 Reinforced 95, 103
 Brake
 BE05 – 2 130
 BE1 – 11 130
 BE20 131
 BE30 – 32 131
 BE60 – 122 132
 Brake connection 81
 Brake control 52, 81, 161
 BG 190
 BGE 190
 BMP3.1 195
 BSG 190
 BSR 192

BUR 190
 Control cabinet 164
 Motor wiring space 163
 Brake malfunctions 179
 Brake rectifier combinations 161
 Brake replacement
 DR..250 – 315, DRN250 – 315 145
 DR..71 – 80, DRN80 142
 DR..90 – 225, DRN90 – 225 143
 Brakemotor inspection
 DR..71 – 315, DRN80 – 315 127
 Brakemotor structure
 DR..160 – 280, DRN132M – 280 125
 DR..71 – 80, DRN80 123
 DR..90 – 132, DRN90 – 132S 124
 DR.315 126
 Brakes
 Braking torques 150
 Work done 150
 Working air gap 150
 Braking torques 150, 152
 Built-in encoder 90, 188

C

Changing the blocking direction 96
 Changing the brake disk
 BE05 – 122 135
 Changing the brake spring
 BE05 – 122 138
 Changing the braking torque
 BE05 – 122 137
 Changing the magnet body
 BE05 – 122 140
 Condensation drain holes 35
 Connecting the diagnostic unit 82
 Connecting the motor 64
 AB., AD., AM., AK., AC., AS plug connectors 78
 IS plug connector 74
 KC1 terminal strip 80
 KCC terminal strip 79
 Terminal box 65, 66, 67
 via plug connector 74
 via terminal board 65

via terminal strip	79
Connection	
Cable	101
Encoders	92
Variants	29
Copyright notice	11
Corrosion protection	103
Customer service	182

D

Delta connection	
R13	183
R72	184
Design	
Brakemotor	123, 124, 125
DR..160 – 280, DRN132M – 280 with BE	125
DR..160 – 180, DRN132M – 180	20, 117
DR..200 – 225, DRN200 – 225	21, 118
DR..250 – 280, DRN250 – 280	22, 119
DR..315, DRN315	23, 120
DR..71 – 132	19, 116
DR..71 – 80, DRN80 with BE	123
DR..90 – 132, DRN90 – 132S with BE	124
Motor	19, 20, 21, 22, 23, 116, 117, 118, 119, 120
Designated use	15
Disposal	182
Drive components, installation	36
DRK	61
DRK.. single-phase motor	
S1 duty type	175
DRK... single-phase motor	
Wiring diagram	198
Drying the motor	33
DUB (Diagnostic Unit Brake)	148
DUB diagnostic unit	82
Dusts	63
E	
EG7	89
EH7	89
EI7	188
EI7	90
Electrical connection	17
Electrical installation	51
Embedded safety notes	10

EMC	56
Encoder	
Non-SEW encoder mounting	39
Technical data	167
Encoder connection	92
Encoder mounting adapter	39, 41
Encoders	29, 89
AG7	89
AH7	89
AS7	89
EG7	89
EH7	89
EI7	90
ES7	89
Equipment, optional	28, 46, 83
ES7	89
Exclusion of liability	11
Explosion-proof motors	31
Extended fan guard	49
Extended storage	33

F

Forced cooling fan	
Wiring diagram	196
Forced cooling fan V	87
Frequency inverter operation	52
Functional safety	14, 173

G

Gases	63
General safety notes	12
Grounding	56
At the terminal box	55
LF	55

H

Hazard symbols	
Meaning	10
Hollow shaft rotary encoder	42
HR/HF manual brake release, retrofitting	38

I

Improving the grounding	56
Inspection	99
DUB for function and wear monitoring	149
DUB for function monitoring	148

DUB for wear monitoring	149
Inspection intervals	101
Installation	17, 35
Electrical	51
In damp locations or outdoors	35
Mechanical	32
Installation altitude	63
Installation note	
Encoders	92
Installation regulations	51
Installation tolerances	36
Installation, conditions	32
Insulation resistance	33
Insulation, reinforced	53
Intervals for inspection and maintenance	101
IS plug connectors	74
Isolation transformer	33
K	
KC1 terminal strip	80
KCC terminal strip	79
KTY84-130	85
KTY84-130 temperature sensor	85
L	
LF	46
LF air filter	46
Low-speed motors	60
Low-voltage equipment	51
Lubricant table	166
Lubrication	102
M	
Maintenance	99
Maintenance intervals	101
Malfunctions	176
Malfunctions when operating with a frequency in- verter	181
Measuring nipple mounting adapter	48
Mechanical installation	32
Motor	
Connect via terminal board	65
Connecting the terminal strip	79
Connecting via plug connector	74
Connection	64
Drying	33

Extended storage	33
Installation	35
Motor design	19
DR..160 – 180, DRN132M – 180	20, 117
DR..200 – 225, DRN200 – 225	21, 118
DR..250 – 280, DRN250 – 280	22, 119
DR..315, DRN315	23, 120
DR..71 – 132	19, 116
Motor designation	27
Motor feet	
Motor feet retrofitting/modifying	45
Motor inspection	
DR..71 – 315, DRN80 – 315	121
Motor malfunctions	177
Motor protection	186, 187
TF	186, 187
TH	186, 187
Motor protection device	52
Mounting adapter	39, 41
Measuring nipple	48
XH	114
XV.A	109, 110, 113
Mounting XH.A	42
N	
Nameplate	24
Non-SEW encoder mounting	39
Notes	
Designation in the documentation	9
Meaning of the hazard symbols	10
O	
Operating currents	154
Operation with frequency inverter	52
Optional equipment	46, 83
Overview	28
Options	28
Electrical	83
Mechanical	46
Other applicable documentation	16
P	
Plug connector	74
AB., AD., AM., AK., AC., AS	78
IS	74

Preliminary work for motor and brake maintenance	104
Product names	11
PT100.....	86
PT100 temperature detection.....	86
Pulse voltages.....	53

R

Reinforced bearings	95, 103
Relubrication	102
Relubrication device.....	102
Relubrication intervals.....	103
Removing the absolute encoder	109, 110, 113
Removing the encoder.....	104, 105, 106, 107, 109, 110, 113, 114
EG7. and AG7.....	105, 106
EH7. and AH7.	107
ES7. and AS7.	104
EV., AV., and XV.....	109, 110, 113
Removing the hollow shaft encoder	114
Removing the incremental encoder ...	109, 110, 113
EV., AV., and XV.....	109, 110, 113
Removing the rotary encoder.....	104, 105, 106, 107
EG7. and AG7.....	105, 106
EH7. and AH7.	107
ES7. and AS7.	104
Removing the special encoder.....	109, 110, 113
Resistance measurement of the brake	158, 160
Resistances.....	157
Retrofitting the HR/HF manual brake release	37
Retrofitting the manual brake release HR/HF	38
Rights to claim under limited warranty	11
Rolling bearing types.....	165
RS	96

S

Safety characteristics	173
Safety notes	12
Designated use	15
Designation in the documentation.....	9
Electrical connection	17
General	12
Installation	17
Operation	18
Structure of embedded	10
Structure of the safety notes	9

Transport.....	16
Safety, functional.....	173
Second shaft end	49
Section-related safety notes.....	9
Set the working air gap	
BE05 – 122	133
Signal words in the safety notes	9
Single-phase motor	61
Special design.....	32
Special features	
Low-speed motors	60
Switching operation.....	60
Torque motors.....	60
Star connection	
R13	183
R76	185
Startup.....	94
Storage, extended.....	33
Structure	
Brakemotor	126
DR.315 with BE.....	126
DUB	146, 147
Switching operation.....	60

T

Technical data	150
ASI absolute encoder.....	169
Incremental rotary encoders with plug-in shaft ...	167
Incremental rotary encoders with solid shaft.....	171
Incremental rotary encoders with spread shaft....	167
SSI absolute encoder.....	168
Terminal arrangement.....	199
Terminal board	65
Terminal box	
Turn.....	43
Terminal box positions	199
Terminal strip	79
KC1	80
KCC	79
TF	186, 187
TF temperature sensor.....	83
TH	84, 186, 187
TH winding thermostats	84

Torque motors.....	60
Trademarks.....	11
Transport.....	16
TS.....	83
Type designation.....	26
Output types, output types.....	28
Temperature detection.....	28
Type designation DR..	
Bearings.....	30
Condition monitoring.....	30
Connection variants.....	29
Encoders.....	29
Explosion-proof motors.....	31
Mechanical attachments.....	28
Other additional features.....	30
Temperature sensor and temperature detection.....	28
Ventilation.....	30

U

UWU51A switched-mode power supply.....	88
--	----

V

V forced cooling fan.....	87
Vapors.....	63
Visual feedback.....	90

W

Warning notes	
Meaning of the hazard symbols.....	10
Wear.....	101
Wiring diagram	
BG.....	190
BGE.....	190
BMP3.1.....	195
BSG.....	191
R13 delta connection.....	183, 184
R13 star connection.....	183
R76 star connection.....	185
Wiring diagrams.....	183
BSR.....	192
TF.....	186, 187
TH.....	186, 187
Work done.....	150
Working air gap.....	150

X

XV.A mounting.....	39
--------------------	----





SEW-EURODRIVE
Driving the world

SEW
EURODRIVE

SEW-EURODRIVE GmbH & Co KG
P.O. Box 3023
76642 BRUCHSAL
GERMANY
Phone +49 7251 75-0
Fax +49 7251-1970
sew@sew-eurodrive.com
→ www.sew-eurodrive.com