



**SEW**  
**EURODRIVE**

# Operating Instructions



Decentralized Drive and Application Controller  
**MOVIPRO® PHC22A-A150M1-E25A-99/S11**  
with connection for energy management



## Table of contents

<b>1</b>	<b>General information .....</b>	<b>5</b>
1.1	About this documentation .....	5
1.2	Structure of the safety notes .....	5
1.3	Rights to claim under limited warranty .....	6
1.4	Exclusion of liability .....	6
1.5	Other applicable documentation .....	7
1.6	Product names and trademarks .....	7
1.7	Copyright notice .....	7
<b>2</b>	<b>Safety notes .....</b>	<b>8</b>
2.1	Preliminary information .....	8
2.2	General information .....	8
2.3	Target group .....	9
2.4	Designated use .....	9
2.5	Functional safety technology .....	9
2.6	Transport .....	10
2.7	Installation/assembly .....	10
2.8	Electrical connection .....	10
2.9	Safe disconnection .....	11
2.10	Startup/operation .....	11
2.11	Inspection/maintenance .....	12
<b>3</b>	<b>Unit structure .....</b>	<b>13</b>
3.1	Type designation .....	13
3.2	Scope of delivery .....	13
3.3	Short designation .....	13
3.4	Unit overview .....	14
3.5	Labels on the unit .....	15
3.6	Operating principle .....	16
3.7	Function Units .....	17
<b>4</b>	<b>Integrated safety technology.....</b>	<b>23</b>
4.1	Standards .....	23
4.2	Safety functions .....	23
4.3	Safety concept .....	23
4.4	Additional information .....	23
<b>5</b>	<b>Mechanical installation .....</b>	<b>24</b>
5.1	Requirements .....	24
5.2	Assembly .....	28
<b>6</b>	<b>Electrical installation.....</b>	<b>36</b>
6.1	General information .....	36
6.2	Low-voltage supply systems .....	36
6.3	Contactors .....	36
6.4	Electromagnetic compatibility (EMC) .....	36
6.5	Cable routing .....	36
6.6	Using prefabricated cables .....	37

6.7	Installation topology of SNI .....	38
6.8	Installation altitude higher than 1000 m above sea level .....	39
6.9	Shielding .....	39
6.10	Unit output .....	39
6.11	Motor types .....	40
6.12	Protective measures against electrical hazards .....	41
6.13	Connection block .....	44
6.14	Electrical connections .....	46
<b>7</b>	<b>Startup .....</b>	<b>95</b>
7.1	General information .....	95
7.2	Prerequisites .....	96
7.3	Lifting applications .....	96
7.4	SD memory card .....	97
<b>8</b>	<b>Operation.....</b>	<b>98</b>
8.1	Energy management components .....	99
8.2	Relative cyclic duration factor (cdf) .....	99
8.3	Duty cycles .....	99
8.4	Status and error messages .....	101
<b>9</b>	<b>Service.....</b>	<b>108</b>
9.1	Inspection/maintenance .....	108
9.2	Unit replacement .....	108
9.3	Encoder replacement .....	109
9.4	Display .....	110
9.5	Error information of the power section .....	110
9.6	Shutdown .....	111
9.7	Storage .....	111
9.8	Extended storage .....	111
9.9	Waste disposal .....	112
9.10	Additional information .....	112
<b>10</b>	<b>Technical data.....</b>	<b>113</b>
10.1	Basic unit .....	113
10.2	Axis data .....	115
10.3	Communication and control unit .....	116
10.4	Dimension drawing .....	117
10.5	Hybrid cable type "D" .....	118
10.6	Hybrid cable type "E" .....	119
<b>11</b>	<b>Additional documentation .....</b>	<b>121</b>
<b>12</b>	<b>MAXOLUTION® Competence Center.....</b>	<b>122</b>
<b>13</b>	<b>Address list.....</b>	<b>124</b>
	<b>Index .....</b>	<b>136</b>

## 1 General information

### 1.1 About this documentation

This documentation is an integral part of the product. The documentation is intended for all employees who perform assembly, installation, startup, and service work on the product.

Make sure this documentation is accessible and legible. Ensure that persons responsible for the machinery and its operation as well as persons who work on the device independently have read through the documentation carefully and understood it. If you are unclear about any of the information in this documentation or require further information, contact SEW-EURODRIVE.

### 1.2 Structure of the safety notes

#### 1.2.1 Meaning of signal words

The following table shows the grading and meaning of the signal words for safety notes.

Signal word	Meaning	Consequences if disregarded
<b>▲ DANGER</b>	Imminent hazard	Severe or fatal injuries.
<b>▲ WARNING</b>	Possible dangerous situation	Severe or fatal injuries.
<b>▲ CAUTION</b>	Possible dangerous situation	Minor injuries
<b>NOTICE</b>	Possible damage to property	Damage to the drive system or its environment.
<b>INFORMATION</b>	Useful information or tip: Simplifies handling of the drive system.	

#### 1.2.2 Structure of section-related safety notes

Section-related safety notes do not apply to a specific action but to several actions pertaining to one subject. The hazard symbols used either indicate a general hazard or a specific hazard.

This is the formal structure of a safety note for a specific section:



##### **SIGNAL WORD**

Type and source of hazard.






Possible consequence(s) if disregarded.

- Measure(s) to prevent the hazard.

#### Meaning of the hazard symbols

The hazard symbols in the safety notes have the following meaning:

Hazard symbol	Meaning
	General hazard

Hazard symbol	Meaning
	Warning of dangerous electrical voltage
	Warning of hot surfaces
	Warning of risk of crushing
	Warning of suspended load
	Warning of automatic restart

### 1.2.3 Structure of embedded safety notes

Embedded safety notes are directly integrated into the instructions just before the description of the dangerous action.

This is the formal structure of an embedded safety note:

- **▲ SIGNAL WORD** Type and source of hazard.  
Possible consequence(s) if disregarded.  
– Measure(s) to prevent the hazard.

## 1.3 Rights to claim under limited warranty

Read the information in this documentation. This is essential for fault-free operation and fulfillment of any rights to claim under limited warranty. Read the documentation before you start working with the unit!

## 1.4 Exclusion of liability

Read the information in this documentation, otherwise safe operation is impossible. You must comply with the information contained in this documentation to achieve the specified product characteristics and performance features. SEW-EURODRIVE assumes no liability for injury to persons or damage to equipment or property resulting from non-observance of these operating instructions. In such cases, SEW-EURODRIVE assumes no liability for defects.

## **1.5 Other applicable documentation**

Observe the corresponding documentation for all connected devices. Observe the following documentation in addition to the operating instructions:

<b>Title</b>	<b>Part number</b>
"MOVIPRO® Functional Safety" manual	19289626/EN
"Drive Power Solution – MOVI-DPS Energy Interface EKK-A-....-I06-500-.-0/E1." operating instructions	21293007/EN

## **1.6 Product names and trademarks**

The brands and product names in this documentation are trademarks or registered trademarks of their respective titleholders.

## **1.7 Copyright notice**

© 2015 SEW-EURODRIVE. All rights reserved.

Unauthorized reproduction, modification, distribution or any other use of the whole or any part of this documentation is strictly prohibited.

## 2 Safety notes

### 2.1 Preliminary information

The following basic safety notes must be read carefully to prevent injury to persons and damage to property. The user must ensure that the basic safety notes are read and observed. Make sure that persons responsible for the system and its operation, as well as persons who work independently on the unit, have read through the operating instructions carefully and understood them. If you are unclear about any of the information in this documentation, or if you require further information, please contact SEW-EURODRIVE.

The following safety notes are primarily concerned with the use of the unit described in these operating instructions. If you use other components from SEW-EURODRIVE, also refer to the safety notes for these particular components in the corresponding documentation.

Please also observe the supplementary safety notes in the individual chapters of this documentation.

### 2.2 General information



#### ⚠ WARNING

Depending on its degree of protection, the unit may have live, uninsulated as well as moving or rotating parts and hot surfaces during operation.

Severe or fatal injuries.

- All work related to transportation, storage, installation, assembly, connection, startup, maintenance, and repair may only be carried out by qualified personnel, in strict observance of
  - The relevant detailed documentation
  - The warning and safety signs on the unit
  - All other relevant project planning documents, startup instructions and wiring diagrams
  - The specific regulations and requirements for the system
  - The national/regional regulations governing safety and the prevention of accidents.
- Never install damaged products.
- Submit a complaint to the shipping company immediately in the event of damage.

Removing covers without authorization, improper use as well as incorrect installation or operation may result in severe injuries to persons or damage to machinery.

Refer to the following chapters for more information.

## 2.3 Target group

Mechanical work of any kind may be carried out only by trained specialists. Specialists in the context of this documentation are persons who are familiar with the design, mechanical installation, troubleshooting, and maintenance of the product and have the following qualifications:

- Training in mechanical engineering (for example, as a machinist or mechatronics technician) and the successful completion of final examinations.
- Knowledge of this documentation.

Electrical work of any kind may be carried out only by skilled persons. In the context of this documentation, skilled persons are persons who are familiar with the electrical installation, startup, troubleshooting, and maintenance of the product and who have the following qualifications:

- Training in electrical engineering (for example, as an electronics technician or mechatronics technician) and the successful completion of final examinations.
- Knowledge of this documentation.

In addition to that, they must be familiar with the relevant safety regulations and laws, especially with the requirements of the performance levels in accordance with DIN EN ISO 13849-1 and all other standards, directives and laws specified in this documentation. The above-mentioned persons must have the express authorization of the company to operate, program, parameterize, identify, and ground units, systems, and circuits in accordance with safety technology standards.

All work in the areas of transportation, storage, operation, and waste disposal must be performed by suitably trained personnel.

## 2.4 Designated use

The device can be used in mobile and stationary operation in industrial and commercial plants for the operation of AC asynchronous motors with squirrel cage rotor or permanent-field AC synchronous motors. The motors must be suitable for operation with frequency inverters. Do not connect any other loads to the device. The device can take on control and communication tasks.

In case of installation in electrical systems or machines, startup of the device (i.e. start of designated operation) is prohibited until it is determined that the machine meets the requirements stipulated in the EC Directive 2006/42/EC (Machinery Directive). Observe standard EN 60204-1. Startup (i.e. the start of designated use) is only permitted under observance of the EMC Directive (2004/108/EC).

The unit meets the requirements stipulated in the Low Voltage Directive 2006/95/EC. The standards included in the declaration of conformity are used for the unit.

Technical data and information on the connection conditions are provided on the nameplate and in the documentation. Always comply with the data and conditions.

## 2.5 Functional safety technology

The unit may not perform safety functions without higher-level safety systems unless these functions are described and expressly permitted in the relevant documentation.

## 2.6 Transport

Inspect the shipment for transport damage as soon as you receive the delivery. Inform the shipping company immediately of any damage. If necessary, put startup on hold.

Note the following points regarding transport:

- Before transportation, cover the connections with the supplied protection caps.
- Place the unit only on the cooling fins or on a side without connectors during transportation.
- Ensure that the unit is not subjected to mechanical impact during transportation.

If necessary, use suitable, sufficiently rated handling equipment. Prior to startup, remove the transport protection.

Observe the information on climatic conditions as stated in chapter "Technical Data".

## 2.7 Installation/assembly

Ensure that the unit is installed and cooled according to the regulations in the related documentation.

Protect the unit from excessive strain. Especially during transportation and handling, do not allow the components to be deformed or insulation spaces altered. Electrical components must not be mechanically impaired or irreparably damaged.

The following applications are prohibited unless explicitly permitted:

- Use in potentially explosive atmospheres
- Use in environments exposed to harmful oils, acids, gases, vapors, dust, radiation, etc.
- Use in applications that are subject to mechanical vibration and impact loads in excess of the requirements in EN 61800-5-1.

Observe the notes in the "Mechanical installation" chapter.

## 2.8 Electrical connection

Observe the applicable national accident prevention regulations when working on a live unit.

Perform electrical installation according to the pertinent regulations (e.g. cable cross sections, fusing, protective earth connection). The documentation contains additional notes.

Preventive measures and protection devices must meet the applicable regulations (e.g. EN 60204-1 or EN 61800-5-1).

Necessary preventive measures for mobile use:

Type of energy transfer	Preventive measure
Direct power supply	<ul style="list-style-type: none"> <li>• Ground connection</li> </ul>
MOVITRANS® contactless energy transfer system	<ul style="list-style-type: none"> <li>• Protective separation DIN VDE 0100-410 / IEC 60364-4-41</li> <li>• Electrostatic discharge (ESD) protection</li> </ul>

Necessary preventive measures for stationary use:

Type of energy transfer	Preventive measure
Direct power supply	• Ground connection
MOVITRANS® contactless energy transfer system	

## 2.9 Safe disconnection

The unit meets all requirements for the safe disconnection of power and electronics connections in accordance with EN 61800-5-1. To ensure safe disconnection, all connected circuits must also comply with the requirements for safe disconnection.

## 2.10 Startup/operation



### ▲ CAUTION

Danger of burns due to hot surfaces of the unit or connected options, e.g. braking resistors

Injury

- Secure hot surfaces by covering them.
- Install the protection devices according to the regulations.
- Check the protection device at regular intervals.
- Let the unit and the connected options cool down before you start working on them.

Do not deactivate monitoring and protection devices even for a test run.

When in doubt, switch off the unit whenever changes occur in relation to normal operation (e.g. increased temperatures, noise, oscillation). Determine the cause of the fault and consult SEW-EURODRIVE, if necessary.

Where required, systems in which such units are installed must be equipped with additional monitoring and protection devices in accordance with the respective applicable safety regulations, e.g. the law governing technical equipment, accident prevention regulations, etc.

Additional protective measures may be necessary for applications with increased hazard potential. You must check the functionality of protection devices each time you change the configuration.

Connections that are not being used must be covered with the supplied protection caps during operation.

Do not touch live components or power connections immediately after disconnecting the unit from the voltage supply because some capacitors may still be charged. Adhere to a minimum switch-off time of 10 minutes. Observe the corresponding labels on the unit.

When the unit is switched on, dangerous voltages are present at all power connections as well as at any connected cables and motor terminals. This also applies even when the unit is inhibited and the motor is at standstill.

The fact that the operation LED and other display elements are no longer illuminated does not indicate that the unit has been disconnected from the supply system and no longer carries any voltage.

Mechanical blocking or internal safety functions of the unit can cause a motor standstill. Eliminating the cause of the problem or performing a reset may result in the drive re-starting automatically. If, for safety reasons, this is not permitted for the drive-controlled machine, disconnect the unit from the supply system before correcting the error.

## 2.11 Inspection/maintenance



### **⚠ WARNING**

Danger of electric shock due to exposed, live parts in the unit.

Severe or fatal injuries

- Never open the unit.
  - Only SEW-EURODRIVE is authorized to carry out repairs.
-

### 3 Unit structure

#### 3.1 Type designation

The type designation of the drive and application controller MOVIPRO® PHC22A-A150M1-E25A-99/S11 includes the following characteristic unit data:

<b>PHC22A</b>	MOVIPRO® drive and application controller
-	
<b>A</b>	Energy supply: Three-phase alternating current
<b>150</b>	Rated input power: 15 kW
<b>M1</b>	1 integrated power section
-	
<b>E2</b>	Fieldbus connection: PROFINET IO
<b>5A</b>	Function level: CCU
-	
<b>99</b>	Unit design: customer specific unit
/	
<b>S11</b>	PROFIsafe option S11

#### 3.2 Scope of delivery

The following components are included in the scope of delivery:

Component	Part number
PHC22A-A150M1-E25A-99/S11	18258964
SD memory card OMC41B-T1	18228771
Protective covers for all plug connectors	-
Grounding kit	12704628
Jumper plug energy management	18166903


#### 3.3 Short designation

The following short designations are used in this documentation:

Type designation	Short designation
PHC22A-A150M1-E25A-99/S11	Unit

### 3.4 Unit overview

The following figure provides an overview of the most important unit components and the position of the labels on the unit:




- [1] Main nameplate
- [2] Nameplate of function modules (optional)
- [3] Status display
- [4] MAC address label
- [5] Cooling fins
- [6] T-slot profile
- [7] Miniature circuit breaker (optional)
- [8] Connection block
- [9] Service interface
- [10] Memory card cover
- [11] Connection block label
- [12] Handles (optional)

You can equip the unit with handles for easier handling. For more information, refer to the Addendum to the "MOVIPRO® – Accessories" operating instructions.

### 3.5 Labels on the unit

#### 3.5.1 Main nameplate

The following figure shows an example of a nameplate:



9007212603009931


[1] UL approval depending on the unit variant

The main nameplate lists the following information:

- Type designation (*Type*)
- Production number (*SO#*)
- Part number (*Part#*)
- Voltage (*U*)
- Current (*I*)
- Frequency (*f*)
- Ambient temperature (*T*)
- Rated output power (*P*)
- Degree of protection (*IP*)

#### 3.5.2 Connection block label


The designations of the individual connections of the unit are given on the connection block label. The following figure shows an example of a connection block label:



63050399610367755

## 3.6 Operating principle

The block diagram below shows the basic structure of the unit. The following section describes the internal elements:



18014407284585995

**PFH.. – Communication and control unit**

- [1] PROFINET fieldbus unit (→ 19)
- [2] Service unit (→ 21)
- [3] Processing unit (→ 20)
- [4] PROFIsafe option S11 (→ 20)

**PFA.. – Internal axis**

- [5] Frequency inverter on MOVIDRIVE® basis (→ 19)
- [6] Safety-relevant BST brake module
- [7] Encoder evaluation (→ 19)

**PFZ-SN.. – Actuator module**

- [8] Circuit breaker (→ 17)

**[C] Power supply PFE..**

[9] Supply system rectifier (→ 18)

[10] 24 V power supply unit for internal components (→ 18)

**3.7 Function Units****3.7.1 Actuator module PFZ-SN..**

The actuator module PFZ-SN.. modulates the SNI signal onto the supply system cable. This means the same cable is used for communication and power supply of the connected components (**SNI = Single Line Network Installation**). The actuator module PFZ-SN.. can service up to 10 SNI actuators.

The NET LED indicates the communication status between the application controller and component. For the position of the NET LED on the application controller, refer to chapter "Electrical Connections" (→ 46). For information about the status messages output by the NET LED, refer to chapter "Operation".


**Circuit breaker****NOTICE**

Increased wear on contacts caused by activating the miniature circuit breaker in energized state

Damages to the unit

- Always actuate the miniature circuit breakers in a de-energized state.

The miniature circuit breakers are located below a plastic cover that is secured by screw plugs:



9007205082719883

- [1] Unit
- [2] Plastic cover
- [3] Screw plugs
- [4] Miniature circuit breaker

The miniature circuit breakers protect the line phases leading out of the following plug connectors from overcurrent:

- X2241, AC 400 V output for unit supply with Single Line Network Installation (SNI)
- X2371, AC 400 V output to supply external devices

### 3.7.2 PFE.. power supply

#### When MOVI-DPS EKK is connected

Refer to section "Safety notes" > "Startup/operation" in the operating instructions "MOVI-DPS energy and power interface EKK-A-....-I06-500-0-0/E..".

#### 24 V power supply unit for internal components

The unit is equipped with an integrated power supply that uses the DC link voltage to generate a DC 24 V supply for internal components.

#### Supply system rectifier

Energy is supplied to the unit via a three-phase alternating current supply system and a line rectifier. The line rectifier supplies the DC link voltage.

### 3.7.3 Internal axis PFA..

The function module consists of the following internal elements.

### Frequency inverter on MOVIDRIVE® basis

The frequency inverter controls synchronous and asynchronous motors. For further information on system properties and motor assignment refer to the "MOVIDRIVE® MDX60B/61B" system manual.

### Encoder evaluation

Encoder evaluation enables the drive inverter to control different motor types, such as synchronous servomotors. For detailed information on encoder evaluation, refer to section "Technical data > Axis data".

### Motor types

The unit supports the following motor series from SEW-EURODRIVE:

- DRE..
- DRS..
- DRP..
- CM..

### Safety-relevant BST brake module



#### ▲ WARNING

Failure of the BST safety-related brake module and sudden brake application if performance data are exceeded.

Severe or fatal injuries.

- For safety applications observe the information in the "MOVIPRO® – Functional safety" manual.

The safety-related BST brake module supplies and controls the SEW-EURODRIVE disc brakes connected to the motors. Only use approved disk brakes. Redundant systems may use multiple brake coils.

Observe the maximum voltage and power levels. For more information, refer to section "Technical Data". For information on the control outputs, refer to section "Startup" > "Brake module control".

For further information, refer to the following documentation:

- "Safety-Related BST Brake Module" operating instructions
- "MOVIPRO® Functional Safety" manual

### 3.7.4 Communication and control unit

The function module consists of the following internal elements.

#### PROFINET fieldbus unit


The device has a PROFINET module for connection to the fieldbus. The bus is connected via plugs as described in chapter "Electrical connections".

### PROFIsafe option S11

The application controller supports parallel operation of standard and safety-related communication via a bus system or network. The safety-related PROFIsafe communication can be carried out via PROFINET.

The data exchange between bus master and application controller takes place via the respective communication system that simultaneously acts as a "gray channel" for the safety-related application. The transmitted bus messages contain standard information for conventional application controller operation and the PROFIsafe safety telegram. Depending on the configuration, the maximum available expansion level enables exchanges of PROFIsafe safety data, parameter and process data between the bus master and the application controller.

The following figure outlines the communication:



9007200895639947

### Processing unit

The unit is equipped with a MOVI-PLC® processor unit.

The engineering of the communication and control unit comprises the following activities:

- Configuration
- Parameterization
- Programming


These activities are carried out using MOVITOOLS® MotionStudio engineering software. The software enables startup and error diagnostics for all SEW-EURODRIVE units. The unit is connected to the engineering computer via the service interface.

For further information, refer to the "Controller DHE21B / DHF21B / DHR21B (standard), DHE41B / DHF41B / DHR41B (advanced)" manual.

### SD memory card

The slot for the memory card is located under the memory card cover on the top of the unit. The cover ensures the degree of protection of the unit and enables easy access in the event of a required replacement or any other maintenance procedures.

The following figure shows the memory card cover:



27021598965048843

- [1] Retaining nuts (4×)
- [2] Memory card cover


### Removing the memory card cover

1. Loosen the 4 retaining nuts.
2. Lift the memory card cover upwards.

### Service unit

The service unit is used for startup, diagnostics and maintenance of the unit. It is equipped with a status display, 3 status LEDs and a service interface.

The following figure shows the service unit:



9007207512455435

- [1] Status display
- [2] Ethernet service interface (Ethernet RJ45)
- [3] Status LED

The status display and status LEDs display status and error messages and thus enable you to record the current state of the unit.

For further information, refer to section "Operation" > "Status messages" and the documentation of the application software.

The Ethernet service interface connects the unit with an engineering PC for configuration and maintenance purposes.

Ethernet service interface:

- Standard IP address: 192.168.10.4
- Subnet mask: 255.255.255.0

## 4 Integrated safety technology



### ▲ WARNING

Failure of the safety components due to improper startup.

Severe or fatal injuries.

- Only use the unit in combination with functional safety technology when you have the "MOVIPRO® – Functional Safety" manual at hand and you have ensured compliance with the requirements for operation with functional safety.

### 4.1 Standards

The safety technology of the unit described below has been developed and tested in accordance with the following safety requirements:

- DIN EN 1037: 2008
- EN ISO 13849-1: 2008
- EN ISO 13849-2: 2008

### 4.2 Safety functions

You can use the following drive-related safety function:

- STO – Safe Torque Off according to EN 61800-5-2: 2007
- SS1(c) Safe Stop 1 – function variant c according to EN 61800-5-2: 2007
- SBC – Safe Brake Control according to EN 61800-5-2: 2007

### 4.3 Safety concept

The following safety concepts can be realized with this unit:

- Axis module with safe torque off
- Safety-related brake module
- PROFIsafe option S11

### 4.4 Additional information

For detailed information, refer to the "MOVIPRO® – Functional Safety" manual.

## 5 Mechanical installation

### 5.1 Requirements



#### ▲ WARNING

Risk of crushing if the load falls

Severe or fatal injuries

- Do not sit or stand underneath the load.
- Secure the area in which the mechanical installation is to take place.



#### NOTICE

Risk of collision

Damage to plant and unit components

- Always position the unit in such a way that it will not collide with other components or design elements along the travel route.

The following preconditions must be fulfilled for the mechanical installation:

- Trained specialists perform the installation.
- The information provided in the technical data and the permitted conditions for the operating location of the unit are observed.
- The minimum clearance and distance and the required gaps for using a mounting plate are complied with; see the "Minimum clearance" section.
- The unit is only mounted using the intended mounting options.
- The selection and dimensioning of the mounting and locking elements are in line with the applicable standards, the technical data of the units and the local requirements.
- The bore dimensions are calculated in line with the particular method of fastening. See the following sections.
- The mounting and locking elements fit into the existing bores, threads and counter-sinks.
- All display and actuator elements are visible and accessible after installation.

#### 5.1.1 Mounting position


The mounting position for units with cooling fins depends on the application:

Applica- tion	Mounting po- sition	Speed	Power reduction
Stationary	Vertical [1]	-	-
	Horizontal [2]		50%
Mobile	Vertical [1]	Slow traveling velocity ≤ 0.5 m/s	-
	Horizontal [2]		50%
	Vertical [1]	Fast traveling velocity > 0.5 m/s	-
	Horizontal [2]		-

In stationary applications, the horizontal mounting position [2] causes a power reduction of 50% due to reduced convection.

When using a horizontal mounting position for a mobile application, the cooling fins must be parallel to the travel direction so that sufficient cooling and convection are possible.

The following figure shows permissible and impermissible mounting positions:



9007200455213451

- [1] Permissible vertical mounting position
- [2] Conditionally permitted horizontal mounting position
- [3] Impermissible mounting positions

### 5.1.2 Minimum clearance


## INFORMATION



- Make sure to provide the required minimum clearance when installing for:
  - the connection of the cables and plug connectors
  - Handling the display elements, diagnostics elements and actuator elements
  - heat convection at the level of the cooling fins, if installed
- Refer to the dimension drawing in the chapter "Technical data" for information on the required space.

### Vertical installation

The following figure shows the required minimum clearance sizes of the unit:




9007209054909579

Refer to the following table for the minimum distance sizes and minimum clearance sizes:

Clearance	Function	Size
<b>A: Above</b>	Space for optimum heat convection: The cooling fins may not be located in a closed hollow space.	≥ 200 mm (7.9 in)
<b>B: Behind the cooling fins</b>	Space for optimum heat convection	≥ 15 mm (0.59 in)
<b>C: To the side on the right</b>	Space for connection cables, plug connectors, add-on elements and elements for operation, such as maintenance switch	See dimension drawing
<b>D: Below</b>	Space for connection cables and plug connectors	See dimension drawing
<b>E: Unit cover</b>	Space for display elements, diagnostics elements and actuator elements, e.g. service unit	≥ 150 mm (5.91 in)
<b>F: On the side (optional)</b>	Space for connection cables, plug connectors, add-on elements and elements for operation, such as maintenance switch	See dimension drawing

## Horizontal installation

The following figure shows the required minimum clearance sizes of the unit:



36028797483068939

- [A] Housing cover clearance
- [B] Clearance on the side
- [C] Clearance below the cooling fins
- [Z<sub>1</sub>] Housing cover clearance height
- [Z<sub>2</sub>] Cooling fins clearance height

Refer to the following table for the minimum distance sizes and minimum clearance sizes:

Clearance	Function	Size
<b>A: Housing cover</b> Height Z <sub>1</sub>	Space for display elements, diagnostics elements and actuator elements, e.g. service unit	Z <sub>1</sub> = min. 150 mm (5.91 in)
<b>B: On the side (optional)</b>	Space for connection cables, plug connectors, add-on elements and elements for operation, such as maintenance switch	See dimension drawing
<b>C: Behind the cooling fins</b> Height Z <sub>2</sub>	Space for optimum heat convection: The cooling fins may not be located in a closed hollow space.	Z <sub>2</sub> ≥ 15 mm (0.59 in)

### 5.1.3 Waste heat

Ensure that the cooling fins can dissipate waste heat into the environment by free convection.

Observe the following notes to ensure optimum heat convection:

- Use SEW mounting systems or suitable spacers, e.g.:
  - Spacers
  - Profiles
  - Square pipes
  - Mounting plates
  - T-beams

- Rails
- Ensure that the cooling fins are not located in a closed hollow space.
- It is essential that a minimum distance of 15 mm (0.59 in) between the highest cooling fin and the next surface, e.g. a mounting plate, is maintained.
- Avoid heat sources in the immediate proximity of the unit.

## 5.2 Assembly

Use one of the following mechanical mounting options:

- Mounting with mounting brackets
- Mount using the through bores

### 5.2.1 Mounting with mounting brackets



#### ▲ CAUTION

Risk of injury due to protruding parts

Minor injuries

- Wear suitable protective gloves.



#### NOTICE


External force too high

Damage to the thread or the screw

- Do not exceed the maximum tightening torque of 3.2 Nm (28 in-lb).

#### Required material

- SEW-EURODRIVE "Large bracket mounting set" accessory (part number 12708305):
  - 4 mounting brackets
  - 8 M5 × 8 studs
- Holding fixture, e.g. square pipe with an edge length ≤ 32 mm
- Suitable fastening and locking elements, e.g. M6 or M8 screws of suitable length with washers



63050395199050507

- [1] Unit
- [2] M5 × 8 studs
- [3] Large mounting bracket
- [4] Bore for M8 screw of suitable length with washer
- [5] Bore for M5 × 8 stud
- [6] Bore for M8 × 30 screw
- [7] T-slot
- [8] Bore for M6 screw of suitable length with washer
- [9] Holding fixture, e.g. square pipe with an edge length ≤ 32 mm


### Fastening the mounting plates

1. Insert the mounting bracket [3] into the T-slot [7] of the unit [1] so that the upper edge of the bracket is flush with the upper end of the slot.
2. In order to prevent the mounting bracket [3] from slipping out of position in the T-slot [7], fix the mounting bracket with M8 x 30 screws [6] in the through holes of the unit.
3. Firmly fasten the mounting bracket [3] using the studs [2] supplied in the T-slot [7].
4. Repeat the steps for the other mounting bracket.

### Preparing the holding fixture

Square pipes can be used as a holding fixture for the unit. Use only square pipes with an edge length ≤ 32 mm for mounting the unit to avoid mechanical interference.

The following figure shows the required dimensions:



9686885899

X, Y Housing dimensions; see chapter "Technical Data"  
 X<sub>2</sub> Bore dimension  
 A Distance

### Procedure

1. Refer to the dimension drawing in the "Technical data" (→ 113) chapter for the housing dimensions X and Y.
2. Refer to the following table for dimensions of the tapped holes in the holding fixture:

Bore dimension	Value
X <sub>2</sub>	Housing dimension X – 30 mm (1.2 in)


3. Mark the tapped holes of the holding fixture.
4. Cut the threads for the bolts [7] at the marked points.
5. Refer to the following table for distance dimensions for the holding fixture:

Distance	Value
A	Housing dimension Y – 145 mm (5.71 in)

6. Mark the spacing at the installation location.
7. Mount the holding fixture at the installation location at the calculated distance.

## Mounting the unit

1. Use the mounting brackets to hang the unit on the fixture.
2. Fasten the mounting brackets securely using the M6 screws through the bores on the holding fixture.



9797753867

### 5.2.2 Mounting using the through bores



#### ⚠ CAUTION

Risk of injury due to protruding parts

Minor injuries

- Wear suitable protective gloves.



#### NOTICE


External force too high

Damage to the thread or the screw

- Do not exceed the maximum tightening torque of 3.2 Nm (28 in-lb).

In order to attach the unit, it is equipped with 4 through bores in the corner profiles with a diameter of 6.5 mm (0.26 in) and M8 threads on both sides with countersinks.

The following figure shows the design of the through bore and the minimum clearance in mm (in):



36028797483065611

- [1] Unit  
 [2] Cooling fins  
 Z Height of the through bore + T-slot (see the dimension drawing in the "Technical data" (→ 113) chapter)

### Fastening the unit from the front


## INFORMATION



It is not possible to mount the unit in this way when using the handles.

### Required material

- In order to comply with the required minimum distances and clearances, use one of the following mounting elements:
  - Suitable spacers
  - Mounting plate (with an appropriate cut-out for long cooling fins)
- Suitable mounting and locking elements, e.g. M6 screws of an appropriate length with washers
- Suitable locking devices, e.g. lock washers



45035996748517515

- [1] Mounting elements, e.g. M6 screws
- [2] Locking elements, e.g. lock washers
- [3] Mounting elements, e.g. washers
- [4] Mounting surface, e.g. mounting plate
- X, Y Housing dimensions
- X<sub>2</sub>, Y<sub>2</sub> Bore dimensions

### Procedure

1. Refer to the dimension drawing in the "Technical data" chapter for the housing dimensions X and Y.
2. Refer to the following table for dimensions of the bores:

Bore dimension	Value
X <sub>2</sub>	Housing dimension X – 30 mm
Y <sub>2</sub>	Housing dimension Y – 30 mm


3. Mark the tapped holes on the mounting surface [4].
4. Drill the bores at the marked points.
5. Firmly screw the unit on the mounting surface [4] from the front via the through bores. Use suitable mounting and locking elements, e.g.:
  - M6 screws [1]
  - lock washers [2] and
  - washers [3].

### Fastening the unit from the back

#### Required material

- In order to comply with the required minimum distances and clearances, use one of the following mounting elements:
  - Suitable spacers
  - Mounting plate (with an appropriate cut-out for long cooling fins)

- Suitable mounting and safety elements, e.g. M8 screws of an appropriate length with washers
- Suitable locking devices, e.g. lock washers



18014398973593739

- [1] Mounting elements, e.g. M8 screws
- [2] Locking elements, e.g. lock washers
- [3] Mounting elements, e.g. washers
- [4] Mounting surface, e.g. mounting plate
- X, Y Housing dimensions
- X<sub>2</sub>, Y<sub>2</sub> Bore dimensions

Proceed as follows to mount the unit:

1. Refer to the dimension drawing in the "Technical data" chapter for the housing dimensions X and Y.
2. Refer to the following table for dimensions of the bores:

Bore dimension	Value
X <sub>2</sub>	Housing dimension X – 30 mm
Y <sub>2</sub>	Housing dimension Y – 30 mm

3. Mark the tapped holes on the mounting surface [4].
4. Drill the bores at the marked points.

21356203/EN – 03/2015

5. Firmly screw the unit on the mounting surface [4] from the back via the through bores. Use suitable mounting and locking elements, e.g.:
  - M6 screws [1]
  - Lock washers [2]
  - Washers [3]

## 6 Electrical installation

### 6.1 General information

Observe the following notes on electrical installation:

- Observe the general safety notes.
- Strictly observe all instructions referring to the technical data and the permissible conditions regarding the place of installation.
- The integrated line filter reduces the bleeder resistance to less than 500 kΩ. Therefore do not include the unit in the system test.

### 6.2 Low-voltage supply systems

The unit is suited and allowed for operation in the following systems:

- TN and TT systems with directly grounded star point
- IT systems with non-grounded star point

SEW-EURODRIVE recommends using insulation monitors with pulse-code measurement. The use of such devices prevents the earth-leakage monitor from mis-tripping due to the earth capacitance of the inverter.

No EMC limits are specified for interference emission in IT systems.

### 6.3 Contactors

Only use contactors in utilization category AC-3 (EN 60947-4-1) as line and brake contactors.

### 6.4 Electromagnetic compatibility (EMC)

#### INFORMATION



The unit can cause EMC interference within the permitted limit range according to DIN EN 61800-3.

This unit is a drive system of the category C3 (see DIN EN 61800-3).

For detailed information on EMC-compliant installation, refer to the publication "Drive Engineering – Electromagnetic Compatibility in Drive Engineering."

### 6.5 Cable routing

Observe the following when routing the cables:

- Use suitable cables to connect the power supply and the communication. Refer to chapter "Electrical connections" for descriptions of connections.
- Route power cables and signal lines in separate cable ducts.
- Maintain the greatest possible distance between power cables and signal lines.
- Avoid using long cables running parallel to one another.

For detailed information on EMC-compliant installation, refer to the publication "Drive Engineering – Electromagnetic Compatibility in Drive Engineering".

## **6.6 Using prefabricated cables**

SEW-EURODRIVE uses prefabricated cables for certifications, type tests and approval of the units. The cables provided by SEW-EURODRIVE fulfill all requirements necessary to ensure that the unit and all connected components function properly. The units under consideration are always the basic units including all connected components and corresponding connection cables.

This is why SEW-EURODRIVE recommends to use only the prefabricated cables specified in the documentation.

In accordance with EN ISO 13849, when using units with integrated safety functions, you must also adhere to all of the conditions and requirements for the installation and routing of cables described in the corresponding unit's functional safety documentation.

### **6.6.1 Use of third-party cables**

If third-party cables are used – even if these cables are technically equivalent – SEW-EURODRIVE will not accept any liability and cannot guarantee compliance with unit properties or that the unit will function correctly.

When using third-party cables to connect the unit and/or unit components, make sure to comply with all applicable national regulations. Note that the technical features of the unit or system of units might be affected inadvertently when using non-SEW cables. This concerns in particular the following properties:


- Mechanical properties (such as IP protection class, cable carrier suitability)
- Chemical properties (such as the absence of silicone and halogen, resistance against substances)
- Thermal properties (e.g. temperature stability, heating of the unit, flammability class)
- EMC behavior (such as interference emission limit values, compliance with interference immunity values stipulated in standards)
- Functional safety (approvals according to EN ISO 13849-1)

Non-SEW cables not explicitly recommended by SEW-EURODRIVE must meet at least the requirements of the following standards and have been permitted according to these standards:

- IEC 60309
- IEC 61984
- IEC 60204

## 6.7 Installation topology of SNI

The following figure shows the basic installation topology with SNI interface. The application of MOVIGEAR® SNI is depicted as an example:



18014400585978763

The approved cable length between the SNI controller and the last SNI actuator is 100 m when the mandatory cable is used.

21356203/EN – 03/2015

## 6.8 Installation altitude higher than 1000 m above sea level

Units with a system voltage of phase to ground of 300 V or phase to phase of 500 V can be used at an altitude of more than 1000 m above sea level up to a maximum of 4000 m above sea level under the following conditions:

- The nominal continuous power is reduced due to the reduced cooling above 1000 m; see the chapter "Technical Data".
- For 2000 m AMSL and higher, the air and creepage distances are only sufficient for overvoltage class 2. If the installation calls for overvoltage class 3, you will have to install additional external overvoltage protection to limit overvoltage peaks to 2.5 kV phase-to-phase and phase-to-ground.
- If safe electrical disconnection is required, it must be implemented outside the unit at altitudes of more than 2000 m above sea level (safe electrical disconnection in accordance with EN 61800-5-1 and/or EN 60204-1).
- Overvoltage classes according to EN 60664

## 6.9 Shielding

### Required material

Use shielded power supply and electronics cables.

1. Connect the shield and make sure it is grounded over a wide area at both ends.
2. For cables with multiple shields, also connect the inner shield at both ends making sure it is grounded over a wide area.

### Required documents

For external bus connections, refer to the bus-specific installation instructions.

## 6.10 Unit output




### NOTICE

Damage to the unit if the unit output is subjected to capacitive loads.

Damage to the units

- Only connect ohmic/inductive loads.
- Never connect capacitive loads.

No capacitive loads may be connected to the unit output. A capacitive load occurs, for example, when very long cables are used to connect the motor. For this reason, the motor supply cable must not exceed 30 m (98 ft).



9007199668673675

### 6.11 Motor types


The unit supports the following motor series from SEW-EURODRIVE:

- DRE..
- DRS..
- DRP..
- CM..

## 6.12 Protective measures against electrical hazards

### 6.12.1 Overview

The following figure shows an overview of preventive measures against electrical hazards:



### 6.12.2 PE connection



#### ⚠ WARNING

Electric shock due to incorrect connection of PE or equipotential bonding.

Severe or fatal injuries

- Observe the installation notes.

The stationary units must be grounded.

Observe the following rules when grounding the unit:

- Ground the unit using the shortest possible route.
- Use a green/yellow grounding cable.
- Use the shortest possible low-impedance, RF-compatible cables.

Leakage currents  $\geq$  AC 3.5 mA/DC 10 mA may occur during normal operation. Observe the following to comply with EN 61800-5-1:

- **Supply system lead  $< 10 \text{ mm}^2$  (AWG 7):**  
Route a **second PE conductor with the same cable cross section as the supply system lead** in parallel to the protective earth via separate terminals. Alternatively, use a **copper protective earth conductor with a cross section of  $10 \text{ mm}^2$  (AWG 7)**.
- **Supply system lead  $10 \text{ mm}^2$  to  $16 \text{ mm}^2$  (AWG 7 to AWG 6):**  
Route a **copper protective earth conductor with the cross section of the supply system lead**.

- **Supply system lead 16 mm<sup>2</sup> to 35 mm<sup>2</sup> (AWG 6 to AWG 2):**

Route a **copper protective earth conductor with a cable cross section of 16 mm<sup>2</sup>**.

- **Supply system lead > 35 mm<sup>2</sup> (AWG 2):**

Route a **copper protective earth conductor with half the cross section of the supply system lead**.

### 6.12.3 PE connection for mobile applications

For mobile applications, the type of energy transfer determines how to apply grounding or equipotential bonding.

The following energy transfer types can be used:

- Direct power supply, for example via a conductor rail
- Contactless energy transfer system with MOVITRANS®

#### Direct power supply


Equip all electrical equipment in mobile systems with direct power supply, such as motor, application controller, etc., with a ground connection (PE).

Comply with the following rules:

- Ground the unit with the shortest possible route (PE).
- Use a green/yellow grounding cable.

Ground the unit using 2 mobile contact outlets (sliding contacts) or using a trailing cable.


The following figure shows a sample mobile system with direct power supply via sliding contacts:



18014398844514443

- [1] Stationary system component
- [2] Wheels
- [3] Vehicle support frame
- [4] Power supply
- [5] Motor
- [6] Application controller
- [7] Vehicle GND
- [8] Ground

### 6.12.4 Unit connection points for grounding or equipotential bonding


The connection points for grounding or equipotential bonding are marked on the housing corners of the units with the symbol .

The bores in the housing corners are prepared for M5 self-tapping screws, for example M5 x 12 according to DIN ISO 3506 or equivalent.


Adhere to the following rules when you install the grounding or the equipotential bonding:

- Secure the grounding or equipotential bonding cable using connection elements that breach the surface as shown in the figure below.
- Use the grounding kit included in the delivery.
- Mount the parts as shown in the figure. Observe the maximum tightening torque of 5 Nm (40 in-lb).

The following figure shows the positions of the connection points and the sequence in which to install the individual parts:



27021598023672843

- [1] Screw, self-tapping
- [2] Tooth lock washer
- [3] Crimp cable lug for M5
- [4] Terminal yoke
- [5] Ground symbol 
- [6] Housing corner

### 6.12.5 Residual current device



#### ▲ WARNING

No protection against electric shock if an incorrect type of residual current device is used.

Severe or fatal injuries.

- Use only universal current sensitive residual current devices of type B for 3-phase frequency inverters.

- A 3-phase frequency inverter creates a DC component in the leakage current and may greatly reduce the sensitivity of a type-A residual current device. A type-A residual current device is therefore not permitted as a protection device.

Use only a type-B residual current device.

- If the use of a residual current device is not stipulated in the standards, SEW-EURODRIVE recommends not using a residual current device.

#### 6.12.6 Line fuse types

Install the fuses at the beginning of the power supply cables behind the supply bus junction.

##### Line protection types in operation classes gL, gG:

- Rated fusing voltage  $\geq$  rated line voltage
- Depending on the frequency inverter capacity utilization, the rated fusing current must be dimensioned for 100% of the frequency inverter current.

##### Miniature circuit breaker with characteristics B, C:

- Power circuit breaker nominal voltage  $\geq$  nominal line voltage
- The nominal current of the miniature circuit breaker must be 10% above the frequency inverter current.

#### 6.13 Connection block




##### ⚠ WARNING

Electric shock due to connecting or disconnecting plug connectors when voltage is applied.

Severe or fatal injuries.

- Disconnect all supply voltages.
- Ensure that there is no voltage present in the inverter.
- Never plug or unplug the plug connectors while they are energized.
- **When MOVI-DPS EKK is connected:** Never disconnect the plug connector at the energy management port if you do not know the actual state of charge of the MOVI-DPS storage bundle. Also refer to the operating instructions of the connected MOVI-DPS energy or power interface.



- [1] X4232\_2, Ethernet fieldbus (→ 80)
- [2] X4232\_1, Ethernet fieldbus (→ 80)
- [3] X5611\_2, Digital outputs – safety-related (→ 94)
- [4] X5601\_2, Digital inputs – safety-related (→ 92)
- [5] X5611\_1, Digital outputs – safety-related (→ 93)
- [6] X5601\_1, Digital inputs – safety-related (→ 91)
- [7] X5001\_2: Digital inputs/outputs – communication and control unit (→ 82)
- [8] X5001\_1: Digital inputs/outputs – communication and control unit (→ 81)
- [9] NET LED (→ 17)
- [10] X2371: AC 400 V output (→ 66)
- [11] X1213: AC 400 V input/DC 24 V supply for interface box (up to 15.0 kW – coded) (→ 49)
- [12] X2241: AC 400 V output (SNI) (→ 62)
- [13] X4101: CAN bus – system bus (→ 75)
- [14] X1271: Connection for energy management (→ 54)
- [15] X2303: Braking resistor (→ 60)
- [16] X2016: Motor with brake control (→ 56)
- [17] X5102\_2: Digital inputs – Frequency inverter (→ 86)
- [18] X5502: Safe disconnection – input (→ 89)
- [19] X5102\_1: Digital inputs – Frequency inverter (→ 85)
- [20] X3011: Motor encoder (HIPERFACE, Sin/Cos, TTL, HTL, RS422) (→ 68)
- [21] X3222: Multi distance encoder (HIPERFACE, SSI, Sin/Cos, TTL, HTL, RS422) (→ 72)
- [22] X5111: Fan subassembly (→ 88)

## 6.14 Electrical connections

### 6.14.1 Representation of connections

The wiring diagrams show the contact end of the connections.

### 6.14.2 Designation key

The connection designations are based on the following structure: *Xabbc<sub>mn</sub>*.

The individual positions represent the following information:

<b>X</b>	<b>Terminal</b>
<b>a</b>	<b>Group</b> 1 = Power input 2 = Power output 3 = Encoder 4 = Bus 5 = Inputs and outputs
<b>bb</b>	<b>Function</b> Function of the connection within a group
<b>c</b>	<b>Type</b> Wiring diagram of the connection within a function
–	
<b>m</b>	<b>Group number (optional)</b> Groups connections with the same signal
<b>n</b>	<b>Number (optional)</b> In case of several connections in one group

### 6.14.3 Connection cables

Connection cables are not included in the scope of delivery.

Prefabricated cables for connections between SEW components can be ordered from SEW-EURODRIVE. For each connection, the available prefabricated cables are listed. Specify the part number and the required length of cable in your order.

The required quantity and design of the connection cables depend on the unit design and the components to be connected. This is why you do not need all listed cables.

#### Cable designs:

The table below shows the various illustrations and what they mean:





<b>Illustration</b>	<b>Meaning</b>
	Fixed length
	Variable length

Illustration	Meaning
	Suitable for cable carriers
	Not suitable for cable carriers

## INFORMATION



For more detailed information on cable types, refer to the "Technical data" chapter.

### 6.14.4 Cable structure

#### Diagram

The cable design is specified as follows. The example is a cable with a (4X2X0.25) design:


(	Cable shield
4	Number of core pairs (in twisted cables only)
X	
2	Number of cores
X	G - with green-yellow PE conductor X - without PE conductor
0.25	Core cross section in mm <sup>2</sup>
)	Cable shield
+	A plus sign is added to additional cores with other features.
...	

#### Examples

The following examples illustrate the scheme which specifies the cable design:





- **3G1.5:**  
Cable with 3 cores of 1.5 mm<sup>2</sup> each, one green-yellow cable
- **((2X2X0.25)+4G2.5):**  
Shielded hybrid cable with
  - 4 twisted-pair cables of 0.25 mm<sup>2</sup> each, shielded, and
  - 4 power cores of 2.5 mm<sup>2</sup> each, one green-yellow cable.


#### 6.14.5 X1213: AC 400 V input/DC 24 V supply for interface box (up to 15.0 kW – coded)

Function		
<ul style="list-style-type: none"> <li>AC 400 V unit supply input</li> <li>DC 24 V input and output</li> <li>With signal contact for external maintenance switch</li> <li>For connecting an interface box (PZM)</li> </ul>		
Connection type		
Han-Modular® 10 B, male, 1 single lever		
Wiring diagram		
		
9007201697235339		
Assignment		
No.	Name	Function
[a] Han® C module, male		
1	L1	Line connection phase 1
2	L2	Line connection phase 2
3	L3	Line connection phase 3
[b] Han® EE module, male		
Coding of the unit power, see section "coding" (→ 50)		
[c] Han® EE module, male		
1	+24V_C	DC 24 V input – backup voltage
2	SC	Signal contact for external maintenance switch
3	VO24	DC 24 V output
4	n.c.	Not assigned
5	0V24_C	0V24 reference potential – backup voltage
6	n.c.	Not assigned
7	GND	Reference potential
8	n.c.	Not assigned
Hinged frame		
–	PE	PE connection

### Coding


The following table shows the assignment of the different coding to the respective unit power ratings and the corresponding power interfaces:

Unit power	Coding of the connections	Interface box
2.2 kW		PZM2xA-A075-D02-00 PZM2xA-A150-D03-00 PZM2xA-A022-M13-00
4.0 kW		PZM2xA-A075-D02-00 PZM2xA-A150-D03-00 PZM2xA-A040-M14-00
7.5 kW		PZM2xA-A075-D02-00 PZM2xA-A150-D03-00 PZM2xA-A075-M16-00
11.0 kW		PZM2xA-A150-D03-00

Unit power	Coding of the connections	Interface box
15.0 kW		PZM2xA-A150-D03-00

Interface box connections

The following table shows the connections of the interface box:




18014400464385931

- [1] Connection to unit (Han® 10 B, female)
- [2] Terminal strip, power input
- [3] Covers of the screw fitting holes (M32 × 1.5)<sup>1)</sup>
- [4] Covers of the screw fitting holes (M25 × 1.5)<sup>1)</sup>

1) The screw fittings are not included in the scope of delivery.

### X1 terminal strip of the interface box

The following figure shows the terminal strip of the interface box:



Terminal strip X1 (power input terminal strip)			Terminal cross section
	Name	Function	
[1]	VO24	DC 24 V output	6 mm <sup>2</sup>
[2]	GND	Reference potential / DC 24 V output	
[3]	+24V_C	DC 24 V input	
[4]	0V24_C	0V24 reference potential – input	
[5]	HT1	Auxiliary terminal for additional voltage levels (without internal function)	
[6]	HT2	Auxiliary terminal for additional voltage levels (without internal function)	
[7]	L1	Phase L1	10 mm <sup>2</sup>
[8]	L2	Phase L2	
[9]	L3	Phase L3	
[10]	PE	Equipotential bonding/protective earth conductor	


### DC 24 V supply

The unit is equipped with a DC 24 V output that can be used to supply the unit from the DC link.

To use the 24 V supply from the DC link, you must jumper the following terminals:

- 1 with 3
- 2 with 4

The following figure illustrates the wiring for using the 24 V supply from the DC link:




18014400675416459

To use an external DC 24 V backup voltage, connect it to the following terminals:

- 3
- 4


In this case, terminals **1 and 2 must not be used!**

The following figure illustrates the wiring for using an external 24 V supply:







18014400675412875

## 6.14.6 X1271: Connection for energy management

Function		
AC 400 V and DC link connection for jumpering the line phases or for connecting energy management components		
Connection type		
Han-Modular® 10 B, female-male-female, 1 single locking latch		
Wiring diagram		
		
13557105803		
Assignment		
No.	Name	Function
[a] Han® C protected module, female		
1	n.c.	Not assigned
2	+Uz	DC link (+)
3	n.c.	Not assigned
4	-Uz	DC link (-)
[b] Han® C module, male		
1	L1_In	Line connection phase 1 – Input
2	L2_In	Line connection phase 2 – Input
3	L3_In	Line connection phase 3 – Input
[c] Han® C module, female		
1	L1_Out	Line connection phase 1 – Output
2	L2_Out	Line connection phase 2 – Output
3	L3_Out	Line connection phase 3 – Output
Hinged frame		
PE	PE	PE connection

Connection cables

Cable	Length/installation type	Component
<p><b>Part number: 18166873</b></p> <p>Cable design: (3G6)</p>  <p>Han® 10B, male-female-male ↔ Han® Q4/2, female</p>	<p>Variable length, max. 5 m</p> 	MOVI-DPS EKK.../E12
<p><b>Part number: 18166865</b></p> <p>Cable design: (7G6)</p>  <p>Han® 10B, male-female-male ↔ Han® 6B, female-fe-male</p>	<p>Variable length, max. 5 m</p> 	MOVI-DPS EKK.../E11


Connection components

Jumper plug energy management

Part number 18166903

Structure	
Modules	Jumpered pins
[B] – [C]	1 – 1
	2 – 2
	3 – 3

Connection: Han® 10 B, male-female-male



14494361355

21356203/EN – 03/2015

## 6.14.7 X2016: Motor with brake control

**NOTICE**

Damage or malfunction due to motors with built-in brake rectifiers.

Damage to the external brake rectifier, malfunction of the motor brake, malfunction of the unit, damage to internal components of the unit.


- Do not use motors with built-in brake rectifiers in conjunction with this unit.

**Function**

Power connection for motor with brake up to 15 kW

**Connection type**

Han-Modular® 10 B, female, 1 single lever

**Wiring diagram**










9007201697232779

**Assignment**




No.	Name	Function
<b>[A] Han® C module, female</b>		
1	U	Motor phase U output
2	V	Motor phase V output
3	W	Motor phase W output
<b>[C] Han® E protected module, female</b>		
1	TF/TH/KTY+	Motor temperature sensor (+)
2	15	SEW brake terminal 15 (blue)
3	13	SEW brake terminal 13 (red)
4	14	SEW brake terminal 14 (white)
5	n.c.	Not assigned
6	TF/TH/KTY-	Motor temperature sensor (–)
<b>Hinged frame</b>		
PE	PE	PE connection

## Connection cables

11,0 kW (IEC)




Cable	Length/installation type	Type	Component
<b>Part number: 18120644</b>  Han® 10 B ↔ Open (terminal box connection M5)	Variable length 	D/4.0	DR112 – 132 
<b>Part number: 18120741</b>  Han® 10 B ↔ Open (terminal box connection M6)	Variable length 	D/4.0	DR160 
<b>Part number: 18120652</b>  Han® 10 B ↔ ABB8	Variable length 	D/4.0	DR112 – 160 

11,0 kW (IEC/UL) to 15,0 kW (IEC)




Cable	Length/installation type	Type	Component
<b>Part number: 18110444</b>  Han® 10 B ↔ ABE8	Variable length 	D/6.0	DR112 – 160 

# 6 Electrical installation



## Electrical connections

Cable	Length/installation type	Type	Component
<b>Part number: 18110312</b>  Han® 10 B ↔ ABC8	Variable length 	D/6.0	DR112 – 160 

11.0 kW to 15.0 kW



Cable	Length/installation type	Type	Component
<b>Part number: 18110614</b>  Han® 10 B ↔ SBC50	Variable length 	E/6.0	CM 

Phase reversal cable


Cable	Length/installation type	Type
<b>Part number: 18145299</b> For units from 11,0 kW (IEC/UL) to 15,0 kW (IEC)  Han® 10 B ↔ ABE8	Variable length 	D/6.0

21356203/EN – 03/2015







Adapter cable

Cable	Length/installation type	Type
<p><b>Part number: 18119964</b> MOVIPRO® size 2 to size 1</p>  <p>Han® 10 B ↔ Han® 6 B</p>	<p>Variable length</p> 	<p>D/2.5</p>

### 6.14.8 X2303: Braking resistor

Function		
Power connection for external braking resistor		
Connection type		
Han® Q 2/0, female, I-coded		
Wiring diagram		
<div>  </div>		
9007201697330955		
Assignment		
No.	Name	Function
1	+R	Braking resistor (+)
2	-R	Braking resistor (-)
3	PE	PE connection

### Connection cables

Cable	Length/installation type	Component
<b>Part number: 18121969</b> Cable design: (3G2.5) Core cross section: 2.5 mm  Han®Q 2/0 ↔ Open with conductor end sleeves	Variable length 	External braking resistor  Terminal cross section: 6 mm <sup>2</sup>
<b>Part number: 18121977</b> Cable design: (3G6.0) Core cross section: 6 mm <sup>2</sup>  Han®Q 2/0 ↔ Open with conductor end sleeves	Variable length 	External braking resistor  Terminal cross section: 6 mm <sup>2</sup>


21356203/EN – 03/2015

*Conductor assignment*

Part number	Signal name	Color coding
18121969	+R	Black/1
18121977	-R	Black/2
	PE connection	Green/yellow

## 6.14.9 X2241: AC 400 V output (SNI)









The following table shows information about this connection:

Function		
AC 400 V output for unit supply with Single Line Network Installation (SNI)		
Connection type		
M23 H-Tec, SEW P-insert 11-pole, female, coding ring red		
Wiring diagram		
 <p style="text-align: right;">9007207371130251</p>		
Assignment		
No.	Name	Function
A	L1_SNI	Actuator supply phase 1 with SNI communication
B	L2_SNI	Actuator supply phase 2 with SNI communication
C	L3_SNI	Actuator supply phase 3 with SNI communication
D	n.c.	Not assigned
PE	PE	PE connection
1	n.c.	Not assigned
2	n.c.	Not assigned
3	n.c.	Not assigned
4	n.c.	Not assigned
5	n.c.	Not assigned
6	n.c.	Not assigned









### Connection cables

The following tables list the cables available for this connection:

Cable cross section 2.5 mm<sup>2</sup>

Connection cables	Conformity / part number	Cable type, see also technical data	Length/ installation type	Cable cross section / operating voltage
 M23, coding ring: red M23, coding ring: red	CE: 18127509	HELUKA-BEL® TOP-FLEX® – EMV-UV-2YSL-CYK-J	Variable 	2.5 mm <sup>2</sup> / AC 500 V
	UL: 18150381	HELUKA-BEL® TOP-FLEX® – EMV-UV-2YSL-CYK-J-UL/CSA	Variable 	
	CE/UL: 18120679	HELUKA-BEL® TOP-SERV® – 109	Variable 	
 Open M23, coding ring: red	CE: 18127517	HELUKA-BEL® TOP-FLEX® – EMV-UV-2YSL-CYK-J	Variable 	2.5 mm <sup>2</sup> / AC 500 V
	UL: 18150403	HELUKA-BEL® TOP-FLEX® – EMV-UV-2YSL-CYK-J-UL/CSA	Variable 	
	CE/UL: 18120687	HELUKA-BEL® TOP-SERV® – 109	Variable 	

Cable cross section 4 mm<sup>2</sup>

Connection cables	Conformity / part number	Cable type, see also technical data	Length/ installation type	Cable cross section / operating voltage
 M23, coding ring: red M23, coding ring: red	CE: 18127525	HELUKA-BEL® TOP-FLEX® – EMV-UV-2YSL-CYK-J	Variable 	4 mm <sup>2</sup> / AC 500 V
	UL: 18150411	HELUKA-BEL® TOP-FLEX® – EMV-UV-2YSL-CYK-J-UL/CSA	Variable 	
	CE/UL: 18120695	HELUKA-BEL® TOP-SERV® – 109	Variable 	
 Open M23, coding ring: red	CE: 18127533	HELUKA-BEL® TOP-FLEX® – EMV-UV-2YSL-CYK-J	Variable 	4 mm <sup>2</sup> / AC 500 V
	UL: 18153259	HELUKA-BEL® TOP-FLEX® – EMV-UV-2YSL-CYK-J-UL/CSA	Variable 	
	CE/UL: 18120709	HELUKA-BEL® TOP-SERV® – 109	Variable 	

### Connection of cables with open end

The following tables show the conductor assignment of cables with the following part numbers:

Part number	Signal name	Color coding
18127517	L1_SNI	Brown
18150403	L2_SNI	Black
18127533	L3_SNI	Gray
18153259	PE	Green/yellow

21356203/EN – 03/2015



Part number	Signal name	Core color/designation
18120687	L1_SNI	Black / 1
18120709	L2_SNI	Black / 2
	L3_SNI	Black / 3
	PE	Green/yellow

## 6.14.10 X2371: AC 400 V output



Function		
AC 400 V output to supply external devices		
Connection type		
Han® Q 4/2, female		
Wiring diagram		
18014400953610763		
Assignment		
No.	Name	Function
1	L1	Line connection phase 1
2	L2	Line connection phase 2
3	L3	Line connection phase 3
4	n.c.	Not assigned
11	n.c.	Not assigned
12	n.c.	Not assigned
PE	PE	PE connection

### Connection cables

The following table shows the cables available for this connection:

Cable	Length/installation type	Component
<b>Part number: 18150187</b> Cable design: (4G2.5)  Han® Q 4/2 ↔ Open with conductor end sleeves	Variable length 	—


21356203/EN – 03/2015

Cable	Length/installation type	Component
<p><b>Part number: 18150306</b></p> <p>Cable design: (4G2.5)</p>  <p>Han® Q 4/2 ↔ Han® Q 4/2 male</p>	<p>Variable length</p> 	-



Conductor assignment

Part number	Signal name	Color coding
18150187	L1	Black / U
	L2	Black / V
	L3	Black / W
	PE	Green/yellow









## 6.14.11 X3011: Motor encoder









Function		
Connection for HIPERFACE®, sin/cos, TTL, HTL and RS422 encoders		
Connection type		
M23, P insert 12-pole, female, +20°-coded		
Wiring diagram		
		
2459939339		
Assignment		
No.	Name	Function
1	C	Signal track C (K0)
2	/C	Negated signal track C (/K0)
3	A	Signal track A (K1)
4	/A	Negated signal track A (/K1)
5	B	Signal track B (K2)
6	/B	Negated signal track B (/K2)
7	Data-	Data line (-)
8	Data+	Data line (+)
9	TF/TH/KTY+	Motor temperature sensor (+)
10	TF/TH/KTY-	Motor temperature sensor (-)
11	GND	Reference potential
12	+12V	DC 12 V output

### Connection cables

Cables	Length/ installation type	Component
<b>Part number: 18121454 (with temperature sensor)</b> Cable design: (6X2X0.25)  M23, 12-pole, 20°-coded ↔ M23, 12-pole, 0°-coded	Variable length 	<ul style="list-style-type: none"> <li>AK0H</li> <li>AK1H</li> <li>AS1H</li> <li>EK0H</li> <li>EK1H</li> <li>ES1H</li> </ul>

21356203/EN – 03/2015

Cables	Length/ installation type	Component
<b>Part number: 18121926 (without temperature sensor)</b> Cable design: (6X2X0.25)  M23, 12-pole, 20°-coded ↔ M23, 12-pole, 0°-coded	Variable length 	<ul style="list-style-type: none"> <li>• AS3H</li> <li>• AS4H</li> <li>• AV1H</li> <li>• AV6H</li> </ul>
<b>Part number: 18121438 (without temperature sensor)</b> Cable design: (6X2X0.25)  M23, 12-pole, 20°-coded ↔ open with conductor end sleeves	Variable length 	<ul style="list-style-type: none"> <li>• A.7W</li> <li>• AG7Y</li> <li>• AS7Y</li> <li>• E.7C</li> <li>• E.7R</li> <li>• E.7S</li> <li>• EH1.</li> <li>• EI7.</li> <li>• EV1.</li> <li>• ES1.</li> <li>• ES2.</li> </ul>
<b>Part number: 18121446 (with temperature sensor)</b> Cable design: (6X2X0.25)  M23, 12-pole, 20°-coded ↔ open with conductor end sleeves	Variable length 	<ul style="list-style-type: none"> <li>• AK1H</li> <li>• EK1H</li> <li>• ES1H</li> <li>• AS1H</li> </ul>
<b>Part number: 18110991 (without temperature sensor)</b> Cable design: (6X2X0.25)  M23, 12-pole, 20°-coded ↔ encoder cover	Variable length 	<ul style="list-style-type: none"> <li>• A.7W</li> <li>• E.7C</li> <li>• E.7R</li> <li>• E.7S</li> </ul>

Cables	Length/ installation type	Component
<b>Part number: 18121950 (without temperature sensor)</b> Cable design: (4X2X0.25)  M23, 12-pole, 20°-coded ↔ M12, 8-pole	Variable length 	<ul style="list-style-type: none"> <li>• EI7.</li> </ul>
<b>Part number: 11717238</b> Cable design: (6X2X0.25)  M23, 12-pole, 20°-coded ↔ M23, 12-pole, 0°-coded	Variable length 	<ul style="list-style-type: none"> <li>• AV1H</li> <li>• AS3H</li> <li>• AS4H</li> </ul>
<b>Part number: 18109594</b> Cable design: (6X2X0.25)  M23, 12-pole, 20°-coded ↔ open with conductor end sleeves	Variable length 	<ul style="list-style-type: none"> <li>• ES1S</li> <li>• ES2S</li> <li>• EV1S</li> </ul>
<b>Part number: 18114806 (Not suitable for HIPERFACE® encoders)</b> Cable design: (6X2X0.25)  M23, 12-pole, 20°-coded ↔ M23, 12-pole, 20°-coded	Variable length 	<ul style="list-style-type: none"> <li>• E..T</li> <li>• E..C</li> <li>• E..S</li> <li>• E..R</li> </ul>

#### Conductor assignment of special cables


The following table shows the conductor assignment of cables with the following part numbers:

1 810 959 4





Signal name	Color coding
C	Brown
/C	White

Signal name	Color coding
A	Red
/A	Blue
B	Yellow
/ B	Green
GND	Gray/Pink + Gray
+12V	Red/Blue + Pink

### 6.14.12 X3222: Multi-distance encoder (HIPERFACE®, SSI, Sin/Cos, TTL, HTL, RS422)

Function		
Connection for HIPERFACE®, SSI, sin/cos, TTL, HTL and RS422 encoders		
Connection type		
M23, P insert 12-pole, female, +20°-coded		
Wiring diagram		
 <p style="text-align: right;">2459939339</p>		
Assignment		
No.	Name	Function
1	CLK (C)	Clock line (Signal track C (K0))
2	/CLK (/C)	Negated clock line (Negated signal track C (/K0))
3	A	Signal track A (K1)
4	/A	Negated signal track A (/K1)
5	B	Signal track B (K2)
6	/B	Negated signal track B (/K2)
7	Data-	Data line (-)
8	Data+	Data line (+)
9	GND	Reference potential
10	+24V	DC 24 V output Total current load of DC 24 V encoder supply ≤ 400 mA
11	GND	Reference potential
12	+12V	DC 12 V output Total current load of DC 12 V encoder supply ≤ 650 mA

### Connection cables


Cable	Length/ installation type	Component
<b>Part number: 18121934</b> Cable design: (6X2X0.25)  M23, 12-pole, 20°-coded ↔ Open with conductor end sleeves	Variable length 	HIPERFACE® / SSI en- coder (12 V)
<b>Part number: 18121942</b> Cable design: (6X2X0.25)  M23, 12-pole, 20°-coded ↔ Open with conductor end sleeves	Variable length 	HIPERFACE® / SSI en- coder (24 V)

### Conductor assignment

Part number	Signal name	Color coding
• 18121934	CLK	Brown
	/CLK	White
	A	Red
	/A	Blue
	B	Yellow
	/ B	Green
	Data-	Purple
	Data+	Black
	GND	Gray/Pink + Pink
	+12V	Red/Blue + Gray

Part number	Signal name	Color coding
• 18121942	CLK	Brown
	/CLK	White
	A	Red
	/A	Blue
	B	Yellow
	/ B	Green
	Data-	Purple
	Data+	Black
	GND	Gray/Pink + Pink
	+24V	Red/Blue + Gray

### 6.14.13 X4101: CAN bus – system bus





Function		
Internal CAN bus (system bus) – output		
Connection type		
M12, 5-pole, female, A-coded		
Wiring diagram		
 <p>18014400774298251</p>		
Assignment		
No.	Name	Function
1	CAN_SHLD	Shield/equipotential bonding
2	+24V	DC 24 V output
3	GND	Reference potential
4	CAN_H	CAN data line (high)
5	CAN_L	CAN data line (low)



## INFORMATION

If there is no node connected here, you must terminate the CAN bus with a 120  $\Omega$  resistor.

## Connection cables

Cable	Length/installation type	Component
<p><b>Standard lengths:</b></p> <p>1 m: Part number 13237748</p> <p>2 m: Part number 13237756</p> <p>3 m: Part number 13286315</p> <p>4 m: Part number 13286323</p> <p>5 m: Part number 13286331</p> <p>10 m: Part number 13286358</p> <p>15 m: Part number 13286366</p> <p><b>Custom lengths:</b></p> <p>1.5 m: Part number 13286293</p> <p>2.5 m: Part number 13286307</p> <p>Cable design: ((1X2X0.2)+(1X2X0.32)+1X0.32)</p>  <p>M12, male, A-coded ↔ M12, female, A-coded</p>	<p>Fixed length</p> 	—
<p><b>Standard lengths:</b></p> <p>2 m: Part number 13281364</p> <p>5 m: Part number 13281402</p> <p><b>Custom lengths:</b></p> <p>1 m: Part number 13281348</p> <p>1.5 m: Part number 13281356</p> <p>2.5 m: Part number 13281372</p> <p>3 m: Part number 13281380</p> <p>4 m: Part number 13281399</p> <p>10 m: Part number: 13281410</p> <p>15 m: Part number: 13281429</p> <p>Cable design: ((1X2X0.2)+(1X2X0.32)+1X0.32)</p>  <p>M12, male, A-coded ↔ open</p>	<p>Fixed length</p> 	—

### Conductor assignment


Part number	Signal name	Color coding
13281348	CAN_SHLD	-
13281356	+24V	Red
13281364	GND	Black
13281372	CAN_H	White
13281380	CAN_L	Blue
13281399		
13281402		
13281410		
13281429		

### Connection components

#### CAN T-piece

Part number: 13290967

Connection: M12




5656744075

#### CAN terminating resistor

Part number: 13287036

Connection: M12




63050395932099851

*PZO00A-SAZIR0-C000-02 display unit*


Part number: 28214072

Connection: M12




13362062603

#### 6.14.14 X4223: Ethernet service interface

Function		
Ethernet service interface of the communication and control unit		
Connection type		
Ethernet-RJ45		
Wiring diagram		
 <p style="text-align: right;">9007201609174667</p>		
Assignment		
No.	Name	Function
1	TX+	Transmit line (+)
2	TX-	Transmit line (-)
3	RX+	Receive line (+)
4	res.	Reserved
5	res.	Reserved
6	RX-	Receive line (-)
7	res.	Reserved
8	res.	Reserved

### 6.14.15 X4232: Ethernet fieldbus

The following table shows information about this connection:

Function		
Ethernet fieldbus interface		
Connection type		
Push-pull RJ45		
Wiring diagram		
<div>  </div> <p>9007201609174667</p>		
Assignment		
No.	Name	Function
1	TX+	Transmit line (+)
2	TX-	Transmit line (-)
3	RX+	Receive line (+)
4	res.	Reserved
5	res.	Reserved
6	RX-	Receive line (-)
7	res.	Reserved
8	res.	Reserved




NOTICE


RJ45 patch cable without push-pull connector housing not snapped into place.  
Damage to the push-pull RJ45 connection.

- Only use push-pull RJ45 mating connectors in accordance with IEC PAS 61076-3-117.

**6.14.16 X5001\_1: Digital inputs/outputs – communication and control unit**





Function		
Digital inputs/outputs of the communication and control unit		
Connection type		
M23, P insert 12-pole, female, 0°-coded		
Wiring diagram		
 <p style="text-align: right;">9007201519561099</p>		
Assignment		
No.	Name	Function
1	DI00 / DO00	Digital input DI00 or digital output DO00
2	DI01 / DO01	Digital input DI01 or digital output DO01
3	DI02 / DO02	Digital input DI02 or digital output DO02
4	DI03 / DO03	Digital input DI03 or digital output DO03
5	DI04	Digital input DI04
6	DI05	Digital input DI05
7	DI06	Digital input DI06
8	DI07	Digital input DI07
9	0V24	0V24 reference potential
10	0V24	0V24 reference potential
11	+24V	DC 24 V output
12	FE	Equipotential bonding / functional earth

### 6.14.17 X5001\_2: Digital inputs – communication and control unit

Function		
Digital inputs of the communication and control unit		
Connection type		
M23, P insert 12-pole, female, 0°-coded		
Wiring diagram		
		
Assignment		
No.	Name	Function
1	DI08	Digital input DI08
2	DI09	Digital input DI09
3	DI10	Digital input DI10
4	DI11	Digital input DI11
5	DI12	Digital input DI12
6	DI13	Digital input DI13
7	DI14	Digital input DI14
8	DI15	Digital input DI15
9	0V24	0V24 reference potential
10	0V24	0V24 reference potential
11	+24V	DC 24 V output
12	FE	Equipotential bonding / functional earth



#### Connection cables

The following table shows the cables available for the connection X5001\_1 and X5001\_2:

Cable	Length/ installation type
<p>Length: 1 m, part number: 13309269</p> <p>Length: 2 m, part number: 13309277</p> <p>Length: 3 m, part number: 13309285</p> <p>Length: 5 m, part number: 13309293</p> <p>Length: 10 m, part number: 13309307</p> <p>Cable design: (3X0.75+8X0.34)</p>  <p>M23, 12-pole, male, 0°-coded ↔ sensor/actuator box with 8 slots M12</p>	<p>Fixed length</p> 
<p>Part number: 11741457</p> <p>Cable design: (6X2X0.25)</p>  <p>M23, 12-pole, 0°-coded ↔ open with conductor end sleeves</p>	<p>Variable length</p> 

#### Extension cable

The following extension cable is available for the sensor/actuator box:

Cable	Length/installation type
<p>Part number: 18123465</p> <p>Cable design: (6X2X0.25)</p>  <p>M23, 12-pole, male, 0°-coded (1:1 assignment) ↔ M23, 12-pole, female, 0°-coded</p>	<p>Variable length</p> 

#### Conductor assignment

The following table shows the conductor assignment of the cable with part number 11741457

##### Conductor assignment X5001\_1

Signal name	Color coding
DI00	Pink
DI01	Gray


Signal name	Color coding
DI02	Red
DI03	Blue
DI04	Yellow
DI05	Green
DI06	Violet
DI07	Black
0V24	Brown
0V24	White
+24V	Gray pink
FE	Red blue

**Conductor assignment X5001\_2**

Signal name	Color coding
DI08	Pink
DI09	Gray
DI10	Red
DI11	Blue
DI12	Yellow
DI13	Green
DI14	Violet
DI15	Black
0V24	Brown
0V24	White
+24V	Gray pink
FE	Red blue


#### 6.14.18 X5102\_1: Digital inputs – Frequency inverter

The following table shows information about this connection:

Function		
Digital inputs/outputs – frequency inverter		
Connection type		
M12, 5-pole, female, A-coded		
Wiring diagram		
 <p>18014400774298251</p>		
Assignment		
No.	Name	Function
1	+24V	DC 24 V output
2	DI03	Digital input DI03
3	0V24	0V24 reference potential
4	DI02	Digital input DI02
5	FE	Equipotential bonding/functional earth

### 6.14.19 X5102\_2: Digital inputs – Frequency inverter

The following table shows information about this connection:


Function		
Digital inputs/outputs – frequency inverter		
Connection type		
M12, 5-pole, female, A-coded		
Wiring diagram		
 <p>18014400774298251</p>		
Assignment		
No.	Name	Function
1	+24V	DC 24 V output
2	DI05	Digital input DI05
3	0V24	0V24 reference potential
4	DI04	Digital input DI04
5	FE	Equipotential bonding/functional earth

#### Y adapter

For connecting 2 sensors/actuators to an M12 plug connector, use a Y adapter with extension.

The Y adapter is available from different manufacturers:


- **Manufacturer:** Escha  
**Type:** WAS4-0,3-2FKM3/..



915294347


21356203/EN – 03/2015

- **Manufacturer:** Binder  
**Type:** 79 5200..




1180380683

- **Manufacturer:** Phoenix Contact  
**Type:** SAC-3P-Y-2XFS SCO/.../...  
The cable sheath is made of PVC. Provide suitable UV protection.




1180375179

- **Manufacturer:** Murr  
**Type:** 7000-40721-..



1180386571

### 6.14.20 X5111: Fan subassembly

Function		
Temperature-controlled DC 24 V output for additional external fan		
Connection type		
M12, 5-pole, female, A-coded		
Wiring diagram		
<div>  </div>		
18014400774298251		
Assignment		
No.	Name	Function
1	res.	Reserved
2	res.	Reserved
3	0V24	0V24 reference potential
4	+24V_FAN	DC 24 V output – fan (switching signal)
5	res.	Reserved


### Connection component

The following components are suitable for this connection:

#### Fan subassembly

Part number: 12709700

Connection: M12



2610269323

21356203/EN – 03/2015

#### 6.14.21 X5502: Safe disconnection – input




### ⚠ WARNING

Risk of injury due to non safety-related disconnection of the unit if the connection is jumpered.

Severe or fatal injuries.

- Jumper this connection only if the unit will not perform any safety functions according to EN ISO 13849-1.

This connection is identified with a yellow ring.

Function		
Input for safe disconnection		
Connection type		
M12, 5-pole, female, A-coded		
Wiring diagram		
		
18014400774298251		
Assignment		
No.	Name	Function
1	+24V	DC 24 V output
2	STO-	0V24 reference potential for safe disconnection
3	0V24	0V24 reference potential
4	STO+	DC 24 V input for safe disconnection
5	res.	Reserved

### INFORMATION




Use only shielded cables for this connection.

**Jumper plug**

Part number 11747099

Structure: bridged 1+4 / 2+3


Connection: M12



63050395932099851

#### 6.14.22 X5601\_1: Digital inputs – safety-related

The following table shows information about this connection:

Function		
Safety-related inputs		
Connection type		
M12, 5-pole, female, A-coded		
Wiring diagram		
 <p>18014400774298251</p>		
Assignment		
No.	Name	Function
1	F-SS0	DC 24 V sensor supply for safe inputs
2	F-DI01	Safety-related digital input F-DI01
3	GND	Reference potential
4	F-DI00	Safety-related digital input F-DI00
5	F-SS1	DC 24 V sensor supply for safe inputs

#### Connection cables



### INFORMATION


Use only shielded cables for this connection.

Note that

- You only connect sensors with contacts to the safe F-DI inputs in accordance with the fail-safe principle (e.g. emergency switching off buttons, door contact switches etc.)
- Both sensor supplies F-SS0 and F-SS1 are always clocked.
- F-SS0 is connected via the respective sensor with F-DI00 and F-DI02 (fixed assignment).
- F-SS1 is connected via the respective sensor with F-DI01 and F-DI02 (fixed assignment)
- unused inputs do not have to be connected. An open input is always read as a "0" signal.

### 6.14.23 X5601\_2: Digital inputs – safety-related

The following table shows information about this connection:

Function		
Safety-related inputs		
Connection type		
M12, 5-pole, female, A-coded		
Wiring diagram		
 <p style="text-align: right;">18014400774298251</p>		
Assignment		
No.	Name	Function
1	F-SS0	DC 24 V sensor supply for safe inputs
2	F-DI03	Safety-related digital input F-DI03
3	GND	Reference potential
4	F-DI02	Safety-related digital input F-DI02
5	F-SS1	DC 24 V sensor supply for safe inputs

#### Connection cables



### INFORMATION


Use only shielded cables for this connection.

Note that

- You only connect sensors with contacts to the safe F-DI inputs in accordance with the fail-safe principle (e.g. emergency switching off buttons, door contact switches etc.)
- Both sensor supplies F-SS0 and F-SS1 are always clocked.
- F-SS0 is connected via the respective sensor with F-DI00 and F-DI02 (fixed assignment).
- F-SS1 is connected via the respective sensor with F-DI01 and F-DI02 (fixed assignment)
- unused inputs do not have to be connected. An open input is always read as a "0" signal.


#### 6.14.24 X5601\_1: Digital outputs – safety-related

The following table shows information about this connection:

Function		
Safety-related outputs		
Connection type		
M12, 5-pole, female, A-coded		
Wiring diagram		
 <p>18014400774298251</p>		
Assignment		
No.	Name	Function
1	res.	Reserved
2	F-DO00_M	Safety-related digital output F-DO00 (sinking signal)
3	GND	Reference potential
4	F-DO00_P	Safety-related digital output F-DO00 (sourcing signal)
5	res.	Reserved

## 6.14.25 X5611\_2: Digital outputs – safety-related

The following table shows information about this connection:

Function		
Safety-related outputs		
Connection type		
M12, 5-pole, female, A-coded		
Wiring diagram		
 <p>18014400774298251</p>		
Assignment		
No.	Name	Function
1	res.	Reserved
2	F-DO01_M	Safety-related digital output F-DO01 (sinking signal)
3	GND	Reference potential
4	F-DO01_P	Safety-related digital output F-DO01 (sourcing signal)
5	res.	Reserved

## 7 Startup

### 7.1 General information

#### INFORMATION



Observe the general safety notes in chapter "Safety Notes / General information".



#### ▲ WARNING

Risk of injury due to uncontrolled unit behavior caused by ineffective emergency stop circuit

Severe or fatal injuries

- The installation may only be carried out by trained specialists.



#### ▲ WARNING

Risk of injury due to unit malfunction caused by incorrect unit setting

Severe or fatal injuries

- The installation may only be carried out by trained specialists.
- Check the parameters and data sets.
- Always use the appropriate functional settings.



#### ▲ WARNING

Risk of crushing if the motor starts up unintentionally.

Severe or fatal injuries.

- Observe the startup notes.
- Set the controller inhibit.
- Switch off the output stage.
- De-couple the drive.
- Deactivate auto reset for drives that start up automatically.



#### ▲ WARNING

Electric shock due to missing or defective protection covers.

Severe or fatal injuries.

- Install the protective covers according to the regulations.
- Installation may only be carried out by qualified personnel.
- Never start the unit if the protective covers are not installed.



#### ▲ WARNING

Danger of electric shock due to open connections

Severe or fatal injuries

- The installation may only be carried out by trained specialists.
- Never start the unit if the touch guard is not installed.



### NOTICE

Danger due to arcing

Damage to electrical components

- Do not plug or unplug the power connectors during operation.



### INFORMATION

To ensure fault-free operation, do not disconnect or connect signal lines during operation.

## 7.2 Prerequisites



### ⚠ WARNING

Danger of crushing if the motor starts up unintentionally.

Severe or fatal injuries.

- Observe the startup notes.
- Set the controller inhibit.
- Switch off the output stage.
- De-couple the drive.
- Deactivate auto reset for drives that start up automatically.

#### The following conditions apply to startup:

- The drive controller must be installed correctly both mechanically and electrically.
- The system and connected drives must be configured correctly.
- Appropriate safety measures are taken to prevent the drives from starting up unintentionally.
- Appropriate safety measures must be taken to prevent risk of injury or damage to machines.

#### The following hardware is required for startup:

- PC or laptop with Ethernet interface
- Ethernet cable, prefabricated with an M12 D coded plug connector on the unit side

## 7.3 Lifting applications



### ⚠ WARNING

Danger of fatal injury if the hoist falls

Severe or fatal injuries.

- The unit is not designed for use as a safety device in hoist applications. Use monitoring systems or mechanical protection devices to ensure safety.

## 7.4 SD memory card

Operating the processor unit requires the SD memory card. The SD memory card contains the firmware, the IEC program and user data. The slot for the memory card is located under the memory card cover on the top of the unit.

## 8 Operation



### ⚠ WARNING

Electric shock caused by dangerous voltages at the connections, cables and motor terminals

When the unit is switched on, dangerous voltages are present at the connectors and at any connected cables and motor terminals. This also applies even when the unit is inhibited and the motor is at standstill.

Severe or fatal injuries.

- Do not switch under load.
- Before performing any work on the unit, disconnect it from the power supply. Dangerous voltages may still be present for up to 10 minutes after disconnection from the power supply.
- Inhibit the output stage of the frequency inverter before changing the switch at the unit output.



### ⚠ WARNING

Electric shock due to connecting or disconnecting plug connectors when voltage is applied.

Severe or fatal injuries.

- Disconnect all supply voltages.
- Ensure that there is no voltage present in the inverter.
- Never plug or unplug the plug connectors while they are energized.
- **When MOVI-DPS EKK is connected:** Never disconnect the plug connector at the energy management port if you do not know the actual state of charge of the MOVI-DPS storage bundle. Also refer to the operating instructions of the connected MOVI-DPS energy or power interface.



### ⚠ WARNING

Risk of crushing if the motor starts up unintentionally.

Severe or fatal injuries.

- Observe the startup notes.
- Set the controller inhibit.
- Switch off the output stage.
- De-couple the drive.
- Deactivate auto reset for drives that start up automatically.



### ⚠ WARNING

Electric shock due to charged capacitors

Severe or fatal injuries

- Observe a minimum switch-off time after disconnecting the power supply:  
**10 minutes**



### ▲ CAUTION

Danger of burns due to hot surfaces of the unit or connected options, e.g. braking resistors

Injury

- Secure hot surfaces by covering them.
- Install the protection devices according to the regulations.
- Check the protection device at regular intervals.
- Let the unit and the connected options cool down before you start working on them.



### INFORMATION

- For operating modes with encoder feedback, parameters must not be changed in cycles faster than 2 seconds. This ensures that the encoders are initialized.
- The maximum output frequency in the VFC operating modes without encoder feedback is 150 Hz.
- The maximum output frequency in the V/f operating mode and all operating modes with encoder feedback is 599 Hz.
- If the maximum output frequency is exceeded, error 08 "Speed monitoring" is displayed.

## 8.1 Energy management components

You can connect the unit to energy management components via the connection X1271. For operation without energy management components the supplied jumper plug must be used to jumper the phases of the AC 400 V input.

## 8.2 Relative cyclic duration factor (cdf)

The cyclic duration factor (cdf) is the ratio between the load duration and the cycle duration. The duration of the duty cycle is the sum of times of operation and times at rest and de-energized. A typical value for the cycle duration is 10 minutes.

$$cdf = \frac{\text{total time of operation}}{\text{cycle duration (T)}} \cdot 100\% = \frac{(t1 + t2 + t3)}{T} \cdot 100\%$$

27021597976207755

## 8.3 Duty cycles

### 8.3.1 Ambient conditions

The following ambient conditions apply according to cdf specification IEC 60034-1 (2005):


- Ambient temperature  $\vartheta_u$  [+5 °C – +40 °C (+41 – +104 °F)]

Every temperature increase by 1 °C (1.8 °F) results in a cdf decrease of 4%.

- $I_D = 100 \% I_N$  at  $f_{PWM} = 4 \text{ kHz}$
- Installation location up to 1000 m above sea level

### 8.3.2 Duty type S1


**Continuous duty:** Operation with a constant load state, the motor achieves a thermal steady state.



2325833867

### 8.3.3 Duty type S2


**Short-time duty:** Operation at constant load for a limited, given time followed by a time at rest. The motor returns to ambient temperature during the rest period.



2325835787

### 8.3.4 Duty type S3

**Intermittent periodic duty:** The switch-on sequence does not affect the temperature rise. Characterized by a sequence of identical duty cycles, each including a time of operation at constant load and a time at rest. Described by the "cyclic duration factor (cdf)" in %.



2325831947

### 8.3.5 Duty types S4 to S10

**Intermittent periodic duty:** The startup current affects the temperature rise. Characterized by a sequence of identical duty cycles, each including a time of operation at constant load and a time at rest. Described by the "cyclic duration factor (cdf)" in % and the number of cycles per hour.

## 8.4 Status and error messages

The 7-segment display provides information on the status of the MOVIPRO®. In case of repeated malfunctions, contact the SEW Service staff.

The display of the 7-segment display shows the current status of the unit. If several statuses or errors are active at the same time, the error with the highest priority is displayed.

### 8.4.1 Status displays

#### Initial startup

When you switch on the programmable unit for the first time, it displays the following:

Code	Possible cause	Measure
no_ → CnF <b>S2:</b> Flashing green <b>S3:</b> Lit green	No executable IEC program is loaded.	Load your user program into the unit.

#### Unit status

The following unit statuses are possible after successful initial configuration:

Code	Meaning	Response	Possible cause	Measure
oFF	The maintenance switch is switched off.			Switch on the maintenance switch.  <b>Units without interface box:</b> Check the DC 24 V cabling and the cabling of the switch feedback.
InI	Initialization: A connection is established with all internal components.  This can take several minutes after a unit replacement.			
run	The connection has been established successfully. The statuses of the components or the application are displayed after 3 s.			
Flashing dot	Application module of the "PFA-..." power section is running.			

Code	Meaning	Response	Possible cause	Measure
buS → Err	Fieldbus error			<ul style="list-style-type: none"> <li>Check the fieldbus cabling to the higher-level controller.</li> <li>Check the fieldbus parameterization of the unit and the higher-level controller.</li> </ul>
OFL	Internal communication error			<p><b>While backing up data or restoring a data backup:</b></p> <p>Wait a few minutes until the display changes.</p> <p><b>In normal operation:</b></p> <ul style="list-style-type: none"> <li>Disconnect the unit from the AC 400 V supply and the DC 24 V supply for at least 30 s.</li> <li>Restart the unit.</li> </ul>
8.8.8. <b>S2:</b> Flashing green <b>S3:</b> Off			Application module not running / not loaded	Create a configuration with the Application Configurator and load it into the unit.

Code	Meaning	Response	Possible cause	Measure
Ax.F → 111	Communication error with the power section	Not able to establish a connection with the "PFA-..." power section (connection failed).		<b>When using the application module "Transparent 3PD"</b> <ul style="list-style-type: none"> <li>In MOVITOOLS® MotionStudio, right-click the unit.</li> <li>Choose [Application modules] &gt; [Application Configurator].</li> <li>Choose [Open configuration from controller]. Check the following settings, and adjust them, if necessary: <ul style="list-style-type: none"> <li>Controller interface = SBUS_1</li> <li>Axis address = 20</li> <li>Unit type = MOVIPRO LT</li> </ul> </li> </ul> <b>When using other application modules</b> <ul style="list-style-type: none"> <li>In MOVITOOLS® MotionStudio, right-click the power section of your unit.</li> <li>Choose [Technology Editor] &gt; [Drive startup for MOVI-PLC/CCU] and start up the drive.</li> </ul>
Ax.F → 116	Communication error with the power section	The existing connection to the "PFA-..." power section was interrupted.		
SF1	Communication error with the power section			
SF2	Error in external periphery			<ul style="list-style-type: none"> <li>Disconnect the unit from the AC 400 V supply and the DC 24 V supply for at least 30 s.</li> <li>Restart the unit.</li> </ul> <p>Check the cabling of the digital inputs and outputs as well as the connections of the communication package.</p>

Code	Meaning	Response	Possible cause	Measure
SF3	Error while loading the application module		Non-enabled application module loaded	<ul style="list-style-type: none"> <li>Set parameter P802 "Factory setting" of the "PFA-..." power section to "Delivery status".</li> <li>Load an enabled application module into the "PFA-..." power section.</li> </ul>
SF → 10	Error in Application Configurator communication		Configuration with Application Configurator not completed.	Complete the configuration with the Application Configurator and load it into the unit.
SF → 20	Error during data backup	Data backup on SD memory card failed, upload aborted		Start data backup again.
SF → 21	Error during data backup	Data backup on SD memory card failed	SD memory card is write protected	Remove write protection from SD memory card.
SF → 22	Error during data restoring	Data restoring to the unit failed, download aborted.		Start data restoring again.
SF → 23	Error during data restoring	Data restoring to the unit failed	Controller not inhibited	Set the unit to one of the following states: <ul style="list-style-type: none"> <li>Controller inhibit (A1.1)</li> <li>Safe stop (A1.u)</li> </ul>
SF → 99	Internal system error			
SF → 110	Actuator voltage overload error		Actuator voltage overload	Check the cabling of the digital inputs and outputs.
SF → 120	Error due to overload in sensor voltage of group 1		Overload sensor voltage group 1	Check the cabling of the digital inputs and outputs.
SF → 121	Error due to overload in sensor voltage of group 2		Overload sensor voltage group 2	Check the cabling of the digital inputs and outputs.

#### 8.4.2 Inverter status



#### ▲ WARNING

Risk of injury due to incorrect interpretation of display **U = "Safe Torque Off" active**  
Severe or fatal injuries.

- The display **U = "Safe Torque Off" active** is not safety-related. Thus it must not be used safety-related.

The inverter status is indicated by displaying the address/number of the axis and the corresponding status code in the form of A1.y.

## INFORMATION



The unit status display takes priority over the inverter status display. If the maintenance switch is switched off of a fieldbus error occurs, no inverter status is displayed.

The following figure shows the display for the "Enable" status of axis 1:



1820269707

The following table shows the various status codes:


Status display	Device status (high byte in status word 1)	Meaning
0	0 <sub>dec</sub>	DC 24 V operation (inverter not ready)
1	1 <sub>dec</sub>	Controller inhibit active
2	2 <sub>dec</sub>	No enable
3	3 <sub>dec</sub>	Standstill current
4	4 <sub>dec</sub>	Enable
5	5 <sub>dec</sub>	n-control
6	6 <sub>dec</sub>	M-control
7	7 <sub>dec</sub>	Hold control
8	8 <sub>dec</sub>	Factory setting
9	9 <sub>dec</sub>	Limit switch reached
A	10 <sub>dec</sub>	Technology option
c	12 <sub>dec</sub>	IPOS <sup>plus</sup> ® reference travel
d	13 <sub>dec</sub>	Flying start
E	14 <sub>dec</sub>	Calibrate encoder
F	Error code	Fault indicator (flashing)
U	17 <sub>dec</sub>	"Safe Torque Off" active
• (blinking dot)	—	Application module running

If the transition function of the status display is disabled using the processing unit, the bus is no longer monitored. If an error occurs in this case, the status display may still display the last status before occurrence of the error. This is why you should only switch off the monitoring function in exceptional cases, and inform the respective personnel accordingly.

### 8.4.3 Inverter error

In case of an inverter error, the status display alternatively shows the address/number of the axis and 3 times the corresponding error code.

The following figure shows the display for an "Overtemperature" error of axis 1:




1806505867

For a list of error codes, refer to section "Service".

#### 8.4.4 Status LED

The status LEDs are located on the service unit of the MOVIPRO® and show the status of the fieldbus and the unit.



1954344587

[1] Status LEDs S1, S2, S3

#### Status LED S2 PLC status

State LED	Possible cause	Measure
Flashing green	<ul style="list-style-type: none"> <li>The firmware of the communication and control unit is running correctly.</li> </ul>	—
Flashing green/orange	<ul style="list-style-type: none"> <li>Data backup is created/restored.</li> </ul>	—
Lights up orange	<ul style="list-style-type: none"> <li>Boot is active.</li> </ul>	—
Flashing orange	<ul style="list-style-type: none"> <li>Firmware is being updated or</li> <li>Bootloader update required.</li> </ul>	—
Flashing red	<ul style="list-style-type: none"> <li>SD card is not inserted.</li> <li>File system on the SC card is corrupt.</li> <li>Boot process has failed.</li> </ul>	<ul style="list-style-type: none"> <li>Switch the unit off and back on again. If the error reoccurs, contact SEW service.</li> </ul>


#### Status LED S3

State LED	Possible cause	Measure
Lit green	<ul style="list-style-type: none"> <li>Program is running.</li> </ul>	—
Off	<ul style="list-style-type: none"> <li>No program is loaded.</li> </ul>	<ul style="list-style-type: none"> <li>Replace the SD card.</li> </ul>

Status LEDs FO1 and FO2 Ethernet connection push-pull SCRJ

The two LEDs "FO1" and "FO2" indicate the signal quality of the respective optical transmission line.

The LEDs are located to the left and right of the two Ethernet fieldbus connections push-pull SCRJ:



4083348491

- [1] FO1  
[2] FO2

Status LED	Possible cause	Measure
Off	The signal level is 2 dB or more. The signal quality is good.	–
Lights up yellow	The optical signal level has fallen below 2 dB. This can have the following reasons: <ul style="list-style-type: none"><li>• Aging effect of the polymer fiber.</li><li>• The plug connector is not properly connected.</li><li>• The externally connected cable is faulty or damaged.</li></ul>	<ul style="list-style-type: none"><li>• Check whether the plug connector is inserted correctly.</li><li>• Check the damping of the externally connected cable.</li></ul>

## 9 Service

### 9.1 Inspection/maintenance

The unit is maintenance-free. SEW-EURODRIVE does not stipulate any regular inspection work. However, it is recommended that you check the following parts regularly:

- Connection cables:  
Damaged or fatigued cables must be replaced immediately.
- Cooling fins:  
To ensure sufficient cooling, remove any deposits that accumulate.
- If there is a fan subassembly, check its individual axial fans for functionality.

### INFORMATION



Only SEW-EURODRIVE is authorized to carry out repairs.

### 9.2 Unit replacement

#### 9.2.1 Notes on replacing units

The unit allows for a quick unit replacement. It is equipped with a replaceable memory card on which all unit data can be stored.

If the unit has to be replaced, the plant can be started up again quickly by simply re-plugging the memory card.

After the startup procedure, you have to download the unit data to the memory card.

### INFORMATION



Observe the following notes during unit replacement:

- Only insert the memory card when the unit is switched off.
- After the unit replacement, the parameters last saved on the SD card are used.
- If an absolute encoder is used as motor encoder or synchronous encoder, you have to perform a reference travel during initial startup or after a unit or encoder replacement.
- If you are using an encoder with HIPERFACE® interface, a unit or encoder replacement is detected automatically and the message "IPOS reference" is reset.
- If you use an encoder with SSI interface, you have to adapt the encoder position to the mechanical plant conditions via a reference travel.

### INFORMATION




Observe the following information for **programmable** units:

- The status display depends on the programming. **Conditions:** The module for the data backup function (data management) must be integrated in the program!

## 9.2.2 Replacing the unit

Proceed as follows to replace the unit:

1. Perform a data backup now if you are not certain whether the current unit parameterization is stored on the SD memory card.
2. Disconnect the unit and remove it from the system.
3. Remove the SD memory card of the unit via the service cover plate on the housing cover.
4. Insert the memory card into a new unit via the service cover plate.
5. Install the new unit in the system and connect it to the power supply.
6. Switch on the new unit.



9007202214921995

7. The parameters saved on the SD memory card are now available again. If a different parameter set is needed for the new unit change it now. Back up the changed unit data on the SD memory card again after startup.
8. For applications with motor encoder or distance encoder, you must perform a reference travel.

## 9.3 Encoder replacement

### 9.3.1 Replacing incremental encoders

Incremental encoders for positioning always require a reference travel after startup. This is why there are no special measures required in the event of a unit or encoder (motor) replacement.

### 9.3.2 Replacing absolute encoders.

MOVIPRO® stores the position of absolute encoders with 32 bit. This allows for representing a larger absolute area than with an encoder with typical 12 bits in the single-turn range and 12 bits in the multi-turn range. However, this also means that you must reference the encoder in case of a unit or encoder (motor) replacement.

### 9.3.3 Replacing linear encoder systems

If you replace an absolute linear encoder system without encoder overflow in such a way that the encoder system provides the same values as before the replacement, a reference travel is not required.

### 9.3.4 Replacing HIPERFACE® encoders

With HIPERFACE® encoders, you can use parameter P948 to specify whether or not a reference travel is required after an encoder replacement.

## 9.4 Display

The status display indicates the status of the unit. It is operated by the processor unit. Refer to the software documentation for detailed information on possible error messages.

## 9.5 Error information of the power section

### 9.5.1 Fault memory

The error memory (P080) stores the last 5 error messages (faults t-0 through t-4) of the inverter. The oldest error message is deleted whenever more than 5 error messages have occurred.

The following information is stored when an error occurs:

- Error which has occurred
- Status of digital inputs/outputs
- Operating state of the inverter
- Inverter status
- Heat sink temperature
- Speed
- Output current
- Active current
- Unit utilization
- DC link voltage
- Operating hours
- Enable hours
- Parameter set
- Motor utilization

### 9.5.2 Reset



#### ▲ WARNING

Risk of crushing if the motor starts up unintentionally.

Severe or fatal injuries.

- Observe the startup notes.
- Set the controller inhibit.
- Switch off the output stage.
- De-couple the drive.
- Deactivate auto reset for drives that start up automatically.

An error message can be acknowledged by:

- Switching the voltage supply off and then on  
Always maintain a minimum switch-off time of 1 minute.
- Reset using the parameters of the frequency inverter
- Reset via the process data interface

Auto reset performs up to 5 unit resets with an adjustable restart time.

## 9.6 Shutdown

### 9.6.1 Unit with connected MOVI-DPS

Proceed as follows to shut down the unit:

- Inhibit the output stage of the unit.
- Disconnect the unit from the supply system.
- Observe the instructions in the documentation of the connected MOVI-DPS.

### 9.6.2 Unit without connected MOVI-DPS



#### ⚠ WARNING

Electric shock due to charged capacitors

Severe or fatal injuries

- Observe a minimum switch-off time after disconnecting the power supply:  
**10 minutes**

To shut down the unit, disconnect it from the power supply using appropriate measures.

## 9.7 Storage

Observe the following instructions when shutting down or storing the unit:

- If you shut down and store the unit for a longer period, you must cover the connections with the supplied protection caps.
- Place the unit on a side without connectors during storage.
- Ensure that the unit is not subject to mechanical impact during storage.
- Connect the unit to the supply voltage for at least 5 minutes every 2 years.

Observe the notes about the storage temperature in the “Technical data” chapter.

## 9.8 Extended storage

If the unit is stored for a long time, connect it to the power supply for at least 5 minutes every 2 years. Otherwise, the service life of the unit may be reduced.

#### Procedure when maintenance has been neglected:

Electrolytic capacitors are used in the frequency inverters. They are subject to aging effects when de-energized. This effect can damage the capacitors if the unit is connected using the nominal voltage after a longer period of storage.

If you have not performed maintenance regularly, SEW-EURODRIVE recommends that you increase the line voltage slowly up to the maximum voltage. This can be done, for example, by using a variable transformer for which the output voltage has been set according to the following overview:

- Stage 1: AC 0 V to AC 350 V within a few seconds
- Stage 2: AC 350 V for 15 minutes

- Stage 3: AC 420 V for 15 minutes
- Stage 4: AC 500 V for 1 hour

## **9.9 Waste disposal**

Observe the applicable national regulations. Dispose of materials separately in accordance with the nature of the materials and the regulations in force, for example:

- Electronics scrap (printed circuit boards)
- Plastic
- Sheet metal
- Copper
- Aluminum

## **9.10 Additional information**

For additional service information, refer to chapter "Service" of the project description of the system solution.

## 10 Technical data

### 10.1 Basic unit

#### INFORMATION



Operation without MOVI-DPS changes the technical data. Observe the latest edition of the relevant documentation.

General	
Ambient temperature	+5 – +40 °C (non-condensing, no moisture condensation) The unit provides intrinsic thermal safety. Once the heat sink temperature exceeds a certain level, a disconnection is triggered and an "Overtemperature" error message is generated.
Derating ambient temperature	EN 60721-3-3
Climate class	Class 3K3
Storage temperature	-25 – +70 °C
Degree of protection	IP54
Weight	38.5 kg
Dimensions W × H × D	750 × 420 × 190 mm

Input data X1213	
Supply type	3-phase AC connection
Input voltage range	3 × AC 380 – 500 V
Nominal input current At $I_L = AC\ 400\ V$	AC 15.8 A
Nominal input current with optional fan:	AC 28.8 A
Nominal input frequency	50 – 60 Hz

Output data	
Operating mode	S1 (IEC 60034-1)
Rated output power	8.4 kW
Rated output power with optional fan	15 kW

The total rated output power is crucial for the maximum output power of the unit. The power data of the individual axes may deviate from these values.

24 V backup voltage	
Nominal input voltage	DC 24 V -15% / +20% (EN 61131-2)
Internal consumption	< 1 A, typ. 750 mA
Total current consumption	Own consumption + output current on buses and I/Os

AC 400 V output X2371 / AC 400 V output (SNI) X2241	
Nominal output voltage	$U_l$
Line connection fusing (via circuit breaker for total current)	10 A trip characteristic K
Maximum line length	100 m

The integrated 10 A fuses are connected before the line output. Note the required cable cross sections of at least AWG 14 for UL installations.

## 10.2 Axis data

Motor with brake control X2016	
Axis type	PFA-MD150B
Nominal output power According to EN 60034-1	15 kW at $f_{A1} = 4$ kHz
Nominal output current According to EN 60034-1	AC 32 A
Current limiting (motor and regenerative operation, duration depending on capacity utilization)	AC 48 A
Output voltage	3 × AC 0 – 500 V
PWM frequency	Adjustable: 4 / 8 / 12 / 16 kHz
Speed range	– 6000 – 0 – + 6000 min <sup>-1</sup>
Resolution	0.2 min <sup>-1</sup> over the entire range
Rated brake voltage Terminals 13 / 15	DC 167 V
SEW brake type	AC 400 V
Nominal brake current Terminals 13/15 per motor output	DC 0.7 A
Brake acceleration current Terminals 13/14 per motor output	4 – 8.5 x the holding current, depending on brake type
Maximum braking power	120 W (0,161 HP)
Temperature sensor when 2 motors are connected	TH (series connection via both motors)
Temperature sensor when 1 motor is connected	TF / TH / KTY: The temperature sensor contacts of the motor connection not in use must be jumpered.
Maximum motor cable length	30 m
Braking resistor	
Minimum permitted braking resistance (4Q operation)	15 Ω

## INFORMATION



For more information, refer to the "MOVIPRO® Accessories" addendum to the operating instructions.

### 10.3 Communication and control unit

#### 10.3.1 Processing unit


MOVI-PLC® advanced DHR41B	
Digital inputs	PLC-compatible (IEC 61131-2), sampling cycle 1 ms
Signal level	24 V = "1" = contact closed 0 V = "0" = contact open
Digital outputs	500 mA / output Dissipation of inductive switch-off energy up to 0.7 J (freewheeling diodes are not integrated) All outputs are short-circuit proof, protected against overloads, and interference-voltage-proof. There is no integrated free-wheeling diode.
Memory card	PC readable
Engineering	Engineering is performed via the ETHERNET service interface and the PLC Editor in the MOVITOOLS® MotionStudio PC software. Additional engineering access via PROFINET, EtherNet/IP and Modbus/TCP interface.
Fieldbus connections	Push-pull RJ45 Integrated Ethernet switch with auto-crossing and auto-negotiation function.
24 V voltage supply of the buses	
Output voltage	DC 24 V ± 10%
Output current	500 mA / output The total output power of the 24 V supplies must not exceed 48 W.

#### 10.3.2 PROFINET interface

PROFINET interface	
PROFINET protocol variant	PROFINET IO RT
Supported baud rate	100 Mbit/s (full duplex)
SEW ident number	010A <sub>hex</sub>
Unit ident number	4
Connection technology	M12 (D-coded) or RJ45 (push-pull)
Integrated switch	Supports auto-crossing, auto-negotiation
Permitted cable types	Category 5 and higher, class D according to IEC 11801
Maximum cable length (from switch to switch)	100 m according to IEEE 802.3
GSD file name	GSDML-V2.1-SEW-MOVIPRO-yyyymmdd.xml
Bitmap file name	SEWMOVIPRO1.bmp

## 10.4 Dimension drawing

The dimension drawing shows the mechanical dimensions of the drive controller in mm (in):




18014407364700555

<sup>1)</sup> Recommended clearance for connection cables (can vary depending on the cables used)

## 10.5 Hybrid cable type "D"

### 10.5.1 Mechanical structure

The following figure shows the mechanical structure of the cable:



9007201213477771

[1] Shield

	Cable type				
	D/1.5	D/2.5	D/4.0	D/6.0	D/10.0
Supply cores (mm <sup>2</sup> )	4 x 1.5	4 x 2.5	4 x 4.0	4 x 6.0	4 x 10.0
Control core pair (mm <sup>2</sup> )	2 x 0.75	2 x 0.75	2 x 0.75	2 x 0.7	2 x 0.75
Brake control (mm <sup>2</sup> )	3 x 1.0	3 x 1.0	3 x 1.5	3 x 1.5	3 x 1.5
Conductor insulation	PP (polypropylene)				
Conductor	Bare E-Cu litz wire, extra fine wires with individual wire 0.15 mm				
Shield	Made of tinned E-Cu wire				
Overall diameter (mm)	13.9	17.2	19.0	21.5	25.3
Color of outer cable jacket	Orange				
Outer cable jacket insulation	TPE-U (polyurethane)				

### 10.5.2 Properties

All cable types have the following properties:

- Maximum 600 V operating voltage for all cores
- Approved according to European and American standards
- Suitable for cable carriers
  - Bending cycles > 5 million
  - Travel speed ≤ 3 ms<sup>-1</sup>

- Min. bending radius: 10 x cable diameter
- Minimum bending radius for fixed installation: 5 x cable diameter
- Resistance against oil according to VDE 0250 part 407
- General resistance to acids, alkalis, cleaning agents
- General resistance against dusts (e.g. bauxite, magnesite)
- Insulation and sheath material halogen-free
- Within the specified temperature range, free from substances interfering with wetting agents (silicone-free)
- Flame retardant according to VDE 0472 part 804 (method B IEC 60 332-1)
- Temperature range for processing and operation:


Fixed installation	Cable carrier installation
–40 °C to +90 °C (current-carrying capacity to DIN VDE 0298-4)	–5 °C to +90 °C (current-carrying capacity to DIN VDE 0298-4)
–30 °C to +80 °C according to UL758	–5 °C to +80 °C according to UL758

- Temperature range for transportation and storage:
  - –40 °C to +90 °C (current-carrying capacity to DIN VDE 0298-4)
  - –30 °C to +80 °C according to UL758

## 10.6 Hybrid cable type "E"

### 10.6.1 Mechanical structure

The following figure shows the mechanical structure of the cable:



2111423499

- [1] Shielded "three-conductor" cable
- [2] EMC shielding, "three-conductor" cable
- [3] Plaiting for complete EMC shielding

	Cable type			
	E/1.5	E/2.5	E/4.0	E/6.0
Supply cores (mm <sup>2</sup> )	4 x 1.5	4 x 2.5	4 x 4.0	4 x 6.0
Brake control (mm <sup>2</sup> )	3 x 1.0	3 x 1.0	3 x 1.0	3 x 1.5
Conductor insulation	TPM			

	Cable type			
	E/1.5	E/2.5	E/4.0	E/6.0
Conductor	Blank CU litz wire			
Shield	Made of tinned Cu wire			
Overall diameter (mm)	15.0	16.3	15.3	17.4
Color of outer cable jacket	Orange			
Outer cable jacket insulation	PUR (polyurethane)			

### 10.6.2 Properties

All cable types have the following properties:

- Maximum 600 V operating voltage for all cores
- Approved according to European and American standards
- Suitable for cable carriers
  - Bending cycles > 5 million
  - Travel speed  $\leq 3 \text{ ms}^{-1}$
  - Min. bending radius: 10 x cable diameter
- Minimum bending radius for fixed installation: 5 x cable diameter
- Resistance against oil according to VDE 0250 part 407
- General resistance to acids, alkalis, cleaning agents
- General resistance against dusts (e.g. bauxite, magnesite)
- Insulation and sheath material halogen-free
- Within the specified temperature range, free from substances interfering with wetting agents (silicone-free)
- Flame retardant according to VDE 0472 part 804 (method B IEC 60 332-1)
- Temperature range for processing and operation:
  - $-50 \text{ }^{\circ}\text{C}$  to  $+80 \text{ }^{\circ}\text{C}$
  - $-20 \text{ }^{\circ}\text{C}$  to  $+60 \text{ }^{\circ}\text{C}$
- Temperature range for transportation and storage:
  - $-40 \text{ }^{\circ}\text{C}$  to  $+90 \text{ }^{\circ}\text{C}$  (current-carrying capacity to DIN VDE 0298-4)
  - $-30 \text{ }^{\circ}\text{C}$  to  $+80 \text{ }^{\circ}\text{C}$  according to UL758

## 11 Additional documentation

The following documentation contains further information:

Title	Part number
Addendum to the "MOVIPRO® – Accessories" operating instructions	19446012/EN
"Controllers DHE21B/DHF21B/DHR21B (Standard), DHE41B/DHF41B/DHR41B (advanced)" manual	16897226/EN
"MOVIPRO® ADC with PROFINET Interface" manual	19298412/EN
"MOVIPRO® Functional Safety" manual	19289626/EN

## 12 MAXOLUTION® Competence Center

### Germany

Bruchsal	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 D-76646 Bruchsal P.O. Box Postfach 3023 – D-76642 Bruchsal	Tel. +49 7251 75-0 Fax +49 7251 75-1970 <a href="http://www.sew-eurodrive.de">http://www.sew-eurodrive.de</a> <a href="mailto:maxolution@sew-eurodrive.de">maxolution@sew-eurodrive.de</a>
Kirchheim	SEW-EURODRIVE GmbH & Co KG Domagkstraße 5 D-85551 Kirchheim (München)	Tel. +49 89 909552-10 Fax +49 89 909552-50 <a href="mailto:dtc-sued@sew-eurodrive.de">dtc-sued@sew-eurodrive.de</a>

### Australia

Melbourne	SEW-EURODRIVE PTY. LTD. 27 Beverage Drive Tullamarine, Victoria 3043	Tel. +61 3 9933-1000 Fax +61 3 9933-1003 <a href="http://www.sew-eurodrive.com.au">http://www.sew-eurodrive.com.au</a> <a href="mailto:enquires@sew-eurodrive.com.au">enquires@sew-eurodrive.com.au</a>
-----------	----------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

### Brazil

São Paulo	SEW-EURODRIVE Brasil Ltda. Estrada Municipal José Rubim, 205 – Rodovia Santos Dumont Km 49 Indaiatuba – 13347-510 – SP	Tel. +55 19 3835-8000 <a href="mailto:sew@sew.com.br">sew@sew.com.br</a>
-----------	------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------

### China

Tianjin	SEW-EURODRIVE (Tianjin) Co., Ltd. No. 78, 13th Avenue, TEDA Tianjin 300457	Tel. +86 22 25322612 Fax +86 22 25323273 <a href="http://www.sew-eurodrive.cn">http://www.sew-eurodrive.cn</a> <a href="mailto:info@sew-eurodrive.cn">info@sew-eurodrive.cn</a>
---------	----------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

### France

Hagenau	SEW-USOCOME 48-54 route de Soufflenheim B. P. 20185 F-67506 Haguenau Cedex	Tel. +33 3 88 73 67 00 Fax +33 3 88 73 66 00 <a href="http://www.usocomme.com">http://www.usocomme.com</a> <a href="mailto:sew@usocomme.com">sew@usocomme.com</a>
---------	-------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------

### India

Chennai	SEW-EURODRIVE India Private Limited Plot No. K3/1, Sipcot Industrial Park Phase II Mambakkam Village Sriperumbudur - 602105 Kancheepuram Dist, Tamil Nadu	Tel. +91 44 37188888 Fax +91 44 37188811 <a href="mailto:saleschennai@seweurodriveindia.com">saleschennai@seweurodriveindia.com</a>
---------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------

### Italy

Solaro	SEW-EURODRIVE di R. Blickle & Co.s.a.s. Via Bernini, 14 I-20020 Solaro (Milano)	Tel. +39 02 96 9801 Fax +39 02 96 79 97 81 <a href="http://www.sew-eurodrive.it">http://www.sew-eurodrive.it</a> <a href="mailto:sewit@sew-eurodrive.it">sewit@sew-eurodrive.it</a>
--------	---------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

### Poland

Tychy	SEW-EURODRIVE Polska Sp.z o.o. ul. Strzelecka 66 PL-43-109 Tychy	Tel. +48 32 32 32 610 Fax +48 32 32 32 648
-------	------------------------------------------------------------------------	-----------------------------------------------

### South Africa

Johannesburg	SEW-EURODRIVE (PROPRIETARY) LIMITED Eurodrive House Cnr. Adcock Ingram and Aerodrome Roads Aeroton Ext. 2 Johannesburg 2013 P.O.Box 90004 Bertsham 2013	Tel. +27 11 248-7000 Fax +27 11 248-7289 <a href="http://www.sew.co.za">http://www.sew.co.za</a> <a href="mailto:info@sew.co.za">info@sew.co.za</a>
--------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------

### South Korea

Ansan	SEW-EURODRIVE KOREA CO., LTD. 7, Dangjaengi-ro, Danwon-gu, Ansan-si, Gyeonggi-do, Zip 425-839	Tel. +82 31 492-8051 Fax +82 31 492-8056 <a href="http://www.sew-eurodrive.kr">http://www.sew-eurodrive.kr</a> <a href="mailto:master.korea@sew-eurodrive.com">master.korea@sew-eurodrive.com</a>
-------	--------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

**Sweden**

Jönköping

SEW-EURODRIVE AB  
Gnejsvägen 6-8  
S-55303 Jönköping  
Box 3100 S-55003 Jönköping

Tel. +46 36 34 42 00  
Fax +46 36 34 42 80  
<http://www.sew-eurodrive.se>  
[jonkoping@sew.se](mailto:jonkoping@sew.se)

**USA**

Lyman

SEW-EURODRIVE INC.  
1295 Old Spartanburg Highway  
P.O. Box 518  
Lyman, S.C. 29365

Tel. +1 864 439-7537  
Fax +1 864 439-7830  
<http://www.seweurodrive.com>  
[cslyman@seweurodrive.com](mailto:cslyman@seweurodrive.com)

## 13 Address list

<b>Algeria</b>			
Sales	Algiers	REDUCOM Sarl 16, rue des Frères Zaghroune Bellevue 16200 El Harrach Alger	Tel. +213 21 8214-91 Fax +213 21 8222-84 <a href="http://www.reducom-dz.com">http://www.reducom-dz.com</a> <a href="mailto:info@reducom-dz.com">info@reducom-dz.com</a>
<b>Argentina</b>			
Assembly Sales	Buenos Aires	SEW EURODRIVE ARGENTINA S.A. Ruta Panamericana Km 37.5, Lote 35 (B1619IEA) Centro Industrial Garín Prov. de Buenos Aires	Tel. +54 3327 4572-84 Fax +54 3327 4572-21 <a href="http://www.sew-eurodrive.com.ar">http://www.sew-eurodrive.com.ar</a> <a href="mailto:sewar@sew-eurodrive.com.ar">sewar@sew-eurodrive.com.ar</a>
<b>Australia</b>			
Assembly Sales Service	Melbourne	SEW-EURODRIVE PTY. LTD. 27 Beverage Drive Tullamarine, Victoria 3043	Tel. +61 3 9933-1000 Fax +61 3 9933-1003 <a href="http://www.sew-eurodrive.com.au">http://www.sew-eurodrive.com.au</a> <a href="mailto:enquires@sew-eurodrive.com.au">enquires@sew-eurodrive.com.au</a>
	Sydney	SEW-EURODRIVE PTY. LTD. 9, Sleigh Place, Wetherill Park New South Wales, 2164	Tel. +61 2 9725-9900 Fax +61 2 9725-9905 <a href="mailto:enquires@sew-eurodrive.com.au">enquires@sew-eurodrive.com.au</a>
<b>Austria</b>			
Assembly Sales Service	Vienna	SEW-EURODRIVE Ges.m.b.H. Richard-Strauss-Strasse 24 A-1230 Wien	Tel. +43 1 617 55 00-0 Fax +43 1 617 55 00-30 <a href="http://www.sew-eurodrive.at">http://www.sew-eurodrive.at</a> <a href="mailto:sew@sew-eurodrive.at">sew@sew-eurodrive.at</a>
Croatia	Zagreb	KOMPEKS d. o. o. Zeleni dol 10 HR 10 000 Zagreb	Tel. +385 1 4613-158 Fax +385 1 4613-158 <a href="mailto:kompeks@inet.hr">kompeks@inet.hr</a>
Romania	Bucharest	Sialco Trading SRL str. Brazilia nr. 36 011783 Bucuresti	Tel. +40 21 230-1328 Fax +40 21 230-7170 <a href="mailto:sialco@sialco.ro">sialco@sialco.ro</a>
Serbia	Belgrade	DIPAR d.o.o. Ustanicka 128a PC Košum, IV floor SRB-11000 Beograd	Tel. +381 11 347 3244 / +381 11 288 0393 Fax +381 11 347 1337 <a href="mailto:office@dipar.rs">office@dipar.rs</a>
Slovenia	Celje	Pakman - Pogonska Tehnika d.o.o. Ul. XIV. divizije 14 SLO - 3000 Celje	Tel. +386 3 490 83-20 Fax +386 3 490 83-21 <a href="mailto:pakman@siol.net">pakman@siol.net</a>
<b>Bangladesh</b>			
Vertrieb	Bangladesh	SEW-EURODRIVE INDIA PRIVATE LIMITED 345 DIT Road East Rampura Dhaka-1219, Bangladesh	Tel. +88 01729 097309 <a href="mailto:salesdhaka@seweurodrivebangladesh.com">salesdhaka@seweurodrivebangladesh.com</a>
<b>Belarus</b>			
Sales	Minsk	Foreign Enterprise Industrial Components Rybalko Str. 26 BY-220033 Minsk	Tel. +375 17 298 47 56 / 298 47 58 Fax +375 17 298 47 54 <a href="http://www.sew.by">http://www.sew.by</a> <a href="mailto:sales@sew.by">sales@sew.by</a>
<b>Belgium</b>			
Assembly Sales Service	Brussels	SEW-EURODRIVE n.v./s.a. Researchpark Haasrode 1060 Evenementenlaan 7 BE-3001 Leuven	Tel. +32 16 386-311 Fax +32 16 386-336 <a href="http://www.sew-eurodrive.be">http://www.sew-eurodrive.be</a> <a href="mailto:info@sew-eurodrive.be">info@sew-eurodrive.be</a>
Service Competence Center	Industrial Gears	SEW-EURODRIVE n.v./s.a. Rue de Parc Industriel, 31 BE-6900 Marche-en-Famenne	Tel. +32 84 219-878 Fax +32 84 219-879 <a href="http://www.sew-eurodrive.be">http://www.sew-eurodrive.be</a> <a href="mailto:service-wallonie@sew-eurodrive.be">service-wallonie@sew-eurodrive.be</a>

<b>Brazil</b>			
Production Sales Service	São Paulo	SEW-EURODRIVE Brasil Ltda. Estrada Municipal José Rubim, 205 – Rodovia Santos Dumont Km 49 Indaiatuba – 13347-510 – SP	Tel. +55 19 3835-8000 sew@sew.com.br
Assembly Sales Service	Rio Claro	SEW-EURODRIVE Brasil Ltda. Rodovia Washington Luiz, Km 172 Condomínio Industrial Conpark Caixa Postal: 327 13501-600 – Rio Claro / SP	Tel. +55 19 3522-3100 Fax +55 19 3524-6653 montadora.rc@sew.com.br
	Joinville	SEW-EURODRIVE Brasil Ltda. Rua Dona Francisca, 12.346 – Pirabeiraba 89239-270 – Joinville / SC	Tel. +55 47 3027-6886 Fax +55 47 3027-6888 filial.sc@sew.com.br
<b>Bulgaria</b>			
Sales	Sofia	BEVER-DRIVE GmbH Bogdanovetz Str.1 BG-1606 Sofia	Tel. +359 2 9151160 Fax +359 2 9151166 bever@bever.bg
<b>Cameroon</b>			
is supported by Germany.			
<b>Canada</b>			
Assembly Sales Service	Toronto	SEW-EURODRIVE CO. OF CANADA LTD. 210 Walker Drive Bramalea, ON L6T 3W1	Tel. +1 905 791-1553 Fax +1 905 791-2999 <a href="http://www.sew-eurodrive.ca">http://www.sew-eurodrive.ca</a> l.watson@sew-eurodrive.ca
	Vancouver	SEW-EURODRIVE CO. OF CANADA LTD. Tilbury Industrial Park 7188 Honeyman Street Delta, BC V4G 1G1	Tel. +1 604 946-5535 Fax +1 604 946-2513 b.wake@sew-eurodrive.ca
	Montreal	SEW-EURODRIVE CO. OF CANADA LTD. 2555 Rue Leger Lasalle, PQ H8N 2V9	Tel. +1 514 367-1124 Fax +1 514 367-3677 a.peluso@sew-eurodrive.ca
<b>Chile</b>			
Assembly Sales Service	Santiago de Chile	SEW-EURODRIVE CHILE LTDA Las Encinas 1295 Parque Industrial Valle Grande LAMP RCH-Santiago de Chile P.O. Box Casilla 23 Correo Quilicura - Santiago - Chile	Tel. +56 2 2757 7000 Fax +56 2 2757 7001 <a href="http://www.sew-eurodrive.cl">http://www.sew-eurodrive.cl</a> ventas@sew-eurodrive.cl
<b>China</b>			
Production Assembly Sales Service	Tianjin	SEW-EURODRIVE (Tianjin) Co., Ltd. No. 78, 13th Avenue, TEDA Tianjin 300457	Tel. +86 22 25322612 Fax +86 22 25323273 <a href="http://www.sew-eurodrive.cn">http://www.sew-eurodrive.cn</a> info@sew-eurodrive.cn
Assembly Sales Service	Suzhou	SEW-EURODRIVE (Suzhou) Co., Ltd. 333, Suhong Middle Road Suzhou Industrial Park Jiangsu Province, 215021	Tel. +86 512 62581781 Fax +86 512 62581783 suzhou@sew-eurodrive.cn
	Guangzhou	SEW-EURODRIVE (Guangzhou) Co., Ltd. No. 9, JunDa Road East Section of GETDD Guangzhou 510530	Tel. +86 20 82267890 Fax +86 20 82267922 guangzhou@sew-eurodrive.cn
	Shenyang	SEW-EURODRIVE (Shenyang) Co., Ltd. 10A-2, 6th Road Shenyang Economic Technological Development Area Shenyang, 110141	Tel. +86 24 25382538 Fax +86 24 25382580 shenyang@sew-eurodrive.cn
	Taiyuan	SEW-EURODRIVE (Taiyuan) Co., Ltd. No.3, HuaZhang Street, TaiYuan Economic & Technical Development Zone ShanXi, 030032	Tel. +86-351-7117520 Fax +86-351-7117522 taiyuan@sew-eurodrive.cn

China			
	Wuhan	SEW-EURODRIVE (Wuhan) Co., Ltd. 10A-2, 6th Road No. 59, the 4th Quanli Road, WEDA 430056 Wuhan	Tel. +86 27 84478388 Fax +86 27 84478389 wuhan@sew-eurodrive.cn
	Xi'An	SEW-EURODRIVE (Xi'An) Co., Ltd. No. 12 Jinye 2nd Road Xi'An High-Technology Industrial Development Zone Xi'An 710065	Tel. +86 29 68686262 Fax +86 29 68686311 xian@sew-eurodrive.cn
Sales Service	Hong Kong	SEW-EURODRIVE LTD. Unit No. 801-806, 8th Floor Hong Leong Industrial Complex No. 4, Wang Kwong Road Kowloon, Hong Kong	Tel. +852 36902200 Fax +852 36902211 contact@sew-eurodrive.hk
Colombia			
Assembly Sales Service	Bogota	SEW-EURODRIVE COLOMBIA LTDA. Calle 22 No. 132-60 Bodega 6, Manzana B Santafé de Bogotá	Tel. +57 1 54750-50 Fax +57 1 54750-44 <a href="http://www.sew-eurodrive.com.co">http://www.sew-eurodrive.com.co</a> sew@sew-eurodrive.com.co
Croatia			
Sales Service	Zagreb	KOMPEKS d. o. o. Zeleni dol 10 HR 10 000 Zagreb	Tel. +385 1 4613-158 Fax +385 1 4613-158 kompeks@inet.hr
Czech Republic			
Assembly Sales Service	Hostivice	SEW-EURODRIVE CZ s.r.o. Floriánova 2459 253 01 Hostivice	Tel. +420 255 709 601 Fax +420 235 350 613 <a href="http://www.sew-eurodrive.cz">http://www.sew-eurodrive.cz</a> sew@sew-eurodrive.cz
	Drive Service Hotline / 24 Hour Service	+420 800 739 739 (800 SEW SEW)	Service Tel. +420 255 709 632 Fax +420 235 358 218 servis@sew-eurodrive.cz
Denmark			
Assembly Sales Service	Copenhagen	SEW-EURODRIVEA/S Geminivej 28-30 DK-2670 Greve	Tel. +45 43 95 8500 Fax +45 43 9585-09 <a href="http://www.sew-eurodrive.dk">http://www.sew-eurodrive.dk</a> sew@sew-eurodrive.dk
Egypt			
Sales Service	Cairo	Copam Egypt for Engineering & Agencies 33 El Hegaz ST Heliopolis, Cairo	Tel. +20 222566299 Fax +20 2 22594-757 <a href="http://www.copam-egypt.com">http://www.copam-egypt.com</a> copam@copam-egypt.com
Estonia			
Sales	Tallin	ALAS-KUUL AS Reti tee 4 EE-75301 Peetri küla, Rae vald, Harjumaa	Tel. +372 6593230 Fax +372 6593231 <a href="http://www.alas-kuul.ee">http://www.alas-kuul.ee</a> veiko.soots@alas-kuul.ee
Finland			
Assembly Sales Service	Hollola	SEW-EURODRIVE OY Vesimäentie 4 FIN-15860 Hollola 2	Tel. +358 201 589-300 Fax +358 3 780-6211 <a href="http://www.sew-eurodrive.fi">http://www.sew-eurodrive.fi</a> sew@sew.fi
Service	Hollola	SEW-EURODRIVE OY Keskikankaantie 21 FIN-15860 Hollola	Tel. +358 201 589-300 Fax +358 3 780-6211 <a href="http://www.sew-eurodrive.fi">http://www.sew-eurodrive.fi</a> sew@sew.fi
Production Assembly	Karkkila	SEW Industrial Gears Oy Santasalonkatu 6, PL 8 FI-03620 Karkkila, 03601 Karkkila	Tel. +358 201 589-300 Fax +358 201 589-310 <a href="http://www.sew-eurodrive.fi">http://www.sew-eurodrive.fi</a> sew@sew.fi

France			
Production Sales Service	Hagenau	SEW-USOCOME 48-54 route de Soufflenheim B. P. 20185 F-67506 Haguenau Cedex	Tel. +33 3 88 73 67 00 Fax +33 3 88 73 66 00 <a href="http://www.usocome.com">http://www.usocome.com</a> <a href="mailto:sew@usocome.com">sew@usocome.com</a>
Production	Forbach	SEW-USOCOME Zone industrielle Technopôle Forbach Sud B. P. 30269 F-57604 Forbach Cedex	Tel. +33 3 87 29 38 00
	Brumath	SEW-USOCOME 1 rue de Bruxelles F-67670 Mommenheim	Tel. +33 3 88 37 48 48
Assembly Sales Service	Bordeaux	SEW-USOCOME Parc d'activités de Magellan 62 avenue de Magellan – B. P. 182 F-33607 Pessac Cedex	Tel. +33 5 57 26 39 00 Fax +33 5 57 26 39 09
	Lyon	SEW-USOCOME Parc d'affaires Roosevelt Rue Jacques Tati F-69120 Vaulx en Velin	Tel. +33 4 72 15 37 00 Fax +33 4 72 15 37 15
	Nantes	SEW-USOCOME Parc d'activités de la forêt 4 rue des Fontenelles F-44140 Le Bignon	Tel. +33 2 40 78 42 00 Fax +33 2 40 78 42 20
	Paris	SEW-USOCOME Zone industrielle 2 rue Denis Papin F-77390 Verneuil l'Étang	Tel. +33 1 64 42 40 80 Fax +33 1 64 42 40 88

### Gabon

is supported by Germany.

Germany			
Headquarters Production Sales	Bruchsal	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 D-76646 Bruchsal P.O. Box Postfach 3023 – D-76642 Bruchsal	Tel. +49 7251 75-0 Fax +49 7251 75-1970 <a href="http://www.sew-eurodrive.de">http://www.sew-eurodrive.de</a> <a href="mailto:sew@sew-eurodrive.de">sew@sew-eurodrive.de</a>
Production / Industrial Gears	Bruchsal	SEW-EURODRIVE GmbH & Co KG Christian-Pähr-Str. 10 D-76646 Bruchsal	Tel. +49 7251 75-0 Fax +49 7251 75-2970
Production	Graben	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 1 D-76676 Graben-Neudorf P.O. Box Postfach 1220 – D-76671 Graben-Neudorf	Tel. +49 7251 75-0 Fax +49 7251-2970
	Östringen	SEW-EURODRIVE GmbH & Co KG, Werk Östringen Franz-Gurk-Straße 2 D-76684 Östringen	Tel. +49 7253 9254-0 Fax +49 7253 9254-90 <a href="mailto:oestringen@sew-eurodrive.de">oestringen@sew-eurodrive.de</a>
Service Competence Center	Mechanics / Mechatronics	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 1 D-76676 Graben-Neudorf	Tel. +49 7251 75-1710 Fax +49 7251 75-1711 <a href="mailto:scc-mechanik@sew-eurodrive.de">scc-mechanik@sew-eurodrive.de</a>
	Electronics	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 D-76646 Bruchsal	Tel. +49 7251 75-1780 Fax +49 7251 75-1769 <a href="mailto:scc-elektronik@sew-eurodrive.de">scc-elektronik@sew-eurodrive.de</a>
Drive Technology Center	North	SEW-EURODRIVE GmbH & Co KG Alte Ricklinger Straße 40-42 D-30823 Garbsen (Hannover)	Tel. +49 5137 8798-30 Fax +49 5137 8798-55 <a href="mailto:dtc-nord@sew-eurodrive.de">dtc-nord@sew-eurodrive.de</a>
	East	SEW-EURODRIVE GmbH & Co KG Dankritzer Weg 1 D-08393 Meerane (Zwickau)	Tel. +49 3764 7606-0 Fax +49 3764 7606-30 <a href="mailto:dtc-ost@sew-eurodrive.de">dtc-ost@sew-eurodrive.de</a>
	South	SEW-EURODRIVE GmbH & Co KG Domagkstraße 5 D-85551 Kirchheim (München)	Tel. +49 89 909552-10 Fax +49 89 909552-50 <a href="mailto:dtc-sued@sew-eurodrive.de">dtc-sued@sew-eurodrive.de</a>

Germany			
	West	SEW-EURODRIVE GmbH & Co KG Siemensstraße 1 D-40764 Langenfeld (Düsseldorf)	Tel. +49 2173 8507-30 Fax +49 2173 8507-55 dtc-west@sew-eurodrive.de
Drive Center	Berlin	SEW-EURODRIVE GmbH & Co KG Alexander-Meißner-Straße 44 D-12526 Berlin	Tel. +49 306331131-30 Fax +49 306331131-36 dc-berlin@sew-eurodrive.de
	Saarland	SEW-EURODRIVE GmbH & Co KG Gottlieb-Daimler-Straße 4 D-66773 Schwalbach Saar – Hülzweiler	Tel. +49 6831 48946 10 Fax +49 6831 48946 13 dc-saarland@sew-eurodrive.de
	Ulm	SEW-EURODRIVE GmbH & Co KG Dieselstraße 18 D-89160 Dornstadt	Tel. +49 7348 9885-0 Fax +49 7348 9885-90 dc-ulm@sew-eurodrive.de
	Würzburg	SEW-EURODRIVE GmbH & Co KG Nürnbergerstraße 118 D-97076 Würzburg-Lengfeld	Tel. +49 931 27886-60 Fax +49 931 27886-66 dc-wuerzburg@sew-eurodrive.de
Drive Service Hotline / 24 Hour Service			+49 800 SEWHELP +49 800 7394357
Great Britain			
Assembly Sales Service	Normanton	SEW-EURODRIVE Ltd. DeVilliers Way Trident Park Normanton West Yorkshire WF6 1GX	Tel. +44 1924 893-855 Fax +44 1924 893-702 <a href="http://www.sew-eurodrive.co.uk">http://www.sew-eurodrive.co.uk</a> info@sew-eurodrive.co.uk
Drive Service Hotline / 24 Hour Service			Tel. 01924 896911
Greece			
Sales	Athens	Christ. Boznos & Son S.A. 12, K. Mavromichali Street P.O. Box 80136 GR-18545 Piraeus	Tel. +30 2 1042 251-34 Fax +30 2 1042 251-59 <a href="http://www.boznos.gr">http://www.boznos.gr</a> info@boznos.gr
Hungary			
Sales Service	Budapest	SEW-EURODRIVE Kft. Csillaghegyi út 13. H-1037 Budapest	Tel. +36 1 437 06-58 Fax +36 1 437 06-50 <a href="http://www.sew-eurodrive.hu">http://www.sew-eurodrive.hu</a> office@sew-eurodrive.hu
Iceland			
Sales	Reykjavik	Varma & Vélaverk ehf. Knarrarvogi 4 IS-104 Reykjavik	Tel. +354 585 1070 Fax +354 585)1071 <a href="http://www.varmaverk.is">http://www.varmaverk.is</a> vov@vov.is
India			
Registered Office Assembly Sales Service	Vadodara	SEW-EURODRIVE India Private Limited Plot No. 4, GIDC POR Ramangamdi • Vadodara - 391 243 Gujarat	Tel. +91 265 3045200 Fax +91 265 3045300 <a href="http://www.seweurodriveindia.com">http://www.seweurodriveindia.com</a> salesvadodara@seweurodriveindia.com
Assembly Sales Service	Chennai	SEW-EURODRIVE India Private Limited Plot No. K3/1, Sipcot Industrial Park Phase II Mambakkam Village Sriperumbudur - 602105 Kancheepuram Dist, Tamil Nadu	Tel. +91 44 37188888 Fax +91 44 37188811 saleschennai@seweurodriveindia.com
	Pune	SEW-EURODRIVE India Private Limited Plant: Plot No. D236/1, Chakan Industrial Area Phase- II, Warale, Tal- Khed, Pune-410501, Maharashtra	Tel. +91 21 35301400 salespune@seweurodriveindia.com
Indonesia			
Sales	Jakarta	PT. Cahaya Sukses Abadi Komplek Rukan Puri Mutiara Blok A no 99, Sunter Jakarta 14350	Tel. +62 21 65310599 Fax +62 21 65310600 csajkt@cbn.net.id

Indonesia			
	Jakarta	PT. Agrindo Putra Lestari Jl. Pantai Indah Selatan, Komplek Sentra Industri Terpadu, Pantai indah Kapuk Tahap III, Blok E No. 27 Jakarta 14470	Tel. +62 21 2921-8899 Fax +62 21 2921-8988 aplindo@indosat.net.id http://www.aplindo.com
	Medan	PT. Serumpun Indah Lestari Jl. Pulau Solor no. 8, Kawasan Industri Medan II Medan 20252	Tel. +62 61 687 1221 Fax +62 61 6871429 / +62 61 6871458 / +62 61 30008041 sil@serumpunindah.com serumpunindah@yahoo.com http://www.serumpunindah.com
	Surabaya	PT. TRIAGRI JAYA ABADI Jl. Sukosemolo No. 63, Galaxi Bumi Permai G6 No. 11 Surabaya 60111	Tel. +62 31 5990128 Fax +62 31 5962666 sales@triagri.co.id http://www.triagri.co.id
	Surabaya	CV. Multi Mas Jl. Raden Saleh 43A Kav. 18 Surabaya 60174	Tel. +62 31 5458589 Fax +62 31 5317220 sianhwa@sby.centrin.net.id http://www.cvmultimas.com
Ireland			
Sales Service	Dublin	Alperton Engineering Ltd. 48 Moyle Road Dublin Industrial Estate Glasnevin, Dublin 11	Tel. +353 1 830-6277 Fax +353 1 830-6458 http://www.alperton.ie info@alperton.ie
Israel			
Sales	Tel Aviv	Liraz Handasa Ltd. Ahofer Str 34B / 228 58858 Holon	Tel. +972 3 5599511 Fax +972 3 5599512 http://www.liraz-handasa.co.il office@liraz-handasa.co.il
Italy			
Assembly Sales Service	Solaro	SEW-EURODRIVE di R. Blicke & Co.s.a.s. Via Bernini,14 I-20020 Solaro (Milano)	Tel. +39 02 96 9801 Fax +39 02 96 79 97 81 http://www.sew-eurodrive.it sewit@sew-eurodrive.it
Ivory Coast			
Sales	Abidjan	SEW-EURODRIVE SARL Ivory Coast Rue des Pêcheurs, Zone 3 26 BP 916 Abidjan 26	Tel. +225 21 21 81 05 Fax +225 21 25 30 47 info@sew-eurodrive.ci http://www.sew-eurodrive.ci
Japan			
Assembly Sales Service	Iwata	SEW-EURODRIVE JAPAN CO., LTD 250-1, Shimoman-no, Iwata Shizuoka 438-0818	Tel. +81 538 373811 Fax +81 538 373814 http://www.sew-eurodrive.co.jp sewjapan@sew-eurodrive.co.jp
Kazakhstan			
Sales	Almaty	SEW-EURODRIVE LLP 291-291A, Tole bi street 050031, Almaty	Tel. +7 (727) 238 1404 Fax +7 (727) 243 2696 http://www.sew-eurodrive.kz sew@sew-eurodrive.kz
	Tashkent	SEW-EURODRIVE LLP Representative office in Uzbekistan 96A, Sharaf Rashidov street, Tashkent, 100084	Tel. +998 71 2359411 Fax +998 71 2359412 http://www.sew-eurodrive.uz sew@sew-eurodrive.uz
	Ulaanbaatar	SEW-EURODRIVE LLP Representative office in Mongolia Suite 407, Tushig Centre Seoul street 23, Sukhbaatar district, Ulaanbaatar 14250	Tel. +976-77109997 Fax +976-77109997 http://www.sew-eurodrive.mn sew@sew-eurodrive.mn
Kenya			
is supported by Tanzania.			

<b>Latvia</b>			
Sales	Riga	SIA Alas-Kuul Katlakalna 11C LV-1073 Riga	Tel. +371 6 7139253 Fax +371 6 7139386 <a href="http://www.alas-kuul.ee">http://www.alas-kuul.ee</a> <a href="mailto:info@alas-kuul.com">info@alas-kuul.com</a>
<b>Lebanon</b>			
Sales Lebanon	Beirut	Gabriel Acar & Fils sarl B. P. 80484 Bourj Hammoud, Beirut	Tel. +961 1 510 532 Fax +961 1 494 971 <a href="mailto:ssacar@inco.com.lb">ssacar@inco.com.lb</a>
Sales / Jordan / Kuwait / Saudi Arabia / Syria	Beirut	Middle East Drives S.A.L. (offshore) Sin El Fil. B. P. 55-378 Beirut	Tel. +961 1 494 786 Fax +961 1 494 971 <a href="http://www.medrives.com">http://www.medrives.com</a> <a href="mailto:info@medrives.com">info@medrives.com</a>
<b>Lithuania</b>			
Sales	Alytus	UAB Irseva Statybininku 106C LT-63431 Alytus	Tel. +370 315 79204 Fax +370 315 56175 <a href="http://www.sew-eurodrive.lt">http://www.sew-eurodrive.lt</a> <a href="mailto:irmantas@irseva.lt">irmantas@irseva.lt</a>
<b>Luxembourg</b>			
Assembly Sales Service	Brussels	SEW-EURODRIVE n.v./s.a. Researchpark Haasrode 1060 Evenementenlaan 7 BE-3001 Leuven	Tel. +32 16 386-311 Fax +32 16 386-336 <a href="http://www.sew-eurodrive.lu">http://www.sew-eurodrive.lu</a> <a href="mailto:info@sew-eurodrive.be">info@sew-eurodrive.be</a>
<b>Macedonia</b>			
Sales	Skopje	Boznos DOOEL Dime Anicin 2A/7A 1000 Skopje	Tel. +389 23256553 Fax +389 23256554 <a href="http://www.boznos.mk">http://www.boznos.mk</a>
<b>Madagascar</b>			
Sales	Antananarivo	Ocean Trade BP21bis. Andraharo Antananarivo 101 Madagascar	Tel. +261 20 2330303 Fax +261 20 2330330 <a href="mailto:oceanrabp@moov.mg">oceanrabp@moov.mg</a>
<b>Malaysia</b>			
Assembly Sales Service	Johor	SEW-EURODRIVE SDN BHD No. 95, Jalan Seroja 39, Taman Johor Jaya 81000 Johor Bahru, Johor West Malaysia	Tel. +60 7 3549409 Fax +60 7 3541404 <a href="mailto:sales@sew-eurodrive.com.my">sales@sew-eurodrive.com.my</a>
<b>Mexico</b>			
Assembly Sales Service	Quéretaro	SEW-EURODRIVE MEXICO SA DE CV SEM-981118-M93 Tequisquiapan No. 102 Parque Industrial Quéretaro C.P. 76220 Quéretaro, México	Tel. +52 442 1030-300 Fax +52 442 1030-301 <a href="http://www.sew-eurodrive.com.mx">http://www.sew-eurodrive.com.mx</a> <a href="mailto:scmexico@seweurodrive.com.mx">scmexico@seweurodrive.com.mx</a>
<b>Mongolia</b>			
Technical Office	Ulaanbaatar	SEW-EURODRIVE LLP Representative office in Mongolia Suite 407, Tushig Centre Seoul street 23, Sukhbaatar district, Ulaanbaatar 14250	Tel. +976-77109997 Fax +976-77109997 <a href="http://www.sew-eurodrive.mn">http://www.sew-eurodrive.mn</a> <a href="mailto:sew@sew-eurodrive.mn">sew@sew-eurodrive.mn</a>
<b>Morocco</b>			
Sales Service	Mohammedia	SEW-EURODRIVE SARL 2 bis, Rue Al Jahid 28810 Mohammedia	Tel. +212 523 32 27 80/81 Fax +212 523 32 27 89 <a href="http://www.sew-eurodrive.ma">http://www.sew-eurodrive.ma</a> <a href="mailto:sew@sew-eurodrive.ma">sew@sew-eurodrive.ma</a>

<b>Namibia</b>			
Sales	Swakopmund	DB Mining & Industrial Services Einstein Street Strauss Industrial Park Unit1 Swakopmund	Tel. +264 64 462 738 Fax +264 64 462 734 anton@dbminingnam.com
<b>Netherlands</b>			
Assembly Sales Service	Rotterdam	SEW-EURODRIVE B.V. Industrieweg 175 NL-3044 AS Rotterdam Postbus 10085 NL-3004 AB Rotterdam	Tel. +31 10 4463-700 Fax +31 10 4155-552 Service: 0800-SEWHELP <a href="http://www.sew-eurodrive.nl">http://www.sew-eurodrive.nl</a> info@sew-eurodrive.nl
<b>New Zealand</b>			
Assembly Sales Service	Auckland	SEW-EURODRIVE NEW ZEALAND LTD. P.O. Box 58-428 82 Greenmount drive East Tamaki Auckland	Tel. +64 9 2745627 Fax +64 9 2740165 <a href="http://www.sew-eurodrive.co.nz">http://www.sew-eurodrive.co.nz</a> sales@sew-eurodrive.co.nz
	Christchurch	SEW-EURODRIVE NEW ZEALAND LTD. 10 Settlers Crescent, Ferryroad Christchurch	Tel. +64 3 384-6251 Fax +64 3 384-6455 sales@sew-eurodrive.co.nz
<b>Nigeria</b>			
Sales	Lagos	EISNL Engineering Solutions and Drives Ltd Plot 9, Block A, Ikeja Industrial Estate ( Ogba Scheme) Adeniyi Jones St. End Off ACME Road, Ogba, Ikeja, Lagos	Tel. +234 1 217 4332 <a href="http://www.eisnl.com">http://www.eisnl.com</a> team.sew@eisnl.com
<b>Norway</b>			
Assembly Sales Service	Moss	SEW-EURODRIVE A/S Solgaard skog 71 N-1599 Moss	Tel. +47 69 24 10 20 Fax +47 69 24 10 40 <a href="http://www.sew-eurodrive.no">http://www.sew-eurodrive.no</a> sew@sew-eurodrive.no
<b>Pakistan</b>			
Sales	Karachi	Industrial Power Drives Al-Fatah Chamber A/3, 1st Floor Central Commercial Area, Sultan Ahmed Shah Road, Block 7/8, Karachi	Tel. +92 21 452 9369 Fax +92-21-454 7365 seweurodrive@cyber.net.pk
<b>Paraguay</b>			
Sales	Fernando de la Mora	SEW-EURODRIVE PARAGUAY S.R.L De la Victoria 112, Esquina nueva Asunción Departamento Central Fernando de la Mora, Barrio Bernardino	Tel. +595 991 519695 Fax +595 21 3285539 sewpy@sew-eurodrive.com.py
<b>Peru</b>			
Assembly Sales Service	Lima	SEW EURODRIVE DEL PERU S.A.C. Los Calderos, 120-124 Urbanizacion Industrial Vulcano, ATE, Lima	Tel. +51 1 3495280 Fax +51 1 3493002 <a href="http://www.sew-eurodrive.com.pe">http://www.sew-eurodrive.com.pe</a> sewperu@sew-eurodrive.com.pe
<b>Philippines</b>			
Sales	Makati	P.T. Cerna Corporation 4137 Ponte St., Brgy. Sta. Cruz Makati City 1205	Tel. +63 2 519 6214 Fax +63 2 890 2802 mech_drive_sys@ptcerna.com <a href="http://www.ptcerna.com">http://www.ptcerna.com</a>
<b>Poland</b>			
Assembly Sales Service	Łódź	SEW-EURODRIVE Polska Sp.z.o.o. ul. Techniczna 5 PL-92-518 Łódź	Tel. +48 42 293 00 00 Fax +48 42 293 00 49 <a href="http://www.sew-eurodrive.pl">http://www.sew-eurodrive.pl</a> sew@sew-eurodrive.pl
	Service	Tel. +48 42 293 0030 Fax +48 42 293 0043	24 Hour Service Tel. +48 602 739 739 (+48 602 SEW SEW) serwis@sew-eurodrive.pl

<b>Portugal</b>			
Assembly Sales Service	Coimbra	SEW-EURODRIVE, LDA. Apartado 15 P-3050-901 Mealhada	Tel. +351 231 20 9670 Fax +351 231 20 3685 <a href="http://www.sew-eurodrive.pt">http://www.sew-eurodrive.pt</a> <a href="mailto:info@sew-eurodrive.pt">info@sew-eurodrive.pt</a>
<b>Romania</b>			
Sales Service	Bucharest	Sialco Trading SRL str. Brazilia nr. 36 011783 Bucuresti	Tel. +40 21 230-1328 Fax +40 21 230-7170 <a href="mailto:sialco@sialco.ro">sialco@sialco.ro</a>
<b>Russia</b>			
Assembly Sales Service	St. Petersburg	ZAO SEW-EURODRIVE P.O. Box 36 RUS-195220 St. Petersburg	Tel. +7 812 3332522 / +7 812 5357142 Fax +7 812 3332523 <a href="http://www.sew-eurodrive.ru">http://www.sew-eurodrive.ru</a> <a href="mailto:sew@sew-eurodrive.ru">sew@sew-eurodrive.ru</a>
<b>Sambia</b>			
is supported by South Africa.			
<b>Senegal</b>			
Sales	Dakar	SENEMECA Mécanique Générale Km 8, Route de Rufisque B.P. 3251, Dakar	Tel. +221 338 494 770 Fax +221 338 494 771 <a href="http://www.senemeca.com">http://www.senemeca.com</a> <a href="mailto:senemeca@senemeca.sn">senemeca@senemeca.sn</a>
<b>Serbia</b>			
Sales	Belgrade	DIPAR d.o.o. Ustanicka 128a PC Košum, IV floor SRB-11000 Beograd	Tel. +381 11 347 3244 / +381 11 288 0393 Fax +381 11 347 1337 <a href="mailto:office@dipar.rs">office@dipar.rs</a>
<b>Singapore</b>			
Assembly Sales Service	Singapore	SEW-EURODRIVE PTE. LTD. No 9, Tuas Drive 2 Jurong Industrial Estate Singapore 638644	Tel. +65 68621701 Fax +65 68612827 <a href="http://www.sew-eurodrive.com.sg">http://www.sew-eurodrive.com.sg</a> <a href="mailto:sewsingapore@sew-eurodrive.com">sewsingapore@sew-eurodrive.com</a>
<b>Slovakia</b>			
Sales	Bratislava	SEW-Eurodrive SK s.r.o. Rybničná 40 SK-831 06 Bratislava	Tel. +421 2 33595 202, 217, 201 Fax +421 2 33595 200 <a href="http://www.sew-eurodrive.sk">http://www.sew-eurodrive.sk</a> <a href="mailto:sew@sew-eurodrive.sk">sew@sew-eurodrive.sk</a>
	Košice	SEW-Eurodrive SK s.r.o. Slovenská ulica 26 SK-040 01 Košice	Tel. +421 55 671 2245 Fax +421 55 671 2254 Mobile +421 907 671 976 <a href="mailto:sew@sew-eurodrive.sk">sew@sew-eurodrive.sk</a>
<b>Slovenia</b>			
Sales Service	Celje	Pakman - Pogonska Tehnika d.o.o. Ul. XIV. divizije 14 SLO - 3000 Celje	Tel. +386 3 490 83-20 Fax +386 3 490 83-21 <a href="mailto:pakman@siol.net">pakman@siol.net</a>
<b>South Africa</b>			
Assembly Sales Service	Johannesburg	SEW-EURODRIVE (PROPRIETARY) LIMITED Eurodrive House Cnr. Adcock Ingram and Aerodrome Roads Aeroton Ext. 2 Johannesburg 2013 P.O.Box 90004 Bertsham 2013	Tel. +27 11 248-7000 Fax +27 11 248-7289 <a href="http://www.sew.co.za">http://www.sew.co.za</a> <a href="mailto:info@sew.co.za">info@sew.co.za</a>
	Cape Town	SEW-EURODRIVE (PROPRIETARY) LIMITED Rainbow Park Cnr. Racecourse & Omuramba Road Montague Gardens Cape Town P.O.Box 36556 Chempet 7442	Tel. +27 21 552-9820 Fax +27 21 552-9830 Telex 576 062 <a href="mailto:bgriffiths@sew.co.za">bgriffiths@sew.co.za</a>

**South Africa**

Durban	SEW-EURODRIVE (PROPRIETARY) LIMITED 48 Prospecton Road Isipingo Durban P.O. Box 10433, Ashwood 3605	Tel. +27 31 902 3815 Fax +27 31 902 3826 cdejager@sew.co.za
Nelspruit	SEW-EURODRIVE (PROPRIETARY) LIMITED 7 Christie Crescent Vintonia P.O.Box 1942 Nelspruit 1200	Tel. +27 13 752-8007 Fax +27 13 752-8008 robermeyer@sew.co.za

**South Korea**

Assembly Sales Service	Ansan	SEW-EURODRIVE KOREA CO., LTD. 7, Dangjaengi-ro, Danwon-gu, Ansan-si, Gyeonggi-do, Zip 425-839	Tel. +82 31 492-8051 Fax +82 31 492-8056 <a href="http://www.sew-eurodrive.kr">http://www.sew-eurodrive.kr</a> master.korea@sew-eurodrive.com
	Busan	SEW-EURODRIVE KOREA CO., LTD. 28, Noksansandan 262-ro 50beon-gil, Gangseo-gu, Busan, Zip 618-820	Tel. +82 51 832-0204 Fax +82 51 832-0230

**Spain**

Assembly Sales Service	Bilbao	SEW-EURODRIVE ESPAÑA, S.L. Parque Tecnológico, Edificio, 302 E-48170 Zamudio (Vizcaya)	Tel. +34 94 43184-70 Fax +34 94 43184-71 <a href="http://www.sew-eurodrive.es">http://www.sew-eurodrive.es</a> sew.spain@sew-eurodrive.es
------------------------------	--------	----------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------

**Sri Lanka**

Sales	Colombo	SM International (Pte) Ltd 254, Galle Raod Colombo 4, Sri Lanka	Tel. +94 1 2584887 Fax +94 1 2582981
-------	---------	-----------------------------------------------------------------------	-----------------------------------------

**Swaziland**

Sales	Manzini	C G Trading Co. (Pty) Ltd PO Box 2960 Manzini M200	Tel. +268 2 518 6343 Fax +268 2 518 5033 engineering@cgtrading.co.sz
-------	---------	----------------------------------------------------------	----------------------------------------------------------------------------

**Sweden**

Assembly Sales Service	Jönköping	SEW-EURODRIVE AB Gnejsvägen 6-8 S-55303 Jönköping Box 3100 S-55003 Jönköping	Tel. +46 36 34 42 00 Fax +46 36 34 42 80 <a href="http://www.sew-eurodrive.se">http://www.sew-eurodrive.se</a> jonkoping@sew.se
------------------------------	-----------	---------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------

**Switzerland**

Assembly Sales Service	Basel	Alfred Imhof A.G. Jurastrasse 10 CH-4142 Münchenstein bei Basel	Tel. +41 61 417 1717 Fax +41 61 417 1700 <a href="http://www.imhof-sew.ch">http://www.imhof-sew.ch</a> info@imhof-sew.ch
------------------------------	-------	-----------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------

**Taiwan**

Sales	Taipei	Ting Shou Trading Co., Ltd. 6F-3, No. 267, Sec. 2 Tung Huw S. Road Taipei	Tel. +886 2 27383535 Fax +886 2 27368268 Telex 27 245 sewtwn@ms63.hinet.net <a href="http://www.tingshou.com.tw">http://www.tingshou.com.tw</a>
	Nan Tou	Ting Shou Trading Co., Ltd. No. 55 Kung Yeh N. Road Industrial District Nan Tou 540	Tel. +886 49 255353 Fax +886 49 257878 sewtwn@ms63.hinet.net <a href="http://www.tingshou.com.tw">http://www.tingshou.com.tw</a>

**Tanzania**

Sales	Daressalam	SEW-EURODRIVE PTY LIMITED TANZANIA Plot 52, Regent Estate PO Box 106274 Dar Es Salaam	Tel. +255 0 22 277 5780 Fax +255 0 22 277 5788 <a href="http://www.sew-eurodrive.co.tz">http://www.sew-eurodrive.co.tz</a> central.mailbox@sew.co.tz
-------	------------	------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Thailand</b>			
Assembly Sales Service	Chonburi	SEW-EURODRIVE (Thailand) Ltd. 700/456, Moo.7, Donhuaroh Muang Chonburi 20000	Tel. +66 38 454281 Fax +66 38 454288 sewthailand@sew-eurodrive.com
<b>Tunisia</b>			
Sales	Tunis	T. M.S. Technic Marketing Service Zone Industrielle Mghira 2 Lot No. 39 2082 Fouchana	Tel. +216 79 40 88 77 Fax +216 79 40 88 66 http://www.tms.com.tn tms@tms.com.tn
<b>Turkey</b>			
Assembly Sales Service	Kocaeli-Gebze	SEW-EURODRIVE Hareket Sistemleri San. Ve TIC. Ltd. Sti Gebze Organize Sanayi Böl. 400 Sok No. 401 41480 Gebze Kocaeli	Tel. +90 262 9991000 04 Fax +90 262 9991009 http://www.sew-eurodrive.com.tr sew@sew-eurodrive.com.tr
<b>Ukraine</b>			
Assembly Sales Service	Dnipropetrovsk	ООО «СЕВ-Евродрайв» ул.Рабочая, 23-В, офис 409 49008 Днепропетровск	Tel. +380 56 370 3211 Fax +380 56 372 2078 http://www.sew-eurodrive.ua sew@sew-eurodrive.ua
<b>United Arab Emirates</b>			
Sales Service	Sharjah	Copam Middle East (FZC) Sharjah Airport International Free Zone P.O. Box 120709 Sharjah	Tel. +971 6 5578-488 Fax +971 6 5578-499 copam_me@eim.ae
<b>Uruguay</b>			
Assembly Sales	Montevideo	SEW-EURODRIVE Uruguay, S. A. Jose Serrato 3569 Esquina Corumbe CP 12000 Montevideo	Tel. +598 2 21181-89 Fax +598 2 21181-90 sewuy@sew-eurodrive.com.uy
<b>USA</b>			
Production Assembly Sales Service	Southeast Region	SEW-EURODRIVE INC. 1295 Old Spartanburg Highway P.O. Box 518 Lyman, S.C. 29365	Tel. +1 864 439-7537 Fax Sales +1 864 439-7830 Fax Production +1 864 439-9948 Fax Assembly +1 864 439-0566 Fax Confidential/HR +1 864 949-5557 http://www.seweurodrive.com cslyman@seweurodrive.com
Assembly Sales Service	Northeast Region	SEW-EURODRIVE INC. Pureland Ind. Complex 2107 High Hill Road, P.O. Box 481 Bridgeport, New Jersey 08014	Tel. +1 856 467-2277 Fax +1 856 845-3179 csbridgeport@seweurodrive.com
	Midwest Region	SEW-EURODRIVE INC. 2001 West Main Street Troy, Ohio 45373	Tel. +1 937 335-0036 Fax +1 937 332-0038 cstroy@seweurodrive.com
	Southwest Region	SEW-EURODRIVE INC. 3950 Platinum Way Dallas, Texas 75237	Tel. +1 214 330-4824 Fax +1 214 330-4724 csdallas@seweurodrive.com
	Western Region	SEW-EURODRIVE INC. 30599 San Antonio St. Hayward, CA 94544	Tel. +1 510 487-3560 Fax +1 510 487-6433 cshayward@seweurodrive.com
Additional addresses for service in USA provided on request!			
<b>Uzbekistan</b>			
Technical Office	Tashkent	SEW-EURODRIVE LLP Representative office in Uzbekistan 96A, Sharaf Rashidov street, Tashkent, 100084	Tel. +998 71 2359411 Fax +998 71 2359412 http://www.sew-eurodrive.uz sew@sew-eurodrive.uz

**Venezuela**

Assembly Sales Service	Valencia	SEW-EURODRIVE Venezuela S.A. Av. Norte Sur No. 3, Galpon 84-319 Zona Industrial Municipal Norte Valencia, Estado Carabobo	Tel. +58 241 832-9804 Fax +58 241 838-6275 <a href="http://www.sew-eurodrive.com.ve">http://www.sew-eurodrive.com.ve</a> <a href="mailto:ventas@sew-eurodrive.com.ve">ventas@sew-eurodrive.com.ve</a> <a href="mailto:sewfinanzas@cantv.net">sewfinanzas@cantv.net</a>
------------------------------	----------	------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

**Vietnam**

Sales	Ho Chi Minh City	Nam Trung Co., Ltd Huế - South Vietnam / Construction Materials 250 Binh Duong Avenue, Thu Dau Mot Town, Binh Duong Province HCM office: 91 Tran Minh Quyen Street District 10, Ho Chi Minh City	Tel. +84 8 8301026 Fax +84 8 8392223 <a href="mailto:khánh-nguyen@namtrung.com.vn">khánh-nguyen@namtrung.com.vn</a> <a href="http://www.namtrung.com.vn">http://www.namtrung.com.vn</a>
	Hanoi	MICO LTD Quảng Trị - North Vietnam / All sectors except Construction Materials 8th Floor, Ocean Park Building, 01 Dao Duy Anh St, Ha Noi, Viet Nam	Tel. +84 4 39386666 Fax +84 4 3938 6888 <a href="mailto:nam_ph@micogroup.com.vn">nam_ph@micogroup.com.vn</a> <a href="http://www.micogroup.com.vn">http://www.micogroup.com.vn</a>

## Index

### Numerical

7-segment display ..... 21, 101

### A

AC 400 V output (SNI)  
     Connection ..... 62

Assembly  
     Safety notes ..... 10  
     Via through bores ..... 31

### B

Brake module BST, see safety-related BST brake module ..... 19  
 Brake, see Motor with brake ..... 56  
 Braking contactor, see contactor ..... 36  
 BST, see safety-related BST brake module ..... 19

### C

Cable  
     AC 400 V output ..... 66  
     Cross sections ..... 41  
     see also connection .... 56, 57, 66, 68, 76, 82, 88  
     see also hybrid cables ..... 118  
     See hybrid cable[Cable:zzz] ..... 119  
     Structure ..... 48  
 Cable cross section ..... 41  
 Cable routing ..... 36  
 Cable type "D" ..... 118, 119  
 CAN bus  
     Cable ..... 76  
 CDF, see cyclic duration factor ..... 99  
 Communication and control unit  
     Technical data ..... 116  
 Components  
     Encoder evaluation ..... 19  
     Frequency inverter ..... 19  
     Safety-related BST brake module ..... 19  
     SD memory card ..... 21  
     Service unit ..... 21  
 Connection  
     Safety notes ..... 10  
     AC 400 V output (SNI) ..... 62  
     Digital inputs, safety-related ..... 91, 92  
     Digital inputs/outputs ..... 85, 86

Display ..... 46  
 Distance encoder ..... 72  
 Ethernet service interface ..... 79  
 Interface box ..... 51, 52  
 Motor encoder ..... 68  
 Motor with brake ..... 56  
 PROFINET ..... 80  
 Safety relay ..... 89  
 Safety-related digital outputs ..... 93, 94  
 Connection block label ..... 15  
 Connection components  
     CAN terminating resistor ..... 77  
     CAN T-piece ..... 77  
     Jumper plug ..... 90  
     Jumper plug energy management ..... 55  
     PZO00A-SAZIR0-C000-02 display unit ..... 78  
     Y adapter ..... 86  
 Connections ..... 46  
 Contactor ..... 36  
 Controller ..... 20  
 Cooling ..... 27  
 Copyright notice ..... 7  
 Cyclic duration factor ..... 99

### D

DC 24 V input for backup voltage supply  
     Cable ..... 88  
 Derating ..... 39  
 Designation  
     Short name of the unit ..... 13  
 Device status ..... 107  
 Digital inputs, safety-related  
     Connection ..... 91, 92  
 Digital inputs/outputs  
     Cable ..... 82  
     Connection ..... 85, 86  
 Disconnection, safe ..... 11  
 Display  
     Connections ..... 46  
 Distance encoder  
     Connection ..... 72  
     HIPERFACE® ..... 72  
     HTL ..... 72  
     RS422 ..... 72

Sin/cos .....	72
SSI .....	72
TTL .....	72
Duty cycles .....	99

## E

Electrical connection .....	10
Electrical hazard .....	41
Electrical installation .....	36
Electromagnetic compatibility (EMC) .....	36
Embedded safety notes .....	6
EMC (electromagnetic compatibility) .....	36
EN 61800-5-1 .....	41
EN 1037 .....	23
EN 60721-3-3 .....	113
EN 61800-3 .....	113
EN 61800-5-2 .....	23
EN ISO 13849-1 .....	23
Encoder	
Change of the .....	109
Encoder replacement .....	109
Encoder, see motor encoder .....	68
Equipotential bonding .....	43
Error information .....	110
Error messages .....	101
Ethernet engineering	
See Ethernet service interface .....	79
Ethernet interface .....	21
Ethernet service interface	
Connection .....	79
Exclusion of liability .....	6
Extended storage .....	111

## F

Fastening	
From the back .....	33
From the front .....	32
With mounting brackets .....	28
Fault memory .....	110
Fieldbus .....	19
FO1 .....	107
FO2 .....	107
Frequency inverter	
Component description .....	19
Safety functions .....	23
Function Units .....	17

Functional safety technology	
Applicable standards .....	23
Integrated safety technology .....	23
Safety note .....	9

## G

Ground connection .....	41
Grounded star point .....	36
Grounding .....	43

## H

Hazard symbols	
Meaning .....	5
HIPERFACE®, see motor encoder .....	68
HTL, see motor encoder .....	68
Hybrid cable	
Cable design .....	118, 119
Cable type "D" .....	118, 119

## I

IEC 61800-5-2 .....	23
Inputs, see digital inputs .....	91, 92
Installation	
Cable routing .....	36
Contactor .....	36
Cooling .....	27
Electrical .....	36
Electromagnetic compatibility (EMC) .....	36
Ground connection .....	41
Installation topology .....	38
Low-voltage supply systems .....	36
Mechanical .....	24
Minimum clearance .....	25
Shielding .....	39
Unit output .....	39
Waste heat .....	27
Installation altitude .....	39
Installation instructions	
Derating .....	39
Installation altitude .....	39
Installation topology .....	38
Insulation monitor .....	36
Interface	
Ethernet .....	21
Fieldbus .....	19
Service .....	21

Inverter status .....	104, 105
Inverter, see frequency inverter .....	19
IT system.....	36

## L

LED POF .....	107
LED Push-pull SCRJ.....	107
Line contactor, see contactor .....	36
Line fuse.....	44
Line protection.....	44

## M

Mechanical installation .....	24
Memory card	
Unit replacement.....	109
Memory card cover .....	21
Minimum clearance .....	25
Installation, horizontal .....	27
Installation, vertical .....	26
Minimum distances .....	25
Mobile application .....	42
Motor encoder	
Connection.....	68
Motor with brake	
Connection.....	57
Mounting brackets	
Use.....	28
Mounting position .....	24
MOVI-DPS .....	111
MOVITRANS®	
PE connection.....	42
Protective measures against electrical hazards .....	41

## N

Nameplate.....	15
Nomenclature.....	13
Notes	
Designation in the documentation.....	5
Meaning of the hazard symbols .....	5

## O

OMH41B-T2, see SD memory card .....	13
Operation	
Duty cycles.....	99
Error messages.....	101
Safety notes .....	11

Status LED.....	106
Status messages .....	101
Other applicable documentation .....	7
Outputs, see digital outputs.....	93, 94

## P

Part numbers	
Grounding kit.....	13
MOVIPRO® .....	13
SD memory card .....	13
PE connection .....	41, 42
POF, see push-pull SCRJ .....	107
Power circuit breaker .....	18
Power converter .....	111
Power section	
Error information .....	110
Fault memory .....	110
Processing unit.....	20
Product names .....	7
PROFINET .....	19
Connection.....	80
PROFIsafe option S11 .....	20
Pulse code measuring process.....	36
Push-pull SCRJ.....	107

## R

Repairs.....	101, 108
Reset.....	110
Residual current device.....	44
Rights to claim under limited warranty .....	6

## S

S11, see PROFIsafe option S11 .....	20
Safe disconnection.....	11
Safety concept .....	23
Safety functions.....	9, 23
Safety functions, see functional safety technology .....	23
Safety notes	
Assembly .....	10
Designation in the documentation.....	5
General information .....	8
Meaning of the hazard symbols .....	5
Preliminary information .....	8
Structure of embedded .....	6
Structure of the section-related .....	5

Safety relay	
Connection .....	89
Safety technology	
Detailed information .....	23
Safety-related BST brake module	
Component description .....	19
Safety-related digital outputs	
Connection .....	93, 94
Safety-related, see digital inputs .....	91, 92
Safety-related, see digital outputs .....	93, 94
Scope of delivery .....	13
SD card	
Unit replacement .....	109
SD memory card .....	97
Part number .....	13
Position on the unit .....	21
Section-related safety notes .....	5
Service	
Device status .....	107
Inverter status .....	104, 105
Unit replacement .....	108, 109
Unit status .....	106
Service cover plate .....	21
Service interface .....	21
Service unit .....	21
Shielding .....	39
Short designation .....	13
Shutdown .....	111
Shutting down the unit .....	111
Signal words in the safety notes .....	5
Sin/Cos, see motor encoder .....	68
Startup	
Notes .....	95
Safety notes .....	11
Status display	
Component description .....	21
Status LED .....	106
Status messages .....	101
STO, see safety relay .....	89
Storage .....	111
<b>T</b>	
Target group .....	9
Technical data	
Cable type "D" .....	118, 119
Communication and control unit .....	116

Hybrid cable .....	118, 119
TN system .....	36
Trademarks .....	7
Transportation .....	10
TT system .....	36
TTL, see motor encoder .....	68
Type designation .....	13

## U


Unit	
Shutting down the unit .....	111
Unit output .....	39
Unit overview .....	14
Unit replacement .....	108
Unit status .....	106


## W


Waste disposal .....	112
Waste heat .....	27
Wiring diagrams .....	46



## X

X1213 .....	49
X1241_1	
Connection cables, available .....	62
X1241_2	
Connection cables, available .....	62
X1271 .....	54
X2016 .....	56
X2241 .....	62
X2303 .....	60
X2371 .....	66
X3011 .....	68
X3222 .....	72
X4101 .....	75
X4223 .....	79
X4232 .....	80
X5001 .....	81, 82
X5102_1 .....	85
X5102_2 .....	86
X5111 .....	88
X5502 .....	89
X5601 .....	91, 92
X5611 .....	93, 94











**SEW-EURODRIVE**  
Driving the world

**SEW**  
**EURODRIVE**

SEW-EURODRIVE GmbH & Co KG  
P.O. Box 3023  
76642 BRUCHSAL  
GERMANY  
Phone +49 7251 75-0  
Fax +49 7251 75-1970  
sew@sew-eurodrive.com  
→ [www.sew-eurodrive.com](http://www.sew-eurodrive.com)