



SEW
EURODRIVE

Assembly and Operating Instructions



Explosion-Proof Gear Units

R..7, F..7, K..7, K..9, S..7, SPIROPLAN® W Series



Table of contents

| | | |
|----------|---|-----------|
| 1 | General information..... | 6 |
| 1.1 | About this documentation | 6 |
| 1.2 | Structure of the safety notes | 6 |
| 1.3 | Rights to claim under limited warranty | 7 |
| 1.4 | Product names and trademarks | 7 |
| 1.5 | Copyright notice | 8 |
| 2 | Safety notes | 9 |
| 2.1 | Preliminary information | 9 |
| 2.2 | Duties of the user | 9 |
| 2.3 | Target group | 9 |
| 2.4 | Designated use | 10 |
| 2.5 | Other applicable documentation | 11 |
| 2.6 | Safety note for working in potentially explosive areas | 11 |
| 2.7 | Transportation/storage | 11 |
| 2.8 | Installation/assembly | 12 |
| 2.9 | Startup/operation | 12 |
| 2.10 | Inspection/maintenance | 12 |
| 3 | Gear unit structure | 13 |
| 3.1 | Basic structure of helical gear units R..07 – R..167 | 13 |
| 3.2 | Basic structure of parallel-shaft helical gear units F..27 – F..157 | 14 |
| 3.3 | Basic structure of helical-bevel gear units K..19/K..29 | 15 |
| 3.4 | Basic structure of helical-bevel gear units K..39/K..49 | 17 |
| 3.5 | Basic structure of helical-bevel gear units K..37 – K..187 | 18 |
| 3.6 | Basic structure of helical-worm gear units S..37 – S..97 | 19 |
| 3.7 | Basic structure of SPIROPLAN® gear units W..10 – W..30 | 20 |
| 3.8 | Basic structure of SPIROPLAN® gear units W..37 – W..47 | 21 |
| 3.9 | Nameplate/type designation | 22 |
| 3.10 | Type designation | 25 |
| 4 | Mechanical installation | 29 |
| 4.1 | General information | 29 |
| 4.2 | Gear units/gearmotors in explosion-proof design II2GD and II3GD | 30 |
| 4.3 | Prerequisites for installation | 31 |
| 4.4 | Required tools/resources | 32 |
| 4.5 | Installation tolerances | 32 |
| 4.6 | Installing the gear unit | 33 |
| 4.7 | Gear unit with solid shaft | 43 |
| 4.8 | Torque arms for shaft-mounted gear units | 45 |
| 4.9 | Mounting shaft-mounted gear units with splined hollow shaft | 51 |
| 4.10 | Shaft-mounted gear unit with keyway | 52 |
| 4.11 | Shaft-mounted gear unit with shrink disk | 57 |
| 4.12 | Shaft-mounted gear units with TorqLOC® | 60 |
| 4.13 | Cover | 73 |
| 4.14 | Coupling of AM adapter | 74 |

| | | |
|-----------|---|------------|
| 4.15 | AQ. adapter coupling | 78 |
| 4.16 | Adapter with AR slip clutch | 82 |
| 4.17 | AD input shaft assembly | 84 |
| 4.18 | Accessory equipment..... | 88 |
| 5 | Startup | 93 |
| 5.1 | Checklists..... | 94 |
| 5.2 | Inverter-operated gearmotors | 96 |
| 5.3 | Checking the oil level | 96 |
| 5.4 | Pseudo-leakage at shaft seals..... | 96 |
| 5.5 | Measuring surface and oil temperature | 97 |
| 5.6 | Helical-worm gear units and SPIROPLAN® W gear units | 98 |
| 5.7 | Helical/parallel-shaft helical/helical-bevel gear units..... | 99 |
| 5.8 | Gear units with backstop..... | 99 |
| 5.9 | Speed monitoring..... | 101 |
| 5.10 | Installation and adjustment of the WEX speed monitor | 101 |
| 5.11 | Installation of the voltage encoder | 105 |
| 6 | Inspection/maintenance..... | 107 |
| 6.1 | Wearing parts..... | 109 |
| 6.2 | Inspection/maintenance intervals..... | 111 |
| 6.3 | Lubricant change intervals | 112 |
| 6.4 | Maintenance of AL/AM/AQ. adapter | 112 |
| 6.5 | AR adapter maintenance | 113 |
| 6.6 | Maintenance of AR adapter with slip clutch | 113 |
| 6.7 | AD input shaft assembly maintenance..... | 117 |
| 6.8 | Inspection/maintenance for the gear unit..... | 118 |
| 7 | Mounting positions..... | 136 |
| 7.1 | Designation of the mounting positions | 136 |
| 7.2 | Churning losses and thermal rating | 137 |
| 7.3 | Change of mounting position | 137 |
| 7.4 | Universal mounting position M0..... | 138 |
| 7.5 | Mounting position MX | 138 |
| 7.6 | Mounting position sheets | 139 |
| 8 | Technical data..... | 174 |
| 8.1 | Extended storage..... | 174 |
| 8.2 | Lubricants | 176 |
| 9 | Malfunctions and remedies | 189 |
| 9.1 | Gear units | 190 |
| 9.2 | AM/AQ./AL adapters | 191 |
| 9.3 | AD input shaft assembly | 191 |
| 9.4 | Adapter with AR slip clutch | 191 |
| 9.5 | Service | 192 |
| 9.6 | Waste disposal..... | 192 |
| 10 | Declarations of conformity | 193 |
| 10.1 | Gear units in category 2G and 2D with AM., AQ., AL., AD., AR.. adapter..... | 193 |

| | | |
|-----------|---|------------|
| 10.2 | Gear units in category 2G and 2D with AR., AM., AQ., AL., AD.. adapter..... | 194 |
| 11 | Address list | 195 |
| | Index | 206 |

1 General information

1.1 About this documentation

The current version of the documentation is the original.

This documentation is an integral part of the product. The documentation is written for all employees who assemble, install, start up, and service this product.

Make sure this documentation is accessible and legible. Ensure that persons responsible for the machinery and its operation as well as persons who work on the product independently have read through the documentation carefully and understood it. If you are unclear about any of the information in this documentation or require further information, contact SEW-EURODRIVE.

1.2 Structure of the safety notes

1.2.1 Meaning of signal words

The following table shows the graduation and meaning of the signal words for safety notes.

| Signal word | Meaning | Consequences if disregarded |
|--|--|--|
| ▲ DANGER | Imminent hazard | Severe or fatal injuries |
| ▲ WARNING | Possible dangerous situation | Severe or fatal injuries |
| ▲ CAUTION | Possible dangerous situation | Minor injuries |
| NOTICE | Possible damage to property | Damage to the product or its environment |
| INFORMATION ON EXPLOSION PROTECTION | Important information about explosion protection | |
| INFORMATION | Useful information or tip: Simplifies handling of the product. | |

1.2.2 Structure of section-related safety notes

Section-related safety notes do not apply to a specific action but to several actions pertaining to one subject. The hazard symbols used either indicate a general hazard or a specific hazard.

This is the formal structure of a safety note for a specific section:



SIGNAL WORD







Type and source of hazard.

Possible consequence(s) if disregarded.

- Measure(s) to prevent the hazard.

Meaning of the hazard symbols

The hazard symbols in the safety notes have the following meaning:

| Hazard symbol | Meaning |
|---|---|
|  | General hazard |
|  | Warning of dangerous electrical voltage |
|  | Warning of hot surfaces |
|  | Warning of risk of crushing |
|  | Note on explosion protection |
|  | Warning of automatic restart |

1.2.3 Structure of embedded safety notes

Embedded safety notes are directly integrated into the instructions just before the description of the dangerous action.

This is the formal structure of an embedded safety note:

▲ SIGNAL WORD Type and source of hazard. Possible consequence(s) if disregarded. Measure(s) to prevent the hazard.

1.3 Rights to claim under limited warranty

Read the information in this documentation. This is essential for fault-free operation and fulfillment of any rights to claim under limited warranty. Read the documentation before you start working with the product.

1.4 Product names and trademarks

The brands and product names in this documentation are trademarks or registered trademarks of their respective titleholders.

1.5 Copyright notice

© 2018 SEW-EURODRIVE. All rights reserved.

Copyright law prohibits the unauthorized reproduction, modification, distribution, and use of this document, in whole or in part.

2 Safety notes

2.1 Preliminary information

The following general safety notes serve the purpose of preventing injury to persons and damage to property. They primarily apply to the use of products described in this documentation. If you use additional components, also observe the relevant warning and safety notes.

2.2 Duties of the user

As the user, you must ensure that the basic safety notes are observed and complied with. Make sure that persons responsible for the machinery and its operation as well as persons who work on the device independently have read through the documentation carefully and understood it.

As the user, you must ensure that all of the work listed in the following is carried out only by qualified specialists:

- Setup and installation
- Installation and connection
- Startup
- Maintenance and repairs
- Shutdown
- Disassembly

Ensure that the persons who work on the product pay attention to the following regulations, conditions, documentation, and information:

- National and regional safety and accident prevention regulations
- Warning and safety signs on the product
- All other relevant project planning documents, installation and startup instructions, and wiring diagrams
- Do not assemble, install or operate damaged products
- All system-specific specifications and conditions

Ensure that systems in which the product is installed are equipped with additional monitoring and protection devices. Observe the applicable safety regulations and legislation governing technical work equipment and accident prevention regulations.

2.3 Target group

Specialist for
mechanical work

Any mechanical work may only be performed by adequately qualified specialists. Specialists in the context of this documentation are persons familiar with the design, mechanical installation, troubleshooting, and maintenance of the product who possess the following qualifications:

- Qualification in the mechanical area in accordance with the national regulations
- Familiarity with this documentation

| | |
|--------------------------------------|--|
| Specialist for electrotechnical work | Any electrotechnical work may only be performed by electrically skilled persons with a suitable education. Electrically skilled persons in the context of this documentation are persons familiar with electrical installation, startup, troubleshooting, and maintenance of the product who possess the following qualifications: <ul style="list-style-type: none"> • Qualification in the electrotechnical area in accordance with the national regulations • Familiarity with this documentation |
| Additional qualification | In addition to that, these persons must be familiar with the valid safety regulations and laws, as well as with the requirements of the standards, directives, and laws specified in this documentation. The persons must have the express authorization of the company to operate, program, parameterize, label, and ground units, systems, and circuits in accordance with the standards of safety technology. |
| Instructed persons | All work in the areas of transportation, storage, operation and waste disposal must be carried out by persons who are trained appropriately. The purpose of the instruction is that the persons are capable of performing the required tasks and work steps in a safe and correct manner. |

2.4 Designated use

The gear units are intended for industrial systems and may only be used in accordance with the information provided in the technical documentation by SEW-EURODRIVE and the information given on the nameplate. They meet the requirements set forth in Directive 2014/34/EU and comply with the applicable standards and regulations.

The gear units are components for the installation in machines and plants according to the 2006/42/EC Machinery Directive. Within the scope of the Directive, you must not operate the machine in the designated fashion until you have established that the end product complies with Machinery Directive 2006/42/EC.

Optional equipment

In addition to the general installation guidelines, the following regulations in accordance with German operating safety regulations (BetrSichV) or other national regulations must be observed for connecting additional devices:

- EN ISO 80079-36 Potentially explosive atmosphere - part 36: Non-electrical equipment for use in potentially explosive atmospheres – Basics and requirements
- EN ISO 80079-37 Potentially explosive atmosphere - part 37: Non-electrical equipment for explosive atmospheres - Non-electrical type of protection constructional safety "c", control of ignition sources "b", liquid immersion "k"
- EN 50281-2-1 Electrical apparatus for use in the presence of combustible dust - Part 2-1: Test methods; methods for determining the minimum ignition temperatures of dust
- EN 60079-0 Potentially explosive areas – part 0: General requirements
- EN 60079-1 Potentially explosive areas – part 1: Device protection by flameproof enclosure "d"
- EN 60079-7 Potentially explosive areas – part 7: Equipment protection by increased safety "e"
- EN 60079-11 Potentially explosive areas – part 11: Device protection by intrinsic safety "i"
- EN 60079-14 Potentially explosive areas – part 14: Project planning, selection and setup of electrical machinery.

- EN 60079-15 Potentially explosive areas – part 15: Equipment protection by protection type "n"
- EN 60079-17 Potentially explosive areas – part 17: Testing and maintenance of electrical machinery
- EN 60079-31 Potentially explosive areas – part 31: Equipment dust ignition protection by housing "t"
- DIN VDE 105-9 "Operating electrical equipment" or other national regulations
- DIN VDE 0100 "Erection of power installations with rated voltages below 1000 V" or other national regulations

Technical data and information on the permitted conditions are given on the nameplate and in the documentation; they have to be observed under all circumstances.

2.5 Other applicable documentation


Observe the corresponding documentation for all further components.

2.6 Safety note for working in potentially explosive areas

Note that explosive gas mixtures or concentrations of dust can lead to explosions in conjunction with hot, live, or moving parts of electrical machinery.


2.7 Transportation/storage

Inspect the shipment for damage as soon as you receive the delivery. Inform the shipping company immediately about any damage. If the product is damaged, it must not be assembled, installed or started up.

Observe the storage information on climatic conditions as given in chapter "Storage conditions" (→  174).

If the product is not immediately installed, it must be stored in a dry and dust-free location. The product can be stored for up to 9 months without requiring any special measures before startup. Do not store the product outdoors.

The permissible storage temperature is -30 °C to +50 °C.

For storage periods longer than 9 months, SEW-EURODRIVE recommends the "Extended storage" design. For further information, refer to chapter "Extended storage" (→  174).

The installed lifting eyebolts are in accordance with DIN 580. Observe the loads and regulations specified there. The tension force vector of the slings must not exceed a 45° angle in accordance with DIN 580.

If the product has several lifting eyes or lifting eyebolts, then you should use all lifting eyes and lifting eyebolts for attaching transport ropes. Tighten lifting eyebolts. The lifting eyes or lifting eyebolts are designed to carry only the weight of the product. Do not apply any additional loads.

The gear units K..167 and K..187 have no lifting eyes and are supplied without lifting eyebolts. Use alternative, suitable slings.

Do not store the gearmotor on the fan guard.

Use suitable, sufficiently rated and reusable handling equipment.

2.8 Installation/assembly

Ensure that the product is installed and cooled according to the regulations in the documentation.


Protect the product from strong mechanical strain. The product and its mounting parts must never protrude into the path of persons or vehicles. Ensure that components are not deformed, particularly during transportation and handling. Electric components must not be mechanically damaged or destroyed.

The following applications are prohibited unless the device is explicitly designed for such use:

- Operation in applications with impermissibly high mechanical vibration and shock loads in excess of the regulations stipulated in EN 61800-5-1
- Use in environments with harmful oils, acids, gases, vapors, dust, radiation, etc.

Observe the danger due to static overdetermination. Gear units with foot (e.g. KA19/29B, KA127/157B or FA127/157B) must not be fastened via the torque arm and the foot plate at the same time. Gearmotors must also not be fastened to the foot plate of the gear unit (e.g. KA19/29B, KA127/157B or FA127/157B, R gear unit with foot-mounted motor) and the foot plate of the motor at the same time.

2.9 Startup/operation

Check the oil level before startup as described in chapter "Inspection/maintenance" (→  107).


Check that the direction of rotation is correct in the **decoupled** state. Listen out for unusual grinding noises as the shaft rotates.

Secure the keys for the test run without output elements.

Do not deactivate monitoring and protection devices even for a test run.

Switch off the gearmotor if in doubt whenever changes occur in relation to normal operation (e.g. increased temperatures, unusual noises, vibrations). Determine the cause. It may be necessary to contact SEW-EURODRIVE.

2.10 Inspection/maintenance

Observe the information in chapter "Inspection/maintenance" (→  107).


3 Gear unit structure

INFORMATION




The following figures are block diagrams. Their purpose is only to make it easier to assign components to the spare parts lists. Discrepancies may occur depending on the gear unit size and version.

3.1 Basic structure of helical gear units R..07 – R..167



18014398528676235


| | | | |
|----------------------|------------------------|------------------------|------------|
| [1] Pinion | [19] Key | [42] Rolling bearing | [507] Shim |
| [2] Gear | [20] Breather valve | [43] Key | [508] Shim |
| [3] Pinion shaft | [22] Gear unit housing | [45] Rolling bearing | [515] Shim |
| [4] Gear | [24] Eyebolt | [47] Retaining ring | [516] Shim |
| [5] Pinion shaft | [25] Rolling bearing | [59] Screw plug | [517] Shim |
| [6] Gear | [30] Rolling bearing | [88] Retaining ring | [521] Shim |
| [7] Output shaft | [31] Key | [100] Inspection cover | [522] Shim |
| [8] Key | [32] Spacer tube | [101] Hex head screw | [523] Shim |
| [9] Oil seal | [34] Rolling bearing | [102] Gasket | |
| [11] Rolling bearing | [37] Rolling bearing | [131] Closing cap | |
| [12] Retaining ring | [39] Retaining ring | [181] Closing cap | |
| [17] Spacer tube | [41] Retaining ring | [506] Shim | |

3.2 Basic structure of parallel-shaft helical gear units F..27 – F..157

9007199274039051

| | | | |
|----------------------|------------------------|------------------------|------------|
| [1] Pinion | [22] Gear unit housing | [91] Retaining ring | [506] Shim |
| [2] Gear | [25] Rolling bearing | [92] Washer | [507] Shim |
| [3] Pinion shaft | [30] Rolling bearing | [93] Lock washer | [508] Shim |
| [4] Gear | [31] Key | [94] Hex head screw | [515] Shim |
| [5] Pinion shaft | [32] Spacer tube | [100] Inspection cover | [516] Shim |
| [6] Gear | [37] Rolling bearing | [101] Hex head screw | [517] Shim |
| [7] Hollow shaft | [39] Retaining ring | [102] Gasket | [521] Shim |
| [9] Oil seal | [41] Retaining ring | [131] Closing cap | [522] Shim |
| [11] Rolling bearing | [42] Rolling bearing | [160] Closing plug | [523] Shim |
| [14] Hex head screw | [43] Key | [161] Closing cap | |
| [16] Output flange | [45] Rolling bearing | [165] Closing plug | |
| [17] Spacer tube | [59] Screw plug | [181] Closing cap | |
| [19] Key | [81] Shield ring | [183] Oil seal | |
| [20] Breather valve | [88] Retaining ring | | |


3.3 Basic structure of helical-bevel gear units K..19/K..29



9007206676351499

| | | | |
|-------------------------------|-----------------------------|-----------------------|------------|
| [1] Pinion | [26] Housing of 1st stage | [94] Hex head screw | [520] Shim |
| [2] Gear | [36] Stud | [95] Protection cap | [521] Shim |
| [5] Pinion shaft | [42] Tapered roller bearing | [115] Retaining ring | [522] Shim |
| [6] Gear | [43] Key | [141] Bushing | [523] Shim |
| [7] Hollow shaft | [44] Seal | [159] Closing plug | [530] Shim |
| [9] Oil seal | [45] Tapered roller bearing | [163] Supporting ring | [531] Shim |
| [11] Rolling bearing | [50] Bevel gear set | [167] Closing plug | [532] Shim |
| [12] Retaining ring | [59] Screw plug | [168] Protection cap | [536] Shim |
| [19] Key | [88] Retaining ring | [183] Oil seal | [537] Shim |
| [20] Breather valve | [91] Retaining ring | [193] Closing plug | [538] Shim |
| [22] Gear unit housing | [92] Washer | [518] Shim | |
| [25] Deep groove ball bearing | [93] Lock washer | [519] Shim | |


3.4 Basic structure of helical-bevel gear units K..39/K..49



14457456395

| | | | |
|-------------------------------|-------------------------------|------------------------|------------|
| [1] Pinion | [12] Retaining ring | [48] Supporting ring | [518] Shim |
| [2] Gear | [17] Spacer tube | [50] Bevel gear set | [519] Shim |
| [5] Pinion shaft | [19] Key | [59] Screw plug | [520] Shim |
| [6] Gear | [20] Breather valve | [88] Retaining ring | [521] Shim |
| [7] Hollow shaft | [22] Gear unit housing | [89] Closing cap | [522] Shim |
| [8] Key | [25] Deep groove ball bearing | [100] Inspection cover | [523] Shim |
| [9] Oil seal | [42] Tapered roller bearing | [101] Hex head screw | [536] Shim |
| [10] Oil seal | [43] Key | [102] Gasket | [537] Shim |
| [11] Deep groove ball bearing | [45] Tapered roller bearing | [113] Slotted nut | [538] Shim |


3.5 Basic structure of helical-bevel gear units K..37 – K..187



9007199274042123


| | | | |
|------------------------|------------------------|-------------------------|------------|
| [1] Pinion | [25] Rolling bearing | [102] Gasket | [522] Shim |
| [2] Gear | [30] Rolling bearing | [113] Slotted nut | [523] Shim |
| [3] Pinion shaft | [31] Key | [114] Multi-tang washer | [533] Shim |
| [4] Gear | [37] Rolling bearing | [116] Thread lock | [534] Shim |
| [5] Pinion shaft | [39] Retaining ring | [119] Spacer tube | [535] Shim |
| [6] Gear | [42] Rolling bearing | [131] Closing cap | [536] Shim |
| [7] Output shaft | [43] Key | [132] Retaining ring | [537] Shim |
| [8] Key | [45] Rolling bearing | [133] Supporting ring | [538] Shim |
| [9] Oil seal | [59] Screw plug | [135] Shield ring | [542] Shim |
| [11] Rolling bearing | [83] Shield ring | [137] Supporting ring | [543] Shim |
| [12] Retaining ring | [84] Shield ring | [161] Closing cap | [544] Shim |
| [17] Spacer tube | [88] Retaining ring | [506] Shim | |
| [19] Key | [89] Closing cap | [507] Shim | |
| [20] Breather valve | [100] Inspection cover | [508] Shim | |
| [22] Gear unit housing | [101] Hex head screw | [521] Shim | |

3.6 Basic structure of helical-worm gear units S..37 – S..97



18014398528786187


| | | | | | | | |
|------|-----------------|------|-------------------|-------|-----------------|-------|------|
| [1] | Pinion | [20] | Breather valve | [88] | Retaining ring | [518] | Shim |
| [2] | Gear | [22] | Gear unit housing | [89] | Closing cap | [519] | Shim |
| [5] | Worm | [25] | Rolling bearing | [100] | Gear unit cover | [520] | Shim |
| [6] | Worm gear | [30] | Rolling bearing | [101] | Hex head screw | [521] | Shim |
| [7] | Output shaft | [31] | Key | [102] | Seal | [522] | Shim |
| [9] | Oil seal | [37] | Rolling bearing | [131] | Closing cap | [523] | Shim |
| [11] | Rolling bearing | [39] | Retaining ring | [137] | Supporting ring | | |
| [12] | Retaining ring | [59] | Screw plug | [506] | Shim | | |
| [19] | Key | [61] | Retaining ring | [507] | Shim | | |

3.7 Basic structure of SPIROPLAN® gear units W..10 – W..30

9007199274048267

| | | | |
|----------------------|------------------------|------------------------|------------|
| [1] Pinion | [19] Key | [88] Retaining ring | [518] Shim |
| [6] Gear | [22] Gear unit housing | [89] Closing cap | [519] Shim |
| [7] Output shaft | [25] Rolling bearing | [100] Inspection cover | [520] Shim |
| [8] Key | [65] Oil seal | [101] Hex head screw | [521] Shim |
| [9] Oil seal | [66] Rolling bearing | [102] Gasket | [522] Shim |
| [11] Rolling bearing | [68] Retaining ring | [143] Supporting ring | [523] Shim |
| [12] Retaining ring | [71] Supporting ring | [250] Retaining ring | |
| [17] Spacer tube | [72] Retaining ring | [251] Retaining ring | |

3.8 Basic structure of SPIROPLAN® gear units W..37 – W..47



18014399115354379

| | | | |
|-------------------------------|-------------------------------|---------------------|------------|
| [1] Pinion | [22] Gear unit housing | [59] Screw plug | [521] Shim |
| [2] Gear | [25] Deep groove ball bearing | [61] Retaining ring | [522] Shim |
| [5] Pinion shaft | [26] Housing stage 1 | [88] Retaining ring | [523] Shim |
| [6] Gear | [30] Deep groove ball bearing | [89] Closing cap | |
| [7] Output shaft | [31] Key | [133] Shim | |
| [8] Key | [32] Spacer tube | [137] Shim | |
| [9] Oil seal | [33] Retaining ring | [506] Shim | |
| [11] Deep groove ball bearing | [36] Hex head screw | [518] Shim | |
| [12] Retaining ring | [37] Deep groove ball bearing | [519] Shim | |
| [19] Key | [44] O-ring | [520] Shim | |

3.9 Nameplate/type designation

3.9.1 Nameplate

The following figure gives an example of a nameplate of an explosion-proof gearmotor:

| | | | | |
|------|-----------------------------------|-------------------|-----------------|------|
| [1] | SEW-EURODRIVE | CE | Ex | [1] |
| [2] | 76646 Bruchsal/Germany | | | [2] |
| [3] | R77/II2GD EDRE112M4/2GD/KCC/TF/AL | | | [3] |
| [4] | 01.12345678910.0001.00 | | | [4] |
| [5] | na r/min 148 | ne max r/min 1425 | i 9,64 | [5] |
| [6] | Ma Nm 142 | Me max Nm 15.0 | kg 58.041 | [6] |
| [7] | Fra max N 8830 | | Fb 3.8 | [7] |
| [8] | | | IP 65 | [8] |
| [9] | | | IM M1 | [9] |
| [10] | II 2G Ex h IIC T4 Gb | Ta -20...+40°C | Made in Germany | [10] |
| [11] | II 2D Ex h IIIC T120°C Db | | | [11] |
| [12] | CLP HC 220 Synth.Öl/1.2 l | | | [12] |

- [1] Company name, CE marking, ATEX marking
- [2] Address
- [3] Type designation of the gear unit, type designation of the motor
- [4] Serial number
- [5] Output speed, maximum input speed, gear ratio
- [6] Output torque, maximum input torque, weight
- [7] Maximum overhung load acting on the output shaft, service factor
- [8] Degree of protection
- [9] Mounting position
- [10] Indicates gas explosion protection, ambient temperature, country of manufacture
- [11] Indicates dust explosion protection
- [12] Oil type, oil quantity

INFORMATION



For ATEX gearmotors, the nameplates of the motor and gear unit must be compared. When you compare the values (e.g. dust or ambient temperature) on the nameplates, the least common multiples determines the overall unit of motor and gear unit.



INFORMATION

In some applications, SEW-EURODRIVE gear units/gearmotors must only be operated in compliance with special measures. For these cases, there is a special indication on the nameplate "II..X". For further information, refer to chapter "Information on special indication X identification" (→ 23).

The gear unit designs and options are described in chapter "Type designation" (→ 25).

3.9.2 EAC marking



On request, the explosion-proof gear units from SEW-EURODRIVE meet the requirements of the technical regulations of the Eurasian Economic customs union (Russia, Kazakhstan, Belarus, and Armenia). The EAC marking on the product certifies the conformity with the safety requirement of the Customs Union.

3.9.3 Information on special indication X identification

INFORMATION




For the special operation data, refer to the order confirmation and the nameplate.

In some applications, SEW-EURODRIVE gear units, motors, or gearmotors must only be operated if special measures are adhered to (e.g. intermittent duty exclusively, reduced output torque etc.). These special measures may be necessary due to various reasons. The customer has been informed about the required special measures on the initial distribution of the gear unit/motor/gearmotor. The customer is obliged to ensure the compliance with these special measures.

Gear units, motors, or gearmotors with special measures are indicated with the special identification "X" on the nameplate (see following figure). The relevant special measure is indicated separately by an "X" combined with a number on the nameplate. The following describes the special measures in detail.

X1: Intermittent duty



23913221003

[1] Special measure X1 [2] Special indication "X"

In this case, an arrangement has been made with the buyer that the drive may be used only in intermittent duty. The maximum time for operation and pauses in minutes are indicated on the nameplate [1] and the order confirmation. Reducing the idling time is not permitted. The operating time may be reduced but not extended. The buyer is obliged to take measures to ensure that the specifications are adhered to.

X2: Drive in combination with an ATEX-compliant oil cooling system provided by the customer

In this case, it was agreed with the buyer that this drive may only be operated in connection with an ATEX compliant oil cooling system on the customer side. On the basis of the required oil bath temperature, the cooling system must provide a certain minimum cooling power at a certain ambient temperature. The oil quantity must be extended by the volume of the cooling circuit to ensure sufficient and permanent lubrication of the gear unit. The buyer is responsible for the assessment of the reliability of the oil cooling system. The buyer of this product is obligated to meet these requirements through appropriate dimensioning and installation of a suitable cooling system.

X3: Concession for multiple mounting positions

In this case, it was agreed with the buyer that this drive can also be operated in mounting positions other than the one specified in the following quotation text. Prerequisite is that the breather valve is mounted according to the mounting position.


X4: Customer-supplied output shaft

In this case, customer-specific load data regarding overhung load, force application point, axial load and output torque are confirmed as the output shaft is supplied by the customer.

X5: Oil change
(summer and
winter operation)

In this case, it was agreed with the buyer that the oil must be changed for summer and winter operation.

The fields marked on the following nameplate refer to the initial filling. These fields are only highlighted as an example.



23913752331

- [1] Special measure X5 [2] Special indication "X"
 [3] The values specified
 refer to the initial filling

X6: Reduced over-
hung load for
mounting position
M..AB/A, M..AB/B,
M..A/AB, M..B/AB

In this case, the following agreement was met with the buyer: If the force is applied on a different side than where the customer's flange connection is mounted, then the maximum permitted overhung load is reduced to the value specified in line X.

The buyer of this product shall take appropriate measures to ensure that these requirements are met.

For the special operation data, refer to the order confirmation and the nameplate.

3.10 Type designation

INFORMATION



For a detailed overview of type designations and additional information, refer to the following publications:

- "Explosion-Proof Gearmotors" catalog
- "Explosion-Proof AC Motors" catalog

Example: Helical-bevel gear units in explosion-proof design II2GD

| Example: KF87/II2GD | | |
|------------------------|--------------|---|
| Series | KF | <ul style="list-style-type: none"> • K = Helical-bevel gear unit • F = B5 flange-mounted design |
| Size | 87 | Size 87 |
| Explosion-proof design | /II2G | Explosion-proof design according to equipment group II: <ul style="list-style-type: none"> • 2G = category 2, explosive gas atmosphere • 2D = category 2, explosive dust atmosphere |

Below an overview of type designations for R, F, S, K, and W gear units and their options.

3.10.1 Helical gear units

| Designation | Description |
|-------------|---|
| RX.. | Single-stage foot-mounted design, output shaft with key |
| RXF.. | Single-stage B5 flange-mounted design, output shaft with key |
| R.. | Foot-mounted design, output shaft with key |
| R..F | Foot- and B5 flange-mounted design, output shaft with key |
| RF.. | B5 flange-mounted design, output shaft with key |
| RZ.. | B14 flange-mounted design, output shaft with key |
| RM.. | B5 flange-mounted design with extended bearing hub, output shaft with key |

3.10.2 Parallel-shaft helical gear units

| Designation | Description |
|-------------|---|
| F.. | Foot-mounted design, output shaft with key |
| FA..B | Foot-mounted design, hollow shaft with keyway |
| FH..B | Foot-mounted design, hollow shaft with shrink disk |
| FV..B | Foot-mounted design, splined hollow shaft to DIN 5480 |
| FF.. | B5 flange-mounted design, output shaft with key |
| FAF.. | B5 flange-mounted design, hollow shaft with keyway |
| FHF.. | B5 flange-mounted design, hollow shaft with shrink disk |

| Designation | Description |
|-------------|--|
| FVF.. | B5 flange-mounted design, splined hollow shaft to DIN 5480 |
| FA.. | Hollow shaft with keyway |
| FH.. | Hollow shaft with shrink disk |
| FT.. | Hollow shaft with TorqLOC® hollow shaft mounting system |
| FV.. | Splined hollow shaft to DIN 5480 |
| FZ.. | B14 flange-mounted design, output shaft with key |
| FAZ.. | B14 flange-mounted design, hollow shaft with keyway |
| FHZ.. | B14 flange-mounted design, hollow shaft with shrink disk |
| FVZ.. | B14 flange-mounted design, splined hollow shaft to DIN 5480 |
| FM.. | B5 flange-mounted design with extended bearing hub, output shaft with key |
| FAM.. | B5 flange-mounted design with extended bearing hub, hollow shaft with keyway |

3.10.3 Helical-bevel gear units

| Designation | |
|-------------|--|
| K.. | Foot-mounted design, output shaft with key |
| KA..B | Foot-mounted design, hollow shaft with keyway |
| KAF..B | B5 flange-mounted design, foot-mounted design, hollow shaft with keyway |
| KF..B | B5 flange-mounted design, foot-mounted design, output shaft with key |
| KH..B | Foot-mounted design, hollow shaft with shrink disk |
| KHF..B | B5 flange-mounted design, foot-mounted design, hollow shaft with shrink disk |
| KV..B | Foot-mounted design, splined hollow shaft to DIN 5480 |
| KF.. | B5 flange-mounted design, output shaft with key |
| KAF.. | B5 flange-mounted design, hollow shaft with keyway |
| KHF.. | B5 flange-mounted design, hollow shaft with shrink disk |
| KVF.. | B5 flange-mounted design, splined hollow shaft to DIN 5480 |
| KA.. | Hollow shaft with keyway |
| KH.. | Hollow shaft with shrink disk |
| KT.. | Hollow shaft with TorqLOC® hollow shaft mounting system |
| KV.. | Splined hollow shaft to DIN 5480 |
| KZ.. | B14 flange-mounted design, output shaft with key |
| KAZ.. | B14 flange-mounted design, hollow shaft with keyway |
| KHZ.. | B14 flange-mounted design, hollow shaft with shrink disk |
| KVZ.. | B14 flange-mounted design, splined hollow shaft to DIN 5480 |

| Designation | |
|-------------|--|
| KM.. | B5 flange-mounted design with extended bearing hub, output shaft with key |
| KAM.. | B5 flange-mounted design with extended bearing hub, hollow shaft with keyway |

3.10.4 Helical-worm gear units

| Designation | Description |
|-------------|---|
| S.. | Foot-mounted design, output shaft with key |
| SF.. | B5 flange-mounted design, output shaft with key |
| SAF.. | B5 flange-mounted design and hollow shaft with keyway |
| SHF.. | B5 flange-mounted design and hollow shaft with shrink disk |
| SA.. | Hollow shaft with keyway |
| SH.. | Hollow shaft with shrink disk |
| ST.. | Hollow shaft with TorqLOC® hollow shaft mounting system |
| SAZ.. | B14 flange-mounted design and hollow shaft with keyway |
| SHZ.. | B14 flange-mounted design and hollow shaft with shrink disk |

3.10.5 SPIROPLAN® gear units

| Designation | Description |
|-------------|--|
| W.. | Foot-mounted design, output shaft with key |
| WF.. | B5 flange-mounted design, output shaft with key |
| WAF.. | B5 flange-mounted design and hollow shaft with keyway |
| WA.. | Hollow shaft with keyway |
| WA..B | Foot-mounted design and hollow shaft with keyway |
| WH..B | Foot-mounted design and hollow shaft with shrink disk |
| WHF.. | B5 flange-mounted design and hollow shaft with shrink disk |
| WH.. | Hollow shaft with shrink disk |
| WT.. | Hollow shaft with TorqLOC® hollow shaft mounting system |

3.10.6 Options

| Designation | Description |
|-------------|------------------|
| /WEX | Speed monitoring |

R, F and K gear units:

| Designation | Description |
|-------------|------------------|
| /R | Reduced backlash |

K, S and W gear units:

| Designation | Description |
|-------------|-----------------|
| /T | With torque arm |

F gear units:

| Designation | Description |
|-------------|--------------------|
| /G | With rubber buffer |

4 Mechanical installation

4.1 General information



⚠ WARNING

Risk of explosion due to hot gear unit surfaces caused by loss of oil.

Fatal or serious injuries.

- Check the transportation packaging for oil residues. Oil residues could indicate an oil leak. In this case, the lubrication of the gear unit is not guaranteed. This could cause excessive temperature on the surface.
- Contact SEW-EURODRIVE if there are oil residues on the gear unit.



⚠ CAUTION

Risk of injury due to protruding gear unit parts.

Minor injuries.

- Keep a sufficient safety distance to the gear unit/gearmotor.



⚠ CAUTION

Health risk due to dangerous gases, vapors, and residue created by heating fluorocarbon rubber to > 200 °C.

Damage to health.

The following gear unit components may contain fluorocarbon rubber: Oil seals, breather valves, screw plugs.

- Make sure that components made of fluorocarbon rubber are not exposed to temperatures > 200 °C. Remove the components, if necessary.
- Avoid inhaling fluorocarbon rubber gases and vapors as well as skin and eye contact.
- Avoid contact with the cooled-down fluorocarbon rubber, as dangerous residue were formed while it was heated.

NOTICE

The bearing and the sealing rings can be damaged if exposed to solvents.

Damage to property.

- When cleaning the shafts and flange surfaces with solvents, protect bearings and oil seals.
- Use a commercially available solvent.



INFORMATION

The assembly of gear head units with motors or adapters may be performed by authorized personnel only. Contact SEW-EURODRIVE.

4.2 Gear units/gearmotors in explosion-proof design II2GD and II3GD**INFORMATION**

- Explosion-proof gear units and gearmotors of the R..7, F..7, K..7, K..9, S..7, and SPIROPLAN® W series comply with the design requirements for equipment group II, categories 2G (potentially explosive gas atmosphere) and 2D (potentially explosive dust atmosphere). These units are intended for use in zones 1 and 21.
- The explosion-proof gear units of the R..7, F..7, K..7, K9, and S..7 series with AR adapter (adapter with slip clutch) comply with equipment group II, categories 3G (potentially explosive gas atmosphere) and 3D (potentially explosive dust atmosphere). These units are intended for use in zones 2 and 22.

4.2.1 Ambient temperature

If no deviating data is given on the nameplate, gear units in explosion-proof design may only be used at ambient temperatures in the range from -20 °C – +40 °C.

If an attached component limits this temperature range, the data on the components nameplate applies.

INFORMATION

Any ambient temperatures deviating from this range are listed on the nameplate.

4.2.2 Temperature class

Mains-operated gear units/gearmotors in category II2G (potentially explosive gas atmosphere) are approved for temperature classes T3 to T6 depending on their speed, reduction ratio and mounting position.

The temperature class of the gear unit is specified on the nameplate.

To define which stand-alone gear units and which 4-pole gearmotors operated with inverters can be used in an application, contact SEW-EURODRIVE.

4.2.3 Surface temperature

The surface temperature of gear units of category II2D is 120 °C or 140 °C depending on speed, ratio and mounting position. Refer to the nameplate for the maximum surface temperature of the gear unit.

The system operator must guarantee that a possible accumulation of dust will not exceed a maximum thickness of 5 mm, in accordance with EN 50281-1-2.

4.2.4 Degree of protection

The degree of protection for the gear unit design is IP65 according to EN 60529. Deviating information is specified on the nameplate.

4.2.5 Ambient conditions

The gear unit must be sufficiently ventilated. No external heat generation (e.g. via couplings, flanges or shafts) must be present.

4.2.6 Output power and output torque

Observe the nominal output torque and the permitted overhung loads.

4.3 Prerequisites for installation

Check that the following conditions have been met:

- The drive has not been damaged during transportation or storage.
- The entries on the nameplate of the gearmotor match the voltage supply system.
- The ambient temperature corresponds to the specifications in the technical documentation, the nameplate and the lubricant table in chapter Lubricants.
- No harmful oils, acids, gases, vapors, radiation etc. are present in the environment.
- The oil seals on the output end are protected against wear in abrasive ambient conditions.
- In case of helical-worm gear units and SPIROPLAN® W gear units: Make sure that no large external mass moments of inertia are present, which could exert a retrodriving load on the gear unit. In this respect, observe the following formula:
$$\eta' \text{ (retrodriving)} = 2 - 1/\eta$$

Self-locking if $\eta' < 0.5!$
- In case of **special designs**, make sure that the drive is designed according to the ambient conditions. Observe the information on the nameplate.

4.4 Required tools/resources

The following tools and resources are required for the mechanical installation:

- Wrench
- Torque wrench for:
 - Gear unit mounting
 - Shrink disks
 - AQH motor adapter
 - Input shaft assembly with centering shoulder
- Mounting device
- Compensation elements (shims and spacing rings)
- Fasteners for input and output elements
- Lubricant (e.g. NOCO® fluid)
- Threadlocker compound for input cover with centering shoulder (e.g. Loctite® 243)

INFORMATION

Standard parts are not included in the delivery.

4.5 Installation tolerances

| Shaft end | Flanges |
|---|--|
| Diameter tolerance according to DIN 748 <ul style="list-style-type: none"> • ISO k6 for solid shafts with $\varnothing \leq 50$ mm • ISO m6 for solid shafts with $\varnothing > 50$ mm • ISO H7 for hollow shafts • Centering bore in accordance with DIN 332, shape DR | Centering shoulder tolerance to DIN 42948 <ul style="list-style-type: none"> • ISO j6 with $b1 \leq 230$ mm • ISO h6 with $b1 > 230$ mm |

4.6 Installing the gear unit



⚠ WARNING

Risk of explosion due to electric sparks if housing is not additionally grounded.

Fatal and serious injuries.

- Additionally ground the housing. Use the grounding screw at the motor.



⚠ WARNING

Risk of explosion due to friction that causes electrical charge on the coating.

Fatal and serious injuries.

- Prevent moving parts on the coating from creating electric sparks.



⚠ CAUTION

Risk of injury due to improper installation/removal

Severe personal injury and damage to property

- Work on the gear unit only when the machine is not in use.
- Secure the drive unit against unintentional power-up.
- Attach an information sign near the ON switch to warn that the gear unit is being worked on.
- Prevent heavy component parts (e.g. shrink disks) against falling during installation/disassembly.
- It is important that you observe the notes in this chapter.



⚠ CAUTION

Risk of injury due to protruding gear unit parts

Severe injuries

- Keep a sufficient safety distance to the gear unit/gearmotor.



⚠ CAUTION

Danger due to static overdetermination if gear units with foot (e.g. KA19/29B, KA127/157B or FA127/157B) are mounted both via the torque arm and via the foot plate.

Risk of injuries and damage to property

- Especially with the KA.9B/T variant, it is not permitted to use the foot plates and the torque arm at the same time.
- Attach the KA.9B/T design only via the torque arm.
- Attach the K.9 or KA.9B design only via the foot plate.
- If you want to use foot plates and torque arms for mounting, contact SEW-EURODRIVE.



▲ CAUTION

Danger due to static overdetermination in the case of gearmotors when the gear unit is attached to the foot plate (e.g. KA19/29B, KA127/157B or FA127/157B, R gear unit with foot-mounted motor) and the motor is attached to the foot plate as well.

Risk of injuries and damage to property

- Attach only the gear unit or only the motor to the foot plate.

NOTICE

Damage to gear unit/gearmotor due to cold air currents. Condensed water in the gear unit can cause damage.

Damage to property

- Protect the gear unit from direct cold air currents.



INFORMATION

When installing the gear unit, make sure that the oil level and drain plugs as well as the breather valves are easily accessible!

Mounting position

The gear unit or gearmotor is only allowed to be installed in the specified mounting position. Observe the information on the nameplate. SPIROPLAN® gear units of sizes W10 – W30 are mounting position-independent.

Oil fill quantity

Check the oil fill depending on the mounting position (for information on the fill quantity refer to the nameplate). Control the oil fill level at this opportunity. See chapter "Inspection/maintenance for the gear unit" (→ 118). The gear units are filled with the required oil quantity at the factory. There may be slight deviations at the oil level plug as a result of the mounting position, which are permitted within the manufacturing tolerances.

Changing the mounting position

Adjust the lubricant fill quantities and the position of the breather valve accordingly in the event of a change of mounting position. Also observe chapter "Mounting positions" (→ 136).

INFORMATION



Do not change the mounting position without prior consultation with SEW-EURODRIVE.

The information on the nameplate is binding. The ATEX EU declaration of conformity and the guarantee no longer apply if the mounting position is changed without prior consultation with SEW-EURODRIVE. Changes to the mounting position must be projected and indicated on the nameplate.

Submounting

The support structure must have the following characteristics:

- Level
- Vibration damping
- Torsionally rigid

The following table shows the maximally permitted flatness defect for foot- and flange-mounting (guide values based on DIN ISO 1101):

| Gear unit size | Flatness defect |
|----------------|-----------------|
| ≤ 67 | max. 0.4 mm |

| | |
|-----------|-------------|
| 77 – 107 | max. 0.5 mm |
| 137/147 | max. 0.7 mm |
| 157 – 187 | max. 0.8 mm |

Do not twist housing legs and mounting flanges against each other. Observe the permitted overhung and axial loads! Observe the chapter "Project Planning" in the gear unit/gearmotor catalog for calculating the permitted overhung and axial loads.

Strength class of the screws

Always mount gearmotors using screws of strength class 8.8. The gearmotors in flange-mounted design and in foot-/flange-mounted design listed in the following table are an exception. Always use screws of strength class 10.9 for these gearmotors. Use suitable washers.

| Gear unit | Ø flange mm | Strength class of the screws |
|--|----------------|---------------------------------|
| RF37/R37F | 120 | 10.9 |
| RF47/R47F | 140 | |
| RF57/R57F | 160 | |
| FF/FAF77 KF/KAF77 | 250 | |
| FM/FAM67, FM/FAM77 KM/KAM67, KM/KAM77 | 300 | |
| FM/FAM87 KM/KAM87 | 350 | |
| FM/FAM97 KM/KAM97 | 400 | |
| RF147 FM/FAM107 KM/KAM107 | 450 | |
| RF167 FM/FAM127 KM/KAM127 | 550 | |
| FM/FAM157 KM/KAM157 | 660 | |
| RZ37 – RZ87 | 60ZR – 130ZR | |

Corrosion protection for screw connections

Use plastic inserts (2 – 3 mm thick) if there is a risk of electrochemical corrosion between the gear unit and the driven machine. The material used must have an electrical leakage resistance $< 10^9 \Omega$. Electrochemical corrosion can occur between various metals, for example, cast iron and stainless steel. Also install the bolts with plastic washers! Additionally ground the housing. Use grounding screws on the motor.

4.6.1 Installation in damp locations or outdoors

NOTICE

Paint can block the breather valve and damage the sealing lips of the oil seals.

Damage to property.

- Thoroughly cover the breather valve and sealing lip of the oil seals with strips prior to painting/re-painting.
- Remove the strips after painting.

Drives are supplied in corrosion-resistant designs with an according surface protection coating for use in damp areas or outdoors.

- Repair any damage to the paint work (e.g. on the breather valve or the lifting eyes).
- When mounting the motors onto AM, AQ adapters and to AR, AT start-up couplings and slip clutches, seal the flange areas with a suitable sealant (e.g. Loctite® 574).
- In case of setup outdoors, the drives must not be exposed to direct sunlight. Install appropriate protection devices e.g. a cover or a canopy. The protection device must not cause heat build-up.
- The system operator must ensure that no foreign objects (e.g. falling objects or coverings) affect the operation of the gear unit.

4.6.2 Tightening torques for retaining screws

Mount the gearmotors with the following tightening torques:

| Screw/nut | Tightening torque $\pm 10\%$ Strength class 8.8 Nm |
|-----------|--|
| M6 | 11 |
| M8 | 27 |
| M10 | 54 |
| M12 | 93 |
| M16 | 230 |
| M20 | 464 |
| M24 | 798 |
| M30 | 1597 |
| M36 | 2778 |
| M42 | 3995 |
| M48 | 6022 |
| M56 | 9650 |

Mount the specified gearmotors in flange-mounted design with the following increased tightening torques:

| Flange Ø mm | Gear unit | Screw/nut | Tightening torque ± 10% Strength class 10.9 Nm |
|----------------|--|-----------|--|
| 120 | RF37 | M6 | 17 |
| 140 | RF37/RF47 | M8 | 40 |
| 160 | RF57 | M8 | 40 |
| 300 | FM/FAM67, FM/FAM77 KM/KAM67, KM/KAM77 | M12 | 137 |
| 350 | FM/FAM87 KM/KAM87 | M16 | 338 |
| 400 | FM/FAM97 KM/KAM97 | M16 | 338 |
| 450 | FM/FAM107 KM/KAM107 | M16 | 338 |
| 450 | RF147 | M20 | 661 |
| 550 | FM/FAM127 KM/KAM127 | M16 | 338 |
| 550 | RF167 | M20 | 661 |
| 660 | FM/FAM157 KM/KAM157 | M20 | 661 |
| 60ZR | RZ37 | M8 | 40 |
| 70ZR | RZ47 | M8 | 40 |
| 80ZR | RZ57 | M10 | 79 |
| 95ZR | RZ67 | M10 | 79 |
| 110ZR | RZ77 | M10 | 79 |
| 130ZR | RZ87 | M12 | 137 |
| 250 | FF77/KF77/ FAF77/ KAF77 | M12 | 137 |

4 Mechanical installation

Installing the gear unit

4.6.3 Tightening torques for oil level plugs, oil drain plugs, screw plugs, breather valves and oil sight glasses

Observe the tightening torques in the following table when screwing in:

| Thread | Tightening torque Nm |
|-----------|-------------------------|
| M10 × 1 | 8 |
| M12 × 1.5 | 14 |
| M22 × 1.5 | 45 |
| M33 × 2 | 100 |
| M42 × 2 | 160 |

4.6.4 Installing the gear unit

INFORMATION



If you use the gear unit in flange-mounted design or foot/flange-mounted design in connection with VARIBLOC® variable-speed gear units, use screws of 10.9 quality and suitable washers for flange mounting on the customer side.

To improve the friction contact between flange and mounting surface, SEW-EURODRIVE recommends anaerobic gaskets or an anaerobic glue.

INFORMATION



With the gear units KAZ/KZ/FAZ/FZ 107 – 157, remove the 4 transport protection screws from the B14 flange. The 2 recessed screws **must** remain in the B14 flange.

Foot-mounted gear unit

The following table shows the thread sizes of the foot-mounted gear units depending on the gear unit type and size:

| Screw | Gear unit type | | | | | |
|-------|----------------|--------|-------------------|-------------------------|-------|----------|
| | R/R..F | RX | F/FH..B/ FA..B | K/KH..B/KV..B/ KA..B | S | W |
| M6 | 07 | – | – | 19 | – | 10/20 |
| M8 | 17/27/37 | – | 27/37 | 29 | 37 | 30/37/47 |
| M10 | – | 57 | 47 | 37/39/47/49 | 47/57 | – |
| M12 | 47/57/67 | 67 | 57/67 | 57/67 | 67 | – |
| M16 | 77/87 | 77/87 | 77/87 | 77 | 77 | – |
| M20 | 97 | 97/107 | 97 | 87 | 87 | – |
| M24 | 107 | – | 107 | 97 | 97 | – |
| M30 | 127/137 | – | 127 | 107/167 | – | – |
| M36 | 147/167 | – | 157 | 127/157/187 | – | – |

24804134/EN – 05/2018

Gear unit with B14 flange-mounted design and/or hollow shaft

The following table shows the thread sizes of the gear units with B14 flange and/or hollow shaft depending on the gear unit type and size:

| Screw | Gear unit type | | | | |
|-------|----------------|--------------------|--------------------|------------|------------------------|
| | RZ | FZ/FAZ/FHZ/ FVZ | KZ/KAZ/KHZ/ KVZ | SA/SAZ/SHZ | WA |
| M6 | 07/17/27 | – | – | 37 | 10/20/30 ¹⁾ |
| M8 | 37/47 | 27/37/47 | 37/47 | 47/57 | 37 |
| M10 | 57/67 | – | – | – | 47 |
| M12 | 77/87 | 57/67/77 | 57/67/77 | 67/77 | – |
| M16 | – | 87/97 | 87/97 | 87/97 | – |
| M20 | – | 107/127 | 107/127 | – | – |
| M24 | – | 157 | 157 | – | – |

1) For the W30 design mounted directly to a CMP.. motor, the thread size is M8.

Gear unit with B5 flange-mounted design

The following table shows the thread sizes of the gear units with B5 flange depending on the gear unit type, size and flange diameter:

| Ø flange mm | Screw | Gear unit type | | | | | |
|----------------|-------|-------------------------|--------------------|------------------|--------------------|----------------|----------------|
| | | RF/R..F/RM | FF/FAF/ FHF/FVF | FM/FAM KM/KAM | KF/KAF/ KHF/KVF | SF/SAF/ SHF | WF/WAF/ WHF |
| 80 | M6 | – | – | – | – | – | 10 |
| 110 | M8 | – | – | – | – | – | 20 |
| 120 | M6 | 07/17/27 | – | – | – | 37 | 10/20/30/37 |
| 120 | M8 | – | – | – | 19 | – | – |
| 140 | M8 | 07/17/27/37/47 | – | – | – | – | – |
| 160 | M8 | 07/17/27/37/47 | 27/37 | – | 19/37 | 37/47 | 30/37/47 |
| 160 | M10 | – | – | – | 29/39 | – | – |
| 200 | M10 | 37/47/57/67 | 47 | – | 29/47 | 57/67 | – |
| 200 | M12 | – | – | – | 49 | – | – |
| 250 | M12 | 57/67/77/87 | 57/67 | – | 57/67 | 77 | – |
| 300 | M12 | 67/77/87 | 77 | 67/77 | 77 | – | – |
| 350 | M16 | 77/87/97/107 | 87 | 87 | 87 | 87 | – |
| 400 | M16 | – | – | 97 | – | – | – |
| 450 | M16 | 97/107/127/137/ 147 | 97/107 | 107 | 97/107 | 97 | – |
| 550 | M16 | 107/127/137/ 147/167 | 127 | 127 | 127 | – | – |
| 660 | M20 | 147/167 | 157 | 157 | 157 | – | – |

4.6.5 Components made of elastomers with fluorocarbon rubber

Under normal operating conditions and at temperatures up to 200 °C, fluorocarbon rubber is very stable and safe. However, when heated to more than 300 °C, e.g. by fire or the flame of a cutting torch, fluorocarbon rubber forms harmful gases and vapors as well as residue.



⚠ CAUTION

Health risk due to dangerous gases, vapors, and residue created by heating fluorocarbon rubber to > 200 °C.

Damage to health.

- Make sure that components made of fluorocarbon rubber are not exposed to temperatures > 200 °C. Remove the components, if necessary.
- Avoid inhaling fluorocarbon rubber gases and vapors as well as skin and eye contact at all costs.
- Avoid contact with the cooled-down fluorocarbon rubber, as dangerous residue has formed while it was heated.

The following components of R..7, F..7, K..7, K..9, S..7, and SPIROPLAN® W gear units can contain elastomers made of fluorocarbon rubber.

- Oil seals
- Breather valve
- Screw plugs

The user is responsible for safe handling during the service life including eco-friendly disposal.

SEW-EURODRIVE is not responsible for damage caused by improper handling.

4.6.6 Venting the gear unit



⚠ WARNING

Risk of explosion due to overheated gear unit due to a dirty or dusty breather valve.

Severe or fatal injuries

- Check the breather valve function regularly and replace it if necessary.
- In case of high dirt and dust load use a breather filter instead of a breather valve.

The following table lists gear units that do not require venting:

| Gear unit | Mounting position |
|-------------------|-------------------|
| R..07 | M1/M2/M3/M5/M6 |
| R..17/R..27/F..27 | M1/M3/M5/M6 |
| W..10/W..20/W..30 | M1 – M6 |
| W..37/W..47 | M1/M2/M3/M5/M6 |
| K..19/K..29 | M1/M2/M3/M5/M6 |

All other gear units are delivered with a breather valve suitable to the mounting position and activated.

Exceptions:

1. The following gear units are delivered with a screw plug on the provided breather hole:


- Gear unit with pivoted mounting position (dynamic)
- Gear unit for mounting in an inclined position (stationary)
- Mounting position MX

A breather valve is supplied in a separate plastic bag attached to the gear unit. Before startup, replace the highest screw plug with the breather valve provided. Observe for this the tightening torques in chapter "Tightening torques for oil level plugs, oil drain plugs, screw plugs, breather valves and oil sight glasses" (→ 38).


2. For **gear head units** and **gear units with pivoted mounting position** with venting on the input end, a breather valve is supplied in a plastic bag.
3. **Enclosed gear units** are delivered without a breather valve.
4. In some countries, the breather valve is installed, but not activated due to possible pressure fluctuations during transport. In such cases the transport protection must be removed. This activates the breather valve (see chapter "Activating the breather valve" (→ 41)).
5. Gear units with gear unit venting on fixed piping, with expansion tank, and with ventilation filter are delivered without a breather filter.

Activating the breather valve


1. Before startup, check whether the transport protection on the breather valve has been removed and the valve is therefore activated. The following figure shows a breather valve with transport protection:



2. Remove the transport protection.



⇒ The following figure shows an activated breather valve:



4.6.7 Painting gear units

SEW-EURODRIVE delivers the drives with a coating that complies with the requirements regarding the prevention of electrostatic charge according to EN/IEC 13463-1.

WARNING



Risk of explosion due to electrostatic charge and sparks caused by improper painting.

Severe or fatal injuries from explosion.

- If the motor is painted, observe the requirements for painting to avoid electrostatic charge according to EN 13463-1.

WARNING



Paint can block the breather valve and damage the sealing lips of the oil seals.

Severe or fatal injuries.

- Thoroughly mask the breather valve and sealing lip of the oil seals with strips prior to painting/re-painting.
- Remove the masking strips after painting.

4.7 Gear unit with solid shaft

INFORMATION



If input and output elements are subject to the Directive 2014/34/EU, the input and output elements require ATEX approval.

INFORMATION



Only use belts with sufficient electrical leakage resistance $< 10^9 \Omega$.

4.7.1 Assembling input and output elements

NOTICE

Damage to bearing, housing or shafts due to incorrect mounting

Possible damage to property.

- Only use a mounting device for installing input and output elements (see chapter "Using the mounting device" (→ 44)). Use the threaded centering bore at the shaft end.
- Never force belt pulleys, couplings, pinions, etc. onto the shaft end by hitting them with a hammer.
- During the installation of belt pulleys, make sure the belt is tensioned correctly in accordance with the manufacturer's instructions.
- Make sure the transmission elements are balanced after fitting and do not give rise to any impermissible radial or axial forces. For the approved values, refer to the catalog "Gearmotors" or "Explosion-Proof Drives".


INFORMATION



Mounting is easier if you first apply lubricant to the output element or heat it up briefly to 80 – 100 °C.

Using a mounting device

The following figure shows a mounting device for installing couplings or hubs on gear unit or motor shaft ends. Should you be able to tighten the screw without any problems, you may not need the thrust bearing on the mounting device.




211368587

[1] Gear shaft end
[2] Thrust bearing

[3] Coupling hub

Avoiding excessive overhung loads

To avoid high overhung loads, mount gears and sprockets according to figure B.



211364235

[1] Hub
[A] Incorrect assembly

F_{X1} Overhung load at point X1
[B] Correct assembly

4.7.2 Mounting of couplings

▲ CAUTION


Risk of injury due to moving drive elements, such as belt pulleys or couplings, during operation.

Risk of jamming and crushing.

- Equip the input and output elements with a touch guard.

Adjust the following misalignments according to the coupling manufacturer's specifications when mounting couplings:

- Maximum and minimum clearance
- Axial misalignment
- Angular misalignment



4.8 Torque arms for shaft-mounted gear units


NOTICE

Damage to gear unit due to improper installation

Damage to the gear unit


- Do not place torque arms under strain during installation.
- Always use bolts of quality 8.8 to fasten torque arms.

The following figure shows the mounted torque arm without tension:



4.8.1 Mounting torque arms for parallel-shaft helical gear units

The following figure shows the torque support for parallel-shaft helical gear units in loose state.



36028797230330379

- | | |
|-------------------------------------|---|
| [1] Screw | a Washer width |
| [2] Washer | b Rubber buffer inner diameter |
| [3] Nuts | c Rubber buffer length in loose state |
| [4] Rubber buffer | d Rubber buffer diameter |
| [5] Metal side of the rubber buffer | ΔL Preload per rubber buffer in tightened state |


Proceed as follows:

1. Make sure that the metal sides of the rubber buffers lay against the gear unit.
2. Use screws [1] and washers [2] according to the following table.
3. Secure the screw connection with a nut [3].
4. Tighten the screw [1] until the preload "Δ L" of the rubber buffers is reached according to the table:

| Gear unit | Washer | Rubber buffer | | | |
|-----------|---------|---------------|---------|---------|-----------|
| | a mm | d mm | b mm | c mm | Δ L mm |
| F..27 /G | 5 | 40 | 12.5 | 20 | 1 |
| F..37 /G | 5 | 40 | 12.5 | 20 | 1 |
| F..47 /G | 5 | 40 | 12.5 | 20 | 1.5 |
| F..57 /G | 5 | 40 | 12.5 | 20 | 1.5 |
| F..67 /G | 5 | 40 | 12.5 | 20 | 1.5 |
| F..77 /G | 10 | 60 | 21.0 | 30 | 1.5 |
| F..87 /G | 10 | 60 | 21.0 | 30 | 1.5 |
| F..97 /G | 12 | 80 | 25.0 | 40 | 2 |
| F..107 /G | 12 | 80 | 25.0 | 40 | 2 |
| F..127 /G | 15 | 100 | 32.0 | 60 | 3 |
| F..157 /G | 15 | 120 | 32.0 | 60 | 3 |

4.8.2 Mounting torque arms for helical-bevel gear unit K..19 – K..49

The following figure shows the torque support for the helical-bevel gear units K..19 – K..49:



[1] Bushing

A Connection side
B Connection side


Observe the following points during assembly:

- Apply bearings to both sides of the bushing [1].
- Mount connection side B so that it mirrors side A.
- Use screws and tightening torques according to the following table:

| Gear unit | Screws | Tightening torque $\pm 10\%$ Nm |
|-----------|--------------------|------------------------------------|
| K..19 /T | 4 × M8 × 20 – 8.8 | 27 |
| K..29 /T | 4 × M8 × 22 – 8.8 | 27 |
| K..39 /T | 4 × M10 × 30 – 8.8 | 54 |
| K..49 /T | 4 × M12 × 35 – 8.8 | 93 |

4.8.3 Mounting torque arms for helical-bevel gear unit K..37 – K..157

The following figure shows the torque support for the helical-bevel gear units K..37 – K..157.



27021597975585035

[1] Bushing

A Connection side
B Connection side


Proceed as follows:

1. Apply bearings to both sides of the bushing [1].
2. Mount connection side B so that it mirrors side A.
3. Use screws and tightening torques according to the following table:

| Gear unit | Screws | Tightening torque $\pm 10\%$ Nm |
|-----------|---------------------|------------------------------------|
| K..37 /T | 4 × M10 × 25 – 8.8 | 54 |
| K..47 /T | 4 × M10 × 30 – 8.8 | 54 |
| K..57 /T | 4 × M12 × 35 – 8.8 | 93 |
| K..67 /T | 4 × M12 × 35 – 8.8 | 93 |
| K..77 /T | 4 × M16 × 40 – 8.8 | 230 |
| K..87 /T | 4 × M16 × 40 – 8.8 | 230 |
| K..97 /T | 4 × M20 × 50 – 8.8 | 464 |
| K..107 /T | 4 × M24 × 60 – 8.8 | 796 |
| K..127 /T | 4 × M36 × 130 – 8.8 | 2778 |
| K..157 /T | 4 × M36 × 130 – 8.8 | 2778 |

4.8.4 Mounting torque arms for helical-worm gear units

The following figure shows the torque support for helical-worm gear units.



27021597975714699

[1] Connector


Proceed as follows:

1. Apply bearings to both sides of the bushing [1].
2. Use screws and tightening torques according to the following table:

| Gear unit | Screws | Tightening torque $\pm 10\%$ |
|-----------|--------------------|------------------------------|
| | | Nm |
| S..37 /T | 4 × M6 × 16 – 8.8 | 11 |
| S..47 /T | 4 × M8 × 25 – 8.8 | 27 |
| S..57 /T | 6 × M8 × 25 – 8.8 | 27 |
| S..67 /T | 4 × M12 × 35 – 8.8 | 93 |
| S..77 /T | 4 × M12 × 35 – 8.8 | 93 |
| S..87 /T | 4 × M16 × 45 – 8.8 | 230 |
| S..97 /T | 4 × M16 × 50 – 8.8 | 230 |

4.8.5 Mounting torque arms for SPIROPLAN® W gear units

The following figure shows the torque support for SPIROPLAN® W gear units.



27021597975712523

[1] Bushing

Proceed as follows:

1. Apply bearings to both sides of the bushing [1].
2. Use screws and tightening torques according to the following table:

| Gear unit | Screws | Tightening torque ± 10% |
|-----------|--------------------|-------------------------|
| | | Nm |
| W..10 /T | 4 × M6 × 16 – 8.8 | 11 |
| W..20 /T | 4 × M6 × 16 – 8.8 | 11 |
| W..30 /T | 4 × M6 × 16 – 8.8 | 11 |
| W..37 /T | 4 × M8 × 20 – 8.8 | 27 |
| W..47 /T | 4 × M10 × 20 – 8.8 | 54 |

4.9 Mounting shaft-mounted gear units with splined hollow shaft


INFORMATION



Concerning the configuration of the customer shaft, please also refer to the design notes in the "Gearmotors" catalog.


Proceed as follows:

1. Apply NOCO® fluid. Spread carefully.



20685469067

2. Install the shaft and secure it axially. For easier mounting, use a mounting device.



20685473931

- [1] Closing plug
- [2] Cap screw
- [3] Supporting ring

- [4] Retaining ring
- [5] Washer

4.10 Shaft-mounted gear unit with keyway

INFORMATION




Concerning the design of the customer shaft, please also refer to the design notes in the "Gearmotors" catalog.

4.10.1 Mounting shaft-mounted gear units with keyway

Proceed as follows:


1. Apply NOCO® fluid. Spread carefully.



9007199466257163

2. Install the shaft and secure it axially. For easier mounting, use a mounting device. Proceed according to one of the **3 mounting types**, depending on the scope of delivery.


A) Mounting a customer shaft (standard scope of delivery):



9007199466259339

- | | |
|---|--------------------|
| [1] Short retaining screw (standard scope of delivery) | [3] Washer |
| [2] Lock washer | [4] Retaining ring |
| | [5] Customer shaft |


B) Mounting customer shaft with contact shoulder using the SEW-EURODRIVE assembly/disassembly kit:



9007199466261515

- | | | | |
|-----|-----------------|-----|--------------------------------------|
| [1] | Retaining screw | [4] | Retaining ring |
| [2] | Lock washer | [5] | Customer shaft with contact shoulder |
| [3] | Washer | | |


C) Mounting customer shaft without contact shoulder using the SEW-EURODRIVE assembly/disassembly kit:



9007199466263691

- | | | | |
|-----|-----------------|-----|---|
| [1] | Retaining screw | [4] | Retaining ring |
| [2] | Lock washer | [5] | Spacer tube |
| [3] | Washer | [6] | Customer shaft without contact shoulder |

3. Tighten the retaining screw to the appropriate torque. Observe the tightening torques specified in the following table.



9007199466265867


| Screw | Tightening torque Nm |
|--------|-------------------------|
| M5 | 5 |
| M6 | 8 |
| M10/12 | 20 |
| M16 | 40 |
| M20 | 80 |
| M24 | 200 |

INFORMATION

To avoid contact corrosion, SEW-EURODRIVE recommends that the customer shaft should be lathed down between the 2 contact surfaces.

4.10.2 Removing the shaft-mounted gear unit

This description is only applicable if the gear unit was assembled using the SEW-EURODRIVE assembly/disassembly kit (see step 2 of Mounting the shaft-mounted gear unit).




9007199466268043

- | | |
|---------------------|--------------------|
| [1] Retaining screw | [4] Retaining ring |
| [2] Lock washer | [5] Spacer tube |
| [3] Washer | [6] Customer shaft |

Proceed as follows:

1. Loosen the retaining screw [1].
2. Remove parts [2] to [4] and, if applicable, the spacer tube [5].
3. Insert the forcing washer [8] and the fixed nut [7] from the SEW-EURODRIVE assembly/disassembly kit between the customer shaft [6] and the retaining ring [4] (see "SEW-EURODRIVE assembly/disassembly kit" (→ 56)).

4. Re-install the retaining ring [4].
5. Re-install the retaining screw [1]. Press the gear unit off the shaft by tightening the screw.



9007199466270219


- | | | | |
|-----|-----------------|-----|----------------|
| [1] | Retaining screw | [7] | Fixed nut |
| [4] | Retaining ring | [8] | Forcing washer |
| [6] | Customer shaft | | |

4.10.3 Assembly/disassembly kit by SEW-EURODRIVE

Applies only if the installation/removal kit was previously used for installation.

1. Loosen the retaining screw [5].
2. Remove the retaining ring [4] and, if used, the spacer tube.
3. Insert the forcing washer [2] and the fixed nut [3] between the customer shaft [1] and retaining ring [4] as shown in the following figure.
4. Re-insert the retaining ring [4].
5. Re-install the retaining screw [5]. Now you can force the gear unit off the shaft.

The following figure shows the SEW-EURODRIVE assembly/disassembly kit.



27021606946895115

- | | |
|-------------------------------|---------------------|
| [1] Customer shaft | [4] Retaining ring |
| [2] Forcing washer | [5] Retaining screw |
| [3] Fixed nut for disassembly | |

Dimensions and part numbers of the assembly/disassembly kit:

| Type | D ^{H7} mm | M ¹⁾ | C4 mm | C5 mm | C6 mm | U ^{-0.5} mm | T ^{-0.5} mm | D3 ^{-0.5} mm | L4 mm | Part number of the assembly/disassembly kit |
|--|-----------------------|-----------------|----------|----------|----------|-------------------------|-------------------------|--------------------------|----------|---|
| WA..10 | 16 | M5 | 5 | 5 | 12 | 4.5 | 18 | 15.7 | 50 | 6437125 |
| WA..20 | 18 | M6 | 5 | 6 | 13.5 | 5.5 | 20.5 | 17.7 | 25 | 643682X |
| WA..20, WA..30, SA..37, WA..37, KA..19 | 20 | M6 | 5 | 6 | 15.5 | 5.5 | 22.5 | 19.7 | 25 | 6436838 |
| FA..27, SA..47, WA..47, KA..29 | 25 | M10 | 5 | 10 | 20 | 7.5 | 28 | 24.7 | 35 | 6436846 |
| FA..37, KA..29, KA..37, KA..39, SA..47, SA..57, WA..47 | 30 | M10 | 5 | 10 | 25 | 7.5 | 33 | 29.7 | 35 | 6436854 |
| FA..47, KA..39, KA..47, KA..49, SA..57 | 35 | M12 | 5 | 12 | 29 | 9.5 | 38 | 34.7 | 45 | 6436862 |
| FA..57, KA..57, FA..67, KA..49, KA..67, SA..67 | 40 | M16 | 5 | 12 | 34 | 11.5 | 41.9 | 39.7 | 50 | 6436870 |
| SA..67 | 45 | M16 | 5 | 12 | 38.5 | 13.5 | 48.5 | 44.7 | 50 | 6436889 |
| FA..77, KA..77, SA..77 | 50 | M16 | 5 | 12 | 43.5 | 13.5 | 53.5 | 49.7 | 50 | 6436897 |
| FA..87, KA..87, SA..77, SA..87 | 60 | M20 | 5 | 16 | 56 | 17.5 | 64 | 59.7 | 60 | 6436900 |
| FA..97, KA..97, SA..87, SA..97 | 70 | M20 | 5 | 16 | 65.5 | 19.5 | 74.5 | 69.7 | 60 | 6436919 |
| FA..107, KA..107, SA..97 | 90 | M24 | 5 | 20 | 80 | 24.5 | 95 | 89.7 | 70 | 6436927 |

1) Retaining screw

4.11 Shaft-mounted gear unit with shrink disk

4.11.1 Mounting the shaft-mounted gear unit

NOTICE


Deformation of the hollow shaft due to tightening the locking screws without first installing the shaft.

Damage to the hollow shaft.

- Never tighten the locking screws without the shaft installed.


Proceed as follows:

1. Slightly loosen the locking screws. Do not remove the locking screws completely.



9007199466274571

2. Carefully **degrease** the hollow shaft bore and the input shaft using a commercial solvent.



9007199466276747


3. Only apply NOCO® fluid to the input shaft around the bushing.

NOTICE

The hollow shaft mounting system is without function if NOCO® fluid is applied directly to the bushing. When the input shaft is installed, NOCO® fluid can get into the clamping area of the shrink disk.


Possible damage to property

- Never apply NOCO® fluid directly to the bushing. The clamping area of the shrink disk must be absolutely free of grease.



9007199466281099

4. Install the input shaft. Proceed as follows to do so:
- Make sure that the outer rings of the shrink disk are plane-parallel.
 - In the case of a gear unit with shaft shoulder, mount the shrink disk at the shaft shoulder up to the stop.
 - In the case of a gear unit without shaft shoulder, mount the shrink disk at a distance of 1 – 2 mm from the gear unit housing.
 - Tighten the locking screws with the specified tightening torque according to the following table. Tighten the screws in several turns. Tighten screws one after the other, not in diametrically opposite sequence.



211542283

INFORMATION



The exact values for the tightening torques are shown on the shrink disk.

INFORMATION



Standard shrink disks and stainless steel shrink disks have the same tightening torques.

| Gear unit type | | | | Locking screw ISO 4014/ISO 4017/ ISO 4762 | Tightening torque $\pm 4\%$ Nm |
|----------------|------|------|------|---|--------------------------------------|
| KH.. | FH.. | SH.. | WH.. | | |
| 19/29 | 27 | 37 | 37 | M5 | 5 |

| KH.. | Gear unit type | | | Locking screw ISO 4014/ISO 4017/ ISO 4762 | Tightening torque $\pm 4\%$ Nm |
|----------------------|----------------|-------------|------|---|--------------------------------------|
| | FH.. | SH.. | WH.. | | |
| 37/39/47/49/57/67/77 | 37/47/57/67/77 | 47/57/67/77 | 47 | M6 | 12 |
| 87/97 | 87/97 | 87/97 | – | M8 | 30 |
| 107 | 107 | – | – | M10 | 59 |
| 127/157 | 127/157 | – | – | M12 | 100 |
| 167 | – | – | – | M16 | 250 |
| 187 | – | – | – | M20 | 470 |

5. After installation, make sure the remaining gap "s" between the outer rings of the shrink disk is > 0 mm.
6. To prevent corrosion, grease the outside of the hollow shaft around the shrink disk.

4.11.2 Removing the shaft-mounted gear unit

Proceed as follows:

1. To prevent the outer rings from jamming, loosen the locking screws for a quarter turn, one after the other.
2. Steadily loosen the locking screws one after the other, but do not remove the locking screws completely.
3. If rust has formed on the shaft in front of the hub, remove the rust.
4. Remove the shaft or pull the hub off the shaft.
5. Remove the shrink disk from the hub.

INFORMATION



There is no need to dismantle removed shrink disks before they are reinstalled.

4.11.3 Cleaning and lubricating shaft-mounted gear units

Proceed as follows:

1. If the shrink disk is dirty, clean and lubricate the shrink disk.
2. Lubricate the tapered surfaces. Use one of the following solid lubricants:

| Lubricant (Mo S2) | Sold as |
|-------------------------------------|----------------|
| Molykote 321 (lube coat) | Spray |
| Molykote spray (powder spray) | Spray |
| Molykote G Rapid | Spray or paste |
| Aemasol MO 19P | Spray or paste |
| Aemasol DIO-sétral 57 N (lube coat) | Spray |

3. Grease the locking screws with a multipurpose grease such as Molykote BR 2.

4.12 Shaft-mounted gear units with TorqLOC®

NOTICE

With a fixed flange or foot mounting, stress can build up in the drive train because of the possible tolerance adjustment of the TorqLOC® shaft.

Damage to property

- A flange or foot mounting is only allowed for TorqLOC® mounting if it is ensured that no static overdetermination can occur. Tolerance adjustment of the shaft must be possible.

INFORMATION




In case of flange mounting, installing the clamping ring may not be possible depending on the size.

4.12.1 Mounting a customer shaft without contact shoulder


Proceed as follows:

1. Clean the customer shaft and the inside of the hollow shaft. Ensure that all traces of grease or oil are removed.
2. Install the stop ring and the bushing on the customer shaft.




211941003

3. Attach the torque arm to the drive unit. Observe the information in chapter "Torque arms for shaft-mounted gear units" (→ 45).




K..7



S../W../K..9


20622111627

4. Apply NOCO® fluid directly to the bushing. Spread carefully.




211938827

5. Push the gear unit onto the customer shaft.




9007199466677643

6. Preassemble the torque arm. Do not firmly tighten the screws.




36028797230907147

7. Push the bushing into the gear unit up to the stop.



9007199466686347


8. Secure the bushing with the stop ring. Attach the stop ring to the bushing with the respective tightening torque. Refer to the following table for the suitable tightening torque.



9007199466741899

| Gear unit type | | | | Tightening torque Nm | |
|----------------|----------|------|------|-------------------------|-----------------|
| FT.. | KT.. | ST.. | WT.. | Standard | Stainless steel |
| – | – | 37 | 37 | 10 | 10 |
| 37 | 37 | 47 | 47 | 10 | 10 |
| 47 | 39/47 | 57 | – | 10 | 10 |
| 57/67 | 49/57/67 | 67 | – | 25 | 25 |
| 77 | 77 | 77 | – | 25 | 25 |
| 87 | 87 | 87 | – | 25 | 25 |
| 97 | 97 | 97 | – | 25 | 25 |
| 107 | 107 | – | – | 38 | 38 |
| 127 | 127 | – | – | 65 | 65 |
| 157 | 157 | – | – | 150 | 150 |


9. Make sure that all screws are loosened and slide the shrink disk onto the hollow shaft.



18014398721485067


24804134/EN – 05/2018

10. Slide the counter bushing onto the customer shaft and into the hollow shaft.




9007199466746251

11. In the case of a gear unit **with shaft shoulder**, mount the shrink disk at the shaft shoulder up to the stop. In the case of a gear unit **without shaft shoulder**, mount the shrink disk at a distance of 1 mm to 2 mm from the gear unit housing.
12. Tap lightly on the flange of the counter bushing to ensure that the bushing is fitted securely in the hollow shaft.




9007199466748427

13. Make sure that the customer shaft is seated in the counter bushing.




9007199466750603

14. Manually tighten the screws of the shrink disk. Make sure that the outer rings of the shrink disk are plane-parallel.



9007199466752779

15. Tighten the locking screws with the specified tightening torque according to the following table. Tighten the screws by working round several times from one bolt to the next (not in diametrically opposite sequence).



18014398721495947

INFORMATION



The exact values for the tightening torques are shown on the shrink disk.

INFORMATION




Standard shrink disks and stainless steel shrink disks have the same tightening torques.

| Gear unit type | | | | Locking screw | Tightening torque ± 4% |
|----------------|----------------|----------|------|---------------|---------------------------|
| FT.. | KT.. | ST.. | WT.. | ISO 4762 | Nm |
| — | — | 37 | 37 | M5 | 4 |
| 37 | 37 | 47 | 47 | M6 | 12 |
| 47/57/67 | 39/47/49/57/67 | 57/67 | — | M6 | 12 |
| 77/87/97 | 77/87/97 | 77/87/97 | — | M8 | 30 |
| 107 | 107 | — | — | M10 | 59 |
| 127/157 | 127/157 | — | — | M12 | 100 |



16. After installation, make sure the remaining gap "s" between the outer rings of the shrink disk is > 0 mm.

17. Make sure that the remaining gap between counter bushing and hollow shaft end, as well as between hollow shaft end and the stop ring is > 0 mm.



27021600112884107


18. Tighten the torque arm. Observe the information in chapter "Torque arms for shaft-mounted gear units" (\rightarrow 45).



20623147019


4.12.2 Mounting a customer shaft with contact shoulder

1. Clean the customer shaft and the inside of the hollow shaft. Ensure that all traces of grease or oil are removed.




9007214342258187

2. Attach the torque arm to the drive unit. Observe the information in chapter "Torque arms for shaft-mounted gear units" (→ 45).




K..7



S../W../K..9


20622111627

3. Slide the bushing onto the customer shaft.



2349377035


4. Apply NOCO® fluid directly to the bushing. Spread carefully.



2349367435


24804134/EN – 05/2018

5. Push the gear unit onto the customer shaft.




5129650443

6. Ensure that all screws are loosened. Slide the shrink disk onto the hollow shaft.



18014398721485067


7. Slide the counter bushing onto the customer shaft and into the hollow shaft.



9007199466746251


8. In the case of a gear unit **with shaft shoulder**, mount the shrink disk at the shaft shoulder up to the stop. In the case of a gear unit **without shaft shoulder**, mount the shrink disk at a distance of 1 mm to 2 mm from the gear unit housing.

9. Tap lightly on the flange of the counter bushing to ensure that the bushing is fitted securely in the hollow shaft.




9007199466748427

10. Make sure that the customer shaft is seated in the counter bushing.




9007199466750603

11. Manually tighten the screws of the shrink disk. Make sure that the outer rings of the shrink disk are plane-parallel.



9007199466752779

12. Tighten the locking screws with the specified tightening torque according to the following table. Tighten the screws by working round several times from one bolt to the next (not in diametrically opposite sequence).



18014398721495947

INFORMATION



The exact values for the tightening torques are shown on the shrink disk.

INFORMATION




Standard shrink disks and stainless steel shrink disks have the same tightening torques.

| Gear unit type | | | | Locking screw | Tightening torque ± 4% |
|----------------|----------------|----------|------|---------------|---------------------------|
| FT.. | KT.. | ST.. | WT.. | ISO 4762 | Nm |
| – | – | 37 | 37 | M5 | 4 |
| 37 | 37 | 47 | 47 | M6 | 12 |
| 47/57/67 | 39/47/49/57/67 | 57/67 | – | M6 | 12 |
| 77/87/97 | 77/87/97 | 77/87/97 | – | M8 | 30 |
| 107 | 107 | – | – | M10 | 59 |
| 127/157 | 127/157 | – | – | M12 | 100 |



13. After installation, make sure the remaining gap "s" between the outer rings of the shrink disk is > 0 mm.

14. Make sure that the remaining gap between counter bushing and hollow shaft end, as well as between the hollow shaft end and customer shaft shoulder is > 0 mm.



22017650059

15. Mount the torque arm and firmly tighten it. Observe the information in chapter "Torque arms for shaft-mounted gear units" (→ 45).



20623147019

4.12.3 Removing the shaft-mounted gear unit



▲ CAUTION


Risk of burns caused by hot surfaces

Severe injuries

- Let the units cool down before working on them.


Proceed as follows:

1. To prevent the outer rings from jamming, loosen the locking screws for a quarter turn, one after the other.



2903644171

2. Unscrew the locking screws evenly one after the other. Do not remove the locking screws completely.
3. Remove the conical steel bushing. If required, use the outer rings as pullers. Proceed as follows to do so:
 - Remove all the locking screws.
 - Screw the respective number of screws in the tapped holes of the shrink disk.
 - Support the inner ring against the gear unit housing.
 - Pull off the conical steel bushing by tightening the screws.
4. Remove the gear unit from the shaft.



9007202158521227

5. Remove the shrink disk from the hub.

INFORMATION



There is no need to dismantle removed shrink disks before they are reinstalled.

4.12.4 Cleaning and lubricating shaft-mounted gear units

Proceed as follows:

1. If the shrink disk is dirty, clean and lubricate the shrink disk.
2. Lubricate the tapered surfaces. Use one of the following solid lubricants:

| Lubricant (Mo S2) | Sold as |
|-------------------------------------|----------------|
| Molykote 321 (lube coat) | Spray |
| Molykote spray (powder spray) | Spray |
| Molykote G Rapid | Spray or paste |
| Aemasol MO 19P | Spray or paste |
| Aemasol DIO-sétral 57 N (lube coat) | Spray |

3. Grease the locking screws with a multipurpose grease such as Molykote BR 2.

4.13 Cover



⚠ CAUTION

Risk of injury due to rotating input and output elements during operation.

Risk of jamming and crushing.

- Equip the input and output elements with a touch guard.



INFORMATION


Observe the following points during installation:

- The seal must not be damaged.
- The glued connection between gasket and cover must be flawless.
- The bores of the gasket and the cover must match.

4.13.1 Mounting the fixed cover

Proceed as follows:

1. Remove the plastic plug on the gear unit housing (see figure 1).



9007199273238539

2. Use the delivered screws to mount the cover to the gear unit housing (see figure 2).

4.13.2 Operation without cover

In certain application cases, e.g. with a through-shaft, a cover cannot be installed. The cover is not necessary if the system or unit manufacturer provides corresponding components to guarantee for compliance with the required degree of protection. If this results in additional maintenance, the manufacturer has to describe this in the operating instructions for the system or component.

4.14 Coupling of AM adapter

**⚠ WARNING**

Risk of explosion due to electric sparks when using the spacer tube as assembly aid.

Fatal and serious injuries.

- Do not use the spacer tube as assembly aid but measure the distance.

4.14.1 Mounting the IEC adapter AM63 – 280/NEMA adapter AM56 – 365

NOTICE


Damage to adapter due to ingress of moisture when mounting a motor to the adapter.

Damage to the adapter

- Seal the adapter with an anaerobic fluid seal.

INFORMATION

To avoid contact corrosion, SEW-EURODRIVE recommends to apply NOCO® fluid to the motor shaft before mounting the coupling half.



27021597976322955

- [1] Motor shaft
[479] Coupling half
[481] Set screw

- [484] Key
[491*] This spacer tube must not be used due to the risk of electric sparks

Proceed as follows:

1. Clean the motor shaft and flange surfaces of the motor and the adapter.

2. Remove the key from the motor shaft. Replace the key from the motor shaft with the supplied key [484] (not AM63 and AM250).
3. Heat the coupling half [479] to approx. 80 – 100 °C and push the coupling half onto the motor shaft. Position as follows:
 - IEC adapter AM63 – 225 until stop at motor shaft shoulder.
 - IEC adapter AM250 – 280 to distance "A". The values for the distance "A" are listed in the following table.
 - NEMA adapter to distance "A". The values for the distance "A" are listed in the following table.
4. Secure the key and coupling half using the set screw [481] on the motor shaft. Refer to the following table for the required tightening torque "T_A".
5. Check the position of the coupling half. The values for the distance "A" are listed in the following table.
6. Seal the contact surfaces between the adapter and motor using a suitable sealing compound.
7. Mount the motor on the adapter. Ensure that the coupling claws of the adapter shaft are engaged in the plastic cam ring.

| IEC AM | 63/71 | 80/90 | 100/112 | 132 | 160/180 | 200 | 225 | 250/280 |
|----------------------|-------|---------|---------|---------|---------|---------|---------|---------|
| A | 24.5 | 31.5 | 41.5 | 54 | 76 | 78.5 | 93.5 | 139 |
| T_A | 1.5 | 1.5 | 4.8 | 4.8 | 10 | 17 | 17 | 17 |
| Thread | M4 | M4 | M6 | M6 | M8 | M10 | M10 | M10 |
| NEMA AM | 56 | 143/145 | 182/184 | 213/215 | 254/256 | 284/286 | 324/326 | 364/365 |
| A | 46 | 43 | 55 | 63.5 | 78.5 | 85.5 | 107 | 107 |
| T_A | 1.5 | 1.5 | 4.8 | 4.8 | 10 | 17 | 17 | 17 |
| Thread | M4 | M4 | M6 | M6 | M8 | M10 | M10 | M10 |

Permitted loads

NOTICE

Overloading of the gear unit due to excessive weight or excessive power rating of an attached motor.

Gear unit failure

- Note that the load data specified in the following table are not to be exceeded.
- Make sure that the approved power rating (torque and speed) on the adapter is observed according to the nameplate.

NOTICE


Danger due to static overdetermination when motors are additionally attached via a foot plate.

Damage to property

- A motor attached at the foot relieves the interface on the adapter, but you have to make sure that the attached foot-mounted motor is attached to the customer's construction stress-free.

4 Mechanical installation

Coupling of AM adapter



9007199273254411

- ⊗ Motor's center of gravity
X Distance from adapter flange – motor center
 F_R Overhung load

Permitted loads for gear unit series R..7, F..7, K..7, K..9, and S..7:

| Adapter type | | $x^{1)}$ mm | $F_R^{1)}$ N | |
|---------------------|-------------------------|----------------|-----------------|--------------|
| IEC | NEMA | | IEC adapter | NEMA adapter |
| AM63/71 | AM56 | 77 | 530 | 410 |
| AM80/90 | AM143/145 | 113 | 420 | 380 |
| AM100/112 | AM182/184 | 144 | 2000 | 1760 |
| AM132 ²⁾ | AM213/215 ²⁾ | 186 | 1600 | 1250 |
| AM132.. | AM213/215 | | 4700 | 3690 |
| AM160/180 | AM254/286 | 251 | 4600 | 4340 |
| AM200/225 | AM324-AM365 | 297 | 5600 | 5250 |
| AM250/280 | - | 390 | 11200 | — |

- 1) If the center of gravity distance x increases, the maximum permitted weight $F_{R_{max}}$ of the attached motor must be reduced linearly. If this center of gravity distance x is reduced, it is not permitted to increase the maximum permitted weight $F_{R_{max}}$.
- 2) Diameter of the adapter output flange: 160 mm

24804134/EN – 05/2018

Permitted loads for gear unit series SPIROPLAN® W37 – W47

| Adapter type | | x ¹⁾ mm | F _R ¹⁾ N | |
|--------------|-----------|-----------------------|-----------------------------------|--------------|
| IEC | NEMA | | IEC adapter | NEMA adapter |
| AM63/71 | AM56 | 115 | 140 | 120 |
| AM80/90 | AM143/145 | 151 | 270 | 255 |

1) If the center of gravity distance x increases, the maximum permitted weight F_{R_max} of the attached motor must be reduced linearly. If this center of gravity distance x is reduced, it is not permitted to increase the maximum permitted weight F_{R_max}.

4.14.2 AM adapter with AM../RS backstop

Check the direction of rotation of the drive prior to mounting or startup. In case of a wrong direction of rotation, contact SEW-EURODRIVE.

The backstop is maintenance-free in operation. Backstops have a minimum lift-off speed depending on the size (see following table).

NOTICE

If the speed is below the minimum lift-off speed of the drive, the backstop is subject to wear and heats up.

Possible damage to property.

- In nominal operation the lift-off speed of the drive must not drop below the specified minimum.
- During startup or braking, the lift-off speed of the drive may drop below the minimum levels.

| Type | Maximum locking torque of the backstop Nm | Minimum lift-off speed min ⁻¹ |
|------------------------------|--|---|
| AM80/90/RS AM143/145/RS | 65 | 820 |
| AM100/112/RS AM182/184/RS | 425 | 620 |
| AM132/RS AM213/215/RS | 850 | 530 |
| AM160/180/RS AM254/286/RS | 1450 | 480 |
| AM200/225/RS AM324-365/RS | 1950 | 450 |
| AM250/280/RS | 1950 | 450 |

4.14.3 Mounting of third-party motors at AM and AR/AL adapters

If a third-party motor is mounted, the customer must ensure that the permitted weight and the power at the adapter are adhered to according to the operating instructions. For information on the permitted loads, refer to chapter "Permitted loads" (→ 75).

| Type | X ¹⁾ mm | F _R ¹⁾ N |
|------------------------|-----------------------|-----------------------------------|
| AR/AL71 | 77 | 375 |
| AR/AL80/90 | 113 | 320 |
| AR/AL100/112 | 144 | 1560 |
| AR/AL132 ²⁾ | 186 | 1230 |
| AR/AL132 | 186 | 3630 |
| AR/AL160/180 | 251 | 3540 |

¹⁾ If the center of gravity distance x increases, the maximum permitted weight F_{R_max} of the attached motor must be reduced linearly. If the center of gravity distance x decreases, the maximum permitted weight F_{R_max} must not be increased.

²⁾ Diameter of the adapter output flange: 160 mm

4.14.4 AM adapter with foot-mounted motor

A foot-mounted motor reduces the loads at the adapter interface. The foot-mounted motor at the adapter must be installed without tensions at the customer construction.

4.15 AQ. adapter coupling



⚠ WARNING

Risk of explosion due to electric sparks when using the spacer tube as assembly aid.

Fatal and serious injuries.

- Do not use the spacer tube as assembly aid but measure the distance.

4.15.1 Mount adapter AQA80 – 190 (with keyway)/Adapter AQH80 – 190 (without keyway)

NOTICE

Damage to the adapter due to ingress of moisture or dirt (e.g. dust) when a motor/drive is attached to the adapter.

Damage to the adapter


- Seal the adapter with an anaerobic fluid seal.
- When the motor/drive to be attached has openings or bores that provide access to the inside of the adapter, seal these against dust or liquid.



INFORMATION

For AQA: To avoid contact corrosion, SEW-EURODRIVE recommends applying NOCO® fluid to the motor shaft before mounting the coupling half.

For AQH: Using NOCO® fluid is not approved.



9007199466855947

- | | |
|-----------------|---------------------|
| [1] Motor shaft | [3] Washer |
| [2] Lock washer | [479] Coupling half |

Proceed as follows:

1. Clean the motor shaft and flange surfaces of the motor and the adapter.
2. **AQH design:** Loosen the screws of the coupling half [479] and loosen the conical connection.
3. **AQA/AQH design:** Heat the coupling half to approx. 80 – 100 °C and push the coupling half onto the motor shaft up to distance "A". The values for the distance "A" are listed in the table in chapter "Setting standards and tightening torques" (→ 80).
4. **AQH design:** Tighten the screws at the coupling half evenly in diametrically opposite sequence, working round several times. The values for the tightening torque " T_A " are listed in the table in chapter "Setting standards and tightening torques" (→ 80).
5. **AQA design:** Secure the coupling half using the set screw (see figure).
6. Check the position of the coupling half. The values for the distance "A" are listed in the table in chapter "Setting standards and tightening torques" (→ 80).
7. Mount the motor onto the adapter, making sure that the claws of the two coupling halves engage in each other.
 - ⇒ The force that must be applied when joining the two coupling halves is dissipated after final assembly, so there is no risk of any axial load being applied to adjacent bearings.

4.15.2 Setting standards and tightening torques

| Type | Coupling Ø mm | Distance A mm | Screws | | Tightening torque T _A Nm | |
|---------------------|------------------|------------------|--------|--------|--|-------|
| | | | AQA.. | AQH.. | AQA.. | AQH.. |
| AQA/AQH 80 /1 /2 /3 | 19 | 44.5 | M5 | 6 x M4 | 2 | 4 |
| AQA/AQH 100 /1 /2 | | 39 | | | | |
| AQA/AQH 100 /3 /4 | | 53 | | | | |
| AQA/AQH 115 /1 /2 | | 62 | | | | |
| AQA/AQH 115 /3 | 24 | 62 | M5 | 4 x M5 | 2 | 9 |
| AQA/AQH 140 /1 /2 | | 62 | | | | |
| AQA/AQH 140 /3 /4 | 28 | 74.5 | M8 | 8 x M5 | 10 | 9 |
| AQA/AQH 160 /1 | | 74.5 | | | | |
| AQA/AQH 190 /1 /2 | | 76.5 | | | | |
| AQA/AQH 190 /3 | 38 | 100 | M8 | 8 x M6 | 10 | 14 |

4.15.3 Permitted loads

NOTICE

Overloading of the gear unit due to excessive weight or excessive power rating of an attached motor.

Gear unit failure

- Note that the load data specified in the following table are not to be exceeded.
- Make sure that the approved power rating (torque and speed) on the adapter is observed according to the nameplate.


NOTICE

Danger due to static overdetermination when motors are additionally attached via a foot plate.

Damage to property

- A motor attached at the foot relieves the interface on the adapter, but you have to make sure that the attached foot-mounted motor is attached to the customer's construction stress-free.

The following figure shows the permitted force application points for the permitted maximum weights:




9007199273254411

- ⊗ Motor's center of gravity
 X Adapter flange – motor center distance
 F_R Overhung load

| Type | $x^{1)}$ mm | $F_R^{1)}$ N |
|-------------------------|----------------|-----------------|
| AQ80 | 77 | 370 |
| AQ100/1/2 | 113 | 350 |
| AQ100/3/4 | 113 | 315 |
| AQ115 | 113 | 300 |
| AQ140/1/2 | 144 | 1550 |
| AQ140/3 | 144 | 1450 |
| AQ160 | 144 | 1450 |
| AQ190/1/2 ²⁾ | 186 | 1250 |
| AQ190/3 ²⁾ | 186 | 1150 |
| AQ190/1/2 | 186 | 3750 |
| AQ190/3 | 186 | 3400 |

- 1) Maximum load values for connection screws of strength class 8.8. If the center of gravity distance x increases, the maximum permitted weight $F_{R_{max}}$ of the attached motor must be reduced linearly. If the center of gravity distance x decreases, the maximum permitted weight $F_{R_{max}}$ must not be increased.
- 2) Diameter of the adapter output flange: 160 mm

4.16 Adapter with AR slip clutch



Drives with a slip clutch consist of a standard gear unit and a motor/variable-speed gearmotor with an adapter installed between them. This adapter accommodates the slip clutch. In gearmotors with a compound gear unit, the slip clutch may be located between the first and second gear unit.

Via the friction lining [4] of the driving disk [3], the input friction hub [7] with cup springs [5] and slotted nut [6] drives the output coupling plate with connecting pin. The slip torque is set individually according to the drive selection.

The speed of the coupling plate at the output end is picked up by a voltage encoder [2] and passed on to a monitoring unit [8]. Speed monitors and slip monitors are used as monitoring units. You can install them together with contactors, safety devices, etc. on a 35 mm standard rail (according to DIN EN 50 022) in a control cabinet or mounted via 2 bores.

4.16.1 WEX speed monitor

INFORMATION



The speed monitor and remote speed indication must be located outside the potentially explosive area.


The speed monitor [8] is used for gearmotors with constant speed. The speed monitor is connected to the voltage encoder [2] in the adapter.

4.16.2 Mount voltage encoder

Proceed as follows:

1. Remove the fan guard from the driving motor.

2. Slowly turn the motor and adapter shaft end until you can see a trip cam meaning the head of the cap screw in the tapped hole.
3. Screw in the voltage encoder [1] so deep that it touches the trip cam.



212097803

4. Turn back the voltage encoder [1] by 2 revolutions. It corresponds to a distance of approx. 2 mm.
5. Secure the voltage encoder at the adapter outside using a lock nut.
6. Check to see if the trip cam does not touch the voltage encoder while slowly turning the motor and adapter shaft end.
7. Reinstall the fan guard at the driving motor.

4.16.3 Connecting monitoring devices

INFORMATION



- To prevent interference voltages, do not route the supply lines in multicore cables.
- Use cables with a maximum length of 500 m and a core cross section of 1.5 mm².
- If there is a risk of interference from power current or control cables and if the lines are longer than 10 m, use shielded cables.
- Observe the applicable standards especially in the explosion-proof area.

Proceed as follows:

1. For designs with WEX speed monitor, connect the incremental encoder of the adapter to the speed monitor via a 2-core cable.
 - ⇒ The incremental encoder supplies 1 pulse/revolution.
2. Connect the speed monitor according to the enclosed wiring diagram.

4.17 AD input shaft assembly


For mounting drive components, observer chapter "Assembling input and output elements" (→ 43).

INFORMATION



- Only use belts with sufficient electrical leakage resistance ($< 10^9 \Omega$) between the output shaft end and the motor shaft.
- Prior to installation of the protection cover, a risk analysis performed by the manufacturer of the protection cover must demonstrate that no sources of ignition can occur (such as impact sparks from grinding).

4.17.1 Mounting the cover with motor platform AD../P



212119307

- | | |
|------------------------------------|---------------------|
| [1] Motor platform | [4] Nut |
| [2] Stud bolt (only AD6/P / AD7/P) | [5] Threaded column |
| [3] Support (only AD6/P / AD7/P) | |

To mount the motor and to adjust the motor platform proceed as follows:

1. Set the motor platform [1] to the required mounting position by evenly tightening the adjusting nuts [4].
2. If necessary, remove the lifting eyebolt/lifting eye of the helical gear unit to reach the lowest adjustment position. Touch up any damage to the paint work.
3. Align the motor on the motor platform [1] so that the shaft ends are in line. Attach the motor.
4. Mount the drive component onto the input side shaft end and the motor shaft.
5. Align drive component, shaft end and motor shaft. If necessary correct the motor position again.

6. Put on the traction elements (V-belt, chain, etc.) and apply a preload by evenly adjusting the motor platform [1]. Do not stress the motor platform and the columns against each other when doing this.
7. To fasten the threaded columns [5] tighten the nuts [4] that are not used for adjustment.

4.17.2 Special aspects of AD6/P and AD7/P

Proceed as follows:

1. Unscrew the nuts on the threaded bolts [2] before adjustment to allow the threaded bolts [2] to move axially in the support [3] without restriction.
2. Only tighten the nuts when the final adjustment position is reached.

INFORMATION




Do not adjust the motor platform [1] via the support [3].

4.17.3 AD../ZR input shaft assembly with centering shoulder

Mounting applications on the input shaft assembly with centering shoulder

1. Prepare screws of a suitable length for attaching the application. The following figure shows the screw length $l = t + a$. **Round off the result to the next smaller standard length.**



18014398721603467

- | | | | |
|---|------------------------------------|---|------------------------------|
| a | Strength of the additional element | s | Retaining thread (see table) |
| t | Screw-in depth (see table) | | |

2. Remove the retaining screw from the centering shoulder
3. Clean the contact surface and the centering shoulder.
4. Clean the threads of the new bolts and apply a thread locking compound (e.g. Loctite® 243) to the first few threads.
5. Place the application on the centering shoulder. Tighten the retaining screws with the specified tightening torque " T_A " (see following table).

4 Mechanical installation

AD input shaft assembly

| Type | Screw-in depth t mm | Retaining thread | Tightening torque T_A for connection screws of strength class 8.8 Nm |
|--------|------------------------|------------------|---|
| AD2/ZR | 25.5 | M8 | 27 |
| AD3/ZR | 31.5 | M10 | 54 |
| AD4/ZR | 36 | M12 | 93 |
| AD5/ZR | 44 | M12 | 93 |
| AD6/ZR | 48.5 | M16 | 230 |
| AD7/ZR | 49 | M20 | 464 |
| AD8/ZR | 42 | M12 | 93 |

Permitted loads

NOTICE

Overloading of the gear unit due to excessive weight or excessive power rating of an attached motor.

Gear unit failure

- Note that the load data specified in the following table are not to be exceeded.
- Make sure that the approved power rating (torque and speed) on the adapter is observed according to the nameplate.


NOTICE

Danger due to static overdetermination when motors are additionally attached via a foot plate.

Damage to property

- A motor attached at the foot relieves the interface on the adapter, but you have to make sure that the attached foot-mounted motor is attached to the customer's construction stress-free.

The following figure shows the permitted force application points for the permitted maximum weights:



- ⊗ Motor's center of gravity
- X Distance from adapter flange – motor center

F_R Overhung load

24804134/EN – 05/2018

| Type | $x^{1)}$ mm | $F_R^{1)}$ N |
|----------------------|----------------|-----------------|
| AD2/ZR | 193 | 330 |
| AD3/ZR | 274 | 1400 |
| AD4/ZR ²⁾ | 361 | 1120 |
| AD4/ZR | | 3300 |
| AD5/ZR | 487 | 3200 |
| AD6/ZR | 567 | 3900 |
| AD7/ZR | 663 | 10000 |
| AD8/ZR | 516 | 4300 |

- 1) Maximum load values for connection screws of strength class 8.8. If the center of gravity distance x increases, the maximum permitted weight $F_{R_{max}}$ of the attached motor must be reduced linearly. If the center of gravity distance x decreases, the maximum permitted weight $F_{R_{max}}$ must not be increased.
- 2) Diameter of the adapter output flange: 160 mm

4.17.4 Cover with backstop AD../RS

NOTICE

If the speed is below the minimum lift-off speed of the drive, the backstop is subject to wear and heats up.

Possible damage to property.

- In nominal operation the lift-off speed of the drive must not drop below the specified minimum.
- During startup or braking, the lift-off speed of the drive may drop below the minimum levels.

Check the direction of rotation of the drive prior to mounting or startup. In case of a wrong direction of rotation, contact SEW-EURODRIVE.


The backstop is maintenance-free in operation. Backstops have a minimum lift-off speed depending on the size (see following table).

| Type | Maximum locking torque of the backstop Nm | Minimum lift-off speed min ⁻¹ |
|--------|---|---|
| AD2/RS | 65 | 820 |
| AD3/RS | 425 | 620 |
| AD4/RS | 850 | 530 |
| AD5/RS | 1450 | 480 |
| AD6/RS | 1950 | 450 |
| AD7/RS | 1950 | 450 |
| AD8/RS | 1950 | 450 |

4.18 Accessory equipment

4.18.1 Oil drain valve

The gear unit is equipped with an oil drain plug as standard. An oil drain valve can optionally be installed, that enables attaching a drain pipe for changing the gear unit oil.




4984750475

4.18.2 Oil expansion tank

The oil expansion tank allows the lubricant or air space of the gear unit to expand. This means no lubricant can escape the breather valve at high operating temperatures.

SEW-EURODRIVE recommends to use oil expansion tanks for gear units and gear-motors in M4 mounting position and for input speeds $> 2000 \text{ min}^{-1}$.

The following figure shows the oil expansion tank of a gearmotor.



4979181323

The oil expansion tank is delivered as assembly kit for mounting onto the gearmotor. In case of limited space or of gear units without motor, the oil expansion tank can also be mounted to nearby machine parts.

INFORMATION



Transverse acceleration is not permitted for gear units with expansion tank with fixed piping for third party motors and servomotors.

For further information, contact your SEW-EURODRIVE sales representative.

4.18.3 Agitator design

Relubrication of the agitator design

A relubrication of the output shaft bearing is offered as an option for the agitator drives FM., FAM., KM.. and KAM...


Position of greasing points

INFORMATION



The gear shaft must turn during the relubrication procedure.

Regreasable sealing systems are usually equipped with taper greasing nipples according to DIN 71412 A. The following figure shows the position of the greasing points:




23563258507


Maintenance interval and grease quantities

Relubricate the agitator design after 10000 operating hours. The number of relubrication procedures is limited to 5×. Observe the information on the required grease quantities in the following table:

| Size | Grease quantity for relubrication g |
|------|--|
| 67 | 5 |
| 77 | 11 |
| 87 | 11 |
| 97 | 16 |
| 107 | 35 |
| 127 | 34 |
| 157 | 46 |

The table shows the lubricants recommended by SEW-EURODRIVE:

| Area of operation | Ambient temperature | Manufacturer | Type |
|---|---------------------|-----------------|---------------------------------|
| Standard | -40 °C to +80 °C | Fuchs | Renolit CX-TOM 15 ¹⁾ |
| | -40 °C to +80 °C | Klüber | Petamo GHY 133 N |
|  ²⁾ | -40 °C to +40 °C | Bremer & Leguil | Cassida Grease GTS 2 |

| Area of operation | Ambient temperature | Manufacturer | Type |
|---|---------------------|--------------|--------------|
|  | -20 °C to +40 °C | Fuchs | Plantogel 2S |

- 1) Bearing grease based on semi-synthetic base oil
- 2) Lubricant for the food processing industry
- 3) Easily biodegradable lubricant for environmentally sensitive areas

INFORMATION



If a customer wants to use a grease that is not listed in the above table, the customer has to make sure that it is suitable for the intended application.

4.18.4 Temperature sensor

INFORMATION




If the oil temperature is $>115\text{ °C}$, the drive must be switched off.

INFORMATION



To ensure intrinsically safe wiring, the temperature sensor must be used with a Zener barrier. The current consumption of the Zener barrier enables correct measuring operation. The Zener barrier must be located outside the potentially explosive atmosphere.


PT100 screw-in temperature sensor, connection element shape J



9007199869992331

24804134/EN – 05/2018

PT100 dimension drawing




4139976587

PT100 technical data

| Technical data | Value |
|-----------------------|---|
| Area of application | For monitoring the oil temperature |
| Operating temperature | -50 °C to 400 °C |
| Ambient temperature | -40 °C to 100 °C |
| Thermowell | Stainless steel (1.4571) |
| Connection element | Shape J, aluminum die-casting, M16x1.5, IP54 |
| Outer thread | G1/2 A-cylindrical according to DIN EN ISO 228 |
| Measuring insert | According to DIN EN 60751 class B in two-wire circuit, without measuring transducer |
| Manufacturer | JUMO (JUM according to W93DE) |
| SEW part number | 13274171 |

PT100 connection diagram




359158539

Contact 1 and 2: Connection of the resistance element

PT1000 temperature sensor

PT1000 dimension drawing




15115011083

PT1000 technical data

| Technical Data | Value |
|--|--|
| Rod length | 62.5 mm |
| Measuring range | -40 – 130 °C |
| Permitted oil temperature | -40 – 130 °C |
| Accuracy | ± (PT1000 + 0.2 K) |
| Measuring element | 1 × PT1000 to DIN EN 60751, class B, 4-wire connection |
| Dynamic response T05/T09 (s) | 3/8 to DIN EN 60751 |
| Ambient temperature | -25 – 80 °C |
| Degree of protection, protection class | IP67, III |
| Housing materials | V4A (1.4404) |
| Materials in contact with the medium | V4A (1.4404) |
| Port | M12 plug-in connection; gold-plated contacts |

PT1000 connection diagram



15115128971

24804134/EN – 05/2018

5 Startup

NOTICE

Improper startup may result in damage to the gear unit.

Possible damage to property.

- Observe the following notes.

- Before startup, always check to see that the oil level is correct. Refer to the unit's nameplate for lubricant fill quantities.
- The oil checking and drain screws and the breather valves must be freely accessible.
- Observe the maximum and r.m.s values of project planning during startup of gear units with servomotor. The buyer is obliged to make the data available to the end user.
- The most important technical data is provided on the nameplate. Additional data relevant for operation is available in drawings and the order confirmation.
- After gear unit setup, ensure that all retaining screws are tight.
- Make sure that the alignment has not changed after tightening the mounting elements.
- Prior to startup, ensure that rotating shafts as well as couplings are equipped with suitable protective covers.
- If an oil sight glass is used for oil level monitoring, protect it against damage.
- It is essential that there is no open fire or risk of sparks when working on the gear unit.
- Protect the gear unit from falling objects.
- Remove transport protection prior to startup.
- Observe the safety notes.

5.1 Checklists

5.1.1 Before startup

This checklist includes all activities that will have to be executed **prior to startup** of a gear unit according to Directive 2014/34/EU for operation in potentially explosive atmospheres.

| Check prior to startup in potentially explosive atmospheres | Verified | See chapter |
|--|----------|--------------|
| Inspect the shipment for damage as soon as you receive the delivery. Inform the shipping company immediately about any damage. It may be necessary to suspend startup. Remove any transport protection prior to startup. | | 2.6 |
| Does the data on the nameplate of the drive match the situation on site for operation in a potentially explosive area? <ul style="list-style-type: none"> • Equipment group • Explosion protection category • Temperature class • Maximum surface temperature | | 3.9 4.2 |
| Have arrangements been made to prevent potentially explosive atmospheres (oils, acids, gases, vapors or radiation) during installation of the gear unit? | | |
| Does the ambient temperature comply with the specifications (nameplate and order confirmation)? | | 3.9 |
| Have measures been taken to ensure that the gear units are sufficiently ventilated and that they are not heated by an external heat source (e.g. the coupling)? The cooling air must not exceed the maximum ambient temperature designated on the nameplate. | | |
| Does the mounting position correspond to the specifications on the gear unit nameplate? Do not change the mounting position without prior consultation with SEW-EURODRIVE. ATEX approval will become void without prior consultation. | | 7.0 |
| Does the oil level for the mounting position on the gear unit nameplate correspond to the indicated oil fill quantity? | | 3.9 |
| Are all oil level plugs, oil drain plugs as well as breather plugs and breather valves freely accessible? | | 7.6 |
| Do all input and output elements to be installed have ATEX certification? | | |
| Ensure that the data specified on the nameplate are not exceeded for stand-alone gear units with adapters or input shaft assembly. | | 3.9 |
| Is the cover mounted properly for gear units with hollow shaft and shrink disk? | | 4.11 |
| Ensure that no spacer bushing is used as assembly aid during the installation of the AM, AQA adapter. | | 4.14 4.15 |
| When mounting a motor on the AD input shaft assembly: <ul style="list-style-type: none"> • Does the belt have sufficient electrical leakage resistance $< 10^9 \Omega$ between input shaft end and motor shaft? • Before mounting a protection cover: Does a risk analysis performed by the manufacturer of the protection cover demonstrate that no sources of ignition can occur (such as impact sparks from grinding)? | | 4.17 |

| Check prior to startup in potentially explosive atmospheres | Verified | See chapter |
|--|----------|-------------|
| For mains-operated motors: <ul style="list-style-type: none"> Does the data specified on the nameplate of the gear unit and the motor correspond to the ambient conditions at the location where the drive is to be installed? | | 3.9 |
| When operating gearmotors with inverter: <ul style="list-style-type: none"> Is the gearmotor approved for inverter operation? Does the parameterization of the inverter prevent the gear unit from being overloaded (see gear unit nameplate)? | | 3.9 |

5.1.2 During startup

This checklist includes all activities that will have to be executed **during startup** of a gear unit according to Directive 2014/34/EU for operation in potentially explosive atmospheres.

| Check during startup in potentially explosive atmospheres | Verified | See chapter |
|---|----------|--------------|
| Check surface temperature: <ul style="list-style-type: none"> Measure the surface temperature after 3 hours of operation. Do not exceed a temperature difference of 70 K compared to the ambient temperature. At a value > 70 K immediately set the drive to standstill. Contact SEW-EURODRIVE. | | 5.5 |
| Lubricant change intervals: <ol style="list-style-type: none"> Measure the oil temperature. Add 10 K to the measured value. Determine the lubricant change interval based on the calculated value. | | 5.5 6.4 |
| For gear units with AM adapter or AD input shaft assembly with RS backstop: <ul style="list-style-type: none"> Check if in nominal operation, the lift-off speeds of the backstops does not drop below the minimum values. | | 4.14 4.17 |

5.2 Inverter-operated gearmotors

For gear units with servomotor, the maximum and r.m.s. values of project planning must be observed during startup. The buyer is obliged to make the data available to the user.

5.3 Checking the oil level

Before startup, make sure that the oil level corresponds to the mounting position. Observe chapter "Checking the oil level and changing the oil" (→ 118).

If the gear unit is equipped with an oil sight glass, you can also determine the oil level at the oil sight glass.


NOTICE

Damage to the gear unit due to oil leaking from the damaged oil sight glass.

Possible damage to the unit

- Attach a protective device to prevent the oil sight glass from being damaged by mechanical impacts.

1. Observe the information at the beginning of chapter "Inspection/maintenance" (→ 107).
2. Check the oil level at the oil sight glass according to the following figure:



4158756363

[1] The oil level must be within this range.

3. Proceed as follows if the oil level is too low:
 - Open the respective oil fill plug, see chapter "Inspection/maintenance for the gear unit" (→ 118).
 - Fill in new oil of the same type via the oil fill plug up to the mark.
 - Screw in the oil fill plug.

Before startup, make sure that the oil level corresponds to the mounting position. Observe chapter "Checking the oil level and changing the oil" (→ 118).

5.4 Pseudo-leakage at shaft seals

Due to their operating principle, seals between moving surfaces at shaft passages cannot be completely tight, as a lubricant film must form during operation. The lubricant film between shaft and sealing lip keeps the built-up of heat and wear on the sealing system to a minimum and ensures the intended service life. The optimum sealing properties are only achieved after the run-in phase.

5.5 Measuring surface and oil temperature

INFORMATION



The nameplate data on maximum surface temperature is based on measurements at standard ambient conditions and installation altitudes. Even slight changes of these conditions (such as limited installation space) can have a tremendous impact on the temperature.

5.5.1 Measuring the surface temperature


It is absolutely necessary to measure the surface temperature at maximum load during startup of the gear unit. A commercially available thermometer is sufficient for this measurement. Measure the surface temperature at the transition space between gear unit and motor where the position of the terminal box prevents venting by the motor fan. The maximum surface temperature will be reached after approximately 3 hours and **must not exceed a difference value of 70 K** compared to the ambient temperature.

INFORMATION



Stop the drive immediately if the difference exceeds the given value. Contact SEW-EURODRIVE in this case.

For gear units with AM, AQ, AR adapter, or AD input shaft assembly, the surface temperature is measured at the joint between input gear unit flange and customer motor flange (see following picture).



18669579

5.5.2 Measuring the oil temperature

It is necessary to measure the oil temperature to determine the lubricant change intervals set forth in the chapter "Inspection and maintenance" (→ 107). Measure the temperature at the bottom of the gear unit. In case of gear units with oil drain plug, measure the temperature at the oil drain plug. Add 10 K to the measured value. Determine the lubricant change interval based on this temperature values, see chapter "Lubricant change intervals" (→ 112).

5.6 Helical-worm gear units and SPIROPLAN® W gear units

5.6.1 Run-in period

SPIROPLAN® and helical-worm gear units require a run-in period of at least 48 h before reaching their maximum efficiency. A separate run-in period applies for each direction of rotation if the gear unit is operated in both directions of rotation. The table shows the average power reduction during the run-in period.

Helical-worm gear units

| | Worm | |
|----------------|----------------|------------------|
| | i range | η reduction |
| 1-start | About 50 – 280 | Approx. 12% |
| 2-start | About 20 – 75 | Approx. 6% |
| 3-start | About 20 – 90 | Approx. 3% |
| 4-start | – | – |
| 5-start | About 6 – 25 | Approx. 3% |
| 6-start | About 7 – 25 | Approx. 2% |

SPIROPLAN® gear units

| W10/W20/W30 | | W37/W47 | |
|---------------|------------------|---------------|------------------|
| i range | η reduction | i range | η reduction |
| About 35 – 75 | Approx. 15% | | |
| About 20 – 35 | Approx. 10% | | |
| About 10 – 20 | Approx. 8% | About 30 – 70 | Approx. 8% |
| Approx. 8 | Approx. 5% | About 10 – 30 | Approx. 5% |
| Approx. 6 | Approx. 3% | About 3 – 10 | Approx. 3% |

5.6.2 Helical-worm gear unit with projecting worm shaft



⚠ WARNING

Risk of explosion due to electric sparks of rotating unit parts.

Fatal and serious injuries.

- Take appropriate measures to prevent rotating unit parts to come into contact with foreign objects (e.g. install cover).




⚠ CAUTION

Risk of injury due to rotating parts.

Injuries

- Before you operate the helical-worm gear unit using the inserted handwheel or the hand crank, de-energize the drive.
- If the handwheel or the hand crank remains attached to the shaft during operation, take appropriate measures to prevent injuries.

The following figure shows a helical-worm gearmotor with projecting worm shaft:



15050784011

5.7 Helical/parallel-shaft helical/helical-bevel gear units

If the gear units were installed according to chapter "Mechanical installation" (→ 29), no special startup notes must be observed for helical, parallel-shaft helical and helical-bevel gear units.

5.8 Gear units with backstop


NOTICE

Operating the motor in the blocking direction could destroy the backstop.

Possible damage to property

- Do not start up the motor in the blocking direction. Before motor startup, make sure the current supply of the motor for the direction of rotation is connected accordingly.
- For control purposes, operation in blocking direction with half the output torque is permitted once.

The purpose of a backstop is to prevent unwanted directions of rotation. During operation, the backstop permits rotation only in the specified direction.



659173899


The permitted direction of rotation is indicated by a direction arrow on the housing:



15985405835

A replacement label is enclosed for the customer.

In right-angle gear units, you also have to indicate whether the direction of rotation is given looking onto the A or B-side.



16117549579

- | | | | |
|----------------------------------|-----------------------|-----------------------|-----------------------|
| [1] Viewing direction | Direction of rotation | [2] Viewing direction | Direction of rotation |
| | Output B | | Output A and A+B |
| [3] Viewing direction | Direction of rotation | [4] Gear unit | |
| | Input end | | |
| [5] Adapter/cover with RS option | | | |

5.9 Speed monitoring

5.9.1 WEX option standard design

The standard version of the explosion-proof AR adapter features an M12×1 thread for mounting a voltage encoder in the motor flange of the adapter. Speed monitor and voltage encoder are included in the delivery.

5.9.2 Manufacturer's data

Speed monitor in WEX design:

| | |
|----------------------------|----------------------------|
| Manufacturer: | Pepperl + Fuchs, Mannheim |
| Type: | KFU8-UFC-Ex1.D |
| Auxiliary voltage: | DC 20 – 90 V/AC 48 – 253 V |
| ATEX certification number: | TÜV 99 ATEX 1471 |

Voltage encoder data in WEXA/WEX/IGEX design:

| | |
|----------------------------|-------------------------------------|
| Manufacturer: | Pepperl + Fuchs, Mannheim |
| Type: | NCB2-12GM35-N0 to DIN 19234 (NAMUR) |
| Housing: | M12×1 |
| ATEX certification number: | TÜV 99 ATEX 1471 |

5.10 Installation and adjustment of the WEX speed monitor

1. Read the operating instructions of the speed monitor manufacturer before you begin with the installation.
2. Perform the basic adjustment of the speed monitor in accordance with the operating instructions of the speed monitor manufacturer.

When the nominal speed of the motor in use is undercut by 5%, the settings must cause the drive to be switched off. Refer to the nameplate for the nominal speed of the driving motor.

The sensor integrated in the adapter generates 1 pulse per revolution of the adapter shaft. If the switching speed of the adapter is too low, i.e. the coupling slips, the driving motor must be disconnected from the supply voltage immediately.

The cause of the problem must be eliminated and the operation of the adapter must be stopped for at least 15 minutes before re-startup. If incorrect operation by the operating personnel cannot be ruled out, this interval should be guaranteed using an automatic restart lockout.

All following installation and setting notes given refer to the speed monitor or voltage encoder in WEX design.


If the installation and setting instructions do not correspond to the speed monitor included in the delivery, perform the installation and startup according to the documentation of the manufacturer.

The speed monitor must be located outside the potentially explosive atmosphere.

5.10.1 Installation and adjustment of the WEXA/WEX speed monitor

Relay 2 can be used for creating a warning signal or for machine control (terminal assignment 16 – 18).

The wiring diagram below shows possible connection of the speed monitor.




18698891

- [1] Sensor +
- [3] Sensor -
- [10] Relay 1 (common connection)
- [11] Relay 1 (NO contact)
- [12] Relay 1 (NC contact)

- [14] Start bypass
- [23] DC 24 V voltage supply, +
- [24] DC 24 V voltage supply, -
- [19] Auxiliary output for customer application +
- [20] Auxiliary output for customer application -

The following figure shows the front of the speed monitor:



18702219

LED in CHK 1
(yellow/red):

Input pulses (flashing yellow in sync),
input malfunction (flashing red), and unit malfunction (con-
tinuously red)

LED PWR (green):

Voltage

LED OUT 1 (yellow):

Relay 1 active

LED OUT 2 (yellow):

Relay 2 active

LED OUT 3 (yellow):

Transistor active

RS232:

The RS232 interface for connecting a PC for parameteriza-
tion and diagnosing of the UFC with PACTware

Display:

For showing measured values and faults and visualization in
parameterization mode

INFORMATION



The start bypass time may not exceed 3 seconds. The settings above must be per-
formed with care and measured in a subsequent test.

5.10.2 Installing and setting other speed monitors


If other speed monitors are used, they must feature an intrinsically safe sensor input (identification color: blue) for evaluation of sensors according to DIN 19234 (NAMUR) and be approved for use of this sensor in potentially explosive atmospheres.

INFORMATION

The voltage encoder (sensor) generally features a blue connection cable and must conform to DIN 19234 (NAMUR). The corresponding inspection number may be attached to the voltage encoder or the connection cable.

5.11 Installation of the voltage encoder

The following figure illustrates the installation of the voltage encoder and the setting of the sensing distance x .



9007199273453323

- | | |
|----------------------------------|--------------------------|
| [1] Adapter flange bearing cover | [4] Voltage encoder |
| [2] Screw head | [5] Sensing distance x |
| [3] Lock nut | |

1. Rotate the output shaft of the adapter until the slotted screw head can be seen through the tapped hole in the bearing cover.
2. Voltage encoder:
 - Carefully screw it into the thread in the adapter flange [1] of the variable-speed gear unit until the voltage encoder [5] rests on the screw head [2].
 - Turn the encoder back by 2 turns and secure with the lock nut [3].

The sensing distance is now set to 2 mm. During operation, the voltage encoder supplies 1 pulse per revolution at this sensing distance.

5.11.1 Changing sensing distance "x"

If no circuit state change occurs at the voltage encoder (LED display) with rotating shaft of the adapter shaft operating with sensing distance $x = 1 \text{ mm}$, the sensing distance can be changed as follows:

1. With **constantly lit LED** [4] of the voltage encoder, turn the voltage encoder a half turn **counterclockwise** at a time and check its function.
2. If the **LED is not lit** [4], turn the voltage encoder **clockwise** by 90 degrees but no more than one time.

⚠ CAUTION

A collision with the slotted screw heads may destroy the voltage encoder.

Possible damage to property.

- Do not turn in the voltage encoder by more than half a turn
-

3. If a circuit change still does not occur, check the voltage supply of the voltage encoder using the evaluation electronics (with WEXA/WEX design).

6 Inspection/maintenance



⚠ WARNING

Risk of injury if the drive starts up unintentionally.

Severe or fatal injuries

- Disconnect the drive from the power supply before you start working on the unit.
- Prevent the drive from starting up unintentionally for example, by locking the key switch or removing the fuses from the current supply.



⚠ WARNING

Risk of injury if preloaded shaft connections are loosened.

Severe or fatal injuries

- Before releasing any shaft connections, make sure there is no active torsional torque present that could lead to tension within the system.



⚠ WARNING

Risk of burns due to hot gear unit and hot gear unit lubricant

Severe injuries

- Let the gear unit cool down before you start working on it.
- Carefully remove the oil level plug and the oil drain plug.

NOTICE

Loss of lubricant qualities due to filling of wrong lubricant

Damage to the gear unit

- Do not mix synthetic lubricants and mineral lubricants.
- Do not mix different synthetic lubricants.
- As standard lubricant use mineral oil.

NOTICE

Damage to oil seal caused by cleaning the gear unit with a high pressure device.

Gear unit damage.

- Do not clean the gear unit with a high-pressure cleaning device.

NOTICE

Damage to gear unit due to ingress of foreign objects during maintenance and inspection work

Gear unit failure

- Prevent foreign particles from entering into the gear unit during maintenance and inspection work.

**INFORMATION**

Maintain the inspection and maintenance intervals. This is necessary to ensure operational safety.

**INFORMATION**

Perform a safety check and functional check following maintenance and repair work.

6.1 Wearing parts

Gearing

If the SEW-EURODRIVE design criteria and the intervals for inspection and maintenance are observed, the gearing components are wear-free after the run-in period. For constructional reasons, the worm gearing is an exception. The amount of material abrasion on the worm gear tooth flanks varies depending on the operating conditions. The main influencing factors are:

- Rotational speed
- Load
- Operating temperature
- Lubricant (type, viscosity, additives, pollution)
- Switching frequency

For information on the worm gearing service life under certain operating conditions, contact SEW-EURODRIVE.

Rolling bearing

Rolling bearings in the gear unit, adapter and input shaft assembly have a limited service life, even under ideal operating conditions. This nominal bearing service life is a solely statistical value. The actual service life of an individual bearing may deviate greatly from this value. The main influencing factors are:

- Rotational speed
- Equivalent bearing load
- Operating temperature
- Lubricant (type, viscosity, additives, pollution)
- Lubricant supply of the bearing
- Misalignment under operating load

Therefore the rolling bearings must be inspected regularly. Observe the corresponding inspection and maintenance intervals in the chapters "Inspection/maintenance intervals" (→ 111), "Lubricant change intervals" (→ 112), "Maintenance of AL/AM/AQ. adapter" (→ 112), and "AD input shaft assembly maintenance" (→ 117).

For information on the nominal bearing service life under certain operating conditions, contact SEW-EURODRIVE.

Lubricants

Lubricants are subject to aging. Their service life is limited depending on the load conditions.

The service life significantly depends on the oil operating temperature. The dependency of lubricant change intervals and operating temperature is depicted in the figure in chapter "Lubricant change intervals" (→ 112).

Oil seals

Oil seals are contact seals that are used to seal unit housings at emerging elements, such as shafts, from the environment. Oil seals are wear parts with a service life that is influenced by various factors. For example:

- Shaft speed and circumferential speed at the sealing lip
- Ambient conditions (temperature, dust, humidity, pressure, chemicals, radiation)
- Lubricant (type, viscosity, additives, pollution)
- Surface quality of the sealing
- Lubricant supply of the sealing
- Oil seal material

Due to the various influencing factors it is not possible to predict the service life. Therefore the oil seals must be inspected regularly. Observe the corresponding inspection and maintenance intervals in the chapters "Inspection/maintenance intervals" (→ 111), "Lubricant change intervals" (→ 112), "Maintenance of AL/AM/AQ. adapter" (→ 112), and "AD input shaft assembly maintenance" (→ 117).

Cam ring/ coupling ring

The couplings used in the AM, AL, and AQ. adapters are designed to be positive, puncture-proof and low-maintenance claw couplings. They have a an impact and vibration-absorbing cam ring (AM) or coupling ring (AQ., AL). The service life of cam ring/coupling ring is influenced by various factors. These are, among other things:

- Ambient conditions (temperature, chemicals, radiation)
- Operational conditions (switching frequency, impact characteristics)

Adhere to the corresponding inspection and maintenance intervals in chapter "Maintenance of AL/AM/AQ. adapter" (→ 112).

Rubber buffer

The rubber buffer is required for shaft-mounted gear units of type F for torque support. Rubber buffers are wear parts with a service life that is influenced by the following factors:

- Load
- Ambient conditions
 - Temperature
 - Humidity
 - Aggressive chemicals, e.g. ozone
- Switching frequency
- Impact characteristics

Flexible bushing

A so-called flexible bushing is required for the torque arm of the S and K gear unit types. Flexible bushings are wear parts with a service life that is influenced by the following factors:

- Load
- Ambient conditions
 - Temperature
 - Humidity
 - Aggressive chemicals, e.g. ozone
- Switching frequency
- Impact characteristics

6.2 Inspection/maintenance intervals

The following table lists the obligatory intervals and the corresponding measures:

| Time interval | What to do? |
|---|---|
| <ul style="list-style-type: none"> Every 3000 hours of operation, at least every 6 months | <ul style="list-style-type: none"> Check oil and oil level Check running noise for possible bearing damage Visual inspection of the seals for leakage Check that all screw plugs, any oil sight glass, the breather valve and the gear unit cover screws are tight. For gear units with a torque arm: Check and replace the rubber buffers, if necessary |
| <ul style="list-style-type: none"> Depending on the operating conditions (see illustration in chapter "Lubricant change intervals" (→ 112)), every 3 years at the latest according to oil temperature | <ul style="list-style-type: none"> Change mineral oil Replace bearing grease (recommendation) Replace oil seal (do not install it in the same track) |
| <ul style="list-style-type: none"> Depending on the operating conditions (see illustration in chapter "Lubricant change intervals" (→ 112)), every 5 years at the latest according to oil temperature | <ul style="list-style-type: none"> Change synthetic oil Replace bearing grease (recommendation) Replace oil seal (do not install it in the same track) |
| <ul style="list-style-type: none"> Varying (depending on external factors) | <ul style="list-style-type: none"> Touch up or renew the surfaces / anti-corrosion coating |


Exceptions

The following gear units are lubricated for life. A scheduled oil change is not necessary:

- Helical gear units R07, R17, R27
- Parallel-shaft helical gear unit F27
- SPIROPLAN® gear units

6.3 Lubricant change intervals

The following image depicts the change intervals for standard gear units under normal ambient conditions. In case of special designs under severe/aggressive ambient conditions, change the lubricant more frequently.



27021597782952587

- [1] Operating hours
- [2] Sustained oil bath temperature
- [3] CLP PG/CLP PG NSF H1
- [4] CLP HC/ CLP HC NSF H1
- [5] CLP (CC)/E
- [6] SEW GearOil Base
- [7] SEW GearOil Poly (H1)

6.4 Maintenance of AL/AM/AQ. adapter

The following table lists the obligatory intervals and the corresponding measures:

| Time interval | What to do? |
|---|---|
| <ul style="list-style-type: none"> Every 3000 operating hours, at least every 6 months | <ul style="list-style-type: none"> Check the running noises to detect possible bearing damage. Visually check the adapter for leakage. |
| <ul style="list-style-type: none"> After 10000 operating hours | <ul style="list-style-type: none"> Check the rotational clearance. Visual check the cam ring (AM) or coupling ring (AQ., AL). |
| <ul style="list-style-type: none"> After 10 000 operating hours with NBR/FKM oil seals After 20 000 operating hours with Premium Sine Seal (PSS) adapter oil seals: | <ul style="list-style-type: none"> Change the bearing grease. Change the oil seal. With standard NBR or FKM oil seals, the new oil seal must not be fitted on the previous track. This is allowed with Premium Sine Seal (PSS) adapter oil seals. |

24804134/EN – 05/2018

6.5 AR adapter maintenance

The following table lists the obligatory intervals and the corresponding measures:

| Time interval | What to do? |
|--|--|
| <ul style="list-style-type: none"> Every 3000 hours of operation, at least every 6 months | <ul style="list-style-type: none"> Check the running noises to detect possible bearing damage. Visually check the adapter for leakage. |
| <ul style="list-style-type: none"> After 25000 – 30000 hours of operation | <ul style="list-style-type: none"> Change the bearing grease. Change the oil seal. Do not mount it in the same track. |

6.6 Maintenance of AR adapter with slip clutch

If you use an adapter with slip clutch, the wear parts are affected by many factors. This is why the inspection intervals are short.

The following table lists the obligatory intervals and the corresponding measures:

| Time interval | What to do? | Chapter |
|-------------------------------------|---|---|
| At least every 3000 operating hours | <ul style="list-style-type: none"> Inspect the friction lining and the cup springs. If necessary, replace them. If the slip torque is too low, adjust it accordingly. | Chapter "Inspecting/replacing the friction lining, adjusting the slip torque" (→ 114) |

6.6.1 Inspecting the friction lining

If the friction lining thickness is reduced by more than 50% compared to the original state, replace the friction lining (see chapter "Replacing the friction lining and adjusting the slip torque" (→ 114)).

The following table lists the friction lining thickness in original state:

| Adapter type | Friction lining thickness mm |
|---|---------------------------------|
| AR71/AR80/AR85/AR90/AR95 | 2 |
| AR100/AR105/AR112 | 3 |
| AR132/AR135/AR145/AR160/AR165/AR180/AR185/AR195 | 4 |

The following table shows the dimensions of the setting tool:

| Adapter type | d mm | l mm | u mm | t _{max} mm |
|-------------------|---------|---------|---------|------------------------|
| AR71 | 14 | 30 | 5 | 16.3 |
| AR80/AR85 | 19 | 40 | 6 | 21.8 |
| AR90/AR95 | 24 | 50 | 8 | 27.3 |
| AR100/AR105/AR112 | 28 | 60 | 8 | 31.3 |
| AR132/AR135/AR145 | 38 | 80 | 10 | 41.3 |

| Adapter type | d mm | l mm | u mm | t _{max} mm |
|-------------------|---------|---------|---------|------------------------|
| AR160/AR165 | 42 | 110 | 12 | 45.3 |
| AR180/AR185/AR195 | 48 | | 14 | 51.8 |

6.6.2 Inspecting/replacing the friction lining, adjusting the slip torque

▲ WARNING



Risk of crushing if the drive starts up unintentionally.

Severe or fatal injuries.

- Before starting the work, de-energize the gearmotor and prevent it from starting up unintentionally for example by locking the key switch or removing the fuses from the current supply.

INFORMATION




It is only possible to check and adjust the slip torque accurately by using a torque wrench with an appropriate connection piece.

The following tools and resources are required:

- Standard tools
- Spanner wrench
- Hydraulic press
- Mounting/dismantling tool
- Torque wrench


The following figure shows the gear unit with mounted AR adapter with slip clutch:



9007199273505291

- | | |
|-------------------------|---------------------|
| [1] Locking screw | [5] Friction lining |
| [2] Cylinder head screw | [6] Cup spring |
| [3] Proximity switch | [7] Slotted nut |
| [4] Friction disk | [8] Friction hub |

The following figure shows the rough slip torque adjustment:



18014398528249355

- | | |
|---|---|
| <p>[9] Marking</p> <p>[10] Multi-tang washer (cams)</p> <p>[11] Slotted nut</p> <p>[12] Z Number of cams of the lock washer</p> | <p>[13] Z number of slots in the slotted nut</p> <p>[14] Mark on the driving disk</p> <p>[15] Slotted nut</p> |
|---|---|

Proceed as follows:

- ✓ The motor/variable-speed gearmotor is disconnected from the adapter.
- 1. Loosen the locking screw [1] and pull the friction hub [8] from the shaft end.
- 2. Clamp the friction hub [8] in a vise.
- 3. For AR 71 – 115 adapters, proceed as follows:
 - Loosen the lock washer [10].
 - Loosen the slotted nut until you can easily adjust the slip clutch manually.
 - Mark this position of the slotted nut [11].
- 4. For AR 132 – 195 adapters, proceed as follows:
 - Loosen the clamping screw at the slotted nut [15].
 - Loosen the slotted nut until you can easily adjust the slip clutch manually.
 - Mark this position of the driving disk [14].
- 5. Loosen the slotted nut and remove the cup springs [6]. Not the sequence of the cup spring (see "Sequence of the cup springs" (→ 116)).

NOTICE

Destruction of the friction lining surface by lubricants.

- Prevent lubricants from getting on the friction surface.

6. Inspect the friction linings [5] (see "Inspecting the friction lining" (→ 113)). Replace them, if they are worn.
7. Inspect the cup springs [6]. Replace them, if cup springs are burned out.
8. Reassemble the cup springs [6] in the same sequence as you disassembled them.
9. Install the slotted nut up to the mark.
10. Measure the slip torque and adjust it. Proceed as follows to do so:
 - How to adjust the slip torque using a torque wrench:
 - Connect the torque wrench with the hub bore.

- Measure the slip torque in both directions of rotation and, if necessary, adjust it via the slotted nut.
 - If you adjust the slip torque using a spanner wrench, you can only roughly set the slip torque. In this case, determine the value "Z" that must be set to achieve the required slip torque based on the following table (see "AR slip torques" (→ 116)). The value "Z" is:
 - For AR 71 – 115 drives, the number of cams of the lock washer starting from the mark.
 - For AR 132 – 195 drives, the number of slots of the slotted nut starting from the mark.
11. Secure the slotted nut either with a lock washer or a clamping screw, depending on the adapter type.
12. Reassemble the drive in opposite order.

AR slip torques

| Adapter type | Cup springs | | | Setting range Nm | No. of cams or slots "Z" | | | | | | | | | | | | | | | | | | | | | |
|--|-------------|--------------|--------------------|------------------|-------------------------------|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|----|----|----|----|----|----|--|
| | Quantity | Thickness mm | Fig. ¹⁾ | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | |
| | | | | | Slip torque M _R Nm | | | | | | | | | | | | | | | | | | | | | |
| AR71 | 4 | 0.6 | 1 | 1.0-2.0 | | | | | | 1.0 | 1.4 | 1.6 | 1.8 | 2.0 | | | | | | | | | | | | |
| | | | 2 | 2.1-4.0 | | | | | | 2.1 | – | 2.4 | 2.6 | 3.2 | 3.4 | 3.8 | 4.0 | | | | | | | | | |
| | 3 | | 3 | 4.1-6.0 | | | 4.1 | 5.0 | 5.8 | 6.0 | | | | | | | | | | | | | | | | |
| AR80 | 4 | 0.6 | 1 | 1.0-2.0 | | | | | | 1.0 | 1.4 | 1.6 | 2.8 | 2.0 | | | | | | | | | | | | |
| | | | 2 | 2.1-4.0 | | | | | | 2.1 | – | 2.4 | 2.6 | 3.2 | 3.4 | 3.8 | 4.0 | | | | | | | | | |
| | 3 | | 3 | 4.1-6.0 | | | 4.1 | 5.0 | 5.8 | 6.0 | | | | | | | | | | | | | | | | |
| AR85 AR90 AR95 | 4 | 0.9 | 2 | 6.1-16 | | | | 6.0 | 8.0 | 9.0 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | | | | | | | | | |
| | 3 | 0.6 | 3 | 4.1-6.0 | | | 4.1 | 5.0 | 5.8 | 6.0 | | | | | | | | | | | | | | | | |
| | 4 | 0.9 | 2 | 6.1-16 | | | | 6.0 | 8.0 | 9.0 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | | | | | | | | | |
| AR100 AR105 AR112 AR115 | 2 | 1.1 | 3 | 17-24 | | | 16 | 20 | 24 | | | | | | | | | | | | | | | | | |
| | 6 | 0.7 | 2 | 5.0-13 | | | | | | | 5.0 | 6.0 | 8.0 | 9.0 | 10 | 11 | 12 | 13 | | | | | | | | |
| | 2 | 1.45 | 2 | 14-35 | | | | | | 14 | 16 | 17 | 18 | 20 | 22 | 23 | 24 | 26 | 27 | 28 | – | 30 | 31 | 32 | 35 | |
| AR132S/M AR132M/L AR135 AR145 | 4 | 1.5 | 3 | 36-80 | | | | | | 36 | 41 | 45 | 48 | 54 | 58 | 60 | | | | | | | | | | |
| | | | 1 | 15-32 | | | | 15 | 18 | 22 | 24 | 26 | – | 28 | 30 | 32 | | | | | | | | | | |
| | | | 2 | 33-65 | | | 33 | 40 | 50 | 58 | 67 | | | | | | | | | | | | | | | |
| AR160 | 4 | 1.5 | 3 | 66 – 130 | | 68 | 100 | 120 | 135 | | | | | | | | | | | | | | | | | |
| | | | 1 | 30-45 | | | | | | | | | | 32 | 36 | 38 | 40 | 41 | 42 | 40 | 44 | 45 | | | | |
| | 2 | 2.7 | 2 | 86-200 | | | | | 86 | 90 | 110 | 125 | 135 | 150 | 160 | 180 | 190 | 200 | | | | | | | | |
| AR165 AR180 AR185 AR195 | 4 | 1.5 | 2 | 46-85 | | | 40 | 48 | 60 | 65 | 70 | 75 | 80 | 85 | | | | | | | | | | | | |
| | | | 1 | 30-45 | | | | | | | | | | 32 | 36 | 38 | 40 | 41 | 42 | 44 | 45 | | | | | |
| | 2 | 2.7 | 2 | 86-200 | | | | | 86 | 90 | 110 | 125 | 135 | 150 | 160 | 170 | 180 | 190 | 200 | | | | | | | |
| | | | 3 | 201-300 | | | 200 | 280 | 300 | | | | | | | | | | | | | | | | | |

1) For "sequence of cup springs", refer to the table below

Sequence of the cup springs

| No. | Meaning | Installation position |
|-----|------------------------------|-----------------------|
| 1 | Double, alternating sequence | ()() |
| 2 | Alternating sequence | () |
| 3 | Aligned sequence |)) |

6.6.3 Replacing the incremental encoder of the adapter



▲ WARNING

Risk of crushing if the drive starts up unintentionally.

Severe or fatal injuries.

- Before starting the work, de-energize the gearmotor and prevent it from starting up unintentionally for example by locking the key switch or removing the fuses from the current supply.

INFORMATION



Use only genuine spare parts in accordance with the valid spare parts list.

Proceed as follows:

1. Remove the fan guard from the driving motor.
2. Remove the incremental encoder connection.
3. Loosen the lock nut at the incremental encoder and remove the old incremental encoder.
4. Install the new incremental encoder, see "Installing the voltage encoder" (→ 105).
5. Connect the incremental encoder to the speed/slip monitor.
6. Reinstall the fan guard.

6.7 AD input shaft assembly maintenance

The following table lists the obligatory intervals and the corresponding measures:

| Time interval | What to do? |
|--|--|
| <ul style="list-style-type: none"> • Every 3000 hours of operation, at least every 6 months | <ul style="list-style-type: none"> • Check the running noises to detect possible bearing damage. • Visually check the adapter for leakage. |
| <ul style="list-style-type: none"> • After 10000 operating hours | <ul style="list-style-type: none"> • Change the bearing grease. • Change the oil seal. Do not mount it in the same track. |

6.8 Inspection/maintenance for the gear unit

6.8.1 Checking the oil level and changing the oil

The procedure when checking the oil level and changing the oil depends on gear unit type, size and mounting position. Determine the code letter (A, B, C, D or E) in the following table in regard of gear unit type and size. Use the code letter to find the reference for the procedure for the corresponding gear unit in the 2nd table.

| Gear unit type | Size | Code letter for chapter "Checking the oil level and changing the oil" | | | | | |
|----------------|--------------|---|----|----|----|----|----|
| | | M1 | M2 | M3 | M4 | M5 | M6 |
| R | R..07 – 27 | B | | | | | |
| | R..37/R..67 | A | | | | | |
| | R..47 /R..57 | A | | | | B | A |
| | R..77 – 167 | A | | | | | |
| | RX..57– 107 | A | | | | | |
| F | F..27 | B | | | | | |
| | F..37 – 157 | A | | | | | |
| K | K..19/K..29 | C | | | | | |
| | K..39/K49 | A | | | | | |
| | K..37 – 187 | A | | | | | |
| S | S..37 | C | | | | | |
| | S..47 – 97 | A | | | | | |
| W | W..10 – 30 | B | | | | | |
| | W..37 – 47 | D | | | E | D | |

| Code letter | Chapter "Checking the oil level and changing the oil" | Reference |
|-------------|--|-----------|
| A | <ul style="list-style-type: none"> Helical gear units... Parallel-shaft helical gear units... K..39/K..49, K..37 – 187 helical-bevel gear units Helical-worm gear units... S..47 – 97 With oil level plug | (→ 120) |
| B | <ul style="list-style-type: none"> Helical gear units... Parallel-shaft helical gear units... SPIROPLAN® gear units... Without oil level plug, with cover plate | (→ 123) |
| C | <ul style="list-style-type: none"> S..37 helical-worm gear unit K..19/K..29 helical-bevel gear unit Without oil level plug, without cover plate | (→ 127) |
| D | <ul style="list-style-type: none"> SPIROPLAN® W..37/W..47 In mounting positions M1, M2, M3, M5, M6 with oil level plug | (→ 130) |

| Code letter | Chapter "Checking the oil level and changing the oil" | Reference |
|-------------|---|-----------|
| E | <ul style="list-style-type: none"> SPIROPLAN® W..37/W..47... In mounting position M4 without oil level plug and cover plate | (→ 133) |

Refer to chapter "Mounting positions" (→ 136) for notes on the mounting positions.

You cannot check the oil level of gear units in pivoted mounting position. The gear units are delivered with the correct oil level. Observe the designations and fill quantities on the nameplate if you have to change the oil.

6.8.2 A: Helical, parallel-shaft helical, helical-bevel and helical-worm gear units with oil level plug

Checking the oil level at the oil level plug



⚠ CAUTION

The R../R.. compound gear units in mounting position M1 and S../R.. compound gear units in mounting position M3 require sufficient lubrication. This is why the oil level is increased.

- The installed oil level plugs must not be used.


Proceed as follows:

- ✓ The prerequisites for inspection and maintenance work are fulfilled, see beginning of chapter "Inspection/maintenance" (→ 107).
- 1. Determine the position of the oil level plug and the breather valve using the mounting position sheets, see chapter "Mounting positions" (→ 136).
- 2. Place a container underneath the oil level plug.
- 3. Slowly remove the oil level plug. Small amounts of oil may leak out.
- 4. Check the fill level at the oil level bore (3) using the oil dipstick (1). The oil dipstick is enclosed with the operating instructions.



NOTICE

For the measurement, make sure that the end (2) of the oil dipstick (1) always points up vertically.



18634635


Max. fill level (max.): Lower edge of the oil level bore

Minimum fill level (min.): The minimum fill level depends on the diameter of the oil level bore and is determined using the oil dipstick.

The minimum fill level corresponds to the mark on the oil dipstick.

| Ø oil level bore | Minimum fill level: Mark X at the oil dipstick (see following figure) mm |
|------------------|--|
| M10 × 1 | 1.5 |
| M12 × 1.5 | 2 |
| M22 × 1.5 | 3 |

| Ø oil level bore | Minimum fill level: Mark X at the oil dipstick (see following figure) mm |
|------------------|--|
| M33 × 2 | 4 |
| M42 × 2 | 5 |



9007199273378699

5. If the oil level is too low, remove the breather valve and refill oil of the same type (if necessary, contact SEW-EURODRIVE) through the vent hole.
6. Re-insert the breather valve and the oil level plug. Observe for this the tightening torques in chapter "Tightening torques for oil level plugs, oil drain plugs, screw plugs, breather valves and oil sight glasses" (→ 38).

Checking the oil via the oil drain plug

Proceed as follows to check the gear unit oil:

1. Observe the information at the beginning of chapter "Inspection/maintenance" (→ 107).
2. Determine the position of the oil drain plug using the mounting position sheets. See chapter "Mounting positions" (→ 136).
3. Remove a little oil from the oil drain plug.
4. Check the oil consistency:
 - Viscosity
 - If you can see that the oil is heavily contaminated, SEW-EURODRIVE recommends to change the oil even if this is outside the service intervals specified in "Inspection and maintenance intervals" (→ 111).
5. Check the oil level. See chapter "Checking the oil level at the oil level plug" (→ 120).

Changing the oil via the oil drain plug and the breather valve







▲ WARNING

Risk of burns due to hot gear unit and hot gear unit oil.

Serious injuries.

- Let the gear unit cool down before you start working on it. Due to the better flowability, the gear unit oil should still be warm so that the gear unit can be drained best.

1. Observe the information at the beginning of chapter "Inspection/maintenance" (→ 107).


2. Determine the position of the oil drain plug, the oil level plug and the breather valve using the mounting position sheets. See chapter "Mounting positions" (→  136).
3. Place a container underneath the oil drain plug.
4. Remove the oil level plug, the breather valve and the oil drain plug.
5. Drain all the oil.
6. Re-insert the oil drain plug. Observe for this the tightening torques in chapter "Tightening torques for oil level plugs, oil drain plugs, screw plugs, breather valves and oil sight glasses" (→  38).
7. Fill in fresh oil of the same type (contact SEW-EURODRIVE if necessary) via the breather bore. Do not mix different synthetic lubricants!
 - Fill the oil according to the quantity specified on the nameplate. See chapter "Lubricant fill quantities" (→  188).
 - Check the oil level at the oil level plug.
8. Re-insert the oil level plug and the breather valve. Observe for this the tightening torques in chapter "Tightening torques for oil level plugs, oil drain plugs, screw plugs, breather valves and oil sight glasses" (→  38).

6.8.3 B: Helical, parallel shaft helical, SPIROPLAN® gear units without oil level plug with cover plate

Checking the oil level via the cover plate


For gear units without oil level bore, the oil level is checked via the cover plate opening. Proceed as follows:

1. Observe the information at the beginning of chapter "Inspection/maintenance" (→ 107).
2. To position the cover plate on the top, place the gear unit in the following mounting position:
 - R07 – R57 in mounting position M1
 - F27 in M3 mounting position
 - W10 – W30 in mounting position M1
3. Loosen the screws [1] of the cover plate [2] and remove the cover plate [2] and the corresponding gasket [3] (see following figure).



9007199273384203

4. Determine the vertical distance "x" between oil level and sealing surface of the gear unit housing (see following figure).




9007199273387275

5. Compare the determined value "x" to the max. distance between oil level and sealing surface of the gear unit housing specified in the following table. Adjust the fill level if required.

| Gear unit type | | Max. distance x in mm between oil level and sealing surface of the gear unit housing for mounting position | | | | | |
|----------------|---------|--|--------|--------|--------|--------|--------|
| | | M1 | M2 | M3 | M4 | M5 | M6 |
| R07 | 2-stage | 52 ± 1 | 27 ± 1 | 27 ± 1 | 27 ± 1 | 27 ± 1 | 27 ± 1 |
| | 3-stage | 49 ± 1 | 21 ± 1 | 21 ± 1 | 21 ± 1 | 21 ± 1 | 21 ± 1 |
| R17 | 2-stage | 63 ± 1 | 18 ± 1 | 46 ± 1 | 18 ± 1 | 46 ± 1 | 46 ± 1 |
| | 3-stage | 58 ± 1 | 11 ± 2 | 40 ± 2 | 11 ± 2 | 40 ± 2 | 40 ± 2 |
| R27 | 2-stage | 74 ± 1 | 22 ± 1 | 45 ± 1 | 22 ± 1 | 45 ± 1 | 45 ± 1 |
| | 3-stage | 76 ± 1 | 19 ± 1 | 42 ± 1 | 19 ± 1 | 42 ± 1 | 42 ± 1 |
| R47 | 2-stage | – | – | – | – | 39 ± 1 | – |
| | 3-stage | – | – | – | – | 32 ± 1 | – |
| R57 | 2-stage | – | – | – | – | 32 ± 1 | – |
| | 3-stage | – | – | – | – | 28 ± 1 | – |
| F27 | 2-stage | 78 ± 1 | 31 ± 1 | 72 ± 1 | 56 ± 1 | 78 ± 1 | 78 ± 1 |
| | 3-stage | 71 ± 1 | 24 ± 1 | 70 ± 1 | 45 ± 1 | 71 ± 1 | 71 ± 1 |
| | | Irrespective of mounting position | | | | | |
| W10 | | 12 ± 1 | | | | | |
| W20 | | 19 ± 1 | | | | | |
| W30 | | 31 ± 1 | | | | | |

6. Close the gear unit after the oil level check:
- Re-attach the seal of the cover plate. Make sure that the sealing surfaces are clean and dry.
 - Screw on the cover plate. Tighten the cover plate screw connections working from the inside to the outside. Tighten the cover plate screw connections in the sequence depicted in the following figure. Tighten the cover plate screw connections with the specified tightening torque according to the following table. Repeat the tightening procedure until the screws are properly tightened. To avoid damaging the cover plate, use only impulse wrenches or torque wrenches. Do not use impact screwdrivers.



27021597782872715

| Gear unit type | Image | Retaining thread | Tightening torque T_N Nm | Minimum tightening torque T_{min} Nm |
|----------------|-------|------------------|----------------------------|--|
| R/RF07/17 | E | M6 | 11 | 7 |
| R/RF27 | D | | | |
| R/RF47/57 | A | | | |
| F27 | B | | | |
| W10 | C | M5 | 6 | 4 |
| W20 | C | M6 | 11 | 7 |
| W30 | A | | | |

Checking the oil via cover plate

Proceed as follows to check the gear unit oil:

1. Observe the information at the beginning of chapter "Inspection/maintenance" (→ 107).
2. Open the cover plate of the gear unit according to chapter "Checking the oil level via the cover plate" (→ 123).
3. Take an oil sample via the cover plate opening.
4. Check the oil consistency.
 - Viscosity
 - If you can see that the oil is heavily contaminated, SEW-EURODRIVE recommends to change the oil even if this is outside the service intervals specified in "Inspection and maintenance intervals" (→ 118).
5. Check the oil level. See chapter "Checking the oil level via the cover plate" (→ 123).
6. Screw on the cover plate. Observe the sequence and tightening torques in chapter "Checking the oil level via the cover plate" (→ 123).

Changing the oil via the cover plate**▲ WARNING**

Risk of burns due to hot gear unit and hot gear unit oil.

Serious injuries.

- Let the gear unit cool down before you start working on it. Due to the better flowability, the gear unit oil should still be warm so that the gear unit can be drained best.
-
1. Observe the information at the beginning of chapter "Inspection/maintenance" (→ 107).
 2. Open the cover plate of the gear unit according to chapter "Checking the oil level via the cover plate" (→ 123).
 3. Completely drain the oil into a container via the cover plate opening.
 4. Fill in fresh oil of the same type (contact SEW-EURODRIVE if necessary) via the cover plate. You must not mix different synthetic lubricants.
 - Fill in the oil as specified on the nameplate or the order confirmation. See chapter "Lubricant fill quantities" (→ 188).
 5. Check the oil level.
 6. Screw on the cover plate. Observe the sequence and tightening torques in chapter "Checking the oil level via the cover plate" (→ 123).

6.8.4 C: Helical-worm gear units S..37 and helical-bevel gear units K..19/K..29 without oil level plug and cover plate


Checking the oil level via screw plug

The gear units S..37, K..19, and K..29 are not equipped with an oil level plug or a cover plate. This is why the oil level is checked via the control bore.

1. Observe the information at the beginning of chapter "Inspection/maintenance" (→ 107).
2. Place the gear unit in the mounting position stated in the following table. Thus the control bore always points upwards.


| Gear unit | Mounting position |
|-----------|-------------------|
| S..37 | M5/M6 |
| K19/29 | M6 |

3. Remove the screw plug [1] as shown in the following figure.




18655371

4. Insert the dipstick vertically via the control bore all the way to the bottom of the gear unit housing. Vertically pull the dipstick out of the control bore, as shown in the following figure.



18658699

- Determine the size of the section "x" of the dipstick covered with lubricant using a slide-gauge as depicted in the following figure.



18661771

- Compare the determined value "x" to the min. value depending on the mounting position specified in the following table. Correct the fill level if required.

| Gear unit type | Oil level = wetted section "x" in mm of the dipstick | | | | | |
|----------------|--|--------|--------|--------|--------|--------|
| | Mounting position | | | | | |
| | M1 | M2 | M3 | M4 | M5 | M6 |
| K..19 | 33 ± 1 | 33 ± 1 | 33 ± 1 | 35 ± 1 | 33 ± 1 | 33 ± 1 |
| K..29 | 50 ± 1 | 50 ± 1 | 50 ± 1 | 63 ± 1 | 50 ± 1 | 50 ± 1 |
| S..37 | 10 ± 1 | 24 ± 1 | 34 ± 1 | 37 ± 1 | 24 ± 1 | 24 ± 1 |

- Re-insert and tighten the screw plug. Observe for this the tightening torques in chapter "Tightening torques for oil level plugs, oil drain plugs, screw plugs, breather valves and oil sight glasses" (→ 38).

Checking the oil via the screw plug

- Observe the information at the beginning of chapter "Inspection/maintenance" (→ 107).
- Open the screw plug of the gear unit according to chapter "Checking the oil level via screw plug" (→ 127).
- Take an oil sample via the screw plug bore.
- Check the oil consistency.
 - Viscosity
 - If you can see that the oil is heavily contaminated, SEW-EURODRIVE recommends to change the oil even if this is outside the service intervals specified in "Inspection and maintenance intervals" (→ 111).
- Check the oil level. See chapter "Checking the oil level via screw plug" (→ 127).
- Re-insert and tighten the screw plug. Observe for this the tightening torques in chapter "Tightening torques for oil level plugs, oil drain plugs, screw plugs, breather valves and oil sight glasses" (→ 38).

Changing the oil via the screw plug



▲ WARNING

Risk of burns due to hot gear unit and hot gear unit oil.

Serious injuries.


- Let the gear unit cool down before you start working on it. Due to the better flowability, the gear unit oil should still be warm so that the gear unit can be drained best.
-
1. Observe the information at the beginning of chapter "Inspection/maintenance" (→ 107).
 2. Open the cover plate of the gear unit according to chapter "Checking the oil level via the screw plug".
 3. Completely drain the oil via the screw plug bore.
 4. Fill in fresh oil of the same type (contact SEW-EURODRIVE if necessary) via the control bore. You must not mix different synthetic lubricants.
 - Observe the oil quantity specified on the nameplate or according to the mounting position. Observe chapter "Lubricant fill quantities" (→ 188).
 5. Check the oil level.
 6. Re-insert and tighten the screw plug. Observe for this the tightening torques in chapter "Tightening torques for oil level plugs, oil drain plugs, screw plugs, breather valves and oil sight glasses" (→ 38).

6.8.5 D: SPIROPLAN® W37/W47 in mounting positions M1, M2, M3, M5, M6 with oil level plug

Checking the oil level at the oil level plug

Proceed as follows:

- ✓ The prerequisites for inspection and maintenance work are fulfilled, see beginning of chapter "Inspection/maintenance" (→ 107).
- 1. Set up the gear unit in mounting position M1, see chapter "Mounting positions" (→ 136).
- 2. Place a container underneath the oil level plug.
- 3. Slowly remove the oil level plug. Small amounts of oil may leak out.




787235211

- 4. Check the fill level at the oil level bore (3) using the oil dipstick (1). The oil dipstick is enclosed with the operating instructions.

NOTICE



For the measurement, make sure that the end (2) of the oil dipstick (1) always points up vertically.




18634635

Max. fill level (max.): Lower edge of the oil level bore

Minimum fill level (min.): The minimum fill level depends on the diameter of the oil level bore and is determined using the oil dipstick.

The minimum fill level corresponds to the mark on the oil dipstick.

| Ø oil level bore | Minimum fill level: Mark X at the oil dipstick (see following figure) mm |
|------------------|--|
| M10 x 1 | 1.5 |



9007199273378699

5. If the oil level is too low, fill in new oil via the oil level bore until the oil level reaches the lower edge of the bore.
6. Screw in the oil level plug again. Observe for this the tightening torques in chapter "Tightening torques for oil level plugs, oil drain plugs, screw plugs, breather valves and oil sight glasses" (→ 38).

Checking the oil level at the oil level plug

Proceed as follows to check the oil of the gear unit:

1. Observe the information at the beginning of chapter "Inspection/maintenance" (→ 107).
2. Remove some oil at the oil level plug.
3. Check the oil consistency.
 - Viscosity
 - If you can see that the oil is heavily contaminated, SEW-EURODRIVE recommends to change the oil even if this is outside the service intervals specified in "Inspection and maintenance intervals" (→ 111).
4. Check the oil level. See previous chapter.

Changing the oil at the oil level plug






▲ WARNING

Risk of burns due to hot gear unit and hot gear unit oil.

Serious injuries.

- Let the gear unit cool down before you start working on it. Due to the better flowability, the gear unit oil should still be warm so that the gear unit can be drained best.

1. Observe the information at the beginning of chapter "Inspection/maintenance" (→ 107).
2. Set up the gear unit in M5 or M6 mounting position. See chapter "Mounting positions" (→ 136).
3. Place a container underneath the oil level plug.
4. Remove the oil level plugs on the A- and B-side of the gear unit.
5. Drain all the oil.


6. Re-insert the lower oil level plug. Observe for this the tightening torques in chapter "Tightening torques for oil level plugs, oil drain plugs, screw plugs, breather valves and oil sight glasses" (→  38).
7. Fill in new oil of the same type (contact SEW-EURODRIVE if necessary) via the upper oil level plug. You must not mix different synthetic lubricants.
 - Observe the oil quantity specified on the nameplate or according to the mounting position. See chapter "Lubricant fill quantities" (→  188).
 - Check the oil level according to chapter "Checking the oil level via oil level plug"
8. Re-insert the upper oil level plug. Observe for this the tightening torques in chapter "Tightening torques for oil level plugs, oil drain plugs, screw plugs, breather valves and oil sight glasses" (→  38).

6.8.6 E: SPIROPLAN® W..37 / W..47 in mounting position M4 without oil level plug and cover plate

Checking the oil level via screw plug


The W37 / W47 gear units are not equipped with an oil level plug or a cover plate. This is why the oil level is checked via the control bore.

1. Observe the information at the beginning of chapter "Inspection/maintenance" (→ 107).
2. Set up the gear unit in M5 or M6 mounting position. See chapter "Mounting positions" (→ 136).
3. Remove the screw plug.
4. Insert the dipstick vertically via the control bore all the way to the bottom of the gear unit housing. Mark the point on the dipstick where it exits the gear unit. Pull out the dipstick vertically (see following figure).



784447371

5. Determine the section "x" between the wetted part and the marking using a caliper (see following figure).



9007200039761803

6. Compare the determined value "x" to the min. value depending on the mounting position specified in the following table. Correct the fill level if required.

| Gear unit type | Oil level = section "x" in mm of the dipstick | |
|-----------------------------|---|---------------------------|
| | Mounting position during check | |
| | M5 Lying on the A-side | M6 Lying on the B-side |
| W37 in M4 mounting position | 37 ± 1 | 29 ± 1 |
| W47 in M4 mounting position | 41 ± 1 | 30 ± 1 |

7. Re-insert and tighten the screw plug. Observe for this the tightening torques in chapter "Tightening torques for oil level plugs, oil drain plugs, screw plugs, breather valves and oil sight glasses" (→ 38).

Checking the oil via the screw plug

Proceed as follows to check the oil of the gear unit:

1. Observe the information at the beginning of chapter "Inspection/maintenance" (→ 107).
2. Remove a little oil at the oil screw plug.
3. Check the oil consistency:
 - Viscosity
 - If you can see that the oil is heavily contaminated, SEW-EURODRIVE recommends to change the oil even if this is outside the service intervals specified in "Inspection and maintenance intervals" (→ 111).
4. Check the oil level. See previous chapter.

Changing the oil via the screw plug



⚠ WARNING

Risk of burns due to hot gear unit and hot gear unit oil.

Serious injuries.

- Let the gear unit cool down before you start working on it. Due to the better flowability, the gear unit oil should still be warm so that the gear unit can be drained best.

1. Observe the information at the beginning of chapter "Inspection/maintenance" (→ 107).
2. Set up the gear unit in M5 or M6 mounting position. See chapter "Mounting positions" (→ 136).
3. Place a container underneath the screw plug.
4. Remove the screw plugs on the A- and B-side of the gear unit.
5. Drain all the oil.
6. Re-insert the lower screw plug. Observe the tightening torques in chapter "Tightening torques for oil level plugs, oil drain plugs, screw plugs, breather valves and oil sight glasses" (→ 38).
7. Fill in fresh oil of the same type (contact SEW-EURODRIVE if necessary) via the upper screw plug. You must not mix different synthetic lubricants.
 - Fill the oil according to the quantity specified on the nameplate. See chapter "Lubricant fill quantities" (→ 188).
 - Check the oil level according to chapter "Checking the oil level via oil level plug".
8. Re-insert the upper screw plug. Observe the tightening torques in chapter "Tightening torques for oil level plugs, oil drain plugs, screw plugs, breather valves and oil sight glasses" (→ 38).

6.8.7 Replacing the oil seal

NOTICE

Damage to oil seal when mounted below 0 °C.

Damage to oil seal.

- Store oil seals at ambient temperatures over 0 °C.
- If necessary, heat the oil seal before mounting it.

Proceed as follows:

1. Ensure that there is a sufficient grease reservoir between the dust lip and sealing lip, depending on the gear unit design.
2. If you use double oil seals, the space has to be filled with grease for one third.

6.8.8 Painting gear units

SEW-EURODRIVE delivers the drives with a coating that complies with the requirements regarding the prevention of electrostatic charge according to EN/IEC 13463-1.



▲ WARNING

Risk of explosion due to electrostatic charge and sparks caused by improper painting.

Severe or fatal injuries from explosion.

- If the motor is painted, observe the requirements for painting to avoid electrostatic charge according to EN 13463-1.



▲ WARNING

Paint can block the breather valve and damage the sealing lips of the oil seals.

Severe or fatal injuries.

- Thoroughly mask the breather valve and sealing lip of the oil seals with strips prior to painting/re-painting.
- Remove the masking strips after painting.

6.8.9 Clean the gear unit




INFORMATION

When cleaning the gear unit, do not use materials or procedures (e.g. compressed air) that result in processes causing electrical charge on the coating.



7 Mounting positions

7.1 Designation of the mounting positions



The following illustration shows the SEW-EURODRIVE mounting positions M1 – M6:




R..



F..




K..
S..
W..



15649312267


24804134/EN – 05/2018

7.2 Churning losses and thermal rating

* (→  X)

Churning losses may occur with the following conditions. They must be considered during thermal check:

- A mounting position where the first gear unit stage is fully immersed in the lubricant. The respective mounting positions of the gear units are indicated with a * in chapter Mounting position sheets.
- A high mean input speed and thus a high circumferential velocity of the gear wheels of the input gear stage.

If one or both requirements are met, determine the requirements of the application and the corresponding operating conditions (see chapter "Data for calculating the thermal rating" (→  137)) and contact SEW-EURODRIVE. SEW-EURODRIVE can calculate the thermal rating based on the actual operating conditions. The thermal rating of the gear unit can be increased by appropriate measure e.g. by using a synthetic lubricant with higher thermal endurance properties.

INFORMATION



To reduce churning losses to a minimum, use gear units preferably in M1 mounting position.

7.2.1 Data for calculating the thermal rating

The following information is required for calculating the thermal rating:

Gear unit type and design:

- Gear unit ratio i
- Mean input speed \bar{n}_{Mot} or mean output speed \bar{n}_G in min^{-1}
- Effective motor torque M_{Mot_eff} in Nm
- Input motor power P_{Mot} in kW
- Mounting position M1 – M6 or pivoting angle

Installation site:

- Ambient temperature T_{amb} in $^{\circ}\text{C}$
- In small, closed rooms or in large rooms (halls) or outdoors

Installation on site:

- Space-critical or well ventilated
- Steel or concrete base

7.3 Change of mounting position

INFORMATION



Do not change the mounting position without prior consultation with SEW-EURODRIVE.

The information on the nameplate is binding. The ATEX EU declaration of conformity and the guarantee no longer apply if the mounting position is changed without prior consultation with SEW-EURODRIVE. Changes to the mounting position must be projected and indicated on the nameplate.

Adjust the lubricant fill quantities and the position of the breather valve accordingly in the event of a change of mounting position.

7.4 Universal mounting position M0

SPIROPLAN® W10 – W30 gear units can be ordered with M0 universal mounting position. These small SPIROPLAN® gear units are entirely enclosed due to their small size and have no breather valve. You can use them in any mounting position M1 – M6 without having to adjust the gear unit.

All W10 – W30 gear units of one size have the same oil fill quantity.

7.5 Mounting position MX

Mounting position MX is available for all gear units of the sizes R..7, F..7, K..7, K..9, S..7 and SPIROPLAN® W..7.

In contrast to the M0 mounting position, gear units in MX mounting position must be adjusted according to the mounting position prior to startup.

For mounting position MX, the gear units are delivered with the maximally possible amount of oil and sealed with oil screw plugs. A breather valve is included with each drive. The oil fill volume must be adapted according to the mounting position of the gear unit (see chapter "Lubricant fill quantities" (→ 188)). Customers will also have to mount the enclosed breather valve at the proper location depending on the mounting position, see chapter "Mounting position sheets" (→ 139). For screwing in the breather valve, observe the corresponding tightening torque in chapter "Tightening torques for oil level plugs, oil drain plugs, screw plugs, breather valves and oil sight glasses" (→ 38).

Check for the correct oil level before startup, as described in chapter "Checking the oil level and changing the oil" (→ 118).

7.5.1 Compound gear units in MX mounting position

In MX mounting position, both gear units (primary and subsequent gear unit) are in the same mounting position.

7.6 Mounting position sheets

7.6.1 Key to the mounting position sheets

INFORMATION



The positions of the breather valve, oil level plug, and oil drain plug specified in the mounting position sheets are binding and comply with the assembly specifications.

The motors are only depicted symbolically on the mounting position sheets.

INFORMATION



For gear units with solid shaft: The displayed shaft is always on the A-side.

For shaft-mounted gear units: The shaft with dashed lines represents the customer shaft. The output side (= shaft position) is always shown on the A-side.

INFORMATION



SPIROPLAN® gearmotors are not dependent on the mounting position, except for W..37 and W..47 gearmotors in mounting position M4. However, mounting positions M1 to M6 are also shown for SPIROPLAN® gearmotors to assist you in working with this documentation.

INFORMATION



SPIROPLAN® gearmotors W..10 to W..30 cannot be equipped with breather valves, oil level plugs or oil drain plugs.

SPIROPLAN® gearmotors W..37 and W..47 are equipped with breather valves in mounting position M4 and with oil drain plugs in mounting position M2.




INFORMATION



Some gear units can be supplied in mounting position M0. In this case, the gear unit is delivered in a universal mounting position and can be adjusted to various mounting positions by the customer. It may be necessary to contact SEW-EURODRIVE.

Symbols used

The following table shows the icons used in the mounting position sheets.

| Icon | Meaning |
|---|------------------------------|
|  | Breather valve |
|  | Oil level plug ¹⁾ |
|  | Oil drain plug |

1) Does not apply to the 1st gear unit (large gear unit) of compound gear units. See chapter "Position of the oil level plug of compound gear units".

Displayed shaft

Observe the following information regarding the illustrations on the mounting position sheets:



INFORMATION

For gear units with solid shaft: The displayed shaft is always on the A-side.


For shaft-mounted gear units: The shaft with dashed lines represents the customer shaft. The output end (= shaft position) is always shown on the A-side.

7.6.2 Position of the oil level plug of compound gear units

To ensure sufficient lubrication of the first gear unit (larger gear unit) in case of compound gear units, the following gear units have a higher oil level in the specified mounting positions:

- Helical gear unit type R..R in mounting position M1 and M2
- Helical-worm gear unit type S..R in mounting position M3

The oil level plugs are located at the following positions, deviating from the specifications on the mounting position sheets:





15987248395

| Icon | Meaning |
|------|----------------|
| | Oil level plug |

7.6.3 Mounting positions of helical gearmotors

RX57-RX107


04 043 03 00



* (→ 137)

RXF57-RXF107



04 044 03 00



* (→ 137)

R07-R167



04 040 04 00



* (→ 137)

RF07-RF167, RZ07-RZ87



04 041 04 00



* (→ 137)

R07F-R87F

04 042 04 00




* (→ 137)

7.6.4 Mounting positions of parallel-shaft helical gearmotors


F/FA..B/FH27B-157B, FV27B-107B

42 042 04 00





FF/FAF/FHF/FZ/FAZ/FHZ27-157, FVF/FVZ27-107, FM/FAM67-157

42 043 04 00



FA/FH27-157, FV27-107, FT37-97

42 044 04 00





* (→ 137)

7.6.5 Mounting positions of helical-bevel gearmotors

K/KA..B/KH19B-29B



33 023 00 15



* (→ 137)

KF..B/KAF..B/KHF19B-29B


33 024 00 15




* (→ 137)

KA..B/KH19B-29B


33 025 00 15



M1



M3





M5

M6

* (→ 137)

KF/KAF/KHF19-29


33 026 00 15





* (→ 137)

KA/KH19-29

33 027 00 15





M1



* (→ 137)

K/KA..B39-49


33 092 02 14



* (→ 137)



KF/KAF/KHF39-49

33 093 01 14



KA/KH/KT39-49



33 094 01 14



* (→ 137)

K/KA..B/KH47B-157B, KV47B-107B



34 025 05 00



* (→ 137)

K167-187, KH167B-187B



34 026 05 00



* (→ 137)

KF/KAF/KHF/KZ/KAZ/KHZ37–157, KVF/KVZ37–107, KM/KAM67–157


34 027 04 00



* (→ 137)



KA/KH37-157, KV37-107, KT37-97

39 025 05 00



KH167-187

39 026 05 00





* (→ 137)

7.6.6 Mounting positions of helical-worm gearmotors



S37

05 025 04 00



S47-S97



05 026 04 00



* (→ 137)



SF/SAF/SHF37

05 027 04 00



SF/SAF/SHF/SAZ/SHZ47-97



05 028 04 00



* (→ 137)



SA/SH/ST37

28 020 05 00



SA/SH/ST47-97

28 021 04 00






* (→ 137)

7.6.7 Mounting positions of SPIROPLAN® gearmotors



W10-30

20 001 02 02





WF10-30

20 002 02 02




WA10-30

20 003 03 02




W/WA..B/WH37B-47B

20 012 02 07






M1




M3

M5





M6




WF/WAF/WHF37-47

20 013 02 07




WA/WH/WT37-47

20 014 02 07






M1




M3

M5



M6



8 Technical data

8.1 Extended storage

8.1.1 Design

SEW-EURODRIVE recommends the "extended storage" gear unit design for storage periods longer than 9 months. The lubricant of those gear units is then mixed with a VCI anti-corrosion agent (volatile corrosion inhibitors). Please note that this VCI anti-corrosion agent is only effective in a temperature range of -25 °C to +50 °C. The flange contact surfaces and shaft ends are also treated with an anti-corrosion agent. As standard, the gear unit with "extended storage" option will be supplied with OS1 surface protection. Instead of OS1, you can order OS2, OS3 or OS4.

INFORMATION



For SPIROPLAN® gear units, the extended storage option is not available yet.

INFORMATION



To prevent the VCI anti-corrosion agent from evaporating, the gear units in "extended storage" design must remain tightly sealed until startup.

The gear units come with the oil fill according to the specified mounting position (M1 – M6). Always check the oil level before you take the gear unit into operation.

8.1.2 Storage conditions

Observe the storage conditions specified in the following table for extended storage:

| Climate zone | Packaging ¹⁾ | Storage ²⁾ | Storage duration |
|--|--|--|--|
| Temperate (Europe, USA, Canada, China and Russia, excluding tropical zones) | <ul style="list-style-type: none"> Packed in containers With desiccant and moisture indicator sealed in the plastic wrap | <ul style="list-style-type: none"> roofed Protected against rain and snow and shocks | Up to 3 years with regular inspection of the packaging and humidity indicator (rel. humidity < 50%) |
| | open | <ul style="list-style-type: none"> Under roof and enclosed at constant temperature and atmospheric humidity (5 °C < θ < 50 °C, relative humidity < 50%) No sudden temperature variations Controlled ventilation with filter (free from dust and dirt) No aggressive vapors No shocks | 2 years or more with regular inspections <ul style="list-style-type: none"> Check for cleanness and mechanical damage during the inspection Check corrosion protection |

| Climate zone | Packaging ¹⁾ | Storage ²⁾ | Storage duration |
|---|---|--|--|
| Tropical (Asia, Africa, Central and South America, Australia, New Zealand exclud- ing temperate zones) | <ul style="list-style-type: none"> • Packed in contain-ers • With desiccant and moisture in-dicator sealed in the plastic wrap • Protected against insect damage and mildew by chemical treat-ment | <ul style="list-style-type: none"> • roofed • Protected against rain and snow • and shocks | Up to 3 years with regu-lar inspection of the packaging and humidity indicator (rel. humidity < 50%) |
| | open | <ul style="list-style-type: none"> • Under roof and enclosed at constant temperature and atmospheric hu-midity (5 °C < ϑ < 50 °C, < 50% rel-ative humidity) • No sudden temperature variations • Controlled ventilation with filter (free from dust and dirt) • No aggressive vapors • No shocks • Protected against insect damage | 2 years or more with regular inspections <ul style="list-style-type: none"> • Check for cleanness and mechanical damage during the inspection • Check corrosion protection |

1) The packaging must be carried out by an experienced company using the packaging materials that have been explicitly specified for the particular application

2) SEW-EURODRIVE recommends to store the gear units according to the mounting position



8.2 Lubricants

Unless a special arrangement is made, SEW-EURODRIVE supplies the drives with a lubricant fill adapted for the specific gear unit and mounting position. The mounting position (see chapter "Mounting positions" (→ 136)) must therefore be specified in the drive order. You must adapt the lubricant fill in case of any subsequent changes made to the mounting position (see chapter "Lubricant fill quantities" (→ 188)).

8.2.1 Bearing greases

The gear unit rolling bearings are given a factory-fill with the greases listed below. SEW-EURODRIVE recommends re-greasing the rolling bearings with a grease filling at the same time as changing the oil.

The table shows the lubricants recommended by SEW-EURODRIVE:

| Area of operation | Ambient temperature | Manufacturer | Type |
|--|---------------------|-----------------|---------------------------------|
| Standard | -40 °C to +80 °C | Fuchs | Renolit CX-TOM 15 ¹⁾ |
| | -40 °C to +80 °C | Klüber | Petamo GHY 133 N |
|  ²⁾ | -40 °C to +40 °C | Bremer & Leguil | Cassida Grease GTS 2 |
|  ³⁾ | -20 °C to +40 °C | Fuchs | Plantogel 2S |

1) Bearing grease based on semi-synthetic base oil

2) Lubricant for the food processing industry

3) Easily biodegradable lubricant for environmentally sensitive areas

INFORMATION



The following grease quantities are required:

- **For fast-running bearings (gear unit input side):** Fill the cavities between the rolling elements one-third full with grease.
- **For slow-running bearings (gear unit output side):** Fill the cavities between the rolling elements two-thirds full with grease.

8.2.2 Lubricant table

NOTICE

Selecting improper lubricants may damage the gear unit.

Possible damage to property.

- Observe the following information.

- The oil viscosity and type (mineral/synthetic) that are to be used are determined by SEW-EURODRIVE specifically for each order. This information is noted in the order confirmation and on the gear unit's nameplate.



If you use other lubricants for the gear units and/or use the lubricants at temperatures outside the recommended temperature range, SEW-EURODRIVE does not assume liability.

The lubricant recommendation in the lubricant table in no way represents a guarantee regarding the quality of the lubricant delivered by each respective supplier. Each lubricant manufacturer is responsible for the quality of their product.

- Do not mix synthetic lubricants.
- Do not mix synthetic and mineral lubricants.
- Oils of the same viscosity class from different manufacturers do not have the same characteristics. In particular, the minimally and maximally permitted oil bath temperatures are manufacturer-specific. These temperatures are specified in the lubricant tables.
- The values specified in the lubricant tables apply as of the time of printing of this document. The data of the lubricants are subject to dynamic change on the part of the lubricant manufacturers. For up-to-date information about the lubricants, visit:

www.sew-eurodrive.de/lubricants

Information on table structure

| | | | |
|---|---|-------------------------------------|---|
| [1]  R.. | [2]  °C -50 0 +50 +100 | | [3] ISO, SAE NLGI VG 460 VG 220 |
| | -15 | +40 | |
| | -25 | +30 | |
| | | [4] [5] CLP HC - NSF H1 - PSS | |

18014416412986635

- [1] Gear unit type
- [2] Ambient temperature range
- [3] Viscosity class
- [4] Note on special approvals
- [5] Lubricant type

The specified ambient temperatures are guide values for the preselection of a suitable lubricant. The exact upper and lower temperature limits for project planning are specified in the table with the respective trade name.

Information on the various lubricants

| | | | |
|-----|--------------|-----|-----|
| | | | [4] |
| [1] | -15 | +80 | [5] |
| [2] | XYZ108 | | |
| [3] | DE, FR | | |
| | SEW070030014 | | [6] |

- [1] Lowest oil sump temperature in °C, **going below this value during operation is not permitted**
- [2] Trade name
- [3] Factory filling for the listed countries
BR: Brazil
CN: China
DE: Germany
FR: France
US: United States of America
- [4] Manufacturer
- [5] Highest oil sump temperature in °C. The service life will be considerably reduced when exceeded. Observe the lubricant change intervals according to chapter Lubricant change intervals.
- [6] Approvals regarding compatibility of the lubricant with approved oil seals

Lubricant compatibility with oil seal

| Approval | Explanation |
|----------------|---|
| SEW07004_ _13: | A lubricant especially recommended with regard to compatibility with the approved oil seals. The lubricant exceeds the state-of-the-art requirements regarding elastomer compatibility. |

Approved application temperature range of the oil seals

In the low temperature range, oil seals can withstand shaft deflections (e. g. through overhung load) only to a limited extent. Especially avoid or limit pulsating or changing radial displacements of the shaft. Contact SEW-EURODRIVE, if required.

| Oil seal Material class | Permitted Oil sump temperature |
|----------------------------|-----------------------------------|
| NBR | -40 °C to +80 °C |
| FKM | -25 °C to +115 °C |
| FKM-PSS | -25 °C to +115 °C |

Limitations of use of oil seals with the specific lubricant are described in the following table:

| Material class | | | Manufacturer | | Material | |
|----------------|---|-----|--------------|-------------|----------|---------------|
| S | 1 | NBR | 1 | Freudenberg | | 72 NBR 902 |
| | | | 2 | Trelleborg | | 4NV11 |
| | 2 | FKM | 1 | Freudenberg | 1 | 75 FKM 585 |
| | | | | | 2 | 75 FKM 170055 |
| | | | 2 | Trelleborg | 1 | VCBVR |
| | | | | | | |






Examples:


S11: Only the elastomer 72NBR902 of the Freudenberg company meets the requirements of the approval in conjunction with the specific lubricant.

S2: Only the elastomer FKM meets the requirements of the approval in conjunction with the specific lubricant.

Key

The following table shows the abbreviations and icons used in the lubricant table and explains what they mean:

| Abbreviation/icon | Meaning |
|---|--|
|  | Synthetic lubricant (marked gray) |
|  | Mineral lubricants |
| CLP | Mineral oil |
| CLP PG | Polyglycol (PG) |
| CLP HC | Synthetic hydrocarbons – polyalphaolefin (PAO) |
| E | Ester-based oil |
|  | Lubricant for the food processing industry – NSF-H1-compliant |
|  | Easily biodegradable oil for environmentally sensitive areas |
|  | Lubricant suitable for ATEX environment. |
| 1) | Helical-worm gear units with CLP-PG: Contact SEW-EURODRIVE |
| 2) | Special lubricant for SPIROPLAN® gear units only |
| 3) | SEW $f_B \geq 1.2$ required |
| 4) | Observe the critical starting behavior at low temperatures |
| 7) | With appropriate measures, the gear units can be operated at ambient temperatures as low as -40 °C. Contact SEW-EURODRIVE. |
| Oil seal | Oil seal |
| PSS | Oil seal type Premium Sine Seal (PSS). The addendum "PSS" at the lubricant type signals compatibility with the sealing system. |

Observe the thermal limit of the oil seal material, see chapter "Lubricant compatibility with oil seal" (→  178).

| | [3] °C -50 0 +50 +100 | [1] | [2] | ISO, SAE NILGI | SEW EURODRIVE | bremner & eguitl | Castrol / | FUCHS | Mobil® | KLÜBERS LUBRICATION | Shell | TOTAL |
|--------------|--|-----|------------|-------------------|------------------|------------------|-------------------------------|------------------|----------------------|-------------------------|--------------------------|--------------|
| R.. | -25 | ⊕ | CLP PG | VG 220 | | | Optigear Synthetic 800/220 | Renolin PG220 | Mobil Glyoyle 220 | Klübersynth GH 6-220 | Shell Omala S4 WE 220 | Cater SY 220 |
| RES K..7 | +80 | | | | | | | | DE.FR. | | ON.US. | |
| KES HK.. F.. | -25 | ⊕ | CLP PG PSS | VG 220 | | | | | | | | |

- [1] Note on special approvals
- [2] Oil type
- [3] Ambient temperature range

The lubricant table is valid at the day this document is published. Refer to www.sew-eurodrive.de/lubricants for the latest tables.

Observe the thermal limit of the oil seal material, see chapter "Lubricant compatibility with oil seal" (→ 178).

| [3] °C -50 0 +50 +100 [4] | [1] Ex | [2] CLP HC | ISO, SAE NLGI | SEW EURODRIVE | b bremer & leguit | Castrol | FUCHS | Mobil® | KLOBER LUBRICATION | Shell | TOTAL |
|---------------------------------|-----------|---------------|----------------------|------------------|----------------------|-----------------------------|--------------------------|--|----------------------------------|------------------------------------|---------------|
| | | | | | | | | | | | |
| -25 +60 | | | VG 220 | | | Optigear Synthetic PD220 | Renolin Unisyn CLP220 | Mobil SHC 630 DE, FR | Klubersynth GEM 4-220 N BR | Shell Omala S4 GX 220 CN, US | Cater SH 220 |
| -30 +50 | | | VG 150 ⁴⁾ | | | Optigear Synthetic PD150 | Renolin Unisyn CLP150 | Mobil SHC 629 DE, FR | Klubersynth GEM 4-150 N | Shell Omala S4 GX 150 | Cater SH 150 |
| -40 +20 | | | VG 68 ⁴⁾ | | | | Renolin Unisyn CLP68 | Mobil SHC 626 DE, FR | | Shell Omala S4 GX 68 | |
| -40 0 | | | VG 32 ⁴⁾ | | | | Renolin Unisyn OL32 | Mobil SHC 624 DE, FR | | | Dacris SH 321 |
| -25 +60 | | CLP HC - PSS | VG 220 | | | | | Mobil SHC 630 DE, FR, US, BR, CN | | | |
| -30 +50 | | | VG 150 ⁴⁾ | | | | | Mobil SHC 629 DE, FR, US, BR, CN | | | |

R.: RES
K.: 7
KES
HK.:
F.:   

- [1] Note on special approvals
[2] Oil type
[3] Ambient temperature range
[4] Standard

The lubricant table is valid at the day this document is published. Refer to www.sew-eurodrive.de/lubricants for the latest tables.

Observe the thermal limit of the oil seal material, see chapter "Lubricant compatibility with oil seal" (→ 178).


































| [3] [4] °C -50 0 +50 +100 | [1] | [2] | ISO/SAE NLGI | SEW EURODRIVE | brenner & lauit | Castrol | FUCHS | Mobil® | KLOBER LUBRICATION | Shell | TOTAL |
|---------------------------------|-----|-----|---------------------|------------------|-------------------------|---|-------------------------------|--------|---------------------------|-------|-------|
| | | | | | | | | | | | |
| -15 | | | VG 460 | | Cassida Fluid GL 460 | Optileb GT 460 DE, FR | | | Klüberoil 4UH1-460 N | | |
| +40 | | | | | | SEW070040013 | | | | | |
| -25 | | | VG 220 | | Cassida Fluid GL 220 | Optileb GT 220 DE, FR | | | Klüberoil 4UH1-220 N | | |
| +30 | | | | | | SEW070040013 | | | | | |
| -35 | | | VG 68 ⁴⁾ | | Cassida Fluid HF 68 | Optileb HY 68 DE, FR | | | Klüberoil 4UH1-68 N | | |
| 0 | | | | | | SEW070040013 | | | | | |
| -40 | | | VG 32 ⁴⁾ | | Cassida Fluid HF 32 | Optileb HY 32 DE, FR | | | KlüberSummit HySynFG32 | | |
| +10 | | | | | | SEW070040013 | | | | | |
| -15 | | | VG 460 | | | Optileb GT 460 DE, FR, US, BR, CN | | | | | |
| +40 | | | | | | SEW070040013 | | | | | |
| -25 | | | VG 220 | | | Optileb GT 220 DE, FR, US, BR, CN | | | | | |
| +30 | | | | | | SEW070040013 | | | | | |
| -20 | | | VG 460 | | | | Plantogear 460 S DE, FR | | Klüberbio CA2-460 | | |
| +40 | | | | | | | | | | | |

- [1] Note on special approvals
 [2] Oil type
 [3] Ambient temperature range
 [4] Standard

Lubricant table for K..9 gear units

The lubricant table is valid at the day this document is published. Refer to www.sew-eurodrive.de/lubricants for the latest tables.

Observe the thermal limit of the oil seal material, see chapter "Lubricant compatibility with oil seal" (→ 178).

| | | | | | | | | | | |
|---|---|---|---|---|---|--|---|---|---|---|
|  |  |  |  |  |  |  |  |  |  |  |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
|  |  |  |  |  |  |  |  |  |  |  |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
|  |  |  |  |  |  |  |  |  |  |  |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |
| | | | | | | | | | | |

- [1] Note on special approvals
- [2] Oil type
- [3] Ambient temperature range
- [4] Standard

Lubricant table for S.. gear units

The lubricant table is valid at the day this document is published. Refer to www.sew-eurodrive.de/lubricants for the latest tables.

Observe the thermal limit of the oil seal material, see chapter "Lubricant compatibility with oil seal" (→ 178).

| [3] °C -50 0 +50 +100 [4] | [1] [2] | ISO, SAE NLGI | SEW EURODRIVE | b tremer & seguit | Castrol | FUCHS | Mobil® | KLOBER LUBRICATION | Shell | TOTAL |
|---------------------------------|------------|------------------|------------------|----------------------|-------------------------------|-------------------|---------------------------------|---|--------------------------|---------------|
| | | | | | | | | | | |
| -15 +80 | [1] | 1) VG 680 | | | Optigear Synthetic 800/680 | Renolin PG 680 | Mobil Glygoyle 680 | Klübersynth GH 6-680 DE, FR | Shell Omala S4 WE 680 | |
| | | | | | | | | | | |
| -25 +40 | [1] | 1) VG 220 | | | Optigear Synthetic 800/220 | Renolin PG 220 | Mobil Glygoyle 220 DE, FR | Klübersynth GH 6-220 | Shell Omala S4 WE 220 | Carter SY 220 |
| | | | | | | | | | | |
| -15 +80 | [1] | 1) VG 680 | | | | | | Klübersynth GH 6-680 DE, FR, US, BR, CN | | |
| | | | | | | | | | | |
| -25 +40 | [1] | 1) VG 220 | | | | | | Klübersynth GH 6-220 DE, FR, US, BR, CN | | |
| | | | | | | | | | | |

S..
HS.. 

- [1] Note on special approvals
- [2] Oil type
- [3] Ambient temperature range
- [4] Standard

The lubricant table is valid at the day this document is published. Refer to www.sew-eurodrive.de/lubricants for the latest tables.

Observe the thermal limit of the oil seal material, see chapter "Lubricant compatibility with oil seal" (→ 178).

| [3] °C -50 0 +50 +100 [4] | [1] [2] | ISO SAE NLGI | SEW EURODRIVE | b tremer & eguit | Castrol | FUCHS | Mobil® | KUBERNER LUBRICATION | Shell | TOTAL |
|---------------------------------|------------|----------------------|------------------|---------------------|------------------------------|---------------------------|--|----------------------------|--------------------------|---------------|
| | | | | | | | | | | |
| [4] -15 +60 | [1] [2] | VG 460 | | | Optigear Synthetic PD 460 | Renolin Unisyn CLP 460 | Mobil SHC 634 DE, FR | Küblersynth GEW 4-460 N | Shell Omala S4 GX 460 | Carter SH 460 |
| | | | | | | | | | | |
| [4] -30 +30 | [1] [2] | VG 150 ⁴⁾ | | | Optigear Synthetic PD 150 | Renolin Unisyn CLP 150 | Mobil SHC 629 DE, FR | Küblersynth GEW 4-150 N | Shell Omala S4 GX 150 | Carter SH 150 |
| | | | | | | | | | | |
| [4] -40 +20 | [1] [2] | VG 68 ⁴⁾ | | | | Renolin Unisyn CLP 68 | Mobil SHC 626 DE, FR | | Shell Omala S4 GX 68 | |
| | | | | | | | | | | |
| [4] -40 0 | [1] [2] | VG 32 ⁴⁾ | | | | Renolin Unisyn OL 32 | Mobil SHC 624 DE, FR | | | Dachis SH 32 |
| | | | | | | | | | | |
| [4] -15 +60 | [1] [2] | VG 460 | | | | | Mobil SHC 634 DE, FR, US, BR, CN | | | |
| | | | | | | | | | | |
| [4] -30 +30 | [1] [2] | VG 150 ⁴⁾ | | | | | Mobil SHC 629 DE, FR, US, BR, CN | | | |
| | | | | | | | | | | |



- [1] Note on special approvals
- [2] Oil type
- [3] Ambient temperature range
- [4] Standard

The lubricant table is valid at the day this document is published. Refer to www.sew-eurodrive.de/lubricants for the latest tables.

Observe the thermal limit of the oil seal material, see chapter "Lubricant compatibility with oil seal" (→ 178).

| [3] °C -50 0 +50 +100 [4] | [1] [2] | ISO SAE NLGI | SEW EURODRIVE | brenner & regit | Castrol | FUCHS | Mobil® | KLOBER Lubrication | Shell | TOTAL |
|---------------------------------|-----------------------|-----------------|------------------|-------------------------|---|-------------------------------|--------|-----------------------------|-------|-------|
| | | | | | | | | | | |
| -15 | CLP HC - NSF H1 | VG 460 | | Cassida Fluid GL 460 | Optileb GT 460 DE, FR | | | Klüberoil 4UH1-460 N | | |
| +40 | | | | | SEW070040013 | | | | | |
| -25 | CLP HC - NSF H1 | VG 220 | | Cassida Fluid GL 220 | Optileb GT 220 DE, FR | | | Klüberoil 4UH1-220 N | | |
| +30 | | | | | SEW070040013 | | | | | |
| -35 | CLP HC - NSF H1 | VG 68 | 4) | Cassida Fluid HF 68 | Optileb HY 68 DE, FR | | | Klüberoil 4UH1-68 N | | |
| +10 | | | | | | | | | | |
| -40 | CLP HC - NSF H1 - PSS | VG 32 | 4) | Cassida Fluid HF 32 | Optileb HY 32 DE, FR | | | KlüberSummit HySyn FG 32 | | |
| -10 | | | | | | | | | | |
| -15 | CLP HC - NSF H1 - PSS | VG 460 | | | Optileb GT 460 DE, FR, US, BR, CN | | | | | |
| +40 | | | | | SEW070040013 | | | | | |
| -25 | CLP HC - NSF H1 - PSS | VG 220 | | | Optileb GT 220 DE, FR, US, BR, CN | | | | | |
| +30 | | | | | SEW070040013 | | | | | |
| -20 | E | VG 460 | | | | Plantogear 460 S DE, FR | | Klüberbio CA2-460 | | |
| +40 | | | | | | | | | | |



S..
HS..


- [1] Note on special approvals
 [2] Oil type
 [3] Ambient temperature range
 [4] Standard

Lubricant table for W.. gear units

The lubricant table is valid at the day this document is published. Refer to www.sew-eurodrive.de/lubricants for the latest tables.


Observe the thermal limit of the oil seal material, see chapter "Lubricant compatibility with oil seal" (→ 178).

| | | | | | | | | | | | | |
|---|---|---|----------------------------------|------------------------------------|-------------------------------------|-------------------------------|--------------------|------------------|------------------|--|------------------|------------------|
| <div>W..</div> <div>HW..</div> <div></div> | <div>[3]</div> <div>°C -50 0 +50 +100</div> | <div>[1]</div> <div></div> | <div>[2]</div> <div>CLP PG</div> | <div>ISO/SAE</div> <div>NLGI</div> | <div>SEW</div> <div>EURODRIVE</div> | <div>reiner & legit</div> | <div>Castrol</div> | <div>FUCHS</div> | <div>Mobil</div> | <div>KLOPPER</div> <div>AMERICAN</div> | <div>Shell</div> | <div>TOTAL</div> |
| | | | | | | | | | | | | |
| | | | | | | | | | | | | |
| | | | | | | | | | | | | |

- [1] Note on special approvals
- [2] Oil type
- [3] Ambient temperature range
- [4] Standard


8.2.3 Lubricant fill quantities

Refer to the gear unit nameplate for prescribed lubricant fill quantities in explosion-proof gear units.

Check the oil level after the filling process, see chapter "Inspection/maintenance for the gear unit" (→  118).

INFORMATION



Unless a special arrangement is made, SEW-EURODRIVE supplies the drives with a lubricant fill adapted for the specific mounting position. The decisive factor is the mounting position (see chapter "Mounting positions" (→  136)) which must be specified with the order.

When the mounting position is changed, the amount of lubricant must be adapted accordingly. Do not **change the mounting position** without prior consultation with SEW-EURODRIVE. If you do not consult SEW-EURODRIVE, the **ATEX certification** and **rights to claim under limited warranty** become void.

9 Malfunctions and remedies



⚠ WARNING

Risk of death or injury if the drive starts up unintentionally.

Severe or fatal injuries.

- De-energize the motor before you start working on the unit.
- Secure the motor against unintended power-up.



⚠ CAUTION

Risk of burns due to hot gear unit and hot gear unit oil.

Serious injuries.

- Let the gear unit cool down before you start working on it.
- Carefully remove the oil level plug and the oil drain plug.

NOTICE

Damage to gear unit/gearmotor due to improper operation.

Damage to the gear unit/gearmotor.

- Repair works at SEW-EURODRIVE gear units may only be performed by qualified personnel. In the context of this documentation, qualified personnel are persons who are familiar with the "Technical regulations on operating safety" (TRBS).
- Drive and motor may only be disconnected by qualified personnel.
- Contact SEW-EURODRIVE.

9.1 Gear units

| Fault | Possible cause | Measure |
|---|--|---|
| Unusual, regular running noise | <ul style="list-style-type: none"> Meshing/grinding noise: Bearing damage Knocking noise: Irregularity in the gearing Deformation of the housing upon tightening Noise generated by insufficient stiffness of the gear unit foundation | <ul style="list-style-type: none"> Check oil consistency, change bearings Consult SEW-EURODRIVE Check the gear unit mounting for possible deformation and correct if necessary Reinforce the gear unit foundation |
| Unusual, irregular running noises | <ul style="list-style-type: none"> Foreign objects in the oil | <ul style="list-style-type: none"> Check the oil consistency Stop the drive, contact SEW-EURODRIVE |
| Oil leaking from inspection cover | <ul style="list-style-type: none"> Seal of the inspection cover leaking | <ul style="list-style-type: none"> Tighten the screws of the inspection cover and observe the gear unit. Contact SEW-EURODRIVE if oil is still leaking. |
| | <ul style="list-style-type: none"> Seal defective | <ul style="list-style-type: none"> Contact SEW-EURODRIVE. |
| Small amounts of oil leak from the oil seal during run-in phase. | <ul style="list-style-type: none"> Function-related pseudo-leakage | <ul style="list-style-type: none"> There is no fault. Remove with soft, lint-free cloth and keep monitoring it. |
| Film of moisture around the dust lip of the oil seal | <ul style="list-style-type: none"> Function-related pseudo-leakage | <ul style="list-style-type: none"> There is no fault. Remove with soft, lint-free cloth and keep monitoring it. |
| Oil leaking from the oil seal. | <ul style="list-style-type: none"> Oil seal leaking/defective | <ul style="list-style-type: none"> Check sealing system. It may be necessary to contact SEW-EURODRIVE. |
| Oil leaking from motor (e.g. terminal box or fan) | <ul style="list-style-type: none"> Too much oil | <ul style="list-style-type: none"> Check oil level, correct if necessary |
| | <ul style="list-style-type: none"> Gear unit not ventilated | <ul style="list-style-type: none"> Vent gear unit |
| | <ul style="list-style-type: none"> Oil seal leaking/defective | <ul style="list-style-type: none"> Check sealing system. It may be necessary to contact SEW-EURODRIVE. |
| Oil leaking from flange | <ul style="list-style-type: none"> Flange gasket leaking/defective | <ul style="list-style-type: none"> Check sealing system. It may be necessary to contact SEW-EURODRIVE. |
| | <ul style="list-style-type: none"> Too much oil | <ul style="list-style-type: none"> Check oil level, correct if necessary |
| | <ul style="list-style-type: none"> Gear unit not ventilated | <ul style="list-style-type: none"> Vent gear unit |
| Oil leaking from breather valve. | <ul style="list-style-type: none"> Too much oil. | <ul style="list-style-type: none"> Check oil quantity, correct if necessary |
| | <ul style="list-style-type: none"> Function-related oil mist | <ul style="list-style-type: none"> There is no fault. |
| | <ul style="list-style-type: none"> Drive not installed in proper mounting position. | <ul style="list-style-type: none"> Install breather valve correctly and adjust the oil level. |
| | <ul style="list-style-type: none"> Frequent cold starts (oil foaming) and/or high oil level. | <ul style="list-style-type: none"> Install oil expansion tank. |
| Output shaft does not turn although the motor is running or the input shaft is rotated. | <ul style="list-style-type: none"> Shaft-hub connection in the gear unit interrupted. | <ul style="list-style-type: none"> Send in the gear unit/gearmotor for repair |

9.2 AM/AQ./AL adapters

| Fault | Possible cause | Measure |
|---|---|---|
| Unusual, regular running noise | <ul style="list-style-type: none"> Meshing/grinding noise: Bearing damage | <ul style="list-style-type: none"> Contact SEW-EURODRIVE. |
| Oil leaking. | <ul style="list-style-type: none"> Seal defective | <ul style="list-style-type: none"> Contact SEW-EURODRIVE. |
| Output shaft does not turn although the motor is running or the input shaft is rotated. | <ul style="list-style-type: none"> Shaft-hub connection in the gear unit interrupted. | <ul style="list-style-type: none"> Send in the gear unit/gearmotor for repair. |
| Change in running noise and/or vibrations | <ul style="list-style-type: none"> Spider wear, short-term torque transmission through metal contact | <ul style="list-style-type: none"> Change the spider. |
| | <ul style="list-style-type: none"> Screws to secure hub axially are loose | <ul style="list-style-type: none"> Tighten the screws |
| Premature wear of spider | <ul style="list-style-type: none"> Contact with aggressive fluids/oils; ozone influence; excessive ambient temperatures, etc. that can change the physical properties of the spider. | <ul style="list-style-type: none"> Contact SEW-EURODRIVE. |
| | <ul style="list-style-type: none"> Impermissibly high ambient/contact temperature for the spider; maximum permitted temperature: -20 °C to +80 °C. | <ul style="list-style-type: none"> Contact SEW-EURODRIVE. |
| | <ul style="list-style-type: none"> Overload | <ul style="list-style-type: none"> Contact SEW-EURODRIVE. |

9.3 AD input shaft assembly

| Fault | Possible cause | Measure |
|---|---|---|
| Unusual, regular running noise. | <ul style="list-style-type: none"> Meshing/grinding noise: Bearing damage. | <ul style="list-style-type: none"> Contact SEW-EURODRIVE. |
| Oil is leaking. | <ul style="list-style-type: none"> Seal defective. | <ul style="list-style-type: none"> Contact SEW-EURODRIVE. |
| Output shaft does not turn although the input shaft is rotated. | <ul style="list-style-type: none"> Shaft-hub connection in gear unit or cover interrupted. | <ul style="list-style-type: none"> Send the gear unit to SEW-EURODRIVE for repair. |

9.4 Adapter with AR slip clutch

| Fault | Possible cause | Measure |
|--------------------------------|--|--|
| Unusual, regular running noise | <ul style="list-style-type: none"> Meshing/grinding noise: Bearing damage | <ul style="list-style-type: none"> Contact SEW-EURODRIVE. |
| Oil leaking. | <ul style="list-style-type: none"> Seal defective | <ul style="list-style-type: none"> Contact SEW-EURODRIVE. |

| Fault | Possible cause | Measure |
|--------------------------------|---|--|
| Evaluation unit display empty. | • Incremental encoder of adapter is defective. | • Measure input pulses and replace incremental encoder of adapter if necessary |
| | • Friction lining worn. | • Inspect friction lining / cup springs and replace if necessary |
| Slip torque is not reached. | <ul style="list-style-type: none"> • Friction lining worn. • Cup springs burned out or installed incorrectly after maintenance. | • Inspect friction lining / cup springs and replace if necessary |

9.5 Service

If you require customer service, include the following information:

- Nameplate data (complete)
- Nature and extent of the problem
- Time the failure occurred and any accompanying circumstances
- Presumed cause
- A digital picture of the failure, if possible

9.6 Waste disposal

Dispose gear units in accordance with the material structure and the regulations in force:

- As steel scrap
 - Housing parts
 - Gears
 - Shafts
 - Rolling bearing
- Parts of the worm gears are made of non-ferrous metals. Dispose of the worm gears appropriately.
- Collect used oil and dispose of it according to the regulations in force.

10 Declarations of conformity

10.1 Gear units in category 2G and 2D with AM..., AQ..., AL..., AD..., AR.. adapter

EU Declaration of Conformity



Translation of the original text

900610510/EN

SEW-EURODRIVE GmbH & Co. KG

Ernst-Blickle-Straße 42, D-76646 Bruchsal

declares under sole responsibility that the following products

| | | |
|--|---|-----|
| Gear units of the series | R.. F.. K.. S.. W.. | |
| optionally with mount-on components of the series | AM.. AQ.. AL.. AD.. AR.. | |
| variant | /II2GD /II2G or /II2D | |
| Category | 2G 2D | |
| Designation | Ex h IIC T4 Gb or Ex h IIC T4 Gb X or Ex h IIIC T120 °C Db or Ex h IIIC T120 °C Db X | 15) |
| in accordance with | | |
| ATEX Directive | 2014/34/EU (L 96, 29.03.2014, 309-356) | 2) |
| Applied harmonized standards: | EN ISO 80079-36:2016 EN ISO 80079-37:2016 EN 60529:1991/A1:2000/A2:2013 | |

2) SEW-EURODRIVE lodges the documents required by 2014/34/EU, appendix VIII, with the notified body: FSA GmbH, EU ID no.: 0588

15) This classification of the temperature class / surface temperature is an example. The order-specific Ex identification can be found on the nameplate.

Bruchsal 01.02.2018

Place Date

Johann Soder
Managing Director Technology

a) b)

- a) Authorized representative for issuing this declaration on behalf of the manufacturer
b) Authorized representative for compiling the technical documents

10.2 Gear units in category 2G and 2D with AR.., AM.., AQ.., AL.., AD.. adapter

EU Declaration of Conformity



Translation of the original text

900580510/EN

SEW-EURODRIVE GmbH & Co. KG**Ernst-Blickle-Straße 42, D-76646 Bruchsal**

declares under sole responsibility that the following products

Gear units of the series

R..
F..
K..
S..
W..

Optionally with mount-on components of the series

AR..
AM..
AQ..
AL..
AD..

variant

/II3GD
/II3G or
/II3D

Category

3G
3D

Designation

Ex h IIC T4 Gc or
Ex h IIC T4 Gc X or
Ex h IIIC T120 °C Dc or
Ex h IIIC T120 °C Dc X

15)

in accordance with

ATEX Directive

2014/34/EU
(L 96, 29.03.2014, 309-356)

Applied harmonized standards:

EN ISO 80079-36:2016
EN ISO 80079-37:2016
EN 60529:1991/A1:2000/A2:2013

15) This classification of the temperature class / surface temperature is an example. The order-specific Ex identification can be found on the nameplate.

Bruchsal

01.02.2018

Place

Date

Johann Soder

Managing Director Technology

a) b)

a) Authorized representative for issuing this declaration on behalf of the manufacturer

b) Authorized representative for compiling the technical documents

11 Address list

| | | | |
|--------------------------------|---------------------|---|--|
| Algeria | | | |
| Sales | Algiers | REDUCOM Sarl 16, rue des Frères Zaghroune Bellevue 16200 El Harrach Alger | Tel. +213 21 8214-91 Fax +213 21 8222-84 http://www.reducom-dz.com info@reducom-dz.com |
| Argentina | | | |
| Assembly Sales | Buenos Aires | SEW EURODRIVE ARGENTINA S.A. Ruta Panamericana Km 37.5, Lote 35 (B1619IEA) Centro Industrial Garín Prov. de Buenos Aires | Tel. +54 3327 4572-84 Fax +54 3327 4572-21 http://www.sew-eurodrive.com.ar sewar@sew-eurodrive.com.ar |
| Australia | | | |
| Assembly Sales Service | Melbourne | SEW-EURODRIVE PTY. LTD. 27 Beverage Drive Tullamarine, Victoria 3043 | Tel. +61 3 9933-1000 Fax +61 3 9933-1003 http://www.sew-eurodrive.com.au enquires@sew-eurodrive.com.au |
| | Sydney | SEW-EURODRIVE PTY. LTD. 9, Sleigh Place, Wetherill Park New South Wales, 2164 | Tel. +61 2 9725-9900 Fax +61 2 9725-9905 enquires@sew-eurodrive.com.au |
| Austria | | | |
| Assembly Sales Service | Vienna | SEW-EURODRIVE Ges.m.b.H. Richard-Strauss-Straße 24 1230 Wien | Tel. +43 1 617 55 00-0 Fax +43 1 617 55 00-30 http://www.sew-eurodrive.at sew@sew-eurodrive.at |
| Bangladesh | | | |
| Sales | Bangladesh | SEW-EURODRIVE INDIA PRIVATE LIMITED 345 DIT Road East Rampura Dhaka-1219, Bangladesh | Tel. +88 01729 097309 salesdhaka@seweurodrivebangladesh.com |
| Belarus | | | |
| Sales | Minsk | Foreign unitary production enterprise SEW- EURODRIVE RybalkoStr. 26 220033 Minsk | Tel. +375 17 298 47 56 / 298 47 58 Fax +375 17 298 47 54 http://www.sew.by sales@sew.by |
| Belgium | | | |
| Assembly Sales Service | Brussels | SEW-EURODRIVE n.v./s.a. Researchpark Haasrode 1060 Evenementenlaan 7 3001 Leuven | Tel. +32 16 386-311 Fax +32 16 386-336 http://www.sew-eurodrive.be info@sew-eurodrive.be |
| Service Competence Center | Industrial Gears | SEW-EURODRIVE n.v./s.a. Rue de Parc Industriel, 31 6900 Marche-en-Famenne | Tel. +32 84 219-878 Fax +32 84 219-879 http://www.sew-eurodrive.be service-IG@sew-eurodrive.be |
| Brazil | | | |
| Production Sales Service | São Paulo | SEW-EURODRIVE Brasil Ltda. Estrada Municipal José Rubim, 205 – Rodovia Santos Dumont Km 49 Indaiatuba – 13347-510 – SP | Tel. +55 19 3835-8000 sew@sew.com.br |
| Assembly Sales Service | Rio Claro | SEW-EURODRIVE Brasil Ltda. Rodovia Washington Luiz, Km 172 Condomínio Industrial Conpark Caixa Postal: 327 13501-600 – Rio Claro / SP | Tel. +55 19 3522-3100 Fax +55 19 3524-6653 montadora.rc@sew.com.br |
| | Joinville | SEW-EURODRIVE Brasil Ltda. Rua Dona Francisca, 12.346 – Pirabeiraba 89239-270 – Joinville / SC | Tel. +55 47 3027-6886 Fax +55 47 3027-6888 filial.sc@sew.com.br |
| Bulgaria | | | |
| Sales | Sofia | BEVER-DRIVE GmbH Bogdanovetz Str.1 1606 Sofia | Tel. +359 2 9151160 Fax +359 2 9151166 bever@bever.bg |

Cameroon

| | | | |
|-------|--------|--|---|
| Sales | Douala | SEW-EURODRIVE S.A.R.L. Ancienne Route Bonabéri P.O. Box B.P 8674 Douala-Cameroun | Tel. +237 233 39 02 10 Fax +237 233 39 02 10 sew@sew-eurodrive-cm |
|-------|--------|--|---|

Canada

| | | | |
|------------------------------|-----------|--|---|
| Assembly Sales Service | Toronto | SEW-EURODRIVE CO. OF CANADA LTD. 210 Walker Drive Bramalea, ON L6T 3W1 | Tel. +1 905 791-1553 Fax +1 905 791-2999 http://www.sew-eurodrive.ca l.watson@sew-eurodrive.ca |
| | Vancouver | SEW-EURODRIVE CO. OF CANADA LTD. Tilbury Industrial Park 7188 Honeyman Street Delta, BC V4G 1G1 | Tel. +1 604 946-5535 Fax +1 604 946-2513 b.wake@sew-eurodrive.ca |
| | Montreal | SEW-EURODRIVE CO. OF CANADA LTD. 2555 Rue Leger Lasalle, PQ H8N 2V9 | Tel. +1 514 367-1124 Fax +1 514 367-3677 a.peluso@sew-eurodrive.ca |

Chile

| | | | |
|------------------------------|-------------------|---|---|
| Assembly Sales Service | Santiago de Chile | SEW-EURODRIVE CHILE LTDA Las Encinas 1295 Parque Industrial Valle Grande LAMP Santiago de Chile P.O. Box Casilla 23 Correo Quilicura - Santiago - Chile | Tel. +56 2 2757 7000 Fax +56 2 2757 7001 http://www.sew-eurodrive.cl ventas@sew-eurodrive.cl |
|------------------------------|-------------------|---|---|

China

| | | | |
|--|-----------|--|---|
| Production Assembly Sales Service | Tianjin | SEW-EURODRIVE (Tianjin) Co., Ltd. No. 78, 13th Avenue, TEDA Tianjin 300457 | Tel. +86 22 25322612 Fax +86 22 25323273 http://www.sew-eurodrive.cn info@sew-eurodrive.cn |
| Assembly Sales Service | Suzhou | SEW-EURODRIVE (Suzhou) Co., Ltd. 333, Suhong Middle Road Suzhou Industrial Park Jiangsu Province, 215021 | Tel. +86 512 62581781 Fax +86 512 62581783 suzhou@sew-eurodrive.cn |
| | Guangzhou | SEW-EURODRIVE (Guangzhou) Co., Ltd. No. 9, JunDa Road East Section of GETDD Guangzhou 510530 | Tel. +86 20 82267890 Fax +86 20 82267922 guangzhou@sew-eurodrive.cn |
| | Shenyang | SEW-EURODRIVE (Shenyang) Co., Ltd. 10A-2, 6th Road Shenyang Economic Technological Development Area Shenyang, 110141 | Tel. +86 24 25382538 Fax +86 24 25382580 shenyang@sew-eurodrive.cn |
| | Taiyuan | SEW-EURODRIVE (Taiyuan) Co., Ltd. No.3, HuaZhang Street, TaiYuan Economic & Technical Development Zone ShanXi, 030032 | Tel. +86-351-7117520 Fax +86-351-7117522 taiyuan@sew-eurodrive.cn |
| | Wuhan | SEW-EURODRIVE (Wuhan) Co., Ltd. 10A-2, 6th Road No. 59, the 4th Quanli Road, WEDA 430056 Wuhan | Tel. +86 27 84478388 Fax +86 27 84478389 wuhan@sew-eurodrive.cn |
| | Xi'An | SEW-EURODRIVE (Xi'An) Co., Ltd. No. 12 Jinye 2nd Road Xi'An High-Technology Industrial Development Zone Xi'An 710065 | Tel. +86 29 68686262 Fax +86 29 68686311 xian@sew-eurodrive.cn |
| Sales Service | Hong Kong | SEW-EURODRIVE LTD. Unit No. 801-806, 8th Floor Hong Leong Industrial Complex No. 4, Wang Kwong Road Kowloon, Hong Kong | Tel. +852 36902200 Fax +852 36902211 contact@sew-eurodrive.hk |

| | | | |
|--------------------------------|---|---|--|
| Colombia | | | |
| Assembly Sales Service | Bogota | SEW-EURODRIVE COLOMBIA LTDA. Calle 17 No. 132-18 Interior 2 Bodega 6, Manzana B Santafé de Bogotá | Tel. +57 1 54750-50 Fax +57 1 54750-44 http://www.sew-eurodrive.com.co sew@sew-eurodrive.com.co |
| Croatia | | | |
| Sales Service | Zagreb | KOMPEKS d. o. o. Zeleni dol 10 10 000 Zagreb | Tel. +385 1 4613-158 Fax +385 1 4613-158 kompeks@inet.hr |
| Czech Republic | | | |
| Assembly Sales Service | Hostivice | SEW-EURODRIVE CZ s.r.o. Floriánova 2459 253 01 Hostivice | Tel. +420 255 709 601 Fax +420 235 350 613 http://www.sew-eurodrive.cz sew@sew-eurodrive.cz |
| | Drive Service Hotline / 24 Hour Service | +420 800 739 739 (800 SEW SEW) | Service Tel. +420 255 709 632 Fax +420 235 358 218 servis@sew-eurodrive.cz |
| Denmark | | | |
| Assembly Sales Service | Copenhagen | SEW-EURODRIVEA/S Geminivej 28-30 2670 Greve | Tel. +45 43 95 8500 Fax +45 43 9585-09 http://www.sew-eurodrive.dk sew@sew-eurodrive.dk |
| Egypt | | | |
| Sales Service | Cairo | Copam Egypt for Engineering & Agencies Building 10, Block 13005, First Industrial Zone, Obour City Cairo | Tel. +202 44812673 / 79 (7 lines) Fax +202 44812685 http://www.copam-egypt.com copam@copam-egypt.com |
| Estonia | | | |
| Sales | Tallin | ALAS-KUUL AS Reti tee 4 75301 Peetri küla, Rae vald, Harjumaa | Tel. +372 6593230 Fax +372 6593231 http://www.alas-kuul.ee veiko.soots@alas-kuul.ee |
| Finland | | | |
| Assembly Sales Service | Hollola | SEW-EURODRIVE OY Vesimäentie 4 15860 Hollola | Tel. +358 201 589-300 Fax +358 3 780-6211 http://www.sew-eurodrive.fi sew@sew.fi |
| Service | Hollola | SEW-EURODRIVE OY Keskikankaantie 21 15860 Hollola | Tel. +358 201 589-300 Fax +358 3 780-6211 http://www.sew-eurodrive.fi sew@sew.fi |
| Production Assembly | Karkkila | SEW Industrial Gears Oy Santasalonkatu 6, PL 8 03620 Karkkila, 03601 Karkkila | Tel. +358 201 589-300 Fax +358 201 589-310 http://www.sew-eurodrive.fi sew@sew.fi |
| France | | | |
| Production Sales Service | Hagenau | SEW-USOCOME 48-54 route de Soufflenheim B. P. 20185 67506 Haguenau Cedex | Tel. +33 3 88 73 67 00 Fax +33 3 88 73 66 00 http://www.usocom.com sew@usocom.com |
| Production | Forbach | SEW-USOCOME Zone industrielle Technopôle Forbach Sud B. P. 30269 57604 Forbach Cedex | Tel. +33 3 87 29 38 00 |
| | Brumath | SEW-USOCOME 1 Rue de Bruxelles 67670 Mommenheim Cedex | Tel. +33 3 88 37 48 00 |
| Assembly Sales Service | Bordeaux | SEW-USOCOME Parc d'activités de Magellan 62 avenue de Magellan – B. P. 182 33607 Pessac Cedex | Tel. +33 5 57 26 39 00 Fax +33 5 57 26 39 09 |

France

| | | |
|--------|---|---|
| Lyon | SEW-USOCOME 75 rue Antoine Condorcet 38090 Vaulx-Milieu | Tel. +33 4 74 99 60 00 Fax +33 4 74 99 60 15 |
| Nantes | SEW-USOCOME Parc d'activités de la forêt 4 rue des Fontenelles 44140 Le Bignon | Tel. +33 2 40 78 42 00 Fax +33 2 40 78 42 20 |
| Paris | SEW-USOCOME Zone industrielle 2 rue Denis Papin 77390 Verneuil l'Étang | Tel. +33 1 64 42 40 80 Fax +33 1 64 42 40 88 |

Gabon

| | | | |
|-------|------------|---|--|
| Sales | Libreville | SEW-EURODRIVE SARL 183, Rue 5.033.C, Lalala à droite P.O. Box 15682 Libreville | Tel. +241 03 28 81 55 +241 06 54 81 33 http://www.sew-eurodrive.cm sew@sew-eurodrive.cm |
|-------|------------|---|--|

Germany

| | | | |
|-------------------------------------|-----------------------------|---|---|
| Headquarters Production Sales | Bruchsal | SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 76646 Bruchsal | Tel. +49 7251 75-0 Fax +49 7251 75-1970 http://www.sew-eurodrive.de sew@sew-eurodrive.de |
| Production / Industrial Gears | Bruchsal | SEW-EURODRIVE GmbH & Co KG Christian-Pähr-Str. 10 76646 Bruchsal | Tel. +49 7251 75-0 Fax +49 7251 75-2970 |
| Production | Graben | SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 1 76676 Graben-Neudorf | Tel. +49 7251 75-0 Fax +49 7251-2970 |
| | Östringen | SEW-EURODRIVE GmbH & Co KG, Werk Östringen Franz-Gurk-Straße 2 76684 Östringen | Tel. +49 7253 9254-0 Fax +49 7253 9254-90 oestringen@sew-eurodrive.de |
| Service Competence Center | Mechanics / Mechatronics | SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 1 76676 Graben-Neudorf | Tel. +49 7251 75-1710 Fax +49 7251 75-1711 scc-mechanik@sew-eurodrive.de |
| | Electronics | SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 76646 Bruchsal | Tel. +49 7251 75-1780 Fax +49 7251 75-1769 scc-elektronik@sew-eurodrive.de |
| Drive Technology Center | North | SEW-EURODRIVE GmbH & Co KG Alte Ricklinger Straße 40-42 30823 Garbsen (Hannover) | Tel. +49 5137 8798-30 Fax +49 5137 8798-55 dtc-nord@sew-eurodrive.de |
| | East | SEW-EURODRIVE GmbH & Co KG Dankritzer Weg 1 08393 Meerane (Zwickau) | Tel. +49 3764 7606-0 Fax +49 3764 7606-30 dtc-ost@sew-eurodrive.de |
| | South | SEW-EURODRIVE GmbH & Co KG Domagkstraße 5 85551 Kirchheim (München) | Tel. +49 89 909552-10 Fax +49 89 909552-50 dtc-sued@sew-eurodrive.de |
| | West | SEW-EURODRIVE GmbH & Co KG Siemensstraße 1 40764 Langenfeld (Düsseldorf) | Tel. +49 2173 8507-30 Fax +49 2173 8507-55 dtc-west@sew-eurodrive.de |
| Drive Center | Berlin | SEW-EURODRIVE GmbH & Co KG Alexander-Meißner-Straße 44 12526 Berlin | Tel. +49 306331131-30 Fax +49 306331131-36 dc-berlin@sew-eurodrive.de |
| | Ludwigshafen | SEW-EURODRIVE GmbH & Co KG c/o BASF SE Gebäude W130 Raum 101 67056 Ludwigshafen | Tel. +49 7251 75 3759 Fax +49 7251 75 503759 dc-ludwigshafen@sew-eurodrive.de |
| | Saarland | SEW-EURODRIVE GmbH & Co KG Gottlieb-Daimler-Straße 4 66773 Schwalbach Saar – Hülzweiler | Tel. +49 6831 48946 10 Fax +49 6831 48946 13 dc-saarland@sew-eurodrive.de |
| | Ulm | SEW-EURODRIVE GmbH & Co KG Dieselstraße 18 89160 Dornstadt | Tel. +49 7348 9885-0 Fax +49 7348 9885-90 dc-ulm@sew-eurodrive.de |

Germany

| | | |
|----------|---|--|
| Würzburg | SEW-EURODRIVE GmbH & Co KG Nürnbergerstraße 118 97076 Würzburg-Lengfeld | Tel. +49 931 27886-60 Fax +49 931 27886-66 dc-wuerzburg@sew-eurodrive.de |
|----------|---|--|

Drive Service Hotline / 24 Hour Service

0 800 SEWHELP
0 800 7394357**Great Britain**

| | | |
|------------------------------|---|--|
| Assembly Sales Service | Normanton SEW-EURODRIVE Ltd. DeVilliers Way Trident Park Normanton West Yorkshire WF6 1GX | Tel. +44 1924 893-855 Fax +44 1924 893-702 http://www.sew-eurodrive.co.uk info@sew-eurodrive.co.uk |
|------------------------------|---|--|

Drive Service Hotline / 24 Hour Service

Tel. 01924 896911

Greece

| | | |
|-------|--|--|
| Sales | Athens Christ. Boznos & Son S.A. 12, K. Mavromichali Street P.O. Box 80136 18545 Piraeus | Tel. +30 2 1042 251-34 Fax +30 2 1042 251-59 http://www.boznos.gr info@boznos.gr |
|-------|--|--|

Hungary

| | | |
|------------------|--|---|
| Sales Service | Budapest SEW-EURODRIVE Kft. Csillaghegyi út 13. 1037 Budapest | Tel. +36 1 437 06-58 Fax +36 1 437 06-50 http://www.sew-eurodrive.hu office@sew-eurodrive.hu |
|------------------|--|---|

Iceland

| | | |
|-------|--|--|
| Sales | Reykjavik Varma & Vélaverk ehf. Knarrarvogi 4 104 Reykjavik | Tel. +354 585 1070 Fax +354 585)1071 http://www.varmaverk.is vov@vov.is |
|-------|--|--|

India

| | | |
|---|--|---|
| Registered Office Assembly Sales Service | Vadodara SEW-EURODRIVE India Private Limited Plot No. 4, GIDC POR Ramangamdi • Vadodara - 391 243 Gujarat | Tel. +91 265 3045200 Fax +91 265 3045300 http://www.seweurodriveindia.com salesvadodara@seweurodriveindia.com |
| Assembly Sales Service | Chennai SEW-EURODRIVE India Private Limited Plot No. K3/1, Sipcot Industrial Park Phase II Mambakkam Village Sriperumbudur - 602105 Kancheepuram Dist, Tamil Nadu | Tel. +91 44 37188888 Fax +91 44 37188811 saleschennai@seweurodriveindia.com |
| | Pune SEW-EURODRIVE India Private Limited Plant: Plot No. D236/1, Chakan Industrial Area Phase- II, Warale, Tal- Khed, Pune-410501, Maharashtra | Tel. +91 21 35 628700 Fax +91 21 35 628715 salespune@seweurodriveindia.com |

Indonesia

| | | |
|-------|---|--|
| Sales | Medan PT. Serumpun Indah Lestari Jl.Pulau Solor no. 8, Kawasan Industri Medan II Medan 20252 | Tel. +62 61 687 1221 Fax +62 61 6871429 / +62 61 6871458 / +62 61 30008041 sil@serumpunindah.com serumpunindah@yahoo.com http://www.serumpunindah.com |
| | Jakarta PT. Cahaya Sukses Abadi Komplek Rukan Puri Mutiara Blok A no 99, Sunter Jakarta 14350 | Tel. +62 21 65310599 Fax +62 21 65310600 csajkt@cbn.net.id |
| | Jakarta PT. Agrindo Putra Lestari Jl.Pantai Indah Selatan, Komplek Sentra Industri Terpadu, Pantai indah Kapuk Tahap III, Blok E No. 27 Jakarta 14470 | Tel. +62 21 2921-8899 Fax +62 21 2921-8988 aplindo@indosat.net.id http://www.aplindo.com |

| Indonesia | | | |
|------------------------------|-------------|--|--|
| | Surabaya | PT. TRIAGRI JAYA ABADI Jl. Sukosemolo No. 63, Galaxi Bumi Permai G6 No. 11 Surabaya 60111 | Tel. +62 31 5990128 Fax +62 31 5962666 sales@triagri.co.id http://www.triagri.co.id |
| | Surabaya | CV. Multi Mas Jl. Raden Saleh 43A Kav. 18 Surabaya 60174 | Tel. +62 31 5458589 Fax +62 31 5317220 sianhwa@sby.centrin.net.id http://www.cvmultimas.com |
| Ireland | | | |
| Sales Service | Dublin | Alperton Engineering Ltd. 48 Moyle Road Dublin Industrial Estate Glasnevin, Dublin 11 | Tel. +353 1 830-6277 Fax +353 1 830-6458 http://www.alperton.ie info@alperton.ie |
| Israel | | | |
| Sales | Tel Aviv | Liraz Handasa Ltd. Ahofer Str 34B / 228 58858 Holon | Tel. +972 3 5599511 Fax +972 3 5599512 http://www.liraz-handasa.co.il office@liraz-handasa.co.il |
| Italy | | | |
| Assembly Sales Service | Milan | SEW-EURODRIVE di R. Blickle & Co.s.a.s. Via Bernini,14 20020 Solaro (Milano) | Tel. +39 02 96 980229 Fax +39 02 96 980 999 http://www.sew-eurodrive.it milano@sew-eurodrive.it |
| Ivory Coast | | | |
| Sales | Abidjan | SEW-EURODRIVE SARL Ivory Coast Rue des Pêcheurs, Zone 3 26 BP 916 Abidjan 26 | Tel. +225 21 21 81 05 Fax +225 21 25 30 47 info@sew-eurodrive.ci http://www.sew-eurodrive.ci |
| Japan | | | |
| Assembly Sales Service | Iwata | SEW-EURODRIVE JAPAN CO., LTD 250-1, Shimoman-no, Iwata Shizuoka 438-0818 | Tel. +81 538 373811 Fax +81 538 373814 http://www.sew-eurodrive.co.jp sewjapan@sew-eurodrive.co.jp hamamatsu@sew-eurodrive.co.jp |
| Kazakhstan | | | |
| Sales | Almaty | SEW-EURODRIVE LLP 291-291A, Tole bi street 050031, Almaty | Tel. +7 (727) 350 5156 Fax +7 (727) 350 5156 http://www.sew-eurodrive.kz sew@sew-eurodrive.kz |
| | Tashkent | SEW-EURODRIVE LLP Representative office in Uzbekistan 96A, Sharaf Rashidov street, Tashkent, 100084 | Tel. +998 71 2359411 Fax +998 71 2359412 http://www.sew-eurodrive.uz sew@sew-eurodrive.uz |
| | Ulaanbaatar | IM Trading LLC Olympic street 28B/3 Sukhbaatar district, Ulaanbaatar 14230 | Tel. +976-77109997 Fax +976-77109997 imt@imt.mn |
| Kenya | | | |
| Sales | Nairobi | SEW-EURODRIVE Pty Ltd Transnational Plaza, 5th Floor Mama Ngina Street P.O. Box 8998-00100 Nairobi | Tel. +254 791 398840 http://www.sew-eurodrive.co.tz info@sew.co.tz |
| Latvia | | | |
| Sales | Riga | SIA Alas-Kuul Katlakalna 11C 1073 Riga | Tel. +371 6 7139253 Fax +371 6 7139386 http://www.alas-kuul.lv info@alas-kuul.com |

| | | | |
|--|-------------|--|--|
| Lebanon | | | |
| Sales (Lebanon) | Beirut | Gabriel Acar & Fils sarl B. P. 80484 Bourj Hammoud, Beirut | Tel. +961 1 510 532 Fax +961 1 494 971 ssacar@inco.com.lb |
| Sales (Jordan, Kuwait , Beirut Saudi Arabia, Syria) | | Middle East Drives S.A.L. (offshore) Sin El Fil. B. P. 55-378 Beirut | Tel. +961 1 494 786 Fax +961 1 494 971 http://www.medrives.com info@medrives.com |
| Lithuania | | | |
| Sales | Alytus | UAB Irseva Statybininku 106C 63431 Alytus | Tel. +370 315 79204 Fax +370 315 56175 http://www.irseva.lt irmantas@irseva.lt |
| Luxembourg | | | |
| representation: Belgium | | | |
| Macedonia | | | |
| Sales | Skopje | Boznos DOOEL Dime Anicin 2A/7A 1000 Skopje | Tel. +389 23256553 Fax +389 23256554 http://www.boznos.mk |
| Malaysia | | | |
| Assembly Sales Service | Johor | SEW-EURODRIVE SDN BHD No. 95, Jalan Seroja 39, Taman Johor Jaya 81000 Johor Bahru, Johor West Malaysia | Tel. +60 7 3549409 Fax +60 7 3541404 sales@sew-eurodrive.com.my |
| Mexiko | | | |
| Assembly Sales Service | Quéretaro | SEW-EURODRIVE MEXICO S.A. de C.V. SEM-981118-M93 Tequisquiapan No. 102 Parque Industrial Quéretaro C.P. 76220 Querétaro, México | Tel. +52 442 1030-300 Fax +52 442 1030-301 http://www.sew-eurodrive.com.mx scmexico@sew-eurodrive.com.mx |
| Sales Service | Puebla | SEW-EURODRIVE MEXICO S.A. de C.V. Calzada Zavaleta No. 3922 Piso 2 Local 6 Col. Santa Cruz Buenavista C.P. 72154 Puebla, México | Tel. +52 (222) 221 248 http://www.sew-eurodrive.com.mx scmexico@sew-eurodrive.com.mx |
| Mongolia | | | |
| Technical Office | Ulaanbaatar | IM Trading LLC Olympic street 28B/3 Sukhbaatar district, Ulaanbaatar 14230 | Tel. +976-77109997 Tel. +976-99070395 Fax +976-77109997 http://imt.mn/ imt@imt.mn |
| Morocco | | | |
| Sales Service | Bouskoura | SEW-EURODRIVE Morocco Parc Industriel CFCIM, Lot 55 and 59 Bouskoura | Tel. +212 522 88 85 00 Fax +212 522 88 84 50 http://www.sew-eurodrive.ma sew@sew-eurodrive.ma |
| Namibia | | | |
| Sales | Swakopmund | DB Mining & Industrial Services Einstein Street Strauss Industrial Park Unit1 Swakopmund | Tel. +264 64 462 738 Fax +264 64 462 734 anton@dbminingnam.com |
| Netherlands | | | |
| Assembly Sales Service | Rotterdam | SEW-EURODRIVE B.V. Industrieweg 175 3044 AS Rotterdam Postbus 10085 3004 AB Rotterdam | Tel. +31 10 4463-700 Fax +31 10 4155-552 Service: 0800-SEWHELP http://www.sew-eurodrive.nl info@sew-eurodrive.nl |

| | | | |
|------------------------------|---------------------|--|--|
| New Zealand | | | |
| Assembly Sales Service | Auckland | SEW-EURODRIVE NEW ZEALAND LTD. P.O. Box 58-428 82 Greenmount drive East Tamaki Auckland | Tel. +64 9 2745627 Fax +64 9 2740165 http://www.sew-eurodrive.co.nz sales@sew-eurodrive.co.nz |
| | Christchurch | SEW-EURODRIVE NEW ZEALAND LTD. 30 Lodestar Avenue, Wigram Christchurch | Tel. +64 3 384-6251 Fax +64 3 384-6455 sales@sew-eurodrive.co.nz |
| Nigeria | | | |
| Sales | Lagos | Greenpeg Nig. Ltd Plot 296A, Adeyemo Akapo Str. Omole GRA Ikeja Lagos-Nigeria | Tel. +234-701-821-9200-1 http://www.greenpegltd.com bolaji.adekunle@greenpegltd.com |
| Norway | | | |
| Assembly Sales Service | Moss | SEW-EURODRIVE A/S Solgaard skog 71 1599 Moss | Tel. +47 69 24 10 20 Fax +47 69 24 10 40 http://www.sew-eurodrive.no sew@sew-eurodrive.no |
| Pakistan | | | |
| Sales | Karachi | Industrial Power Drives Al-Fatah Chamber A/3, 1st Floor Central Com- mercial Area, Sultan Ahmed Shah Road, Block 7/8, Karachi | Tel. +92 21 452 9369 Fax +92-21-454 7365 seweurodrive@cyber.net.pk |
| Paraguay | | | |
| Sales | Fernando de la Mora | SEW-EURODRIVE PARAGUAY S.R.L De la Victoria 112, Esquina nueva Asunción Departamento Central Fernando de la Mora, Barrio Bernardino | Tel. +595 991 519695 Fax +595 21 3285539 sewpy@sew-eurodrive.com.py |
| Peru | | | |
| Assembly Sales Service | Lima | SEW EURODRIVE DEL PERU S.A.C. Los Calderos, 120-124 Urbanizacion Industrial Vulcano, ATE, Lima | Tel. +51 1 3495280 Fax +51 1 3493002 http://www.sew-eurodrive.com.pe sewperu@sew-eurodrive.com.pe |
| Philippines | | | |
| Sales | Makati | P.T. Cerna Corporation 4137 Ponte St., Brgy. Sta. Cruz Makati City 1205 | Tel. +63 2 519 6214 Fax +63 2 890 2802 mech_drive_sys@ptcerna.com http://www.ptcerna.com |
| Poland | | | |
| Assembly Sales Service | Łódź | SEW-EURODRIVE Polska Sp.z.o.o. ul. Techniczna 5 92-518 Łódź | Tel. +48 42 293 00 00 Fax +48 42 293 00 49 http://www.sew-eurodrive.pl sew@sew-eurodrive.pl |
| | Service | Tel. +48 42 293 0030 Fax +48 42 293 0043 | 24 Hour Service Tel. +48 602 739 739 (+48 602 SEW SEW) serwis@sew-eurodrive.pl |
| Portugal | | | |
| Assembly Sales Service | Coimbra | SEW-EURODRIVE, LDA. Av. da Fonte Nova, n.º 86 3050-379 Mealhada | Tel. +351 231 20 9670 Fax +351 231 20 3685 http://www.sew-eurodrive.pt infosew@sew-eurodrive.pt |
| Romania | | | |
| Sales Service | Bucharest | Sialco Trading SRL str. Brazilia nr. 36 011783 Bucuresti | Tel. +40 21 230-1328 Fax +40 21 230-7170 sialco@sialco.ro |
| Russia | | | |
| Assembly Sales Service | St. Petersburg | ЗАО «СЕВ-ЕВРОДРАЙФ» а. я. 36 195220 Санкт-Петербург | Tel. +7 812 3332522 / +7 812 5357142 Fax +7 812 3332523 http://www.sew-eurodrive.ru sew@sew-eurodrive.ru |

Sambia

representation: South Africa

Senegal

| | | | |
|-------|-------|---|--|
| Sales | Dakar | SENEMECA Mécanique Générale Km 8, Route de Rufisque B.P. 3251, Dakar | Tel. +221 338 494 770 Fax +221 338 494 771 http://www.senemeca.com senemeca@senemeca.sn |
|-------|-------|---|--|

Serbia

| | | | |
|-------|----------|---|--|
| Sales | Belgrade | DIPAR d.o.o. Ustanicka 128a PC Košum, IV floor 11000 Beograd | Tel. +381 11 347 3244 / +381 11 288 0393 Fax +381 11 347 1337 office@dipar.rs |
|-------|----------|---|--|

Singapore

| | | | |
|------------------------------|-----------|---|--|
| Assembly Sales Service | Singapore | SEW-EURODRIVE PTE. LTD. No 9, Tuas Drive 2 Jurong Industrial Estate Singapore 638644 | Tel. +65 68621701 Fax +65 68612827 http://www.sew-eurodrive.com.sg sewsingapore@sew-eurodrive.com |
|------------------------------|-----------|---|--|

Slovakia

| | | | |
|-------|------------|--|--|
| Sales | Bratislava | SEW-Eurodrive SK s.r.o. Rybničná 40 831 06 Bratislava | Tel. +421 2 33595 202, 217, 201 Fax +421 2 33595 200 http://www.sew-eurodrive.sk sew@sew-eurodrive.sk |
| | Košice | SEW-Eurodrive SK s.r.o. Slovenská ulica 26 040 01 Košice | Tel. +421 55 671 2245 Fax +421 55 671 2254 Mobile +421 907 671 976 sew@sew-eurodrive.sk |

Slovenia

| | | | |
|------------------|-------|--|---|
| Sales Service | Celje | Pakman - Pogonska Tehnika d.o.o. Ul. XIV. divizije 14 3000 Celje | Tel. +386 3 490 83-20 Fax +386 3 490 83-21 pakman@siol.net |
|------------------|-------|--|---|

South Africa

| | | | |
|------------------------------|--------------|---|--|
| Assembly Sales Service | Johannesburg | SEW-EURODRIVE (PROPRIETARY) LIMITED Eurodrive House Cnr. Adcock Ingram and Aerodrome Roads Aeroton Ext. 2 Johannesburg 2013 P.O.Box 90004 Bertsham 2013 | Tel. +27 11 248-7000 Fax +27 11 248-7289 http://www.sew.co.za info@sew.co.za |
| | Cape Town | SEW-EURODRIVE (PROPRIETARY) LIMITED Rainbow Park Cnr. Racecourse & Omuramba Road Montague Gardens Cape Town P.O.Box 36556 Chempet 7442 | Tel. +27 21 552-9820 Fax +27 21 552-9830 Telex 576 062 bgriffiths@sew.co.za |
| | Durban | SEW-EURODRIVE (PROPRIETARY) LIMITED 48 Prospect Road Isipingo Durban P.O. Box 10433, Ashwood 3605 | Tel. +27 31 902 3815 Fax +27 31 902 3826 cdejager@sew.co.za |
| | Nelspruit | SEW-EURODRIVE (PROPRIETARY) LIMITED 7 Christie Crescent Vintonia P.O.Box 1942 Nelspruit 1200 | Tel. +27 13 752-8007 Fax +27 13 752-8008 robermeyer@sew.co.za |

South Korea

| | | | |
|------------------------------|-------|--|--|
| Assembly Sales Service | Ansan | SEW-EURODRIVE KOREA CO., LTD. 7, Dangjaengi-ro, Danwon-gu, Ansan-si, Gyeonggi-do, Zip 425-839 | Tel. +82 31 492-8051 Fax +82 31 492-8056 http://www.sew-eurodrive.kr master.korea@sew-eurodrive.com |
|------------------------------|-------|--|--|

| South Korea | | | |
|------------------------------|---------------|--|---|
| | Busan | SEW-EURODRIVE KOREA CO., LTD. 28, Noksansandan 262-ro 50beon-gil, Gangseo-gu, Busan, Zip 618-820 | Tel. +82 51 832-0204 Fax +82 51 832-0230 |
| Spain | | | |
| Assembly Sales Service | Bilbao | SEW-EURODRIVE ESPAÑA, S.L. Parque Tecnológico, Edificio, 302 48170 Zamudio (Vizcaya) | Tel. +34 94 43184-70 http://www.sew-eurodrive.es sew.spain@sew-eurodrive.es |
| Sri Lanka | | | |
| Sales | Colombo | SM International (Pte) Ltd 254, Galle Raod Colombo 4, Sri Lanka | Tel. +94 1 2584887 Fax +94 1 2582981 |
| Swaziland | | | |
| Sales | Manzini | C G Trading Co. (Pty) Ltd PO Box 2960 Manzini M200 | Tel. +268 2 518 6343 Fax +268 2 518 5033 engineering@cgtrading.co.sz |
| Sweden | | | |
| Assembly Sales Service | Jönköping | SEW-EURODRIVE AB Gnejsvägen 6-8 553 03 Jönköping Box 3100 S-550 03 Jönköping | Tel. +46 36 34 42 00 Fax +46 36 34 42 80 http://www.sew-eurodrive.se jonkoping@sew.se |
| Switzerland | | | |
| Assembly Sales Service | Basel | Alfred Imhof A.G. Jurastrasse 10 4142 Münchenstein bei Basel | Tel. +41 61 417 1717 Fax +41 61 417 1700 http://www.imhof-sew.ch info@imhof-sew.ch |
| Taiwan | | | |
| Sales | Taipei | Ting Shou Trading Co., Ltd. 6F-3, No. 267, Sec. 2 Tung Huw S. Road Taipei | Tel. +886 2 27383535 Fax +886 2 27368268 Telex 27 245 sewtwn@ms63.hinet.net http://www.tingshou.com.tw |
| | Nan Tou | Ting Shou Trading Co., Ltd. No. 55 Kung Yeh N. Road Industrial District Nan Tou 540 | Tel. +886 49 255353 Fax +886 49 257878 sewtwn@ms63.hinet.net http://www.tingshou.com.tw |
| Tanzania | | | |
| Sales | Daressalam | SEW-EURODRIVE PTY LIMITED TANZANIA Plot 52, Regent Estate PO Box 106274 Dar Es Salaam | Tel. +255 0 22 277 5780 Fax +255 0 22 277 5788 http://www.sew-eurodrive.co.tz info@sew.co.tz |
| Thailand | | | |
| Assembly Sales Service | Chonburi | SEW-EURODRIVE (Thailand) Ltd. 700/456, Moo.7, Donhuaroh Muang Chonburi 20000 | Tel. +66 38 454281 Fax +66 38 454288 sewthailand@sew-eurodrive.com |
| Tunisia | | | |
| Sales | Tunis | T. M.S. Technic Marketing Service Zone Industrielle Mghira 2 Lot No. 39 2082 Fouchana | Tel. +216 79 40 88 77 Fax +216 79 40 88 66 http://www.tms.com.tn tms@tms.com.tn |
| Turkey | | | |
| Assembly Sales Service | Kocaeli-Gebze | SEW-EURODRIVE Hareket Sistemleri San. Ve TIC. Ltd. Sti Gebze Organize Sanayi Böl. 400 Sok No. 401 41480 Gebze Kocaeli | Tel. +90 262 9991000 04 Fax +90 262 9991009 http://www.sew-eurodrive.com.tr sew@sew-eurodrive.com.tr |

United Arab Emirates

| | | | |
|------------------|-------|--|--|
| Sales Service | Dubai | SEW-EURODRIVE FZE PO Box 263835 Office No. S3A1SR03 Jebel Ali Free Zone – South, Dubai, United Arab Emirates | Tel. +971 (0)4 8806461 Fax +971 (0)4 8806464 http://www.sew-eurodrive.ae info@sew-eurodrive.ae |
|------------------|-------|--|--|

Ukraine

| | | | |
|------------------------------|----------------|---|--|
| Assembly Sales Service | Dnipropetrovsk | ООО «СЕВ-Евродрайв» ул. Рабочая, 23-В, офис 409 49008 Днепр | Tel. +380 56 370 3211 Fax +380 56 372 2078 http://www.sew-eurodrive.ua sew@sew-eurodrive.ua |
|------------------------------|----------------|---|--|

Uruguay

| | | | |
|-------------------|------------|--|---|
| Assembly Sales | Montevideo | SEW-EURODRIVE Uruguay, S. A. Jose Serrato 3569 Esquina Corumbe CP 12000 Montevideo | Tel. +598 2 21181-89 Fax +598 2 21181-90 sewuy@sew-eurodrive.com.uy |
|-------------------|------------|--|---|

USA

| | | | |
|--|---------------------|--|---|
| Production Assembly Sales Service | Southeast Region | SEW-EURODRIVE INC. 1295 Old Spartanburg Highway P.O. Box 518 Lyman, S.C. 29365 | Tel. +1 864 439-7537 Fax Sales +1 864 439-7830 Fax Production +1 864 439-9948 Fax Assembly +1 864 439-0566 Fax Confidential/HR +1 864 949-5557 http://www.seweurodrive.com cslyman@seweurodrive.com |
| Assembly Sales Service | Northeast Region | SEW-EURODRIVE INC. Pureland Ind. Complex 2107 High Hill Road, P.O. Box 481 Bridgeport, New Jersey 08014 | Tel. +1 856 467-2277 Fax +1 856 845-3179 csbridgeport@seweurodrive.com |
| | Midwest Region | SEW-EURODRIVE INC. 2001 West Main Street Troy, Ohio 45373 | Tel. +1 937 335-0036 Fax +1 937 332-0038 cstroy@seweurodrive.com |
| | Southwest Region | SEW-EURODRIVE INC. 3950 Platinum Way Dallas, Texas 75237 | Tel. +1 214 330-4824 Fax +1 214 330-4724 csdallas@seweurodrive.com |
| | Western Region | SEW-EURODRIVE INC. 30599 San Antonio St. Hayward, CA 94544 | Tel. +1 510 487-3560 Fax +1 510 487-6433 cshayward@seweurodrive.com |
| | Wellford | SEW-EURODRIVE INC. 148/150 Finch Rd. Wellford, S.C. 29385 | Tel. +1 864 439-7537 Fax +1 864 661 1167 IGOrders@seweurodrive.com |

Additional addresses for service provided on request!

Vietnam

| | | | |
|-------|---------------------|---|--|
| Sales | Ho Chi Minh City | Nam Trung Co., Ltd Huế - South Vietnam / Construction Materials 250 Binh Duong Avenue, Thu Dau Mot Town, Binh Duong Province HCM office: 91 Tran Minh Quyen Street District 10, Ho Chi Minh City | Tel. +84 8 8301026 Fax +84 8 8392223 khanh-nguyen@namtrung.com.vn http://www.namtrung.com.vn |
| | Hanoi | MICO LTD Quảng Trị - North Vietnam / All sectors except Construction Materials 8th Floor, Ocean Park Building, 01 Dao Duy Anh St, Ha Noi, Viet Nam | Tel. +84 4 39386666 Fax +84 4 3938 6888 nam_ph@micogroup.com.vn http://www.micogroup.com.vn |

Index

A

| | |
|---|----|
| AD input shaft assembly..... | 84 |
| Adapter | |
| AM | 74 |
| AQ | 78 |
| Adjustment in mounting position | 34 |
| Agitator | |
| Maintenance intervals | 89 |
| Relubrication | 88 |
| Agitator drive | |
| Strength class of the screws | 35 |
| AM adapter | |
| Foot-mounted motor..... | 78 |
| Mounting of third-party motors | 78 |
| Permitted load | 78 |
| Ambient conditions | 40 |
| AQ. adapter | |
| Permitted loads | 80 |
| Setting standards and tightening torques..... | 80 |
| AQ. adapter coupling..... | 78 |
| Assembly | |
| Safety notes | 12 |

B

| | |
|-------------------------|---------|
| Backstop..... | 99 |
| Bearing greases | 176 |
| Breather valve | 34, 138 |
| Compound gear unit..... | 140 |

C

| | |
|--------------------------------------|----------|
| Change in mounting position | 34 |
| Changing oil | 118 |
| Changing the mounting position | 138, 176 |
| Checking the oil level | 96, 118 |
| At the breather plug..... | 133 |
| At the oil level plug | 130 |
| At the oil level plug | 132, 134 |
| Via the breather plug | 127 |
| Via the cover plate..... | 123 |
| Checklists | 94 |
| Churning losses..... | 137 |
| Compound gear unit | |
| Breather valve | 140 |

| | |
|-----------------------------|-----|
| Oil drain plug | 140 |
| Oil level plug | 140 |
| Screw plug bore | 140 |
| Copyright notice | 8 |
| Coupling of AM adapter..... | 74 |
| Cover, installation | 73 |
| Customer service | 192 |

D

| | |
|----------------------|----|
| Designated use | 10 |
|----------------------|----|

E

| | |
|----------------------------|---------|
| Efficiency | 98, 137 |
| Elastomers | 40 |
| Embedded safety notes..... | 7 |
| Extended storage | 174 |

F

| | |
|---------------------------|----------|
| Failure | |
| Running noise | 190, 191 |
| Features | 88 |
| Flatness defect | 34 |
| Fluorocarbon rubber | 40 |

G

| | |
|--|--------|
| Gaskets | 96 |
| Gear head unit..... | 29 |
| Gear unit | |
| Cleaning | 135 |
| Explosion-proof design II2GD | 30 |
| Explosion-proof design II3GD | 30 |
| Installing | 33 |
| Version with solid shaft..... | 43 |
| Gear unit installation..... | 38 |
| Gear unit mounting | |
| Strength class..... | 35 |
| Gear unit structure..... | 13 |
| Helical gear units | 13 |
| Helical-bevel gear units K..7..... | 18 |
| Helical-bevel gear units K..9..... | 15, 17 |
| Helical-worm gear units | 19 |
| Parallel-shaft helical gear units | 14 |
| SPIROPLAN® gear units W..10 – W..30..... | 20 |
| SPIROPLAN® gear units W..37 – W..47..... | 21 |
| Gear unit venting | 40 |

| | |
|------------------------|-----|
| Gear units | |
| Extended storage | 174 |
| Grease filling | 176 |

H

| | |
|-------------------------------------|--------|
| Helical gear units | 13 |
| Type designation | 25 |
| Helical gearmotors | |
| Mounting positions | 141 |
| Helical-bevel gear units | 15, 17 |
| Type designation | 26 |
| Helical-bevel gear units K..7 | 18 |
| Helical-bevel gearmotors | |
| Mounting positions | 149 |
| Helical-worm gear units | 19 |
| Type designation | 27 |
| Helical-worm gearmotors | |
| Mounting positions | 162 |

I

| | |
|---------------------------------|-----|
| Incremental encoder | |
| Installation | 105 |
| Input and output elements | |
| High overhung loads | 44 |
| Mounting | 43 |
| Using a mounting device | 44 |
| Inspection | 107 |
| Inspection intervals | |
| Gear unit | 111 |
| Inspection work | |
| AD Input shaft assembly | 117 |
| Adapter AL/AM/AQ | 112 |
| AR adapter | 113 |
| Changing oil | 118 |
| Checking the oil level | 118 |
| Gear unit | 118 |
| Oil check | 118 |
| Installation | |
| Couplings | 45 |
| Input and output elements | 43 |
| Mechanical | 29 |
| Installation tolerances | 32 |

L

| | |
|---------------|----|
| Leakage | 96 |
|---------------|----|

| | |
|------------------------------------|-----|
| Lubricant | |
| Compatibility with oil seal | 178 |
| Determining change intervals | 112 |
| Lubricant table | 176 |
| Lubricant change intervals | 112 |
| Lubricant table | |
| Notes | 176 |
| Lubricants | 176 |

M

| | |
|---|-----|
| Maintenance | 107 |
| Agitator | 88 |
| Maintenance intervals | |
| Gear unit | 111 |
| Maintenance work | |
| Adapter AL/AM/AQ | 112 |
| Changing oil | 118 |
| Checking the oil level | 118 |
| Oil check | 118 |
| Maintenance works | |
| AD Input shaft assembly | 117 |
| AR adapter | 113 |
| Gear unit | 118 |
| Malfunctions | 189 |
| AD Input shaft assembly | 191 |
| AM/AQ./AL adapters | 191 |
| Gear unit | 190 |
| Mechanical installation | 29 |
| Mounting position | |
| Mounting position M0 | 138 |
| Mounting position MX | 138 |
| Mounting position sheets | 136 |
| Mounting position sheets, key | 139 |
| Mounting positions | 136 |
| Designation | 136 |
| Helical gearmotors | 141 |
| Helical-bevel gearmotors | 149 |
| Helical-worm gearmotors | 162 |
| Parallel-shaft helical gearmotors | 146 |
| SPIROPLAN® gearmotors | 168 |
| Mounting shaft-mounted gear units with keyway | 52 |
| Mounting shaft-mounted gear units with splined hollow shaft | 51 |

N

| | |
|-----------------|--------|
| Nameplate | 22, 23 |
|-----------------|--------|

Notes

Designation in the documentation 6

O

Oil check..... 118

Oil drain plug

Compound gear unit..... 140

Oil drain valve..... 88

Oil expansion tank..... 88

Oil level plug

Compound gear unit..... 140

Oil seal

Lubricant compatibility..... 178

Oil sight glass 96

Oil temperature..... 97

Optional equipment 88

Options 88

Type designation 28

P

Parallel-shaft helical gear units 14

Type designation 25

Parallel-shaft helical gearmotors

Mounting positions 146

Product names 7

Protective cover, installation..... 73

Pseudo-leakage 96

PT100..... 90

PT100 temperature sensor

Dimensions..... 91

Electrical connection 91

R

Repair..... 189, 192

Resources 32

Rights to claim under limited warranty 7

Run-in period..... 98

S

Safety notes

Assembly..... 12

Designation in the documentation 6

Preliminary information..... 9

Setup 12

Structure of embedded..... 7

Structure of the section-related 6

Screw plug bore

Compound gear unit..... 140

Section-related safety notes 6

Service 192

Shaft-mounted gear unit..... 45

TorqLOC® 60

Shaft-mounted gear units

Keyway..... 52

Shrink disk..... 57

Splined hollow shaft 52

Signal words in safety notes..... 6

Solid shaft..... 43

Speed monitor, WEX 101

SPIROPLAN® gear unit

Mounting position M0 138

SPIROPLAN® gear units

Type designation 27

SPIROPLAN® gear units W..10 – W..30..... 20

SPIROPLAN® gear units W..37 – W..47 21

SPIROPLAN® gearmotors

Mounting positions 168

Storage conditions..... 174

Strength class

Gear unit mounting..... 35

Structure

Helical gear units..... 13

Helical-bevel gear units K..7 18

Helical-bevel gear units K..9..... 15, 17

Helical-worm gear units..... 19

Parallel-shaft helical gear units 14

SPIROPLAN® gear units W..10 – W..30..... 20

SPIROPLAN® gear units W..37 – W..47..... 21

Surface protection 174

Surface temperature..... 97

T

Target group..... 9

Technical data 174

Test list 94

Thermal rating 137

Tightening torques..... 36

Tools..... 32

TorqLOC® 60



Torque arms 45

Torque arms for shaft-mounted gear units 45

Helical-worm gear units..... 49

| | | | |
|---|--------|-------------------------------|---------|
| K..37 – K..157 helical-bevel gear units | 48 | Using a mounting device | 44 |
| Parallel-shaft helical gear units | 46 | V | |
| SPIROPLAN® W gear units | 50 | Ventilation | 40 |
| Trademarks | 7 | Venting | 40 |
| Type designation | 22, 25 | Voltage encoder | 105 |
| Helical gear units | 25 | W | |
| Helical-bevel gear units | 26 | Waste disposal | 192 |
| Helical-worm gear units | 27 | WEX speed monitor | 82, 101 |
| Options | 28 | WEX, speed monitor | 82 |
| Parallel-shaft helical gear units | 25 | X | |
| SPIROPLAN® gear units | 27 | X identification | 23 |
| U | | | |
| Universal mounting position M0 | 138 | | |







SEW-EURODRIVE
Driving the world

SEW
EURODRIVE

SEW-EURODRIVE GmbH & Co KG
Ernst-Blickle-Str. 42
76646 BRUCHSAL
GERMANY
Tel. +49 7251 75-0
Fax +49 7251 75-1970
sew@sew-eurodrive.com
→ www.sew-eurodrive.com