




Operating Instructions



Application Inverter
MOVIDRIVE® modular



Table of contents

| | | |
|----------|---|-----------|
| 1 | General information..... | 10 |
| 1.1 | About this documentation | 10 |
| 1.2 | Structure of the safety notes | 10 |
| 1.2.1 | Meaning of signal words | 10 |
| 1.2.2 | Structure of section-related safety notes..... | 11 |
| 1.2.3 | Structure of embedded safety notes | 11 |
| 1.3 | Decimal separator in numerical values | 11 |
| 1.4 | Rights to claim under limited warranty | 12 |
| 1.5 | Content of the documentation | 12 |
| 1.6 | Other applicable documentation | 12 |
| 1.7 | Product names and trademarks | 12 |
| 1.7.1 | Trademark of Beckhoff Automation GmbH | 12 |
| 1.8 | Copyright notice | 12 |
| 2 | Safety notes | 13 |
| 2.1 | Preliminary information | 13 |
| 2.2 | Duties of the user..... | 13 |
| 2.3 | Target group | 14 |
| 2.4 | Designated use | 14 |
| 2.4.1 | Hoist applications | 15 |
| 2.4.2 | Restrictions under the European WEEE Directive 2012/19/EU | 15 |
| 2.5 | Functional safety technology | 16 |
| 2.6 | Transport..... | 16 |
| 2.7 | Installation/assembly..... | 16 |
| 2.7.1 | Restrictions of use..... | 16 |
| 2.8 | Electrical installation | 17 |
| 2.8.1 | Required preventive measure | 17 |
| 2.8.2 | Stationary application..... | 17 |
| 2.8.3 | Regenerative operation | 17 |
| 2.9 | Protective separation | 17 |
| 2.10 | Startup/operation | 18 |
| 2.10.1 | Energy storage unit | 18 |
| 3 | Device structure, axis system structure | 19 |
| 3.1 | Connection variants | 19 |
| 3.1.1 | Axis system with MOVI-C® CONTROLLER power/power eco | 20 |
| 3.1.2 | Axis system with master module UHX45A/MDM90A | 22 |
| 3.1.3 | Axis system with MOVI-C® CONTROLLER advanced | 24 |
| 3.1.4 | Axis system with MOVI-C® CONTROLLER standard..... | 26 |
| 3.2 | MOVIDRIVE® modular nameplates | 28 |
| 3.2.1 | Power supply module..... | 28 |
| 3.2.2 | Single-axis module..... | 29 |
| 3.2.3 | Double-axis module | 30 |
| 3.3 | MOVIDRIVE® modular type code | 31 |
| 3.4 | Device structure of the MDP power supply module | 32 |
| 3.4.1 | MDP90A-0100-.. (size 1)..... | 32 |

| | | |
|----------|---|-----------|
| 3.4.2 | MDP90A-0100-.. with integrated braking resistance (size 1A)..... | 33 |
| 3.4.3 | MDP90A-0250-.. (size 2)..... | 34 |
| 3.4.4 | MDP90A-0500, 0750-.. (size 3)..... | 35 |
| 3.4.5 | MDP90A-1100-.. (size 4)..... | 36 |
| 3.5 | Device structure of the MDA and MDD axis modules..... | 37 |
| 3.5.1 | MDA90A-0020, 0040, 0080, 0120 (size 1) – Single-axis module | 38 |
| 3.5.2 | MDA90A-0160, 0240 (size 2) – Single-axis module | 39 |
| 3.5.3 | MDA90A-0320, 0480 (size 3) – Single-axis module | 40 |
| 3.5.4 | MDA90A-0640 (size 4) – Single-axis module | 41 |
| 3.5.5 | MDA90A-0640, 1000 (size 5) – Single-axis module | 42 |
| 3.5.6 | MDA90A-1400, 1800 (size 6) – Single-axis module | 43 |
| 3.5.7 | MDD9.A-0020, 0040 (size 1) – Double-axis module..... | 44 |
| 3.5.8 | MDD9.A-0020, 0040, 0080 (size 2) – Double-axis module..... | 45 |
| 3.6 | MDC capacitor module | 47 |
| 3.6.1 | MDC90A-0001/0002-50X-X-000 | 47 |
| 3.7 | Device structure of master module UHX45A/MDM90A | 48 |
| 3.8 | Example for axis system connection without master module | 49 |
| 3.9 | Example for axis system connection with master module | 50 |
| 3.10 | Card slots..... | 51 |
| 3.10.1 | Single-axis modules | 51 |
| 3.10.2 | Double-axis modules..... | 52 |
| 4 | Installation..... | 53 |
| 4.1 | Installation accessories..... | 53 |
| 4.1.1 | Standard accessories..... | 53 |
| 4.1.2 | Available accessories..... | 56 |
| 4.2 | Permitted tightening torques | 57 |
| 4.3 | Special aspects when transporting the devices | 58 |
| 4.4 | Mechanical installation..... | 59 |
| 4.4.1 | Hole pattern..... | 59 |
| 4.4.2 | Minimum clearance and mounting position | 61 |
| 4.5 | Covers..... | 62 |
| 4.5.1 | Covers | 62 |
| 4.5.2 | Touch guards | 64 |
| 4.5.3 | Power connection closing cover..... | 66 |
| 4.5.4 | Closing cover between MDA90A-1400 – 1800-.. and MDA90A-0020 – 0240-.. 67 | |
| 4.5.5 | Front cover | 68 |
| 4.5.6 | Protection caps | 69 |
| 4.6 | Control cabinet installation..... | 71 |
| 4.6.1 | Arrangement of the axis modules within the axis system | 71 |
| 4.6.2 | Installing a module | 72 |
| 4.6.3 | Installing shield plates | 73 |
| 4.6.4 | Removing the covers | 75 |
| 4.6.5 | Removing the touch guards | 76 |
| 4.6.6 | Installing the busbar | 77 |
| 4.6.7 | Installing touch guards | 78 |

| | | |
|---------|---|-----|
| 4.6.8 | Installing front covers and covers | 80 |
| 4.6.9 | Removing an axis module | 80 |
| 4.6.10 | Installation/removal of the UHX45A | 81 |
| 4.7 | Electrical installation | 82 |
| 4.7.1 | General information | 84 |
| 4.7.2 | Permitted voltage systems | 84 |
| 4.7.3 | Use in IT systems | 84 |
| 4.7.4 | Line fuses, fuse types | 85 |
| 4.7.5 | Line connection | 86 |
| 4.7.6 | Power connections | 87 |
| 4.7.7 | 24 V supply voltage | 89 |
| 4.7.8 | Connection of an axis system | 92 |
| 4.7.9 | Connecting a safe brake module to the DC link | 96 |
| 4.7.10 | Two-row design | 98 |
| 4.7.11 | Installing touch guards and closing covers | 108 |
| 4.7.12 | Motor output | 110 |
| 4.7.13 | Output brake chopper | 110 |
| 4.7.14 | Temperature evaluation of the motor | 110 |
| 4.7.15 | Brake output | 110 |
| 4.7.16 | Inputs/outputs | 111 |
| 4.7.17 | System bus EtherCAT®/SBus ^{PLUS} | 112 |
| 4.7.18 | Encoder | 114 |
| 4.7.19 | Notes on MOVILINK® DDI | 116 |
| 4.7.20 | Self-assembled encoder cables | 117 |
| 4.8 | Installing options and accessories | 118 |
| 4.8.1 | Installing a card | 118 |
| 4.8.2 | CIO21A and CID21A input/output card | 121 |
| 4.8.3 | CES11A multi-encoder card | 124 |
| 4.8.4 | Safety cards CS..A | 128 |
| 4.9 | Braking resistors | 129 |
| 4.9.1 | Permitted installation of braking resistors | 130 |
| 4.9.2 | Thermal protection with flat-type resistors | 131 |
| 4.9.3 | Protection against thermal overload of the braking resistor | 132 |
| 4.10 | Line choke | 142 |
| 4.11 | Line filter | 142 |
| 4.12 | EMC-compliant installation | 143 |
| 4.12.1 | Control cabinet | 144 |
| 4.12.2 | HF equipotential bonding in the system | 144 |
| 4.12.3 | Cable installation | 144 |
| 4.12.4 | Supply system cable connection | 144 |
| 4.12.5 | Line filter connection | 145 |
| 4.12.6 | Braking resistor connection | 145 |
| 4.12.7 | Motor and brake connection | 146 |
| 4.12.8 | Control cable connection | 146 |
| 4.12.9 | Encoder connection | 146 |
| 4.12.10 | Shielding connection | 147 |

| | | |
|----------|--|------------|
| 4.13 | Terminal assignment..... | 148 |
| 4.13.1 | Terminal assignment at MDP power supply module..... | 149 |
| 4.13.2 | Terminal assignment at MDA single-axis module..... | 151 |
| 4.13.3 | Terminal assignment at MDD double-axis module..... | 155 |
| 4.13.4 | Terminal assignment of MDC90A-0001/0002-.. capacitor module..... | 159 |
| 4.13.5 | Terminal assignment at master module UHX45A/MDM90A..... | 160 |
| 4.14 | Wiring diagrams..... | 161 |
| 4.14.1 | General information on the wiring diagrams..... | 161 |
| 4.14.2 | Power connection..... | 161 |
| 4.14.3 | Brake control..... | 166 |
| 4.14.4 | Electronics connection MDP90A.. power supply module..... | 171 |
| 4.14.5 | Electronics connection MDA90A.. single-axis module..... | 172 |
| 4.14.6 | MDD9.A.. double-axis module electrical connection..... | 174 |
| 4.14.7 | Connection diagram CIO21A and CID21A input/output card..... | 176 |
| 4.15 | Information regarding UL..... | 180 |
| 4.15.1 | Field Wiring Power Terminals..... | 180 |
| 4.15.2 | Short Circuit Current Rating..... | 180 |
| 4.15.3 | Branch Circuit Protection..... | 181 |
| 4.15.4 | Motor Overload Protection..... | 181 |
| 4.15.5 | Ambient Temperature..... | 181 |
| 5 | Startup..... | 183 |
| 5.1 | General..... | 183 |
| 5.1.1 | Lifting applications..... | 183 |
| 5.1.2 | Connecting power..... | 183 |
| 5.1.3 | Connecting cables..... | 183 |
| 5.2 | Assigning the EtherCAT®/SBus ^{PLUS} address at the axis module..... | 184 |
| 5.3 | Startup requirements..... | 185 |
| 5.4 | Startup procedure..... | 186 |
| 5.4.1 | Check list for startup..... | 189 |
| 5.5 | Connection to the engineering software..... | 189 |
| 6 | Operation..... | 190 |
| 6.1 | General information..... | 190 |
| 6.2 | 7-segment display..... | 191 |
| 6.2.1 | Operating displays..... | 191 |
| 6.2.2 | Fault display..... | 191 |
| 6.3 | Operating displays..... | 192 |
| 6.3.1 | Operating states of the power supply module – 7-segment display..... | 192 |
| 6.3.2 | Operating displays of the power supply module – LED displays..... | 192 |
| 6.3.3 | Operating displays of the axis module – 7-segment display..... | 192 |
| 6.4 | Faults at the power supply module..... | 195 |
| 6.4.1 | Fault 49 Power supply module..... | 195 |
| 6.5 | Faults at the single-axis module/double-axis module..... | 199 |
| 6.5.1 | Fault 1 Output stage monitoring..... | 199 |
| 6.5.2 | Fault 3 Ground fault..... | 199 |
| 6.5.3 | Fault 4 Brake chopper..... | 199 |

| | | |
|--------|---|-----|
| 6.5.4 | Fault 6 Line fault..... | 199 |
| 6.5.5 | Fault 7 DC link..... | 200 |
| 6.5.6 | Fault 8 Speed monitoring | 200 |
| 6.5.7 | Fault 9 Control mode..... | 200 |
| 6.5.8 | Fault 10 Data Flexibility | 202 |
| 6.5.9 | Fault 11 Temperature monitoring | 203 |
| 6.5.10 | Fault 12 Brake | 204 |
| 6.5.11 | Error 13 encoder 1 fault | 204 |
| 6.5.12 | Fault 14 Encoder 2..... | 209 |
| 6.5.13 | Fault 16 Startup..... | 213 |
| 6.5.14 | Fault 17 Internal processor fault..... | 215 |
| 6.5.15 | Fault 18 Software error | 215 |
| 6.5.16 | Fault 19 Process data | 216 |
| 6.5.17 | Fault 20 Device monitoring | 217 |
| 6.5.18 | Fault 21 Digital motor integration 1 | 218 |
| 6.5.19 | Fault 22 Digital motor integration 2 | 219 |
| 6.5.20 | Fault 23 Power section..... | 220 |
| 6.5.21 | Error 24 Cam switch..... | 221 |
| 6.5.22 | Fault 25 Parameter memory monitoring..... | 221 |
| 6.5.23 | Fault 26 External fault | 224 |
| 6.5.24 | Fault 28 FCB drive functions..... | 224 |
| 6.5.25 | Fault 29 HW limit switches | 226 |
| 6.5.26 | Fault 30 Software limit switches..... | 226 |
| 6.5.27 | Fault 31 Thermal motor protection | 227 |
| 6.5.28 | Fault 32 Communication | 229 |
| 6.5.29 | Fault 33 System initialization..... | 230 |
| 6.5.30 | Fault 34 Process data configuration..... | 231 |
| 6.5.31 | Fault 35 Function activation | 231 |
| 6.5.32 | Fault 42 Lag error..... | 232 |
| 6.5.33 | Fault 46 Safety card | 233 |
| 6.5.34 | Fault 47 Supply unit | 233 |
| 6.5.35 | Fault 48 Module bus..... | 234 |
| 6.5.36 | Fault 50 I/O card | 234 |
| 6.5.37 | Fault 51 Analog processing..... | 235 |
| 6.5.38 | Fault 52 Explosion protection function category 2 | 235 |
| 6.6 | Fault at the master module UHX45A/MDM90A | 237 |
| 6.7 | Module bus faults..... | 238 |
| 6.7.1 | Grid condition | 238 |
| 6.7.2 | DC link condition | 238 |
| 6.7.3 | Line phase failure | 238 |
| 6.8 | Responses to fault acknowledgement | 239 |
| 6.8.1 | Fault acknowledgement at the power supply module | 239 |
| 6.8.2 | Fault acknowledgement at the axis modules | 239 |
| 6.9 | Fault responses | 241 |
| 6.9.1 | Default – fault response | 241 |
| 6.9.2 | Parameterizable faults | 241 |

| | | |
|----------|---|------------|
| 7 | Service | 244 |
| 7.1 | Electronics Service by SEW-EURODRIVE | 244 |
| 7.2 | Extended storage | 244 |
| 7.2.1 | Procedure in case maintenance has been neglected | 245 |
| 7.3 | Shutdown | 245 |
| 7.3.1 | Using energy storage units | 245 |
| 7.4 | Waste disposal | 246 |
| 8 | Technical data | 247 |
| 8.1 | Markings | 247 |
| 8.1.1 | Basic device | 247 |
| 8.1.2 | Accessories | 248 |
| 8.2 | General technical data | 250 |
| 8.3 | Technical data of MDP power supply modules | 251 |
| 8.3.1 | Performance data | 251 |
| 8.3.2 | Electronics data – signal terminals | 252 |
| 8.4 | Technical data of MDA and MDD axis modules | 253 |
| 8.4.1 | MDA performance data | 253 |
| 8.4.2 | MDD performance data | 255 |
| 8.4.3 | Electronics data – Signal terminals | 256 |
| 8.4.4 | Electronics data – Drive safety functions | 257 |
| 8.4.5 | Different functionality of the axis modules MDA/MDD | 258 |
| 8.5 | Technical data of the MDC90A-0001/0002-.. capacitor modules | 259 |
| 8.5.1 | Performance data | 259 |
| 8.6 | Technical data of the master module UHX45A/MDM90A | 260 |
| 8.7 | Dimension sheets of the modules | 261 |
| 8.7.1 | Dimension sheets of the power supply modules | 261 |
| 8.7.2 | Dimension sheets of the axis modules | 267 |
| 8.7.3 | Dimension sheet of the capacitor modules | 275 |
| 8.7.4 | Dimension sheet of the master module | 276 |
| 8.8 | Technical data of the cards | 277 |
| 8.8.1 | CIO21A and CID21A input/output cards | 277 |
| 8.8.2 | CES11A multi-encoder card | 279 |
| 8.8.3 | Safety cards CS..A | 280 |
| 8.9 | Technical data of encoder interfaces | 282 |
| 8.9.1 | Basic device | 282 |
| 8.9.2 | CES11A multi-encoder card | 282 |
| 8.10 | Technical data of braking resistors, filters and chokes | 283 |
| 8.10.1 | Braking resistors type BW.../BW...-T | 283 |
| 8.10.2 | TCB thermal circuit breaker option | 290 |
| 8.10.3 | Line filter | 292 |
| 8.10.4 | Line choke | 294 |
| 9 | Functional safety | 296 |
| 9.1 | General information | 296 |
| 9.1.1 | Underlying standards | 296 |
| 9.2 | Integrated safety technology | 296 |

| | | |
|-----------|--|------------|
| 9.2.1 | Safe condition | 296 |
| 9.2.2 | Safety concept | 296 |
| 9.2.3 | Schematic representation of the safety concept | 297 |
| 9.2.4 | Drive safety functions | 297 |
| 9.2.5 | Restrictions | 299 |
| 9.3 | Safety conditions | 299 |
| 9.3.1 | Approved devices | 300 |
| 9.3.2 | Requirements for the installation | 300 |
| 9.3.3 | Requirements for external safety controllers | 301 |
| 9.3.4 | Requirements for startup | 302 |
| 9.3.5 | Requirements for operation | 303 |
| 9.4 | Connection designs | 304 |
| 9.4.1 | General information | 304 |
| 9.4.2 | Requirements | 304 |
| 9.4.3 | Wiring diagrams | 306 |
| 9.4.4 | Port X6 on the device | 307 |
| 9.5 | Safety characteristics | 308 |
| 10 | Appendix | 310 |
| 10.1 | Abbreviation key | 310 |
| | Index | 312 |
| 11 | Address list | 317 |

1 General information

1.1 About this documentation

The documentation at hand is the original.

This documentation is an integral part of the product. The documentation is intended for all employees who perform work on the product.

Make sure this documentation is accessible and legible. Ensure that persons responsible for the systems and their operation as well as persons who work on the product independently have read through the documentation carefully and understood it. If you are unclear about any of the information in this documentation or if you require further information, contact SEW-EURODRIVE.

1.2 Structure of the safety notes

1.2.1 Meaning of signal words

The following table shows the grading and meaning of the signal words for safety notes.

| Signal word | Meaning | Consequences if disregarded |
|--------------------|--|--|
| ▲ DANGER | Imminent hazard | Severe or fatal injuries |
| ▲ WARNING | Possible dangerous situation | Severe or fatal injuries |
| ▲ CAUTION | Possible dangerous situation | Minor injuries |
| NOTICE | Possible damage to property | Damage to the product or its environment |
| INFORMATION | Useful information or tip: Simplifies handling of the product. | |

1.2.2 Structure of section-related safety notes

Section-related safety notes do not apply to a specific action but to several actions pertaining to one subject. The hazard symbols used either indicate a general hazard or a specific hazard.

This is the formal structure of a safety note for a specific section:



SIGNAL WORD

Type and source of hazard.

Possible consequence(s) if disregarded.

- Measure(s) to prevent the hazard.

Meaning of the hazard symbols

The hazard symbols in the safety notes have the following meaning:

| Hazard symbol | Meaning |
|---------------|---|
| | General hazard |
| | Warning of dangerous electrical voltage |
| | Warning of hot surfaces |
| | Warning about suspended load |
| | Warning of automatic restart |

1.2.3 Structure of embedded safety notes

Embedded safety notes are directly integrated into the instructions just before the description of the dangerous action.

This is the formal structure of an embedded safety note:

⚠ SIGNAL WORD! Type and source of hazard. Possible consequence(s) if disregarded. Measure(s) to prevent the hazard.

1.3 Decimal separator in numerical values

In this document, a period is used to indicate the decimal separator.

Example: 30.5 kg

1.4 Rights to claim under limited warranty

Read the information in this documentation. This is essential for fault-free operation and fulfillment of any rights to claim under limited warranty. Read the documentation before you start working with the product.

1.5 Content of the documentation

This documentation contains additional safety-related information and conditions for operation in safety-related applications.

1.6 Other applicable documentation

Observe the corresponding documentation for all further components.

1.7 Product names and trademarks

The brands and product names in this documentation are trademarks or registered trademarks of their respective titleholders.

1.7.1 Trademark of Beckhoff Automation GmbH

EtherCAT® is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

**1.8 Copyright notice**

© 2020 SEW-EURODRIVE. All rights reserved. Unauthorized reproduction, modification, distribution or any other use of the whole or any part of this documentation is strictly prohibited.

2 Safety notes

2.1 Preliminary information

The following general safety notes serve the purpose of preventing injury to persons and damage to property. They primarily apply to the use of products described in this documentation. If you use additional components, also observe the relevant warning and safety notes.

2.2 Duties of the user

As the user, you must ensure that the basic safety notes are observed and complied with. Make sure that persons responsible for the machinery and its operation as well as persons who work on the device independently have read through the documentation carefully and understood it.

As the user, you must ensure that all of the work listed in the following is carried out only by qualified specialists:

- Setup and installation
- Installation and connection
- Startup
- Maintenance and repairs
- Shutdown
- Disassembly

Ensure that the persons who work on the product pay attention to the following regulations, conditions, documentation, and information:

- National and regional safety and accident prevention regulations
- Warning and safety signs on the product
- All other relevant project planning documents, installation and startup instructions, and wiring diagrams
- Do not assemble, install or operate damaged products
- All system-specific specifications and conditions

Ensure that systems in which the product is installed are equipped with additional monitoring and protection devices. Observe the applicable safety regulations and legislation governing technical work equipment and accident prevention regulations.

2.3 Target group

| | |
|--------------------------------------|---|
| Specialist for mechanical work | <p>Any mechanical work may be performed only by adequately qualified specialists. Specialists in the context of this documentation are persons who are familiar with the design, mechanical installation, troubleshooting, and maintenance of the product who possess the following qualifications:</p> <ul style="list-style-type: none"> • Qualifications in the field of mechanics in accordance with the national regulations • Familiarity with this documentation |
| Specialist for electrotechnical work | <p>Any electrotechnical work may be performed only by electrically skilled persons with a suitable education. Electrically skilled persons in the context of this documentation are persons who are familiar with electrical installation, startup, troubleshooting, and maintenance of the product who possess the following qualifications:</p> <ul style="list-style-type: none"> • Qualifications in the in the field of electrical engineering in accordance with the national regulations • Familiarity with this documentation |
| Additional qualifications | <p>In addition to that, these persons must be familiar with the valid safety regulations and laws, as well as with the requirements of the standards, directives, and laws specified in this documentation.</p> <p>The persons must have the express authorization of the company to operate, program, parameterize, label, and ground devices, systems, and circuits in accordance with the standards of safety technology.</p> |
| Instructed persons | <p>All work in the areas of transportation, storage, operation and waste disposal must be carried out by persons who are trained appropriately. The purpose of the training is to give persons the ability to perform the required tasks and work steps in a safe and correct manner.</p> |

2.4 Designated use

The product is intended for control cabinet installation in electrical plants or machines. In case of installation in electrical systems or machines, startup of the product is prohibited until it is determined that the machine meets the requirements stipulated in the local laws and directives. For Europe, Machinery Directive 2006/42/EC as well as the EMC Directive 2014/30/EU apply. Observe EN 60204-1 (Safety of machinery - electrical equipment of machines). The product meets the requirements stipulated in the Low Voltage Directive 2014/35/EU.

The standards given in the declaration of conformity apply to the product.

The systems can be mobile or stationary.

Do not connect any other loads to the product. Never connect capacitive loads to the product.

The product can be used to operate the following motors in industrial and commercial systems:

- AC asynchronous motors with squirrel-cage rotor
- Permanent-field AC synchronous motors

Technical data and information on the connection conditions are provided on the nameplate and in chapter "Technical data" in the documentation. Always comply with the data and conditions.

Unintended or improper use of the product may result in severe injury to persons and damage to property.

2.4.1 Hoist applications

To avoid danger of fatal injury due to falling hoists, observe the following points when using the product in lifting applications:

- Use mechanical protection devices.

Application in ELSM® control mode

When the inverter is operated in ELSM® control mode, using it in lifting applications is not permitted. In this control mode only applications of horizontal materials handling are permitted.

2.4.2 Restrictions under the European WEEE Directive 2012/19/EU

You may use options and accessories from SEW-EURODRIVE exclusively in connection with products from SEW-EURODRIVE.

2.5 Functional safety technology

The product must not perform any safety functions without a higher-level safety system, unless explicitly allowed by the documentation.

2.6 Transport

Inspect the shipment for damage as soon as you receive the delivery. Inform the shipping company immediately about any damage. If the product is damaged, it must not be assembled, installed or started up.

Observe the following notes when transporting the device:

- Ensure that the product is not subject to mechanical impact.

If necessary, use suitable, sufficiently dimensioned handling equipment.

Observe the information on climatic conditions in chapter "Technical data" of the documentation.

2.7 Installation/assembly

Ensure that the product is installed and cooled in accordance with the regulations in the documentation.

Protect the product from excessive mechanical strain. The product and its mounted components must not protrude into the path of persons or vehicles. Ensure that no components are deformed or no insulation spaces are modified, particularly during transportation. Electrical components must not be mechanically damaged or destroyed.

Observe the notes in chapter Mechanical installation in the documentation.

2.7.1 Restrictions of use

The following applications are prohibited unless the device is explicitly designed for such use:

- Use in potentially explosive atmospheres
- Use in areas exposed to harmful oils, acids, gases, vapors, dust, and radiation
- Operation in applications with impermissibly high mechanical vibration and shock loads in excess of the regulations stipulated in EN 61800-5-1
- Use at an elevation of more than 3800 m above sea level

The product can be used at altitudes above 1000 m above sea level up to 3800 m above sea level under the following conditions:

- The reduction of the nominal output current and/or the line voltage is considered according to the data in chapter Technical data in the documentation.
- Above 2000 m above sea level, the air and creeping distances are only sufficient for overvoltage class II according to EN 60664. At altitudes above 2000 m above sea level, limiting measures must be taken which reduce the line side overvoltage from category III to category II for the entire system.
- If a protective electrical separation (in accordance with EN 61800-5-1 and EN 60204-1) is required, then implement this outside the product at altitudes of more than 2000 m above sea level.

2.8 Electrical installation

Ensure that all of the required covers are correctly attached after carrying out the electrical installation.

Make sure that preventive measures and protection devices comply with the applicable regulations (e.g. EN 60204-1 or EN 61800-5-1).

2.8.1 Required preventive measure

Make sure that the product is correctly attached to the ground connection.

2.8.2 Stationary application

Necessary preventive measure for the product is:

| Type of energy transfer | Preventive measure |
|-------------------------|---------------------|
| Direct power supply | • Ground connection |

2.8.3 Regenerative operation

The drive is operated as a generator due to the kinetic energy of the system/machine. Before opening the connection box, secure the output shaft against rotation.

2.9 Protective separation

The product meets all requirements for protective separation of power and electronics connections in accordance with EN 61800-5-1. To ensure protective separation, all connected circuits must also meet the requirements for protective separation.

2.10 Startup/operation

Observe the safety notes in chapters Startup and Operation in this documentation.

Make sure the connection boxes are closed and screwed before connecting the supply voltage.

Depending on the degree of protection, products may have live, uninsulated, and sometimes moving or rotating parts, as well as hot surfaces during operation.

When the device is switched on, dangerous voltages are present at all power connections as well as at any connected cables and terminals. This also applies even when the product is inhibited and the motor is at standstill.

Risk of burns due to arcing: Do not disconnect power connections during operation. Do not connect power connections during operation.

If you disconnect the product from the voltage supply, do not touch any live components or power connections because capacitors might still be charged. Observe the following minimum switch-off time:

10 minutes.

Observe the corresponding information signs on the product.

The fact that the operation LED and other display elements are no longer illuminated does not indicate that the product has been disconnected from the supply system and no longer carries any voltage.

Mechanical blocking or internal protective functions of the product can cause a motor standstill. Eliminating the cause of the problem or performing a reset may result in the drive restarting automatically. If, for safety reasons, this is not permitted for the drive-controlled machine, first disconnect the product from the supply system and then start troubleshooting.

Risk of burns: The surface temperature of the product can exceed 60 °C during operation. Do not touch the product during operation. Let the product cool down before touching it.

2.10.1 Energy storage unit

Products with a connected energy storage unit are not necessarily de-energized when they have been disconnected from the supply system. Usually, the energy storage unit stores sufficient energy to continue operation of the connected motors for a limited period of time. It is not sufficient to observe a minimum switch-off time.

Perform a shutdown as described in the documentation in the chapter "Service" > "Shutdown".

3 Device structure, axis system structure

3.1 Connection variants

The MOVIDRIVE® modular application inverter can be used in the following connection variants:

- As axis system in connection with a MOVI-C® CONTROLLER power/power eco
- As axis system in connection with a master module UHX45A/MDM90A
- As axis system in connection with a MOVI-C® CONTROLLER advanced
- As axis system in connection with a MOVI-C® CONTROLLER standard

In one axis system, up to 15 axis modules can be used, both as single-axis modules and double-axis modules.

NOTICE


Damage to the MOVIDRIVE® modular application inverter when opening the DC link (separate operation).

Separate operation of individual modules will damage the application inverter and is not permitted.

Only operate the application inverter when installed in a system as illustrated above.

3.1.1 Axis system with MOVI-C® CONTROLLER power/power eco


MOVIDRIVE® modular



27021610677277835

- [1] Line voltage 3 × AC 380 – 500 V
- [2] Industrial Communication
- [3] MOVI-C® CONTROLLER
- [4] MOVIDRIVE® modular power supply module MDP..
- [5] MOVIDRIVE® modular single-axis module MDA ..
- [6] MOVIDRIVE® modular double-axis module MDD..

MOVIDRIVE® modular and MOVIDRIVE® system




27021613583815051

- [1] Line voltage 3 × AC 380 – 500 V
- [2] Industrial Communication
- [3] MOVI-C® CONTROLLER
- [4] MOVIDRIVE® modular power supply module MDP..
- [5] MOVIDRIVE® modular single-axis module MDA ..
- [6] MOVIDRIVE® modular double-axis module MDD..
- [7] MOVIDRIVE® system

3.1.2 Axis system with master module UHX45A/MDM90A


MOVIDRIVE® modular



20841212939

- [1] Line voltage 3 × AC 380 – 500 V
- [2] Industrial Communication
- [3] MOVIDRIVE® modular master module UHX45A/MDM90A
- [4] MOVIDRIVE® modular power supply module MDP..
- [5] MOVIDRIVE® modular single-axis module MDA ..
- [6] MOVIDRIVE® modular double-axis module MDD..

MOVIDRIVE® modular and MOVIDRIVE® system




20841205643

- [1] Line voltage $3 \times \text{AC } 380 - 500 \text{ V}$
- [2] Industrial Communication
- [3] MOVIDRIVE® modular master module UHX45A/MDM90A
- [4] MOVIDRIVE® modular power supply module MDP..
- [5] MOVIDRIVE® modular single-axis module MDA ..
- [6] MOVIDRIVE® modular double-axis module MDD..
- [7] MOVIDRIVE® system

3.1.3 Axis system with MOVI-C® CONTROLLER advanced


MOVIDRIVE® modular



20841208075

- [1] Line voltage 3 × AC 380 – 500 V
- [2] Industrial Communication
- [3] MOVI-C® CONTROLLER advanced
- [4] MOVIDRIVE® modular power supply module MDP..
- [5] MOVIDRIVE® modular single-axis module MDA ..
- [6] MOVIDRIVE® modular double-axis module MDD..

MOVIDRIVE® modular and MOVIDRIVE® system




20840829579

- [1] Line voltage 3 × AC 380 – 500 V
- [2] Industrial communication
- [3] MOVI-C® CONTROLLER advanced
- [4] MOVIDRIVE® modular power supply module MDP..
- [5] MOVIDRIVE® modular single-axis module MDA.
- [6] MOVIDRIVE® modular double-axis module MDD..
- [7] MOVIDRIVE® system

3.1.4 Axis system with MOVI-C® CONTROLLER standard


MOVIDRIVE® modular



20841210507

- [1] Line voltage 3 × AC 380 – 500 V
- [2] Industrial Communication
- [3] MOVI-C® CONTROLLER standard
- [4] MOVIDRIVE® modular power supply module MDP..
- [5] MOVIDRIVE® modular single-axis module MDA ..
- [6] MOVIDRIVE® modular double-axis module MDD..

MOVIDRIVE® modular and MOVIDRIVE® system



20841203211

- [1] Line voltage 3 × AC 380 – 500 V
- [2] Industrial Communication
- [3] MOVI-C® CONTROLLER standard
- [4] MOVIDRIVE® modular power supply module MDP..
- [5] MOVIDRIVE® modular single-axis module MDA.
- [6] MOVIDRIVE® modular double-axis module MDD..
- [7] MOVIDRIVE® system

3 Device structure, axis system structure


MOVIDRIVE® modular nameplates

3.2 MOVIDRIVE® modular nameplates

The nameplates are presented as an example.

3.2.1 Power supply module

System nameplate




9007214313636491

[1] Device status

[2] Serial number

Performance data nameplate




9007214313645451

[1] Device status

3.2.2 Single-axis module

System nameplate




9007214313687563

[1] Device status

[2] Serial number

Performance data
nameplate



9007214313691915

[1] Device status

3 Device structure, axis system structure

MOVIDRIVE® modular nameplates

3.2.3 Double-axis module

System nameplate


MDD90A-0020-503-X-S00
01.1234567890.0001.15
10 11 12 13 14 15 16 17 18
01 01 01 01 01 01 01 01 01

[1]

SEW
EURODRIVE
D-76646 Bruchsal
Made in Germany

Type: MDD90A-0020-503-X-S00
SO#: 01.1234567890.0001.15

CE



50

EAC

IP 20

MOVIDRIVE modular
Doppelachsmodul
Double axis module

[2]

9007214313696523

- [1] Device status
- [2] Serial number

Performance data nameplate

MDD90A-0020-503-X-S00
01.1234567890.0001.15
10 11 12 13 14 15 16 17 18
01 01 01 01 01 01 01 01 01

[1]

SEW
EURODRIVE
D-76646 Bruchsal
Made in Germany

PU-Type: MDD90A-0020-503-X-S00

| Eingang / Input | Ausgang / Output |
|-----------------|------------------------------|
| U = DC 560V | U = 2x(3x 0V...U Netz) |
| I = DC 4A | I = 2x(AC 2A) |
| | I _{max} = 2x(AC 5A) |
| | f = 2x(0...599Hz) |
| | P(ASM) = 2x(0.55kW / 0.74HP) |

T = 0...+45°C
S = 2x(1.4kVA)
ML 0001

Status

10 11 12 13 14 15 16 17 18
01 01 01 01 01 01 01 01 01

[1]

9007214314814475

- [1] Device status

25953079/EN – 01/2020

30

Operating Instructions – MOVIDRIVE® modular

SEW

EURODRIVE

3.3 MOVIDRIVE® modular type code

The following type code applies to MOVIDRIVE® modular.

| Example: MDA90A-0080-503-X-S00 | | |
|-----------------------------------|------|---|
| Product family | MD | <ul style="list-style-type: none"> MD = MOVIDRIVE® |
| Device type | A | <ul style="list-style-type: none"> A = Single-axis module C = Capacitor module D = Double-axis module P = Power supply module with brake chopper S = Switched-mode power supply module with AC and DC supply M = Master module UHX45A/MDM90A |
| Series | 90 | <ul style="list-style-type: none"> 90 = Standard design 91 = Double-axis module with MOVILINK® DDI |
| Version | A | <ul style="list-style-type: none"> A = Version status A |
| Performance class | 0080 | <ul style="list-style-type: none"> MDA: Nominal output current – e.g. 0080 = 8 A MDD: Nominal output current – e.g. 0020 = 2 × 2 A MDP: Nominal power – e.g. 0100 = 10 kW MDC: Nominal capacitance – e.g. 0120 = 11.7 mF |
| Connection voltage | 5 | <ul style="list-style-type: none"> 5 = AC 380 – 500 V |
| EMC variants of the power section | 0 | <ul style="list-style-type: none"> 0 = Basic interference suppression integrated |
| Connection type | 3 | <ul style="list-style-type: none"> 3 = 3-phase connection type X = Not relevant |
| Operating mode | X | <ul style="list-style-type: none"> 4 = 4-quadrant operation (with brake chopper) X = Not relevant |
| Device variant | 0 | <ul style="list-style-type: none"> 0 = Not relevant S = Control MOVI-C® CONTROLLER C = Power supply module with integrated braking resistor and capacitor E = Inverter with device profile CiA402 |
| Designs | 00 | <ul style="list-style-type: none"> 00 = Standard design |
| Options | | <ul style="list-style-type: none"> 01 = Axis module MDA90A-0640-.. in size 5 /X = MOVIDRIVE® modular without card slots /L = Design with coated printed circuit boards <p>The following list serves as an example:</p> <ul style="list-style-type: none"> /CES11A = Multi-encoder card /CID21A, /CIO21A = I/O expansion card /CS..A = Safety card |

3.4 Device structure of the MDP power supply module

⚠ WARNING




Uncovered power connections.

Some of the modules shown in this chapter are depicted without touch guards. Touch guards secure the live parts such as DC link, line connections and braking resistor connections.

Severe or fatal injuries from electric shock

- Never start up the application inverter without installed closed touch guards.


3.4.1 MDP90A-0100-.. (size 1)



18014411422564235

| A: View from top | | B: View from front | C: View from bottom |
|------------------|---|--------------------|--------------------------------------|
| [1] | Terminal screw for TN/TT systems | [5] | 7-segment display |
| [2] | X7: Braking resistor temperature monitoring | [6] | Power: LED display DC link voltage |
| [3] | X30 OUT: System bus | [7] | X5: Connection +24 V supply voltage |
| [4] | X30 IN: System bus | [8] | PE connection |
| | | [9] | X4: DC link busbar |
| | | [10] | PE connection housing |
| | | [11] | Shield terminal |
| | | | [12] X3: Braking resistor connection |
| | | | [13] X1: Line connection |

3.4.2 MDP90A-0100-.. with integrated braking resistance (size 1A)



18014411422566667

A: View from top

- [1] Terminal screw for TN/TT systems
- [2] X7: Braking resistor temperature monitoring
- [3] X30 OUT: System bus
- [4] X30 IN: System bus


B: View from front

- [5] 7-segment display
- [6] Power: LED display DC link voltage
- [7] X5: Connection +24 V supply voltage
- [8] PE connection
- [9] X4: DC link busbar
- [10] PE connection housing
- [11] Shield terminal

C: View from bottom

- [12] X3: Braking resistor connection
- [13] X1: Line connection


3.4.3 MDP90A-0250-.. (size 2)



18014411422569099

- | A: View from top | B: View from front | C: View from bottom |
|---|---|--------------------------------------|
| [1] Terminal screw for TN/TT systems | [5] 7-segment display | [10] X1: Line connection |
| [2] X7: Control DC link discharge module, temperature monitoring braking resistor | [6] Power: LED display DC link voltage | [11] X3: Braking resistor connection |
| [3] X30 OUT: System bus | [7] X5: Connection +24 V supply voltage | [12] 3× housing PE connection |
| [4] X30 IN: System bus | [8] PE connection | |
| | [9] X4: DC link busbar | |
| | [10] X1: Line connection | |
| | [11] X3: Braking resistor connection | |
| | [12] 3× housing PE connection | |
| | [13] Shield terminal | |

3.4.4 MDP90A-0500, 0750-.. (size 3)



9007219360767499

A: View from top

- [1] Terminal screw for TN/TT systems
- [2] X7: Control DC link discharge module, temperature monitoring braking resistor
- [3] X30 OUT: System bus
- [4] X30 IN: System bus

B: View from front

- [5] 7-segment display
- [6] Power: LED display DC link voltage
- [7] X5: Connection +24 V supply voltage
- [8] PE connection
- [9] X4: DC link busbar
- [10] X1: Line connection
- [11] 3× housing PE connection
- [12] X3: Braking resistor connection


C: View from bottom

- [13] X1: Line connection
- [14] X3: Braking resistor connection

3 Device structure, axis system structure

Device structure of the MDP power supply module

3.4.5 MDP90A-1100-.. (size 4)



A: View from top

- [1] Terminal screw for TN/TT systems
- [2] X7: Control DC link discharge module, temperature monitoring braking resistor
- [3] X30 OUT: System bus
- [4] X30 IN: System bus

B: View from front

- [5] 7-segment display
- [6] Power: LED display DC link voltage
- [7] X5: Connection +24 V supply voltage
- [8] PE connection
- [9] X4: DC link busbar
- [10] X3: Braking resistor connection
- [11] X1: Line connection
- [12] 2 × housing PE connection

C: View from bottom

- [13] X3: Braking resistor connection
- [14] X1: Line connection

3.5 Device structure of the MDA and MDD axis modules



⚠ WARNING

Uncovered power connections.

Some of the modules shown in this chapter are depicted without touch guards. Touch guards secure the live parts such as DC link, line connections and braking resistor connections.


Severe or fatal injuries from electric shock

- Never start up the application inverter without installed closed touch guards.

MDA: Single-axis module

MDD: Double-axis module

3.5.1 MDA90A-0020, 0040, 0080, 0120 (size 1) – Single-axis module



36028809932026123

A: View from top

- [1] EMC: Terminal screw for TN/TT systems
- [2] X6: Connection for Safe Torque Off (STO)
- [3] X30 OUT: System bus
- [4] X30 IN: System bus


B: View from front

- [5] X31: SEW-EURODRIVE Service interface
- [6] X20: Digital inputs
- [7] X21: Digital outputs
- [8] EtherCAT® ID switch
- [9] Status LEDs EtherCAT®/SBus^{PLUS} "RUN", "ERR"
- [10] 7-segment display
- [11] X15: Motor encoder connection
- [12] X5: Connection +24 V supply voltage
- [13] PE connection
- [14] X4: DC link busbar
- [15] Shield plate
- [16] Card slot

C: View from bottom

- [17] X10: Brake control and motor temperature monitoring
- [18] PE connection housing
- [19] X16: MOVILINK® DDI connection
- [20] X2: Motor connection

3.5.2 MDA90A-0160, 0240 (size 2) – Single-axis module



36028809932028555

A: View from top

- [1] EMC: Terminal screw for TN/TT systems
- [2] X6: Connection for Safe Torque Off (STO)
- [3] X30 OUT: System bus
- [4] X30 IN: System bus


B: View from front

- [5] X31: SEW-EURODRIVE Service interface
- [6] X20: Digital inputs
- [7] X21: Digital outputs
- [8] EtherCAT® ID switch
- [9] Status LEDs EtherCAT®/SBus^{PLUS} "RUN", "ERR"
- [10] 7-segment display
- [11] X15: Motor encoder connection
- [12] X5: Connection +24 V supply voltage
- [13] PE connection
- [14] X4: DC link busbar
- [15] Shield plate
- [16] Card slots

C: View from bottom

- [17] X10: Brake control and motor temperature monitoring
- [18] PE connection housing
- [19] X16: MOVILINK® DDI connection
- [20] X2: Motor connection

3.5.3 MDA90A0-320, 0480 (size 3) – Single-axis module



45036009186784779

A: View from top

- [1] EMC: Terminal screw for TN/TT systems
- [2] X6: Connection for Safe Torque Off (STO)
- [3] X30 OUT: System bus
- [4] X30 IN: System bus


B: View from front

- [5] X31: SEW-EURODRIVE Service interface
- [6] X20: Digital inputs
- [7] X21: Digital outputs
- [8] EtherCAT® ID switch
- [9] Status LEDs EtherCAT®/SBus^{PLUS} "RUN", "ERR"
- [10] 7-segment display
- [11] X15: Motor encoder connection
- [12] X5: Connection +24 V supply voltage
- [13] PE connection
- [14] X4: DC link busbar
- [15] X2: Motor connection
- [16] PE connection housing
- [17] Shield plate
- [18] Card slots

C: View from bottom

- [19] X10: Brake control and motor temperature monitoring
- [20] X16: MOVILINK® DDI connection

3.5.4 MDA90A0-0640 (size 4) – Single-axis module



9007223559673227

A: View from top

- [1] EMC: Terminal screw for TN/TT systems
- [2] X6: Connection for Safe Torque Off (STO)
- [3] X30 OUT: System bus
- [4] X30 IN: System bus


B: View from front

- [5] X31: SEW-EURODRIVE Service interface
- [6] X20: Digital inputs
- [7] X21: Digital outputs
- [8] EtherCAT® ID switch
- [9] Status LEDs EtherCAT®/SBus^{PLUS} "RUN", "ERR"
- [10] 7-segment display
- [11] X15: Motor encoder connection
- [12] X5: Connection +24 V supply voltage
- [13] PE connection
- [14] X4: DC link busbar
- [15] X2: Motor connection
- [16] PE connection housing
- [17] Shield plate
- [18] Card slots

C: View from bottom

- [19] X10: Brake control and motor temperature monitoring
- [20] X16: MOVILINK® DDI connection

3.5.5 MDA90A-0640, 1000 (size 5) – Single-axis module



18014418615503627

A: View from top

- [1] EMC: Terminal screw for TN/TT systems
- [2] X6: Connection for Safe Torque Off (STO)
- [3] X30 OUT: System bus
- [4] X30 IN: System bus


B: View from front

- [5] X31: SEW-EURODRIVE Service interface
- [6] X20: Digital inputs
- [7] X21: Digital outputs
- [8] EtherCAT® ID switch
- [9] Status LEDs EtherCAT®/SBus^{PLUS} "RUN", "ERR"
- [10] 7-segment display
- [11] X15: Motor encoder connection
- [12] X5: Connection +24 V supply voltage
- [13] PE connection
- [14] X4: DC link busbar
- [15] X2: Motor connection
- [16] PE connection housing
- [17] Card slots

C: View from bottom

- [18] X10: Brake control and motor temperature monitoring
- [19] X16: MOVILINK® DDI connection

3.5.6 MDA90A-1400, 1800 (size 6) – Single-axis module



18014418615506059

A: View from top

- [1] EMC: Terminal screw for TN/TT systems
- [2] X6: Connection for Safe Torque Off (STO)
- [3] X30 OUT: System bus
- [4] X30 IN: System bus


B: View from front

- [5] X31: SEW-EURODRIVE Service interface
- [6] X20: Digital inputs
- [7] X21: Digital outputs
- [8] EtherCAT® ID switch
- [9] Status LEDs EtherCAT®/SBus^{PLUS} "RUN", "ERR"
- [10] 7-segment display
- [11] X15: Motor encoder connection
- [12] X5: Connection +24 V supply voltage
- [13] PE connection
- [14] X4: DC link busbar
- [15] PE connection housing
- [16] X2: Motor connection
- [17] Card slots

C: View from bottom

- [18] X10: Brake control and motor temperature monitoring
- [19] X16: MOVILINK® DDI connection

3.5.7 MDD9.A-0020, 0040 (size 1) – Double-axis module



45036009186762251

A: View from top

- [1] EMC: Terminal screw for TN/TT systems
- [2] X6: 2 × connection for safe disconnection (STO)
- [3] X30 OUT: System bus
- [4] X30 IN: System bus


B: View from front

- [5] X31: SEW-EURODRIVE Service interface
- [6] X20: 2 × digital inputs
- [7] X21: 2 × digital outputs
- [8] EtherCAT® ID switch
- [9] Status LEDs EtherCAT®/SBus^{PLUS} "RUN", "ERR"
- [10] 2 × 7-segment display
- [11] X15: 2 × motor encoder connection with MDD90A
- [12] X5: Connection +24 V supply voltage
- [13] PE connection
- [14] X4: DC link busbar
- [15] Shield plate

C: View from bottom

- [16] X10: 2 × brake control and temperature monitoring motor
- [17] X16: Connection MOVILINK® DDI with MDD91A
- [18] PE connection housing
- [19] X2: 2 × motor connection

3.5.8 MDD9.A-0020, 0040, 0080 (size 2) – Double-axis module




45036009186764683

| A: View from top | | B: View from front | C: View from bottom |
|-------------------------|---|--|--|
| [1] | EMC: Terminal screw for TN/TT systems | [5] X31: SEW-EURODRIVE Service interface | [17] X10: 2 × brake control and temperature monitoring motor |
| [2] | X6: 2 × connection for safe disconnection (STO) | [6] X20: 2 × digital inputs | [18] X16: Connection MOVILINK [®] DDI with MDD91A |
| [3] | X30 OUT: System bus | [7] X21: 2 × digital outputs | [19] PE connection housing |
| [4] | X30 IN: System bus | [8] EtherCAT [®] ID switch | [20] X2: 2 × motor connection |
| | | [9] Status LEDs EtherCAT [®] /SBus ^{PLUS} "RUN", "ERR" | |
| | | [10] 2 × 7-segment display | |
| | | [11] X15: 2 × motor encoder connection with MDD90A | |
| | | [12] X5: Connection +24 V supply voltage | |
| | | [13] PE connection | |
| | | [14] X4: DC link busbar | |
| | | [15] Shield plate | |
| | | [16] Card slots | |

3.6 MDC capacitor module

3.6.1 MDC90A-0001/0002-50X-X-000



31396911243

A: View from top

[1] Terminal screw for TN/TT systems


B: View from front

- [2] X5: Connection +24 V supply voltage
- [3] PE connection
- [4] X4: DC link connection
- [5] PE connection

C: View from bottom

[6] Connection of safe brake module

3.7 Device structure of master module UHX45A/MDM90A



9007220061654411

A: View from top

- [1] X5_B: Output of DC 24 V supply voltage of MDM90A
- [2] X5: Input of DC 24 V supply voltage UHX45A
- [3] X30: EtherCAT®/SBus^{PLUS} master
- [4] X81: Ethernet port (reserved)


B: View from front

- [5] X80: Engineering via Ethernet
- [6] SD removable data storage
- [7] Reset of UHX45A
- [8] IP address of the engineering port
- [9] X85: CAN bus/RS485 interface
- [10] X5: Connection +24 V supply voltage
- [11] US1: Operating state of the fieldbus
- [12] BF: Bus error
- [13] X41: Fieldbus - slave interface

C: View from bottom

- [14] X5_A: External 24 V supply voltage
- [15] Fuse for DC 24 V supply UHX45A


3.8 Example for axis system connection without master module



18014411422534411

- [1] X5: Connection +24 V supply voltage
- [2] PE connection
- [3] X4: DC link connection
- [4] MDP.. power supply module
- [5] MDA.. single-axis module
- [6] MDD.. double-axis module

3.9 Example for axis system connection with master module



20848770571

- [1] X5: Connection +24 V supply voltage
- [2] PE connection
- [3] X4: DC link busbar
- [4] Master module UHX45A/MDM90A
- [5] MDP.. power supply module
- [6] MDA.. single-axis module
- [7] MDD.. double-axis module

3.10 Card slots

The application inverters can have up to 2 cards installed. The following section describes the assignment of the slots and possible combinations of cards.



| Type designation | Description | Slot in | | | |
|----------------------|--------------------|-------------------------------|-------------|-------------------------------|-------------------------|
| | | MDA90A-... single-axis module | | MDD9.A-... double-axis module | |
| | | 0020 – 0120 | 0160 – 1800 | 0020 – 0040 (size 1) | 0020 – 0080 (size 2) |
| CES11A | Multi-encoder card | [2] | [2] | – | – |
| CID21A, CIO21A | Input/output cards | – | [3] | – | – |
| CS.21A ¹⁾ | Safety card | [2] | [2] | – | [2] |
| CS.31A | Safety card | [2] | [2] | – | – |

1) With the MDD91A-... only the CSB21A card with the STO/SS1c function can be use.

3.10.1 Single-axis modules

MDA90A-0020, 0040, 0080, 0120

MDA90A-0160 – 1800




9007212169660939


- [1] Connector panel of basic device
- [2] Safety card/additional encoder slot
- [3] I/O expansion slot

3.10.2 Double-axis modules

MDD9.A-0020, 0040 (size 1)



MDD9.A-0020, 0040, 0080 (size 2)



9007212170096139

- [1] Connector panel of basic device for the 1st and 2nd axis
- [2] Slot for safety card

4 Installation

MOVIDRIVE® modular application inverters are exclusively suitable for control cabinet installation according to the degree of protection.

4.1 Installation accessories

4.1.1 Standard accessories


The listed standard accessories are included in the scope of delivery.

Standard accessories – mechanical accessories





| Type designation | Electronics shield clamps Quantity |
|---------------------------------|---------------------------------------|
| Power supply modules | 1 |
| MDP90A-0100-.. – MDP90A-1100-.. | |
| Single-axis modules | |
| MDA90A-0020-.. – MDA90A-1800-.. | |
| Double-axis modules | |
| MDD9.A-0020-.. – MDD9.A-0080-.. | |
| Capacitor module | |
| MDC90A-0001/0002-50X-X-000 | |
| Master module | |
| MDM90A | |
| Type designation | Power shield clamps Quantity |
| Power supply modules | 1 |
| MDP90A-0100-.. – MDP90A-1100-.. | |
| Single-axis modules | |
| MDA90A-0020-.. – MDA90A-1800-.. | |
| Double-axis modules | |
| MDD9.A-0020-.. – MDD9.A-0080-.. | |
| Capacitor module | |
| MDC90A-0001/0002-50X-X-000 | |




The mechanical accessories can be ordered with the following part numbers:

| Type designation | Part number accessory pack |
|--|----------------------------|
| Power supply module | |
| MDP90A-0100-.. (size 1) | 28223756 |
| MDP90A-0100-.. (size 1A) | 28223756 |
| MDP90A-0250-.. | 28224507 |
| MDP90A-0500-.. – MDP90A-0750-.. | 28232984 |
| MDPA90A-1100-.. | 28234316 |
| Single-axis modules | |
| MDA90A-0020-.. – MDA90A-0120-.. | 28223756 |
| MDA90A-0160-.. – MDA90A-0240-.. | 28233530 |
| MDA90A-0320-.. – MDA90A-0480-.. | 28220714 |
| MDA90A-0640-.. | 28226151 |
| MDA90A-1000-.. – MDA90A-1400-.. | 28231635 |
| MDA90A-1800-.. | 28233190 |
| Double-axis module | |
| MDD9.A-0020-.. – MDD9.A-0040-.. (size 1) | 28223756 |

| Type designation | Part number accessory pack | | |
|---|---|-------------|-------------|
| MDD9.A-0020-.. – MDD9.A-0080-.. (size 2) | 28220455 | | |
| Capacitor module | | | |
| MDC90A-0001/0002-50X-X-000 | | | |
| Master module | | | |
| UHX45A/MDM90A | 28244389 | | |
| The following devices must be transported with a lifting eye: | Lifting eye | Designation | Part number |
| MDP90A-1100-.. |  | CLH11A | 28106229 |
| MDA90A-1400/1800-.. | | | |

Standard accessories – electrical accessories

| Type designation | Bar 24 V supply | Quantity |
|---------------------------------|--|----------|
| Power supply modules |  | 2 |
| MDP90A-0100-.. – MDP90A-1100-.. | | |
| Single-axis modules | | |
| MDA90A-0020-.. – MDA90A-1800-.. | | |
| Double-axis modules | | |
| MDD9.A-0020-.. – MDD9.A-0080-.. | | |
| Capacitor module | | |
| MDC90A-0001/0002-50X-X-000 | | |
| Master module | | |
| MDM90A | | |
| Type designation | PE busbar | Quantity |
| Power supply modules |  | 1 |
| MDP90A-0100-.. – MDP90A-1100-.. | | |
| Single-axis modules | | |
| MDA90A-0020-.. – MDA90A-1800-.. | | |
| Double-axis modules | | |
| MDD9.A-0020-.. – MDD9.A-0080-.. | | |
| Capacitor module | | |
| MDC90A-0001/0002-50X-X-000 | | |
| Master module | | |
| MDM90A | | |
| Type designation | DC link bar narrow | Quantity |
| Power supply modules |  | 2 |
| MDP90A-0100-.. – MDP90A-0750-.. | | |
| Single-axis modules | | |
| MDA90A-0020-.. – MDA90A-1000-.. | | |
| Double-axis modules | | |
| MDD9.A-0020-.. – MDD9.A-0080-.. | | |
| Capacitor module | | |
| MDC90A-0001/0002-50X-X-000 | | |
| Master module | | |
| MDM90A | | |
| Type designation | DC link bar wide | Quantity |
| Power supply modules |  | 2 |
| MDP90A-1100-.. | | |
| Single-axis modules | | |
| MDA90A-1400-.. – MDA90A-1800-.. | | |

| Type designation | 8-pin module bus cable, system bus EtherCAT®/SBus ^{PLUS} | Quantity |
|---|--|----------|
| Power supply modules MDP90A-0100-... – MDP90A-1100-... |  | 1 |
| Single-axis modules MDA90A-0020-... – MDA90A-1800-... | | |
| Double-axis modules MDD9.A-0020-... – MDD9.A-0080-... | | |
| Type designation | DC link closing cover | Quantity |
| Power supply modules MDP90A-0100-... – MDP90A-1100-... |  | 2 |
| Type designation | Power connection closing cover | Quantity |
| Power supply modules MDP90A-0250-... – MDP90A-1100-... |  | 1 |
| Single-axis modules MDA90A-0480-... – MDA90A-1800-... | | |

The electrical accessories can be ordered using the following part numbers:

| Module | Part number | |
|--|------------------------------|------------------|
| | Accessory pack ¹⁾ | Module bus cable |
| Power supply module | | |
| MDP90A-0100-... (size 1) | 28224876 | 18166989 |
| MDP90A-0100-... (size 1A) | 28225201 | 18167004 |
| MDP90A-0250-... | 8230027 | 18166989 |
| MDP90A-0500-... – MDP90A-0750-... | 28232992 | 18167012 |
| MDP90A-1100-... | 28234324 | 18167020 |
| Single-axis module | | |
| MDA90A-0020-... – MDA90A-0120-... | 28223764 | 18166989 |
| MDA90A-0160-... – MDA90A-0240-... | 28220463 | 18166997 |
| MDA90A-0320-... – MDA90A-0480-... | 28225236 | 18167004 |
| MDA90A-0640-... – MDA90A-1000-... | 28231643 | 18167012 |
| MDA90A-1400-... – MDA90A-1800-... | 28233212 | 18167020 |
| Double-axis module | | |
| MDD9.A-0020-... – MDD9.A-0040-... (size 1) | 28223764 | 18166989 |
| MDD9.A-0020-... – MDD9.A-0080-... (size 2) | 28220463 | 18166997 |
| Capacitor module | | |
| MDC90A-0001/0002-50X-X-000 | | |
| Master module | | |
| UHX45A/MDM90A | 28244397 | 18166989 |







1) Accessory pack contains module bus cable

4.1.2 Available accessories

Adapter connectors of the DC link connection

To be able to establish an axis system in which modules with DC link bars of different widths are used, adapter connectors must be used at the transition from wide to narrow or narrow to wide. These adapter connectors are listed in the following table.

The necessary closing covers are included with the adapter connectors.

| From module | To module | Adapter connectors/ closing covers | Part number |
|---------------------------------|---|---|-------------|
| MDP90A-0750-.. | MDA90A-1400-.. |  | 28244052 |
| | |  | 18181716 |
| MDP90A-1100-.. | <ul style="list-style-type: none"> MDA90A-0020-.. – MDA90A-1000-.. MDD9.A-0020.. – MDD9.A-0080-.. |  | 28244079 |
| | |  | 18151884 |
| MDA90A-1400-.. – MDA90A-1800-.. | <ul style="list-style-type: none"> MDA90A-0020-.. – MDA90A-1000-.. MDD9.A-0020.. – MDD9.A-0080-.. |  | 28244060 |
| | |  | 18151884 |
| | | | 18183751 |


The closing cover 18181716 is included with the adapter connectors 28244052.

The closing cover 18151884 is included with the adapter connectors 28244079.

The closing covers 18151884 and 18183751 are included with the adapter connectors 28244060.

Adapter connectors are not included in the scope of delivery and must be ordered.

Cable

| Designation | Length | Connector | Part number |
|---|---|-----------|--|
|  | | | |
| 4-pole system bus cable, system bus EtherCAT®/SBus ^{PLUS} | <ul style="list-style-type: none"> 0.75 m 1.5 m 3 m 5 m 10 m | 2 × RJ45 | <ul style="list-style-type: none"> 18167039 18179975 18167047 18179983 18179991 |

4.2 Permitted tightening torques

| Screw connection | | Tightening torque in Nm | | | | |
|----------------------------------|------|-------------------------|----------------|-------|------------|---------|
| | | MDP90A- | | | | |
| | | 0100 (size 1) | 0100 (size 1A) | 0250 | 0500, 0750 | 1100 |
| Line connection | X1 | 0.5 – 0.6 | | 3 – 4 | 18 – 22 | |
| Braking resistor connection | X3 | 0.5 – 0.6 | | 3 – 4 | | 11 – 12 |
| DC link connection | X4 | 3 – 4 | | | | – |
| | X4_A | – | | | | 11 – 12 |
| | X4_B | – | | | | 3 – 4 |
| PE connection | X4 | 3 – 4 | | | | |
| Connection 24 V voltage supply | X5 | 1.2 – 1.5 | | | | |
| Terminal screw for TN/IT systems | EMC | 1 – 1.2 | | | | |
| Safety cover | | 0.6 – 0.8 | | | | 1 – 1.2 |

| Screw connection | | Tightening torque in Nm | | | | | | | | | |
|----------------------------------|------|-----------------------------|------------|------------|------|------------|------------|----------------------------|---------------------------|-------------------------|----------------------|
| | | MDA90A-. single-axis module | | | | | | Double-axis module MDD9.A- | | MDC90A capacitor module | Master module MDM90A |
| | | 0020, 0040, 0080, 0120 | 0160, 0240 | 0320, 0480 | 0640 | 0640, 1000 | 1400, 1800 | 0020, 0040 (size 1) | 0020, 0040, 0080 (size 2) | 0001 | |
| Motor connection | X2 | 0.5 – 0.6 | 1.5 – 1.7 | 3 – 4 | | 18 – 22 | | 0.5 – 0.6 | | – | – |
| DC link connection | X4 | 3 – 4 | | | | | 11 – 12 | 3 – 4 | | 3 – 4 | – |
| PE connection | X4 | 3 – 4 | | | | | | 3 – 4 | | 3 – 4 | 3 – 4 |
| Connection 24 V voltage supply | X5 | 1.2 – 1.5 | | | | | | 1.2 – 1.5 | | 1.2 – 1.5 | – |
| | X5_A | – | | | | | | | | | |
| | X5_B | – | | | | | | | | | 1.2 – 1.5 |
| Terminal screw for TN/TT systems | EMC | 1 – 1.2 | | | | | | 1 – 1.2 | | 1 – 1.2 | – |
| PE connections - M4 - M6 | | 1 – 1.2 3 – 4 | | | | | | 1 – 1.2 3 – 4 | | | – |
| Safety cover | | 0.8 | | | | | 1 – 1.2 | 0.8 | | 0.8 | 0.8 |
| Fastening the cards | | 0.6 – 0.8 | | | | | | 0.6 – 0.8 | | – | – |

NOTICE

Non-compliance with the stipulated tightening torques.

Possible damage to the application inverter.

- Always adhere to the stipulated tightening torques. Otherwise, excessive heat can develop which would damage the application inverter.
- An excessively high tightening torque may cause damage.

4.3 Special aspects when transporting the devices

NOTICE

Incorrect lifting and transporting of the inverter.


Inverter damage.

- When you lift or transport the inverter, use only the intended handling points for transportation to avoid any damage. Do not grip the inverter at any plastic parts or covers when lifting it. Only grip the inverter at metallic parts or use the lifting eye for transportation.

Due to the weight, the following devices are to be transported with a lifting eye:

- MDP90A-1100-..
- MDA90A-1400/1800-..

The lifting eye is attached to the top of the housing, see the following figure.



24550948491

The lifting eye can be attached to assembly stations using suitable slings.

The lifting eye is included in the delivery of the affected products.

4.4 Mechanical installation



⚠ CAUTION

Risk of injury to persons and damage to property.

Never install defective or damaged application inverters.

- Before installing modules, check them for external damage. Replace any damaged modules.

NOTICE

Risk of damage to property due to mounting surface with poor conductivity.

Damage to the application inverter.

- The mounting plate in the control cabinet must be conductive over a large area for the mounting surface of the application inverter (metallically pure, good conductivity). EMC compliant installation of the application inverter can only be accomplished with a mounting plate that is conductive over a large area.

4.4.1 Hole pattern

Preparing the control cabinet


You can prepare the control cabinet for the installation of differently assembled axis systems by drilling tapped holes every 30 mm for mounting the modules. The modules can be attached to this grid irrespective of their width, see figure below.

Dimensions

Device base plate

| Modules | Dimensions of the device base plate in mm | | | | | | | |
|--|---|-----|-----|-----|----|----|---|----|
| | A | B | C | D | E | F | G | H |
| MDP90A-0100 (size 1) | 60 | 30 | 355 | 383 | 19 | 15 | 7 | 13 |
| MDP90A-0100 (size 1a) | 120 | 90 | 355 | 383 | 19 | 15 | 7 | 13 |
| MDP90A-0250 (size 2) | 60 | 30 | 455 | 483 | 19 | 15 | 7 | 13 |
| MDP90A-0500, 0750 (size 3) | 150 | 120 | 455 | 483 | 19 | 15 | 7 | 13 |
| MDP90A-1100 (size 4) | 210 | 180 | 455 | 483 | 19 | 15 | 7 | 13 |
| MDA90A-0020, 0040, 0080, 0120 (size 1) | 60 | 30 | 355 | 383 | 19 | 15 | 7 | 13 |
| MDA90A-0160, 0240 (size 2) | 90 | 60 | 355 | 383 | 19 | 15 | 7 | 13 |
| MDA90A-0320, 0480 (size 3) | 90 | 60 | 455 | 483 | 19 | 15 | 7 | 13 |
| MDA90A-0640 (size 4) | 120 | 90 | 455 | 483 | 19 | 15 | 7 | 13 |
| MDA90A-0640, 1000 (size 5) | 150 | 120 | 455 | 483 | 19 | 15 | 7 | 13 |
| MDA90A-1400, 1800 (size 6) | 210 | 180 | 455 | 483 | 19 | 15 | 7 | 13 |
| MDD9.A-0020, 0040 (size 1) | 60 | 30 | 355 | 383 | 19 | 15 | 7 | 13 |
| MDD9.A0020, 0040, 0080 (size 2) | 90 | 60 | 355 | 383 | 19 | 15 | 7 | 13 |
| MDC90A-0001/0002-50X-X-000 | 60 | 30 | 355 | 383 | 19 | 15 | 7 | 13 |
| MDM90A | 60 | 30 | 355 | 383 | 19 | 15 | 7 | 13 |

Mounting grid



27021610488337547

For dimension sheets of the application inverters, refer to chapter "Technical data".

4.4.2 Minimum clearance and mounting position

When installing the modules in the control cabinet, observe the following:

- To ensure unobstructed cooling, leave a minimum clearance of 100 mm above and below the module housings. Make sure air circulation in the clearance is not impaired by cables or other installation equipment.
- Make sure that the devices are not subjected to heated exhaust air from nearby components.
- The axis system must be assembled without gaps.
- Install the modules only vertically. You must not install them horizontally, tilted or upside down.

INFORMATION



Special bending spaces are required according to EN 61800-5-1 for cables with a cross section of 10 mm² and larger. This means the clearance must be increased if required.

4.5 Covers

For transportation, the safety covers of the power supply modules MDP90A 25 kW and larger, and of the axis modules MDA90A 64 A and larger are protected with cardboard.


Remove this protection before startup.

Observe that the devices must not be gripped at the safety covers when lifting the devices.

4.5.1 Covers

All MDA and MDD axis modules of the application inverter are equipped with a safety cover [1], see following figures.


Removing the
safety cover



27021611749935499

1. The safety cover [1] has a latching mechanism at the bottom. Put your finger in one of the openings of the safety cover and pull it away from the application inverter to unlatch it.
2. Pivot the safety cover forward and lift it to remove it from the application inverter.

Installing the safety cover




9007214394878475

- Place the safety cover [1] into the upper recess and move it towards the application inverter until it clicks into place.

Reinstall all safety covers [1] after installation work.

4.5.2 Touch guards


Axis system with master module



20918974091

1. Insert the closing covers [2] into the touch guards covers [1] of the first and last module in the axis system.
2. Attach the touch guard covers [1] to the modules. Insert the screws and tighten them securely with the specified tightening torque (→ 57).

Axis system without master module




18014412466136331

1. Insert closing covers [2] into the touch guards covers [1] of the first and last module in the axis system.
2. Attach the touch guard covers [1] to the modules. Insert the screws and tighten them securely with the specified tightening torque (→ 57).

4.5.3 Power connection closing cover

To achieve degree of protection IP20 according to EN 60529 with the following modules, a closing cover must be inserted into the touch guard at the power connection.

- Power supply module MDP90A-0250-.. (X1 connection)
- Axis modules MDA90A-0320-.. and MDA90A-0480-.. (X2 connection)



18948602891


- [1] Power supply module touch guard
- [2] Power supply module closing cover
- [3] Axis module touch guard
- [4] Axis module closing cover

1. Remove the touch guard [1], [3] from the respective module.
2. Insert the closing cover [2], [4] into the touch guard.
3. Install the touch guard on the respective module. Insert the screws and tighten them securely with the specified tightening torque (→ 57).

The closing covers are included in the delivery.

4.5.4 Closing cover between MDA90A-1400 – 1800-.. and MDA90A-0020 – 0240-..


If a MDA90A-0020 – 0240-.. axis module comes after a MDA90A-1400 – 1800-.. axis module, a gap arises at the touch guard of the MDA90A-1400 – 1800, which must be closed with the closing cover [1]. The closing cover is included with the adapter connectors of the DC link connection.



9007223607532043

To achieve the degree of protection IP20, the gap must be closed using the closing cover.

4.5.5 Front cover



20806974603

1. Remove the safety cover [1].
2. Push the front cover [2] forwards and downwards.
3. Re-install the safety cover [1].


4.5.6 Protection caps

To achieve degree of protection IP20 according to EN 60529 with the following modules, a protection cap must be used to secure the connectors against being touched. The protection caps are included in the accessory bag.

- Power supply modules MDP90A-0500-.. and larger, line connection X1, braking resistor connection X3
- MDP92A-0250-.. power supply modules: Energy storage unit connection X4_B
- DC/DC converter MDE90A-0750-..: Energy storage unit connection X13
- Power supply modules with energy recovery, MDR91A-0500-.. and larger: Line connection X1, braking resistor connection X3
- Axis modules MDA90A-0640-.. and larger: Motor connection X2


Attached protection caps can be removed as depicted in the following figures.

Line connection,
motor connection



20109660043

Braking resistor
connection




20109663883

To ensure degree of protection IP20, the protection caps must be replaced after connecting the cables.

Breaking out templates

In order to attach the protection caps in case of cables with large cross section or in case of connection with 2 cables, the template in the protection caps must be broken out.

- Cut out the plastic templates [1] in the protection cap using diagonal cutting pliers as depicted in the figure.



20549049227

4.6 Control cabinet installation

The following steps are depicted at the example of an axis system with 1 power supply module, several axis modules, and 1 master module.


Other modules are used analogously to the instructions described in this chapter.

4.6.1 Arrangement of the axis modules within the axis system

When arranging the axis system, observe that the nominal DC link current of the axis modules must decrease from left to right. The axis module with the highest nominal output current must be on the right side of the power supply module. All remaining axis modules are installed in descending order regarding their nominal DC link current.

The axis modules must always be installed on the right of the power supply module.

The master module must always be installed on the left of the power supply module.



20806249227

[1] Master module

[2] Power supply module

[3] Example: MDA90A-0120... single-axis module: $I_{NDCL} = 12 \text{ A}$

[4] Example: MDD9.A-0040... double-axis module: $I_{NDCL} = 8 \text{ A}$

[5] Example: MDA90A-0040... single-axis module: $I_{NDCL} = 4 \text{ A}$

[6] Example: MDA90A-0020... single-axis module: $I_{NDCL} = 2 \text{ A}$

In one axis system, up to 15 axis modules can be used, both as single-axis modules and double-axis modules.


Two-row design

The descending order also applies to the two-row design for the main and the auxiliary row. Up to 15 axis modules can be used together in both rows with the two-row design.

4.6.2 Installing a module

The retaining screws [1] and [2] are screwed into the prepared mounting grid in the control cabinet but not tightened.

1. Place the module with the slotted holes on the unit base plate onto the retaining screws [1] from the top.




20806979851

2. Push the module backwards to insert the retaining screws [2] into the upper holes in the unit base plate.
3. Lower the module.
4. Tighten the retaining screws [1] and [2].

4.6.3 Installing shield plates

Bottom shield plate




20806998283

1. Install the shield plate [3] from below.


Top shield plate

1. Install the top shield plate as shown.



17475894795


4.6.4 Removing the covers



20807002891

1. Pivot the safety cover [1] forward and lift it to remove it from the application inverter.
2. Move the front cover [2] upwards and remove them by pulling them away from the application inverter.


4.6.5 Removing the touch guards



1. Remove the screws [1] of the touch guards of all modules.
2. Remove the touch guards [2] from all modules.

20918971659

4.6.6 Installing the busbar




20807025291

1. Install the busbar [1] for the 24 V supply voltage as shown in the figure. Tighten the screws with the specified tightening torque (→ 57).
2. Install the busbar [2] for the PE connection as shown in the figure. Tighten the screws with the specified tightening torque (→ 57).
3. Install the busbar [3] for the DC link connection X4 as shown in the figure. Tighten the screws with the specified tightening torque (→ 57).

4.6.7 Installing touch guards


All modules of the application inverter are equipped with touch guards [1] and the outer modules of the axis system have closing covers [2], see the following figure. If the axis system contains a master module, the closing cover [2] only needs to be attached at the last module in the axis system.

Axis system with master module



20918974091

Axis system without master module



18014412466136331

- [1] Touch guard
- [2] Closing cover

Reinstall all touch guards [1] after installation work.

1. Insert the closing cover [2] into the touch guard [1].
2. Install the touch guard [1] on the respective module. Insert the screws and tighten them securely with the specified tightening torque (→ 57).

Install one closing cover [2] each at the outer modules of the axis system. The closing covers prevent the DC link from being touched. Two closing covers are included with each power supply module.


⚠ WARNING

Missing touch guards and closing covers
Severe or fatal injuries from electric shock

- Install all touch guards.
- Install closing covers at the first and last module in the axis system.



4.6.8 Installing front covers and covers



20807031691


1. Push the front cover [2] forwards and downwards.
2. Place the safety cover [1] into the recess and pivot it into position.

4.6.9 Removing an axis module

To remove an axis module from the axis system proceed in the opposite order compared to installation, see chapter "Control cabinet installation" (→ 71).

Also observe the safety notes in chapter "Electrical installation" (→ 82).

4.6.10 Installation/removal of the UHX45A



20958668555

- | | |
|---|----------------|
| [1] UHX45A | [4] Screw |
| [2] Housing of the master module MDM90A | [5] 4 cams |
| [3] Touch guard | [6] 4 recesses |

Installation

1. Remove the touch guard [3] at the housing of the master module [2]
2. Install the housing of the UHX45A [1] so that the cams [5] fit into the recesses [6] at the housing of the master module [2].
3. Push the housing of the UHX45A [1] downward until it touches the housing of the master module.
4. Tighten the screw [4]
5. Install the touch guard [3] again

Disassembly

1. Remove the touch guard [3] at the housing of the master module [2]
2. Loosen the screw [4]
3. Pull the housing of the UHX45A [1] upward and remove it toward the front

4.7 Electrical installation



⚠ DANGER

There may be dangerous voltages inside the devices and at the terminal strips after the complete axis system has been disconnected from the power supply.

Severe or fatal injuries from electric shock.

To prevent electric shocks:

- Observe the labels on the devices and the waiting times until discharge of the energy storage units before you start working on the power connections.
- If you discharge the energy storage units with the discharge unit, observe the information in chapter Discharging the energy storage units using the discharge unit.
- After maintenance work, do not operate the axis system unless you have re-mounted the safety covers, because the device has only a IP00 degree of protection with the safety cover removed.



⚠ DANGER

A leakage current > 3.5 mA can occur during operation of the MOVIDRIVE® modular application inverter.

Severe or fatal injuries from electric shock.

To avoid shock currents according to EN 61800-5-1, observe the following:

- Supply system cable < 10 mm²:
 - Route a second PE conductor with the cable cross-section of the supply system cable in parallel to the protective earth via separate terminals or use a copper PE conductor with a cable cross-section of 10 mm².
- Supply system cable 10 mm² – 16 mm²:
 - Route a copper PE conductor with the cable cross-section of the supply system cable.
- Supply system cable 16 mm² – 35 mm²:
 - Route a copper protective earth conductor with a cable cross-section of 16 mm².
- Supply system cable > 35 mm²:
 - Route a copper protective earth conductor with half the cross-section of the supply system cable.
- If an earth leakage circuit breaker is used for protection against direct and indirect contact in isolated cases, it must be universal current-sensitive (RCD type B).

NOTICE

Interchanging the poles when connecting a DC source/sink.

The devices are damaged if you interchange poles while connecting an external DC source/sink to a MDP92A and/or MDC90A.



INFORMATION

Installation with protective separation.

The application inverter meets all requirements for protective separation of power and electronics connections in accordance with EN 61800-5-1. The connected signal circuits and the DC 24 V voltage supply must meet the requirements according to SELV (**S**afety **E**xtra **L**ow **V**oltage) or PELV (**P**rotective **E**xtra **L**ow **V**oltage) to ensure protective separation. The installation must meet the requirements for protective separation.

4.7.1 General information



- Take suitable measures to prevent the motor starting up inadvertently, for example by removing the electronics terminal block X20 on the axis module. You must provide additional safety features depending on the application, to prevent possible injuries and damage to machines.
- SEW-EURODRIVE recommends using closed cable lugs for connection to the screws in order to prevent litz strands from escaping.
- SEW-EURODRIVE recommends using 10 mm-long conductor end sleeves when connecting to plug connectors.

4.7.2 Permitted voltage systems

| Information on voltage systems | Information on permissibility |
|--|---|
| TN and TT systems – voltage systems with directly grounded star point. | Use is possible without restrictions. |
| IT systems – voltage systems with non-grounded star point. | Use is only permitted adhering to specific measures. For measures, refer to chapter "Use in IT systems" (→ 84). |
| Voltage systems with grounded outer conductor. | Not permitted. |

4.7.3 Use in IT systems

To ensure IT system-capability, the terminal screw(s) shown in the following figure must be removed from all modules in the axis system.

| | |
|--|--|
|  <p>12924056459</p> | <ul style="list-style-type: none"> • All axis modules • All double-axis modules • Power supply modules up to MDP90A-0750-.. |
|  | <ul style="list-style-type: none"> • Power supply modules as of MDP90A-1100-.. |

INFORMATION



EMC limit values

No EMC limits are specified for interference emission in voltage supply systems without a grounded star point (IT systems). The effectiveness of line filters is severely limited.

4.7.4 Line fuses, fuse types

Line fuses and miniature circuit breakers are used for fusing the supply system cables of the axis block. In case of a fault, these components protect the power supply module against short-circuits. For fusing, use fuses and miniature circuit breakers with the following properties:

| Type class | Requirement |
|--|---|
| Fuses in utilization categories gL, gG | Fusing voltage \geq nominal line voltage |
| Miniature circuit breaker with characteristics B, C, D | <ul style="list-style-type: none"> Nominal miniature circuit breaker voltage \geq nominal line voltage Nominal miniature circuit breaker currents must be at least 10% above the nominal line current of the power supply module |

Adhere to the country-specific and system-specific regulations when carrying out the fusing. If required, observe the notes in chapter "Information regarding UL".

4.7.5 Line connection

For the terminal assignment for line connection of the various sizes, refer to the chapter "Terminal assignment".

For operation without line contactor, observe the specifications in the chapter "Protection of braking resistor against thermal overload".

Observe a minimum switch-off time of 10 s for the power supply module/the application inverter. Do not turn power on or off more than once per minute.

NOTICE

Non-compliance with the minimum switch-on/switch-off times.

Adhere to the specified times and intervals.

- Observe the minimum switch-off time of 10 s before switching the power back on.
 - Do not turn the power of the supply system on or off more than once per minute.
-
- The line contactor must always be located upstream of the line filter.
 - Use only line contactors of utilization category AC-3 (EN 60947-4-1) or higher.
 - Do not use the line contactor for jog mode, but only for switching the power supply module on and off. The FCB 20 "Jog" must be used for jog mode.
 - Observe the required dimensioning of the cable cross-section for UL-compliant installing.

4.7.6 Power connections


For the terminal assignment for the power connection of the various sizes, refer to the chapter "Terminal assignment" (→ 148).

To achieve degree of protection IP20 according to EN 60529 with larger modules, the connectors must be secured against touch using a protection cap. The protection caps are included in the accessory bag. The ring lugs must be insulated using a heat shrink tubing.

- Power supply modules MDP90A-0500-.. and larger, line connection X1, braking resistor connection X3
- Axis modules MDA90A-0640-.. and larger: Motor connection X2

The power connection can be designed either with 1 or 2 parallel cables.

Connection with 1 cable



20119705995


1. Attach the heat shrink tubing at the ring lug.
2. Connect the cable as depicted in the figure.
3. Attach the protection caps, see chapter "Protection caps" (→ 69).

INFORMATION



If the device is connected using 1 cable, the plastic plate in the connection block must not be removed.

Connection with 2 cables



20119708427


1. Remove the plastic plate in the connection block as depicted in the figure above.
2. Attach a heat shrink tubing at the ring lugs.
3. Connect the 2 cables as depicted in the figure above.
4. Attach the protection caps, see chapter "Protection caps" (→ 69).

4.7.7 24 V supply voltage

24 V supply voltage without master module

MOVIDRIVE® modular requires an external 24 V supply voltage. Use the following installation material for the connection:

- M4 fork-type or ring lugs with insulating collar and a cable cross-section of maximum 4 mm²,
- or
- M4 tubular cable lugs with insulating heat shrink tubing and a cable cross-section of maximum 6 mm².




14476866443

Select the cross-section of the supply cable according to the power demand of the device to be supplied. Note the additionally required power of the directly supplied 24 V brakes for CMP motors with BK or BP brake without brake control.

The maximally permitted length of the 24 V supply cable is 30 m.


The connection is established either one-sided at the power supply module, or two-sided at the power supply module and the last axis module in the axis system, see the following figure for more details.



18014414154550283

- [1] External DC 24 V voltage supply
- [2] DC 24 V fuse

24 V supply voltage with master module UHX45A/MDM90A




9007220204831115

- [1] External DC 24 V supply at X5_A
- [2] DC 24 V fuse
- [3] X5_B → X5: DC 24 V supply voltage UHX45A

Only use the connection cable included in the delivery to connect the 24 V supply of the MOVI-C CONTROLLER® advanced.

4.7.8 Connection of an axis system



27021611563769099

- [1] Connection +24 V supply voltage
- [2] PE connection
- [3] X4: DC link connection
- [4] Connection external 24 V supply voltage

For information on how to connect a DC link, refer to chapter "Installing the bus-bar" (→ 77).

Particularities of the DC link connection

Use of axis modules \leq MDA90A-1000-.. at the MDP90A-1100-.. power supply module.

If the axis modules \leq MDA90A-1000-.. are operated with a PWM frequency of 4 kHz, the following restrictions must not be observed.



INFORMATION

If axis modules \leq MDA90A-1000-.. are operated with a PWM frequency of 8 or 16 kHz on a MDP90A-1100-.. power supply module, either directly or to the right of an axis module \geq MDA90A-1400-..., the total of the nominal DC link currents I_{NDCL} of the axis modules \leq MDA90A-100-... must not exceed 153 A.

Example 1:

MDP90A-1100-..

MDA90A-0640-.. $I_{NDCL} = 64$ A

MDA90A-0640-.. $I_{NDCL} = 64$ A

MDA90A-0240-.. $\rightarrow I_{NDCL} = 24$ A

Total of $I_{NDCL} = 152$ A \rightarrow Set-up is permitted

Example 2:

MDP90A-1100-..

MDA90A-1400-..

MDA90A-0640-.. $I_{NDCL} = 64$ A

MDA90A-0640-.. $I_{NDCL} = 64$ A







MDA90A-0640-.. $I_{NDCL} = 64$ A

Total of $I_{NDCL} = 192$ A \rightarrow Set-up is not permitted

Adapter connectors of the DC link connection

To be able to establish an axis system in which modules with DC link bars of different widths are used, adapter connectors must be used at the transition from wide to narrow or narrow to wide. These adapter connectors are listed in the following table.

The necessary closing covers are included with the adapter connectors.

| From module | To module | Adapter connectors/ closing covers | Part number |
|---------------------------------|---|---|-------------|
| MDP90A-0750-.. | MDA90A-1400-.. |  | 28244052 |
| | |  | 18181716 |
| MDP90A-1100-.. | <ul style="list-style-type: none"> MDA90A-0020-.. – MDA90A-1000-.. MDD9.A-0020.. – MDD9.A-0080-.. |  | 28244079 |
| | |  | 18151884 |
| MDA90A-1400-.. – MDA90A-1800-.. | <ul style="list-style-type: none"> MDA90A-0020-.. – MDA90A-1000-.. MDD9.A-0020.. – MDD9.A-0080-.. |  | 28244060 |
| | |  | 18151884 |
| | | | 18183751 |

The closing cover 18181716 is included with the adapter connectors 28244052.

The closing cover 18151884 is included with the adapter connectors 28244079.


The closing covers 18151884 and 18183751 are included with the adapter connectors 28244060.

Adapter connectors are not included in the scope of delivery and must be ordered.

Examples of the DC link busbar with different bar widths

Example 1

Axis system with MDP90A-0750-.. power supply module, MDA90A-1400-.. axis module




23268391819

Adapter connectors with the part number 28244052 must be ordered for this arrangement.

Example 2

Axis system with MDP90A-1100-.. power supply module, MDA90A-1000-.. axis module, MDA90A-0480-..




23268386955

25953079/EN – 01/2020

Adapter connectors with the part number 28244079 must be ordered for this arrangement.

Example 3

Axis system with MDP90A-1100-.. power supply module, MDA90A-1800-.. axis module, MDA90A-1400-.., MDA90A-0640-..



23268389387


Adapter connectors with the part number 28244060 must be ordered for this arrangement.

4.7.9 Connecting a safe brake module to the DC link

The safe BST brake module is directly supplied from the DC link. For connecting the safe brake module to the DC link, a set of angled bars is available in 2 sizes.

| Axis module | Set of angled bars | Part number |
|-----------------------|--------------------|-------------|
| MDP90A-.. | Small [1] | 28249674 |
| MDA90A-0020 .. 1000.. | Small [1] | 28249674 |
| MDD9.A-0020 .. 0080.. | Small [1] | 28249674 |
| MDA90A-1400 .. 1800.. | Large [2] | 28249682 |

The angled bars are screwed to the DC link bars in the last axis module on the right side or in the power supply module on the left side. Use a M4 screw to fasten a ring cable lug.



⚠ DANGER



Dangerous voltages of up to DC 970 V can occur.

Severe or fatal injuries from electric shock.

To prevent electric shocks:

- After disconnection from the power supply, wait at least 10 minutes and ensure that there is no voltage present before you start working on the power connections.
- After maintenance work, do not operate the axis system unless you have re-mounted the safety covers, because the device has only a IP00 degree of protection with the safety cover removed.
- Use suitable cable lugs for M4 screws.
- Connect a maximum number of 16 BST brake modules to a DC link output.
- Only BST brake modules may be connected to the angled bars.

Two-row design
with MDC90A-..

For more information on the safe brake module, refer to the "BST Safety-Related Brake Module" operating instructions.

In case of a two-row design with MDC90A-0001-.. or MDC90A-0002-.. capacitor module, the safe brake modules can be connected directly to the capacitor module at terminal X4. In this case, no angled bars are required.

4.7.10 Two-row design

Design variants in a control cabinet

If, for reasons of space, the modules of an axis system cannot be set up in one row, some of the modules must be installed in a second row. There are 3 design variants for the two-row design, which are described below.

INFORMATION



Change of the degree of protection

In variant 1 and 2, the degree of protection is reduced to IP10 when the DCP34A cable set is connected.

In variant 1 and 2 the main row and auxiliary row must be connected as in variant 3 if the IP20 degree of protection is required.

For the two-row design in a control cabinet, cable sets from SEW-EURODRIVE must be used, see chapter "Cable sets and accessories" (→ 107).

Variant 1

Auxiliary row

- MDA90A-0020 – 0120-..
 - MDD9.A-0020 – 0080-..
- Maximum 8 modules


Total nominal DC link current in auxiliary row: Max. 46 A

Connection of main row and auxiliary row

- Connection via cable lug
- Cable set DCP34A
- Degree of protection IP10


Main row

- MDP90A-0250 – 1100-..
- MDR91A-0500 – 0750-..
- MDA90A-0020 – 0180-..
- MDD9.A-0020 – 0080-..



Variant 2

Auxiliary row



MDC90A-0001-50X-X-000

Use is mandatory

- MDA90A-0020 – 0120-..

Maximum 8 modules

- MDD9.A-0020 – 0080-..

- MDA90A-0160 – 0240-..

Maximum 2 modules


- MDA90A-0320-..

Maximum 1 module

Total nominal DC link current in auxiliary row: Max. 46 A

Connection of main row and auxiliary row

- Connection via cable lug
- Cable set DCP34A
- Degree of protection IP10



Main row


- MDP90A-0250 – 1100-..

- MDR91A-0500 – 0750-..

- MDA90A-0020 – 0180-..

- MDD9.A-0020 – 0080-..

Variant 3



Auxiliary row

MDC90A-0001-50X-X-000

Use is mandatory

- MDA90A-0020 – 0120-..

Maximum 8 modules

- MDD9.A-0020 – 0080-..

- MDA90A-0160 – 0240-..

Maximum 4 modules

- MDA90A-0320 – 0480-..

Maximum 2 modules

Total nominal DC link current in auxiliary row: Max. 109 A

Connection of main row and auxiliary row

- Connection via connection units
- DCP35A cable set
- With MDP90A in main row: MDP connection unit set, 28261666
- With MDR91A in the main row: MDR connection unit set, 28261674
- Degree of protection IP20

Main row

- MDP90A-0250 – 1100-..

- MDR91A-0500 – 0750-..

- MDA90A-0020 – 0180-..

- MDD9.A-0020 – 0080-..

Design variant with large distance between main row and auxiliary row

If, for reasons of space, the modules of an axis system cannot be set up in one row, some of the modules must be installed in a second row. This variant is used if there is a large distance of up to 50 m between the main row and the auxiliary row.

Applications in this design must be tested by SEW-EURODRIVE for the individual application. Contact SEW-EURODRIVE.

Auxiliary row

| | |
|-------------------------|-------------------|
| - MDC90A-0002-50X-X-000 | Use is mandatory |
| - MDA90A-0020 – 0120-.. | Maximum 8 modules |
| - MDD9.A-0020 – 0080-.. | |
| - MDA90A-0160 – 0240-.. | Maximum 4 modules |
| - MDD9.A-0320 – 0480-.. | Maximum 2 modules |

Total DC link current in auxiliary row: Max. 109 A

Connection of main row and auxiliary row

- Connection via cable lug or connection unit
- Cable or conductor rail up to 50 m
- Maximum cable cross section with cable lug: 16 mm²
- Maximum cable cross section to connection unit: 35 mm²
- Degree of protection: IP10 or IP20

Optional: With MDP.. in the main row: Connection unit MDP, part number: 28261666


Optional: With MDR.. in the main row: Connection unit MDR, part number: 282616746

Main row

- MDP90A-0250 – 1100-..
- MDR91A-0500 – 0750-..
- MDA90A-0020 – 0180-..
- MDD9.A-0020 – 0080-..

The following measures must be checked, depending on the system configuration:

- Use of DC link chokes in the connection from the main row to the auxiliary row.
- Adapted regulator settings in the CFC control mode.



Installation

A MOVIDRIVE® modular axis system is designed so that the axis modules must be mounted in descending order of the nominal DC link current.


If the width of the axis system is wider than the available control cabinet width, it is possible to install some of the modules in a second row (auxiliary row).

The first row is connected with the second row (DC link connection) using cables. The cable length is predetermined. The distance between the upper edge of the main row and the upper edge of the auxiliary row is 670 mm.


The power supply modules are selected in the same way as with the one-row design depending on the connected axis modules in the main row and auxiliary row.

The following requirements must be met for installation in a control cabinet:

- Ensure a clearance of at least 40 mm left of the axis blocks for routing the DC link connection and the motor cables.
- You must route the motor cables on the left side of the axis blocks.
- You must route the DC link connection on the left side of the axis blocks. The DC link connection must be secured using suitable measures, such as a clamp [1], to prevent mechanical oscillation. Consider any oscillations and vibrations, especially in mobile control cabinets.



Connection to the DC link connection




28834999563

- [1] Main row
- [2] Auxiliary row

Connection main row and auxiliary row with DPC34A cable set


Use the DCP34A cable set for the connection of the main row and auxiliary row.

- The cables are connected to the DC link with cable lugs.




28990918795


- The cable lugs must be bent down approx. 7°.



28990911627




Connection main row and auxiliary row with DCP35A cable set and connection unit



28910504203

- Use the screws [2] to screw the 3 conductor rails [1] to the insulator [3]. The tightening torque is 2.5 – 3 Nm.

- The DC link connections U_z+ and U_z- must be twisted 3 times, see the following figure.



28911898379

- Use the screws [5] to screw the 3 prefabricated DC link connections [4] to the conductor rails [1]. The tightening torque is 3 – 4 Nm.

The steps described above must be performed at both insulators.

Mount the preinstalled insulators to the axis module as follows:

- Push the conductor rails [1] **under** the DC link bars [6] of the module and use the screws [7] to connect them.
- Re-install all covers.

Cable sets and accessories

DCP34A cable set, part number: 28261631

| | |
|---------------|--|
| Cables | 1× PVC conductor H07V-K, color: black, identification: Uz- |
| | 1× PVC conductor H07V-K, color: black, identification: Uz+ |
| | 1× PVC conductor H07V-K, color: green/yellow, identification: PE |
| Cross section | 16 mm ² |
| Connection | Crimping cable lug M6 |
| Length | Approx. 1150 mm |


DCP35A cable set, part number: 28261658

| | |
|---------------|--|
| Cables | 1× PVC conductor H07V-K, color: black, identification: Uz- |
| | 1× PVC conductor H07V-K, color: black, identification: Uz+ |
| | 1× PVC conductor H07V-K, color: green/yellow, identification: PE |
| Cross section | 35 mm ² |
| Connection | Crimping cable lug M8 |
| Length | Approx. 1000 mm |

Connection units for:

| | |
|------------|----------|
| MDP90A-... | 28261666 |
| MDR92A-... | 28261674 |

Maximum permitted distance of the module rows




28834999563

- 1 Main row
- 2 Auxiliary row

4.7.11 Installing touch guards and closing covers


All modules of the application inverter are equipped with touch guards [1] and the first and last modules of the axis system have closing covers [2]; see the following figure. If the axis system contains a master module, the closing cover [2] must be attached only to the final module in the axis system.

With master
module



20918974091

Without master
module



18014412466136331

- [1] Touch guard
- [2] Closing cover

Install all touch guards [1] after installation work.

1. Insert the closing cover [2] into the touch guard [1].
2. Install the touch guard [1] on the respective module. Insert the screws and tighten them securely with the specified tightening torque.

Install one closing cover [2] each on the first and final modules of the axis system. The closing covers prevent any contact with the DC link. Two closing covers are included with each power supply module.

▲ WARNING

Missing touch guards and closing covers
Severe or fatal injuries from electric shock

- Install all touch guards.
- Install closing covers on the first and final module in the axis system.



4.7.12 Motor output

NOTICE

Connecting capacitive loads to an axis module.

Destruction of the axis module.

- Only connect ohmic/inductive loads (motors).
- Never connect capacitive loads.

4.7.13 Output brake chopper

NOTICE

Connecting capacitive or inductive loads to the power supply module.

Destruction of the power supply module.

- Only connect ohmic loads (braking resistors).
- Never connect capacitive or inductive loads.

4.7.14 Temperature evaluation of the motor

The temperature evaluation can be connected in 2 ways:

- The encoder cable includes the cables of the temperature evaluation.
- The temperature evaluation is connected via terminal X10.

**▲ WARNING**

Dangerous contact voltages at the signal terminals of the application inverter when connecting the wrong temperature sensors.

Severe or fatal injuries from electric shock.

- Connect only temperature sensors with protective separation from the motor winding to the temperature evaluation. Otherwise, the requirements for protective separation are not met. Dangerous contact voltages may occur at the signal terminals of the application inverter via the signal electronics in case of an error.

4.7.15 Brake output

**INFORMATION**

- If the brake connection and the motor connection are combined in one power cable, the brake cable must be shielded separately. The shielding of the power cable and the brake cable must be connected to the motor and application inverter over a large area.
- SEW-EURODRIVE recommends to also use a shielded brake cable for separate brake cable routing.
- Note the different project planning criteria to determine the length of brake cable and motor cable.

4.7.16 Inputs/outputs

NOTICE

Damage to the digital inputs and digital outputs.

The digital inputs and digital outputs are not electrically isolated. Incorrectly applied voltages can damage the digital inputs and digital outputs.

- Do not apply external voltages to the digital outputs.
 - The digital inputs and outputs are dimensioned according to IEC 61131-2.
-
- The cable length must not exceed 30 m.
 - Cables outside the control cabinet must be shielded.

4.7.17 System bus EtherCAT®/SBus^{PLUS}

For connecting the EtherCAT®/SBus^{PLUS} system bus, SEW-EURODRIVE recommends using only prefabricated cables from SEW-EURODRIVE.

NOTICE

Use of wrong cables

Damage to the application inverter

Only 4-pole cables are permitted to be used as system bus cables [2]. If an 8-pole cable is used, malfunctions or failures may occur at the connected devices.


INFORMATION



The mounting plates on which the axis systems are mounted must have a sufficiently large ground connection, e.g., a ground strap.

System bus and module bus cabling

Example of a system bus and module bus cabling



9007217271733643

- [1] Module bus cable: EtherCAT®/SBus^{PLUS} and internal signals, 8-pole, color: anthracite
- [2] System bus cable: EtherCAT®/SBus^{PLUS}, 4-pole, color: light gray
- [3] MOVI-C® CONTROLLER power UHX85A
- [4] MOVIDRIVE® modular
- [5] MOVIDRIVE® system/technology with DC link connection
- [6] MOVIDRIVE® system/technology
- [7] Other EtherCAT® stations at the EtherCAT®/SBus^{PLUS}

Correct cabling

Module bus cable

In the case of MOVIDRIVE® modular, the 8-core module bus cable connects the power supply module to the first axis module and the axis modules to one another; see figure (→ 112).

In the case of MOVIDRIVE® modular, in addition to the system bus communication, the module bus is routed in the cable for information inside the device. The module bus cable is delivered in the length required as part of the accessories for the axis modules.


The connectors of the module bus cables are red and black to simplify correct attachment of the cables; see the following figure.

- The black connectors must be plugged into the bus input X30 IN.
- The red connectors must be plugged into the bus output X30 OUT.

System bus cable

The 4-pole system bus cable is used between automation components; see figure (→ 112). Some of these components are listed here as examples:

- MOVI-C® CONTROLLER
- MOVIDRIVE® modular/system application inverter
- PC with MOVISUITE® engineering software
- MOVI-PLC® I/O system
- Other EtherCAT® stations at the EtherCAT®/SBus^{PLUS}



[1] MOVIDRIVE® modular

[2] MOVIDRIVE® system

4.7.18 Encoder

The encoder cable may include the cables of the temperature evaluation.

For information on the pin assignment, refer to chapter "Terminal assignment at MDA single-axis module" (→ 151).



⚠ WARNING

Dangerous contact voltages at the terminals of the application inverter when connecting the wrong temperature sensors.


Severe or fatal injuries from electric shock.

- Connect only temperature sensors with protective separation from the motor winding to the temperature evaluation. Otherwise, the requirements for protective separation are not met. Dangerous contact voltages may occur at the terminals of the application inverter via the signal electronics in case of a fault.

Installation notes for encoder connection

Encoder cable

- Use shielded cables with twisted pair cores. Connect the shield over a wide area at both ends:
 - At the encoder in the cable gland or in the encoder plug,
 - At the application inverter in the housing of the D-sub connector.



13887834891

- Route the encoder cable separately from the power cables.
- Connect the shield on the inverter end in the housing of the D-sub connector over a large area.

On the encoder/resolver

- To ensure a flawless shield connection, an EMC screw fitting must be used for the cable entry of the signal line.
- For drives with a plug connector, connect the shield on the encoder plug.

Prefabricated cables

SEW-EURODRIVE offers prefabricated cables for connecting encoders. SEW-EURODRIVE recommends to use these prefabricated cables.

Encoder connection/cable lengths

| Connection/encoder | Cable length |
|---------------------------|--------------|
| HTL encoder ES7C and EG7C | 300 m |
| Standard HTL encoder | 200 m |
| Other encoders | 100 m |



INFORMATION

The maximum cable length might be reduced depending on the technical data of the respective encoder. Observe the manufacturer specifications.

4.7.19 Notes on MOVILINK® DDI


INFORMATION



You must only remove the MOVILINK® DDI connector if the 24 V voltage supply is switched off or if standby operation is active.

Removing the connector

When removing the MOVILINK® DDI connector X16, note that the latch [1] at the connector must be pushed before removing the connector, see figure.



30534546059

Maximum line length


The maximum cable length for the coaxial cable is 200 m.

4.7.20 Self-assembled encoder cables

If self-assembled encoder cables are used, make sure to dimension the connector and the route the cable in a way that the safety cover of the application inverter can be closed.

The maximum permitted width of the connector is 16 mm.

The maximum permitted height of the connector up to the highest point of the cable routing is 46 mm.



14858590859

Minimum requirements for encoder cables

Make sure that self-assembled cables fulfill the following requirements:

- Cross section of voltage supply cable:
 - At least 0.25 mm² for cable lengths up to 50 m.
 - At least 0.5 mm² for cable lengths up to 100 m.
- Cross section of the signal wire:
 - At least 0.25 mm².
- Capacitance per unit length:
 - Maximum 70 pF/m – core/core.
 - Maximum 120 pF/m – core/shield.
- The cable must be shielded.
- Differential signals must be routed via twisted wires e.g. Data+ and Data-.

4.8 Installing options and accessories

4.8.1 Installing a card

Observe the safety notes in chapter "Electrical installation" (→ 82).

INFORMATION




Requirements for installation.

Cards can only be installed in axis modules suitable for option cards.


For information on which option card can be installed in which slot, refer to chapter "Card slots" (→ 51).

1. Disconnect the application inverter from the power supply. Disconnect the DC 24 V supply and the line voltage.
2. Ensure electrostatic discharge with suitable measures before starting the work. Suitable measures for equipotential bonding are e.g. the use of a discharge strap or wearing conductive shoes.
3. Remove the safety cover [1] from the front of the application inverter.



27021611749935499

4. Remove the plastic cover [1] at the card slot.



18014412495192075


INFORMATION



Handling the card


Hold the card by its edges only.

5. Take the card [1] and insert it in the slot with slight pressure.



18014412495196939

6. Screw in the card with the specified tightening torque (→ 57).



18014412495199371

7. Install the safety cover at the front of the application inverter.

4.8.2 CIO21A and CID21A input/output card

INFORMATION



Technical data of the option cards

For technical data and a detailed description of the encoder interface, refer to chapter "Technical data of the option cards".

Voltage supply

The I/O cards are supplied by the basic unit via the 24 V voltage supply.

Short-circuit behavior of digital outputs

The digital outputs are short-circuit-proof.

As soon as the short circuit is remedied, the target output voltage is output, meaning the output does not switch off.

Short circuit behavior of analog outputs

The analog outputs are short-circuit-proof.

In the event of a short circuit, the output current is limited to a maximum value of 30 mA. The short circuit current is not pulsating.

As soon as the short circuit is remedied, the target output voltage is output, meaning the output does not switch off.

Connecting inductive loads at digital outputs

The digital outputs can switch inductive loads up to an energy content of maximum 500 mJ 10 times per seconds at the maximum without any additional measures. For larger energy contents an external protective element (freewheeling diode) is required.

Connecting 2 digital outputs in parallel

Connecting digital outputs in parallel is possible. The possible output current is doubled. Ensure identical parameterization of the digital outputs.

Cable lengths

The maximum cable length of connections on the inputs and outputs is 30 m.






INFORMATION



Shielding the cables.



Cables outside the control cabinet must be shielded.

C1021A terminal assignment

| | Terminal | Conne- ction | Short description | |
|--|---|-----------------|--|---|
|  |  | | S50/1 on: Current input active for AI2x S50/2 on: Current input active for AI3x S50/1 off ¹⁾ : Voltage input active for AI2x S50/2 off ¹⁾ : Voltage input active for AI3x | |
| |  | X50:1 | REF1 | +10 V reference voltage output |
| | | X50:2 | AI21 | Analog current and voltage input |
| | | X50:3 | AI22 | Analog current and voltage input, reference for AI21 |
| | | X50:4 | GND | Reference potential |
| | | X50:5 | AI31 | Analog current and voltage input |
| | | X50:6 | AI32 | Analog current and voltage input, reference for AI31 |
| | | X50:7 | GND | Reference potential |
| | | X50:8 | REF2 | -10 V reference voltage output |
| |  | X51:1 | AOV2 | Analog voltage output 1, freely programmable |
| | | X51:2 | AOC2 | Analog current output 1, freely programmable |
| | | X51:3 | GND | Reference potential for the outputs AOV2 and AOC2 |
| | | X51:4 | AOV3 | Analog voltage output 2, freely programmable |
| | | X51:5 | AOC3 | Analog current output 2, freely programmable |
| | | X51:6 | GND | Reference potential for the outputs AOV3 and AOC3 |
| |  | X52:1 | DI10 | Digital input 1, freely programmable |
| | | X52:2 | DI11 | Digital input 2, freely programmable |
| | | X52:3 | DI12 | Digital input 3, freely programmable |
| | | X52:4 | DI13 | Digital input 4, freely programmable |
| | | X52:5 | GND | Reference potential for the digital inputs DI10 – DI13 |
| | | X52:6 | DO10 | Digital output 1, freely programmable |
| | | X52:7 | DO11 | Digital output 2, freely programmable |
| | | X52:8 | DO12 | Digital output 3, freely programmable |
| | | X52:9 | DO13 | Digital output 4, freely programmable |
| | | X52:10 | GND | Reference potential for the digital outputs DO10 – DO13 |

1) Delivery state

CID21A terminal assignment

| | Terminal | | Conne- ction | Short description |
|--|---|--------|-----------------|---|
|  |  | X52:1 | DI10 | Digital input 1, freely programmable |
| | | X52:2 | DI11 | Digital input 2, freely programmable |
| | | X52:3 | DI12 | Digital input 3, freely programmable |
| | | X52:4 | DI13 | Digital input 4, freely programmable |
| | | X52:5 | GND | Reference potential for the digital inputs DI10 – DI13 |
| | | X52:6 | DO10 | Digital output 1, freely programmable |
| | | X52:7 | DO11 | Digital output 2, freely programmable |
| | | X52:8 | DO12 | Digital output 3, freely programmable |
| | | X52:9 | DO13 | Digital output 4, freely programmable |
| | | X52:10 | GND | Reference potential for the digital outputs DO10 – DO13 |

4.8.3 CES11A multi-encoder card

INFORMATION



Technical data of the cards

For technical data and a detailed description of the encoder interface, refer to the chapter "Technical data of the cards".

Overview of functions

The CES11A multi-encoder card expands the functionality of the application inverter in a way that an additional encoder can be evaluated. The encoder connected to the CES11A multi-encoder card can be used as motor encoder or external encoder.

Supported encoder types

The following encoder types can be evaluated by the CES11A multi-encoder card:

| |
|--|
| HTL 12/24 V (differential) |
| TTL (differential) |
| RS422 |
| sin/cos 1 V _{SS} (differential) |
| HIPERFACE® with sin/cos signals 1 V _{SS} |
| SEW encoder (RS485) with sin/cos signals 1 V _{SS} , e.g. AS7W, AG7W |
| EnDat 2.1 with sin/cos signals 1 V _{SS} |
| SSI encoder with/without sin/cos signals 1 V _{SS} |
| CANopen encoder |

Encoder connection/cable lengths


| Connection/encoder | Cable length |
|---------------------------|--------------|
| HTL encoder ES7C and EG7C | 300 m |
| Standard HTL encoder | 200 m |
| Other encoders | 100 m |

INFORMATION




The maximum cable length might be reduced depending on the technical data of the respective encoder. Observe the manufacturer specifications.

Terminal assignment of TTL, HTL, sin/cos encoder


| Card | Terminal | Connection | Brief description |
|---|----------|---------------------------------|--|
|  | X17:1 | A (cos+) (K1) | Signal track A (cos+) (K1) |
| | X17:2 | B (sin+) (K2) | Signal track B (sin+) (K2) |
| | X17:3 | C | Signal track C (K0) |
| | X17:4 | DATA+ ¹⁾ | Data cable for electronic nameplate |
| | X17:5 | Reserved | – |
| | X17:6 | -TEMP_M | Motor temperature evaluation |
| | X17:7 | Reserved | – |
| | X17:8 | GND | Reference potential |
| | X17:9 | \bar{A} (cos-) ($\bar{K1}$) | Negated signal track \bar{A} (cos-) ($\bar{K1}$) |
| | X17:10 | \bar{B} (sin-) ($\bar{K2}$) | Negated signal track \bar{B} (sin-) ($\bar{K2}$) |
| | X17:11 | \bar{C} | Negated signal track \bar{C} ($\bar{K0}$) |
| | X17:12 | DATA- ¹⁾ | Data cable for electronic nameplate |
| | X17:13 | U _{S24VG} | Encoder supply 24 V |
| | X17:14 | +TEMP_M | Motor temperature evaluation |
| | X17:15 | U _{S12VG} | Encoder supply 12 V |

1) For encoders from SEW-EURODRIVE with electronic nameplate of type E.7S


Terminal assignment HIPERFACE® and SEW-EURODRIVE encoder (RS485)

| Card | Terminal | Connection | Brief description |
|---|----------|---------------------------------|--|
|  | X17:1 | A (cos+) (K1) | Signal track A (cos+) (K1) |
| | X17:2 | B (sin+) (K2) | Signal track B (sin+) (K2) |
| | X17:3 | Reserved | – |
| | X17:4 | DATA+ | Data line |
| | X17:5 | Reserved | – |
| | X17:6 | -TEMP_M | Motor temperature evaluation |
| | X17:7 | Reserved | – |
| | X17:8 | GND | Reference potential |
| | X17:9 | \bar{A} (cos-) ($\bar{K1}$) | Negated signal track \bar{A} (cos-) ($\bar{K1}$) |
| | X17:10 | \bar{B} (sin-) ($\bar{K2}$) | Negated signal track \bar{B} (sin-) ($\bar{K2}$) |
| | X17:11 | Reserved | – |
| | X17:12 | DATA- | Data line |
| | X17:13 | U _{S24VG} | Encoder supply 24 V |
| | X17:14 | +TEMP_M | Motor temperature evaluation |
| | X17:15 | U _{S12VG} | Encoder supply 12 V |


Terminal assignment EnDat encoder

| Card | Terminal | Connection | Brief description |
|---|----------|--------------------|---------------------------------------|
|  | X17:1 | A (cos+) | Signal track A (cos+) |
| | X17:2 | B (sin+) | Signal track B (sin+) |
| | X17:3 | PULSE+ | Clock signal |
| | X17:4 | DATA+ | Data line |
| | X17:5 | Reserved | – |
| | X17:6 | -TEMP_M | Motor temperature evaluation |
| | X17:7 | Reserved | – |
| | X17:8 | GND | Reference potential |
| | X17:9 | \bar{A} (cos-) | Negated signal track \bar{A} (cos-) |
| | X17:10 | \bar{B} (sin-) | Negated signal track \bar{B} (sin-) |
| | X17:11 | PULSE- | Clock signal |
| | X17:12 | DATA- | Data line |
| | X17:13 | U _{S24VG} | Encoder supply 24 V |
| | X17:14 | +TEMP_M | – |
| | X17:15 | U _{S12VG} | Encoder supply 12 V |


Terminal assignment SSI encoder

| Card | Terminal | Connection | Brief description |
|---|----------|--------------------|------------------------------|
|  | X17:1 | Reserved | – |
| | X17:2 | Reserved | – |
| | X17:3 | PULSE+ | Clock signal |
| | X17:4 | DATA+ | Data line RS485 |
| | X17:5 | Reserved | – |
| | X17:6 | -TEMP_M | Motor temperature evaluation |
| | X17:7 | Reserved | – |
| | X17:8 | GND | Reference potential |
| | X17:9 | Reserved | – |
| | X17:10 | Reserved | – |
| | X17:11 | PULSE- | Clock signal |
| | X17:12 | DATA- | Data line |
| | X17:13 | V _{S24VG} | 24 V encoder supply |
| | X17:14 | +TEMP_M | Motor temperature evaluation |
| | X17:15 | V _{S12VG} | 12 V encoder supply |

Terminal assignment SSI and sin/cos combination encoders

| Card | Terminal | Connection | Brief description |
|---|----------|--------------------|---------------------------------------|
|  | X17:1 | A (cos+) | Signal track A (cos+) |
| | X17:2 | B (sin+) | Signal track B (sin+) |
| | X17:3 | PULSE+ | Clock signal |
| | X17:4 | DATA+ | Data line |
| | X17:5 | Reserved | – |
| | X17:6 | -TEMP_M | Motor temperature evaluation |
| | X17:7 | Reserved | – |
| | X17:8 | GND | Reference potential |
| | X17:9 | \bar{A} (cos-) | Negated signal track \bar{A} (cos-) |
| | X17:10 | \bar{B} (sin-) | Negated signal track \bar{B} (sin-) |
| | X17:11 | PULSE- | Clock signal |
| | X17:12 | DATA- | Data line |
| | X17:13 | U _{S24VG} | Encoder supply 24 V |
| | X17:14 | +TEMP_M | Motor temperature evaluation |
| | X17:15 | U _{S12VG} | Encoder supply 12 V |

Terminal assignment CANopen encoder

| Card | Terminal | Connection | Brief description |
|---|----------|--------------------|------------------------------|
|  | X17:1 | Reserved | – |
| | X17:2 | Reserved | – |
| | X17:3 | Reserved | – |
| | X17:4 | CAN_H | CAN high data cable |
| | X17:5 | Reserved | – |
| | X17:6 | -TEMP_M | Motor temperature evaluation |
| | X17:7 | Reserved | – |
| | X17:8 | GND | Reference potential |
| | X17:9 | Reserved | – |
| | X17:10 | Reserved | – |
| | X17:11 | Reserved | – |
| | X17:12 | CAN_L | CAN low data cable |
| | X17:13 | V _{S24VG} | 24 V encoder supply |
| | X17:14 | +TEMP_M | Motor temperature evaluation |
| | X17:15 | V _{S12VG} | 12 V encoder supply |

4.8.4 Safety cards CS..A

For detailed information on the safety card CS..A, refer to the manual "MOVISAFE® CS..A safety card".

4.9 Braking resistors

The supply cables to the braking resistors carry a high pulsed DC voltage during nominal operation.



⚠ DANGER

Dangerous pulsed DC voltage of up to 970 V.

Severe or fatal injuries from electric shock.

To prevent electric shocks:

- Disconnect the application inverter from the power supply and wait 10 minutes before working on a braking resistor or its supply cables.
- Never operate the application inverter without touch guards and installed closing covers.

Braking resistors become very hot during operation.



⚠ WARNING

The surfaces of the braking resistors will reach temperatures of up to 250 °C when the braking resistors are loaded with the nominal power.

Severe burns.

To prevent burns:

- Do not touch any hot braking resistor.
- Select a suitable installation location for the braking resistors such as the control cabinet roof.

4.9.1 Permitted installation of braking resistors

The surfaces of the resistors become very hot if loaded with nominal power. Make sure that you select an installation site that will accommodate these high temperatures. For this reason, braking resistors are usually mounted on the control cabinet roof.



NOTICE

Braking resistors overheat.


Non-permissible installation might lead to an accumulation of heat in the braking resistor due to reduced convection. A tripping temperature contact or an overheated braking resistor can lead to a system standstill.

Adhere to the following minimum clearances:

- 200 mm to adjacent components and walls
- 300 mm to above components/ceilings

Observe the following permitted mounting positions when installing the resistors:


- Grid resistor



18014417021942155


The brake resistor BW003-420-T may be used only in position 1.

- Wire resistor



18512455307

- Flat type resistor



18512457739

4.9.2 Thermal protection with flat-type resistors

In the documented assignment of inverter and flat-type resistor, flat-type resistors have a thermal protection (non-replaceable fuse) that interrupts the current circuit in the event of overload.

4.9.3 Protection against thermal overload of the braking resistor

INFORMATION




Guards for power supply modules with a nominal power of 50 kW and 75 kW

It is not permitted to separate the connection between power supply module and braking resistor. Guards, such as fuses or miniature circuit breakers are not permitted.

External thermal circuit breaker TCB

Power supply module MDP90A 10 kW, 25 kW, 110 kW

If an external TCB thermal circuit breaker is used, the following connection applies.



[1] TCB thermal circuit breaker

[2] Braking resistor

INFORMATION



The polarity of the connections 5 (+R) and 2 (-R) must be strictly adhered to during connection of the TCB circuit breaker to the inverter.


- If the thermal circuit breaker trips, the signal contact is set (23-24 connection is opened) and evaluated in the power supply module.
- The connection between power supply module and braking resistor is disconnected.
- This does not require a response by the PLC.
- It is not required to disconnect the supply system connection with an external switching device.
- If the thermal circuit breaker trips, the power supply module switches all axis modules to "Output stage inhibited".

- Set the control knob of the thermal circuit breaker TCB to the tripping current I_F of the connected braking resistor. Set the scaling 40 °C.
- After all cables are connected, the 3 upper screw holes must be covered with 3 touch guard caps. The touch guard caps are included in the delivery.

Internal temperature switch -T

MDP90A-0100-.. power supply module

If an BW...-T braking resistor with internal temperature switch is used with a 10 kW power supply module, there are 3 possible connections.



[1] Line contactor

[2] Braking resistor

Note that the reference potential GND of the digital input control must be the same as the reference potential of the application inverter when connection 1 is used.

- Connection 1
 - If the thermal circuit breaker trips, the signal in the power supply module and in the PLC is evaluated.
 - If the thermal circuit breaker trips, the PLC must interrupt the power supply.
 - If the thermal circuit breaker trips, the power supply module switches all axis modules to "Output stage inhibited".
- Connection 2
 - If the thermal circuit breaker trips, the signal is evaluated only in the PLC.
 - If the thermal circuit breaker trips, the PLC must interrupt the power supply.
 - If the thermal circuit breaker trips, there is no response in the power supply module and the axis modules.
 - With connection 2, it is possible that the PLC finishes the current travel cycle although the thermal circuit breaker has tripped. Only then is the power supply disconnected. In this case, the residual braking energy $W_{\text{Rest}} = P_{\text{BRnom}} \times 20 \text{ s}$ must not be exceeded.
- Connection 3
 - If the thermal circuit breaker trips, the signal directly affects the line contactor.
 - This does not require a response by the PLC.

- If the thermal circuit breaker trips, there is no response in the power supply module and the axis modules.




INFORMATION

The braking resistor integrated in the MDP90A-0100-...-C00 power supply module is protected by the thermal protection.

MDP90A-0250, 0500, 0750, 1100 power supply module

If an BW...-T braking resistor with internal temperature switch is used with a 25 – 110 kW power supply module, there are 3 possible connections.



[1] Line contactor

[2] Braking resistor


- Connection 1
 - If the thermal circuit breaker trips, the signal in the power supply module is evaluated.
 - This does not require a response by the PLC.
 - It is not required to disconnect the supply system connection with an external switching device.
 - If the thermal circuit breaker trips, the power supply module switches all axis modules to "Output stage inhibited".
- Connection 2
 - If the thermal circuit breaker trips, the signal is evaluated only in the PLC.
 - If the thermal circuit breaker trips, the PLC must interrupt the power supply.
 - If the thermal circuit breaker trips, there is no response in the power supply module and the axis modules.
 - With connection 2, it is possible that the PLC finishes the current travel cycle although the thermal circuit breaker has tripped. Only then is the power supply disconnected. In this case, the residual braking energy $W_{Rest} = P_{BRnom} \times 20 \text{ s}$ must not be exceeded.
- Connection 3
 - If the thermal circuit breaker trips, the signal directly affects the line contactor.
 - This does not require a response by the PLC.

- If the thermal circuit breaker trips, there is no direct response in the application inverter.

External bimetallic relay

MDP90A-0100-.. power supply module

If an external bimetallic relay is used with a 10 kW power supply module, there are 3 possible connections.



[1] Line contactor

[2] Braking resistor


Note that the reference potential GND of the digital input control must be the same as the reference potential of the application inverter when connection 1 is used.

- Connection 1
 - If the thermal circuit breaker trips, the signal in the power supply module and in the PLC is evaluated.
 - If the thermal circuit breaker trips, the PLC must interrupt the power supply.
 - If the thermal circuit breaker trips, the power supply module switches all axis modules to "Output stage inhibited".
- Connection 2
 - If the thermal circuit breaker trips, the signal is evaluated only in the PLC.
 - If the thermal circuit breaker trips, the PLC must interrupt the power supply.
 - If the thermal circuit breaker trips, there is no response in the power supply module and the axis modules.
 - With connection 2, it is possible that the PLC finishes the current travel cycle although the thermal circuit breaker has tripped. Only then is the power supply disconnected. In this case, the residual braking energy $W_{Rest} = P_{BRnom} \times 20 \text{ s}$ must not be exceeded.
- Connection 3
 - If the thermal circuit breaker trips, the signal directly affects the line contactor.

- This does not require a response by the PLC.
- If the thermal circuit breaker trips, there is no response in the power supply module and the axis modules.

MDP90A-0250, 0500, 0750, 1100 power supply module

If an external bimetallic relay is used with a 25 – 110 kW power supply module, there are 3 possible connections.



[1] Line contactor

[2] Braking resistor

- Connection 1
 - If the thermal circuit breaker trips, the signal in the power supply module is evaluated.
 - This does not require a response by the PLC.
 - It is not required to disconnect the supply system connection with an external switching device.
 - If the thermal circuit breaker trips, the power supply module switches all axis modules to "Output stage inhibited".
- Connection 2
 - If the thermal circuit breaker trips, the signal is evaluated only in the PLC.
 - If the thermal circuit breaker trips, the PLC must interrupt the power supply.
 - If the thermal circuit breaker trips, there is no response in the power supply module and the axis modules.
 - With connection 2, it is possible that the PLC finishes the current travel cycle although the thermal circuit breaker has tripped. Only then is the power supply disconnected. In this case, the residual braking energy $W_{Rest} = P_{BRnom} \times 20 \text{ s}$ must not be exceeded.
- Connection 3
 - If the thermal circuit breaker trips, the signal directly affects the line contactor.
 - This does not require a response by the PLC.

- If the thermal circuit breaker trips, there is no direct response in the application inverter.

4.10 Line choke


Install the line choke close to the application inverter but outside the minimum clearance for cooling. The line choke must not be heated by the exhaust air of the application inverter.

- Install the line choke before the line filter.
- The connection cable between line choke and line filter does not have to be shielded.
- Limit the length of the cable between the line choke and the line filter to the absolute minimum needed.

4.11 Line filter

- Install the line filter close to the power supply module/inverter but outside the minimum clearance for cooling. The line filter must not be heated by the exhaust air of the power supply module/inverter.
- Do not wire any other consumers between the line filter and the power supply module/inverter.
- The connection cable between line filter and power supply module/inverter does not have to be shielded.
- Limit the length of the cable between the line filter and the power supply module/inverter to the absolute minimum needed.
- Do not switch between the line filter and power supply module/inverter.

4.12 EMC-compliant installation



19501899787

25953079/EN – 01/2020

- | | |
|---|--|
| [1] Zinc-coated mounting plate | [9] Braking resistor performance |
| [2] Line filter | [10] Motor cable |
| [3] MDP power supply module | [11] Power shield plate at the axis module |
| [4] PE busbar | [12] Brake cable |
| [5] HF connection of PE busbar/mounting plate | [13] Grounding clamp |
| [6] Supply system cable | [15] Electronics shield plate |
| [7] Power shield plate at the power supply module | [16] HF connection |
| [8] Braking resistor | |

The information in this chapter will help you to optimize the system in regard of electromagnetic compatibility, or to eliminate already existing EMC interferences.

The notes in this chapter are not legal regulations; they are merely recommendations for improving the electromagnetic compatibility of your plant.

For further notes on EMC-compliant installation, refer to the publication Drive Engineering – Practical Implementation, edition "EMC in Drive Engineering – Basic Theoretical Principles – EMC-Compliant Installation in Practice".

4.12.1 Control cabinet

Use control cabinets with electrically conductive (galvanized) mounting plates. If several mounting plates are used, connect them in such a way that they are conductive over a large area.

Mount the line filter and inverter on a shared mounting plate if possible. Make sure they are connected over a large area and with good conductivity.

4.12.2 HF equipotential bonding in the system

Make sure that there is a suitable equipotential bonding between the system, the control cabinet, the machine structure, the cable ducts, and the drives.

Connect the individual sections together in an HF-capable manner.

From an electrical safety perspective, the PE busbar is the star point. The PE connection does not replace either the HF grounding or the shielding.

In terms of EMC, it is advantageous if the mounting plate is used as a star point with respect to HF equipotential bonding.

Perform the following measures for a suitable HF equipotential bonding:

- Connect the PE busbar to the mounting plate in an HF-compatible manner.
- Connect the sheet metal cable ducts to the control cabinet in an HF-compatible manner.
- Connect the cable ducts to the mounting plate in the control cabinet using an HF braid.
- Connect the parts of the sheet metal cable ducts together in an HF-compatible manner.
- Connect the sheet metal cable ducts to the gearmotor in an HF-compatible manner.

4.12.3 Cable installation

Route the power cables, such as the motor cable and the brake cable, separately from the supply system cable and the control cables.

Route all cables as closely to the reference potential as possible, e.g. the mounting plate.

Keep all cables as short as possible. Avoid spare loops.

4.12.4 Supply system cable connection

The supply system cable can be connected to the line choke and/or line filter using twisted unshielded single conductors or using unshielded cables.

If necessary, shielded cables may improve EMC.


4.12.5 Line filter connection

Limit the length of the connection lead between the line filter and the inverter to the absolute minimum needed.

You must never route filtered and unfiltered cables together. For this reason, route incoming and outgoing line filter cables separately.

4.12.6 Braking resistor connection

For connecting braking resistors, use 2 closely twisted conductors or a shielded power cable. Connect the braided shields of shielded cables over the entire circumference. Use the designated shield plates at the basic device to connect the shield.




19500969867

4.12.7 Motor and brake connection

Only use shielded motor cables. Connect the braided shield of the motor cable at both ends over its entire circumference to the power shield plate at the inverter.

Shielded cables must be selected for the brake supply. The shield of the brake cable can be connected to the power shield plate at the inverter.

In case motor cable and brake cable are combined in a shared cable, the cable must have an inner shield separating the brake cable from the motor conductors. The cables also possess an overall shield.



9007218755713291


SEW-EURODRIVE recommends to use prefabricated cables.

In case of especially high requirements, an additional connection point for the shield is recommended. To limit the emitted interference the motor shield can additionally be grounded to the control cabinet outlet using commercial installation materials (grounding clamps or EMC screw fittings).

4.12.8 Control cable connection

The digital inputs can be connected using an unshielded single conductor. Shielded cables increase the EMC. Use the designated shield plates to connect the shield.

For routing outside of the control cabinet shielded cables must be used.



19500974731

4.12.9 Encoder connection

SEW-EURODRIVE recommends the use of prefabricated encoder cables.

The shield of prefabricated cables from SEW-EURODRIVE is connected via the connector.

4.12.10 Shielding connection

Ensure that there is an HF-compatible shield connection, e.g. by using grounding clamps or EMC cable glands, so that the braided shield has a large connection surface.

4.13 Terminal assignment



INFORMATION

Reference potentials inside the device:

The device internal reference potential is designated as GND in the following table.

All reference potentials GND are internally connected to PE.



INFORMATION








The assignment "reserved" means that no cable must be connected to this connection.
















INFORMATION









The technical data for the connection of power electronics and control electronics are listed in chapter Technical Data.

4.13.1 Terminal assignment at MDP power supply module






| Representa- tion | Terminal | Conne- ction | Brief description |
|---|-------------------|-----------------|--|
|  | X1:L1 | L1 | Line connection MDP90A-0100-.. (size 1) |
| | X1:L2 | L2 | |
| | X1:L3 | L3 | |
| | ⊕ ⊖ | PE | PE connection |
|  | X1:L1 | L1 | Line connection MDP90A-0250-.. (size 2) |
| | X1:L2 | L2 | |
| | X1:L3 | L3 | |
| | ⊕ ⊖ | PE | PE connection |
|  | X1:1 | L1 | Line connection MDP90A-0500 – 0750-.. (size 3) |
| | X1:2 | L2 | |
| | X1:3 | L3 | |
| | ⊕ ⊖ | PE | PE connection |
|  | X1:1 | L1 | Line connection MDP90A-1100-.. (size 4) |
| | X1:2 | L2 | |
| | X1:3 | L3 | |
| | ⊕ ⊖ | PE | PE connection |
|  | X3:+R | +R | Braking resistor connection MDP90A-0100-.. (size 1) |
| | X3:-R | -R | |
| | X3:R _i | R _i | Reserved with size 1 as no R _i available Connection of internal braking resistor to MDP..C00 (R _i) |
| | ⊕ ⊖ | PE | PE connection |
|  | X3:+R | +R | Braking resistor connection MDP90A-0250 – 0750-.. (size 2, 3) |
| | X3:-R | -R | |
| | ⊕ ⊖ | PE | PE connection |
|  | X3:+R | +R | Braking resistor connection MDP90A-1100-.. (size 4) |
| | X3:-R | -R | |
| | ⊕ ⊖ | PE | PE connection |



| Representa- tion | Terminal | Conne- ction | Brief description |
|--|---|-----------------|---|
|   | X4:+U _Z | +U _Z | DC link connection |
| | X4:-U _Z | -U _Z | |
| |  | PE | PE connection |
|   | X4:+U _Z | +U _Z | DC link connection left side MDP90A-1100-.. (size 4) |
| | X4:-U _Z | -U _Z | |
| |  | PE | PE connection |
|   | X4:+U _Z | +U _Z | DC link connection right side MDP90A-1100-.. (size 4) |
| | X4:-U _Z | -U _Z | |
| |  | PE | PE connection |
|  | X5:24 V | 24V_in | +24 V supply voltage |
| | X5:GND | GND | |
|   | X30 OUT | | System bus |
| | X30 IN | | |
|  | X7:1 | +TEMP_R | DC 24 V auxiliary voltage output |
| | X7:2 | -TEMP_R | Sensor input for temperature monitoring of the braking resistor |
| | X7:3 | Reserved | — |
| | X7:4 | Reserved | — |



4.13.2 Terminal assignment at MDA single-axis module

| Representa- tion | Terminal | Connection | Brief description |
|---|--------------------|-----------------|--|
|  | X2:U | U | Motor connection MDA90A-0020 – 0240-.. (Sizes 1, 2) |
| | X2:V | V | |
| | X2:W | W | |
| | ⊕ | PE | PE connection |
|  | X2:U | U | Motor connection MDA90A-0320 – 1000-.. (sizes 3 – 5) |
| | X2:V | V | |
| | X2:W | W | |
| | ⊕ | PE | PE connection |
|  | X2:U | U | Motor connection MDA90A-1400 – 1800 (size 6) |
| | X2:V | V | |
| | X2:W | W | |
| | ⊕ | PE | PE connection |
|  | X4:+U _z | +U _z | DC link connection |
| | X4:-U _z | -U _z | |
| | ⊕ | PE | PE connection |
|  | X4:+U _z | +U _z | DC link connection MDA90A-1400 – 1800-.. (size 6) |
| | X4:-U _z | -U _z | |
| | ⊕ | PE | PE connection |
|  | X5:24 V | 24V_in | DC 24 V supply voltage |
| | X5:GND | GND | Reference potential |
|  | X10:DB0 | DB00 | Brake control |
| | X10:GND | GND | Reference potential |
| | X10:TF1 | TF1 | Sensor input for temperature monitoring of the motor |
| | X10:GND | GND | Reference potential |
| | ⊕ | PE | PE connection |
|  | X30 OUT | | System bus |
| | X30 IN | | |

25953079/EN – 01/2020











| Representa- tion | Terminal | Connection | Brief description |
|---|----------|--------------|---|
|  | X31 | | SEW-EURODRIVE Service interface |
|  | X20:1 | DI00 | Digital input 1, with fixed assignment "Output stage enable" |
| | X20:2 | DI01 | Digital input 2, fixed setpoints – positive direction of rotation ¹⁾ |
| | X20:3 | DI02 | Digital input 3, fixed setpoints – negative direction of rotation ¹⁾ |
| | X20:4 | DI03 | Digital input 4, fixed setpoint – speed, bit 0 ¹⁾ |
| | X20:5 | DI04 | Digital input 5, fixed setpoint – speed, bit 1 ¹⁾ |
| | X20:6 | DI05 | Digital input 6, fault reset ¹⁾ |
| | X20:7 | GND | Reference potential |
| | X20:8 | 24V_out | DC 24 V voltage output |
|  | X21:1 | DO00 | Digital output 1, ready for operation ²⁾ |
| | X21:2 | DO01 | Digital output 2, output stage enable ²⁾ |
| | X21:3 | DO02 | Digital output 3, error ²⁾ |
| | X21:4 | DO00 | Digital output 4, STO active ²⁾ |
| | X21:5 | GND | Digital output 5, reference potential |
|  | X6:1 | F_STO_P1 | DC +24 V input F_STO_P1 |
| | X6:2 | F_STO_M | DC 0 V input F_STO_M |
| | X6:3 | F_STO_P2 | DC +24 V input F_STO_P2 |
| | X6:4 | GND | Reference potential |
| | X6:5 | 24 V STO_OUT | U _{out} = DC 24 V supply of F_STO_P1 and F_STO_P2 |
|  | X15:1 | S2 (sin+) | Signal track |
| | X15:2 | S1 (cos+) | Signal track |
| | X15:3 | Reserved | – |
| | X15:4 | Reserved | – |
| | X15:5 | R1 (REF+) | Supply voltage resolver |
| | X15:6 | -TEMP_M | Motor temperature evaluation |
| | X15:7 | Reserved | – |
| | X15:8 | Reserved | – |
| | X15:9 | S4 (sin-) | Signal track |
| | X15:10 | S3 (cos-) | Signal track |
| | X15:11 | Reserved | – |
| | X15:12 | Reserved | – |
| | X15:13 | R2 (REF-) | Supply voltage resolver |
| | X15:14 | +TEMP_M | Motor temperature evaluation |
| | X15:15 | Reserved | – |



| Representa- tion | Terminal | Connection | Brief description |
|---|----------|----------------------------------|--|
|  | X15:1 | A (cos+) (K1) | Signal track A (cos+) (K1) |
| | X15:2 | B (sin+) (K2) | Signal track B (sin+) (K2) |
| | X15:3 | C (K0) | Signal track C (K0) |
| | X15:4 | DATA+ ³⁾ | Data cable for electronic nameplate |
| | X15:5 | Reserved | – |
| | X15:6 | -TEMP_M | Motor temperature evaluation |
| | X15:7 | Reserved | – |
| | X15:8 | GND | Reference potential |
| | X15:9 | \bar{A} (cos -) ($\bar{K1}$) | Negated signal track \bar{A} (cos-) ($\bar{K1}$) |
| | X15:10 | \bar{B} (sin-) ($\bar{K2}$) | Negated signal track \bar{B} (sin-) ($\bar{K2}$) |
| | X15:11 | \bar{C} ($\bar{K0}$) | Negated signal track \bar{C} ($\bar{K0}$) |
| | X15:12 | DATA- ²⁾ | Data cable for electronic nameplate |
| | X15:13 | U _{S24VG} | Encoder supply 24 V |
| | X15:14 | +TEMP_M | Motor temperature evaluation |
| | X15:15 | U _{S12VG} | Encoder supply 12 V |
|  | X15:1 | A (K1) | Signal track A (K1) |
| | X15:2 | B (K2) | Signal track B (K2) |
| | X15:3 | C (K0) | Signal track C (K0) |
| | X15:4 | Reserved | – |
| | X15:5 | Reserved | – |
| | X15:6 | -TEMP_M | Motor temperature evaluation |
| | X15:7 | Reserved | – |
| | X15:8 | GND | Reference potential |
| | X15:9 | \bar{A} ($\bar{K1}$) | Negated signal track \bar{A} ($\bar{K1}$) |
| | X15:10 | \bar{B} ($\bar{K2}$) | Negated signal track \bar{B} ($\bar{K2}$) |
| | X15:11 | \bar{C} ($\bar{K0}$) | Negated signal track \bar{C} ($\bar{K0}$) |
| | X15:12 | Reserved | – |
| | X15:13 | U _{S24VG} | Encoder supply 24 V |
| | X15:14 | +TEMP_M | Motor temperature evaluation |
| | X15:15 | U _{S12VG} | Encoder supply 12 V |

| Representa- tion | Terminal | Connection | Brief description |
|---|----------|----------------------------------|--|
|  | X15:1 | A (cos+) (K1) | Signal track A (cos+) (K1) |
| | X15:2 | B (sin+) (K2) | Signal track B (sin+) (K2) |
| | X15:3 | Reserved | – |
| | X15:4 | DATA+ | Data line RS485 |
| | X15:5 | Reserved | – |
| | X15:6 | -TEMP_M | Motor temperature evaluation |
| | X15:7 | Reserved | – |
| | X15:8 | GND | Reference potential |
| | X15:9 | \bar{A} (cos -) ($\bar{K}1$) | Negated signal track \bar{A} (cos-) ($\bar{K}1$) |
| | X15:10 | \bar{B} (sin-) ($\bar{K}2$) | Negated signal track \bar{B} (sin-) ($\bar{K}2$) |
| | X15:11 | Reserved | – |
| | X15:12 | DATA- | Data line |
| | X15:13 | U _{S24VG} | Encoder supply 24 V |
| | X15:14 | +TEMP_M | Motor temperature evaluation |
| | X15:15 | U _{S12VG} | Encoder supply 12 V |
|  | X16 | Coaxial connection | MOVILINK® DDI |

- 1) The assignment of DI01 – DI05 specified here is the factory setting. The inputs are parameterizable.
- 2) The assignment of DO00 – DO02 specified here is the factory setting. The outputs are parameterizable.
- 3) For encoders from SEW-EURODRIVE with electronic nameplate of type E.7S

4.13.3 Terminal assignment at MDD double-axis module


| Representa- tion | Terminals | | Connection | Brief description |
|---|---|-----------|-----------------|---|
|  | X2_1:U | X2_2:U | U | Motor connection MDD9.A-0020 – 0080-.. (Sizes 1, 2) |
| | X2_1:V | X2_2:V | V | |
| | X2_1:W | X2_2:W | W | |
| |  | | PE | PE connection |
|  | X4:+U _z | | +U _z | DC link connection |
| | X4:-U _z | | -U _z | |
| |  | | PE | PE connection |
|  | X5:24 V | | 24V_in | DC 24 V supply voltage |
| | X5:GND | | GND | Reference potential |
|  | X10_1:DB0 | X10_2:DB0 | DB00 | Brake control |
| | X10_1:GND | X10_2:GND | GND | Reference potential |
| | X10_1:TF1 | X10_2:TF1 | TF1 | Sensor input for temperature monitoring of the motor |
| | X10_1:GND | X10_2:GND | GND | Reference potential |
| |  | | PE | PE connection |
|  | X30 OUT | | | System bus |
| | X30 IN | | | |
|  | X31 | | | SEW-EURODRIVE Service interface |
|  | X20_1:1 | X20_2:1 | DI00 | Digital input 1, with fixed assignment "Output stage enable" |
| | X20_1:2 | X20_2:2 | DI01 | Digital input 2, fixed setpoints – positive direction of rotation ¹⁾ |
| | X20_1:3 | X20_2:3 | DI02 | Digital input 3, fixed setpoints – negative direction of rotation ¹⁾ |
| | X20_1:4 | X20_2:4 | DI03 | Digital input 4, fixed setpoint – speed, bit 0 ¹⁾ |
| | X20_1:5 | X20_2:5 | DI04 | Digital input 5, fixed setpoint – speed, bit 1 ¹⁾ |
| | X20_1:6 | X20_2:6 | DI05 | Digital input 6, fault reset ¹⁾ |
| | X20_1:7 | X20_2:7 | GND | Reference potential |
| | X20_1:8 | X20_2:8 | 24V_out | DC 24 V voltage output |


| Representa- tion | Terminals | | Connection | Brief description |
|---|-----------|---------|-----------------|--|
|  | X21_1:1 | X21_2:1 | DO00 | Digital output 1, ready for operation ²⁾ |
| | X21_1:2 | X21_2:2 | DO01 | Digital output 2, output stage enable ²⁾ |
| | X21_1:3 | X21_2:3 | DO02 | Digital output 3, error ²⁾ |
| | X21_1:4 | X21_2:4 | DO03 | Digital output 4, STO active |
| | X21_1:5 | X21_2:5 | GND | Digital output 5, reference potential |
|  | X6_1:1 | X6_2:1 | F_STO_P1 | DC +24 V input F_STO_P1 |
| | X6_1:2 | X6_2:2 | F_STO_M | DC 0 V input F_STO_M |
| | X6_1:3 | X6_2:3 | F_STO_P2 | DC +24 V input F_STO_P2 |
| | X6_1:4 | X6_2:4 | GND | Reference potential |
| | X6_1:5 | X6_2:5 | 24 V STO_OUT | U _{out} = DC 24 V supply of F_STO_P1 and F_STO_P2 |

1) The assignment of DI01 – DI05 specified here is the factory setting. The inputs are parameterizable.


2) The assignment of DO00 – DO02 specified here is the factory setting. The outputs are parameterizable.



The X15_.. terminals are available for the MDD90A double-axis module.

| Representa- tion | Terminals | | Connection | Brief description, motor encoder resolver |
|---|-----------|----------|------------|---|
|  | X15_1:1 | X15_2:1 | S2 (sin+) | Signal track |
| | X15_1:2 | X15_2:2 | S1 (cos+) | Signal track |
| | X15_1:3 | X15_2:3 | Reserved | – |
| | X15_1:4 | X15_2:4 | Reserved | – |
| | X15_1:5 | X15_2:5 | R1 (REF+) | Supply voltage resolver |
| | X15_1:6 | X15_2:6 | -TEMP_M | Motor temperature evaluation |
| | X15_1:7 | X15_2:7 | Reserved | – |
| | X15_1:8 | X15_2:8 | Reserved | – |
| | X15_1:9 | X15_2:9 | S4 (sin-) | Signal track |
| | X15_1:10 | X15_2:10 | S3 (cos-) | Signal track |
| | X15_1:11 | X15_2:11 | Reserved | – |
| | X15_1:12 | X15_2:12 | Reserved | – |
| | X15_1:13 | X15_2:13 | R2 (REF-) | Supply voltage resolver |
| | X15_1:14 | X15_2:14 | +TEMP_M | Motor temperature evaluation |
| | X15_1:15 | X15_2:15 | Reserved | – |








| Representa- tion | Terminals | | Connection | Brief description, motor encoder sin/cos encoder, TTL encoder |
|---|-----------|----------|----------------------------------|--|
|  | X15_1:1 | X15_2:1 | A (cos+) (K1) | Signal track A (cos+) (K1) |
| | X15_1:2 | X15_2:2 | B (sin+) (K2) | Signal track B (sin+) (K2) |
| | X15_1:3 | X15_2:3 | C (K0) | Signal track C (K0) |
| | X15_1:4 | X15_2:4 | DATA+ ¹⁾ | Data cable for electronic nameplate |
| | X15_1:5 | X15_2:5 | Reserved | – |
| | X15_1:6 | X15_2:6 | -TEMP_M | Motor temperature evaluation |
| | X15_1:7 | X15_2:7 | Reserved | – |
| | X15_1:8 | X15_2:8 | GND | Reference potential |
| | X15_1:9 | X15_2:9 | \bar{A} (cos -) ($\bar{K1}$) | Negated signal track \bar{A} (cos-) ($\bar{K1}$) |
| | X15_1:10 | X15_2:10 | \bar{B} (sin-) ($\bar{K2}$) | Negated signal track \bar{B} (sin-) ($\bar{K2}$) |
| | X15_1:11 | X15_2:11 | \bar{C} ($\bar{K0}$) | Negated signal track \bar{C} ($\bar{K0}$) |
| | X15_1:12 | X15_2:12 | DATA- ¹⁾ | Data cable for electronic nameplate |
| | X15_1:13 | X15_2:13 | U _{S24VG} | 24 V encoder supply |
| | X15_1:14 | X15_2:14 | +TEMP_M | Motor temperature evaluation |
| | X15_1:15 | X15_2:15 | U _{S12VG} | Encoder supply 12 V |

1) For encoders from SEW-EURODRIVE with electronic nameplate of type E.7S





| Representa- tion | Terminals | | Connection | Brief description motor encoder HTL en- coder |
|---|-----------|----------|--------------------------|--|
|  | X15_1:1 | X15_2:1 | A (K1) | Signal track A (K1) |
| | X15_1:2 | X15_2:2 | B (K2) | Signal track B (K2) |
| | X15_1:3 | X15_2:3 | C (K0) | Signal track C (K0) |
| | X15_1:4 | X15_2:4 | Reserved | – |
| | X15_1:5 | X15_2:5 | Reserved | – |
| | X15_1:6 | X15_2:6 | -TEMP_M | Motor temperature evaluation |
| | X15_1:7 | X15_2:7 | Reserved | – |
| | X15_1:8 | X15_2:8 | GND | Reference potential |
| | X15_1:9 | X15_2:9 | \bar{A} ($\bar{K1}$) | Negated signal track \bar{A} ($\bar{K1}$) |
| | X15_1:10 | X15_2:10 | \bar{B} ($\bar{K2}$) | Negated signal track \bar{B} ($\bar{K2}$) |
| | X15_1:11 | X15_2:11 | \bar{C} ($\bar{K0}$) | Negated signal track \bar{C} ($\bar{K0}$) |
| | X15_1:12 | X15_2:12 | Reserved | – |
| | X15_1:13 | X15_2:13 | U _{S24VG} | 24 V encoder supply |
| | X15_1:14 | X15_2:14 | +TEMP_M | Motor temperature evaluation |
| | X15_1:15 | X15_2:15 | U _{S12VG} | Encoder supply 12 V |

| Representa- tion | Terminals | | Connection | Brief description motor encoder HIPERFACE® and SEW-EURODRIVE en- coder (RS485) |
|---|-----------|----------|---------------------------------------|--|
|  | X15_1:1 | X15_2:1 | A (cos+) (K1) | Signal track A (cos+) (K1) |
| | X15_1:2 | X15_2:2 | B (sin+) (K2) | Signal track B (sin+) (K2) |
| | X15_1:3 | X15_2:3 | Reserved | – |
| | X15_1:4 | X15_2:4 | DATA+ | Data line RS485 |
| | X15_1:5 | X15_2:5 | Reserved | – |
| | X15_1:6 | X15_2:6 | -TEMP_M | Motor temperature evaluation |
| | X15_1:7 | X15_2:7 | Reserved | – |
| | X15_1:8 | X15_2:8 | GND | Reference potential |
| | X15_1:9 | X15_2:9 | \bar{A} (cos -) ($\overline{K1}$) | Negated signal track \bar{A} (cos-) ($\overline{K1}$) |
| | X15_1:10 | X15_2:10 | \bar{B} (sin-) ($\overline{K2}$) | Negated signal track \bar{B} (sin-) ($\overline{K2}$) |
| | X15_1:11 | X15_2:11 | Reserved | – |
| | X15_1:12 | X15_2:12 | DATA- | Data line |
| | X15_1:13 | X15_2:13 | U _{S24VG} | 24 V encoder supply |
| | X15_1:14 | X15_2:14 | +TEMP_M | Motor temperature evaluation |
| | X15_1:15 | X15_2:15 | U _{S12VG} | Encoder supply 12 V |
|  | X16_1 | X16_2 | Coaxial con- nection | MOVILINK® DDI for MDD91A |

4.13.4 Terminal assignment of MDC90A-0001/0002-.. capacitor module



| Representa- tion | Terminal | Connec- tion | Brief description |
|--|---|-----------------|---------------------------------|
|   | X4:+U _Z | +U _Z | DC link connection |
| | X4:-U _Z | -U _Z | |
| |  | PE | PE connection |
|   | X4_A:+ | +U _Z | Connection of safe brake module |
| | X4_A:- | -U _Z | |
| |  | PE | PE connection |
|  24 V GND | X5:24 V | 24V_in | +24 V supply voltage |
| | X5:GND | GND | |

4.13.5 Terminal assignment at master module UHX45A/MDM90A

| Representa- tion | Terminal | Connection | Brief description |
|---|----------|------------|---|
|  | X5_A:24V | 24V_in | External DC 24 V supply voltage from housing MD-M90A |
| | X5_A:GND | GND | Reference potential housing MDM90A |
|  | X5_B:24V | 24V_out | Output of DC 24 V supply voltage from housing MD-M90A |
| | X5_B:GND | GND | Reference potential housing MDM90A |
|  | X5:24 V | 24V_in | DC 24 V supply voltage UHX45A |
| | X5:GND | GND | Reference potential UHX45A |
|  | X85:1-3 | RS485 | RS485 interface (in preparation) |
| | X85:4-6 | CAN1 | System bus CAN 1 – non-isolated (in preparation) |
| | X85:7-9 | CAN2 | System bus CAN 2 – non-isolated (in preparation) |

4.14 Wiring diagrams

4.14.1 General information on the wiring diagrams

- For technical data of the power electronics and the control electronics, refer to chapter "Technical data" (→  247).
- For the terminal assignment and connections, refer to chapter "Terminal assignment" (→  148).

4.14.2 Power connection

NOTICE

Incorrectly placed components.

Destruction of the power supply module.

- Do not install any other components between the line filter and the power supply module.


NOTICE

Overtemperature of line filter and line choke.

Destruction of line filter and line choke.

- Make sure line filter and line choke are not heated by warm exhaust air of other devices.

Exemplary wiring of the MDP90A.. power connections with line contactor, line choke, and line filter




36028806497163019

- [1] Line contactor
- [2] Line choke (optional)
- [3] Line filter
- [4] Connection of the braking resistor
- [5] Motor
- MDP Power supply module
- MDA Single-axis module
- MDD Double-axis module

Wiring the MDP90A-0250, 0500, 0750, 1100 power connections without line contactor

Operation without line contactor is only possible for power supply modules of 25 kW of higher.



27021609848822539


- [1] Line choke (optional)
- [2] Line filter
- [3] Connection of the braking resistor
- [4] Motor
- MDP Power supply module
- MDA Single-axis module
- MDD Double-axis module

INFORMATION



In case of a line connection without line contactor, the temperature evaluation of the braking resistor via connection X7 of the power supply module must be ensured. The temperature evaluation is evaluated as error message in each axis.


Wiring of the MDP90A---C00 power connections using the integrated braking resistor



27021607242286475

- [1] Line contactor
- [2] Line choke (optional)
- [3] Line filter
- [4] Connection of the braking resistor
- [5] Motor
- MDP Power supply module
- MDA Single-axis module
- MDD Double-axis module







Wiring of the MDP90A---C00 power connections using the external braking resistor



36028806505258635

- [1] Line contactor
- [2] Line choke (optional)
- [3] Line filter
- [4] Connection of the braking resistor
- [5] Motor
- MDP Power supply module
- MDA Single-axis module
- MDD Double-axis module

4.14.3 Brake control

| | |
|---|--|
| Legend: | |
|  | Cut-off in the DC and AC circuits (rapid brake application) |
|  | Cut-off in the DC circuit |
|  | Brake BS = accelerator coil TS = coil section |
|  | DC brake with one brake coil |
|  | Auxiliary terminal strip in terminal box |
|  | Control cabinet limit |
| WH | White |
| RD | Red |
| BU | Blue |


INFORMATION




Type and source of the hazard

The selection of the brake control and the shown connection diagrams only represent one of the many possibilities. Observe the catalogs and operating instructions of the motors for more information and installation notes.


BMK. brake control




BMV brake control – 2 coils




BMV brake control – 1 coil




BMS, BME brake control




BMP brake control



BG, BGE brake control



BSG brake control




Direct control DC 24 V brake

If the system complies with the following specifications for direct brake control, a BK or BP brake (holding brake) can also be controlled directly via the brake output of an application inverter.

Specifications for direct brake control:

- Only the BK brakes of the CMP40 – 63 motor and the BP brake of the CMP71 motor are permitted.
- Expressly excluded are brakes of the motor types CMP80 and greater, CMPZ motors, and all non-SEW brakes.
- Only prefabricated brakemotor cables from SEW-EURODRIVE must be used.
- The brakemotor cable must be shorter than 25 m.
- The shielding of the brake cable must be connected to the shielding plate.


Observe additional information in the "Synchronous Servomotors" catalog.



4.14.4 Electronics connection MDP90A.. power supply module

Wiring the control electronics

For the terminal assignment and connections, refer to chapter "Terminal assignment" (→ 148).




54043209842314507

- X5 Connection +24 V supply voltage
- X7 Braking resistor temperature monitoring
- X30 System bus

4.14.5 Electronics connection MDA90A.. single-axis module


Wiring the control electronics

For the terminal assignment and connections, refer to the chapter "Terminal assignment" (→ 148).



9007224862225163

- X5 Connection +24 V supply voltage
- X20 Digital inputs
- X21 Digital outputs
- X30 System bus
- X31 SEW-EURODRIVE Service interface




9007224862221067

- X6** Connection for Safe Torque Off (STO)
With installed CS.A card, the cable bridges are removed at the factory.
If no CS.A card is installed upon delivery, the cable bridges are installed at the factory
- X10** Brake control and motor temperature monitoring
- X16** MOVILINK® DDI connection
- X30** System bus

4.14.6 MDD9.A.. double-axis module electrical connection


Wiring the control electronics

For the terminal assignment and connections, refer to the chapter "Terminal assignment" (→ 148).



9007224862457611

- X5 Connection +24 V supply voltage
- X15 Motor encoder connection with MDD90A-..
- X20 Digital inputs
- X21 Digital outputs
- X30 System bus
- X31 SEW-EURODRIVE Service interface




25607711883

- X6 Connection for Safe Torque Off (STO)
With installed CS.A card, the cable bridges are removed at the factory.
If no CS.A card is installed upon delivery, the cable bridges are installed at the factory.
- X10 Brake control and motor temperature monitoring
- X16 MOVILINK® DDI connection with MDD91A-..
- X30 System bus

4.14.7 Connection diagram CIO21A and CID21A input/output card


Digital inputs and outputs



18014412829087243


[1] Higher-level controller

Voltage input



9007213575393675


Connection to the terminals AI31 and AI32 is carried out analogously to the connection to the terminals AI21 and AI22 shown in the wiring diagrams.



18014412830137099

Connection to the terminals REF2 and AI31 is carried out analogously to the connection to the terminals REF1 and AI21 shown in the wiring diagrams.

Current input




9007213575398539

Connection to the terminals AI31 and AI32 is carried out analogously to the connection to the terminals AI21 and AI22 shown in the wiring diagrams.

Observe the switch position of DIP switch S50 when activating the current input.


Voltage output



18014412830141963

Connection to the terminals AOV3 and GND is carried out analogously to the connection to the terminals AOV2 and GND shown in the wiring diagram.

Current output



18014412830272395

Connection to the terminals AOC3 and GND is carried out analogously to the connection to the terminals AOC2 and GND shown in the wiring diagram.

4.15 Information regarding UL

INFORMATION



Due to UL requirements, the following chapter is always printed in English independent of the language of the documentation.

4.15.1 Field Wiring Power Terminals

- Use 75 °C solid or stranded copper wire only sized at 14 AWG minimum. Suitable for 1 wire per terminal.
- For double axis modules use wire size 12 – 14 AWG.
- Tighten terminals to in-lbs (Nm) as follows

| MDP90A-...- | Tightening torque in-lbs (Nm) | | | |
|--------------------|-------------------------------|-----------------------------|----------------------------|-----------------------------|
| | Power supply module | | | |
| | Line connection | | Braking resistor terminals | |
| 0100 (size 1) | X1 | 4.4 – 5.3 (0.5 – 0.6) | X3 | 4.4 – 5.3 (0.5 – 0.6) |
| 0100 (size 1A) | X1 | 4.4 – 5.3 (0.5 – 0.6) | X3 | 4.4 – 5.3 (0.5 – 0.6) |
| 0250 | X1 | 26.6 – 35.4 (3.0 – 4.0) | X3 | 26.6 – 35.4 (3.0 – 4.0) |
| 0500 | X1 | 159.3 – 194.7 (18.0 – 22.0) | X3 | 26.6 – 35.4 (3.0 – 4.0) |
| 0750 | X1 | 159.3 – 194.7 (18.0 – 22.0) | X3 | 26.6 – 35.4 (3.0 – 4.0) |
| 1100 | X1 | 159.3 – 194.7 (18.0 – 22.0) | X3 | 97.4 – 106.2 (11.0 – 12.0) |
| MDA90A-...- | Single-axis module | | | |
| | Motor connection | | - | |
| 0020 – 0120 | X2 | 4.4 – 5.3 (0.5 – 0.6) | - | - |
| 0160 – 0240 | X2 | 13.3 – 15.0 (1.5 – 1.7) | - | - |
| 0320 – 0480 | X2 | 26.6 – 35.4 (3.0 – 4.0) | - | - |
| 0640 – 1800 | X2 | 159.3 – 194.7 (18.0 – 22.0) | X3 | 159.3 – 194.7 (18.0 – 22.0) |
| MDD90A-...- | Double-axis module | | | |
| | Motor connection | | - | |
| 0020 – 0040 | X2 | 4.4 – 5.3 (0.5 – 0.6) | - | - |
| 0020 – 0080 | X2 | 13.3 – 15.0 (1.5 – 1.7) | - | - |
| | All modules (exception below) | | | |
| | DC link connection | | PE connection | |
| | X4 | 26.6 – 35.4 (3.0 – 4.0) | | 26.6 – 35.4 (3.0 – 4.0) |
| DC link connection | | | | |
| MDP90A-1100 | X4B | 97.4 – 106.2 (11.0 – 12.0) | - | - |
| MDA90A-1400 – 1800 | X4 | 97.4 – 106.2 (11.0 – 12.0) | - | - |

4.15.2 Short Circuit Current Rating

Suitable for use on a circuit capable of delivering not more than

- 5000/10000/65000 rms symmetrical amperes when protected by fuses and circuit breakers as described in the tables below.

Max. voltage is limited to 500 V.

4.15.3 Branch Circuit Protection

Integral solid state short circuit protection does not provide branch circuit protection. Branch circuit protection must be provided in accordance with the National Electrical Code and any additional local codes.

| Power supply module MDP90A-.. | SCCR: 5 kA/500 V | | SCCR: 65 kA/500 V | | |
|----------------------------------|---|--|--|--|--|
| | when protected by: | | | | |
| | Non semiconductor fuses (currents are maximum values) | Inverse-time circuit breaker (currents are maximum values) | Non semiconductor fuses (currents are maximum values) | Inverse-time circuit breaker (currents are maximum values) | Type E Combination Motor Controller |
| 0100 (size 1) | 20 A/600 V Class: K5 | 20 A/500 V min. | 20 A/600 V Class: CA, CB, CC, CD, CF, G, J, K1, K5, T | 20 A/500 V min. | Siemens Sirius 3RV2011-4AA10 (11 – 16 A) |
| 0100 (size 1A) | 20 A/600 V Class: K5 | 20 A/500 V min. | 20 A/600 V Class: K5 | 20 A/500 V min. | Siemens Sirius 3RV2011-4AA10 (11 – 16 A) |
| 0250 | 50 A/600 V Class: K5 | 50 A/500 V min. | 50 A/600 V Class: K1 | 50 A/500 V min. | Siemens Sirius 3RV1031-4HA10 (40 – 50 A) |
| Power supply module MDP90A-.. | SCCR: 10 kA/500 V | | SCCR: 65 kA/500 V | | |
| | when protected by: | | | | |
| | Non semiconductor fuses (currents are maximum values) | Inverse-time circuit breaker (currents are maximum values) | Non semiconductor fuses (currents are maximum values) | Inverse-time circuit breaker (currents are maximum values) | Type E Combination Motor Controller |
| 0500 (size 3) | 100 A/600 V Class: K1 | 100 A/500 V min. | 100 A/600 V Class: K1 | 100 A/500 V min. | |
| 0750 (size 3) | 150 A/600 V Class: J, T | 150 A/500 V min | 150 A/600 V Class: J, T | 150 A/500 V min. | |
| 1100 (size 4) | 200 A/600 V Class: J, T | 200 A/500 V min. | 200 A/600 V Class: J, T | 200 A/500 V min. | |

- If you use cable cross sections that are dimensioned for a smaller current than the rated current of the unit, make sure that the fuse is dimensioned for the used cable cross section.
- For information on selecting cable cross sections, refer to the project planning manual.
- Comply with the country-specific installation regulations in addition to the above notes.
- Single- and double-axis modules are intended for installation with the supply modules.
- Accessory Model MDM90A is intended for use with the drive system MOVIDRIVE®.

4.15.4 Motor Overload Protection

The units are provided with load and speed-sensitive overload protection and thermal memory retention upon shutdown or power loss.

The trip current is adjusted to 150 % of the rated motor current.

4.15.5 Ambient Temperature

The units are suitable for an ambient temperature of 45 °C.

**INFORMATION**

UL certification does not apply to operation in voltage supply systems without earthed star point (IT systems).

5 Startup

5.1 General



⚠ DANGER

Uncovered power connections.

Severe or fatal injuries from electric shock.

- Install the touch guards at the modules, see chapter "Covers" (→ 62).
- Install the closing covers according to the regulations, see chapter "Covers" (→ 62).
- Never start up the application inverter without installed closed touch guards and closing covers.

5.1.1 Lifting applications



⚠ WARNING

Danger of fatal injury if the hoist falls.

Severe or fatal injuries.

- The application inverter is not designed for use as a safety device in lifting applications. Use monitoring systems or mechanical protection devices to ensure safety.

5.1.2 Connecting power

NOTICE

Undercutting the minimum switch-off time of the line contactor.

Irreparable damage to the application inverter or unforeseeable malfunctions.

The specified times and intervals must be observed.

- After disconnection from the supply system, observe a minimum switch-off time of 10 s.
- Do **not** turn the power of the supply system on or off **more than once per minute**.

5.1.3 Connecting cables

NOTICE

Disconnecting lines under voltage.

Irreparable damage to the application inverter or unforeseeable malfunctions.

- The following plug-in connections must always be disconnected in a de-energized state: Motor, grid, braking resistor, brake, encoder, connection, energy storage unit, connection discharge unit.


5.2 Assigning the EtherCAT®/SBusPLUS address at the axis module

There are 2 hexadecimal address switches S1 and S2 installed in each axis module to set the EtherCAT®/SBusPLUS address. For information on the installation position of the switches, refer to chapter . Use these address switches to set a decimal address between 1 and 255.

The following table lists example settings for the address switches.


| Required address, decimal | Address, hexa-decimal | Setting S1 (× 16) | Setting S2 (× 1) |
|---------------------------|-----------------------|----------------------|---------------------|
| 3 | 03 | 0 | 3 |
| 18 | 12 | 1 | 2 |
| 25 | 19 | 1 | 9 |
| 100 | 64 | 6 | 4 |
| 110 | 6E | 6 | E |
| 255 | FF | F | F |

S1 address switch



6

S2 address switch



E

The EtherCAT®/SBusPLUS address "110" is set as an example in the illustration above.

The setting at the single-axis module is identical to the setting at the double-axis module.

5.3 Startup requirements

The following requirements apply to startup:

- You have installed the device correctly both mechanically and electrically.
- The device and connected devices have been configured correctly.
- Safety measures prevent accidental startup of the drive.
- Safety measures prevent danger to persons or machines.

Required hardware components:

- PC or laptop with Ethernet interface.
- Commercially available Ethernet cable for connection between PC and MOVI-C® CONTROLLER.
- MOVI-C® CONTROLLER with completed startup

Required software:

- MOVISUITE® standard engineering software from SEW-EURODRIVE.

5.4 Startup procedure

The application inverters are put into operation using the MOVISUITE® engineering software from SEW-EURODRIVE.



15643252491

The startup is functionally divided into segments. The following steps illustrate in exemplary fashion the startup procedure for an application inverter.

Drive train segment

| | |
|-------------|---------------------------|
| Drive train | Configuring drive trains. |
|-------------|---------------------------|

Interfaces segment

| | |
|----------------|---|
| Inputs/outputs | <ul style="list-style-type: none"> Basic unit I/O card |
| Setpoints | <ul style="list-style-type: none"> Process data PO data Setpoint buffer Fixed setpoints Control word 1 – 3 |
| Actual values | <ul style="list-style-type: none"> PI data Status word 1 – 3 |

25953079/EN – 01/2020

| | |
|----------------------|--|
| Drive functions | <ul style="list-style-type: none"> • FCB 01 Output stage inhibit • FCB 05 Speed control • FCB 06 Interpolated speed control • FCB 08 Interpolated torque control • FCB 09 Positioning • FCB 10 Interpolated position control • FCB 12 Reference travel • FCB 08 Rotor position identification • FCB 20 Jog mode • FCB 21 Brake test • FCB 26 Stop at user limit |
| Monitoring functions | <ul style="list-style-type: none"> • Reference signals 1 • Reference signals 2 • Limit values 1 • Limit values 2 • Control functions 1 • Monitoring functions 2 • Output stage |
| Advanced functions | <ul style="list-style-type: none"> • Parameter set • Auto reset • Standby mode • Touchprobe 1 • Touchprobe 2 • Cam switch |

Functions segment

| | |
|-----------------------------|---|
| Device data | <ul style="list-style-type: none"> • Device identification • Main component • Subcomponents • Production data |
| Overview of fault responses | <ul style="list-style-type: none"> • Axis module • Power supply monitoring • Functions |
| Setup | <ul style="list-style-type: none"> • Permissions • Reset device parameters • Select memory source |

Information on the application inverter

| | |
|---------|---|
| Default | <p>Basic settings of the installed interfaces</p> <ul style="list-style-type: none"> • Basic unit • Encoder 1 |
|---------|---|

| | |
|----------|---|
| Optional | Basic settings of the options <ul style="list-style-type: none">• Fieldbus• I/O card• Encoder 2• MOVISAFE® CS.. |
|----------|---|

6 Operation

6.1 General information



⚠ DANGER

Dangerous voltages present at cables and motor terminals.

Severe or fatal injuries from electric shock.

- Dangerous voltages are present at the output terminals and the cables and motor terminals connected to them when the device is switched on. This also applies even when the device is inhibited and the motor is at standstill.
- Check whether the device is disconnected from the power supply before you start working on the power connections.
- After disconnection from the power supply, wait at least 10 minutes and ensure that there is no voltage present before you start working on the power connections.
- The fact that the operation LEDs are no longer illuminated does not indicate that the application inverter no longer carries any voltage.
- Observe the general safety notes in chapter Safety notes.



⚠ DANGER

Risk of crushing if the motor starts up unintentionally.

Severe or fatal injuries.

- Ensure that the motor cannot start inadvertently, for example, by removing the electronics terminal block X20.
- Additional safety precautions must be taken, depending on the application, to avoid injury to personnel and damage to machinery.

NOTICE


Switching the motor output at the application inverter with enabled output stage.

Damage to the application inverter.

- The motor output of the application inverter may be switched or disconnected only when the output stage is inhibited.

6.2 7-segment display

6.2.1 Operating displays



- The two 7-segment displays indicate the operating state of the power supply modules and axis modules.
- The displays for the axis modules and the power supply modules are therefore described separately.


6.2.2 Fault display

The application inverter detects any faults that occur and displays them as fault code. Each fault is clearly defined by its fault code and corresponding attributes, as shown below:

- Fault response
- Final state after executing the fault response
- Type of reset response.

The fault codes are indicated as flashing numeric values in the axis and power supply module.

The fault code is displayed in the following display sequence:



In the example, a 2-digit fault code with subfault is shown at the axis module, fault 07.01 in this example.

Fault display at the double-axis module


The double-axis module has one two-digit 7-segment display for each of the two integrated axes. They are located horizontally next to each other. The left display applies to axis 1, the right one to axis 2.

6.3 Operating displays

6.3.1 Operating states of the power supply module – 7-segment display

| Display | Description | State | Comment/action |
|--|---------------------------------|-------------------------------------|--------------------------|
| Displays in normal operation | | | |
| rd | Ready for operation (ready). | No fault/warning: $U_z \geq 100$ V. | Only status display. |
| Display | Description | State | Comment/action |
| Displays of different device statuses | | | |
| 00 | DC link voltage is below 100 V. | 24 V backup mode | Check the supply system. |

6.3.2 Operating displays of the power supply module – LED displays



25761468299

- LED display [1] off: DC link voltage $V_{DCL} < DC\ 60$ V
- LED display [1] is illuminated: DC link voltage $V_{DCL} > DC\ 60$

6.3.3 Operating displays of the axis module – 7-segment display

| Display | Description | State | Comment / action |
|--|---|--|---|
| Displays during boot process | | | |
| b0 | Device passes through several states when loading the firmware (boot) in order to become ready for operation. | <ul style="list-style-type: none"> • Status: Not ready. • Output stage is inhibited. • No communication possible. | <ul style="list-style-type: none"> • Waiting for boot process to finish. • Device stays in this condition: Device is defective. |
| nF | | | |
| nc | | | |
| nH | | | |
| rF | | | |
| -b | | | |
| rb | | | |
| b3 | | | |
| br | | | |
| Display | Description | State | Comment / action |
| Displays of different device statuses | | | |
| 00 | DC link voltage is below 100 V. | 24 V backup mode | Check the supply system. |
| . | Energy-saving mode | | Energy-saving mode active. |
| C0 | Module bus is not ready | | Check the module bus connection. |
| Flashing | | | |

25953079/EN – 01/2020

| Display | Description | State | Comment / action |
|--|---|--|--|
| C1 Flashing | Startup state | | Startup state is active. |
| C2 Flashing | STO active | | The function Safe Torque Off is active. |
| C3 Flashing | Synchronization with bus is incorrect. Process data processing not available. | | <ul style="list-style-type: none"> • Check the bus connection. • Check synchronization setting at device and controller. • Check process data settings at device and controller. |
| C4 Flashing | The encoder evaluation is not ready. | | <ul style="list-style-type: none"> • Encoders are being initialized. • Device stays in this condition: <ul style="list-style-type: none"> – No encoder selected. – "Source actual speed" or "Actual position" parameter shows an encoder that does not exist. |
| C5 Flashing | Motor management is not ready. | | The motor control system is not ready. |
| C6 Flashing | Internal device supply incomplete. | | <ul style="list-style-type: none"> • Supply voltage fault of SMPS • 24 V supply not ready. |
| C7 Flashing | Power section not ready | | The power section is not ready. |
| C8 Flashing | External device not ready. | | The message "Not ready" was detected at the digital input. |
| C9 Flashing | Data flexibilization layer not ready | | Flexibility level is not ready yet. |
| Cd Flashing | Parameter download running. | | One parameter set is being downloaded. |
| Display | Description | State | Comment / action |
| Displays during initialization processes (parameters will be reset to default values) | | | |
| d0 Flashing | Basic initialization. | <ul style="list-style-type: none"> • Status: Not ready. • Output stage is inhibited. • Communication is possible. | Waiting for initialization to finish. |
| d1 Flashing | Initialization at delivery state. | | |
| Display | Description | State | Comment / action |
| Displays in normal operation | | | |
| 01 | Output stage inhibited | <ul style="list-style-type: none"> • Output stage is inhibited. | The drive is not actuated by the output stage. Brake is applied. The motor coasts without brake. This FCB is permanently selected with terminal DI00. But it can be selected by other sources. |

| Display | Description | State | Comment / action |
|---------|----------------------------------|--|--|
| 02 | Stop default | For further information, refer to the FCB description. | Drive function (FCB) "Default stop" active, if not other FCB is selected and the system is "ready". |
| 04 | Manual mode | | Manual mode active |
| 05 | Speed control | | Speed control with internal ramp generator. |
| 06 | Interpolated speed control | | Speed control with setpoints cyclically via bus. The ramp generator is located externally, e.g. in the higher-level controller. |
| 07 | Torque control | | Torque control |
| 08 | Interpolated torque control | | Torque control with setpoints cyclically via bus. |
| 09 | Position control | | Positioning mode with internal ramp generator. |
| 10 | Interpolated positioning control | | Positioning mode with setpoints cyclically via bus. The ramp generator is located externally, e.g. in the higher-level controller. |
| 12 | Reference travel | | The drive performs reference travel. |
| 13 | Stop at application limits | | Deceleration at the application limit. This FCB also becomes active if no other FCB is selected as default FCB. |
| 14 | Emergency stop | | Deceleration at emergency stop limit. |
| 18 | Rotor position identification | | Encoder commutation for synchronous motors. |
| 19 | Position hold control | | Position control on current position. |
| 20 | Jog | | Jog mode active. |
| 21 | Brake test | | Brake is tested by applying torque while brake is closed. |
| 25 | Motor parameter measurement | | Motor parameter measurement active |
| 26 | Stop at user limits | | Serves to stop at user limits. |

6.4 Faults at the power supply module

6.4.1 Fault 49 Power supply module

| | | |
|--|--|---|
| Subfault: 49.1 | | |
| Description: Unknown supply unit | | |
| Response: Remote – critical fault | | |
| | Cause | Measure |
| | Failed to identify supply unit. | Contact SEW-EURODRIVE Service. |
| Subfault: 49.2 | | |
| Description: EEPROM memory – hardware faulty | | |
| Response: Remote – critical fault | | |
| | Cause | Measure |
| | EEPROM cannot be read; initialization error. | Contact SEW-EURODRIVE Service. |
| Subfault: 49.3 | | |
| Description: Internal voltage supply | | |
| Response: Remote – critical fault | | |
| | Cause | Measure |
| | At least one internal supply voltage is faulty. | Switch the power off and on again. Contact SEW-EURODRIVE Service if the error is still present. |
| Subfault: 49.4 | | |
| Description: DC 24 V supply voltage | | |
| Response: Remote – critical fault | | |
| | Cause | Measure |
| | 24 V supply below min. specified 24 V input voltage. | Check the 24 V supply, switch power supply off and on again. Contact SEW-EURODRIVE Service if the error is still present. |
| Subfault: 49.5 | | |
| Description: Fault in hardware component of analog to digital conversion. | | |
| Response: Remote – critical fault | | |
| | Cause | Measure |
| | Measured DC link values outside valid range, or voltage supply of transducers defective. | Contact SEW-EURODRIVE Service. |
| Subfault: 49.6 | | |
| Description: CRC error – power section data | | |
| Response: Remote – critical fault | | |
| | Cause | Measure |
| | Device not calibrated yet. | Contact SEW-EURODRIVE Service. |
| | Initialization error. | Contact SEW-EURODRIVE Service. |
| Subfault: 49.7 | | |
| Description: EEPROM data error | | |
| Response: Remote – critical fault | | |
| | Cause | Measure |
| | Calibration data not plausible. | Contact SEW-EURODRIVE Service. |
| Subfault: 49.8 | | |
| Description: DC link overvoltage | | |
| Response: Remote – critical fault | | |
| | Cause | Measure |
| | Maximum permitted DC link voltage limit exceeded. | – Check brake chopper function, braking resistor, and regenerative energy. – Check project planning of the axis system. |
| Subfault: 49.9 | | |
| Description: DC link overcurrent | | |
| Response: Remote – critical fault | | |
| | Cause | Measure |
| | DC link current too high in motor or generator mode. | – Motoring operation: load too high / check project planning. – Regenerative operation: Braking resistance too low-impedance or short circuit in braking resistor. |

| | | |
|--|---|--|
| Subfault: 49.10 | | |
| Description: Brake chopper short circuit | | |
| | Response: Remote – critical fault | |
| | Cause | Measure |
| | A failed brake chopper was detected in the device. For devices with half-controlled bridge, the thyristors are inhibited. | <ul style="list-style-type: none"> – Check brake chopper circuit connections --> Switch the power off and on again. – If the fault is still present, replace the device. Contact SEW-EURODRIVE Service. |
| Subfault: 49.11 | | |
| Description: Collector emitter voltage monitoring | | |
| | Response: Remote – critical fault | |
| | Cause | Measure |
| | Voltage supply for brake chopper defective. | Check the connection of the braking resistor. |
| | UCE monitoring of brake chopper trips. | Switch the power off and on again. Contact SEW-EURODRIVE Service if the error is still present. |
| | Short circuit in braking resistor. | Check braking resistor and supply cable. |
| | Too much regenerative power. | Check the project planning for the axis system. |
| Subfault: 49.12 | | |
| Description: Temperature sensor (internal) defective | | |
| | Response: Remote – critical fault | |
| | Cause | Measure |
| | Temperature sensor does not respond (e.g. wire break). | Contact SEW-EURODRIVE Service. |
| Subfault: 49.13 | | |
| Description: Overtemperature 105% | | |
| | Response: Remote – critical fault | |
| | Cause | Measure |
| | Maximum permitted heat sink temperature exceeded. | Check the project planning and installation of the axis system. Contact SEW-EURODRIVE Service. |
| Subfault: 49.14 | | |
| Description: Temperature evaluation defective | | |
| | Response: Remote – critical fault | |
| | Cause | Measure |
| | Failed to transfer temperature signals. | Contact SEW-EURODRIVE Service. |
| Subfault: 49.15 | | |
| Description: Capacity utilization 105% | | |
| | Response: Remote – critical fault | |
| | Cause | Measure |
| | Electromechanical utilization of > 105% detected by I2xT model. | <ul style="list-style-type: none"> – Check the project planning and installation of the axis system. – Contact SEW-EURODRIVE Service. |
| Subfault: 49.16 | | |
| Description: Braking resistor temperature monitoring | | |
| | Response: Remote – critical fault | |
| | Cause | Measure |
| | <ul style="list-style-type: none"> – Monitoring of the external braking resistor has tripped. – The temperature of the externally connected braking resistor is too high. | Check the project planning for the axis system. |
| | Incorrect wiring. | Check the installation of the braking resistor. |
| Subfault: 49.17 | | |
| Description: Internal braking resistor utilization 105% | | |
| | Response: Remote – critical fault | |
| | Cause | Measure |
| | Utilization of internal braking resistor reached switch-off threshold of > 105%. | Check the project planning and installation of the axis system. |

| | | |
|--|--|--|
| Subfault: 49.18 | | |
| Description: Internal device temperature | | |
| | Response: Remote – critical fault | |
| | Cause | Measure |
| | Impermissible high device temperature. | <ul style="list-style-type: none"> – Clarify the temperature condition of the axis system. – Check ventilation of the control cabinet. – Check mounting position, fan function. – Check heat sink and fan for dirt and clean them. |
| Subfault: 49.19 | | |
| Description: External fault | | |
| | Response: Remote – critical fault | |
| | Cause | Measure |
| | Another module bus station requested external emergency shutdown. | Eliminate emergency shutdown condition at the module bus station. |
| Subfault: 49.20 | | |
| Description: Utilization 100% | | |
| | Response: Remote – standard fault | |
| | Cause | Measure |
| | Electromechanical utilization of > 100% detected by I2xT model. | <ul style="list-style-type: none"> – Check the project planning and installation of the axis system. – Contact SEW-EURODRIVE Service. |
| Subfault: 49.21 | | |
| Description: Internal braking resistor utilization 100% | | |
| | Response: Remote – standard fault | |
| | Cause | Measure |
| | Utilization of internal braking resistor reached switch-off threshold of > 100%. | <ul style="list-style-type: none"> – Check the braking resistor installation and the project planning of the axis system. – Contact SEW-EURODRIVE Service. |
| Subfault: 49.22 | | |
| Description: Overtemperature 100% | | |
| | Response: Remote – standard fault | |
| | Cause | Measure |
| | Permitted heat sink temperature exceeded. | <ul style="list-style-type: none"> – Check mounting position and fan function. – Check heat sink and fan for dirt and clean them. – Check the project planning and installation of the axis system. |
| Subfault: 49.23 | | |
| Description: Module bus timeout | | |
| | Response: Remote – standard fault | |
| | Cause | Measure |
| | Slave does not receive telegrams. | Check the module bus cable. |
| Subfault: 49.24 | | |
| Description: Module bus initialization | | |
| | Response: Remote – warning | |
| | Cause | Measure |
| | Module bus system not yet initialized. | Check the module bus cable. |
| Subfault: 49.25 | | |
| Description: Module bus CRC error | | |
| | Response: Remote – standard fault | |
| | Cause | Measure |
| | CRC error | Check the module bus cable. |
| Subfault: 49.26 | | |
| Description: Module bus station error | | |
| | Response: Remote – warning | |
| | Cause | Measure |
| | More than 15 module bus stations (axes) connected to module bus master. | Connect a maximum of 15 module bus stations. |

| | | |
|--|--|--|
| Subfault: 49.27 | | |
| Description: Fan function fault | | |
| | Response: Remote – warning | |
| | Cause | Measure |
| | One of the fans not connected or blocked mechanically. | <ul style="list-style-type: none"> – Check the fan plug connector. – Check the fan for mechanical blockage. – Replace the fan. |
| Subfault: 49.28 | | |
| Description: Temperature prewarning | | |
| | Response: Remote – warning | |
| | Cause | Measure |
| | Temperature of heat sink reached prewarning threshold. | <ul style="list-style-type: none"> – Check mounting position and fan function. – Check heat sink and fan for dirt and clean them. – Check the project planning and installation of the axis system. |
| Subfault: 49.29 | | |
| Description: Utilization prewarning | | |
| | Response: Remote – warning | |
| | Cause | Measure |
| | Electromechanical utilization greater than electromechanical utilization of prewarning threshold detected by I2xT model. | Check the project planning and installation of the axis system. |
| Subfault: 49.30 | | |
| Description: Internal braking resistor utilization prewarning | | |
| | Response: Remote – warning | |
| | Cause | Measure |
| | Utilization of internal braking resistor reached prewarning threshold. | Check the connection and project planning of the braking resistor. |
| Subfault: 49.31 | | |
| Description: Braking resistor connection monitoring | | |
| | Response: Remote – warning | |
| | Cause | Measure |
| | Connection monitoring has not detected a connected braking resistor. | Check the connection of the braking resistor. |
| | Connected braking resistor not within configured range. | Check the connection and project planning of the braking resistor. |
| | Short circuit in braking resistor. | Check the connection of the braking resistor. |
| Subfault: 49.32 | | |
| Description: Thermal overload of additional capacity | | |
| | Response: Remote – warning | |
| | Cause | Measure |
| | Additional capacity at full thermal capacity. Braking resistor converts regenerative energy into heat. | Check device utilization and project planning. |

6.5 Faults at the single-axis module/double-axis module

6.5.1 Fault 1 Output stage monitoring

| | | |
|---|--|--|
| Subfault: 1.1 | | |
| Description: Short circuit in motor output terminals | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Overcurrent in output stage or faulty output stage control detected, and output stage inhibited by hardware. | Possible causes for overcurrent are short circuit at the output, excessive motor current, or a defective power output stage. |
| Subfault: 1.2 | | |
| Description: Overcurrent in output stage | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Motor current too high. | Connect a smaller motor. |
| | Current supply | Check the current supply. |
| | Current transformer | Check the current transformer. |
| | Ramp limit deactivated and set ramp time too short. | Increase the ramp time. |
| | Phase module defective. | Check the phase module. |
| | DC 24 V supply voltage unstable. | Check the DC 24 V supply voltage. |
| | Interruption or short circuit on signal lines of phase modules. | Check the signal lines. |

6.5.2 Fault 3 Ground fault

| | | |
|----------------------------------|----------------------------------|--|
| Subfault: 3.1 | | |
| Description: Ground fault | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Ground fault in the motor lead. | Eliminate ground fault in motor lead. |
| | Ground fault in the inverter. | Eliminate ground fault in inverter. |
| | Ground fault in the motor. | Eliminate ground fault in motor. |
| | Ground fault in line components. | Eliminate ground fault in line components. |

6.5.3 Fault 4 Brake chopper

| | | |
|---|---|---|
| Subfault: 4.1 | | |
| Description: Brake chopper overcurrent | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Excessive regenerative power. | Extend the deceleration ramps. |
| | Short circuit detected in braking resistor circuit. | Check the supply cable to the braking resistor. |
| | Braking resistance too high. | Check the technical data of the braking resistor. |
| Subfault: 4.2 | | |
| Description: Brake chopper defective | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Output stage of brake chopper defective. | Replace the defective brake chopper. |

6.5.4 Fault 6 Line fault

| | | |
|--|---------------------------------------|---|
| Subfault: 6.1 | | |
| Description: Line phase failure | | |
| Response: Line phase failure | | |
| | Cause | Measure |
| | Missing line phase detected. | Check the supply system cable. |
| | DC link voltage periodically too low. | Check the configuration of the supply system. |
| | Inadequate line voltage quality. | Check the supply (fuses, contactor). |

6.5.5 Fault 7 DC link

| Subfault: 7.1 Description: DC link overvoltage | | |
|---|--|--|
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Maximum permitted DC link voltage limit exceeded and output stage inhibited by hardware. | <ul style="list-style-type: none"> – Extend the deceleration ramps. – Check the supply cable to the braking resistor. – Check the technical data of the braking resistor. |

6.5.6 Fault 8 Speed monitoring

| Subfault: 8.1 Description: Speed monitoring – motor mode | | |
|---|--|---|
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Speed controller operates at setting limit (mechanical overload or phase failure in supply system or motor). | Increase the delay time set for speed monitoring, or reduce the load. |
| | Encoder not connected correctly. | Check the encoder connection and direction of rotation. If necessary, increase the current limiting or reduce the acceleration values. |
| | Encoder has incorrect direction of rotation. | <ul style="list-style-type: none"> – Check encoder connection and direction of rotation. If necessary, increase current limiting or reduce acceleration values. – Check motor lead and motor, check line phases. |
| Subfault: 8.2 Description: Speed monitoring – generator mode | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Speed controller operates at setting limit (mechanical overload or phase failure in supply system or motor). | Increase the delay time set for speed monitoring, or reduce the regenerative load. |
| | Encoder not connected correctly. | Check the encoder connection and direction of rotation. If necessary, increase the current limiting or reduce the deceleration values. |
| | Encoder has incorrect direction of rotation. | <ul style="list-style-type: none"> – Check the encoder connection and direction of rotation. If necessary, increase the current limiting or reduce the deceleration values. – Check motor cable and motor. Check the line phases. |
| Subfault: 8.3 Description: Maximum speed at motor shaft | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Actual speed exceeded "Maximum speed at motor shaft" limit value (index 8360.9 / 8361.9). This limit value is set at startup matching the motor and gear unit. | Reduce the maximum speed. |

6.5.7 Fault 9 Control mode

| Subfault: 9.1 Description: Magnetization of motor not possible | | |
|--|--|---|
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | The user-defined current limit or output stage monitoring have reduced the possible maximum current to such a degree that the required magnetizing current cannot be set. | <ul style="list-style-type: none"> – Reduce the output stage utilization, e.g. by reducing the PWM frequency or reducing the load. – Increase the user-defined current limit. |
| Subfault: 9.2 Description: Requested operating mode not possible with active control mode | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | The current FCB activated an operating mode. The active control mode does not support this operating mode, for example "position control" or "torque control" with U/f control mode. | Start up control mode that supports the required operating mode. Connect an encoder if necessary. Select an operating mode that is supported by the current control mode. |

| | | |
|---|--|---|
| Subfault: 9.3 | | |
| Description: Absolute rotor position not available | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | The current control mode requires an absolute rotor position. The encoder selected for "Source of actual speed" does not provide an absolute rotor position. | Use an absolute encoder, or identify the rotor position using FCB 18. |
| Subfault: 9.4 | | |
| Description: Correct current supply of motor not possible | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Failed to set required current during premagnetization. | Check the cabling, or disable the function "Current monitoring during premagnetization". |
| Subfault: 9.5 | | |
| Description: Maximum output frequency exceeded | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Maximum output frequency exceeded. | Reduce the maximum speed. |
| Subfault: 9.6 | | |
| Description: Maximum model speed exceeded | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Speed of drive calculated in ELSM® control mode too high for motor control. | If possible, minimize the "Speed/position controller sampling cycle", or reduce the speed. |
| Subfault: 9.8 | | |
| Description: Flux model error | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Rotor flux calculated by motor model not plausible, or calculated internal voltage too small. | <ul style="list-style-type: none"> – Check configuration data. – Check motor data. – Check machine: Idle state or speed too low. – Check the connection cable between inverter and motor. – Contact SEW-EURODRIVE Service. |
| Subfault: 9.9 | | |
| Description: Parameter measurement not possible with active motor type | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Parameter measurement is possible only with "asynchronous" and "synchronous" motor types. No magnetic reluctance motors and LSPM motors. | Select the correct motor type. |
| Subfault: 9.10 | | |
| Description: Rotor stall monitoring | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | The current control cannot hold the load torque. The deviation between stationary setpoint voltage and actual voltage is too large. | Reduce the load torque (hoist) in the controlled system. |
| Subfault: 9.11 | | |
| Description: Standstill current function | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | With the ELSM method, the standstill current function is possible only in combination with rotor position measurement. | <ul style="list-style-type: none"> – Enable rotor position measurement. – Check motor data. |

6.5.8 Fault 10 Data Flexibility

| | | |
|---|---|---|
| Subfault: 10.1 | | |
| Description: Initialization | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Init task error. | The init task has issued a return code ! = 0. Check the program. |
| Subfault: 10.2 | | |
| Description: Illegal operation code | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Illegal opcode in Data Flexibility program. | Contact SEW-EURODRIVE Service. |
| Subfault: 10.3 | | |
| Description: Memory access | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Memory area violated while accessing array. | For example, an array access results in writing beyond the permitted memory range. Check the program. |
| Subfault: 10.4 | | |
| Description: Stack | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Overflow of Data Flexibility stack detected. | Check the program. |
| Subfault: 10.5 | | |
| Description: Division by 0 | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Division by 0. | Check the program. |
| Subfault: 10.6 | | |
| Description: Runtime | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Runtime error/watchdog | Check the program. The program execution time exceeds the permitted time. |
| | PDI or PDO tasks. | Check the program. The execution time of the PDI or PDO task exceeds the permitted time. |
| Subfault: 10.7 | | |
| Description: Calculation result of multiplication/division command too large | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Calculation result of multiplication/division command exceeds 32 bits. | Check the program. |
| | Failed to write calculation result of multiplication/division command into result variable. | Check the program. |
| Subfault: 10.8 | | |
| Description: Illegal connection | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Index used in connect not allowed. | Check the program. The index used either does not exist or is not permitted for access via process data – see parameter list. |
| Subfault: 10.9 | | |
| Description: CRC code | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Wrong CRC checksum of code. | Load the program again. The program memory is corrupt. Unauthorized write access to the program memory. |

| | | |
|---|---|--|
| Subfault: 10.10 | | |
| Description: Setpoint cycle time not supported | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Non-supported setpoint cycle time parameterized. | Set the setpoint cycle time to the default value 1 ms. |
| Subfault: 10.11 | | |
| Description: No application program loaded | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | No Data Flexibility application program loaded. | Load the program or disable Data Flexibility. |
| Subfault: 10.99 | | |
| Description: Unknown error | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Unknown Data Flexibility error. | Contact SEW-EURODRIVE Service. |

6.5.9 Fault 11 Temperature monitoring

| | | |
|--|---|---|
| Subfault: 11.1 | | |
| Description: Heat sink overtemperature | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Maximum permitted heat sink temperature exceeded. The capacity utilization is possibly too high. | <ul style="list-style-type: none">– Reduce the load.– Reduce the rms value of the current.– Reduce the PWM frequency.– Ensure sufficient cooling.– Reduce the ambient temperature. |
| Subfault: 11.2 | | |
| Description: Heat sink utilization – prewarning | | |
| | Response: Heat sink utilization – prewarning | |
| | Cause | Measure |
| | High thermal load on heat sink of device, and prewarning threshold reached. | <ul style="list-style-type: none">– Reduce the load.– Reduce the rms value of the output current.– Reduce the PWM frequency.– Ensure sufficient cooling.– Reduce the ambient temperature. |
| Subfault: 11.3 | | |
| Description: Device utilization | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | The temperature has reached or exceeded the switch-off threshold. Possible causes: Mean output current too high. | Reduce the load. |
| | PWM frequency too high. | Reduce the PWM frequency. |
| | Ambient temperature too high. | Ensure sufficient cooling. |
| | Unfavorable air convection. | Check air convection. |
| | Fan defective. | Check the fan and replace if necessary. |
| | Subfault: 11.5 | |
| Description: Electromechanical utilization | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Electromechanical components of device overloaded by excessive continuous current. | Reduce the load. If necessary, reduce the rms value of the current. |
| Subfault: 11.6 | | |
| Description: Electromechanical utilization – prewarning | | |
| | Response: Electromechanical utilization – prewarning | |
| | Cause | Measure |
| | High load on electromechanical components of device due to high continuous current. Prewarning threshold reached. | <ul style="list-style-type: none">– Reduce the load.– Reduce the PWM frequency.– Reduce the rms value of the current.– Reduce the ambient temperature. |

| | | |
|--|---|--------------------------------|
| Subfault: 11.7 | | |
| Description: Wire break at temperature sensor of heat sink | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Wire break at temperature sensor of heat sink. | Contact SEW-EURODRIVE Service. |
| Subfault: 11.8 | | |
| Description: Short circuit at temperature sensor of heat sink | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Short circuit at temperature sensor of heat sink. | Contact SEW-EURODRIVE Service. |

6.5.10 Fault 12 Brake

| | | |
|---|--|--|
| Subfault: 12.1 | | |
| Description: Brake output | | |
| Response: Application stop + output stage inhibit | | |
| | Cause | Measure |
| | No brake connected. | Check the connection of the brake. |
| | Brake cable disconnected in switched-on state. | Check the connection of the brake. |
| | Overload due to overcurrent > 2 A | Check the sequential profile of brake control. |
| | Overload due to excessive connection (> 0.5 Hz) | Check the sequential profile of brake control. |
| | Monitoring works only with parameter setting "Brake installed" and "Brake applied". | Make sure that the connected brake is permitted. |
| Subfault: 12.2 | | |
| Description: DC 24 V brake voltage | | |
| Response: Application stop + output stage inhibit | | |
| | Cause | Measure |
| | DC 24 V supply voltage not within permitted tolerance of $\pm 10\%$. | Check the DC 24 V supply voltage. |
| | Monitoring is only active with parameter settings "Brake installed" and "Brake applied". | Check the parameter setting. |

6.5.11 Error 13 encoder 1 fault

| | | |
|---|--|---|
| Subfault: 13.1 | | |
| Description: Position comparison check | | |
| Response: Encoder 1 – latest critical fault | | |
| | Cause | Measure |
| | Faulty comparison between raw position and track counter of absolute encoders. | <ul style="list-style-type: none"> – Check the track signal wiring. – Check interference sources (e.g. from the area of EMC). – Replace encoder. – Replace the card. Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty. |
| Subfault: 13.2 | | |
| Description: Unknown encoder type | | |
| Response: Encoder 1 – latest critical fault | | |
| | Cause | Measure |
| | Encoder type not known and not supported by device. | <ul style="list-style-type: none"> – Check the encoder type. – Contact SEW-EURODRIVE Service. Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty. |

| | | |
|---|--|---|
| Subfault: 13.3 | | |
| Description: Invalid data | | |
| Response: Encoder 1 – latest critical fault | | |
| | Cause | Measure |
| | Invalid encoder nameplate data (measuring steps/pulses per revolution/multi-turn). | <ul style="list-style-type: none"> – Check the startup parameters. – Replace encoder. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 13.4 | | |
| Description: Track measurement error | | |
| Response: Encoder 1 – latest critical fault | | |
| | Cause | Measure |
| | Error during track measurement. | <ul style="list-style-type: none"> – Switch the device off and on again. – Check the wiring. – Check interference sources (e.g. from EMC). – Check the encoder. Replace if necessary. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 13.5 | | |
| Description: Internal warning | | |
| Response: Encoder – warning | | |
| | Cause | Measure |
| | Encoder signaled warning. | <ul style="list-style-type: none"> – Check the wiring. – Check interference sources (light beam interrupted, reflector, data cables, etc.). – Clean the sensor. |
| Subfault: 13.6 | | |
| Description: Signal level too low | | |
| Response: Encoder 1 – latest critical fault | | |
| | Cause | Measure |
| | Vector below permitted limit during signal level monitoring. | <ul style="list-style-type: none"> – Check the wiring. – Check interference sources (e.g. from the area of EMC). – Check the encoder. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 13.7 | | |
| Description: Signal level too high | | |
| Response: Encoder 1 – latest critical fault | | |
| | Cause | Measure |
| | Vector exceeds permitted limit during signal level monitoring. | <p>Check the gear ratio of the resolver in use.</p> <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 13.8 | | |
| Description: Signal level monitoring | | |
| Response: Encoder 1 – latest critical fault | | |
| | Cause | Measure |
| | Vector exceeds permitted limit during signal level monitoring. | <p>Check the resolver mounting position.</p> <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 13.9 | | |
| Description: Quadrant check | | |
| Response: Encoder 1 – latest critical fault | | |
| | Cause | Measure |
| | Error checking quadrants (sine encoder). | <ul style="list-style-type: none"> – Switch the device off and on again. – Check the wiring. – Check interference sources (e.g. from the area of EMC). – Check the encoder. Replace if necessary. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |

| | | |
|---|--|--|
| Subfault: 13.10 | | |
| Description: Position tolerance range monitoring | | |
| Response: Encoder 1 – latest critical fault | | |
| | Cause | Measure |
| | Position outside tolerance range. | <ul style="list-style-type: none"> – Check the startup parameters. – Check the wiring. – Check interference sources (light beam interrupted, reflector, data cables, etc.). – Replace encoder. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 13.11 | | |
| Description: Data timeout | | |
| Response: Encoder 1 – latest critical fault | | |
| | Cause | Measure |
| | Encoder process data timeout. | <ul style="list-style-type: none"> – Check interference sources (e.g. from the area of EMC). – Check the startup parameters. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 13.12 | | |
| Description: Emergency | | |
| Response: Encoder 1 – latest critical fault | | |
| | Cause | Measure |
| | Encoder signaled emergency. | <ul style="list-style-type: none"> – Check interference sources (e.g. from the area of EMC). – Check the startup parameters. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 13.13 | | |
| Description: Error during initialization | | |
| Response: Encoder 1 – latest fault | | |
| | Cause | Measure |
| | Communication error during initialization. | <ul style="list-style-type: none"> – Check parameterization. – Check baud rate. – Ensure that the CANopen interface on the encoder (Node ID) is correctly adjusted. – Check the wiring. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 13.14 | | |
| Description: Communication | | |
| Response: Encoder 1 – latest fault | | |
| | Cause | Measure |
| | Faulty communication with encoder. | <ul style="list-style-type: none"> – Check the voltage supply. – Check interference sources (e.g. from the area of EMC). – Check the wiring. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |

| Subfault: 13.15 | | |
|--|---|---|
| Description: System error | | |
| | Response: Encoder 1 – latest critical fault | |
| | Cause | Measure |
| | System error while evaluating encoder. | <ul style="list-style-type: none"> – Ensure that the multi-turn encoder is within the configured path range. – Check the limits. – Check for correct settings of encoder numerator/denominator factors. – Check interference sources (e.g. from the area of EMC). – Check the startup parameters. – Switch the device off and on again. – If the fault occurs repeatedly, contact SEW-EURODRIVE Service. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 13.16 | | |
| Description: Permanent high level in data line – critical | | |
| | Response: Encoder 1 – latest critical fault | |
| | Cause | Measure |
| | Permanent high level of data signal. | <ul style="list-style-type: none"> – Check the wiring. – Check the encoder. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 13.17 | | |
| Description: Permanent high level in data line | | |
| | Response: Encoder 1 – latest fault | |
| | Cause | Measure |
| | Permanent high level of data signal. | <ul style="list-style-type: none"> – Check the wiring. – Check the encoder. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 13.18 | | |
| Description: Permanent low level in data line – critical | | |
| | Response: Encoder 1 – latest critical fault | |
| | Cause | Measure |
| | Permanent low level of data signal. | <ul style="list-style-type: none"> – Check the wiring. – Check the encoder. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 13.19 | | |
| Description: Permanent low level in data line | | |
| | Response: Encoder 1 – latest fault | |
| | Cause | Measure |
| | Permanent low level of data signal. | <ul style="list-style-type: none"> – Check the wiring. – Check the encoder. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 13.20 | | |
| Description: SSI error bit – critical | | |
| | Response: Encoder 1 – latest critical fault | |
| | Cause | Measure |
| | Error bit set in SSI protocol. | <ul style="list-style-type: none"> – Check the startup parameters. – Check the settings at the SSI encoder (fault bit). – Check the wiring. – Check interference sources (light beam interrupted, reflector, data cables, etc.). – Replace encoder. <p>Note: In "Emergency mode" manual mode, you can move the drive even with a fault in an external position encoder.</p> |

| | | |
|--|---|--|
| Subfault: 13.21 | | |
| Description: SSI error bit | | |
| | Response: Encoder 1 – latest fault | |
| | Cause | Measure |
| | Error bit set in SSI protocol. | <ul style="list-style-type: none"> – Check the startup parameters. – Check the settings at the SSI encoder (fault bit). – Check the wiring. – Check interference sources (light beam interrupted, reflector, data cables, etc.). – Replace encoder. <p>Note: In "Emergency mode" manual mode, you can move the drive even with a fault in an external position encoder.</p> |
| Subfault: 13.22 | | |
| Description: Internal fault – critical | | |
| | Response: Encoder 1 – latest critical fault | |
| | Cause | Measure |
| | Encoder signaled internal fault. | <ul style="list-style-type: none"> – Check the wiring. – Check interference sources (light beam interrupted, reflector, data cables, etc.). – Replace encoder. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 13.23 | | |
| Description: Internal fault | | |
| | Response: Encoder 1 – latest fault | |
| | Cause | Measure |
| | Encoder signaled internal fault. | <ul style="list-style-type: none"> – Check the wiring. – Check interference sources (light beam interrupted, reflector, data cables, etc.). – Replace encoder. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 13.24 | | |
| Description: Travel range exceeded | | |
| | Response: Encoder 1 – latest fault | |
| | Cause | Measure |
| | Current position mode (index 8381.10) does not allow for larger travel range. | <p>Check travel range.</p> <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 13.25 | | |
| Description: Error during encoder startup | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Fatal error during encoder startup. | <p>Switch the device off and on again.</p> <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 13.26 | | |
| Description: Digital motor integration fault – critical | | |
| | Response: Encoder 1 – latest critical fault | |
| | Cause | Measure |
| | Encoder of "Digital motor integration" signaled a component fault. | <ul style="list-style-type: none"> – Check interference sources. – Replace encoder. |
| Subfault: 13.27 | | |
| Description: Digital motor integration fault | | |
| | Response: Encoder 1 – latest fault | |
| | Cause | Measure |
| | Encoder of "Digital motor integration" signaled a component fault. | <ul style="list-style-type: none"> – Check interference sources – Replace encoder. |

| | | |
|---|--|-------------------------------|
| Subfault: 13.28 | | |
| Description: Digital motor integration warning | | |
| Response: Encoder – warning | | |
| | Cause | Measure |
| | Encoder of "Digital motor integration" signaled a warning. | – Check interference sources. |

6.5.12 Fault 14 Encoder 2

| | | |
|---|--|---|
| Subfault: 14.1 | | |
| Description: Position comparison check | | |
| Response: Encoder 2 – latest critical fault | | |
| | Cause | Measure |
| | Faulty comparison between raw position and track counter of absolute encoders. | <ul style="list-style-type: none"> – Check the track signal wiring. – Check interference sources (e.g. from the area of EMC). – Replace encoder. – Replace the card. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 14.2 | | |
| Description: Unknown encoder type | | |
| Response: Encoder 2 – latest critical fault | | |
| | Cause | Measure |
| | Encoder type not known and not supported by device. | <ul style="list-style-type: none"> – Check the encoder type. – Contact SEW-EURODRIVE Service. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 14.3 | | |
| Description: Invalid data | | |
| Response: Encoder 2 – latest critical fault | | |
| | Cause | Measure |
| | Invalid encoder nameplate data (measuring steps/pulses per revolution/multi-turn). | <ul style="list-style-type: none"> – Check the startup parameters. – Replace encoder. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 14.4 | | |
| Description: Track measurement error | | |
| Response: Encoder 2 – latest critical fault | | |
| | Cause | Measure |
| | Error during track measurement. | <ul style="list-style-type: none"> – Switch the device off and on again. – Check the wiring. – Check interference sources (e.g. from the area of EMC). – Check the encoder. Replace if necessary. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 14.5 | | |
| Description: Internal warning | | |
| Response: Encoder – warning | | |
| | Cause | Measure |
| | Encoder signaled warning. | <ul style="list-style-type: none"> – Check the wiring. – Check interference sources (light beam interrupted, reflector, data cables, etc.). – Clean the sensor. |

| Subfault: 14.6 | | |
|---|--|---|
| Description: Signal level too low | | |
| | Response: Encoder 2 – latest critical fault | |
| | Cause | Measure |
| | Vector below permitted limit during signal level monitoring. | <ul style="list-style-type: none"> – Check the wiring. – Check interference sources (e.g. from the area of EMC). – Check the encoder. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 14.7 | | |
| Description: Signal level too high | | |
| | Response: Encoder 2 – latest critical fault | |
| | Cause | Measure |
| | Vector exceeds permitted limit during signal level monitoring. | <p>Check the gear ratio of the resolver in use.</p> <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 14.8 | | |
| Description: Signal level monitoring | | |
| | Response: Encoder 2 – latest critical fault | |
| | Cause | Measure |
| | Vector below permitted limit during signal level monitoring. | <p>Check the resolver mounting position.</p> <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 14.9 | | |
| Description: Quadrant check | | |
| | Response: Encoder 2 – latest critical fault | |
| | Cause | Measure |
| | Error checking quadrants (sine encoder). | <ul style="list-style-type: none"> – Switch the device off and on again. – Check the wiring. – Check interference sources (e.g. from the area of EMC). – Check the encoder. Replace if necessary. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 14.10 | | |
| Description: Position tolerance range monitoring | | |
| | Response: Encoder 2 – latest critical fault | |
| | Cause | Measure |
| | Position outside tolerance range. | <ul style="list-style-type: none"> – Check the startup parameters. – Check the wiring. – Check interference sources (light beam interrupted, reflector, data cables, etc.). – Replace encoder. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 14.11 | | |
| Description: Data timeout | | |
| | Response: Encoder 2 – latest critical fault | |
| | Cause | Measure |
| | Encoder process data timeout. | <ul style="list-style-type: none"> – Check interference sources (e.g. from the area of EMC). – Check the startup parameters. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |

| | | |
|--|---|--|
| Subfault: 14.12 | | |
| Description: Emergency | | |
| | Response: Encoder 2 – latest critical fault | |
| | Cause | Measure |
| | Encoder signaled emergency. | <ul style="list-style-type: none"> – Check interference sources (e.g. from the area of EMC). – Check the startup parameters. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 14.13 | | |
| Description: Error during initialization | | |
| | Response: Encoder 2 – latest fault | |
| | Cause | Measure |
| | Communication error during initialization. | <ul style="list-style-type: none"> – Check parameterization. – Check baud rate. – Ensure that the CANopen interface on the encoder (Node ID) is correctly adjusted. – Check the wiring. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 14.14 | | |
| Description: Communication | | |
| | Response: Encoder 2 – latest fault | |
| | Cause | Measure |
| | Faulty communication with encoder. | <ul style="list-style-type: none"> – Check the voltage supply. – Check interference sources (e.g. from the area of EMC). – Check the wiring. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 14.15 | | |
| Description: System error | | |
| | Response: Encoder 2 – latest critical fault | |
| | Cause | Measure |
| | System error while evaluating encoder. | <ul style="list-style-type: none"> – Make sure that the multi-turn encoder is within the configured track area. – Check the limits. – Check for correct settings of encoder numerator/denominator factors. – Check interference sources (e.g. from the area of EMC). – Check the startup parameters. – Switch the device off and on again. – If the fault occurs repeatedly, contact SEW-EURODRIVE Service. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 14.16 | | |
| Description: Permanent high level in data line – critical | | |
| | Response: Encoder 2 – latest critical fault | |
| | Cause | Measure |
| | Permanent high level of data signal. | <ul style="list-style-type: none"> – Check the wiring. – Check the encoder. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 14.17 | | |
| Description: Permanent high level in data line | | |
| | Response: Encoder 2 – latest fault | |
| | Cause | Measure |
| | Permanent high level of data signal. | <ul style="list-style-type: none"> – Check the wiring. – Check the encoder. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |

| | | |
|---|-------------------------------------|--|
| Subfault: 14.18 | | |
| Description: Permanent low level in data line – critical | | |
| Response: Encoder 2 – latest critical fault | | |
| | Cause | Measure |
| | Permanent low level of data signal. | <ul style="list-style-type: none"> – Check the wiring. – Check the encoder. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 14.19 | | |
| Description: Permanent low level in data line | | |
| Response: Encoder 2 – latest fault | | |
| | Cause | Measure |
| | Permanent low level of data signal. | <ul style="list-style-type: none"> – Check the wiring. – Check the encoder. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 14.20 | | |
| Description: SSI error bit – critical | | |
| Response: Encoder 2 – latest critical fault | | |
| | Cause | Measure |
| | Error bit set in SSI protocol. | <ul style="list-style-type: none"> – Check the startup parameters. – Check the settings at the SSI encoder (fault bit). – Check the wiring. – Check interference sources (light beam interrupted, reflector, data cables, etc.). – Replace encoder. <p>Note: In "Emergency mode" manual mode, you can move the drive even with a fault in an external position encoder.</p> |
| Subfault: 14.21 | | |
| Description: SSI error bit | | |
| Response: Encoder 2 – latest fault | | |
| | Cause | Measure |
| | Error bit set in SSI protocol. | <ul style="list-style-type: none"> – Check the startup parameters. – Check the settings at the SSI encoder (fault bit). – Check the wiring. – Check interference sources (light beam interrupted, reflector, data cables, etc.). – Replace encoder. <p>Note: In "Emergency mode" manual mode, you can move the drive even with a fault in an external position encoder.</p> |
| Subfault: 14.22 | | |
| Description: Internal fault – critical | | |
| Response: Encoder 2 – latest critical fault | | |
| | Cause | Measure |
| | Encoder signaled internal fault. | <ul style="list-style-type: none"> – Check the wiring. – Check interference sources (light beam interrupted, reflector, data cables, etc.). – Replace encoder. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |
| Subfault: 14.23 | | |
| Description: Internal fault | | |
| Response: Encoder 2 – latest fault | | |
| | Cause | Measure |
| | Encoder signaled internal fault. | <ul style="list-style-type: none"> – Check the wiring. – Check interference sources (light beam interrupted, reflector, data cables, etc.). – Replace encoder. <p>Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p> |

| | | |
|--|---|---|
| Subfault: 14.24 | | |
| Description: Travel range exceeded | | |
| | Response: Encoder 2 – latest fault | |
| | Cause | Measure |
| | Current position mode (index 8381.10) does not allow for larger travel range. | Check travel range. Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty. |
| Subfault: 14.25 | | |
| Description: Error during encoder startup | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Fatal error during encoder startup. | Switch the device off and on again. Note: In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty. |

6.5.13 Fault 16 Startup

| | | |
|---|--|---|
| Subfault: 16.1 | | |
| Description: Motor not started up | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Motor not started up or not started up completely. | Perform complete motor startup. |
| Subfault: 16.2 | | |
| Description: Cannot calculate controller parameters | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Delay of encoder in use too long to calculate required filter coefficients. | Use an encoder with a shorter delay, or contact SEW-EURODRIVE Service. |
| Subfault: 16.3 | | |
| Description: Thermal motor model not possible | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Invalid parameters for thermal motor model or for drive enable although starting up thermal model not yet completed. | Check the parameters of the thermal motor model, and perform startup. |
| Subfault: 16.5 | | |
| Description: Current limit smaller than magnetizing current of the motor | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Current limit smaller than magnetizing current of the motor calculated by active control mode. | Increase the current limit. Required magnetizing current: See diagnostics parameters of control mode. |
| Subfault: 16.6 | | |
| Description: Control mode not possible | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Wrong control mode selected for the motor. | Choose a control mode that matches the selected motor. |
| Subfault: 16.7 | | |
| Description: PWM frequency not possible | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Specified PWM frequency not allowed for this power output stage. | Choose another PWM frequency. For possible PWM frequencies, refer to the device configuration data. |
| Subfault: 16.8 | | |
| Description: Temperature sensor motor 1 | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Faulty startup of temperature sensor of motor 1. | Perform startup again. |

| | | |
|---|--|---|
| Subfault: 16.9 | | |
| Description: Temperature sensor motor 2 | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Faulty startup of temperature sensor of motor 2. | Perform startup again. |
| Subfault: 16.10 | | |
| Description: Actual position source not assigned | | |
| Response: Application stop + output stage inhibit | | |
| | Cause | Measure |
| | Active control mode requires an encoder for position mode. | – Assign actual position source in encoder assignment of the active drive train (Index 8565.3 or 8566.3). – If no encoder is installed, activate the FCBs only using "torque control" or "speed control" operating mode. |
| Subfault: 16.11 | | |
| Description: Motor data calculation error | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Motor startup not possible because of inconsistent motor data or wrong device configuration data. | Check the motor data for plausibility, or contact SEW-EURODRIVE Service. |
| Subfault: 16.12 | | |
| Description: Motor data write sequence | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Subindex 1 not written to zero before writing electrical startup parameters (index 8357, 8360, 8394, 8420 or 8358, 8361, 8395, 8421). | Reset the fault. Set parameters 8360/1 or 8361/1 to "0" before writing additional parameters. |
| Subfault: 16.20 | | |
| Description: Nominal speed too high or nominal frequency too low | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | During startup using nameplate data: Nominal speed too high or nominal frequency too low. The resulting number of pole pairs is 0. | Enter plausible motor data (nominal speed and nominal frequency). |
| Subfault: 16.21 | | |
| Description: Nominal slip negative | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | During startup using nameplate data, the calculated nominal slip is negative: Nominal frequency too low, or nominal speed too high, or number of pole pairs too high. | Enter plausible motor data (nominal frequency, nominal speed, number of pole pairs). |
| Subfault: 16.22 | | |
| Description: Specify the number of pole pairs | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | During startup using nameplate data: It is not possible to calculate the number of pole pairs accurately from nominal frequency and nominal speed. | Enter the number of pole pairs. |
| Subfault: 16.23 | | |
| Description: Plausibility check failed | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | During startup using nameplate data: The estimated nominal power does not match the entered nominal power. | Check entered nameplate data for plausibility. |
| Subfault: 16.24 | | |
| Description: Speed controller sampling cycle not possible with current PWM frequency or current control mode | | |
| Response: Application stop + output stage inhibit | | |
| | Cause | Measure |
| | At a PWM frequency of "2.5 kHz", only the speed controller sampling cycle of 2 ms is permitted. For the ELSM® control mode, the only permitted speed controller sampling cycles are 1 ms and 2 ms. | Increase PWM frequency or increase sampling cycle of speed controller to 2 ms. Set the sampling cycle to 1 ms or 2 ms for ELSM® control mode. |

| | | |
|---|--|--|
| Subfault: 16.25 | | |
| Description: User-defined current limit too low for standstill current | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | User-defined current limit value too small for minimum standstill current. | Increase the user-defined current limit, or disable the standstill current function. |
| Subfault: 16.26 | | |
| Description: Nominal values incomplete or implausible | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | During startup using nameplate data: Nominal voltage, nominal current, nominal speed or nominal torque are not entered or are not plausible. | Enter or check nominal voltage, nominal current, nominal speed, and nominal torque. |
| Subfault: 16.27 | | |
| Description: Maximum current or maximum torque not plausible | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | During startup using nameplate data: Maximum current or maximum torque not entered, or maximum current and maximum torque not plausible. | Check the maximum current and maximum torque. |
| Subfault: 16.30 | | |
| Description: Faulty EtherCAT® EEPROM configuration state | | |
| | Response: Warning | |
| | Cause | Measure |
| | Faulty EtherCAT®/SBus ^{PLUS} EEPROM configuration status. EEPROM not loaded; binary file not loaded. | Contact SEW-EURODRIVE Service. |
| | Faulty EEPROM loading procedure. | Contact SEW-EURODRIVE Service. |
| | Faulty EEPROM checksum. | Contact SEW-EURODRIVE Service. |

6.5.14 Fault 17 Internal processor fault

| | | |
|-------------------------------------|--------------------------------|--------------------------------|
| Subfault: 17.7 | | |
| Description: Exception error | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Exception trap in CPU. | Contact SEW-EURODRIVE Service. |

6.5.15 Fault 18 Software error

| | | |
|---|--|---|
| Subfault: 18.1 | | |
| Description: Motor management | | |
| | Response: Output stage inhibit System state: Fault acknowledgment with CPU reset | |
| | Cause | Measure |
| | Error detected at motor management interface. | – Switch the device off and on again. – Contact SEW-EURODRIVE Service if the fault persists. |
| Subfault: 18.3 | | |
| Description: Task system warning | | |
| | Response: Warning | |
| | Cause | Measure |
| | Error while processing internal task system. This may be a timeout for cyclical tasks, for example. | – Acknowledge the warning. – Contact SEW-EURODRIVE Service if the warning occurs regularly. |
| Subfault: 18.4 | | |
| Description: Task system | | |
| | Response: Output stage inhibit System state: Fault acknowledgment with CPU reset | |
| | Cause | Measure |
| | A fault was detected during the processing of the internal task system. This may be a timeout for cyclical tasks, for example. | – Switch the device off and on again. – Contact SEW-EURODRIVE Service if the fault persists. |

| | | |
|---|---|--|
| Subfault: 18.7 | | |
| Description: Fatal error | | |
| | Response: Output stage inhibit System state: Fault acknowledgment with CPU reset | |
| | Cause | Measure |
| | Fatal software error. | <ul style="list-style-type: none"> – Switch the device off and on again. – If the fault occurs repeatedly, replace the device and send it together with the fault number to SEW-EURODRIVE. For further support, contact SEW-EURODRIVE Service. |
| Subfault: 18.8 | | |
| Description: Invalid fault code | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Invalid fault code requested. | <ul style="list-style-type: none"> – Switch the device off and on again. – Contact SEW-EURODRIVE Service if the fault persists. |
| Subfault: 18.9 | | |
| Description: Internal software error | | |
| | Response: Output stage inhibit System state: Fault acknowledgment with CPU reset | |
| | Cause | Measure |
| | The software reports an unexpected event. | <ul style="list-style-type: none"> – Switch the device off and on again. – If the fault occurs repeatedly, replace the device and send it together with the fault number to SEW-EURODRIVE. For further support, contact SEW-EURODRIVE Service. |
| Subfault: 18.10 | | |
| Description: Watchdog | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Software no longer operates within intended cycle time. | <ul style="list-style-type: none"> – Switch the device off and on again. – Contact SEW-EURODRIVE Service if the fault persists. |
| Subfault: 18.12 | | |
| Description: Configuration data | | |
| | Response: Output stage inhibit System state: Fault acknowledgment with CPU reset | |
| | Cause | Measure |
| | Configuration data not plausible or cannot be interpreted by active firmware version. | Update the firmware or load valid configuration data. |
| Subfault: 18.13 | | |
| Description: Calibration data | | |
| | Response: Output stage inhibit System state: Fault acknowledgment with CPU reset | |
| | Cause | Measure |
| | Calibration data not plausible. | Load valid calibration data. |

6.5.16 Fault 19 Process data

| | | |
|---|---|----------------------------------|
| Subfault: 19.1 | | |
| Description: Torque setpoint violation | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Implausible values specified as torque setpoints. | Adjust torque setpoints. |
| Subfault: 19.2 | | |
| Description: Position setpoint violation | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Position setpoint outside software limit switches. | Check the position setpoint. |
| | Position setpoint outside modulo range. | Check position setpoint. |
| | Position in user unit generates number overflow in the system unit. | Check the position in user unit. |

| | | |
|---|--|---|
| Subfault: 19.3 | | |
| Description: Speed setpoint violation | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Specified rotational speed setpoints not plausible. | Adjust rotational speed setpoints. |
| Subfault: 19.4 | | |
| Description: Acceleration setpoint violation | | |
| | Response: Emergency stop + output stage inhibit | |
| | Cause | Measure |
| | The specified acceleration setpoints are not plausible. Only a value range of ≥ 0 is permitted. | Adjust acceleration setpoints. |
| Subfault: 19.5 | | |
| Description: Drive function does not exist | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Non-existing drive function (FCB) selected via process data. | Specify an existing FCB number for FCB activation via process data. |
| Subfault: 19.6 | | |
| Description: Mass moment of inertia setpoint violation | | |
| | Response: Emergency stop + output stage inhibit | |
| | Cause | Measure |
| | Implausible values specified as mass moment of inertia setpoints. Only a value range of ≥ 0 is permitted. | Adjust the setpoints for the mass moment of inertia. |
| Subfault: 19.7 | | |
| Description: Referencing missing | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Activated function permitted only with referenced encoder. | Reference the encoder first, then activate the function. |
| Subfault: 19.8 | | |
| Description: Drive train changeover not allowed | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Drive train changeover requested while output stage is enabled. | Inhibit the output stage before changing to another drive train. |
| Subfault: 19.9 | | |
| Description: Jerk setpoint violation | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Jerk values not plausible. | Adjust jerk setpoints. |

6.5.17 Fault 20 Device monitoring

| | | |
|--|---|---|
| Subfault: 20.1 | | |
| Description: Supply voltage fault | | |
| | Response: Output stage inhibit System state: Fault acknowledgment with CPU reset | |
| | Cause | Measure |
| | Internal electronics supply voltage or externally connected DC 24 V standby supply voltage outside permitted voltage range. | Check the voltage level of the external DC 24 V standby supply voltage and check for correct connection. If required, correct. – Acknowledge the fault. – If the fault occurs repeatedly, replace the device. For further support, contact SEW-EURODRIVE Service. |

| | | |
|--|---|--|
| Subfault: 20.2 | | |
| Description: Supply voltage overload | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | For MOVIDRIVE® system, the current load of the current paths of the DC 24 V standby supply voltage inside the device is too high. The device signal output of the device was de-energized because of the fault message. | Identify the consumer that is overloading the internal supply voltage: 1) Remove all external consumers: – At the digital outputs of the basic device. – At options that may be present. – At all encoder connections. – At other consumers at the DC 24 V output voltage terminals. 2) Acknowledge the fault. 3) Reconnect the consumers with the device, one after the other, until the fault message appears once again. 4) To eliminate the fault, connect a consumer with a lower current consumption or eliminate the short circuit. |
| Subfault: 20.7 | | |
| Description: Internal hardware fault | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Fault in the device hardware. | – Acknowledge the fault. – If the fault occurs repeatedly, replace the device. For further support, contact SEW-EURODRIVE Service. |
| Subfault: 20.8 | | |
| Description: Fan warning | | |
| | Response: Warning with self-reset | |
| | Cause | Measure |
| | Fan function impaired. | Check the fan for proper functioning. |
| Subfault: 20.9 | | |
| Description: Fan fault | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Fan defective. | Contact SEW-EURODRIVE Service. |
| Subfault: 20.10 | | |
| Description: Fan supply voltage fault | | |
| | Response: Emergency stop + output stage inhibit | |
| | Cause | Measure |
| | Supply voltage of fan missing. | Check the connection or establish a connection. |
| Subfault: 20.11 | | |
| Description: STO – switching delay | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Switching delay between STO signals F-STO_P1 and F-STO_P2. | – Check the STO wiring. – Check the STO wiring before acknowledging the fault, and make sure that both STO signals are switched to low level. |

6.5.18 Fault 21 Digital motor integration 1

| | | |
|---|---|---|
| Subfault: 21.1 | | |
| Description: Communication error | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Communication error detected on the interface of the "digital motor integration". | Check the cabling. |
| Subfault: 21.2 | | |
| Description: Slave required | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Device started up with a drive with "digital motor integration" but no drive with "Digital motor integration" is connected. | Connect a drive with "digital motor integration" matching start-up, or perform a new startup. |

| | | |
|---|--|--|
| Subfault: 21.3 | | |
| Description: Incompatible driving motor | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Connected drive not compatible with started-up drive. | Connect a drive that matches startup, or perform a new startup. |
| Subfault: 21.4 | | |
| Description: Invalid label | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | The connected drive contains invalid data. | Replace the drive. |
| Subfault: 21.5 | | |
| Description: Incompatible slave | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | The connected slave of "digital motor integration" cannot be used with this inverter firmware. | Update inverter or slave. |
| Subfault: 21.6 | | |
| Description: Overload/short circuit on the interface | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Short circuit in the cabling of components of "Digital motor integration" | Check the cabling of the component of "digital motor integration". |
| | Voltage of "Digital motor integration" component too low. | Check the voltage supply of the component. |

6.5.19 Fault 22 Digital motor integration 2

| | | |
|--|---|--|
| Subfault: 22.1 | | |
| Description: Communication error | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Communication error detected on the interface of the "digital motor integration". | Check the cabling. |
| Subfault: 22.2 | | |
| Description: Slave required | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Device started up with a drive with "digital motor integration" but no drive with "Digital motor integration" is connected. | Connect a drive with "digital motor integration" matching startup, or perform a new startup. |
| Subfault: 22.3 | | |
| Description: Incompatible driving motor | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Connected drive not compatible with started-up drive. | Connect a drive that matches startup, or perform a new startup. |
| Subfault: 22.4 | | |
| Description: Invalid label | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | The connected drive contains invalid data. | Replace the drive. |
| Subfault: 22.5 | | |
| Description: Incompatible slave | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | The connected slave of "digital motor integration" cannot be used with this inverter firmware. | Update inverter or slave. |

| | | |
|---|---|---|
| Subfault: 22.6 | | |
| Description: Overload/short circuit on the interface | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Short circuit in the cabling of components of "Digital motor integration" | Check the cabling of the "Digital motor integration" component. |
| | Voltage of "Digital motor integration" component too low. | Check the voltage supply of the component. |

6.5.20 Fault 23 Power section

| | | |
|--|---|---|
| Subfault: 23.1 | | |
| Description: Warning | | |
| | Response: Warning with self-reset | |
| | Cause | Measure |
| | Power section fault with fault response of the type "Warning". | See also "Power section subcomponent" fault status. |
| Subfault: 23.2 | | |
| Description: Fault | | |
| | Response: Emergency stop + output stage inhibit | |
| | Cause | Measure |
| | Power section fault with fault response of the type "Standard". | See also "Power section subcomponent" fault status. |
| Subfault: 23.3 | | |
| Description: Critical fault | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Power section fault with fault response of the type "Critical fault". | See also "Power section subcomponent" fault status. |
| Subfault: 23.4 | | |
| Description: Hardware fault | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | A fault occurred in a hardware component of the power section, e.g.: Overcurrent hardware comparator. | <ul style="list-style-type: none"> – Check the current supply. – Increase the ramp time. – Check for correct motor size (the motor current is too high). – Contact SEW-EURODRIVE Service. |
| | Switched-mode power supply fault, hardware fault. | <ul style="list-style-type: none"> – Check the current supply. – Check the DC 24 V supply voltage. |
| | Fault at the gate driver of an IGBT. | Defect in the power output stage. Contact SEW-EURODRIVE Service. |
| | Invalid process data configuration. Status of control section and power section are not compatible. | Contact SEW-EURODRIVE Service. |
| Subfault: 23.5 | | |
| Description: Invalid process data configuration | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Invalid process data configuration. | Contact SEW-EURODRIVE Service. |
| Subfault: 23.6 | | |
| Description: Process data timeout | | |
| | Response: Emergency stop + output stage inhibit | |
| | Cause | Measure |
| | Power section communication interface detected process data timeout. | If the fault occurs repeatedly, contact SEW-EURODRIVE Service. |
| Subfault: 23.7 | | |
| Description: Parameter communication timeout | | |
| | Response: Emergency stop + output stage inhibit | |
| | Cause | Measure |
| | Power section communication interface detected timeout in parameter communication. | If the fault occurs repeatedly, contact SEW-EURODRIVE Service. |

| | | |
|---|--|--|
| Subfault: 23.8 | | |
| Description: Parameter communication error | | |
| | Response: Emergency stop + output stage inhibit | |
| | Cause | Measure |
| | Power section communication interface detected error in parameter communication. | If the fault occurs repeatedly, contact SEW-EURODRIVE Service. |
| Subfault: 23.9 | | |
| Description: Firmware of power section corrupt | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Failed to update firmware on power section. | Update the firmware again. |

6.5.21 Error 24 Cam switch

| | | |
|--|--|---|
| Subfault: 24.1 | | |
| Description: Cam window limits interchanged | | |
| | Response: Warning | |
| | Cause | Measure |
| | Left cam window limit larger than right limit. | Check cam window limits and adjust. |
| Subfault: 24.2 | | |
| Description: Cam window limit not within modulo range | | |
| | Response: Warning | |
| | Cause | Measure |
| | Cam window limits outside modulo range. | Check cam window limits and adjust. |
| Subfault: 24.3 | | |
| Description: Cam windows of a track overlap | | |
| | Response: Warning | |
| | Cause | Measure |
| | Cam window limits of a track overlap. | Adjust the cam window limits in such a way that they are flush. |
| Subfault: 24.4 | | |
| Description: Modulo limits swapped | | |
| | Response: Warning | |
| | Cause | Measure |
| | The left limit of the modulo range is larger than the right limit. | Check the limits of the modulo range and adjust accordingly. |

6.5.22 Fault 25 Parameter memory monitoring

| | | |
|---|---|--|
| Subfault: 25.2 | | |
| Description: NV memory – runtime error | | |
| | Response: Emergency stop + output stage inhibit | |
| | Cause | Measure |
| | Runtime error of non-volatile memory system. | <ul style="list-style-type: none"> – Reset the device. – If this error occurs repeatedly, replace the device. Contact SEW-EURODRIVE Service. |

| | | |
|--|---|--|
| Subfault: 25.6 | | |
| Description: Incompatible device configuration | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | The data set in the device was copied from another device, which differs from the current device in the device family, power, or voltage. | <ul style="list-style-type: none"> – Check whether the configuration is correct and repeat the startup, if necessary. – Acknowledge the fault by manual reset with parameter set acceptance. Setting under [Diagnostics] > [Status] > [Fault status] parameter "Manual fault reset". |
| | Replaceable memory module used by another device. Power rating, device family, or voltage differs from the current device. | <ul style="list-style-type: none"> – Check whether the configuration is correct and repeat the startup, if necessary. – Acknowledge the fault by manual reset with parameter set acceptance. Setting under [Diagnostics] > [Status] > [Fault status] parameter "Manual fault reset". |
| | The power section was replaced and differs in its power rating or voltage from the original power section. | <ul style="list-style-type: none"> – Check whether the configuration is correct and repeat the startup, if necessary. – Acknowledge the fault by manual reset with parameter set acceptance. Setting under [Diagnostics] > [Status] > [Fault status] parameter "Manual fault reset". |
| Subfault: 25.7 | | |
| Description: NV memory initialization – error | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Error initializing non-volatile memory system. | <ul style="list-style-type: none"> – Reset the device. – If this error occurs repeatedly, replace the device. Contact SEW-EURODRIVE Service. |
| Subfault: 25.10 | | |
| Description: Power section configuration data – version conflict | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Wrong version of configuration data of power section. | Contact SEW-EURODRIVE Service. |
| Subfault: 25.12 | | |
| Description: Power section configuration data – CRC error | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Faulty configuration data of power section. | Contact SEW-EURODRIVE Service. |
| Subfault: 25.13 | | |
| Description: Control electronics configuration data – CRC error | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Faulty configuration data of control electronics. | Contact SEW-EURODRIVE Service. |
| Subfault: 25.14 | | |
| Description: Calibration data of power section – version conflict | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Wrong version of calibration data of power section. | Contact SEW-EURODRIVE Service. |
| Subfault: 25.15 | | |
| Description: Calibration data of control electronics – version conflict | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Wrong version of calibration data of control electronics. | Contact SEW-EURODRIVE Service. |
| Subfault: 25.16 | | |
| Description: Power section calibration data – CRC error | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Faulty calibration data of power section. | Contact SEW-EURODRIVE Service. |
| Subfault: 25.17 | | |
| Description: Control electronics calibration data – CRC error | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Faulty calibration data of control electronics. | Contact SEW-EURODRIVE Service. |

| | | |
|---|--|--|
| Subfault: 25.18 | | |
| Description: Power section QA data – CRC error | | |
| | Response: Warning | |
| | Cause | Measure |
| | Faulty quality assurance data of power section. | Contact SEW-EURODRIVE Service. |
| Subfault: 25.19 | | |
| Description: Control electronics QA data – CRC error | | |
| | Response: Warning | |
| | Cause | Measure |
| | Faulty quality assurance data of control electronics. | Contact SEW-EURODRIVE Service. |
| Subfault: 25.20 | | |
| Description: Initialization error – basic device memory | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Initialization error of the basic device memory. | Contact SEW-EURODRIVE Service. |
| Subfault: 25.21 | | |
| Description: Runtime error – basic device memory | | |
| | Response: Emergency stop + output stage inhibit | |
| | Cause | Measure |
| | Runtime error in memory of basic device. | Contact SEW-EURODRIVE Service. |
| Subfault: 25.30 | | |
| Description: Initialization error – replaceable memory module | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | The formatting of the replaceable memory module does not match. | Restore delivery state. NOTICE: All the data on the replaceable memory module will be reset to default. |
| | Initialization error of replaceable memory module after delivery state. | Contact SEW-EURODRIVE Service. |
| Subfault: 25.31 | | |
| Description: Runtime error – replaceable memory module | | |
| | Response: Emergency stop + output stage inhibit | |
| | Cause | Measure |
| | Runtime error of replaceable memory module. | Contact SEW-EURODRIVE Service. |
| Subfault: 25.50 | | |
| Description: Runtime error – replaceable safety memory module | | |
| | Response: Output stage inhibit System state: Fault acknowledgment with CPU reset | |
| | Cause | Measure |
| | Runtime error of the replaceable safety memory module. | Contact SEW-EURODRIVE Service. |
| Subfault: 25.51 | | |
| Description: Initialization error – replaceable safety memory module | | |
| | Response: Warning | |
| | Cause | Measure |
| | Initialization error of the replaceable safety memory module. | Contact SEW-EURODRIVE Service. |
| Subfault: 25.61 | | |
| Description: Failure – restore point | | |
| | Response: Emergency stop + output stage inhibit | |
| | Cause | Measure |
| | Failed to create restore point. | Delete restore point. |
| Subfault: 25.70 | | |
| Description: Incompatible card configuration | | |
| | Response: Emergency stop + output stage inhibit | |
| | Cause | Measure |
| | The current configuration of the cards does not match the state of the stored startup. For example, a card was removed that was still present during startup. | – Restore the original configuration of the cards. – Acknowledge the fault by manual reset with parameter set acceptance. Setting under [Diagnostics] > [Status] > [Fault status] parameter "Manual fault reset". |

6.5.23 Fault 26 External fault

| | | |
|--|---|---|
| Subfault: 26.1 | | |
| Description: Terminal | | |
| | Response: External fault | |
| | Cause | Measure |
| | Fault message about external fault source. | Programmable via 8622.5 (default: application stop (with output stage inhibit)). |
| Subfault: 26.2 | | |
| Description: Emergency shutdown | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Another module bus station requested external emergency shutdown. | Check other module bus stations for faults. |
| Subfault: 26.3 | | |
| Description: Power section emergency shutdown | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Power section requested external emergency shutdown because it detected critical fault. | Contact SEW-EURODRIVE Service. |
| Subfault: 26.4 | | |
| Description: External braking resistor fault | | |
| | Response: Response to external braking resistor fault | |
| | Cause | Measure |
| | External braking resistor's temperature switch connected to terminal tripped. | <ul style="list-style-type: none"> – Check the resistor mounting position. – Clean the resistor. – Check the configuration of the resistor. – Install a larger resistor. – Check the trip switch settings. – Optimize the travel cycle so that less regenerative operation energy arises. |

6.5.24 Fault 28 FCB drive functions

| | | |
|---|--|--|
| Subfault: 28.1 | | |
| Description: FCB 11/12 – Timeout while searching zero pulse | | |
| | Response: Emergency stop + output stage inhibit | |
| | Cause | Measure |
| | Failed to find zero pulse of encoder's C track within specified search time during reference travel. | Check the encoder wiring. |
| Subfault: 28.2 | | |
| Description: FCB 11/12 – Hardware limit switch upstream of reference cam | | |
| | Response: Emergency stop + output stage inhibit | |
| | Cause | Measure |
| | The hardware limit switch was reached during reference travel. The reference cam was not detected. | Make sure that the reference cam is not installed downstream of the hardware limit switch. |
| Subfault: 28.3 | | |
| Description: FCB 11/12 – Hardware limit switch and reference cam not flush | | |
| | Response: Emergency stop + output stage inhibit | |
| | Cause | Measure |
| | Hardware limit switch and reference cam not mounted flush. | Make sure that the reference cam and the hardware limit switch are mounted flush. |
| Subfault: 28.4 | | |
| Description: FCB 11/12 – Reference offset error | | |
| | Response: Emergency stop + output stage inhibit | |
| | Cause | Measure |
| | Error when determining reference offset. | <ul style="list-style-type: none"> – Make sure that the reference offset is not set to a larger value than the "Modulo maximum" limit value. When using a single-turn absolute encoder, make sure that the reference offset is not set to a larger value than one encoder revolution. |

| | | |
|--|--|---|
| Subfault: 28.5 | | |
| Description: FCB 11/12 – Referencing not possible | | |
| Response: Emergency stop + output stage inhibit | | |
| | Cause | Measure |
| | In the active drive train, the "Actual position source" parameter is set to "No encoder". | Assign "Actual position source", or do not perform any referencing. |
| Subfault: 28.6 | | |
| Description: FCB 11/12 – Limit switch/reference cam not flush/overlapping with fixed stop | | |
| Response: Emergency stop + output stage inhibit | | |
| | Cause | Measure |
| | Hardware limit switch or reference cam that has not been selected was approached during reference travel to fixed stop. | Check whether the parameters set for reference travel are correct. |
| | During reference travel to fixed stop with selected hardware limit switch or reference cam, the fixed stop was reached without approaching the hardware limit switch or reference cam. | Check whether the parameters set for reference travel are correct. |
| Subfault: 28.7 | | |
| Description: FCB 21 – Test torque greater than maximum torque at motor shaft | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | The required test torque for the brake test is higher than the maximum torque. It cannot be generated by the motor/inverter combination. | Reduce the test torque. |
| Subfault: 28.8 | | |
| Description: FCB 21 – Test torque not reached | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Test torque required for brake test exceeds valid limit values. | <ul style="list-style-type: none"> – Reduce the test torque. – Check limit values. |
| Subfault: 28.9 | | |
| Description: FCB 18 – Rotor position identification not possible | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Rotor position identification started with incremental encoder but aborted prematurely. | <ul style="list-style-type: none"> – Restart the rotor position identification. – Check whether the encoder is connected correctly. – Check whether the encoder is defective. |
| | Result of rotor position identification cannot be stored in encoder. | Select "Inverter" as storage location. |
| | Combination of "Automatic" mode and "Encoder" storage location not permitted. | Set the operating mode to "Manual" or the storage location to "Inverter". |
| Subfault: 28.10 | | |
| Description: FCB 25 – Unbalanced motor phases | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Significantly different values determined in the three phases while measuring stator resistances. | <ul style="list-style-type: none"> – Check whether the motor is connected correctly. – Check all contact points on the motor and inverter. – Check the motor and motor cable for damage. |
| Subfault: 28.11 | | |
| Description: FCB 25 – At least one phase with high resistance | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | At least one motor phase could not be measured during motor parameter measurement. | <ul style="list-style-type: none"> – Check whether the motor is connected correctly. – Check all contact points on the motor and inverter. – Check the motor and motor cable for damage. |
| Subfault: 28.12 | | |
| Description: FCB 25 – Timeout during stator resistance measurement | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Motor parameter measurement activated while motor is turning. | <ul style="list-style-type: none"> – Stop motor. – Start motor parameter measurement when the motor is at standstill. |

| | | |
|---|--|--|
| Subfault: 28.13 | | |
| Description: FCB 25 – Characteristic curve identification not possible | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Motor parameter measurement does not allow for unique identification of the characteristic curve. | Contact SEW-EURODRIVE Service. |
| Subfault: 28.14 | | |
| Description: Modulo min. and max. swapped | | |
| Response: Emergency stop + output stage inhibit | | |
| | Cause | Measure |
| | In the active data set, the value for "Modulo minimum" is greater than the value for "Modulo maximum"; see Monitoring functions\Limit values 1 or Monitoring functions\Limit values 2. | Swap the values for modulo minimum and modulo maximum. |
| Subfault: 28.15 | | |
| Description: FCB 25 – Timeout | | |
| Response: Output stage inhibit | | |
| | Cause | Measure |
| | Measuring rotor resistance, LSigma, or stator inductance not completed. | Contact SEW-EURODRIVE Service. |

6.5.25 Fault 29 HW limit switches

| | | |
|--|--|--|
| Subfault: 29.1 | | |
| Description: Positive limit switch approached | | |
| Response: HW limit switch – current drive train | | |
| | Cause | Measure |
| | Positive hardware limit switch approached. | <ul style="list-style-type: none"> – Check hardware limit switch wiring. – Check target position. – Move clear of the hardware limit switch at negative speed. |
| Subfault: 29.2 | | |
| Description: Negative limit switch approached | | |
| Response: HW limit switch – current drive train | | |
| | Cause | Measure |
| | Negative hardware limit switch approached. | <ul style="list-style-type: none"> – Check hardware limit switch wiring. – Check target position. – Move clear of the hardware limit switch at positive speed. |
| Subfault: 29.3 | | |
| Description: Limit switch missing | | |
| Response: Emergency stop + output stage inhibit | | |
| | Cause | Measure |
| | Both positive and negative hardware limit switches approached at the same time. | <ul style="list-style-type: none"> – Check hardware limit switch wiring. – Check the parameter setting of digital inputs. – Check the parameter setting of process output data. |
| Subfault: 29.4 | | |
| Description: Limit switches swapped | | |
| Response: Emergency stop + output stage inhibit | | |
| | Cause | Measure |
| | Positive hardware limit switch approached at negative speed, or negative hardware limit switch approached at positive speed. | Check whether hardware limit switch connections are swapped. |

6.5.26 Fault 30 Software limit switches

| | | |
|--|--|---|
| Subfault: 30.1 | | |
| Description: Positive limit switch approached | | |
| Response: SW limit switches – current drive train | | |
| | Cause | Measure |
| | Positive software limit switch approached. | <ul style="list-style-type: none"> – Check software limit switch position. – Check target position. – Move clear of software limit switch at negative speed. |

| | | |
|--|---|---|
| Subfault: 30.2 | | |
| Description: Negative limit switch approached | | |
| | Response: SW limit switches – current drive train | |
| | Cause | Measure |
| | Negative software limit switch approached. | <ul style="list-style-type: none"> – Check software limit switch position. – Check target position. – Move clear of software limit switch at positive speed. |
| Subfault: 30.3 | | |
| Description: Limit switches swapped | | |
| | Response: Emergency stop + output stage inhibit | |
| | Cause | Measure |
| | Position value of negative software limit switch greater than position value of positive software limit switch. | Check software limit switch positions. |

6.5.27 Fault 31 Thermal motor protection

| | | |
|--|---|---|
| Subfault: 31.1 | | |
| Description: Temperature sensor wire break – motor 1 | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Connection to temperature sensor of motor 1 interrupted. | Check the temperature sensor wiring. |
| Subfault: 31.2 | | |
| Description: Temperature sensor short circuit – motor 1 | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Short circuit in connection with temperature sensor of motor 1. | Check the temperature sensor wiring. |
| Subfault: 31.3 | | |
| Description: Temperature sensor overtemperature – motor 1 | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Temperature sensor of motor 1 signals overtemperature. | <ul style="list-style-type: none"> – Allow motor to cool down. – Check for motor overload. – Check whether the correct temperature sensor KY (KTY) was parameterized instead of PK (Pt1000). |
| Subfault: 31.4 | | |
| Description: Temperature model overtemperature – motor 1 | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Temperature model of motor 1 signals overtemperature. | <ul style="list-style-type: none"> – Allow motor to cool down. – Check for motor overload. – Check whether the correct temperature sensor KY (KTY) was parameterized instead of PK (Pt1000). |
| Subfault: 31.5 | | |
| Description: Temperature sensor prewarning – motor 1 | | |
| | Response: Thermal motor protection 1 – prewarning threshold | |
| | Cause | Measure |
| | Temperature signaled by temperature sensor of motor 1 exceeds prewarning threshold. | Check for motor overload. |
| Subfault: 31.6 | | |
| Description: Temperature model prewarning – motor 1 | | |
| | Response: Thermal motor protection 1 – prewarning threshold | |
| | Cause | Measure |
| | Temperature signaled by temperature model of motor 1 exceeds prewarning threshold. | Check for motor overload. |
| Subfault: 31.7 | | |
| Description: UL temperature monitoring | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Temperature model of active motor signals overtemperature. | Check for motor overload. |

| | | |
|--|---|---|
| Subfault: 31.8 | | |
| Description: Communication timeout temperature sensor – motor 1 | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Communication with temperature sensor is disrupted, e.g. via MOVILINK® DDI. | Check the cabling. |
| Subfault: 31.9 | | |
| Description: Temperature too low – temperature sensor – motor 1 | | |
| | Response: Warning with self-reset | |
| | Cause | Measure |
| | Temperature signaled by temperature sensor of motor 1 below -50 °C. | <ul style="list-style-type: none"> – Check if a KTY temperature sensor is installed in the motor but the parameterization has been carried out for a Pt1000 temperature sensor. – Heat the motor. |
| Subfault: 31.11 | | |
| Description: Temperature sensor wire break – motor 2 | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Connection to temperature sensor of motor 2 interrupted. | Check the temperature sensor wiring. |
| Subfault: 31.12 | | |
| Description: Temperature sensor short circuit – motor 2 | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Short circuit in connection with temperature sensor of motor 2. | Check the temperature sensor wiring. |
| Subfault: 31.13 | | |
| Description: Temperature sensor overtemperature – motor 2 | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Temperature sensor of motor 2 signals overtemperature. | <ul style="list-style-type: none"> – Allow motor to cool down. – Check for motor overload. – Check whether the correct temperature sensor KY (KTY) was parameterized instead of PK (Pt1000). |
| Subfault: 31.14 | | |
| Description: Temperature model overtemperature – motor 2 | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Temperature model of motor 2 signals overtemperature. | <ul style="list-style-type: none"> – Allow motor to cool down. – Check for motor overload. – Check whether the correct temperature sensor KY (KTY) was parameterized instead of PK (Pt1000). |
| Subfault: 31.15 | | |
| Description: Temperature sensor prewarning – motor 2 | | |
| | Response: Thermal motor protection 2 – prewarning threshold | |
| | Cause | Measure |
| | Temperature signaled by temperature sensor of motor 2 exceeds prewarning threshold. | Check for motor overload. |
| Subfault: 31.16 | | |
| Description: Temperature model prewarning – motor 2 | | |
| | Response: Thermal motor protection 2 – prewarning threshold | |
| | Cause | Measure |
| | Temperature signaled by temperature model of motor 2 exceeds prewarning threshold. | Check for motor overload. |
| Subfault: 31.19 | | |
| Description: Temperature too low – temperature sensor – motor 2 | | |
| | Response: Warning with self-reset | |
| | Cause | Measure |
| | Temperature signaled by temperature sensor of motor 2 below -50 °C. | <ul style="list-style-type: none"> – Check if a KTY temperature sensor is installed in the motor but the parameterization has been carried out for a Pt1000 temperature sensor. – Heat the motor. |

6.5.28 Fault 32 Communication

| | | |
|--|---|--|
| Subfault: 32.2 | | |
| Description: EtherCAT®/SBus^{PLUS} process data timeout | | |
| | Response: Fieldbus – timeout response | |
| | Cause | Measure |
| | Process data timeout during EtherCAT®/SBus ^{PLUS} communication. | <ul style="list-style-type: none"> – Check the wiring of the system bus and module bus. – Check that the EtherCAT®/SBus^{PLUS} configuration is set correctly in the MOVI-C® CONTROLLER. – Check the EtherCAT®/SBus^{PLUS} timeout configuration in the device. |
| Subfault: 32.3 | | |
| Description: Faulty synchronization signal | | |
| | Response: External synchronization | |
| | Cause | Measure |
| | Faulty synchronization signal period. | Check for correct setting of the EtherCAT®/SBus ^{PLUS} configuration in the MOVI-C® CONTROLLER. |
| Subfault: 32.4 | | |
| Description: No synchronization signal | | |
| | Response: External synchronization | |
| | Cause | Measure |
| | No synchronization signal present. | Check for correct setting of the EtherCAT®/SBus ^{PLUS} configuration in the MOVI-C® CONTROLLER. |
| Subfault: 32.5 | | |
| Description: Synchronization timeout | | |
| | Response: External synchronization | |
| | Cause | Measure |
| | Timeout while synchronizing to synchronization signal. | Check for correct setting of the EtherCAT®/SBus ^{PLUS} configuration in the MOVI-C® CONTROLLER. |
| Subfault: 32.6 | | |
| Description: Copy parameter set | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Error while downloading parameter set to device. | <ul style="list-style-type: none"> – Check the wiring of the system bus and module bus. – Restart download. |
| Subfault: 32.7 | | |
| Description: Application heartbeat timeout | | |
| | Response: Application heartbeat – timeout response | |
| | Cause | Measure |
| | Communication interrupted between IEC program in MOVI-C® CONTROLLER and device. | <ul style="list-style-type: none"> – Check the status of the IEC program. – Restart the IEC program. |
| Subfault: 32.8 | | |
| Description: User-timeout timeout | | |
| | Response: User timeout timeout response | |
| | Cause | Measure |
| | The timeout time of the user timeout function elapsed | Write the parameter for triggering the user timeout function cyclically before the timeout time elapses. |
| Subfault: 32.12 | | |
| Description: Manual mode timeout | | |
| | Response: Manual mode – timeout response | |
| | Cause | Measure |
| | Communication connection to device interrupted in manual mode. | <ul style="list-style-type: none"> – Check whether too many programs are open on the operator PC. – Increase the timeout time in manual mode. |
| | New Scope project created. | <ul style="list-style-type: none"> – Reset the fault. – Restart manual mode. |
| | Scope measurement loaded from device. | <ul style="list-style-type: none"> – Reset the fault. – Restart manual mode. |

6.5.29 Fault 33 System initialization

| | | |
|--|---|--|
| Subfault: 33.1 | | |
| Description: Motor current measurement | | |
| | Response: Output stage inhibit System state: Fault acknowledgment with CPU reset | |
| | Cause | Measure |
| | Motor current measurement detected an error. | Contact SEW-EURODRIVE Service. |
| Subfault: 33.2 | | |
| Description: Firmware CRC check | | |
| | Response: Output stage inhibit System state: Fault acknowledgment with CPU reset | |
| | Cause | Measure |
| | Error checking firmware. | Contact SEW-EURODRIVE Service. |
| Subfault: 33.6 | | |
| Description: FPGA configuration | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Error checking FPGA configuration. | Contact SEW-EURODRIVE Service. |
| Subfault: 33.7 | | |
| Description: Function block compatibility error | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Error checking compatibility of function block. | Contact SEW-EURODRIVE Service. |
| Subfault: 33.8 | | |
| Description: SW function block configuration | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Error detected while checking configuration of software function block. | Contact SEW-EURODRIVE Service. |
| Subfault: 33.10 | | |
| Description: Run-up timeout | | |
| | Response: Output stage inhibit System state: Fault acknowledgment with CPU reset | |
| | Cause | Measure |
| | Timeout during system run-up. | Contact SEW-EURODRIVE Service. |
| Subfault: 33.11 | | |
| Description: Hardware compatibility error | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Firmware does not match device. | Contact SEW-EURODRIVE Service. |
| Subfault: 33.12 | | |
| Description: Memory module plugged in | | |
| | Response: Output stage inhibit System state: Fault acknowledgment with CPU reset | |
| | Cause | Measure |
| | A plugged-in memory module was detected during device start. The setting for the device parameter source is set to "Internal memory". | – Switch off the device. Remove the memory module and re-start the device. – Change the parameter "Non-volatile memory source" to "Arbitrary" or "Replaceable memory module". Switch the device off and on again. |
| Subfault: 33.13 | | |
| Description: Memory module removed | | |
| | Response: Output stage inhibit System state: Fault acknowledgment with CPU reset | |
| | Cause | Measure |
| | The device was started without a memory module. The setting for the device parameter source is set to "Replaceable memory module". | Switch off the device. Insert the memory module and restart the device. |
| | Replaceable memory module removed during ongoing operation. | |
| | Change the parameter "Non-volatile memory source" to "Internal memory". Switch the device off and on again. | |

| | | |
|---|---|--|
| Subfault: 33.14 | | |
| Description: EtherCAT® slave controller cannot be accessed | | |
| | Response: Output stage inhibit System state: Fault acknowledgment with CPU reset | |
| | Cause | Measure |
| | EtherCAT® slave controller cannot be accessed. | Contact SEW-EURODRIVE Service. |
| Subfault: 33.15 | | |
| Description: Firmware configuration | | |
| | Response: Output stage inhibit System state: Fault acknowledgment with CPU reset | |
| | Cause | Measure |
| | The Device Update Manager detected a modified version of the application firmware. | Acknowledge the fault. Doing so will update the configuration data of the Device Update Manager. |
| | The error occurs repeatedly several times. The Device Update Manager is outdated and cannot save the configuration. | Update the Device Update Manager. |

6.5.30 Fault 34 Process data configuration

| | | |
|--|--|---|
| Subfault: 34.1 | | |
| Description: Changed process data configuration | | |
| | Response: Application stop + output stage inhibit | |
| | Cause | Measure |
| | Process data configuration changed during active process data operation. | <ul style="list-style-type: none"> – Stop the process data and make your changes. Then start the process data again. – Perform a reset. Doing so will stop the process data, apply the changes, and restart the process data. |

6.5.31 Fault 35 Function activation

| | | |
|--|---|---|
| Subfault: 35.1 | | |
| Description: Activation key – application level invalid | | |
| | Response: Emergency stop + output stage inhibit | |
| | Cause | Measure |
| | The activation key was entered incorrectly. | Enter the activation key again. |
| | The activation key was not created for this device. | Check the activation key. |
| | When using a double axis, the activation key for the wrong instance was entered in the device. | Enter the activation key for the allocated instance. |
| | An activation key for a technology level was entered in the parameter "Application level – Activation key". | Enter the activation key in the correct parameter. |
| Subfault: 35.2 | | |
| Description: Application level too low | | |
| | Response: Emergency stop + output stage inhibit | |
| | Cause | Measure |
| | The activated software module requires a higher application level. | Enter an activation key for the required application level. You can find the required level in the parameter 8438.3 "Application level – Required level". |
| Subfault: 35.3 | | |
| Description: Technology level too low | | |
| | Response: Emergency stop + output stage inhibit | |
| | Cause | Measure |
| | An activated technology function requires a higher technology level. | Enter an activation key for the required technology level. You can find the required level in the parameter 8438.13 "Technology level – Required level". |

Subfault: 35.4**Description: Activation key – technology level invalid**

| Response: Emergency stop + output stage inhibit | | |
|--|--|--|
| Cause | | Measure |
| The activation key was entered incorrectly. | | Enter the activation key again. |
| The activation key was not created for this device. | | Check the activation key. |
| When using a double axis, the activation key for the wrong instance was entered in the device. | | Enter the activation key for the allocated instance. |
| An activation key for an application level was entered in the parameter "Technology level – Activation key". | | Enter the activation key in the correct parameter. |

6.5.32 Fault 42 Lag error**Subfault: 42.1****Description: Positioning lag error**

| Response: Positioning lag error | | |
|---|--|---|
| Cause | | Measure |
| A lag error occurred during positioning. Incorrect encoder connection. | | Check the connection of the encoder. |
| Position encoder inverted or not installed correctly at the track. | | Check the installation and connection of the position encoder. |
| Wiring faulty. | | Check the wiring of encoder, motor, and line phases. |
| Acceleration ramps too short. | | Extend the acceleration ramps. |
| P component of the position controller too small. | | Set P component of the position controller to a larger value. |
| Speed controller parameters set incorrectly. | | Check controller parameters. |
| Value of lag error tolerance too small. | | Increase the lag error tolerance. |
| Mechanical components cannot move freely or are blocked. | | Make sure mechanical parts can move freely, and check whether they are blocked. |

Subfault: 42.2**Description: Jog mode lag error**

| Response: Output stage inhibit | | |
|---|--|---|
| Cause | | Measure |
| A lag error occurred in jog mode (FCB 20). Incorrect encoder connection. | | Check the connection of the encoder. |
| Position encoder inverted or not installed correctly at the track. | | Check the installation and connection of the position encoder. |
| Wiring faulty. | | Check the wiring of encoder, motor, and line phases. |
| Acceleration ramps too short. | | Extend the acceleration ramps. |
| P component of the position controller too small. | | Set P component of the position controller to a larger value. |
| Speed controller parameters set incorrectly. | | Check controller parameters. |
| Value of lag error tolerance too small. | | Increase the lag error tolerance. |
| Mechanical components cannot move freely or are blocked. | | Make sure mechanical parts can move freely, and check whether they are blocked. |

Subfault: 42.3**Description: Standard lag error**

| Response: Output stage inhibit | | |
|--|--|--|
| Cause | | Measure |
| A lag error has occurred outside a positioning process. Incorrect encoder connection. | | Check the connection of the encoder. |
| Position encoder inverted or not installed correctly at the track. | | Check the installation and connection of the position encoder. |
| Wiring faulty. | | Check the wiring of encoder, motor, and line phases. |
| Acceleration ramps too short. | | Extend the acceleration ramps. |
| P component of the position controller too small. | | Set P component of the position controller to a larger value. |
| Speed controller parameters set incorrectly. | | Check controller parameters. |
| Value of lag error tolerance too small. | | Increase the lag error tolerance. |

6.5.33 Fault 46 Safety card**Subfault: 46.1****Description: No response**

| Response: Output stage inhibit | | |
|--|-------|--|
| | Cause | Measure |
| Failed to synchronize with subcomponent. | | <ul style="list-style-type: none"> – Check device assignment of basic device and option. – Check card slot and installation and correct if necessary. – Restart the device. – Contact SEW-EURODRIVE Service. |

Subfault: 46.2**Description: Invalid variant**

| Response: Output stage inhibit | | |
|--|-------|--|
| | Cause | Measure |
| Plugged safety card design does not match inverter type. | | <ul style="list-style-type: none"> – Remove the safety card. – Use the correct safety card design. |
| For double axes, only designs without encoder interface can be used. | | <ul style="list-style-type: none"> – Remove option. – Use the design without encoder interface. |
| For double axes, no encoder option must be plugged in. | | Remove the option. |

Subfault: 46.3**Description: Internal communication timeout**

| Response: Output stage inhibit | | |
|---|-------|---|
| | Cause | Measure |
| Communication interrupted between inverter and safety card. | | Check card slot and installation and correct if necessary. Contact SEW-EURODRIVE Service if the error is still present. |
| Safety card signals subcomponent fault of the type "Warning". | | Check card slot and installation and correct if necessary. Contact SEW-EURODRIVE Service if the error is still present. |

Subfault: 46.50**Description: Warning**

| Response: Warning with self-reset | | |
|---|-------|--|
| | Cause | Measure |
| Safety card signals subcomponent fault of the type "Warning". | | For the exact cause of the fault and for information on how to correct the cause of the problem, refer to the fault reported by the subcomponent (index 8365.3). |

Subfault: 46.51**Description: Fault**

| Response: Emergency stop + output stage inhibit with self-reset | | |
|--|-------|--|
| | Cause | Measure |
| Safety card signals subcomponent fault of the type "Standard fault". | | For the exact cause of the fault and for information on how to correct the cause of the problem, refer to the fault reported by the subcomponent (index 8365.3). |

Subfault: 46.52**Description: Critical fault**

| Response: Output stage inhibit with self-reset | | |
|--|-------|---|
| | Cause | Measure |
| Safety card signals subcomponent fault of the type "Critical fault". | | <ul style="list-style-type: none"> – For the exact cause of the fault and for information on how to correct the cause of the problem, refer to the fault reported by the subcomponent (index 8365.3). – If the jumper plug is plugged at terminal "X6", remove the jumper plug. |

6.5.34 Fault 47 Supply unit**Subfault: 47.1****Description: Supply unit – warning**

| Response: Warning with self-reset | | |
|--|-------|--|
| | Cause | Measure |
| The supply unit signals a fault with response type "warning". The fault is only displayed. | | For the exact cause of the fault and for information on how to correct the cause of the problem, refer to the fault reported by the subcomponent (index 8365.3). |

| | | |
|--|--|--|
| Subfault: 47.2 | | |
| Description: Supply unit – standard fault | | |
| | Response: Emergency stop + output stage inhibit | |
| | Cause | Measure |
| | The supply unit signals a fault with response type "standard". The fault response is determined by the driver implemented on the axis. The axis performs the fault response. | For the exact cause of the fault and for information on how to correct the cause of the problem, refer to the fault reported by the subcomponent (index 8365.3). |
| Subfault: 47.3 | | |
| Description: Supply unit – critical fault | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | The supply unit signals a fault with response type "critical error". The fault response is determined by the driver implemented on the axis. The axis performs the fault response. | For the exact cause of the fault and for information on how to correct the cause of the problem, refer to the fault reported by the subcomponent (index 8365.3). |

6.5.35 Fault 48 Module bus

| | | |
|----------------------------------|--|---|
| Subfault: 48.1 | | |
| Description: Incompatible | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Module bus slave and module bus master not compatible. | Update the firmware of the module bus at the supply unit or the axis modules to a compatible version. |
| Subfault: 48.2 | | |
| Description: Timeout | | |
| | Response: Emergency stop + output stage inhibit | |
| | Cause | Measure |
| | Timeout detected via module bus. | Check cable connections and voltage supply of module bus stations. |

6.5.36 Fault 50 I/O card

| | | |
|--|--|--|
| Subfault: 50.1 | | |
| Description: Boot synchronization timeout | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Card plugged in device but cannot be accessed. | <ul style="list-style-type: none"> – Check device assignment of basic device and option. – Check card slot and installation and correct if necessary. – Restart device. |
| Subfault: 50.2 | | |
| Description: CRC error of FPGA driver | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Communication between FPGA and option card does not work, or is interrupted. | <ul style="list-style-type: none"> – Check card slot and installation and correct if necessary. – Check for EMC-compliant installation. – Restart device. |
| Subfault: 50.3 | | |
| Description: CRC error of option card | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Option card signals CRC error on SPI bus. | <ul style="list-style-type: none"> – Check card slot and installation and correct if necessary. – Check for EMC-compliant installation. – Restart device. |
| Subfault: 50.4 | | |
| Description: Option card timeout error | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Option card signals timeout error on SPI bus. | <ul style="list-style-type: none"> – Check card slot and installation and correct if necessary. – Check for EMC-compliant installation. – Restart device. |

| | | |
|--|--|--|
| Subfault: 50.5 | | |
| Description: Option card watchdog error | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Microcontroller of option card signals a watchdog error. | <ul style="list-style-type: none"> – Check card slot and installation and correct if necessary. – Check for EMC-compliant installation. – Restart device. |
| Subfault: 50.6 | | |
| Description: Ready signal timeout | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Card booted but cyclical communication not possible. | <ul style="list-style-type: none"> – Check card slot and installation and correct if necessary. – Check for EMC-compliant installation. – Restart device. |
| Subfault: 50.7 | | |
| Description: Frame error of option card | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Faulty communication between option card and basic device. | – |

6.5.37 Fault 51 Analog processing

| | | |
|---|-----------------------------------|--------------------------|
| Subfault: 51.1 | | |
| Description: Analog current input 4 mA limit | | |
| | Response: Warning with self-reset | |
| | Cause | Measure |
| | Input current below 4 mA. | Check the input current. |

6.5.38 Fault 52 Explosion protection function category 2

| | | |
|--|--|---|
| Subfault: 52.1 | | |
| Description: Startup error | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | No valid startup available. | Perform startup. |
| Subfault: 52.2 | | |
| Description: Impermissible system function | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Impermissible system function activated. | Disable impermissible functions when Ex protection function is active, such as "Activate standstill current" = "On" in the active control mode. |
| Subfault: 52.3 | | |
| Description: Inverter too large | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Ratio of inverter current to nominal motor current too large. | Check the assignment of motor and inverter, and check the dimensioning of the system. |
| Subfault: 52.4 | | |
| Description: Parameterization of current limit characteristic | | |
| | Response: Output stage inhibit | |
| | Cause | Measure |
| | Error while setting parameters for current limit characteristic. | <ul style="list-style-type: none"> – Parameterize the current limit characteristic. – Perform startup again. |

Subfault: 52.5**Description: Time duration exceeded $f < 5$ Hz**

| Response: Emergency stop + output stage inhibit | | |
|---|---|---|
| | Cause | Measure |
| | Duration of 60 s for $f < 5$ Hz exceeded. | Check the dimensioning of the system: If speed control = FCB05, increase the speed. If speed = 0, inhibit output stage / with stop FCBs, activate the brake function if a brake is installed. |

6.6 Fault at the master module UHX45A/MDM90A

| Description: The master module is not connected to voltage, all LEDs are extinguished. | | |
|--|--|---|
| | Response: | |
| | Cause | Measure |
| | The fuse of the master module has tripped. | The UHX45 module must be replaced. Contact SEW-EURODRIVE Service. |

6.7 Module bus faults

The module bus master sends all occurring fault messages to the connected module bus stations (slaves) using the module bus. The faults are divided into 3 categories (warning, standard fault, critical fault). There are two fault transmission modes (normal, warning) available, see chapter "Module bus – fault transmission".

With system conditions that may damage or destroy the axis system, it is important that the output stages of the drives can be inhibited quickly. For this purpose, the module bus offers emergency shutdown, see chapter "Module bus – fault transmission".

If necessary, the module bus communication in the device can be partially deactivated. This means the module bus data in the device is not evaluated, the module bus communication however proceeds if module bus stations are connected to each other. For safety reasons, the device responds to the emergency shutdown.

6.7.1 Grid condition

Regardless of the set fault responses of the different line faults, the module bus master sends information on the grid condition to other module bus stations (slaves) using the module bus.

The grid condition is only relevant when connecting the module bus slaves. There must be a transition from <Grid OFF> to <Grid OK>. Only then, the slaves are ready to be connected. If there is a line fault or a transition away from <Grid OK> during operation, the slaves do not respond to this information. They respond according to the settings of their own monitoring function.

The power supply module must be able to supply the application using the storage units or another DC source (also external source) if the AC grid has partly or completely failed or if it is not even connected. In this case, the module bus master must not prevent the module bus stations (slaves) from connecting. For this purpose, the parameter "8627.3 sending grid condition" is available. Here, it is possible to set that the grid condition is not transferred, which means the slaves will connect independently of the grid condition.

6.7.2 DC link condition

The DC link condition is determined in the same manner as the grid condition.

6.7.3 Line phase failure

Regardless of the set fault response, the module bus master transmits a line phase failure to other module bus stations (slaves) using the module bus.

This status leads to a fault response in the module bus slave. However, this response can be set in the module bus slave. The response to a line phase failure can also be set at the module bus master, see chapter "Fault responses".

6.8 Responses to fault acknowledgement

6.8.1 Fault acknowledgement at the power supply module

Faults that are detected and displayed at the power supply module are acknowledged by switching off the fault source. The fault messages of the power supply module are transferred to the axis modules.

6.8.2 Fault acknowledgement at the axis modules

During fault acknowledgement, the final fault status determines which reset type will be executed, see following table.

Software reset

| Response | Effect |
|--------------------------------------|--|
| System restart with start of the CPU | Behavior equal to device start |
| | Reference is lost |
| | Fieldbus interface is restarted |
| | EtherCAT®/SBus ^{PLUS} is restarted |
| | The active "fault message" is reset (digital output = 1, system status = 0). |

Software restart

A software restart is **no** real reset of the micro controller.

| Response | Effect |
|------------------|---|
| Software restart | The firmware will be restarted, without the boot loader becoming active (no display "b0!"). |
| | Reference positions of incremental encoder systems will be lost. |
| | Any existing fieldbus interfaces are not affected. |
| | The interface between options and firmware system is initialized again. A new boot synchronization to the fieldbus or control option takes place. |
| | The active "fault message" is reset (digital output = 1, system status = 0). |

The ready signal is set again depending on the system state after the reset by the system state control.

Warm start

A warm start only resets the fault code.

| Response | Effect |
|------------|--|
| Warm start | The firmware system is not rebooted. |
| | All reference positions will be maintained. |
| | Communication is not interrupted. |
| | The active "fault message" is reset (digital output = 1, system status = 0). |

Fieldbus timeout

After manual reset of a fault, the fault message is deleted. The system changes to the state "Waiting for data".

6.9 Fault responses

6.9.1 Default – fault response

| Fault response | Description |
|--|---|
| No response | The inverter ignores the event. |
| Warning with self-reset | The inverter sends a warning message with self-reset. The fault is automatically reset after the cause of fault is eliminated. |
| Warning | The inverter issues a warning message. |
| Application stop (with output stage inhibit) | The inverter stops with the deceleration set for the application limit. Parameter set 1 Index 8375.0-13 Parameter set 2 Index 8375.8-13 |
| Application stop (with output stage inhibit) with self reset | For n=0: Brake "applied" and output stage "off". |
| Emergency stop (with output stage inhibit) | The inverter stops with the set emergency stop deceleration. Parameter set 1 Index 8375.0-20 Parameter set 2 Index 8375.8-20 |
| Emergency stop (with output stage inhibit) with self-reset | |
| Inhibit output stage with self reset | The output stage is deactivated and the brake is applied. |
| Inhibit output stage | |

Self-reset means: Eliminating the cause of the fault acknowledges the fault. The inverter automatically resumes the operation performed before the fault. The drive restarts automatically.

6.9.2 Parameterizable faults

| Parameterizable faults | Description | Index no. | Possible fault response |
|--|---|-----------|--|
| Manual mode – timeout response | This parameter is used to set the response to a bus timeout during manual mode. | 8504.3 | <ul style="list-style-type: none"> • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage |
| Heat sink overtemperature – prewarning | Here, you can set the device response when the prewarning threshold for heat sink utilization is exceeded (index 8336.1). | 8622.2 | <ul style="list-style-type: none"> • No response • Warning |
| Positioning lag fault | This parameter is used to set the device response to a lag error (lag error window exceeded, index 8509.4). | 8622.3 | <ul style="list-style-type: none"> • No response • Warning • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage |
| Line phase failure | This parameter is used to set the device response to a line phase failure (values below threshold defined by the user, index 8351.5). | 8622.4 | <ul style="list-style-type: none"> • No response • Warning • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage |
| External fault | This parameter is used to set the device response to an external fault (e.g. triggered by terminal or control word). | 8622.5 | <ul style="list-style-type: none"> • No response • Warning • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage |

| Parameterizable faults | Description | Index no. | Possible fault response |
|--|---|-----------|---|
| Fieldbus – timeout | This parameter is used to set the device response to an EtherCAT®/SBus ^{PLUS} timeout (timeout time, index 8455.3). | 8622.6 | <ul style="list-style-type: none"> • Warning • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage • Warning with self reset • Application stop (with output stage inhibit) with self reset • Emergency stop (with output stage inhibit) with self reset • Inhibit output stage with self reset |
| External synchronization | This parameter is used to set the device response to loss of external synchronization. | 8622.7 | <ul style="list-style-type: none"> • No response • Warning • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage • Warning with self reset • Application stop (with output stage inhibit) with self reset • Emergency stop (with output stage inhibit) with self reset • Inhibit output stage with self reset |
| Motor temperature prewarning – current parameter set | Motor temperature active parameter set – pre-warning. | 8622.8 | <ul style="list-style-type: none"> • No response • Warning • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage |
| Electromechanical utilization – prewarning | This parameter is used to set the device response to an exceeded prewarning threshold for electromechanical utilization (index 8336.2). | 8622.10 | <ul style="list-style-type: none"> • No response • Warning • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage |
| HW limit switches – current parameter set | | 8622.11 | <ul style="list-style-type: none"> • No response • Emergency stop (with output stage inhibit) • Emergency stop (with output stage inhibit) with self reset |
| SW limit switches – current parameter set | | 8622.12 | <ul style="list-style-type: none"> • No response • Emergency stop (with output stage inhibit) • Emergency stop (with output stage inhibit) with self reset |
| Encoder – warning | This parameter is used to set the device response to an encoder warning. | 8622.13 | <ul style="list-style-type: none"> • Warning • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage |
| Encoder – fault | This parameter is used to set the device response to an encoder fault. | 8622.14 | <ul style="list-style-type: none"> • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage |
| Additional encoder | This parameter is used to set the device response to a fault of an encoder that is not used for control (speed or positioning control). | 8622.15 | <ul style="list-style-type: none"> • Warning • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage |
| Encoder 1 – latest fault | | 8622.16 | <ul style="list-style-type: none"> • No response |
| Encoder 2 – latest fault | | 8622.17 | <ul style="list-style-type: none"> • No response |

| Parameterizable faults | Description | Index no. | Possible fault response |
|---|--|-----------|--|
| Encoder 1 – latest critical fault | | 8622.18 | <ul style="list-style-type: none"> No response Inhibit output stage |
| Encoder 2 – latest critical fault | | 8622.19 | <ul style="list-style-type: none"> No response Inhibit output stage |
| Response to external braking resistor fault | External braking resistor fault | 8622.20 | <ul style="list-style-type: none"> No response Warning Application stop (with output stage inhibit) Emergency stop (with output stage inhibit) Inhibit output stage |
| Application heartbeat timeout | This parameter is used to set the device response to a timeout of the application heartbeat. | 8622.21 | <ul style="list-style-type: none"> Warning Application stop (with output stage inhibit) Emergency stop (with output stage inhibit) Inhibit output stage |

7 Service

7.1 Electronics Service by SEW-EURODRIVE

If you are unable to rectify a fault, contact SEW-EURODRIVE Service. For the addresses, refer to www.sew-eurodrive.com.

When contacting SEW-EURODRIVE Service, always specify the following information so that our service personnel can assist you more effectively:

- Information on the device type on the nameplate (e.g. type designation, serial number, part number, product key, purchase order number)
- Brief description of the application
- Fault message on the status display
- Nature of the fault
- Accompanying circumstances
- Any unusual events preceding the problem

7.2 Extended storage

The following table shows the time intervals and maintenance works that are relevant for extended storage of the application inverter modules.

| Modules | Time interval | Maintenance |
|---|---------------|---|
| MDP90A...-C00/0 ¹⁾ | Every 2 years | Line connections: Connect the device to the line voltage for 5 minutes. |
| MDP90A.... for extended storage above 40 °C | | |

1) Power supply module with integrated braking resistor and capacitor

For all modules other than the ones listed, no maintenance is required.

DANGER



Uncovered power connections.

Severe or fatal injuries from electric shock.

- Install the touch guards at the modules, see chapter "Touch guards" (→ 64).
- Install the closing covers according to the regulations, see chapter "Touch guards" (→ 64).
- Never start up the application inverter without installed closed touch guards and closing covers.

7.2.1 Procedure in case maintenance has been neglected

If you have not performed maintenance regularly, SEW-EURODRIVE recommends that you increase the line voltage slowly up to the maximum voltage. This can be done, for example, by using a variable transformer for which the output voltage has been set according to the following overview. After you have completed the regeneration process, the device can be used immediately or stored again.

The following graduations are recommended:

AC 400/500 V devices:

- Stage 1: 0 V to AC 350 V within a few seconds.
- Stage 2: AC 350 V for 15 minutes.
- Stage 3: AC 420 V for 15 minutes.
- Stage 4: AC 500 V for 1 hour.

7.3 Shutdown

To shut down the application inverter, de-energize the application inverter using appropriate measures.



⚠ WARNING

Electric shock due to incompletely discharged capacitors.

Severe or fatal injuries.

- Observe a minimum switch-off time of 10 minutes after disconnecting the power supply.

7.3.1 Using energy storage units

Voltage from charged capacitors can still be present at the live components or power connections after disconnection from the supply voltage. Observe the following information to avoid electric shock and risk of injury:



⚠ WARNING

The energy storage units are still charged after the device has been switched off.

Severe or fatal injuries from electric shock.

The energy storage units must be discharged before you perform any work on the device. Only electrically skilled persons may discharge the energy storage units and install the fused connectors for discharging. For further information, refer to the documentation "MOVI-DPS® Discharge Unit".

- Prior to any electric work, the energy storage units must be discharged using the discharge units from SEW-EURODRIVE or discharge resistors.
- Observe the hazard symbols on the product.
- Disconnect the device from the power supply.
- Connect the energy storage unit to the discharge unit according to the listed connection variants.
- Install fused connectors for discharging on both MDC90A discharge connections.

7.4 Waste disposal

Observe the applicable national regulations.

Dispose of the following materials separately in accordance with the country-specific regulations in force, such as:

- Electronics scrap (printed circuit boards)
- Plastic
- Sheet metal
- Copper
- Aluminum



This product falls within the scope of the European WEEE Directive 2012/19/EU on waste electrical and electronic equipment.

Under no circumstances may electrical and electronic equipment be placed in regular household waste. The product must be disposed of properly in accordance with the currently applicable statutory regulations of the respective EU Member State, Norway, Liechtenstein, and Iceland.








The aim of this is to ease the burden on natural resources and to protect the environment and human health from hazardous substances by bringing them to recycling.

8 Technical data

8.1 Markings

8.1.1 Basic device





The MOVIDRIVE® modular application inverter complies with the following regulations and guidelines:

| Mark | Definition |
|---|--|
|  | The CE mark states the compliance with the following European guidelines: <ul style="list-style-type: none"> • Low Voltage Directive 2014/35/EU • EMC Directive 2014/30/EU • Machinery Directive 2006/42/EC • Directive 2011/65/EU for limiting the use of hazardous substances in electric and electronic equipment |
|  | Waste disposal of this product must be in compliance with the WEEE directive 2012/19/EU. |
|  | The EAC mark states compliance with the requirements of the technical regulations of the Customs Union of Russia, Kazakhstan, and Belarus. |
|  | The RCM mark states compliance with the technical regulations of the Australian Communications and Media Authority ACMA. |
|  | The China RoHS mark states compliance with directive SJ/T 11364-2014 for limiting the use of hazardous substances in electric and electronic equipment and their packaging. |
|  | The UL and cUL mark states the UL approval. ¹⁾ cUL is equivalent to CSA approval. |
|  | The NM mark states the compliance with the following Moroccan guidelines: <ul style="list-style-type: none"> • Low Voltage Directive N° 2573-14 (July 16, 2015) • EMC Directive N° 2574-14 (July 16, 2015) |




1) UL and cUL mark for the two-row design is in preparation.

8.1.2 Accessories





Braking resistors BR..

| Mark | Definition |
|---|--|
|  | The CE mark states the compliance with the following European guidelines: <ul style="list-style-type: none"> • Low Voltage Directive 2014/35/EU • Directive 2011/65/EU for limiting the use of hazardous substances in electric and electronic equipment |
|  | Waste disposal of this product must be in compliance with the WEEE directive 2012/19/EU. |
|  | The China RoHS mark states compliance with directive SJ/T 11364-2014 for limiting the use of hazardous substances in electric and electronic equipment and their packaging. |
|  | The cUR mark states the UL approval for this component. |





TCB thermal circuit breaker

| Mark | Definition |
|---|--|
|  | The CE mark states the compliance with the following European guidelines: <ul style="list-style-type: none"> • Low Voltage Directive 2014/35/EU • Directive 2011/65/EU for limiting the use of hazardous substances in electric and electronic equipment |
|  | The China RoHS mark states compliance with directive SJ/T 11364-2014 for limiting the use of hazardous substances in electric and electronic equipment. |
|  | The cUR mark states the UL approval for this component. |

NF.. line filter

| Mark | Definition |
|---|--|
|  | The CE mark states the compliance with the following European guidelines: <ul style="list-style-type: none"> • Directive 2011/65/EU for limiting the use of hazardous substances in electric and electronic equipment |
|  | Waste disposal of this product must be in compliance with the WEEE directive 2012/19/EU. |
|  | The China RoHS mark states compliance with directive SJ/T 11364-2014 for limiting the use of hazardous substances in electric and electronic equipment and their packaging. |
|  | The cUR mark states the UL approval for this component. |

ND.. line choke

| Mark | Definition |
|---|--|
|  | The CE mark states the compliance with the following European guidelines: <ul style="list-style-type: none"> • Low Voltage Directive 2014/35/EU • Directive 2011/65/EU for limiting the use of hazardous substances in electric and electronic equipment |
|  | Waste disposal of this product must be in compliance with the WEEE directive 2012/19/EU. |
|  | The China RoHS mark states compliance with directive SJ/T 11364-2014 for limiting the use of hazardous substances in electric and electronic equipment and their packaging. |
|  | The cUR mark states the UL approval for this component. |

8.2 General technical data

The following tables lists the technical data for all MOVIDRIVE® modular application inverters independent of

- Type
- Design
- Size
- Power rating

| | |
|--|--|
| Interference immunity | Meets EN 61800-3; 2. Environment |
| Interference emission | Limit value category C2 to EN 61800-3 |
| Ambient temperature ϑ_{amb} | 0 °C to +45 °C without derating |
| Type of cooling | Increased air cooling due to an installed, temperature-controlled fan. |
| Climatic requirements | <ul style="list-style-type: none"> • Extended storage (weatherproof): EN 60721-3-1 class 1K2 Temperature -25 °C to +70 °C (deviating from norm) Non-condensing; no moisture condensation • Transport (weatherproof): EN 60721-3-2 class 2K3 temperature -25 °C to +70 °C Non-condensing; no moisture condensation • Operation (fixed installation, weatherproof): EN 60721-3-3 class 3K3 temperature 0 °C to +45 °C (deviating from norm) Non-condensing; no moisture condensation |
| Chemically active substances | <ul style="list-style-type: none"> • Extended storage (weatherproof): EN 60721-3-1 class 2C2, no corrosive gases, no salt mist (deviating from norm) • Transport (weatherproof): EN 60721-3-2 class 2C2, no corrosive gases, no salt mist, no sea water (deviating from norm) • Operation (fixed installation, weatherproof): EN 60721-3-3 class 3C2, no corrosive gases, no salt mist |
| Mechanically active substances | <ul style="list-style-type: none"> • Extended storage (weatherproof): EN 60721-3-1 class 1S1, no conductive dust • Transport (weatherproof): EN 60721-3-2 class 2S1 • Operation (fixed installation, weatherproof): EN 60721-3-3 class 3S1, no conductive dust |
| Degree of protection according to EN 60529 | IP20 |
| Pollution class | 2 in accordance with IEC 60664-1 |
| Overvoltage category | III in accordance with IEC 60664-1 |
| Installation altitude | <p>Up to $h \leq 1000$ m without restrictions.</p> <p>The following restrictions apply to altitudes > 1000 m:</p> <ul style="list-style-type: none"> • From 1000 m to maximum 3800 m: I_N reduction by 1% per 100 m • From 2000 m to maximum 3800 m: To maintain protective separation and the air gaps and creepage distances according to EN 61800-5-1, an overvoltage protection device must be connected upstream to reduce the overvoltages from category III to category II. |

8.3 Technical data of MDP power supply modules

8.3.1 Performance data

| MOVIDRIVE® modular | Unit | MDP90A-...-503-4-... | | | | | |
|---|------|---|------|---|---|------|---|
| Type | | 0100 | 0100 | 0250 | 0500 | 0750 | 1100 |
| Size | | 1 | 1A | 2 | 3 | | 4 |
| Nominal power P _N | kW | 10 | | 25 | 50 | 75 | 110 |
| Input | | | | | | | |
| Nominal line voltage (to EN 50160) AC U _{line} | V | 3 × 380 – 500 V | | | | | |
| Nominal line current AC I _{line} | A | 16 | | 40 | 80 | 120 | 175 |
| Line frequency f _{line} | Hz | 50 – 60 Hz ± 10% | | | | | |
| Controlled rectifier | | no | | yes | | | |
| X1 connection | | Plug connector – 1 core: 0.25 – 4 mm ² – 2 cores: 0.25 – 2.5 mm ² (twin AEH) ¹⁾ | | M6 screw × 16 max. 16 mm ² | Screw M10 × 18 max. 70 mm ² | | Screw M10 × 25 max. 120 mm ² |
| PE connection | | | | M6 × 16 | M10 × 18 | | M10 × 25 |
| Output (DC link) | | | | | | | |
| Nominal DC link voltage U _{NDCL} | V | DC 560 | | | | | |
| Nominal DC link current DC I _{NDCL} | A | 21 | | 51 | 102 | 153 | 224 |
| Max. DC link current DC I _{DCL max} | A | 52 | | 127 | 255 | 382 | 560 |
| Additional capacitance | µF | – | 1000 | – | – | – | – |
| Overload capacity | | 250% × P _N : 1 s for cycle duration 10 s | | | | | |
| Connection for UZ-/UZ+ | | CU busbars | | | | | |
| | | M6 screw × 16 | | | | | Right: Screw M8 × 20 Left: M6 screw × 16 |
| PE connection | | M6 screw × 16 | | | | | |
| Brake chopper and braking resistor | | | | | | | |
| Minimum braking resistance value R _{BRmin} | Ω | 26 | | 12 | 4.7 | 3.6 | 2.3 |
| Maximum brake chopper power | kW | 250% × P _N | | | | | |
| Mean dischargeable power in regenerative operation | kW | 25% × P _N | | | | | |
| P _{eff} of the integrated braking resistance | kW | – | 0.2 | – | – | – | – |
| P _{max} of the integrated braking resistance | kW | – | 25 | – | – | – | – |
| X3 connection | | Plug connector – 1 core: 0.25 – 4 mm ² – 2 cores: 0.25 – 2.5 mm ² (twin AEH) ¹⁾ | | M6 screw × 16 max. 10 mm ² | M6 screw × 16 max. 35 mm ² | | Screw M10 × 25 max. 70 mm ² |
| | | M6 × 16 | | | | | M10 × 25 |
| General | | | | | | | |
| Nominal power loss 24 V | W | 15 | | | 20 | | 30 |
| Power section nominal power loss | W | 40 | | 90 | 190 | 290 | 420 |
| Permitted number of times power may be switched on/off per minute | | < 1 | | | | | |
| Minimum switch-off time for power off | s | 10 | | | | | |
| Mass | kg | 4 | 7.9 | 5.2 | 13 | 13 | 21 |
| Dimensions | | | | | | | |
| Width | mm | 60 | 120 | 60 | 150 | | 210 |
| Height | mm | 324 | | | 424 | | |
| Depth | mm | 250 | | | | | |

1) AEH: Conductor end sleeve

8.3.2 Electronics data – signal terminals

| MDP.. power supply module | Terminal | General electronics data |
|---|----------|---|
| DC 24 V voltage supply in accordance with IEC 61131 ¹⁾ | X5 | DC 24 V -10%, +20% For directly supplied DC 24 V brakes, observe the restricted tolerance range of -0% to +10% |
| Contacts | X5 | CU busbars |
| Evaluation of temperature sensor at braking resistor | X7.1 | DC 24 V auxiliary voltage output to supply X7:2 |
| | X7.2 | Sensor input for temperature monitoring of the braking resistor. • Signal contact closed: No overtemperature. • Signal contact open: Overtemperature. Connect isolated signal contacts only. |
| | X7.3/4 | Reserved |
| Connection | | Plug connectors – 1 core: 0.25 – 0.5 mm ² |

1) Note the restricted tolerance range

8.4 Technical data of MDA and MDD axis modules

8.4.1 MDA performance data

| MOVIDRIVE® modular | Unit | MDA90A-...-503-X-... | | | | | | | | | | | | |
|--|------|---|------|------|------|--|------|------------------------------------|------|--|--------------------|---------------------------------------|------------------------|------|
| Type | | 0020 | 0040 | 0080 | 0120 | 0160 | 0240 | 0320 | 0480 | 0640 ¹⁾ | 0640 ²⁾ | 1000 | 1400 | 1800 |
| Size | | 1 | | | | 2 | | 3 | | 4 | 5 | | 6 | |
| Nominal output current I _N PWM = 4 kHz | A | 2 | 4 | 8 | 12 | 16 | 24 | 32 | 48 | 64 | 64 | 100 | 140 | 180 |
| Input | | | | | | | | | | | | | | |
| Nominal DC link voltage U _{NDCL} | | DC 560 V | | | | | | | | | | | | |
| Nominal DC link current I _{NDCL} ³⁾ | A | 2 | 4 | 8 | 12 | 16 | 24 | 32 | 48 | 64 | 64 | 100 | 140 | 180 |
| Connection for UZ-/UZ+ | | CU busbars | | | | | | | | | | | | |
| | | Screw M6 × 16 | | | | | | | | | | | Screw M8 × 20 | |
| PE connection | | Screw M6 × 16 | | | | | | | | | | | | |
| Motor output | | | | | | | | | | | | | | |
| Output voltage V _{out} | V | 0 – max. V _{line} | | | | | | | | | | | | |
| Motor power ASM P _{Mot} | kW | 0.6 | 1.5 | 4 | 5.5 | 7.5 | 11 | 15 | 22 | 30 | 30 | 45 | 75 | 90 |
| Nominal output current I _N PWM = 4 kHz | A | 2 | 4 | 8 | 12 | 16 | 24 | 32 | 48 | 64 | 64 | 100 | 140 | 180 |
| Max. output current at f = 0 Hz | A | 125% × I _N : 1 s at PWM = 4 kHz | | | | | | | | | | | | |
| Overload capacity | | 250%: 1 s at PWM = 4 kHz | | | | | | | | | | | | |
| Apparent output power S _N ⁴⁾ | kVA | 1.4 | 2.8 | 5.5 | 8.5 | 11 | 17 | 22 | 33 | 44 | 44 | 69 | 97 | 125 |
| PWM frequency f _{PWM} | kHz | 4, 8, 16 (adjustable) | | | | | | | | | | | 4, 8 (ad- justable) | |
| Max. output frequency f _{max} | Hz | V/f: 599 VFC ^{PLUS} : 250 CFC: 500 ELSM®: 500 | | | | | | | | | | | | |
| X2 connection | | Plug connector - 1 core: 0.25 – 4 mm ² - 2 cores: 0.25 – 2.5 mm ² (Twin-AEH) ⁵⁾ | | | | Plug con- nector - 1 core: 0.5 – 16 mm ² - 2 cores: 0.25 – 6 mm ² (Twin-AEH) ⁵⁾ | | M6 bolt Max. 16 mm ² | | M10 screw Max. 70 mm ² or 2 × 25 mm ² | | M10 screw Max. 120 mm ² | | |
| PE connection | | | | | | | | Screw M6 × 16 | | Screw M6 × 18 | | Screw M10 × 25 | | |
| Brake output | | | | | | | | | | | | | | |
| Nominal brake voltage V _{BR} (DB00) | | DC 24 V, the tolerance depends on the DC 24 V supply | | | | | | | | | | | | |
| X10 connection | | Plug connector - 1 core: 0.25 – 2.5 mm ² - 2 cores: 0.5 – 1 mm ² (Twin-AEH) ⁵⁾ | | | | | | | | | | | | |
| General | | | | | | | | | | | | | | |
| Nominal power loss 24 V | W | 20 | | | | 22 | 25 | 30 | | 75 | 75 | | 115 | |
| Nominal power loss power section | W | 15 | 35 | 65 | 90 | 110 | 185 | 240 | 360 | 430 | 430 | 670 | 980 | 1250 |
| Mass | kg | 4 | | | 4.1 | 5.3 | | 7.1 | | 14 | 14 | | 18 | |
| Dimensions | | | | | | | | | | | | | | |
| Width | mm | 60 | | | | 90 | | | | 120 | 150 | | 210 | |
| Height | mm | 328 | | | | | | 428 | | | | | | |

| MOVIDRIVE® modular | Unit | MDA90A-...-503-X-... | | | | | | | | | | | | |
|--------------------|------|----------------------|------|------|------|------|------|------|------|--------------------|--------------------|------|------|------|
| Type | | 0020 | 0040 | 0080 | 0120 | 0160 | 0240 | 0320 | 0480 | 0640 ¹⁾ | 0640 ²⁾ | 1000 | 1400 | 1800 |
| Depth | mm | 265 | | | | | | | | | | | | |

1) For installation in new systems, the MDA90A-0640-... axis module in size 4 must be used

2) The MDA90A-0640-... axis module in size 5 is only used as a spare part for the MDA90A-0640-... axis module in size 5

3) The nominal DC link current is defined for $\cos\varphi = 0.82$

4) In relation to PWM = 4 kHz

5) AEH: Conductor end sleeve

8.4.2 MDD performance data

| MOVIDRIVE® modular | Unit | MDD9.A-...-503-X-... ¹⁾ | | MDD9.A-...-503-X-... with card slot ¹⁾ | | |
|---|------|---|---------|--|---------|---------|
| Type | | 0020 | 0040 | 0020 | 0040 | 0080 |
| Size | | 1 | | 2 | | |
| Nominal output current I _N PWM = 4 kHz | A | 2 × 2 | 2 × 4 | 2 × 2 | 2 × 4 | 2 × 8 |
| Input | | | | | | |
| Nominal DC link voltage U _{NDCL} | | DC 560 V | | | | |
| Nominal DC link current I _{NDCL} ²⁾ | A | 4 | 8 | 4 | 8 | 16 |
| Connection for UZ-/UZ+ | | CU busbars | | | | |
| | | M6 screw × 16 | | | | |
| PE connection | | M6 screw × 16 | | | | |
| Motor output | | | | | | |
| Output voltage U _{out} | V | 0 – max. V _{line} | | | | |
| Motor power ASM P _{Mot} | kW | 2 × 0.55 | 2 × 1.5 | 2 × 0.55 | 2 × 1.5 | 2 × 4 |
| Nominal output current I _N PWM = 4 kHz | A | 2 × 2 | 2 × 4 | 2 × 2 | 2 × 4 | 2 × 8 |
| Max. output current at f = 0 Hz | A | 125% × I _N : 1 s at PWM = 4 kHz | | | | |
| Overload capacity | | 250%: 1 s at PWM = 4 kHz | | | | |
| Apparent output power S _N ³⁾ | kVA | 2 × 1.4 | 2 × 2.8 | 2 × 1.4 | 2 × 2.8 | 2 × 5.5 |
| PWM frequency f _{PWM} | kHz | 4, 8 (adjustable) | | | | |
| Max. output frequency f _{max} | | U/f: 599 Hz VFC ^{PLUS} : 250 Hz CFC: 500 Hz ELSM®: 500 Hz | | | | |
| X2 connection | | Plug connectors – 1 core: 0.25 – 4 mm ² – 2 cores: 0.25 – 2.5 mm ² (Twin-AEH) ⁴⁾ | | | | |
| PE connection | | | | | | |
| Brake output | | | | | | |
| Nominal brake voltage V _{BR} (DB00) | | DC 24 V, the tolerance depends on the DC 24 V supply | | | | |
| X10 connection | | Plug connectors – 1 core: 0.25 – 2.5 mm ² – 2 cores: 0.5 – 1 mm ² (Twin-AEH) ³⁾ | | | | |
| General | | | | | | |
| Nominal power loss 24 V | W | 20 | | | | 25 |
| Power section nominal power loss | W | 2 × 15 | 2 × 35 | 2 × 15 | 2 × 35 | 2 × 65 |
| Mass | kg | 4 | | 4.85 | | |
| Dimensions | | | | | | |
| Width | mm | 60 | | 90 | | |
| Height | mm | 328 | | | | |
| Depth | mm | 265 | | | | |

1) MDD90A-...: With encoder input X15, without MOVILINK® DDI X16. MDD91A-...: With MOVILINK® DDI X16, with encoder input X15

2) The nominal DC link current is defined for $\cos\varphi = 0.82$

3) In relation to PWM = 4 kHz

4) AEH: Conductor end sleeve

8.4.3 Electronics data – Signal terminals

| | Terminal designation | | Specifications |
|--|----------------------|------------------------------|---|
| | Single-axis module | Double-axis module | |
| General | | | |
| Design | | | In accordance with IEC 61131-2 |
| Supply voltage | | | |
| Connection | X5 | | External power supply 24 V in accordance with IEC 61131 ¹⁾ |
| Connection | X5 | | CU busbars |
| Digital inputs | | | |
| Cycle time I/O | | | 1 ms |
| Number | | | 6 |
| Response time | | | 100 µs plus cycle time |
| Assignment | X20: 1 – 6 | X20_1: 1 – 6 X20_2: 1 – 6 | DI00: "Output stage enable" permanently assigned. DI01 – DI05: For the selection option, see the parameter menu. All 6 inputs are suitable for Touchprobe function. Latency period < 100 µs, max. 2 simultaneously. DI04, DI05: Connection HTL low-resolution encoder (only MDA). |
| | X20: 7 | X20_1: 7 X20_2: 7 | GND |
| | X20: 8 | X20_1: 8 X20_2: 8 | +24 V supply voltage Maximum output current = 50 mA |
| Connection | | | Plug connector – 1 core: 0.25 – 2.5 mm ² – 2 cores: 0.5 – 1.5 mm ² (twin AEH) ²⁾ Shield terminals for control cables available. |
| Digital outputs | | | |
| Cycle time I/O | | | 1 ms |
| Number | | | • MDA: 1 × 4 • MDD: 2 × 4 |
| Response time | | | 175 µs plus cycle time |
| Output current | | | I _{max} = 50 mA |
| Short-circuit protection | | | Yes |
| Assignment | X21: 1 – 4 | X21_1: 1 – 4 X21_2: 1 – 4 | DO00 – DO03: For the selection option, see the parameter menu. |
| | X21: 5 | X21_1: 5 X21_2: 5 | GND |
| Connection | | | Plug connector – 1 core: 0.25 – 2.5 mm ² – 2 cores: 0.5 – 1.5 mm ² (twin AEH) ¹⁾ Shield terminals for control cables available. |
| Brake control/temperature sensor motor | | | |
| Assignment | X10:DB0 | X10_1:DB0 X10_2:DB0 | DB00: Direct control is possible with selected brakes from SEW-EURODRIVE. See chapter "Project Planning" for more information. |
| | X10:GND | X10_1:GND X10_2:GND | GND |
| | X10:TF1 | X10_1:TF1 X10_2:TF1 | Sensor input for temperature monitoring of the motor |
| | X10:GND | X10_1:GND X10_2:GND | GND |
| Connection | | | Plug connector – One core: 0.25 – 2.5 mm ² – Two cores: 0.5 – 1 mm ² (twin AEH) ¹⁾ Shield terminals for control cables available. |
| Encoder supply | | | |
| | X15:13 | X15:13_1 X15:13_2 | X15:13 DC 24 V, I _{max} = 500 mA |

| | Terminal designation | | Specifications |
|--|----------------------|----------------------|---|
| | Single-axis module | Double-axis module | |
| | X15:15 | X15:15_1 X15:15_2 | X15:15 DC 12 V, $I_{\max} = 500 \text{ mA}$ |

1) For directly supplied DC 24 V brakes, observe the restricted tolerance range of -0% to +10%

2) AEH: Conductor end sleeve

| MOVILINK® DDI connection | | |
|--------------------------|----------------|--------------------------------------|
| MDA90A-.. | X16 | DC 24 V, $I_{\max} = 500 \text{ mA}$ |
| MDD91A-.. | X16_1 X16_2 | |

NOTICE

Connection of inductive loads to digital outputs

Destruction of digital outputs.

If you connect inductive loads to digital outputs, you must install an external protective element (freewheeling diode).

8.4.4 Electronics data – Drive safety functions

The table below shows the technical data of the application inverter relating to the integrated safety technology.

The safety-related digital inputs comply with type 3 in accordance with IEC 61131-2.

Reference potential for the F_STO_P1 and F_STO_P2 is STO_M (contact at terminal X6:2).

| | Terminal designation | General electronics data | | |
|---|----------------------|---|----------------|-----------------------------|
| Safety contact STO | X6 | | | |
| Electrical data of inputs F_STO_P1, F_STO_P2 | | Minimum | Typical | Maximum |
| Input voltage range | X6:1 and X6:3 | DC -3 V | DC 24 V | DC 30 V |
| Input capacitance | | – | 1 nF | 10 nF |
| Power consumption at DC 24 V | | – | 200 mW | 300 mW |
| Input voltage for ON status (STO) | | DC 11 V | – | DC 30 V |
| Input voltage for OFF status (STO) | | DC -3 V | – | DC 5 V |
| Permitted leakage current of the external safety controller | | – | – | 1 mA |
| Technical data | | | | |
| Time from disconnecting the safety voltage until deactivation of the rotating field | | – | 1.5 ms | 10 ms 2 ms ¹⁾ |
| Time from connecting the safety voltage until activation of the rotating field | | – | – | 110 ms |
| Connection | | Plug connectors – 1 core: 0.25 – 1.5 mm ² – 2 cores: 0.25 – 0.5 mm ² (twin AEH) ²⁾ | | |

1) Only when the STO is used and controlled via a MOVISAFE® CS.A card

2) AEH: Conductor end sleeve

8.4.5 Different functionality of the axis modules MDA/MDD

| Functionality | MDA90A-.. single-axis module | MDD9.A-.. double-axis module |
|--|------------------------------|------------------------------|
| Cam switch | Yes | – |
| Number of drive trains per output stage | 2 | 1 |
| Encoder option | Yes | – |
| I/O option | Yes | – |
| PWM frequency constant | 4 kHz/8 kHz/16 kHz | 4 kHz/8 kHz |
| Process data processing basic cycle | 500 µs/1 ms/1ms PLC | 1 ms |
| Simple encoder evaluation via digital inputs (DI04/DI05) | Yes | – |
| Sampling cycle n/X control | 0.25 ms/0.5 ms/1 ms/2 ms | 0.5 ms/1 ms/2 ms |

8.5 Technical data of the MDC90A-0001/0002-.. capacitor modules

8.5.1 Performance data

| Capacitor module | MDC90A-0001-50X-X-000 | MDC90A-0002-50X-X-000 |
|--|---|-----------------------|
| DC link connection | | |
| Nominal DC link voltage U _{line} (ac-cording to EN 50160) | DC 560 V | |
| Nominal capacitance | 70 µF | 130 µF |
| Connection for UZ-/UZ+ | M6 screw × 16, max. 35 mm ² | |
| PE connection | M6 screw × 16 | |
| Connection of safe brake module X2 | Plug connectors | |
| | – 1 core: 0.25 – 4 mm ² – 2 cores: 0.25 – 2.5 mm ² (Twin-AEH) | |
| General | | |
| Mass | 3.8 kg | 4.5 kg |
| Dimensions | | |
| Width | 60 mm | |
| Height | 328 mm | |
| Depth | 265 mm | |

8.6 Technical data of the master module UHX45A/MDM90A

| MOVIDRIVE® modular | Terminal | UHX45A/MDM90A |
|---|----------|--|
| Input | | |
| DC 24 V supply ¹⁾ | X5_A | 40 A |
| Connection contacts | | 2-pin plug connector <ul style="list-style-type: none">• 1 core: 0.5 – 10 mm²• 2 cores: 0.5 – 6 mm² |
| Output | | |
| DC 24 V voltage output UHX45A ²⁾ | X5_B | Maximum 4 A |
| Fuse for voltage output UHX45A | | 5 × 20, 4 A, 125 V, miniature fuse, slow-blow Part number: 18190464 |
| DC 24 V connection | | Maximum 40 A |
| General | | |
| Power loss UHX45A | | 12 W |
| Mass | | 1.85 kg |
| Dimensions | | |
| Width | | 60 |
| Height | | 383 |
| Depth | | 250 |



1) The master module can be used to supply the DC 24 V supply voltage for the entire axis system

2) Auxiliary output X5_B for supply of MOVI-C® CONTROLLER advanced UHX45A

8.7 Dimension sheets of the modules



8.7.1 Dimension sheets of the power supply modules

MDP90A-0100-.. (size 1)



18014414468029707



MDP90A-0100-...-C00 (size 1A)



18014414468032139




25953079/EN – 01/2020

MDP90A-0250-.. (size 2)



27021613722775563


MDP90A-0500 – 0750-.. (size 3)




18014416571936267

25953079/EN – 01/2020

MDP90A-1100-.. (size 4)





+ EMC



18014417553895435

MDP92A-..





28547711499

25953079/EN – 01/2020




8.7.2 Dimension sheets of the axis modules

MDA90A-0020 – 0120-.. (size 1)



18014414467556747



MDA90A-0160 – 0240-.. (BG 2)




18014414467559179

25953079/EN – 01/2020

MDA90A- 0320 – 0480-.. (BG 3)






+ EMC





27021613722763403

MDA90A-0640-.. (size 4)




9007223429893643

MDA90A-0640 – 1000.. (size 5)






+ EMC






18014416571933835

MDA90A-1400 – 1800-.. (size 6)






18014417553897867

MDD9.A-0020 – 0040-.. (size 1)



18014414468024843


MDD9.A-0020 – 0080-.. (BG 2)



18014414468027275


25953079/EN – 01/2020

8.7.3 Dimension sheet of the capacitor modules



29497403787

8.7.4 Dimension sheet of the master module



20724035339

8.8 Technical data of the cards

8.8.1 CIO21A and CID21A input/output cards

The CIO21A input/output card provides digital/analog inputs and outputs; the CID21A cards provide digital inputs and outputs.

| | Terminal designation/ specification | | Specifications |
|--------------------------|--|----------|--|
| | CIO21A | CID21A | |
| Part number | 28229495 | 28229487 | |
| General | | | |
| Design | | | In accordance with IEC 61131-2 (type 3 for digital inputs) |
| Cycle time | | | 1 ms |
| Power consumption | 1.2 W | 0.4 W | Base load (exclusively total power at outputs) |
| Connection contacts | | | Plug connector – 1 core: 0.25 – 0.5 mm ² Shield terminals for control lines available |
| Digital inputs | | | |
| Number | | | 4 |
| Response time | | | 160 µs plus cycle time |
| Assignment | X52: 1 – 4 | | DI10 – DI13: For the selection option, see parameter menu |
| | X52: 5 | | GND |
| Digital outputs | | | |
| Number | | | 4 |
| Response time | | | 175 µs plus cycle time |
| Output current | | | I ≤ 50 mA |
| Capacitive load | | | ≤ 300 nF |
| Inductive load | | | Not permitted |
| Protection device | | | Short-circuit proof, protected against external voltage DC 0 – 30 V |
| Assignment | X52: 6 – 9 | | DO10 – DO13: For the selection option, see parameter menu |
| | X52: 10 | | GND |
| Analog inputs | | | |
| Number | | | 2 |
| Type | | | Differential Switchable to current input |
| Range of values | | | 0 to +10 V, -10 V to +10 V 0(4) – 20 mA |
| Assignment | X50:2 X50:3 | | Analog input AI21 Reference of analog input AI21 |
| | X50:4 X50:7 | | GND |
| | X50:5 X50:6 | | Analog input AI31 Reference of analog input AI31 |
| Voltage input | | | |
| Resolution | | | 0 to +10 V (11 bit), -10 V to +10 V (12 bit) |
| Tolerance | | | ± 0.5% |
| Overvoltage immunity | | | DC -20 V to DC +20 V |
| Input resistance | | | ≥ 10 kΩ |
| Current input | | | |
| Resolution | | | 0(4) – 20 mA (11 bit) |
| Tolerance | | | ± 2% |
| Load impedance | | | (Internal) 250 Ω |
| Overvoltage immunity | | | DC -10 V to DC +10 V |
| Analog outputs | | | |
| Number | | | 2 |
| Short-circuit protection | | | Yes |

| | Terminal designation/ specification | | Specifications |
|--------------------------|--|--------|---------------------------------|
| | CIO21A | CID21A | |
| Assignment | X51:1 X51:4 | | Analog voltage output AOV2/AOV3 |
| | X51:2 X51:5 | | Analog current output AOC2/AOC3 |
| | X51: 3, 6 | | GND |
| Voltage output | | | |
| Tolerance | | | ± 5% |
| Capacitive load | | | ≤ 300 nF |
| Inductive load | | | ≤ 500 µH |
| Load resistance | | | ≥ 1 kΩ |
| Resolution | | | 12 bit |
| Reset state | | | 0 V |
| Output value | | | -10 V to +10 V ≤ 10 mA |
| Current output | | | |
| Tolerance | | | ± 3 % |
| Capacitive load | | | ≤ 300 nF |
| Inductive load | | | None |
| Load resistance | | | ≤ 500 Ω |
| Resolution | | | 11 bit |
| Reset state | | | 0 mA |
| Measuring range | | | 0(4) – 20 mA |
| Reference voltage output | | | |
| Short-circuit protection | | | Yes |
| Output voltage | | | DC -10 V, DC +10 V |
| Tolerance | | | ± 0.5 % |
| Noise | | | ≤ 10 mA |
| Output current | | | ≤ 3 mA |
| Capacitive load | | | ≤ 300 nF |
| Inductive load | | | ≤ 500 µH |
| Assignment | X50: 1 | | REF1 (DC +10 V) |
| | X50: 8 | | REF2 (DC -10 V) |

NOTICE

Connection of inductive loads to digital outputs

Destruction of digital outputs.

If inductive loads are connected to digital outputs, you must install an external protective element (freewheeling diode).

8.8.2 CES11A multi-encoder card

Voltage supply

The multi-encoder card is supplied by the basic device.

Technical data of encoder supply

| | Terminal designation | Specifications |
|--|----------------------|--|
| Part number | | 28229479 |
| Power consumption | | |
| Nominal power loss 24 V | | 0.8 W |
| Maximum power consumption 24 V (card including encoder supply) | | 12.8 W |
| Encoder supply | | |
| 12 V | X17:15 | DC 12 V \pm 10% |
| 24 V | X17:13 | DC 24 V -10%, +20% in accordance with EN 61131 ¹⁾ |
| Nominal output current 12 V or 24 V | | 500 mA |
| Peak current I_{max} for 150 μ s | | 1000 mA |
| Capacitive load | | < 220 μ F |
| Inductive load | | < 500 μ H |
| Short-circuit protection of 12 V supply | | Yes, but a permanent short circuit is not permitted. |
| Short-circuit protection of 24 V supply | | Yes, but a permanent short circuit is not permitted. |
| Evaluable temperature sensor | | TF / TH / KTY84-130 / Pt1000 |

1) Note the restricted tolerance range

Encoder connection

| Encoder connection | Specification |
|--------------------------------|--|
| Connection on encoder card end | 15-pin socket |
| Maximum encoder cable length | - HTL encoder ES7C and EG7C: 300 m - Standard HTL encoder: 200 m - Other encoders: 100 m |

8.8.3 Safety cards CS..A

General technical data

| | Value |
|--|--|
| Ambient temperature for storage of the safety card | $\geq -25\text{ °C} - \leq 85\text{ °C}$ |
| Ambient temperature of MOVIDRIVE® system/technology, all sizes (For derating, see the "MOVIDRIVE® system" and "MOVIDRIVE® technology" operating instructions) | <ul style="list-style-type: none"> • $0\text{ °C} - 40\text{ °C}$ without derating • $40\text{ °C} - 55\text{ °C}$ with derating |
| Ambient temperature of MOVIDRIVE® modular, all sizes | $0\text{ °C} - 45\text{ °C}$ without derating |
| Installation altitude | Maximum 3800 m above sea level |

Safe digital inputs

| F-DI00 – F-DI03 | Value/description |
|---|---|
| Properties | DC 24 V input pursuant to EN 61131-2, type 3 |
| Signal level | <ul style="list-style-type: none"> • Logic "0" = LOW input: $\leq 5\text{ V}$ or $\leq 1.5\text{ mA}$ • Logic "1" = HIGH input: $\geq 11\text{ V}$ and $\geq 2\text{ mA}$ |
| Reference ground | GND |
| Power demand (typical) | 0.21 W at DC 24 V |
| Input current | $\leq 15\text{ mA}$ |
| Input resistance | $\leq 4\text{ k}\Omega$ at DC 24 V |
| Input filter time, parameterizable | 4 ms – 250 ms |
| Permitted cable length | 30 m |
| Error response time with single-pole connection | No greater than the response time without error. |
| Edge steepness of input signal | $> 120\text{ V/s}$ |
| Input capacitance | $< 500\text{ pF}$ |

Sensor supply

| F-SS0, F-SS1 | Value/description |
|--------------------------------------|---|
| Properties | <ul style="list-style-type: none"> DC 24 V output pursuant to EN 61131-2 Short circuit and overload protection No galvanic isolation |
| Rated current | 150 mA |
| Inrush current (≤ 10 ms) | 300 mA |
| Short-circuit protection | 1.2 A |
| Internal voltage drop | < DC 1.3 V |
| Pulsed voltage supply (if activated) | <ul style="list-style-type: none"> 2 ms open (LOW) Period duration, pulsed voltage supply: 8 ms |
| Permitted cable length | 30 m (per sensor) |
| Leakage current (F-SSx blocked) | < 0.1 mA |

Safe digital outputs

| F-DO00_P/M, F-DO01_P/M | Value/description |
|--|---|
| Features | <ul style="list-style-type: none"> DC 24 V output in accordance with EN 61131-2 Short circuit and overload protection |
| Rated current | 150 mA |
| Inrush current (≤ 10 ms) | 300 mA |
| Leakage current (F-DOx blocked) | < 0.1 mA |
| Maximum switching frequency | <ul style="list-style-type: none"> 10 Hz during operation < 1 minute 0.5 Hz during operation > 1 minute |
| Overload protection | 210 mA |
| Minimum current for wire break monitoring | 15 mA |
| Permitted cable length | 30 m |
| Load capacitance (max. test pulse duration) | ≤ 300 nF |
| Load capacitance (1 ms test pulse duration) | 50 nF |
| Capacitance to GND/PE (sourcing output only) | ≤ 10 nF |
| Load capacitance with diode decoupling | ≤ 12 μ F |
| Load inductance | ≤ 100 μ H |
| Load inductance with freewheeling diode | ≤ 40 H |
| Minimum load resistance | > 130 Ω |

8.9 Technical data of encoder interfaces

8.9.1 Basic device

| | Terminal designation | Specification |
|---|----------------------|--|
| Encoder interface | X15:1 – 15 | Supported encoders |
| | | Resolver |
| | | SIN/COS |
| | | TTL/HTL |
| | | HIPERFACE® |
| | | Encoders with RS422 signals |
| Connecting contacts | | 15-pin socket |
| Encoder supply | | |
| Nominal output voltage U_{S24VG} according to IEC 61131 | | DC 24 V |
| Nominal output voltage U_{S12VG} according to IEC 61131 | | DC 12 V |
| I_{max} | | 500 mA |
| I_{peak} for 150 µs | | 1000 mA |
| Short-circuit protection of 12 V supply | | Yes, but a permanent short circuit is not permitted. |
| Short-circuit protection of 24 V supply | | Yes, but a permanent short circuit is not permitted. |

8.9.2 CES11A multi-encoder card

| | Terminal designation | Specification |
|---|----------------------|-------------------------------|
| encoder interface | X17:1 – 15 | Supported encoders |
| | | SIN/COS |
| | | TTL/HTL |
| | | HIPERFACE® |
| | | EnDat2.1 with sin/cos signals |
| | | SSI |
| | | CANopen |
| | | Encoders with RS422 signals |
| Connecting contacts | | 15-pin socket |
| Encoder supply | | |
| Nominal output voltage U_{S24VG} according to IEC 61131 | | DC 24 V |
| Nominal output voltage U_{S12VG} according to IEC 61131 | | DC 12 V |
| I_{max} | | 500 mA |
| I_{peak} for 150 µs | | 1000 mA |

8.10 Technical data of braking resistors, filters and chokes

8.10.1 Braking resistors type BW.../BW...-T

General

The BW... / BW...-T braking resistors are adapted to the technical characteristics of the application inverter.

There are braking resistors with different continuous and peak braking power available.

The braking resistors can be protected against overload and overtemperature by the customer by using a thermal overload relay. The tripping current is set to the value I_F , see the following tables (→ 284).

The braking resistors of the series BW...-T are equipped with an integrated temperature switch that monitors the temperature. If the nominal operating temperature is exceeded, the temperature switch triggers a signal contact. The temperature switch does not switch off the braking resistor. This is why the temperature switch must be evaluated to avoid thermal overload of the braking resistor.

Another possibility to protect the braking resistor is the TCB thermal circuit breaker. The TCB thermal circuit breaker protects the braking resistor against continuous overload and power peaks over short periods.

INFORMATION



Use of protection devices

Only use the protection devices listed in the following section:

- TCB thermal circuit breaker
- Internal temperature switch -T
- External bimetallic relay

→ See also chapter "Protection against thermal overload of the braking resistor" (→ 132).

UL and cUL approval

The listed braking resistors have cRUus approvals independent of the application inverter.

Technical data and assignment to an inverter

Technical data

| Braking resistor | Unit | BW047-002 ¹⁾ | BR047-010-T | BR027-016-T | BW027-024-T |
|--------------------------------------|------|-------------------------|---------------------------|-------------|-------------|
| Part number | | 08281661 | 17983207 | 17983215 | 17983231 |
| Nominal power P _N | kW | 0.2 | 1 | 1.6 | 2.4 |
| Resistance value R _{BW} | Ω | 47 ±10% | 47 ±10% | 27 ± 10% | |
| Tripping current I _{trip} | A | 1.6 | 4.6 | 7.7 | 9.4 |
| Design | | Flat-type resistor | Wire resistor | | |
| Power connections | | – | 0.75 – 10 mm ² | | |
| Tightening torque | Nm | – | 1.5 – 1.8 | | |
| PE connection | | – | M6 stud | | |
| Tightening torque PE | Nm | – | 1.8 | | |
| Degree of protection | | IP65 | IP20 | | |
| Ambient temperature ϑ _{amb} | | -20 °C to +40 °C | | | |
| Mass | kg | 0.6 | 4 | 5.8 | 8 |

1) In the documented assignment of inverter and flat-type resistor, flat-type resistors have a thermal protection (non-replaceable fuse) that interrupts the current circuit in the event of overload.

Assignment

| Braking resistor | | BW047-002 | BR047-010-T | BR027-016-T | BW027-024-T |
|-------------------------|--|-------------|-------------|-------------|-------------|
| Assignment to MDP90A-.. | | 0100 – 1100 | | | |
| Assignment to MDR91A-.. | | 0500/0750 | | | |
| Assignment to MDP92A-.. | | 0250 | | | |

Technical data

| Braking resistor | Unit | BW012-016 | BW012-024 | BW012-050-T |
|---------------------------------------|----------|---------------------------|-----------|---------------|
| Part number | | 18213243 | 17983894 | 18201407 |
| Nominal power P_N | kW | 1.6 | 2.4 | 5 |
| Resistance value R_{BW} | Ω | $12 \pm 10\%$ | | |
| Tripping current I_{trip} | A | 11.5 | 14.1 | 20.4 |
| Design | | Wire resistor | | Grid resistor |
| Power connections | | 0.75 – 10 mm ² | | M8 stud |
| Tightening torque | Nm | 1.5 – 1.8 | | 6 |
| PE connection | | M6 stud | | M6 stud |
| Tightening torque PE | Nm | 1.8 | | 3 |
| Degree of protection | | IP20 | | |
| Ambient temperature ϑ_{amb} | | -20 °C to +40 °C | | |
| Mass | kg | 5.8 | 8 | 12 |

Assignment

| Braking resistor | | BW012-016 | BW012-024 | BW012-050-T |
|-------------------------|--|-------------|-----------|-------------|
| Assignment to MDP90A-.. | | 0250 – 1100 | | |
| Assignment to MDR91A-.. | | 0500/0750 | | |
| Assignment to MDP92A-.. | | 0250 | | |

Technical data

| Braking resistor | Unit | BR106-T | BR206-T | BR005-07 0 | BR004-050- 01 | BR002-07 0 | BR003-420 -T |
|---------------------------------------|----------|------------------|----------|----------------|------------------|----------------|-----------------|
| Part number | | 18200834 | 18204120 | 17983282 | 18200133 | 17983304 | 13302345 |
| Nominal power P_N | kW | 13.5 | 18 | 7 | 5 | 7 | 42 |
| Resistance value R_{BW} | Ω | $6 \pm 10\%$ | | $4.7 \pm 10\%$ | $3.6 \pm 10\%$ | $2.3 \pm 10\%$ | $2.5 \pm 10\%$ |
| Tripping current I_{trip} | A | 47.4 | 54.7 | 38.6 | 37.3 | 55.2 | 135.1 |
| Design | | Grid resistor | | | | | |
| Power connections | | M8 stud | | | | M8 stud | M12 stud |
| Tightening torque | Nm | 6 | | | | 6 | 15.5 |
| PE connection | | M6 stud | | | | M6 stud | M10 stud |
| Tightening torque PE | Nm | 3 | | | | 3 | 10 |
| Degree of protection | | IP20 | | | | | |
| Ambient temperature ϑ_{amb} | | -20 °C to +40 °C | | | | | |
| Mass | kg | 30 | 40 | 13 | 12 | 33 | 93 |

Assignment


| Braking resistor | | BR106-T | BR206-T | BR005-07 0 | BR004-050- 01 | BR003-42 0-T | BR002-070 |
|-------------------------|--|-------------|---------|---------------|------------------|-----------------|-----------|
| Assignment to MDP90A-.. | | 0500 – 1100 | | | 0750 – 1100 | 1100 | |
| Assignment to MDR91A-.. | | 0500/0750 | | | 0750 | – | – |

Technical data BW...-T signal contact

| Specifications for BW...-T signal contact | Design |
|---|---|
| Connection contacts | 0.75 – 2.5 mm ² |
| Tightening torque | 0.6 Nm |
| Switching capacity | DC 2 A / DC 24 V (DC11) AC 2 A / AC 230 V (AC11) |
| Switch contact (NC contact) | According to EN 61800-5-1 |

Dimension sheets and dimensions

Wire resistor




18874863883

[1] Cable entry is possible from both sides.

| Braking resistor | Main dimensions in mm | | | Mounting dimensions in mm | | | | Cable gland |
|------------------|-----------------------|-----|-----|---------------------------|-----|-----|---|-------------|
| | A | B | C | a | b | d | x | |
| BR047-010-T | 749 | 92 | 125 | 630 | 80 | 6.5 | 8 | M25+M12 |
| BR027-016-T | 649 | 185 | 125 | 530 | 150 | 6.5 | 8 | M25+M12 |
| BW027-024-T | 649 | 275 | 125 | 530 | 240 | 6.5 | 8 | M25+M12 |
| BW012-016 | 649 | 185 | 120 | 530 | 150 | 6.5 | 8 | M25 |
| BW012-024 | 649 | 275 | 125 | 530 | 240 | 6.5 | 9 | M25 |

Grid resistor mounting position 1




18874868747

| Braking resistor | Main dimensions in mm | | | Mounting dimensions in mm | | | | Cable gland |
|------------------|-----------------------|-----|-----|---------------------------|-----|------|---|-------------|
| | A | B | C | a | b | d | x | |
| BW012-050-T | 395 | 490 | 260 | 370 | 380 | 10.5 | — | — |
| BR106-T | 795 | 490 | 270 | 770 | 380 | 10.5 | — | — |
| BR206-T | 995 | 490 | 270 | 970 | 380 | 10.5 | — | — |
| BR005-070 | 395 | 490 | 260 | 370 | 380 | 10.5 | — | — |
| BR004-050-01 | 395 | 490 | 260 | 370 | 380 | 10.5 | — | — |
| BR002-070 | 395 | 490 | 260 | 370 | 380 | 10.5 | — | — |

| Braking resistor | Main dimensions in mm | | | Mounting dimensions in mm | | | | Cable gland |
|------------------|-----------------------|-----|-----|---------------------------|-----|------|---|-------------|
| | A | B | C | a | b | d | x | |
| BW012-050-T | 395 | 490 | 260 | 370 | 380 | 10.5 | - | - |
| BR106-T | 795 | 490 | 270 | 770 | 380 | 10.5 | — | — |
| BR206-T | 995 | 490 | 270 | 970 | 380 | 10.5 | — | — |
| BR005-070 | 395 | 490 | 260 | 370 | 380 | 10.5 | — | — |
| BR004-050-01 | 395 | 490 | 260 | 370 | 380 | 10.5 | — | — |
| BR002-070 | 395 | 490 | 260 | 370 | 380 | 10.5 | — | — |


Grid resistor mounting position 2



18874876043

| Braking resistor | Main dimensions in mm | | | Mounting dimensions in mm | | | | Cable gland |
|------------------|-----------------------|-----|-----|---------------------------|-----|------|---|-------------|
| | A | B | C | a | b | d | x | |
| BW003-420-T | 995 | 490 | 710 | 970 | 380 | 10.5 | - | - |

Flat type resistor



18874878475

| Braking resistor | Main dimensions in mm | | | Mounting dimensions in mm | | | | Cable gland |
|------------------|-----------------------|----|----|---------------------------|----|---|---|-------------|
| | A | B | C | a | b | d | x | |
| BW047-002 | 110 | 80 | 15 | 98 | 60 | - | - | - |


Touch guard BS..

Description

A BS.. touch guard is available for braking resistors in flat design.

| Touch guard | BS005 |
|----------------------|-----------|
| Part number | 0813152X |
| for braking resistor | BW047-002 |

Dimension sheet BS..



1455849867

- [1] Grommet
- [2] Support rail mounting

| Type | Main dimensions in mm | | | Mounting dimensions mm | | | | | Mass kg |
|--------|-----------------------|-----|-----|------------------------|---|----|---|------|---------|
| | A | B | C | b | d | e | a | x | |
| BS-005 | 60 | 160 | 252 | 125 | 4 | 20 | 6 | 17.5 | 0.5 |

Mounting rail installation

A mounting rail attachment HS001 is available from SEW-EURODRIVE, part number 8221944, for mounting the touch guard on a mounting rail.

8.10.2 TCB thermal circuit breaker option

General

The TCB thermal circuit breaker protects the braking resistor from constant overload and protects in case of a short circuit in the cable or the braking resistor.

The setting range of the thermal circuit breaker has to be selected in such a way that it corresponds to the tripping current I_F of the braking resistor.

The switch reacts to the following events:

- Thermal overload via current monitoring device.
- Short circuit.

In the event of a fault, the thermal circuit breaker switches off the braking resistor. The present fault is signaled via isolated NO and NC contacts.

After fault elimination, the thermal circuit breaker can be reconnected like a normal miniature circuit breaker.

The thermal circuit breaker is installed on DIN rails (TS35).

UL and cUL approval

The listed thermal circuit breakers have a cRUus approval independent of the inverter.

Technical data


| Circuit breaker type | Unit | TCB0040 | TCB0063 | TCB0100 |
|---|-----------------|------------------------|----------|----------|
| Part number | | 19170424 | 19170432 | 19170440 |
| Setting range | A | 2.5 – 4 | 4 – 6.3 | 6.3 – 10 |
| Connection cross section main contact | mm ² | 1.5 – 16 | | |
| Tightening torque | Nm | 2.5 | | |
| Signal contact connection cross section | mm ² | 0.5 – 1.5 | | |
| Tightening torque | Nm | 0.8 | | |
| Mechanical service life | | 20000 switching cycles | | |

| Circuit breaker type | Unit | TCB0160 | TCB0200 | TCB0250 | TCB0320 | TCB0400 |
|---|-----------------|------------------------|----------|----------|----------|----------|
| Part number | | 19170459 | 19148658 | 19170467 | 19170475 | 19170483 |
| Setting range | A | 10 – 16 | 16 – 20 | 20 – 25 | 25 – 32 | 32 – 40 |
| Connection cross section main contact | mm ² | 2.5 – 16 | 4 – 16 | | 6 – 16 | 10 – 16 |
| Tightening torque | Nm | 2.5 | | | | |
| Signal contact connection cross section | mm ² | 0.5 – 1.5 | | | | |
| Tightening torque | Nm | 0.8 | | | | |
| Mechanical service life | | 20000 switching cycles | | | | |

Technical data of signal contact

| Specifications of the signal contacts | Design |
|---------------------------------------|--|
| Connecting contacts | 0.5 – 1.5 mm ² |
| Tightening torque | 0.8 Nm |
| Switching capacity | DC 5 A / DC 24 V AC 10 A / AC 230 V |

Dimension sheet



17195255435

8.10.3 Line filter

Line filters are used to suppress interference emission on the line side of inverters.

UL and cUL approval

The listed line filters have an cRUus approval independent of the inverter.

Technical data


| Line filter | NF0420-513 | NF0420-523 |
|--|--------------------------------|------------|
| Part number | 17983789 | 17983797 |
| Nominal line voltage U_N | Maximum 3 × AC 500 V, 50/60 Hz | |
| Nominal current I_N | 42 A | |
| Nominal power loss | 30 W | 37 W |
| Ambient temperature ϑ_{amb} | 0 °C to 45 °C | |
| Connection contacts L1/L2/L3 – L1'/L2'/L3' | 2.5 – 16 mm ² | |
| Tightening torque L1/L2/L3 – L1'/L2'/L3' | 2 – 4 Nm | 2 - 2.3 Nm |
| PE connection contact | M6 | |
| Tightening torque PE | 6 Nm | |
| Degree of protection | IP20 according to EN 60529 | |
| Weight | 3 kg | 4.5 kg |

| Line filter | NF0910-523 | NF1800-523 |
|--|--------------------------------|--------------------------|
| Part number | 17987504 | 17987865 |
| Nominal line voltage U_N | Maximum 3 × AC 500 V, 50/60 Hz | |
| Nominal current I_N | 91 A | 180 A |
| Nominal power loss | 51.5 W | 89 W |
| Ambient temperature ϑ_{amb} | 0 °C to 45 °C | |
| Connection contacts L1/L2/L3 – L1'/L2'/L3' | 25 – 50 mm ² | 16 – 120 mm ² |
| Tightening torque L1/L2/L3 – L1'/L2'/L3' | 6 - 8 Nm | 12 - 20 Nm |
| PE connection contact | M8 | M10 |
| Tightening torque PE | 12 Nm | 23 Nm |
| Degree of protection | IP20 according to EN 60529 | |
| Weight | 5 kg | 9 kg |

Assignment to an inverter

| Line filter | NF0420-513 | NF0420-523 |
|-------------------------|------------|------------|
| Assignment to MDP90A-.. | 0100, 0250 | |
| Assignment to MDP90A-.. | 0500 | 0750, 1100 |
| Assignment to MDR91A-.. | 0500 | 0750 |

Dimension sheets and dimensions



9007218145873675

| Line filter | Main dimensions in mm | | | | Mounting dimensions in mm | | | |
|-------------|-----------------------|-----|-----|-----|---------------------------|-----|-----|-----|
| | A | B | C | E | a | b | d | PI |
| NF0420-513 | 250 | 88 | 97 | 255 | 235 | 60 | 5.5 | M6 |
| NF0420-523 | 330 | 83 | 187 | 340 | 314 | 55 | 6.5 | M6 |
| NF0910-523 | 270 | 100 | 152 | 320 | 255 | 65 | 6.5 | M8 |
| NF1800-523 | 380 | 132 | 185 | 465 | 365 | 102 | 6.5 | M10 |

8.10.4 Line choke

Using line chokes is optional:

- To support overvoltage protection.
- To smoothen the line current, to reduce harmonics.
- For protection in the event of distorted line voltage.
- For limiting the inrush current.

UL and cUL approval

The listed line chokes have cRUus approvals independent of the inverter.


Technical data

| Line choke | ND0300-503 | ND0420-503 | ND0910-503 | ND1800-503 |
|--|--|--------------------------|-------------------------|-----------------------------|
| Part number | 17983800 | 17983819 | 17987520 | 17987539 |
| Nominal line voltage V_N | Maximum 3 × AC 230 V - 500 V, 50/60 Hz | | | |
| Nominal current I_N | 30 A | 42 A | 91 A | 180 A |
| Nominal inductance | 0.1 mH | 0.045 mH | 0.035 mH | 0.018 mH |
| Nominal power loss | 11 W | 13 W | 53 W | 116 W |
| Ambient temperature ϑ_{amb} | -10 °C to 45 °C | | | |
| Terminal contacts L1/L2/L3 - L1'/L2'/L3' | 0.2 – 10 mm ² | 2.5 – 16 mm ² | 25 – 50 mm ² | 16 - 120 mm ² |
| Tightening torque L1/L2/L3 - L1'/L2'/L3' | 1.2 – 2 Nm | 2.5 Nm | 3 - 6 Nm | 12 - 20 Nm |
| PE terminal contact | M5 | | M8 | M10 |
| Tightening torque PE | 3 Nm | | 12 | 20 |
| Degree of protection | IPXXB according to EN 60529 | | | IPXXA according to EN 60529 |
| Weight | 1.95 kg | 1.82 kg | 4.4 kg | 10 kg |

Assignment to an inverter


| Line choke | ND0300-503 | ND0420-503 | ND0910-503 | ND1800-503 |
|-----------------------|------------|------------|------------|------------|
| Assignment to MDP90A- | 0100 | 0250 | 0500 | 0750, 1100 |

Dimension sheets and dimensions



18891130251

| Line choke | Main dimensions in mm | | | | Mounting dimensions in mm | | | |
|------------|-----------------------|----|-----|----|---------------------------|----|-----|----|
| | A | B | C | E | a | b | d | PE |
| ND0300-503 | 121 | 86 | 145 | 86 | 105 | 70 | 4.8 | M5 |
| ND0420-503 | 121 | 86 | 150 | 90 | 105 | 70 | 4.8 | M5 |



20917778571

| Line choke | Main dimensions in mm | | | | Mounting dimensions in mm | | | |
|------------|-----------------------|-----|-----|-----|---------------------------|----|-----|-----|
| | A | B | C | E | a | b | d | PE |
| ND0910-503 | 156 | 96 | 220 | 120 | 135 | 80 | 5.8 | M8 |
| ND1800-503 | 187 | 121 | 260 | 153 | 166 | 93 | 6.2 | M10 |

9 Functional safety

9.1 General information

9.1.1 Underlying standards

The safety assessment of the device is based on the following standards and safety classes:

| Underlying standards | |
|--------------------------------------|--|
| Safety class/ underlying standard | <ul style="list-style-type: none"> • Performance level (PL) in accordance with ISO 13849-1:2015 • Safety Integrity Level (SIL) in accordance with IEC 61800-5-2:2016 • Safety Integrity Level Claim Limit (SILCL) in accordance with IEC 62061 2015 |

9.2 Integrated safety technology

The described safety technology of the device has been developed and tested in accordance with the following safety requirements:

- SIL 3 in accordance with IEC 61800-5-2:2016, IEC 61508:2010.
- PL e in accordance with ISO 13849-1:2015.

This was certified by TÜV Rheinland. Copies of the TÜV certificate and the corresponding report are available from SEW-EURODRIVE on request.

9.2.1 Safe condition

For safety-related operation of the device, Safe Torque Off is defined as safe state (see STO drive safety function). The safety concept is based on this definition.


9.2.2 Safety concept

The device is supposed to be able to perform the drive safety function "Safe Torque Off" in accordance with IEC 61800-5-2:

- Device is characterized by the optional connection of an external safety controller/safety relay. This external safety controller/safety relay disconnects the safety-related STO input via a 2-pole 24 V switching signal (sourcing/sinking) when a connected command device (e.g. emergency stop button with latching function) is activated. This activates the STO function of the device. As an alternative to an external safety controller/safety relay, the STO function can also be implemented with the optional MOVISAFE® CS..A safety card.
- An internal, dual-channel structure with diagnostics prevents the generation of pulse trains at the power output stage (IGBT).
- Instead of a galvanic isolation of the drive from the supply system by means of contactors or switches, the disconnection of the STO input described here safely prevents the activation of the power semiconductors in the output stage. The rotary-field generation for the respective motor is deactivated even though the line voltage is still present.

- When the STO drive safety function is activated, the generated PWM signals from the device are interrupted by the STO circuit and not transmitted to the IGBTs.
- If the internal diagnostics of the STO circuit detects a discrepancy between the two channels, the PWM signals are locked, i.e. the STO is activated. This locking requires a reset by switching the DC 24 V supply voltage of the device or the DC 24 V switching signal at the STO inputs F_STO_P1 and F_STO_P2 off and on.

9.2.3 Schematic representation of the safety concept



23543720971

- [1] STO function
- [2] Drive controller
- [3] Internal safety card/safety option (optional)
- [4] Diagnostics and inhibiting unit
- [5] External safety device (optional)
- [6] Motor

9.2.4 Drive safety functions


The following drive-related safety functions can be used:

- **STO** (Safe Torque Off in accordance with IEC 61800-5-2) by disconnecting the STO input.


If the STO function is activated, the frequency inverter no longer supplies power to the motor for generating torque. This drive safety function corresponds to a non-controlled stop according to EN 60204-1, stop category 0.

The STO input must be disabled by a suitable external safety controller/safety relay.

The following figure shows the STO function:



2463228171

| | |
|---|-------------------------------------|
| v | Speed |
| t | Time |
| t_1 | Point of time when STO is triggered |
|  | Disconnection range |


- **SS1(c) (SS1-t)** (safe stop 1, function variant c in accordance with IEC 61800-5-2) by means of suitable external control (e.g. safety relay with delayed disconnection).

The following sequence is mandatory:



- Decelerate the drive using an appropriate brake ramp specified via setpoints.
- Disconnect the STO input (= triggering the STO function) after a specified safety-related time delay.

This drive safety function corresponds to a controlled stop in accordance with EN 60204-1, stop category 1.

The following figure illustrates the SS1(c) (SS1-t) function:



2463226251

| | |
|---|--|
| v | Speed |
| t | Time |
| t_1 | Point of time when brake ramp is initiated |
| t_2 | Point of time when STO is triggered |
| Δt | Delay time until STO is triggered |
|  | Safe time delay range |
|  | Disconnection range |

9.2.5 Restrictions

- Note that if the drive does not have a mechanical brake or if the brake is defective, the drive may coast to a halt (depending on the friction and mass moment of inertia of the system). In the event of regenerative loads or with axes that are loaded with gravitational forces or driven externally, the drive can even accelerate. This must be taken into account in a risk assessment of the system/machine. Additional safety measures might have to be implemented (e.g. safety brake system).

In the case of application-related drive safety functions that require bringing the hazardous motion safely to a standstill, an additional safety brake system may be necessary on an application-specific basis.

- When using the function SS1(c) (SS1-t) as described in the chapter "Drive safety functions", the brake ramp of the drive is not monitored with respect to safety. In the event of a fault, deceleration may fail during the delay time or, in the worst-case scenario, there might be an acceleration. In this case, the STO function (see the chapter "Safety functions") is only activated after the set time delay elapsed. The resulting danger must be taken into account in the risk assessment of the system/machine. Additional safety measures might have to be implemented.
- The STO function cannot prevent a possible jerk or DC braking.



⚠ WARNING

The safety concept is suitable only for performing mechanical work on driven system/machine components.

When the STO signal is disconnected, the voltage is still present at the DC link of the device.

- Before working on the electric part of the drive system, disconnect it from the supply voltage using an appropriate external disconnecting device and secure it against unintentional reconnection.



⚠ WARNING

Electric shock due to incompletely discharged capacitors.

Severe or fatal injuries.

- Observe a minimum switch-off time of 10 minutes after disconnecting the power supply.



INFORMATION

In the event of a safety-related disconnection of the DC 24 V supply voltage at the STO connection, the brake controller is switched off. The brake control in the device is not safety-related.

9.3 Safety conditions

The requirement for safe operation is that the drive safety functions of the application inverter are properly integrated into an application-specific, higher-level drive safety function. A system/machine-specific risk assessment must be carried out without fail by the system/machine manufacturer and taken into account for the use of the drive system with the device.

The system/machine manufacturer and the user are responsible for the compliance of the system/machine with the applicable safety regulations.

The following requirements are mandatory when installing and operating the device in safety-related applications:

- Use of the approved devices
- Installation requirements
- Requirements for external safety controllers and safety relays
- Startup requirements
- Operational requirements

9.3.1 Approved devices

The following device versions of MOVIDRIVE® modular are permitted for safety-related applications:

| Device | Size |
|---|-----------|
| MOVIDRIVE® modular (single-axis and double-axis modules) | All sizes |

9.3.2 Requirements for the installation

- The components must be protected against conductive dirt, e.g. by installing them in a control cabinet with degree of protection IP54 in accordance with IEC 60529.

Assuming that the presence of conductive dirt can be excluded at the installation site, a control cabinet with a correspondingly lower degree of protection is also permitted if in accordance with the applicable standards (e.g. EN 60204-1).

- The wiring technology used must comply with the standard EN 60204-1.
- The STO control cables must be routed according to EMC guidelines and as follows:
 - Inside an electrical installation space: Single conductors can be routed.
 - Outside a closed installation space: Shielded cables must be routed permanently (fixed) and protected against external damage, or equivalent measures must be taken.
 - Adhere to the regulations in force for the application.
 - The sinking and sourcing cables from the external safety controller/safety relay to the device must be routed right next to each other with a cable length of ≤ 100 m.
 - The sinking and sourcing cables from the external safety device to the device must have the same cable length. A difference in length $\leq 3\%$ of the two cables is permitted.
 - You must use suitable measures to ensure that STO control cables are routed separately from the power lines of the drive. This does not apply to cables approved by SEW-EURODRIVE specifically for this application case.
- The STO function does not detect short circuits or interference voltage in the supply line, so you must ensure the following:
 - No parasitic voltages can occur in the STO control cables
 - The external safety controller can detect a cross fault from an external potential to the STO control lines
- Observe without fail the values specified for safety components when designing the safety circuits.

- The STO signal (F_STO_P1, F_STO_P2, and F_STO_M) must not be used for feedback.
- For safety controller/safety relays, you must only use grounded voltage sources with protective electrical separation (PELV) in accordance with EN 61131-2 and EN 60204-1.
- If several voltage sources are used, each voltage source must be connected to a PE system.
- When planning the installation, observe the technical data of the devices.
- Do not use the port X6:5 (24 V_Out) of the device for safety-related applications. The voltage is only permitted to supply the port for the safe disconnection X6 when a jumper plug is plugged.
- For safety-related applications with the device, the jumper plug at the STO input X6 must be removed.

9.3.3 Requirements for external safety controllers

A safety relay can be used as an alternative to a safety controller. The following requirements apply analogously.

- The safety controller and all other safety-related subsystems must be approved for at least that safety class which is required in the overall system for the respective, application-related drive safety function.

The following table shows an example of the required safety class of the safety controller:

| Application | Safety controller requirements |
|---|--|
| Performance level d in accordance with ISO 13849-1, SIL 2 in accordance with EN 62061 | Performance level d in accordance with ISO 13849-1 SIL 2 in accordance with IEC 61508 |
| Performance level e in accordance with ISO 13849-1, SIL 3 in accordance with EN 62061 | Performance level e in accordance with ISO 13849-1, SIL 3 in accordance with EN 61508 |

- The wiring of the safety controller must be suitable for the required safety class (see manufacturer documentation). The STO input of the device can be switched with 2 poles (sourcing or sourcing/sinking) or with 1 pole (sourcing).
- The values specified for the safety controller must be strictly adhered to when designing the circuit.
- No electro-sensitive protective equipment (such as a light grid or scanner) in accordance with EN 61496-1 or emergency stop buttons may be connected directly to the STO input. The connection must be made via a safety controller or a safety relay.
- To ensure protection against an unintended startup in accordance with EN ISO 14118, the safe control system must be designed and connected in such a way that resetting the command device alone does not lead to a restart. This means that a restart may be carried out only after a manual reset of the safety circuit.
- If no fault exclusion is used for the STO wiring in accordance with ISO 13849-2 or IEC 61800-5-2, the external safety device must detect the following faults in the STO wiring within 20 s depending on the connection type:
 - 2-pole sourcing output:
Short circuit of 24 V at F_STO_P1 or F_STO_P2 (Stuck-at 1)

Crossfault between F_STO_P1 and F_STO_P2

- 2-pole sourcing/sinking:

Short circuit of 24 V at F_STO_P1 (Stuck-at 1)

Short circuit of 0 V at F_STO_M (Stuck-at 0)

- 1-pole sourcing output:

In the case of a single-pole connection, a fault exclusion is necessary for the wiring between the safety relay and the STO input.

2-pole sourcing output:

- Test pulses can be present when the device is switched on or off:
 - The test pulses on both sourcing channels must be switched with a time delay. However, additional test pulses may occur simultaneously.
 - The test pulses in both sourcing channels must not exceed 1 ms.
 - The next test pulse in one sourcing channel must occur only after a 2 ms time period.
 - A maximum package of 3 switch-on test pulses may be generated in sequence at an interval of 2 ms. Wait for at least 500 ms after any package before you generate another switch-on test pulse or another switch-on test pulse package.
 - The test pulses must be monitored in the safety device. If a fault is detected, the safety device must initiate a suitable fault response.

2-pole sourcing/sinking:

- Test pulses can be present when the device is switched on or off:
 - The test pulses in the sourcing and sinking channel must not exceed 1 ms.
 - The next test pulse in the sourcing or sinking channel must only occur after a 2 ms time period at the earliest.
 - A maximum package of 3 switch-on test pulses may be generated in sequence at an interval of 2 ms. Wait for at least 500 ms after any package before you generate another switch-on test pulse or another switch-on test pulse package.
 - The test pulses must be monitored in the safety device. If a fault is detected, the safety device must initiate a suitable fault response.

1-pole sourcing output:

- In switched-off state, no switch-on test pulses must occur in the sourcing cable.
- In switched-on state:
 - The switch-off test pulse in the sourcing channel must not exceed 1 ms.
 - The next switch-off test pulse may only occur after a time period of 2 ms at the earliest.
 - A maximum package of 3 switch-on test pulses may be generated in sequence at an interval of 2 ms. Wait for at least 500 ms after any package before you generate another switch-on test pulse or another switch-on test pulse package.
 - The test pulses must be monitored in the safety device. If a fault is detected, the safety device must initiate a suitable fault response.


9.3.4 Requirements for startup

- To validate the implemented drive safety functions, they must be checked and documented after successful startup (functional test).

- Observe the restrictions for drive safety functions in the chapter "Restrictions". Non-safety-related parts and components that affect the result of the functional test (e.g. motor brake) must be deactivated, if necessary.
- For using the device in safety-relevant applications, it is essential that you perform and document startup checks for the disconnecting device and the correct electrical connection.

9.3.5 Requirements for operation

- Operation is permitted only within the limits specified in the corresponding documentation. This principle applies to the external safety controller as well as to the device and any approved options.
- The built-in diagnostic function is limited in the case of a permanently enabled or permanently disabled STO input. Advanced diagnostic functions are performed only upon a level change of the STO signal. This is why the STO input of the device must be requested with connected line voltage at least once every 12 months for PL d in accordance with ISO 13849-1 and SIL 2 IEC 61800-5-2 and at least once every 3 months for PL e in accordance with ISO 13849-1 and SIL 3 IEC 61800-5-2 to achieve complete test coverage. Adhere to the following test procedure.



- [1] Maximum 12 months with PL d/SIL 2
Maximum 3 months with PL e/SIL 3
- [2] Internal diagnostics
- [3] High: No STO
- [4] Low: STO active

- To achieve complete test coverage after a device reset (e.g. after connecting the line voltage), the state transition (STO active → not active) can be started only > 700 ms later. The device signals "ready for operation" or "STO – Safe Torque Off" if it is not in fault state.
- A detected hardware fault in the internal switch-off channels for STO will lead to a locking fault state in the device. If the fault is reset (e.g. by switching the line voltage on/off or by a low level at the STO input for at least 30 ms), a complete test with internal diagnostics according to the abovementioned test procedure must be performed. If the fault occurs again, replace the device or contact SEW-EURODRIVE Service.

9.4 Connection designs

9.4.1 General information

Generally, all the connection designs listed in this documentation are permitted for safety-relevant applications, insofar as the safety conditions arising from this documentation are satisfied. This means that you must ensure without fail that the DC 24 V safety inputs are activated by a safety controller or an external safety relay, so that an independent restart is not possible.

All the safety conditions stipulated in the chapters "Integrated safety technology", "Safety conditions", and "Connection variants" must be satisfied on a primary basis for the basic selection, installation, and application of the safety components, such as safety relay, emergency stop switch, and the approved connection variants.

The wiring diagrams are block diagrams whose only purpose is to show the drive safety function(s) with the relevant components. For reasons of clarity, circuit-related measures that usually always have to be implemented are not shown in the diagram. These measures are e.g.:

- Ensuring the availability of touch guards.
- Handling overvoltages and undervoltages.
- Avoiding installation errors.
- Detecting ground faults or short circuits in externally installed lines.
- Guaranteeing the required interference immunity against electromagnetic interference.

9.4.2 Requirements

Use of safety relays


The requirements of the manufacturers of safety relays (such as protecting the output contacts against welding) or of other safety components must be strictly observed. The basic requirements for cable routing apply as described in this documentation.

For connecting the device to the safety relays, observe the installation requirements in accordance with the chapter "Installation requirements".

All instructions by the manufacturer of the safety relay used in the particular application must be observed.

Use of safety controllers

The switch-off test pulse of the used safe digital outputs (F-DO) must be ≤ 1 ms and another switch-off test pulse must only occur 2 ms later at the earliest.



15214338827

[1] High
[2] Low

INFORMATION



If the safety-related control voltage at X6 is switched off (STO activated), you must observe the chapter "Requirements for the external safety controller" with regard to the test pulses.

INFORMATION



If F_STO_P1, F_STO_P2 are connected to DC 24 V, and F_STO_M is connected to GND, STO is deactivated.

STO signal for group disconnection


For group drives, the STO signal may be provided for several devices by a single safety relay. The following requirements must be met:

- The total cable length is limited to max. 100 m. Any other instructions published by the manufacturer on the use of the safety device (for the respective application) must also be observed.
- The maximum output current and the maximally permitted contact load of the safety device must be observed (see the chapter "Technical data" > "Electronic data – Drive safety functions").
- You must comply with the permitted signal levels at the STO input and all other technical data of the device. The respective routing of the STO control cables and the voltage drop must be considered.
- Other requirements of the safety device manufacturer (such as protecting the output contacts against welding) must be strictly observed. The basic requirements for cable routing also apply.
- A calculation based on the technical data of the device must be performed separately for each case of group drive disconnection.
- A maximum of 20 devices may be used in a group disconnection.

9.4.3 Wiring diagrams

Delivery state


In the delivery state, the terminals at the port for safe disconnection X6 are jumpered.



27743538443

[1] STO terminal X6


2-pole sourcing



27743543947

[1] External safety device
[2] STO terminal X6


2-pole sourcing/sinking



27743625995

[1] External safety device
[2] STO terminal X6


1-pole sourcing




27743633163

[1] External safety device
[2] STO terminal X6


STO group disconnection, 2-pole, sourcing



STO group disconnection, 2-pole, sourcing/sinking




STO group disconnection, 1-pole, sourcing



9.4.4 Port X6 on the device

The following figures show the STO connection X6 at the top of the axis modules.


Single-axis module



14950796555

[1] X6: Connection for Safe Torque Off (STO)

Double-axis module



9007214205669003

[1] X6_1: Connection for safe torque off (STO) on axis 1

[2] X6_2: Connection for safe torque off (STO) on axis 2

9.5 Safety characteristics

| | Characteristic values in accordance with | |
|---|--|----------------------------------|
| | IEC 61800-5-2 | ISO 13849-1 |
| Tested safety class/underlying standards | Safety integrity level 3 | Performance level e / category 3 |
| Probability of a dangerous failure per hour (PFH value) | $2.5 \times 10^{-9} \text{ h}^{-1}$ | |

25953079/EN – 01/2020

| | Characteristic values in accordance with | |
|-----------------------|--|-------------|
| | IEC 61800-5-2 | ISO 13849-1 |
| Service life | 20 years, after which the component must be replaced with a new one. | |
| Proof test interval | > 20 years | – |
| Safe state | Safe Torque Off (STO) | |
| Drive safety function | STO, SS1 ¹⁾ in accordance with IEC 61800-5-2 | |

1) With suitable external control

INFORMATION



In the case of 1-pole wiring, the achievable performance level in accordance with ISO 13849-1 is reduced to PL d, and the achievable Safety Integrity Level in accordance with IEC 61800-5-2 is reduced to SIL 2. A fault exclusion is necessary for the wiring between the safety relay and the STO input.

10 Appendix

10.1 Abbreviation key

The following table lists the abbreviations that are used in this document together with their unit and meaning.

| Abbreviation | Information on the nameplate | Unit | Meaning |
|--------------------|------------------------------|---------------|--|
| ASM | | | Asynchronous motor |
| C | C | μF | Capacitance |
| f_{max} | f | Hz | Maximum output frequency |
| f_{line} | f | Hz | Line frequency |
| f_{PWM} | | kHz | Frequency of the pulse width modulation |
| h | | m | Installation altitude |
| I_{trip} | | A | Tripping current (braking resistor) |
| I_{max} | I_{max} | A | Max. DC link current (specification on the nameplate) |
| I_{max} | | A | Maximum output current (encoder cards) |
| I_{peak} | | A | Output peak current (encoder cards) |
| $I_{\text{A max}}$ | | A | Max. output current |
| I_{Appl} | | A | Total current of the application |
| I_{N} | | A | Nominal output current/nominal current (filter, choke) |
| I_{line} | I | A | Nominal line current |
| I_{NDCL} | I | A | Nominal DC link current |
| L_{N} | | mH | Inductance |
| LSPM | | | Line Start Permanent Magnet |
| P_{eff} | | kW | Effective power (braking resistor) |
| P_{max} | | kW | Maximum power (braking resistor) |
| P_{Mot} | P(ASM) | kW | Motor power of the asynchronous motor |
| P_{N} | | kW | Nominal motor power (rated power) |
| P_{V} | | W | Power loss |
| PWM | | | Pulse width modulation |
| R_{BW} | | Ω | Value of the braking resistance |
| R_{BWmin} | | Ω | Minimum value of the braking resistance |
| S_{N} | S | kVA | Apparent output power |
| SM | | | Synchronous motor |
| U_{A} | U | V | Motor output voltage |
| U_{BR} | | V | Brake supply voltage |
| U_{N} | | V | Nominal line voltage (filter, choke) |
| U_{line} | U | V | Connection voltage |
| U_{NDCL} | U | V | Nominal DC link voltage |

| Abbreviation | Information on the nameplate | Unit | Meaning |
|-------------------|------------------------------|------|--|
| U_{out} | | V | DC 24 V to supply STO_P1 and STO_P2 |
| U_S | | V | Supply voltage of encoders |
| U_{S12VG} | | V | DC 12 V supply voltage of encoders |
| U_{S24VG} | | V | DC 24 V supply voltage of encoders |
| U_{I24} | | V | Voltage supply for electronics and brake |
| ϑ_{amb} | T | °C | Ambient temperature |
| (+ES) | | | ... with output stage inhibit |

Index

Symbols

+24 V supply voltage 89

Numerical

7-segment display 191

A

Abbreviation key 310

Accessories 53

Arrangement of the axis modules within the axis system 71

Assembling an axis system 71

Assembly

Safety notes 16

Assigning the EtherCAT®/SBusPLUS address.. 184

Axis module fault 199

B

Bimetallic relay 138

Brake chopper 110

Brake control 166

Brake output 110

Braking resistors 129, 283

External bimetallic relay 138

External thermal circuit breaker TCB 132

Internal temperature switch -T..... 134

Permitted installation 130

Protection of the braking resistor against thermal overload..... 132

C

Cabling of the axis system 113

Card installation..... 118

Card slots 51

CES11A multi-encoder card 124

Encoder connection/cable lengths 115, 124

Supported encoder types 124

Terminal assignment CANopen encoder 127

Terminal assignment EnDat encoder 126

Terminal assignment HIPERFACE® and SEW encoder (RS485) 125

Terminal assignment of TTL, HTL, sin/cos encoder 125

Terminal assignment SSI + sin/cos combination encoders..... 127

Terminal assignment SSI encoder 126

Checking the disconnection device 302

CIO21A, CID21A input/output card 121

Closing covers and touch guards 108

Connecting power 183

Connecting the cables..... 183

Connection diagram of digital inputs and outputs 176

Connection of an axis system 49, 92

Connection of an axis system with master module 50

Connection to the engineering software 189

Connection variants..... 304

Cooling

Derating 16

Installation altitude..... 16

Copyright notice 12

Covers 62

D

DC link busbar 92

DC link connection 92

Decimal separator 11

Derating 16

Designated use 14

Device structure 19

Card slots 51

Connection of an axis system 49

Connection of an axis system with master module..... 50

MDA and MDD axis modules 37

MDA single-axis modules..... 38

MDC capacitor module..... 47

MDD Double-axis modules..... 44

MDP power supply modules..... 32

UHX45A/MDM90A capacitor module 48

Dimension sheets

BW1.4-170 braking resistor..... 289

Dimension sheets of the modules 261

Disconnection of a single device

Requirements 304

Drilling template..... 59

E

Electrical accessories 54

| | | | |
|---|--------|--|-----|
| Electrical installation | 17, 82 | Fault display at the double-axis module | 191 |
| +24 V supply voltage | 89 | Fault module bus | 238 |
| Brake chopper | 110 | Fault responses | 241 |
| Brake output | 110 | Default fault response | 241 |
| Cabling of the axis system | 113 | Parameterizable faults | 241 |
| Connection of an axis system | 92 | Faults at the power supply module | 195 |
| Encoder | 114 | Front cover | 68 |
| Encoder connection | 114 | FS standards | 296 |
| Fuse types, line fuses | 85 | FS validity | 296 |
| General information | 84 | Functional safety | |
| Inputs/outputs | 111 | Approved devices | 300 |
| Installation notes encoder connection | 114 | Functional safety technology | |
| Line connection | 86 | Safety note | 16 |
| Line fuses, fuse types | 85 | Fuse types, line fuses | 85 |
| Minimum requirements for encoder cables .. | 117 | | |
| Motor output | 110 | G | |
| Permitted voltage systems | 84 | General technical data | 250 |
| Safety notes | 17 | H | |
| Self-assembled encoder cables | 117 | Hazard symbols | |
| System bus EtherCAT®/SBusPLUS | 112 | Meaning | 11 |
| Temperature evaluation of the motor | 110 | I | |
| Touch guards and closing covers | 108 | Identifying drive safety functions | 302 |
| Use in IT systems | 84 | Inputs/outputs | 111 |
| Electronics connection of the double-axis modules | 174 | Installation | 53 |
| Electronics connection of the power supply module | 171 | Arrangement of the axis modules within the axis system | 71 |
| Electronics connection of the single-axis modules | 172 | Braking resistors | 129 |
| Electronics Service | 244 | Connection diagram for input/output cards .. | 176 |
| Embedded safety notes | 11 | Covers | 62 |
| EMC-compliant installation | 143 | Digital inputs and outputs | 176 |
| Encoder | 114 | Drilling template | 59 |
| Encoder cable | 117 | Electrical installation | 82 |
| Encoder cable requirements | 117 | EMC-compliant installation | 143 |
| Encoder connection | | Front cover | 68 |
| Installation notes | 114 | Installation accessories | 53 |
| Prefabricated cables | 114 | Installing a module | 72 |
| EtherCAT® | | Installing front covers and covers | 80 |
| Beckhoff trademark | 12 | Installing the bottom shield plate | 73 |
| Extended storage | 244 | Installing the busbar | 77 |
| External safety controllers | 301 | Installing the top shield plate | 74 |
| F | | Installing touch guards | 78 |
| Fault at master module | 237 | Line choke | 142 |
| Fault display | 191 | Line filter | 142 |
| | | Mechanical installation | 59 |

| | | | |
|--|---------|---|-----|
| Minimum clearance and mounting position | 61 | MDA single-axis modules | |
| Permitted installation of braking resistors..... | 130 | Performance data..... | 253 |
| Permitted tightening torques | 57 | MDD Double-axis modules | |
| Protecting the braking resistor..... | 132 | Performance data..... | 255 |
| Removing an axis module | 80 | MDP power supply modules | |
| Removing the safety covers | 75 | Dimension sheets..... | 261 |
| Removing the touch guards | 76 | Performance data..... | 251 |
| Requirements | 300 | Signal terminals – electronics data..... | 252 |
| Structure of an axis system | 71 | Mechanical accessories | 53 |
| Terminal assignment..... | 148 | Mechanical installation | 59 |
| Touch guards | 64, 65 | Minimum clearance and mounting position | 61 |
| Wiring diagrams | 161 | Minimum requirements for encoder cables | 117 |
| Installation accessories | 53 | Module bus | |
| Installation notes | | Grid condition | 238 |
| Derating..... | 16 | Line phase failure | 238 |
| Installation altitude > 1000 m | 16 | Motor output | 110 |
| Installing a card | 118 | Mounting position and minimum clearance | 61 |
| Installing a module | 72 | N | |
| Installing front covers and covers | 80 | Nameplates | 28 |
| Installing options and accessories | | Double-axis module..... | 30 |
| CES11A multi-encoder card | 124 | Performance data..... | 28 |
| CID21A terminal assignment..... | 123 | Power supply module | 28 |
| CIO21A terminal assignment | 122 | Single-axis module | 29 |
| CIO21A, CID21A input/output card | 121 | System nameplate..... | 28 |
| Installing a card | 118 | Notes | |
| Installing the bottom shield plate | 73 | Designation in the documentation | 10 |
| Installing the busbar | 77 | Meaning of the hazard symbols | 11 |
| Installing the top shield plate | 74 | O | |
| Installing touch guards | 78 | Operating displays..... | 191 |
| IT systems | 84 | Operating displays at the axis module | 192 |
| L | | Operating displays at the power supply module | 192 |
| Lifting applications..... | 15, 183 | Operation..... | 190 |
| Line choke | 294 | 7-segment display | 191 |
| Line connection | 86 | Axis module fault..... | 199 |
| Line filter | 292 | Fault at master module..... | 237 |
| Line fuses, fuse types..... | 85 | Fault display | 191 |
| M | | Fault module bus..... | 238 |
| Maintenance neglected | 245 | Fault responses..... | 241 |
| Marks..... | 247 | Faults at the power supply module..... | 195 |
| MDA and MDD axis modules | | Fieldbus timeout | 240 |
| Dimension sheets..... | 267 | Operating displays..... | 191 |
| Drive safety functions – Electronics data | 257 | Operating displays at the axis module | 192 |
| Signal terminals – electronics data..... | 256 | Operating displays at the power supply module | 192 |

| | |
|--|-----|
| Responses to fault acknowledgement..... | 239 |
| Safety notes | 18 |
| Software reset | 239 |
| Software restart | 239 |
| Warm start..... | 240 |
| Operation, requirements..... | 303 |
| Option cards, possible combinations..... | 51 |

P

| | |
|------------------------------------|----|
| Permitted tightening torques | 57 |
| Permitted voltage systems | 84 |
| Product names | 12 |
| Protective separation..... | 17 |

R

| | |
|--|-----|
| Removing an axis module | 80 |
| Removing the axis module | 80 |
| Removing the safety covers | 75 |
| Removing the touch guards | 76 |
| Repair..... | 244 |
| Requirements | |
| External safety controllers | 301 |
| Installation | 300 |
| Operation..... | 303 |
| Startup..... | 302 |
| Responses to fault acknowledgement..... | 239 |
| At the axis module..... | 239 |
| At the power supply module | 239 |
| Fieldbus timeout | 240 |
| Software reset | 239 |
| Software restart | 239 |
| Warm start..... | 240 |
| Restrictions to application | 16 |
| Rights to claim under limited warranty | 12 |

S

| | |
|---------------------------------------|-----|
| Safe state | 296 |
| Safe Torque Off (STO) | 297 |
| Safety concept..... | 296 |
| Restrictions..... | 299 |
| Safety controllers, external..... | 301 |
| Requirements | 301 |
| Safety controllers, requirements..... | 305 |
| Safety functions..... | 16 |
| Safety notes | |
| Assembly | 16 |

| | |
|--|--------|
| Designation in the documentation | 10 |
| Installation | 16 |
| Installation altitude > 1000 m | 16 |
| Meaning of the hazard symbols | 11 |
| Preliminary information..... | 13 |
| Regenerative operation | 17 |
| Structure of embedded..... | 11 |
| Structure of section-related | 11 |
| Transport..... | 16 |
| Safety relays, requirements..... | 304 |
| Safety technology | |
| Safe state | 296 |
| Safety-related conditions..... | 299 |
| Section-related safety notes | 11 |
| Self-assembled encoder cables | 117 |
| Separation, protective | 17 |
| Service | 244 |
| Extended storage | 244 |
| Maintenance neglected | 245 |
| Shutdown | 245 |
| Shutdown | 245 |
| Signal words in safety notes..... | 10 |
| Special aspects when transporting the devices .. | 58 |
| Standard accessories | 53 |
| Electrical accessories..... | 54 |
| Mechanical accessories | 53 |
| Startup..... | 183 |
| Assigning the EtherCAT®/SBusPLUS address | 184 |
| Checklist..... | 189 |
| Connecting power | 183 |
| Connecting the cables..... | 183 |
| Connection to the engineering software..... | 189 |
| Lifting applications..... | 183 |
| Safety notes | 18 |
| Startup procedure..... | 186 |
| Startup, requirements..... | 302 |
| STO (Safe Torque Off) | 297 |
| Structure of an axis system | 19, 71 |
| System bus EtherCAT®/SBusPLUS | 112 |

T

| | |
|----------------------------------|-----|
| Target group..... | 14 |
| TCB thermal circuit breaker..... | 132 |
| Technical data | 247 |
| Braking resistors..... | 283 |

| | | | |
|--|----------|---|----------|
| Cards..... | 277 | MDD double-axis module | 155 |
| CES11A multi-encoder card | 279 | MDP power supply modules..... | 149 |
| Chokes | 283 | Tightening torques..... | 57 |
| CIO21A and CID21A input/output cards | 277 | Touch guards | 64, 65 |
| Dimension sheets of the modules | 261 | Touch guards and closing covers..... | 108 |
| Electronics data drive safety functions | 257 | Trademarks | 12 |
| Electronics data of axis modules | 256 | Transport | 16 |
| Electronics data of MDP power supply modules | 252 | Transporting the devices | 58 |
| Encoder interfaces | 282 | Two-row design | 98 |
| Filters..... | 283 | Type code..... | 31 |
| General technical data | 250, 280 | U | |
| Line choke | 294 | Use in IT systems | 84 |
| Line filter..... | 292 | Use of option cards | |
| Marks..... | 247 | Double-axis modules..... | 52 |
| MDA and MDD axis modules | 253 | Single-axis modules | 51 |
| MDC capacitor module..... | 259 | V | |
| MDP supply modules | 251 | Validation..... | 302 |
| Performance data MDA single-axis modules | 253 | W | |
| Performance data MDD double-axis modules | 255 | Waste disposal | 246 |
| Performance data MDP power supply modules | 251 | Wiring diagrams | |
| Safe digital inputs | 280 | Axis module - Wiring the control electronics | 172, 174 |
| Safe digital outputs..... | 281 | Brake control | 166 |
| Sensor supply..... | 281 | Connection diagram of digital inputs | 176 |
| TCB thermal circuit breaker..... | 290 | Electronics connection of the double-axis modules..... | 174 |
| UHX45A/MDM master module | 260 | Electronics connection of the power supply module..... | 171 |
| Technical data of encoder interfaces | 282 | Electronics connection of the single-axis modules..... | 172 |
| Temperature evaluation of the motor | 110 | General information | 161 |
| Temperature switch -T | 134 | Power connection..... | 161 |
| Terminal assignment..... | 148 | Power supply module - Wiring the control electronics..... | 171 |
| CID21A..... | 123 | | |
| CIO21A..... | 122 | | |
| MDA axis module | 151 | | |
| MDA single-axis modules..... | 151 | | |

11 Address list

Argentina

| | | | |
|-------------------|--------------|---|--|
| Assembly Sales | Buenos Aires | SEW EURODRIVE ARGENTINA S.A. Ruta Panamericana Km 37.5, Lote 35 (B1619IEA) Centro Industrial Garín Prov. de Buenos Aires | Tel. +54 3327 4572-84 Fax +54 3327 4572-21 http://www.sew-eurodrive.com.ar sewar@sew-eurodrive.com.ar |
|-------------------|--------------|---|--|

Australia

| | | | |
|------------------------------|-----------|---|--|
| Assembly Sales Service | Melbourne | SEW-EURODRIVE PTY. LTD. 27 Beverage Drive Tullamarine, Victoria 3043 | Tel. +61 3 9933-1000 Fax +61 3 9933-1003 http://www.sew-eurodrive.com.au enquires@sew-eurodrive.com.au |
| | Sydney | SEW-EURODRIVE PTY. LTD. 9, Sleigh Place, Wetherill Park New South Wales, 2164 | Tel. +61 2 9725-9900 Fax +61 2 9725-9905 enquires@sew-eurodrive.com.au |

Austria

| | | | |
|------------------------------|--------|--|---|
| Assembly Sales Service | Vienna | SEW-EURODRIVE Ges.m.b.H. Richard-Strauss-Straße 24 1230 Wien | Tel. +43 1 617 55 00-0 Fax +43 1 617 55 00-30 http://www.sew-eurodrive.at sew@sew-eurodrive.at |
|------------------------------|--------|--|---|

Bangladesh

| | | | |
|-------|------------|---|---|
| Sales | Bangladesh | SEW-EURODRIVE INDIA PRIVATE LIMITED 345 DIT Road East Rampura Dhaka-1219, Bangladesh | Tel. +88 01729 097309 salesdhaka@seweurodrivebangladesh.com |
|-------|------------|---|---|

Belarus

| | | | |
|-------|-------|--|--|
| Sales | Minsk | Foreign unitary production enterprise SEW- EURODRIVE Rybalko Str. 26 220033 Minsk | Tel. +375 17 298 47 56 / 298 47 58 Fax +375 17 298 47 54 http://www.sew.by sales@sew.by |
|-------|-------|--|--|

Belgium

| | | | |
|------------------------------|---------------------|---|--|
| Assembly Sales Service | Brussels | SEW-EURODRIVE n.v./s.a. Researchpark Haasrode 1060 Evenementenlaan 7 3001 Leuven | Tel. +32 16 386-311 Fax +32 16 386-336 http://www.sew-eurodrive.be info@sew-eurodrive.be |
| Service Competence Center | Industrial Gears | SEW-EURODRIVE n.v./s.a. Rue du Parc Industriel, 31 6900 Marche-en-Famenne | Tel. +32 84 219-878 Fax +32 84 219-879 http://www.sew-eurodrive.be info@sew.be |

Brazil

| | | | |
|--------------------------------|-----------|---|---|
| Production Sales Service | São Paulo | SEW-EURODRIVE Brasil Ltda. Estrada Municipal José Rubim, 205 – Rodovia Santos Dumont Km 49 Indaiatuba – 13347-510 – SP | Tel. +55 19 3835-8000 sew@sew.com.br |
| Assembly Sales Service | Rio Claro | SEW-EURODRIVE Brasil Ltda. Rodovia Washington Luiz, Km 172 Condomínio Industrial Conpark Caixa Postal: 327 13501-600 – Rio Claro / SP | Tel. +55 19 3522-3100 Fax +55 19 3524-6653 montadora.rc@sew.com.br |
| | Joinville | SEW-EURODRIVE Brasil Ltda. Jvl / Ind Rua Dona Francisca, 12.346 – Pirabeiraba 89239-270 – Joinville / SC | Tel. +55 47 3027-6886 Fax +55 47 3027-6888 filial.sc@sew.com.br |

Bulgaria

| | | | |
|-------|-------|---|---|
| Sales | Sofia | BEVER-DRIVE GmbH Bogdanovetz Str.1 1606 Sofia | Tel. +359 2 9151160 Fax +359 2 9151166 bever@bever.bg |
|-------|-------|---|---|

Cameroon

| | | | |
|-------|--------|--|---|
| Sales | Douala | SEW-EURODRIVE S.A.R.L. Ancienne Route Bonabéri P.O. Box B.P 8674 Douala-Cameroun | Tel. +237 233 39 02 10 Fax +237 233 39 02 10 sew@sew-eurodrive-cm |
|-------|--------|--|---|

Canada

| | | | |
|------------------------------|-----------|--|---|
| Assembly Sales Service | Toronto | SEW-EURODRIVE CO. OF CANADA LTD. 210 Walker Drive Bramalea, ON L6T 3W1 | Tel. +1 905 791-1553 Fax +1 905 791-2999 http://www.sew-eurodrive.ca l.watson@sew-eurodrive.ca |
| | Vancouver | SEW-EURODRIVE CO. OF CANADA LTD. Tilbury Industrial Park 7188 Honeyman Street Delta, BC V4G 1G1 | Tel. +1 604 946-5535 Fax +1 604 946-2513 b.wake@sew-eurodrive.ca |
| | Montreal | SEW-EURODRIVE CO. OF CANADA LTD. 2001 Ch. de l'Aviation Dorval Quebec H9P 2X6 | Tel. +1 514 367-1124 Fax +1 514 367-3677 n.paradis@sew-eurodrive.ca |

Chile

| | | | |
|------------------------------|-------------------|---|---|
| Assembly Sales Service | Santiago de Chile | SEW-EURODRIVE CHILE LTDA Las Encinas 1295 Parque Industrial Valle Grande LAMP Santiago de Chile P.O. Box Casilla 23 Correo Quilicura - Santiago - Chile | Tel. +56 2 2757 7000 Fax +56 2 2757 7001 http://www.sew-eurodrive.cl ventas@sew-eurodrive.cl |
|------------------------------|-------------------|---|---|

China

| | | | |
|--|-----------|--|---|
| Production Assembly Sales Service | Tianjin | SEW-EURODRIVE (Tianjin) Co., Ltd. No. 78, 13th Avenue, TEDA Tianjin 300457 | Tel. +86 22 25322612 Fax +86 22 25323273 http://www.sew-eurodrive.cn info@sew-eurodrive.cn |
| Assembly Sales Service | Suzhou | SEW-EURODRIVE (Suzhou) Co., Ltd. 333, Suhong Middle Road Suzhou Industrial Park Jiangsu Province, 215021 | Tel. +86 512 62581781 Fax +86 512 62581783 suzhou@sew-eurodrive.cn |
| | Guangzhou | SEW-EURODRIVE (Guangzhou) Co., Ltd. No. 9, JunDa Road East Section of GETDD Guangzhou 510530 | Tel. +86 20 82267890 Fax +86 20 82267922 guangzhou@sew-eurodrive.cn |
| | Shenyang | SEW-EURODRIVE (Shenyang) Co., Ltd. 10A-2, 6th Road Shenyang Economic Technological Development Area Shenyang, 110141 | Tel. +86 24 25382538 Fax +86 24 25382580 shenyang@sew-eurodrive.cn |
| | Taiyuan | SEW-EURODRIVE (Taiyuan) Co., Ltd. No.3, HuaZhang Street, TaiYuan Economic & Technical Development Zone ShanXi, 030032 | Tel. +86-351-7117520 Fax +86-351-7117522 taiyuan@sew-eurodrive.cn |
| | Wuhan | SEW-EURODRIVE (Wuhan) Co., Ltd. 10A-2, 6th Road No. 59, the 4th Quanli Road, WEDA 430056 Wuhan | Tel. +86 27 84478388 Fax +86 27 84478389 wuhan@sew-eurodrive.cn |
| | Xi'An | SEW-EURODRIVE (Xi'An) Co., Ltd. No. 12 Jinye 2nd Road Xi'An High-Technology Industrial Development Zone Xi'An 710065 | Tel. +86 29 68686262 Fax +86 29 68686311 xian@sew-eurodrive.cn |
| | Hong Kong | SEW-EURODRIVE LTD. Unit No. 801-806, 8th Floor Hong Leong Industrial Complex No. 4, Wang Kwong Road Kowloon, Hong Kong | Tel. +852 36902200 Fax +852 36902211 contact@sew-eurodrive.hk |

| | | | |
|--------------------------------|------------|---|--|
| Colombia | | | |
| Assembly Sales Service | Bogota | SEW-EURODRIVE COLOMBIA LTDA. Calle 17 No. 132-18 Interior 2 Bodega 6, Manzana B Santafé de Bogotá | Tel. +57 1 54750-50 Fax +57 1 54750-44 http://www.sew-eurodrive.com.co sew@sew-eurodrive.com.co |
| Croatia | | | |
| Sales Service | Zagreb | KOMPEKS d. o. o. Zeleni dol 10 10 000 Zagreb | Tel. +385 1 4613-158 Fax +385 1 4613-158 kompeks@inet.hr |
| Czech Republic | | | |
| Assembly Sales Service | Hostivice | SEW-EURODRIVE CZ s.r.o. Floriánova 2459 253 01 Hostivice | Tel. +420 255 709 601 Fax +420 235 350 613 http://www.sew-eurodrive.cz sew@sew-eurodrive.cz |
| Denmark | | | |
| Assembly Sales Service | Copenhagen | SEW-EURODRIVE A/S Geminivej 28-30 2670 Greve | Tel. +45 43 95 8500 Fax +45 43 9585-09 http://www.sew-eurodrive.dk sew@sew-eurodrive.dk |
| Service | Vejle | SEW-EURODRIVE A/S Bødkervej 2 7100 Vejle | Tel. +45 43 9585 00 http://www.sew-eurodrive.dk sew@sew-eurodrive.dk |
| Egypt | | | |
| Sales Service | Cairo | Copam Egypt for Engineering & Agencies Building 10, Block 13005, First Industrial Zone, Obour City Cairo | Tel. +202 44812673 / 79 (7 lines) Fax +202 44812685 http://www.copam-egypt.com copam@copam-egypt.com |
| Estonia | | | |
| Sales | Tallin | ALAS-KUUL AS Loomäe tee 1, Lehmja küla 75306 Rae vald Harjumaa | Tel. +372 6593230 Fax +372 6593231 http://www.alas-kuul.ee info@alas-kuul.ee |
| Finland | | | |
| Assembly Sales Service | Hollola | SEW-EURODRIVE OY Vesimäentie 4 15860 Hollola | Tel. +358 201 589-300 Fax +358 3 780-6211 http://www.sew-eurodrive.fi sew@sew.fi |
| Service | Hollola | SEW-EURODRIVE OY Keskikankaantie 21 15860 Hollola | Tel. +358 201 589-300 Fax +358 3 780-6211 http://www.sew-eurodrive.fi sew@sew.fi |
| | Tornio | SEW-EURODRIVE Oy Lossirannankatu 5 95420 Tornio | Tel. +358 201 589 300 Fax +358 3 780 6211 http://www.sew-eurodrive.fi sew@sew.fi |
| Production Assembly | Karkkila | SEW Industrial Gears Oy Santasalonkatu 6, PL 8 03620 Karkkila, 03601 Karkkila | Tel. +358 201 589-300 Fax +358 201 589-310 http://www.sew-eurodrive.fi sew@sew.fi |
| France | | | |
| Production Sales Service | Hagenau | SEW USOCOME 48-54 route de Soufflenheim B. P. 20185 67506 Hagenau Cedex | Tel. +33 3 88 73 67 00 Fax +33 3 88 73 66 00 http://www.usocom.com sew@usocom.com |
| Production | Forbach | SEW USOCOME Zone industrielle Technopôle Forbach Sud B. P. 30269 57604 Forbach Cedex | Tel. +33 3 87 29 38 00 |
| | Brumath | SEW USOCOME 1 Rue de Bruxelles 67670 Mommenheim Cedex | Tel. +33 3 88 37 48 00 |

France

| | | | |
|------------------------------|----------|--|---|
| Assembly Sales Service | Bordeaux | SEW USOCOME Parc d'activités de Magellan 62 avenue de Magellan – B. P. 182 33607 Pessac Cedex | Tel. +33 5 57 26 39 00 Fax +33 5 57 26 39 09 |
| | Lyon | SEW USOCOME 75 rue Antoine Condorcet 38090 Vaulx-Milieu | Tel. +33 4 74 99 60 00 Fax +33 4 74 99 60 15 |
| | Nantes | SEW USOCOME Parc d'activités de la forêt 4 rue des Fontenelles 44140 Le Bignon | Tel. +33 2 40 78 42 00 Fax +33 2 40 78 42 20 |
| | Paris | SEW USOCOME Zone industrielle 2 rue Denis Papin 77390 Verneuil l'Étang | Tel. +33 1 64 42 40 80 Fax +33 1 64 42 40 88 |

Gabon

Representation: Cameroon

Germany

| | | | |
|-------------------------------------|-----------------------------|---|---|
| Headquarters Production Sales | Bruchsal | SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 76646 Bruchsal | Tel. +49 7251 75-0 Fax +49 7251 75-1970 http://www.sew-eurodrive.de sew@sew-eurodrive.de |
| Production / Industrial Gears | Bruchsal | SEW-EURODRIVE GmbH & Co KG Christian-Pähr-Str. 10 76646 Bruchsal | Tel. +49 7251 75-0 Fax +49 7251 75-2970 |
| Production | Graben | SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 1 76676 Graben-Neudorf | Tel. +49 7251 75-0 Fax +49 7251-2970 |
| | Östringen | SEW-EURODRIVE GmbH & Co KG, Werk Östringen Franz-Gurk-Straße 2 76684 Östringen | Tel. +49 7253 9254-0 Fax +49 7253 9254-90 oestringen@sew-eurodrive.de |
| Service Competence Center | Mechanics / Mechatronics | SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 1 76676 Graben-Neudorf | Tel. +49 7251 75-1710 Fax +49 7251 75-1711 scc-mechanik@sew-eurodrive.de |
| | Electronics | SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 76646 Bruchsal | Tel. +49 7251 75-1780 Fax +49 7251 75-1769 scc-elektronik@sew-eurodrive.de |
| Drive Technology Center | North | SEW-EURODRIVE GmbH & Co KG Alte Ricklinger Straße 43 30823 Garbsen (Hannover) | Tel. +49 5137 8798-30 Fax +49 5137 8798-55 dtc-nord@sew-eurodrive.de |
| | East | SEW-EURODRIVE GmbH & Co KG Dankritzer Weg 1 08393 Meerane (Zwickau) | Tel. +49 3764 7606-0 Fax +49 3764 7606-20 dtc-ost@sew-eurodrive.de |
| | South | SEW-EURODRIVE GmbH & Co KG Domagkstraße 5 85551 Kirchheim (München) | Tel. +49 89 909551-21 Fax +49 89 909551-50 dtc-sued@sew-eurodrive.de |
| | West | SEW-EURODRIVE GmbH & Co KG Siemensstraße 1 40764 Langenfeld (Düsseldorf) | Tel. +49 2173 8507-10 Fax +49 2173 8507-50 dtc-west@sew-eurodrive.de |
| Drive Center | Berlin | SEW-EURODRIVE GmbH & Co KG Alexander-Meißner-Straße 44 12526 Berlin | Tel. +49 306331131-30 Fax +49 306331131-36 dc-berlin@sew-eurodrive.de |
| | Hamburg | SEW-EURODRIVE GmbH & Co KG Hasselbinnen 44 22869 Schenefeld | Tel. +49 40298109-60 Fax +49 40298109-70 dc-hamburg@sew-eurodrive.de |
| | Ludwigshafen | SEW-EURODRIVE GmbH & Co KG c/o BASF SE Gebäude W130 67056 Ludwigshafen | Tel. +49 7251 75 3759 Fax +49 7251 75 503759 dc-ludwigshafen@sew-eurodrive.de |
| | Saarland | SEW-EURODRIVE GmbH & Co KG Gottlieb-Daimler-Straße 4 66773 Schwalbach Saar – Hülzweiler | Tel. +49 6831 48946 10 Fax +49 6831 48946 13 dc-saarland@sew-eurodrive.de |

Germany

| | | | |
|---|----------|---|--|
| | Ulm | SEW-EURODRIVE GmbH & Co KG Dieselstraße 18 89160 Dornstadt | Tel. +49 7348 9885-0 Fax +49 7348 9885-90 dc-ulm@sew-eurodrive.de |
| | Würzburg | SEW-EURODRIVE GmbH & Co KG Nürnbergerstraße 118 97076 Würzburg-Lengfeld | Tel. +49 931 27886-60 Fax +49 931 27886-66 dc-wuerzburg@sew-eurodrive.de |
| Drive Service Hotline / 24 Hour Service | | | 0 800 SEWHELP 0 800 7394357 |

Great Britain

| | | | |
|------------------------------|-----------|--|--|
| Assembly Sales Service | Normanton | SEW-EURODRIVE Ltd. DeVilliers Way Trident Park Normanton West Yorkshire WF6 1GX | Tel. +44 1924 893-855 Fax +44 1924 893-702 http://www.sew-eurodrive.co.uk info@sew-eurodrive.co.uk |
|------------------------------|-----------|--|--|

Greece

| | | | |
|-------|--------|--|--|
| Sales | Athens | Christ. Boznos & Son S.A. 12, K. Mavromichali Street P.O. Box 80136 18545 Piraeus | Tel. +30 2 1042 251-34 Fax +30 2 1042 251-59 http://www.boznos.gr info@boznos.gr |
|-------|--------|--|--|

Hungary

| | | | |
|------------------|----------|--|---|
| Sales Service | Budapest | SEW-EURODRIVE Kft. Csillaghegyi út 13. 1037 Budapest | Tel. +36 1 437 06-58 Fax +36 1 437 06-50 http://www.sew-eurodrive.hu office@sew-eurodrive.hu |
|------------------|----------|--|---|

Iceland

| | | | |
|-------|-----------|---|--|
| Sales | Reykjavik | Varma & Vélaverk ehf. Knarrarvogi 4 104 Reykjavik | Tel. +354 585 1070 Fax +354 585)1071 https://vov.is/ vov@vov.is |
|-------|-----------|---|--|

India

| | | | |
|---|----------|---|---|
| Registered Office Assembly Sales Service | Vadodara | SEW-EURODRIVE India Private Limited Plot No. 4, GIDC POR Ramangamdi • Vadodara - 391 243 Gujarat | Tel. +91 265 3045200 Fax +91 265 3045300 http://www.seweurodriveindia.com salesvadodara@seweurodriveindia.com |
| Assembly Sales Service | Chennai | SEW-EURODRIVE India Private Limited Plot No. K3/1, Sipcot Industrial Park Phase II Mambakkam Village Sriperumbudur - 602105 Kancheepuram Dist, Tamil Nadu | Tel. +91 44 37188888 Fax +91 44 37188811 saleschennai@seweurodriveindia.com |
| | Pune | SEW-EURODRIVE India Private Limited Plant: Plot No. D236/1, Chakan Industrial Area Phase- II, Warale, Tal- Khed, Pune-410501, Maharashtra | Tel. +91 21 35 628700 Fax +91 21 35 628715 salespune@seweurodriveindia.com |
| Sales Service | Gurgaon | SEW-EURODRIVE India Private Limited Drive Center Gurugram Plot no 395, Phase-IV, UdyogVihar Gurugram , 122016 Haryana | Tel. +91 99588 78855 salesgurgaon@seweurodriveindia.com |

Indonesia

| | | | |
|-------|---------|--|--|
| Sales | Medan | PT. Serumpun Indah Lestari Jl.Pulau Solor no. 8, Kawasan Industri Medan II Medan 20252 | Tel. +62 61 687 1221 Fax +62 61 6871429 / +62 61 6871458 / +62 61 30008041 sil@serumpunindah.com serumpunindah@yahoo.com http://www.serumpunindah.com |
| | Jakarta | PT. Cahaya Sukses Abadi Komplek Rukan Puri Mutiara Blok A no 99, Sunter Jakarta 14350 | Tel. +62 21 65310599 Fax +62 21 65310600 csajkt@cbn.net.id |

| Indonesia | | | |
|------------------------|-------------|---|---|
| | Jakarta | PT. Agrindo Putra Lestari JL.Pantai Indah Selatan, Komplek Sentra Industri Terpadu, Pantai indah Kapuk Tahap III, Blok E No. 27 Jakarta 14470 | Tel. +62 21 2921-8899 Fax +62 21 2921-8988 aplindo@indosat.net.id http://www.aplindo.com |
| | Surabaya | PT. TRIAGRI JAYA ABADI Jl. Sukosemolo No. 63, Galaxi Bumi Permai G6 No. 11 Surabaya 60111 | Tel. +62 31 5990128 Fax +62 31 5962666 sales@triagri.co.id http://www.triagri.co.id |
| | Surabaya | CV. Multi Mas Jl. Raden Saleh 43A Kav. 18 Surabaya 60174 | Tel. +62 31 5458589 Fax +62 31 5317220 sianhwa@sby.centrin.net.id http://www.cvmultimas.com |
| Ireland | | | |
| Sales Service | Dublin | Alpert Engineering Ltd. 48 Moyle Road Dublin Industrial Estate Glasnevin, Dublin 11 | Tel. +353 1 830-6277 Fax +353 1 830-6458 http://www.alpert.ie info@alpert.ie |
| Israel | | | |
| Sales | Tel Aviv | Liraz Handasa Ltd. Ahofer Str 34B / 228 58858 Holon | Tel. +972 3 5599511 Fax +972 3 5599512 http://www.liraz-handasa.co.il office@liraz-handasa.co.il |
| Italy | | | |
| Assembly Sales Service | Milan | SEW-EURODRIVE S.a.s. di SEW S.r.l. & Co. Via Bernini,12 20020 Solaro (Milano) | Tel. +39 02 96 980229 Fax +39 02 96 980 999 http://www.sew-eurodrive.it milano@sew-eurodrive.it |
| Ivory Coast | | | |
| Sales | Abidjan | SEW-EURODRIVE SARL Ivory Coast Rue des Pêcheurs, Zone 3 26 BP 916 Abidjan 26 | Tel. +225 21 21 81 05 Fax +225 21 25 30 47 info@sew-eurodrive.ci http://www.sew-eurodrive.ci |
| Japan | | | |
| Assembly Sales Service | Iwata | SEW-EURODRIVE JAPAN CO., LTD 250-1, Shimoman-no, Iwata Shizuoka 438-0818 | Tel. +81 538 373811 Fax +81 538 373814 http://www.sew-eurodrive.co.jp sewjapan@sew-eurodrive.co.jp |
| Kazakhstan | | | |
| Sales Service | Almaty | SEW-EURODRIVE LLP 291-291A, Tole bi street 050031, Almaty | Tel. +7 (727) 350 5156 Fax +7 (727) 350 5156 http://www.sew-eurodrive.kz sew@sew-eurodrive.kz |
| | Tashkent | SEW-EURODRIVE LLP Representative office in Uzbekistan 96A, Sharaf Rashidov street, Tashkent, 100084 | Tel. +998 71 2359411 Fax +998 71 2359412 http://www.sew-eurodrive.uz sew@sew-eurodrive.uz |
| | Ulaanbaatar | IM Trading LLC Olympic street 28B/3 Sukhbaatar district, Ulaanbaatar 14230, MN | Tel. +976-77109997 Fax +976-77109997 imt@imt.mn |
| Latvia | | | |
| Sales | Riga | SIA Alas-Kuul Katlakalna 11C 1073 Riga | Tel. +371 6 7139253 Fax +371 6 7139386 http://www.alas-kuul.lv info@alas-kuul.com |
| Lebanon | | | |
| Sales (Lebanon) | Beirut | Gabriel Acar & Fils sarl B. P. 80484 Bourj Hammoud, Beirut | Tel. +961 1 510 532 Fax +961 1 494 971 ssacar@inco.com.lb |

Lebanon

| | | |
|--|---|--|
| Sales (Jordan, Kuwait , Beirut Saudi Arabia, Syria) | Middle East Drives S.A.L. (offshore) Sin El Fil. B. P. 55-378 Beirut | Tel. +961 1 494 786 Fax +961 1 494 971 http://www.medrives.com info@medrives.com |
|--|---|--|

Lithuania

| | | | |
|-------|--------|---|--|
| Sales | Alytus | UAB Irseva Statybininku 106C 63431 Alytus | Tel. +370 315 79204 Fax +370 315 56175 http://www.irseva.lt irmantas@irseva.lt |
|-------|--------|---|--|

Luxembourg

Representation: Belgium

Macedonia

| | | | |
|-------|--------|--|--|
| Sales | Skopje | Boznos DOOEL Dime Anicin 2A/7A 1000 Skopje | Tel. +389 23256553 Fax +389 23256554 http://www.boznos.mk |
|-------|--------|--|--|

Malaysia

| | | | |
|------------------------------|-------|---|---|
| Assembly Sales Service | Johor | SEW-EURODRIVE SDN BHD No. 95, Jalan Seroja 39, Taman Johor Jaya 81000 Johor Bahru, Johor West Malaysia | Tel. +60 7 3549409 Fax +60 7 3541404 sales@sew-eurodrive.com.my |
|------------------------------|-------|---|---|

Mexico

| | | | |
|------------------------------|-----------|--|--|
| Assembly Sales Service | Quéretaro | SEW-EURODRIVE MEXICO S.A. de C.V. SEM-981118-M93 Tequisquiapan No. 102 Parque Industrial Quéretaro C.P. 76220 Querétaro, México | Tel. +52 442 1030-300 Fax +52 442 1030-301 http://www.sew-eurodrive.com.mx scmexico@sew-eurodrive.com.mx |
| Sales Service | Puebla | SEW-EURODRIVE MEXICO S.A. de C.V. Calzada Zavaleta No. 3922 Piso 2 Local 6 Col. Santa Cruz Buenavista C.P. 72154 Puebla, México | Tel. +52 (222) 221 248 http://www.sew-eurodrive.com.mx scmexico@sew-eurodrive.com.mx |

Mongolia

| | | | |
|------------------|-------------|---|--|
| Technical Office | Ulaanbaatar | IM Trading LLC Olympic street 28B/3 Sukhbaatar district, Ulaanbaatar 14230, MN | Tel. +976-77109997 Tel. +976-99070395 Fax +976-77109997 http://imt.mn/ imt@imt.mn |
|------------------|-------------|---|--|

Morocco

| | | | |
|------------------------------|-----------|--|--|
| Sales Service Assembly | Bouskoura | SEW-EURODRIVE Morocco SARL Parc Industriel CFCIM, Lot. 55/59 27182 Bouskoura Grand Casablanca | Tel. +212 522 88 85 00 Fax +212 522 88 84 50 http://www.sew-eurodrive.ma sew@sew-eurodrive.ma |
|------------------------------|-----------|--|--|

Namibia

| | | | |
|-------|------------|---|---|
| Sales | Swakopmund | DB MINING & INDUSTRIAL SUPPLIES CC Einstein Street Strauss Industrial Park Unit1 Swakopmund | Tel. +264 64 462 738 Fax +264 64 462 734 anton@dbminingnam.com |
|-------|------------|---|---|

Netherlands

| | | | |
|------------------------------|-----------|---|---|
| Assembly Sales Service | Rotterdam | SEW-EURODRIVE B.V. Industrieweg 175 3044 AS Rotterdam Postbus 10085 3004 AB Rotterdam | Tel. +31 10 4463-700 Fax +31 10 4155-552 Service: 0800-SEWHELP http://www.sew-eurodrive.nl info@sew-eurodrive.nl |
|------------------------------|-----------|---|---|

| New Zealand | | | |
|------------------------------|---------------------|--|--|
| Assembly Sales Service | Auckland | SEW-EURODRIVE NEW ZEALAND LTD. P.O. Box 58-428 82 Greenmount drive East Tamaki Auckland | Tel. +64 9 2745627 Fax +64 9 2740165 http://www.sew-eurodrive.co.nz sales@sew-eurodrive.co.nz |
| | Christchurch | SEW-EURODRIVE NEW ZEALAND LTD. 30 Lodestar Avenue, Wigram Christchurch | Tel. +64 3 384-6251 Fax +64 3 384-6455 sales@sew-eurodrive.co.nz |
| Nigeria | | | |
| Sales | Lagos | Greenpeg Nig. Ltd Plot 296A, Adeyemo Akapo Str. Omole GRA Ikeja Lagos-Nigeria | Tel. +234-701-821-9200-1 http://www.greenpeg ltd.com bolaji.adekunle@greenpeg ltd.com |
| Norway | | | |
| Assembly Sales Service | Moss | SEW-EURODRIVE A/S Solgaard skog 71 1599 Moss | Tel. +47 69 24 10 20 Fax +47 69 24 10 40 http://www.sew-eurodrive.no sew@sew-eurodrive.no |
| Pakistan | | | |
| Sales | Karachi | Industrial Power Drives Al-Fatah Chamber A/3, 1st Floor Central Com- mercial Area, Sultan Ahmed Shah Road, Block 7/8, Karachi | Tel. +92 21 452 9369 Fax +92-21-454 7365 seweurodrive@cyber.net.pk |
| Paraguay | | | |
| Sales | Fernando de la Mora | SEW-EURODRIVE PARAGUAY S.R.L De la Victoria 112, Esquina nueva Asunción Departamento Central Fernando de la Mora, Barrio Bernardino | Tel. +595 991 519695 Fax +595 21 3285539 sewpy@sew-eurodrive.com.py |
| Peru | | | |
| Assembly Sales Service | Lima | SEW EURODRIVE DEL PERU S.A.C. Los Calderos, 120-124 Urbanizacion Industrial Vulcano, ATE, Lima | Tel. +51 1 3495280 Fax +51 1 3493002 http://www.sew-eurodrive.com.pe sewperu@sew-eurodrive.com.pe |
| Philippines | | | |
| Sales | Makati | P.T. Cerna Corporation 4137 Ponte St., Brgy. Sta. Cruz Makati City 1205 | Tel. +63 2 519 6214 Fax +63 2 890 2802 mech_drive_sys@ptcerna.com http://www.ptcerna.com |
| Poland | | | |
| Assembly Sales Service | Łódź | SEW-EURODRIVE Polska Sp.z.o.o. ul. Techniczna 5 92-518 Łódź | Tel. +48 42 293 00 00 Fax +48 42 293 00 49 http://www.sew-eurodrive.pl sew@sew-eurodrive.pl |
| | Service | Tel. +48 42 293 0030 Fax +48 42 293 0043 | 24 Hour Service Tel. +48 602 739 739 (+48 602 SEW SEW) serwis@sew-eurodrive.pl |
| Portugal | | | |
| Assembly Sales Service | Coimbra | SEW-EURODRIVE, LDA. Av. da Fonte Nova, n.º 86 3050-379 Mealhada | Tel. +351 231 20 9670 Fax +351 231 20 3685 http://www.sew-eurodrive.pt infosew@sew-eurodrive.pt |
| Romania | | | |
| Sales Service | Bucharest | Sialco Trading SRL str. Brazilia nr. 36 011783 Bucuresti | Tel. +40 21 230-1328 Fax +40 21 230-7170 http://www.sialco.ro sialco@sialco.ro |

| | | | |
|------------------------------|----------------|---|--|
| Russia | | | |
| Assembly Sales Service | St. Petersburg | ЗАО «СЕВ-ЕВРОДРАЙФ» 188660, Russia, Leningrad Region, Vse- volozhsky District, Korabselki, Aleksandra Nevskogo str. building 4, block 1 P.O. Box 36 195220 St. Petersburg | Tel. +7 812 3332522 / +7 812 5357142 Fax +7 812 3332523 http://www.sew-eurodrive.ru sew@sew-eurodrive.ru |
| Senegal | | | |
| Sales | Dakar | SENEMECA Mécanique Générale Km 8, Route de Rufisque B.P. 3251, Dakar | Tel. +221 338 494 770 Fax +221 338 494 771 http://www.senemeca.com senemeca@senemeca.sn |
| Serbia | | | |
| Sales | Belgrade | DIPAR d.o.o. Ustanicka 128a PC Košum, IV floor 11000 Beograd | Tel. +381 11 347 3244 / +381 11 288 0393 Fax +381 11 347 1337 office@dipar.rs |
| Singapore | | | |
| Assembly Sales Service | Singapore | SEW-EURODRIVE PTE. LTD. No 9, Tuas Drive 2 Jurong Industrial Estate Singapore 638644 | Tel. +65 68621701 Fax +65 68612827 http://www.sew-eurodrive.com.sg sewsingapore@sew-eurodrive.com |
| Slovakia | | | |
| Sales | Bernolákovo | SEW-Eurodrive SK s.r.o. Priemyselná ulica 6267/7 900 27 Bernolákovo | Tel. +421 2 33595 202, 217, 201 Fax +421 2 33595 200 http://www.sew-eurodrive.sk sew@sew-eurodrive.sk |
| Slovenia | | | |
| Sales Service | Celje | Pakman - Pogonska Tehnika d.o.o. Ul. XIV. divizije 14 3000 Celje | Tel. +386 3 490 83-20 Fax +386 3 490 83-21 pakman@siol.net |
| South Africa | | | |
| Assembly Sales Service | Johannesburg | SEW-EURODRIVE (PROPRIETARY) LIMITED Eurodrive House Cnr. Adcock Ingram and Aerodrome Roads Aeroton Ext. 2 Johannesburg 2013 P.O.Box 90004 Bertsham 2013 | Tel. +27 11 248-7000 Fax +27 11 248-7289 http://www.sew.co.za info@sew.co.za |
| | Cape Town | SEW-EURODRIVE (PROPRIETARY) LIMITED Rainbow Park Cnr. Racecourse & Omuramba Road Montague Gardens Cape Town P.O.Box 36556 Chempet 7442 | Tel. +27 21 552-9820 Fax +27 21 552-9830 Telex 576 062 bgriffiths@sew.co.za |
| | Durban | SEW-EURODRIVE (PROPRIETARY) LIMITED 48 Prospecton Road Isipingo Durban P.O. Box 10433, Ashwood 3605 | Tel. +27 31 902 3815 Fax +27 31 902 3826 cdejager@sew.co.za |
| | Nelspruit | SEW-EURODRIVE (PROPRIETARY) LIMITED 7 Christie Crescent Vintonia P.O.Box 1942 Nelspruit 1200 | Tel. +27 13 752-8007 Fax +27 13 752-8008 robermeyer@sew.co.za |
| | | | |
| South Korea | | | |
| Assembly Sales Service | Ansan | SEW-EURODRIVE KOREA CO., LTD. 7, Dangjaengi-ro, Danwon-gu, Ansan-si, Gyeonggi-do, Zip 425-839 | Tel. +82 31 492-8051 Fax +82 31 492-8056 http://www.sew-eurodrive.kr master.korea@sew-eurodrive.com |

| South Korea | | | |
|------------------------------|---------------|---|---|
| | Busan | SEW-EURODRIVE KOREA CO., LTD. 28, Noksansandan 262-ro 50beon-gil, Gangseo-gu, Busan, Zip 618-820 | Tel. +82 51 832-0204 Fax +82 51 832-0230 |
| Spain | | | |
| Assembly Sales Service | Bilbao | SEW-EURODRIVE ESPAÑA, S.L. Parque Tecnológico, Edificio, 302 48170 Zamudio (Vizcaya) | Tel. +34 94 43184-70 http://www.sew-eurodrive.es sew.spain@sew-eurodrive.es |
| Sri Lanka | | | |
| Sales | Colombo | SM International (Pte) Ltd 254, Galle Raod Colombo 4, Sri Lanka | Tel. +94 1 2584887 Fax +94 1 2582981 |
| Swaziland | | | |
| Sales | Manzini | C G Trading Co. (Pty) Ltd Simunye street Matsapha, Manzini | Tel. +268 7602 0790 Fax +268 2 518 5033 charles@cgtrading.co.sz www.cgtradingswaziland.com |
| Sweden | | | |
| Assembly Sales Service | Jönköping | SEW-EURODRIVE AB Gnejsvägen 6-8 553 03 Jönköping Box 3100 S-550 03 Jönköping | Tel. +46 36 34 42 00 Fax +46 36 34 42 80 http://www.sew-eurodrive.se jonkoping@sew.se |
| Switzerland | | | |
| Assembly Sales Service | Basel | Alfred Imhof A.G. Jurastrasse 10 4142 Münchenstein bei Basel | Tel. +41 61 417 1717 Fax +41 61 417 1700 http://www.imhof-sew.ch info@imhof-sew.ch |
| Taiwan | | | |
| Sales | Taipei | Ting Shou Trading Co., Ltd. 6F-3, No. 267, Sec. 2 Tung Huw S. Road Taipei | Tel. +886 2 27383535 Fax +886 2 27368268 Telex 27 245 sewtwn@ms63.hinet.net http://www.tingshou.com.tw |
| | Nan Tou | Ting Shou Trading Co., Ltd. No. 55 Kung Yeh N. Road Industrial District Nan Tou 540 | Tel. +886 49 255353 Fax +886 49 257878 sewtwn@ms63.hinet.net http://www.tingshou.com.tw |
| Tanzania | | | |
| Sales | Daressalam | SEW-EURODRIVE PTY LIMITED TANZANIA Plot 52, Regent Estate PO Box 106274 Dar Es Salaam | Tel. +255 0 22 277 5780 Fax +255 0 22 277 5788 http://www.sew-eurodrive.co.tz info@sew.co.tz |
| Thailand | | | |
| Assembly Sales Service | Chonburi | SEW-EURODRIVE (Thailand) Ltd. 700/456, Moo.7, Donhuaroh Muang Chonburi 20000 | Tel. +66 38 454281 Fax +66 38 454288 sewthailand@sew-eurodrive.com |
| Tunisia | | | |
| Sales | Tunis | T. M.S. Technic Marketing Service Zone Industrielle Mghira 2 Lot No. 39 2082 Fouchana | Tel. +216 79 40 88 77 Fax +216 79 40 88 66 http://www.tms.com.tn tms@tms.com.tn |
| Turkey | | | |
| Assembly Sales Service | Kocaeli-Gebze | SEW-EURODRIVE Ana Merkez Gebze Organize Sanayi Böl. 400 Sok No. 401 41480 Gebze Kocaeli | Tel. +90 262 9991000 04 Fax +90 262 9991009 http://www.sew-eurodrive.com.tr sew@sew-eurodrive.com.tr |

Ukraine

| | | | |
|------------------------------|----------------|--|--|
| Assembly Sales Service | Dnipropetrovsk | SEW-EURODRIVE, LLC Robochya str., bld. 23-B, office 409 49008 Dnipro | Tel. +380 56 370 3211 Fax +380 56 372 2078 http://www.sew-eurodrive.ua sew@sew-eurodrive.ua |
|------------------------------|----------------|--|--|

United Arab Emirates

| | | | |
|----------------------------|-------|---|---|
| Drive Technology Center | Dubai | SEW-EURODRIVE FZE PO Box 263835 Jebel Ali Free Zone – South, P.O. Box Dubai, United Arab Emirates | Tel. +971 (0)4 8806461 Fax +971 (0)4 8806464 info@sew-eurodrive.ae |
|----------------------------|-------|---|---|

Uruguay

| | | | |
|-------------------|------------|--|---|
| Assembly Sales | Montevideo | SEW-EURODRIVE Uruguay, S. A. Jose Serrato 3569 Esquina Corumbe CP 12000 Montevideo | Tel. +598 2 21181-89 Fax +598 2 21181-90 sewuy@sew-eurodrive.com.uy |
|-------------------|------------|--|---|

USA

| | | | |
|--|---------------------|--|---|
| Production Assembly Sales Service | Southeast Region | SEW-EURODRIVE INC. 1295 Old Spartanburg Highway P.O. Box 518 Lyman, S.C. 29365 | Tel. +1 864 439-7537 Fax Sales +1 864 439-7830 Fax Production +1 864 439-9948 Fax Assembly +1 864 439-0566 Fax Confidential/HR +1 864 949-5557 http://www.seweurodrive.com cslyman@seweurodrive.com |
| Assembly Sales Service | Northeast Region | SEW-EURODRIVE INC. Pureland Ind. Complex 2107 High Hill Road, P.O. Box 481 Bridgeport, New Jersey 08014 | Tel. +1 856 467-2277 Fax +1 856 845-3179 csbridgeport@seweurodrive.com |
| | Midwest Region | SEW-EURODRIVE INC. 2001 West Main Street Troy, Ohio 45373 | Tel. +1 937 335-0036 Fax +1 937 332-0038 cstroy@seweurodrive.com |
| | Southwest Region | SEW-EURODRIVE INC. 3950 Platinum Way Dallas, Texas 75237 | Tel. +1 214 330-4824 Fax +1 214 330-4724 csdallas@seweurodrive.com |
| | Western Region | SEW-EURODRIVE INC. 30599 San Antonio St. Hayward, CA 94544 | Tel. +1 510 487-3560 Fax +1 510 487-6433 cshayward@seweurodrive.com |
| | Wellford | SEW-EURODRIVE INC. 148/150 Finch Rd. Wellford, S.C. 29385 | Tel. +1 864 439-7537 Fax +1 864 661 1167 IGOrders@seweurodrive.com |


Additional addresses for service provided on request!

Vietnam

| | | | |
|-------|---------------------|--|---|
| Sales | Ho Chi Minh City | SEW-EURODRIVE PTE. LTD. RO at Hochim- inh City Floor 8, KV I, Loyal building, 151-151 Bis Vo Thi Sau street, ward 6, District 3, Ho Chi Minh City, Vietnam | Tel. +84 937 299 700 huytam.phan@sew-eurodrive.com |
| | Hanoi | MICO LTD Quảng Trị - North Vietnam / All sectors except Construction Materials 8th Floor, Ocean Park Building, 01 Dao Duy Anh St, Ha Noi, Viet Nam | Tel. +84 4 39386666 Fax +84 4 3938 6888 nam_ph@micogroup.com.vn http://www.micogroup.com.vn |

Zambia

Representation: South Africa











SEW-EURODRIVE
Driving the world

SEW
EURODRIVE

SEW-EURODRIVE GmbH & Co KG
Ernst-Blickle-Str. 42
76646 BRUCHSAL
GERMANY
Tel. +49 7251 75-0
Fax +49 7251 75-1970
sew@sew-eurodrive.com
→ www.sew-eurodrive.com