



# Manual



## **MOVIKIT® Power and Energy Solutions** **DirectMode**



## Table of contents

|          |                                                                 |           |
|----------|-----------------------------------------------------------------|-----------|
| <b>1</b> | <b>General information.....</b>                                 | <b>5</b>  |
| 1.1      | About this documentation .....                                  | 5         |
| 1.2      | Content of the documentation.....                               | 5         |
| 1.3      | Structure of the safety notes .....                             | 5         |
| 1.3.1    | Meaning of signal words .....                                   | 5         |
| 1.3.2    | Structure of section-related safety notes.....                  | 5         |
| 1.3.3    | Structure of embedded safety notes .....                        | 6         |
| 1.4      | Decimal separator in numerical values .....                     | 6         |
| 1.5      | Rights to claim under limited warranty .....                    | 6         |
| 1.6      | Product names and trademarks.....                               | 6         |
| 1.6.1    | Trademark of Beckhoff Automation GmbH .....                     | 6         |
| 1.7      | Copyright notice .....                                          | 6         |
| 1.8      | Other applicable documentation .....                            | 7         |
| 1.9      | Short designation .....                                         | 7         |
| <b>2</b> | <b>Safety notes .....</b>                                       | <b>8</b>  |
| 2.1      | Preliminary information .....                                   | 8         |
| 2.2      | Target group .....                                              | 8         |
| 2.3      | Network security and access protection .....                    | 8         |
| 2.4      | Designated use .....                                            | 8         |
| <b>3</b> | <b>System description .....</b>                                 | <b>9</b>  |
| 3.1      | Module description.....                                         | 9         |
| 3.1.1    | Operating modes.....                                            | 10        |
| 3.1.2    | IEC libraries.....                                              | 10        |
| 3.2      | Functions .....                                                 | 11        |
| <b>4</b> | <b>Project planning information.....</b>                        | <b>12</b> |
| 4.1      | Requirement .....                                               | 12        |
| 4.2      | Hardware .....                                                  | 12        |
| 4.3      | Software.....                                                   | 12        |
| 4.4      | Licensing.....                                                  | 12        |
| <b>5</b> | <b>Startup .....</b>                                            | <b>13</b> |
| 5.1      | Requirements.....                                               | 13        |
| 5.2      | Startup procedure .....                                         | 13        |
| 5.3      | Configuring the project.....                                    | 14        |
| 5.3.1    | Example project .....                                           | 14        |
| 5.3.2    | Add MOVIKIT® Power and Energy Solutions DirectMode.....         | 15        |
| 5.3.3    | Configuring MOVIKIT® Power and Energy Solutions DirectMode..... | 16        |
| 5.4      | Generating an IEC project .....                                 | 21        |
| 5.4.1    | IEC project structure .....                                     | 22        |
| <b>6</b> | <b>IEC programming.....</b>                                     | <b>23</b> |
| 6.1      | Opening the IEC project.....                                    | 23        |
| 6.2      | Interface in the IEC Editor.....                                | 23        |
| 6.3      | Basic functions.....                                            | 24        |
| 6.3.1    | Diagnostics.....                                                | 24        |

|          |                                                      |           |
|----------|------------------------------------------------------|-----------|
| 6.3.2    | Access management.....                               | 24        |
| 6.3.3    | Operating mode selection (ModeControl) .....         | 25        |
| 6.3.4    | Basic measured values (Basic).....                   | 25        |
| 6.3.5    | Inverter status (inverter) .....                     | 27        |
| 6.3.6    | Accessing measured values .....                      | 28        |
| 6.4      | Operating modes .....                                | 29        |
| 6.4.1    | State of charge control (StateOfChargeControl) ..... | 29        |
| 6.5      | IEC libraries .....                                  | 33        |
| 6.5.1    | SEW PES GridMonitor .....                            | 33        |
| 6.5.2    | SEW PES PowerMonitor .....                           | 40        |
| <b>7</b> | <b>Process data assignment .....</b>                 | <b>43</b> |
| 7.1      | Fieldbus connection .....                            | 43        |
| 7.2      | Process output data .....                            | 43        |
| 7.3      | Process input data .....                             | 45        |
| <b>8</b> | <b>Error management.....</b>                         | <b>47</b> |
| 8.1      | Error codes .....                                    | 47        |
| 8.1.1    | Device communication .....                           | 47        |
|          | <b>Index .....</b>                                   | <b>48</b> |

# 1 General information

## 1.1 About this documentation

This documentation is an integral part of the product. The documentation is intended for all employees who perform work on the product.

Make sure this documentation is accessible and legible. Ensure that persons responsible for the systems and their operation as well as persons who work with the product independently have read through the documentation carefully and understood it. If you are unclear about any of the information in this documentation, or if you require further information, contact SEW-EURODRIVE.

## 1.2 Content of the documentation

The descriptions in this documentation apply to the software and firmware versions applicable at the time of publication. These descriptions might differ if you install later software or firmware versions. In this case, contact SEW-EURODRIVE.

## 1.3 Structure of the safety notes

### 1.3.1 Meaning of signal words

The following table shows the grading and meaning of the signal words for safety notes.

| Signal word        | Meaning                                                        | Consequences if disregarded              |
|--------------------|----------------------------------------------------------------|------------------------------------------|
| <b>⚠ DANGER</b>    | Imminent hazard                                                | Severe or fatal injuries                 |
| <b>⚠ WARNING</b>   | Possible dangerous situation                                   | Severe or fatal injuries                 |
| <b>⚠ CAUTION</b>   | Possible dangerous situation                                   | Minor injuries                           |
| <b>NOTICE</b>      | Possible damage to property                                    | Damage to the product or its environment |
| <b>INFORMATION</b> | Useful information or tip: Simplifies handling of the product. |                                          |

### 1.3.2 Structure of section-related safety notes

Section-related safety notes do not apply to a specific action but to several actions pertaining to one subject. The hazard symbols used either indicate a general hazard or a specific hazard.

This is the formal structure of a safety note for a specific section:



#### **SIGNAL WORD**

Type and source of hazard.

Possible consequence(s) if disregarded.

- Measure(s) to prevent the hazard.

## Meaning of the hazard symbols

The hazard symbols in the safety notes have the following meaning:

| Hazard symbol                                                                     | Meaning        |
|-----------------------------------------------------------------------------------|----------------|
|  | General hazard |

### 1.3.3 Structure of embedded safety notes

Embedded safety notes are directly integrated into the instructions just before the description of the dangerous action.

This is the formal structure of an embedded safety note:

**⚠ SIGNAL WORD!** Type and source of hazard. Possible consequence(s) if disregarded. Measure(s) to prevent the hazard.

## 1.4 Decimal separator in numerical values

In this document, a period is used to indicate the decimal separator.

Example: 30.5 kg

## 1.5 Rights to claim under limited warranty

Read the information in this documentation. This is essential for fault-free operation and fulfillment of any rights to claim under limited warranty. Read the documentation before you start working with the product.

## 1.6 Product names and trademarks

The brands and product names in this documentation are trademarks or registered trademarks of their respective titleholders.

### 1.6.1 Trademark of Beckhoff Automation GmbH

EtherCAT® is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.



## 1.7 Copyright notice

© 2019 SEW-EURODRIVE. All rights reserved. Unauthorized reproduction, modification, distribution or any other use of the whole or any part of this documentation is strictly prohibited.

## 1.8 Other applicable documentation

Observe the corresponding documentation for all further components.

Always use the latest edition of the documentation and the software.

The SEW-EURODRIVE website ([www.sew-eurodrive.com](http://www.sew-eurodrive.com)) provides a wide selection of documents for download in various languages. If required, you can also order printed and bound copies of the documentation from SEW-EURODRIVE.

## 1.9 Short designation

The following short designations are used in this documentation:

| Type designation                                           | Short designation   |
|------------------------------------------------------------|---------------------|
| MOVIKIT® Power and Energy Solutions DirectMode             | MOVIKIT® DirectMode |
| MOVIKIT® Power and Energy Solutions DirectMode             | Software module     |
| MDP92A power supply module with controlled DC link voltage | MDP92A              |
| DC/DC converter module MDE90A                              | MDE90A              |

## 2 Safety notes

### 2.1 Preliminary information

The following general safety notes serve the purpose of preventing injury to persons and damage to property. They primarily apply to the use of products described in this documentation. If you use additional components, also observe the relevant warning and safety notes.

### 2.2 Target group

**Software specialist** Any work with the software may only be performed by a specialist with suitable training. A specialist in this context is someone who has the following qualifications:

- Appropriate training
- Knowledge of this documentation and other applicable documentation
- SEW-EURODRIVE recommends additional training for products that are operated using this software.

### 2.3 Network security and access protection

A bus system makes it possible to adapt electronic drive technology components to the particulars of the machinery within wide limits. There is a risk that a change of parameters that cannot be detected externally may result in unexpected but not uncontrolled system behavior and may have a negative impact on operational safety, system availability, or data security.

Ensure that unauthorized access is prevented, especially with respect to Ethernet-based networked systems and engineering interfaces.

Use IT-specific safety standards to increase access protection to the ports. For a port overview, refer to the respective technical data of the device in use.

### 2.4 Designated use

The MOVIKIT® Power and Energy Solutions DirectMode is used in conjunction with the hardware components of the Power and Energy Solutions product range to provide intelligent power and energy management.

Use the device-independent MOVISUITE® engineering software to start up and configure the devices and to download the complete configuration to a MOVI-C® CONTROLLER.

Observe the documentation for the components used.

Unintended or improper use of the product may result in severe injury to persons and damage to property.

## 3 System description


### 3.1 Module description

#### Introduction

The Power and Energy Solutions product range expands SEW-EURODRIVE's current line of MOVIDRIVE® modular inverters to include intelligent power and energy management components. In addition to hardware components, the product range includes the MOVIKIT® modular system with software modules for optimum integration at the control software level.

#### Overview

The following figure provides an overview of software modules of the MOVIKIT® Power and Energy Solutions modular system:



31251670155

#### MOVIKIT® DirectMode

MOVIKIT® DirectMode is primarily designed for applications without energy storage. The software module offers operating modes and IEC libraries for operating the MDP92A and MDE90A devices from the controller, for setting a state of charge in the DC link, and for reading measured values from the devices to use them in the IEC program.

### INFORMATION

All minimum required function blocks are integrated by the automatic code generation function.



### 3.1.1 Operating modes

MOVIKIT® DirectMode provides the following operating modes:

- **State of charge control**

The state of charge control mode (*StateOfChargeControl*) is used to balance a specific state of charge in the DC link or energy storage by means of a connected device.

For further information, refer to chapter "Operating modes" (→  29).

### 3.1.2 IEC libraries

MOVIKIT® DirectMode also provides the following IEC libraries for manual integration:

- **SEW PES GridMonitor**

Function blocks for detecting AC loads via measuring terminals.

- **SEW PES PowerMonitor**

Central power node for balancing DC link power flows.

For further information, refer to chapter "IEC libraries" (→  33).

## 3.2 Functions

Overview of functions:

- **Recording of power and energy data**
  - Communication with Power and Energy Solutions devices (MDP92A, MDE90A) for detecting power and energy data at the connection point to the power grid and to the energy storage unit
  - Communication with MOVIDRIVE® modular for determining the power demand of the connected application
  - Determining the total power and energy balance including AC loads
- **Managing the DC link**
  - Specifying voltage setpoints of the DC link during operation
  - Assigning a maximum power output to the DC link during operation
  - Calculating the power of the DC link capacity
  - Use as a central node for supply and output power
- **Managing the AC connection**
  - Limiting the grid power (peak shaving)
  - Measuring phase-to-phase voltages
  - Calculating the current consumption of the individual line phases (applies only to symmetrical AC power systems)
  - Phase and power failure detection and calculation of the remaining system runtime

## 4 Project planning information

### 4.1 Requirement

Correct project planning and proper installation of the devices is required for successful startup and operation.

For detailed project planning information, refer to the documentation of the respective devices.

### 4.2 Hardware

The following hardware is required for operation:

- MOVI-C® CONTROLLER (recommended for UHX45A performance class and higher)
- MDP92A power supply module with controlled DC link voltage

**or**

DC/DC converter module MDE90A

### 4.3 Software

The following software is required for operation:

- MOVISUITE® engineering software
- MOVIRUN® flexible software platform

For more detailed information on the hardware requirements of the individual software components, see the documentation for the respective software.

### 4.4 Licensing

You need the following license(s) for operation:

- MOVIRUN® flexible

License for the software platform MOVIRUN® flexible

For further information on licensing, refer to the document "MOVI-C® Software Components". You can download the document from the SEW-EURODRIVE website ([www.sew-eurodrive.com](http://www.sew-eurodrive.com)).


## 5 Startup

### 5.1 Requirements

- Check the installation of the inverters and, if installed, also check the encoder connection.
- Observe the installation notes in the documentation of the respective device and software components.
- The devices to be started up are displayed in MOVISUITE®.

### 5.2 Startup procedure

The schematic diagram below shows the startup procedure:



9007227600287243

The startup steps specific to these software modules are explained in detail in the following chapters of this manual. For startup, also observe the documentation of all the other components in use.

### 5.3 Configuring the project

#### INFORMATION




For detailed information on how to operate the MOVISUITE® engineering software, refer to the corresponding documentation.

- ✓ A MOVISUITE® project has been created and is open.
- 1. Add required device nodes, software nodes (MOVI-C® SoftwareNode) and software modules (see "Sample project") to the project. Devices can be added by performing a network scan or manually by selecting them from the catalog.
- 2. Configure the added devices or software modules. If available, observe the specific notes in the following chapters that apply to MOVIKIT® Power and Energy Solutions DirectMode. For detailed information on the configuration of devices or software modules, refer to the respective documentation.

#### 5.3.1 Example project

The following figure shows an example project:



31237315339

### 5.3.2 Add MOVIKIT® Power and Energy Solutions DirectMode.



#### INFORMATION

For detailed information on how to operate the MOVISUITE® engineering software, refer to the corresponding documentation.

- ✓ A MOVISUITE® project has been created and is open.
- 1. Click on the empty software module section of the required node.
  - ⇒ The catalog section opens and displays the available software modules.
- 2. In the catalog section, click on MOVIKIT® Power and Energy Solutions DirectMode.
  - ⇒ A context menu opens.
- 3. Select the version from the respective drop-down list in the context menu and confirm your selection with [Apply].
  - ⇒ The MOVIKIT® Power and Energy Solutions DirectMode is assigned to the node, the configuration is created, and the basic settings are performed.


### 5.3.3 Configuring MOVIKIT® Power and Energy Solutions DirectMode

## INFORMATION



For detailed information on how to operate the MOVISUITE® engineering software, refer to the corresponding documentation.

1. In MOVISUITE®, click on MOVIKIT® Power and Energy Solutions DirectMode.  
⇒ The "configuration menus" (→ 17) of the software module are displayed.



9007228165413771

- [1] Button to return to the project overview
- [2] Main menu of the software module configuration (MOVIKIT® section)
- [3] Submenus of the configuration
- [4] Setting fields of the respective submenu

2. Configure the software module using the respective setting fields.
3. Click button [1] after having completed the configuration.  
⇒ The project overview is displayed.

## INFORMATION



For the changes made to the configuration to take effect, you have to update the configuration data. To do so, click [Update configuration data] in the respective notification at the node or in the context menu of the MOVI-C® CONTROLLER. The MOVI-C® CONTROLLER is stopped and restarted for updating the configuration data.

## Configuration menus

The section of the MOVIKIT® Power and Energy Solutions DirectMode in the main menu of the configuration includes the configuration menus described in the following chapters.

### Basic settings

| Parameter group | Description                                                       |
|-----------------|-------------------------------------------------------------------|
| Initialization  | Initialization of the device for operation of the software module |

### Device functions

#### FCB 55 Voltage control

| Parameter group                     | Value                                                                    |
|-------------------------------------|--------------------------------------------------------------------------|
| Voltage control                     | Activation of boost mode<br><b>Default value: No</b>                     |
| Voltage-controlled output stage end | Selection of the controlled output stage end<br><b>Default value: No</b> |

### Monitoring functions

#### Limit values

Configuration of the application limits correspond to the application.

| Parameter group | Description                                                                                                                                                                                                        |
|-----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Voltage limits  | Voltage limits in [V] are set using the following parameters: <ul style="list-style-type: none"> <li>A-side and B-side voltage</li> <li>Minimum A-side and B-side voltage</li> </ul> <b>Default value: 0.0 V</b>   |
| Current limits  | Current limits in [A] are set using the following parameters: <ul style="list-style-type: none"> <li>Positive A- and B-side current</li> <li>Negative A- and B-side current</li> </ul> <b>Default value: 0.0 A</b> |
| Power limits    | Power limits in [kW] are set using the following parameters: <ul style="list-style-type: none"> <li>B-A or A-B power</li> </ul> <b>Default value: 0 kW</b>                                                         |

## System design



## INFORMATION

As a rule, you have already received the values to be configured during project planning.

| Parameter group      | Description                                                                                                                                                                                                                                                                                                           |
|----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Boost charging power | <p>The boost charging power is set using the following parameters:</p> <ul style="list-style-type: none"> <li>Activation of boost mode<br/><b>Default value: Off</b></li> <li>Setting of the application limit B-A in [W]<br/><b>Default value: 0 W</b></li> </ul>                                                    |
| Discharging limit    | <p>The discharging limit is set using the following parameters:</p> <ul style="list-style-type: none"> <li>Application limit – minimum voltage A-side in [V]<br/><b>Default value: 0.0 V</b></li> <li>Minimum A-side voltage – source<br/><b>Default value: Application limit – minimum A-side voltage</b></li> </ul> |
| Charging limit       | <p>The charging limit is set using the following parameters:</p> <ul style="list-style-type: none"> <li>Application limit – voltage A-side in [V]<br/><b>Default value: 0.0 V</b></li> <li>Maximum A-side voltage – source<br/><b>Default value: Application limit – A-side voltage</b></li> </ul>                    |
| Current limits       | <p>Current limits are set using the following parameters:</p> <ul style="list-style-type: none"> <li>Application limit – positive A-side current in [A]<br/><b>Default value: 0.00 A</b></li> <li>Application limit – negative B-side current in [A]<br/><b>Default value: 0.00 A</b></li> </ul>                      |

## Operating modes

### State of charge control

| Parameter group                             | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|---------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| State of charge control                     | <p>The permitted operating range of the state of charge control is set using the following parameters.</p> <ul style="list-style-type: none"> <li>Maximum voltage – operating range A</li> <li>Maximum voltage – operating range B</li> <li>Minimum voltage – operating range A</li> <li>Minimum voltage – operating range B</li> </ul> <p><b>Default value (each): 0 V</b></p> <p>Setpoints (independent of the set unit) are limited to these values.</p>                       |
| Voltage lower limit axis operation          | <p>The voltage lower limit in axis operation is set using the following parameters:</p> <ul style="list-style-type: none"> <li>Lower limit DC link voltage – axis operation</li> </ul> <p><b>Default value: 0 V</b></p> <p>Operation of connected axes is possible above this voltage. However, the value must be below the operating range.</p>                                                                                                                                  |
| Backup mode / remaining runtime calculation | <p>The remaining runtime calculation is set using the following parameters:</p> <ul style="list-style-type: none"> <li>Lower limit DC link voltage – backup mode</li> </ul> <p><b>Default value: 0 V</b></p> <p>Operation of the 24 V supply from the DC link is possible in case of a power failure up to this voltage.</p>                                                                                                                                                      |
| Setpoint/actual value representation        | <p>The representation of the setpoint/actual value is set using the following parameters:</p> <ul style="list-style-type: none"> <li>Unit for state of charge: <ul style="list-style-type: none"> <li><b>Electrical voltage [V]</b></li> <li>Operating range in percent [%]</li> <li>Electrical energy [Ws]</li> </ul> </li> <li>Unit for charge limit: <ul style="list-style-type: none"> <li><b>Electrical power [W]</b></li> <li>Electrical current [A]</li> </ul> </li> </ul> |

*Fieldbus interface*

| Parameter group        | Value                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Fieldbus configuration | <ul style="list-style-type: none"> <li>• Activate fieldbus connection – Fieldbus block is integrated and connected to the fieldbus handler of the MOVI-C® CONTROLLER.</li> <li>• Start address<br/>Start address of the fieldbus process data words in the array of the bus system. Counting starts at 1.</li> </ul>                                                                                                                                                                                                                                                       |
| Process data length    | <ul style="list-style-type: none"> <li>• Process data length – Number of process data words used by the software module. Set this value to "8" to use the software module.<br/><b>Default value: 1</b></li> <li>• Unit for state of charge: <ul style="list-style-type: none"> <li>– <b>Electrical voltage [V]</b></li> <li>– Operating range in percent [%]</li> <li>– Electrical energy [Ws]</li> </ul> </li> <li>• Unit for charge limit: <ul style="list-style-type: none"> <li>– <b>Electrical power [W]</b></li> <li>– Electrical current [A]</li> </ul> </li> </ul> |


*Module identification*

| Parameter name        | Description                                                    |
|-----------------------|----------------------------------------------------------------|
| Module identification | Includes name and version for identifying the software module. |

## 5.4 Generating an IEC project

Carry out the following steps to create an IEC project using automatic code generation and based on the configuration settings in MOVISUITE®.

- ✓ The MOVISUITE® project has been configured.
- 1. In the function view of MOVISUITE®, click the software module section of the MOVI-C® CONTROLLER.
  - ⇒ The "IEC project" menu opens.



27021618448637067

### INFORMATION



If you have carried out the configuration in MOVISUITE® using the "Startup" mode and the message "Device cannot be reached" appears, proceed as follows:

- If the MOVI-C® CONTROLLER is not available via the network, switch over to "Planning" mode.
- If the MOVI-C® CONTROLLER is available via the network, carry out a network scan and connect the MOVI-C® CONTROLLER in the network view with the MOVI-C® CONTROLLER in the function view.

2. Click [Create new IEC project].

⇒ The IEC Editor opens and a new IEC project is created.


### INFORMATION



If changes are made to the project structure, to inverter data sets, or to a software module configuration after the IEC project is generated for the first time, a notification symbol is displayed on the MOVI-C® CONTROLLER node. Click on the notification symbol for more information on the change, and to update the IEC project.

### 5.4.1 IEC project structure

The IEC project has the following basic structure:



18014423003085323

| No. | Name               | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|-----|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| [1] | SEW_GVL_Internal   | The SEW_GVL_Internal global list of variables contains the instances that correspond to the software module used. These variables may not be written to from the user program.<br><br>In addition, the structure contains an instance as a communication buffer for controlling or monitoring the software module by means of a monitor.                                                                                                                                                                                                                              |
| [2] | SEW_PRG            | Program that contains all the important instance calls. Automatic code generation recreates this program in accordance with the configuration made in MOVISUITE® each time the IEC project is created, thereby overwriting the previous version. Therefore, you should not make any changes to this program.                                                                                                                                                                                                                                                          |
| [3] | SEW_GVL            | The SEW_GVL global list of variables is the interface for accessing the software module features.                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| [4] | User_PRG           | The user program is created once, initially, by automatic code generation. Since the program is not overwritten with each subsequent creation, this is the appropriate place for integrating user programs.<br><br>The program is divided into five actions. These actions differ in the time at which they are called during the program sequence.                                                                                                                                                                                                                   |
| [5] | Task configuration | The list of tasks created in the project. Automatic code generation initially adds tasks that differ in how they are prioritized.<br><br>The user can add additional programs to existing tasks or create new tasks.<br><br>It is the responsibility of the user to design the capacity utilization of the tasks to enable the tasks to be processed within the required cycle time. Moving beyond the cyclical tasks, in particular, prevents setpoints for the interpolating axes being generated in time, which means that these axes cannot be operated properly. |

## 6 IEC programming

### 6.1 Opening the IEC project

- If an IEC project has already been generated, select the entry [IEC Editor] under "Tools" from the context menu of the MOVI-C® CONTROLLER in MOVISUITE®.
- If no IEC project has been generated, follow the steps described in the "Generating an IEC project" (→ 21) chapter.

### 6.2 Interface in the IEC Editor

The user interface is implemented in the IEC program by an instance in the global variable list *SEW\_GVL*. This variable list contains variables for accessing the functions of the software module.

The following diagram shows the interface of the software module in the IEC project:

|                          |                                              |       |
|--------------------------|----------------------------------------------|-------|
| Interface_MDP92A         | SEW_MK_PES_DirectMode.EnergyHubMDP_UI        |       |
| xError                   | BOOL                                         | FALSE |
| xWarning                 | BOOL                                         | FALSE |
| udiMessageID             | UDINT                                        |       |
| sAdditionalText          | STRING(Constants.gc_udiLengthAdditionalText) | "     |
| xReset                   | BOOL                                         | FALSE |
| xGetAccessControl        | BOOL                                         | TRUE  |
| xControlActive           | BOOL                                         | FALSE |
| ModeControl              | SEW_PES_IEnHubBas.ST_ModeControl             |       |
| Basic                    | SEW_PES_IEnHubCom.ST_Basic                   |       |
| Inverter                 | SEW_PES_IEnHubCom.ST_Inverter                |       |
| ModeStateOfChargeControl | SEW_PES_IModeSoCCtrl.ST_ModeSoCCControl      |       |

30880259211

### 6.3 Basic functions

#### 6.3.1 Diagnostics

Variables for reporting and writing faults and warnings.

| Variable name   | Description                                                                                                        |
|-----------------|--------------------------------------------------------------------------------------------------------------------|
| xError          | Data type – BOOL                                                                                                   |
|                 | <ul style="list-style-type: none"> <li>• TRUE – Fault present</li> <li>• FALSE – No fault present</li> </ul>       |
| xWarning        | Data type – BOOL                                                                                                   |
|                 | <ul style="list-style-type: none"> <li>• TRUE – Warning present</li> <li>• FALSE – No warning present</li> </ul>   |
| udiMessageID    | Data type: UDINT                                                                                                   |
|                 | Message ID number                                                                                                  |
| sAdditionalText | Data type: STRING                                                                                                  |
|                 | Additional message text                                                                                            |
| xReset          | Data type – BOOL                                                                                                   |
|                 | <ul style="list-style-type: none"> <li>• TRUE – Reset messages</li> <li>• FALSE – Do not reset messages</li> </ul> |

#### 6.3.2 Access management

Variables for managing access permissions.

| Variable name     | Description                                                                                                |
|-------------------|------------------------------------------------------------------------------------------------------------|
| xGetAccessControl | Data type – BOOL                                                                                           |
|                   | <ul style="list-style-type: none"> <li>• TRUE – Request access</li> <li>• FALSE – Return access</li> </ul> |
| xControlActive    | Data type – BOOL                                                                                           |
|                   | <ul style="list-style-type: none"> <li>• TRUE – Access granted</li> <li>• FALSE – Access denied</li> </ul> |

##### Access via user interface (UserInterface):

An instance requests access by setting *xGetAccessControl* to "TRUE." If *xControlActive* returns a "TRUE" value, access has been granted and is now permitted.

##### Access via other function blocks in the user program:

If another function block in control mode wants to access the device interface at the same time as the user interface (UserInterface), the device interface decides which one receives write permission based on the priority of the function block. The user interface (UserInterface) has the highest priority. This means if the user interface (UserInterface) has control access, then *xControlActive* returns "FALSE" to all other function blocks.

### 6.3.3 Operating mode selection (ModeControl)

The *ModeControl* structure is used to select the "operating mode" (→ 29) of the software module. Several operating modes cannot be activated at the same time because each operating mode is specifically defined to perform a certain function.

#### IN

| Variable name   | Description                                                                                                                                                                           |
|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| uiRequestedMode | Data type: UINT<br>Operating mode selection <ul style="list-style-type: none"> <li>• 0 – No operating mode</li> <li>• 500 – State of charge control (StateOfChargeControl)</li> </ul> |

#### OUT

| Variable name | Description                                           |
|---------------|-------------------------------------------------------|
| uiActualMode  | Data type: UINT<br>Currently activated operating mode |

### 6.3.4 Basic measured values (Basic)

The *Basic* structure contains variables for outputting basic measured values of the device.

#### OUT

##### Grid

The *Grid* structure contains variables to output information on the electrical supply system. The measured outer conductor voltages as well as additional information on the grid status and the status of the individual line phases are displayed.

## INFORMATION



The information is only output if the connected device provides this information. Using MDE90A, for example, only the grid status is sent from the module bus master device because the device is not physically connected to the external supply system.

| Variable name      | Description                                                                           |
|--------------------|---------------------------------------------------------------------------------------|
| rActualVoltageL1L2 | Data type – REAL<br>Current phase-to-phase voltage (RMS) between phases L1 and L2 [V] |
| rActualVoltageL1L3 | Data type – REAL<br>Current phase-to-phase voltage (RMS) between phases L1 and L3 [V] |
| rActualVoltageL2L3 | Data type – REAL<br>Current phase-to-phase voltage (RMS) between phases L2 and L3 [V] |

| Variable name         | Description                                                                                                                                                                                                                                              |
|-----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| rEstimatedGridCurrent | Data type – REAL                                                                                                                                                                                                                                         |
|                       | Calculated grid phase current per phase (AC RMS [A])                                                                                                                                                                                                     |
| xMainsConnected       | Data type – BOOL                                                                                                                                                                                                                                         |
|                       | <ul style="list-style-type: none"> <li>• TRUE – The measured voltage is within the permissible range (supply system is connected).</li> <li>• FALSE – The measured voltage is outside the permissible range (supply system is not connected).</li> </ul> |
| xPhase1Connected      | Data type – BOOL                                                                                                                                                                                                                                         |
|                       | <ul style="list-style-type: none"> <li>• TRUE – L1 phase voltage has expected value</li> <li>• FALSE – Phase voltage L1 failed</li> </ul>                                                                                                                |
| xPhase2Connected      | Data type – BOOL                                                                                                                                                                                                                                         |
|                       | <ul style="list-style-type: none"> <li>• TRUE – L2 phase voltage has expected value</li> <li>• FALSE – Phase voltage L2 failed</li> </ul>                                                                                                                |
| xPhase3Connected      | Data type – BOOL                                                                                                                                                                                                                                         |
|                       | <ul style="list-style-type: none"> <li>• TRUE – L3 phase voltage has expected value</li> <li>• FALSE – Phase voltage L3 failed</li> </ul>                                                                                                                |

*DCLink*

The *DCLink* structure contains variables to output measured variables of the electrical DC link, such as currents, voltages, and power on the two control sides. The currently selected control side is also output.

| Variable name      | Description                                                                                                                                                                                                                                                                                                   |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| eControlSideActive | Data type – ENUMERATION                                                                                                                                                                                                                                                                                       |
|                    | Active control side of the connected device <ul style="list-style-type: none"> <li>• A_SIDE – A-side is control side for FCB 55.</li> <li>• B_SIDE – B-side is control side for FCB 55.</li> <li>• NONE – No side selected as control side.</li> <li>• BOTH – Both sides selected as control side.</li> </ul> |
| rActualCurrent_A   | Data type – REAL                                                                                                                                                                                                                                                                                              |
|                    | Actual DC current [A] on the A-side of the device                                                                                                                                                                                                                                                             |
| rActualCurrent_B   | Data type – REAL                                                                                                                                                                                                                                                                                              |
|                    | Actual DC current [A] on the B-side of the device                                                                                                                                                                                                                                                             |
| rActualVoltage_A   | Data type – REAL                                                                                                                                                                                                                                                                                              |
|                    | Actual DC voltage [V] on the A-side of the device                                                                                                                                                                                                                                                             |
| rActualVoltage_B   | Data type – REAL                                                                                                                                                                                                                                                                                              |
|                    | Actual DC voltage [V] on the B-side of the device                                                                                                                                                                                                                                                             |
| rActualPower_A     | Data type – REAL                                                                                                                                                                                                                                                                                              |
|                    | Actual DC power [W] on the A-side of the device                                                                                                                                                                                                                                                               |

| Variable name  | Description                                     |
|----------------|-------------------------------------------------|
| rActualPower_B | Data type – REAL                                |
|                | Actual DC power [W] on the B-side of the device |

### 6.3.5 Inverter status (inverter)

The *Inverter* structure contains variables to output the status information of the device and to control the digital inputs and outputs.

#### IN

| Variable name    | Description                                                                                                             |
|------------------|-------------------------------------------------------------------------------------------------------------------------|
| xActivateStandBy | Data type – BOOL                                                                                                        |
|                  | <ul style="list-style-type: none"> <li>TRUE – Activate standby mode</li> <li>FALSE – Deactivate standby mode</li> </ul> |
| wDigitalOutputs  | Data type: WORD                                                                                                         |
|                  | Control of the digital outputs of the device                                                                            |

#### OUT

| Variable name  | Description                                                                                                                                                                                                                                                                                                           |
|----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| xConnected     | Data type – BOOL                                                                                                                                                                                                                                                                                                      |
|                | <ul style="list-style-type: none"> <li>TRUE – Communication connection active</li> <li>FALSE – Communication connection inactive</li> </ul>                                                                                                                                                                           |
| eInverterMode  | Data type – ENUMERATION                                                                                                                                                                                                                                                                                               |
|                | Active FCB or active operating mode.                                                                                                                                                                                                                                                                                  |
|                | <ul style="list-style-type: none"> <li>FCB_STANDARD: 0<br/>Default FCB</li> <li>FCB_BRIDGE_DISABLED: 51<br/>Output stage inhibit activated</li> <li>FCB_BRAKE_CHOPPER_BLOCKED: 52<br/>Brake chopped blocked due to fault</li> <li>FCB_VOLTAGE_CONTROL: 55<br/>Controlling of the DC link voltage activated</li> </ul> |
| wDigitalInputs | Data type: WORD                                                                                                                                                                                                                                                                                                       |
|                | State of the digital inputs                                                                                                                                                                                                                                                                                           |
| usiErrorID     | Data type: USINT                                                                                                                                                                                                                                                                                                      |
|                | Error ID                                                                                                                                                                                                                                                                                                              |
| usiErrorSubID  | Data type: USINT                                                                                                                                                                                                                                                                                                      |
|                | Suberror ID                                                                                                                                                                                                                                                                                                           |

| Variable name    | Description                                                                                                                                                                                       |
|------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| xLimitActive     | Data type – BOOL                                                                                                                                                                                  |
|                  | <ul style="list-style-type: none"> <li>• TRUE – An internal limit is active and limits the setting range of the device</li> <li>• FALSE – The device operates within its setting range</li> </ul> |
| xPowered         | Data type – BOOL                                                                                                                                                                                  |
|                  | <ul style="list-style-type: none"> <li>• TRUE – The output stage of the device is enabled</li> <li>• FALSE – The output stage of the device is inhibited</li> </ul>                               |
| xReady           | Data type – BOOL                                                                                                                                                                                  |
|                  | <ul style="list-style-type: none"> <li>• TRUE – The device is ready for operation</li> <li>• FALSE – The device is not ready for operation</li> </ul>                                             |
| xSetpointActive  | Data type – BOOL                                                                                                                                                                                  |
|                  | <ul style="list-style-type: none"> <li>• TRUE – Setpoints are processed</li> <li>• FALSE – Setpoints are not processed</li> </ul>                                                                 |
| xSetpointReached | Data type – BOOL                                                                                                                                                                                  |
|                  | <ul style="list-style-type: none"> <li>• TRUE – Specified setpoint is reached</li> <li>• FALSE – Specified setpoint is not reached</li> </ul>                                                     |
| xStandByActive   | Data type – BOOL                                                                                                                                                                                  |
|                  | <ul style="list-style-type: none"> <li>• TRUE – Standby mode activated</li> <li>• FALSE – Standby mode deactivated</li> </ul>                                                                     |

### 6.3.6 Accessing measured values

The following example of a code shows how to access measured values via the respective OUT structures to use them, for example, for further calculations.

```

rPGrid := Interface_MDP92A.Basic.OUT.DCLink.rActualPower_A;
rUDC   := Interface_MDP92A.Basic.OUT.DCLink.rActualVoltage_A;
rSoC   := Interface_MDP92A.Basic.OUT.DCLink.rActualVoltage_A*
          Interface_MDP92A.Basic.OUT.DCLink.rActualVoltage_A*
          REAL#1.9290E-06;
rPStorage := Interface_MDP92A.Basic.OUT.DCLink.rActualPower_A;
rPLoad    := rUDC * rUDC / REAL#13.2;
xError    := Interface_MDP92A.xError;

```

## 6.4 Operating modes

### 6.4.1 State of charge control (*StateOfChargeControl*)

The state of charge control operating mode (*StateOfChargeControl*) is used to balance a specific state of charge in the DC link or in the energy storage unit by means of the connected device (such as MDP92A, MDE90A).

#### INFORMATION



With MDP92A, the operating mode can only work with the A-side. With MDE90A, the control side can also be switched to the B-side to allow for charging a connected energy storage unit.

#### INFORMATION



The operating type automatically limits the setpoint for the state of charge to the specified "operating range" (→ 30). Additionally, the setpoints for the charge limit are automatically limited in such a way that the "application limits" (→ 17) set in the device are not exceeded on the respective control side.

### Operating principle

The state of charge to be adjusted is passed on as follows depending on the "configuration" (→ 19):

- As absolute voltage in [V] – Adjust the state of charge according to the specified absolute DC link voltage.
- As percentage value (between 0% and 100%) – Adjust the state of charge depending on the operating range specified in the "configuration" (→ 17).
- As absolute energy value in [Ws] – Adjust the state of charge according to a specified absolute amount of energy in the DC link.


Furthermore, a charge limit can be transferred as follows to limit the charging of the DC link:

- As power limit – Limit the device current on the respective control side so that the specified power limit results with the current voltage.
- As current limit – Limit the maximum device current on the respective control side to the specified value.

### Specifying the operating range

A valid operating range must be specified in the "Configuration" (→ 17) to being able to use the operating mode. Setpoints to the device for the state of charge are always limited to this operating range irrespective of the unit set. This can be a range between 450 V and 720 V, for example (see figure). This means this voltage range corresponds to the state of charge from 0% to 100%.

The following figure shows the operating range to be defined:



The device operates primarily with the voltage of the DC link. For the capacitors used, this is an indicator of the amount of charge or energy in the DC link and consequently also of the state of charge.

The voltage value is included quadratically in the calculation of the amount of energy in the DC link according to the following formula:

$$E = \frac{1}{2}CU^2$$

In this way, the state of charge can be calculated according to the following formula using only the measured voltages and the defined operating range:

$$SoC\% = \frac{(U_i^2 - U_u^2)}{(U_o^2 - U_u^2)} \cdot 100\%$$

$U_o$  and  $U_u$  define the upper and lower voltage limits of the operating range, and  $U_i$  the measured voltage at which the state of charge should be calculated. Similarly, this formula is used to convert state of charge setpoints into voltages and to make these voltages available to the device as voltage setpoints. The state of charge cannot be negative but can take on a value above 100%. This case occurs, for example, if the DC link adopts a higher voltage value than defined by the operating range when absorbing excess recuperation energy.

## IN

The following input variables are available for handling the operating mode.

| Variable name       | Description                                                                                                                                                                                                                 |
|---------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| xStart              | Data type: BOOL                                                                                                                                                                                                             |
|                     | <ul style="list-style-type: none"> <li>• TRUE – Start</li> <li>• FALSE – Stop</li> </ul>                                                                                                                                    |
| eControlSideRequest | Data type – ENUMERATION                                                                                                                                                                                                     |
|                     | Selection of the control side of the connected device. <ul style="list-style-type: none"> <li>• A_SIDE – Select A-side as control side for FCB 55.</li> <li>• B_SIDE – Select B-side as control side for FCB 55.</li> </ul> |
| rSoCSetpoint        | Data type – REAL                                                                                                                                                                                                            |
|                     | Setpoint of the state of charge (observe configured unit)                                                                                                                                                                   |
| rChargeLimit        | Data type – REAL                                                                                                                                                                                                            |
|                     | Setpoint of the charge limit (observe configured unit)                                                                                                                                                                      |

## OUT

The status of the operating mode is output via the following output variables.

| Variable name      | Description                                                                                                                                                                                                                                                                                                   |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| eControlSideActive | Data type – ENUMERATION                                                                                                                                                                                                                                                                                       |
|                    | Active control side of the connected device <ul style="list-style-type: none"> <li>• A_SIDE – A-side is control side for FCB 55.</li> <li>• B_SIDE – B-side is control side for FCB 55.</li> <li>• NONE – No side selected as control side.</li> <li>• BOTH – Both sides selected as control side.</li> </ul> |
| rActualOpRangePct  | Data type – REAL                                                                                                                                                                                                                                                                                              |
|                    | Current stage of charge of the selected control side [%]                                                                                                                                                                                                                                                      |
| rActualVoltage     | Data type – REAL                                                                                                                                                                                                                                                                                              |
|                    | Actual voltage of the selected control side [V]                                                                                                                                                                                                                                                               |
| rActualEnergy      | Data type – REAL                                                                                                                                                                                                                                                                                              |
|                    | Actual amount of energy of the selected control side [Ws]                                                                                                                                                                                                                                                     |

| Variable name   | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|-----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| eOperatingRange | <p>Data type – ENUMERATION</p> <p>Present state of charge.</p> <ul style="list-style-type: none"> <li>• ABOVE<br/>The actual state of charge is above the normal operating range. Risk of overload of the DC link or energy storage unit.</li> <li>• IN_RANGE<br/>The actual state of charge is within the normal operating range.</li> <li>• BELOW_AXES_AVAIL<br/>The actual state of charge is below the normal operating range. Connected axes can still be operated, if necessary even in reduced operation.</li> <li>• BELOW_24V_SUPPLY<br/>The state of charge is too low for operating axes. However, the MDS 24 V power supply unit can supply the system with power.</li> <li>• BELOW_SHUTDOWN<br/>The state of charge is so low that the system switches off within a short time.</li> </ul> |

### Activating DC link control



## INFORMATION

The settings described below can be made everywhere in the program code. To reduce runtime in the *HighPrio* task, we recommend using the *Main* task to make the settings.

The following example of a code shows how the voltage of the DC link on the MD-P92A power supply module is set to 650 V and a maximum charging power of 40 kW is set.

Request access:

```
Interface_MDP92A.xGetAccessControl:=TRUE;
```

Activate voltage control:

```
Interface_MDP92A.ModeControl.IN.uiRequestedMode:=500;
```

```
Interface_MDP92A.ModeStateOfChargeControl.IN.xStart:=TRUE;
```

Setpoint for DC link voltage [V]:

```
Interface_MDP92A.ModeStateOfChargeControl.IN.rSoCSetpoint:=650;
```

Setpoint for maximum charging power [W]:

```
Interface_MDP92A.ModeStateOfChargeControl.IN.rChargeLimit:=40000;
```

## 6.5 IEC libraries


### 6.5.1 SEW PES GridMonitor

Energy loads in the control cabinet that are supplied via an additional AC supply instead of the DC link can be measured using power measurement terminals, for example. The IEC library *SEW PES GridMonitor* provides the function block *ExternalPowerMonitor* as well as sub-blocks for connecting AC loads.

#### Operating principle

The *ExternalPowerMonitor* function block serves as a central node. The *ExternalConsumer* function block is a standardized interface for connecting AC loads to the *ExternalPowerMonitor* function block. Up to 10 AC loads can be connected to the *ExternalPowerMonitor* function block.

The following graphic illustrates this functional principle:




2862558875

The connected (2-phase or 3-phase) AC loads send data via a standardized interface to the *ExternalPowerMonitor* function block, which aggregates the data and displays it in a central location (e.g. determination of the total consumption).

The AC loads are connected via measurement terminals. Each consumption block (*ExternalConsumer2Phase* or *ExternalConsumer3Phase*) requires a connection block (driver). These connection blocks are available for selected power measurement terminals in the *SEW\_PES\_ACTerminalDrivers* IEC library to ensure quick and easy connection. Currently, the IEC library only offers the BECKHOFF EL3403 power measurement terminal.

The following example shows the *ACTermDriverManual\_3Phase* connection block, which can be used if the measurement is performed using non-supported measurement terminals. This connection block provides arrays with data type REAL so that the programmer can transfer the values of the individual phases measured by a terminal to these variables. The values are subsequently forwarded and processed automatically.



31310434443

```

FUNCTION_BLOCK ACTermDriverManual_3Phase
EXTENDS ACTermDriverBasic3Phase
VAR_INPUT
    arApparentPower : ARRAY[0..2] OF REAL;
    arActivePower : ARRAY[0..2] OF REAL;
    arReactivePower : ARRAY[0..2] OF REAL;
    arVoltage : ARRAY[0..2] OF REAL;
    arFrequency : ARRAY[0..2] OF REAL;
END_VAR
  
```

### ExternalPowerMonitor

The *ExternalPowerMonitor* function block represents the active power of all connected AC loads as a measured value and the sum of all active powers of the connected AC loads.

| Variable name       | Description                                                                                                                                                               |
|---------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| arActivePowerSingle | Data type: ARRAY OF REAL<br>Active power measured values [W] of the connected AC loads. Up to 10 loads can be monitored using the "ExternalPower-Monitor" function block. |
| rActivePowerSum     | Data type – REAL<br>Total active power of all connected loads in [W]                                                                                                      |

29182255/EN – 12/2019

**ExternalConsumer3Phase**

The *ExternalConsumer3Phase* function block provides the following electrical measured variables of a connected 3-phase AC load. It also indicates whether the connected loads measure and transmit these variables at all, i.e. whether these values are valid.

| Variable name       | Description                                                                                                               |
|---------------------|---------------------------------------------------------------------------------------------------------------------------|
| rApparentPower      | Data type – REAL                                                                                                          |
|                     | Apparent power measured value of the connected AC load in [VA]                                                            |
| xApparentPowerValid | Data type – BOOL                                                                                                          |
|                     | <ul style="list-style-type: none"> <li>• TRUE – Measured value valid</li> <li>• FALSE – Measured value invalid</li> </ul> |
| rActivePower        | Data type – REAL                                                                                                          |
|                     | Active power measured value of the connected AC load in [W]                                                               |
| xActivePowerValid   | Data type – BOOL                                                                                                          |
|                     | <ul style="list-style-type: none"> <li>• TRUE – Measured value valid</li> <li>• FALSE – Measured value invalid</li> </ul> |
| rReactivePower      | Data type – REAL                                                                                                          |
|                     | Reactive power measured value of the connected AC load in [VAr]                                                           |
| xReactivePowerValid | Data type – BOOL                                                                                                          |
|                     | <ul style="list-style-type: none"> <li>• TRUE – Measured value valid</li> <li>• FALSE – Measured value invalid</li> </ul> |
| rFrequency          | Data type – REAL                                                                                                          |
|                     | Frequency measured value of the connected AC load in [Hz]                                                                 |
| xFrequencyValid     | Data type – BOOL                                                                                                          |
|                     | <ul style="list-style-type: none"> <li>• TRUE – Measured value valid</li> <li>• FALSE – Measured value invalid</li> </ul> |
| rVoltageL1N         | Data type – REAL                                                                                                          |
|                     | Voltage measured value L1-N of the connected AC load in [V]                                                               |
| xVoltageL1NValid    | Data type – BOOL                                                                                                          |
|                     | <ul style="list-style-type: none"> <li>• TRUE – Measured value valid</li> <li>• FALSE – Measured value invalid</li> </ul> |
| rVoltageL2N         | Data type – REAL                                                                                                          |
|                     | Voltage measured value L2-N of the connected AC load in [V]                                                               |
| xVoltageL2NValid    | Data type – BOOL                                                                                                          |
|                     | <ul style="list-style-type: none"> <li>• TRUE – Measured value valid</li> <li>• FALSE – Measured value invalid</li> </ul> |

| Variable name    | Description                                                                                                                               |
|------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| rVoltageL3N      | Data type – REAL<br>Voltage measured value L3-N of the connected AC load in [V]                                                           |
| xVoltageL3NValid | Data type – BOOL<br><ul style="list-style-type: none"> <li>TRUE – Measured value valid</li> <li>FALSE – Measured value invalid</li> </ul> |

### ExternalConsumer2Phase

The *ExternalConsumer2Phase* function block provides the following electrical measured variables of a connected 2-phase AC load. It also indicates whether the connected loads measure and transmit these variables at all, i.e. whether these values are valid.

| Variable name       | Description                                                                                                                               |
|---------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| rApparentPower      | Data type – REAL<br>Apparent power measured value of the connected AC load in [VA]                                                        |
| xApparentPowerValid | Data type – BOOL<br><ul style="list-style-type: none"> <li>TRUE – Measured value valid</li> <li>FALSE – Measured value invalid</li> </ul> |
| rActivePower        | Data type – REAL<br>Active power measured value of the connected AC load in [W]                                                           |
| xActivePowerValid   | Data type – BOOL<br><ul style="list-style-type: none"> <li>TRUE – Measured value valid</li> <li>FALSE – Measured value invalid</li> </ul> |
| rReactivePower      | Data type – REAL<br>Reactive power measured value of the connected AC load in [VAr]                                                       |
| xReactivePowerValid | Data type – BOOL<br><ul style="list-style-type: none"> <li>TRUE – Measured value valid</li> <li>FALSE – Measured value invalid</li> </ul> |
| rFrequency          | Data type – REAL<br>Frequency measured value of the connected AC load in [Hz]                                                             |
| xFrequencyValid     | Data type – BOOL<br><ul style="list-style-type: none"> <li>TRUE – Measured value valid</li> <li>FALSE – Measured value invalid</li> </ul> |
| rVoltage            | Data type – REAL<br>Voltage measured value of the connected AC load in [V]                                                                |

| Variable name | Description                                                                                                           |
|---------------|-----------------------------------------------------------------------------------------------------------------------|
| xVoltageValid | Data type – BOOL                                                                                                      |
|               | <ul style="list-style-type: none"> <li>TRUE – Measured value valid</li> <li>FALSE – Measured value invalid</li> </ul> |

### SetConfig methods

Methods for transferring settings such as a filter time constant for measured value filtering to the function block.

#### ExtConsumer3Phase

Method for transferring modified filter time constants for measured value filtering to the function block. The method must be called once. The filters are reinitialized automatically.

If the new filter time constants have been applied and the filters have been reinitialized, the method returns the BOOLEAN value "TRUE." Otherwise, the value is "FALSE." This allows you to check for correct reinitialization.

| Variable name               | Description                                           |
|-----------------------------|-------------------------------------------------------|
| uiPriorityTask_Cycle-Time   | Data type: UINT                                       |
|                             | Sampling cycle of the priority task in [ms]           |
| rTimeConstActive-PowerPT1   | Data type – REAL                                      |
|                             | PT1 filter time constant of the active power in [s]   |
| rTimeConstReactive-PowerPT1 | Data type – REAL                                      |
|                             | PT1 filter time constant of the reactive power in [s] |
| rTimeConstApparent-PowerPT1 | Data type – REAL                                      |
|                             | PT1 filter time constant of the apparent power in [s] |
| rTimeConstFrequencyPT1      | Data type – REAL                                      |
|                             | PT1 filter time constant of the frequency in [s]      |
| rTimeConstVoltageL1NPT1     | Data type – REAL                                      |
|                             | PT1 filter time constant of voltage L1-N in [s]       |
| rTimeConstVoltageL2NPT1     | Data type – REAL                                      |
|                             | PT1 filter time constant of voltage L2-N in [s]       |
| rTimeConstVoltageL3NPT1     | Data type – REAL                                      |
|                             | PT1 filter time constant of voltage L3-N in [s]       |

#### ExtConsumer2Phase

Method for transferring modified filter time constants for measured value filtering to the function block. The method must be called once. The filters are reinitialized automatically.

If the new filter time constants have been applied and the filters have been reinitialized, the method returns the BOOLEAN value "TRUE." Otherwise, the value is "FALSE." This allows you to check for correct reinitialization.

| Variable name               | Description                                                               |
|-----------------------------|---------------------------------------------------------------------------|
| uiPriorityTask_Cycle-Time   | Data type: UINT<br>Sampling cycle of the priority task in [ms]            |
| rTimeConstActive-PowerPT1   | Data type – REAL<br>PT1 filter time constant of the active power in [s]   |
| rTimeConstReactive-PowerPT1 | Data type – REAL<br>PT1 filter time constant of the reactive power in [s] |
| rTimeConstApparent-PowerPT1 | Data type – REAL<br>PT1 filter time constant of the apparent power in [s] |
| rTimeConstFrequencyPT1      | Data type – REAL<br>PT1 filter time constant of the frequency in [s]      |
| rTimeConstVoltagePT1        | Data type – REAL<br>PT1 filter time constant of the voltage in [s]        |

## Measuring AC loads

### Without ExternalPowerMonitor

The following application example shows how an AC load can be measured using measurement terminals. In this case, third-party hardware is used and the terminals have already been connected and the individual measured variables have already been calculated.

1. Create an instance of the "manual" terminal driver:

```
⇒ FBDriverManual:
   SEW_MK_PES_DirectMode.SEW_GridMon.
   SEW_ACTermDrivers.ACTermDriverManual_3Phase;
```

2. Create an instance of the *ExternalConsumers3Phase* function block:

```
⇒ FB3PhaseConsumer:
   SEW_MK_PES_DirectMode.SEW_GridMon.ExtConsumer3Phase;
```

3. Connect the function blocks in the *Init* action in the *User\_PRG* program using the *LinkACDriver()* method in *ExternalConsumer*:

```
⇒ FB3PhaseConsumer.LinkACDriver (
   itfACDriver:=FBDriverManual
 );
```

4. Initialize both function blocks in the *Init* action in the *User\_PRG* program via their respective initialization methods as follows:

```
⇒ FBDriverManual.Init (
   xApparentPowerValid:=TRUE,
   xActivePowerValid:=TRUE,
   xReactivePowerValid:=FALSE,
   xVoltageValid:=TRUE,
   xFrequencyValid:=TRUE);
```

- ⇒ The "manual" terminal driver is provided with information about which of the measured values must be measured. In the example, these are the apparent power, the active power, the voltage and the frequency. You can disable measurement of the reactive power by setting the *xReactivePowerValid* value to the value "FALSE."
- 5. Initialize the *ExternalConsumer* function block with the cycle time of the calling task:
  - ⇒ 

```
FB3PhaseConsumer.Init(
    uiPriorityTask_CycleTime:=gc_uiTaskCycleTime
);
```
- 6. Call the following method in the *ReadActualValues* action in the *User\_PRG* program:
  - ⇒ 

```
FB3PhaseConsumer.ReadActualValues();
```
- 7. Call the following method in the *HighPrio* action in the *User\_PRG* program:
  - ⇒ 

```
FBDriverMannual.CallHighPrio();
```
- 8. Write the measured values to the variables of the driver block:
  - ⇒ 

```
FBDriverMannual.arActivePower[0]:=rPGrid*2;
FBDriverMannual.arActivePower[1]:=rPGrid*1.5-3000;
FBDriverMannual.arActivePower[2]:=rPGrid*0.5+3000;
```
  - ⇒ The *rPGrid* variable was copied with different scaling to the 3 active power inputs. The measured values can then be viewed centrally in the *ExternalConsumer* block.

The connection of the terminal may differ slightly if a supported terminal is used with a driver from the library. However, the method calls and the connections always take place as described in this chapter.

#### With *ExternalPowerMonitor*

The following application example shows how several AC loads can be detected and totaled using the *ExternalPowerMonitor* block. This requires an additional instance of the *ExternalPowerMonitor*.

1. Create an additional instance of the *ExternalPowerMonitor* function block:
    - ⇒ 

```
FBAcPowerMonitor:SEW_MK_PES_DirectMode.ExternalPowerMonitor;
```
  2. Use an interface link to link the function blocks in the *Init* action in the *User\_PRG* program to each *ExternalConsumer* function block
    - ⇒ 

```
FBAcPowerMonitor.LinkExtConsumer(
    itfExtConsum:=FB3PhaseConsumer
);
```
  3. Call the following method in the *ReadActualValues* action in the *User\_PRG* program:
    - ⇒ 

```
FBAcPowerMonitor.ReadActualValues();
```
  4. Call the following method in the *HighPrio* action in the *User\_PRG* program:
    - ⇒ 

```
FBAcPowerMonitor.CallHighPrio();
```
- ⇒ The measured values of the AC load are called and processed directly by the *ExternalPowerMonitor* function block. The totaled power values can be queried centrally here.

## 6.5.2 SEW PES PowerMonitor

## INFORMATION



The function block is not integrated via automatic code generation but must be implemented manually in the project.


The *SEW PES PowerMonitor* IEC library systematically groups incoming and outgoing instantaneous power values.

## Operating principle

When combining incoming and outgoing instantaneous power, a distinction is made between 3 variables:

- Grid power: Power delivered by the supply unit.
- Load power: Total power consumed in the system (in the same DC link).
- Storage unit power: Power that flows in or out of the additional storage unit.

All power values can also be negative. Axes can recuperate or a supply unit can transfer excess power from the DC link to the outside (conversion into heat at the discharge resistor).



9007228415314315

## Integration

Do the following to integrate the functionality:

- ✓ For example, if MOVIKIT® MultiMotion is used, the process data profile must leave at least 2 process data words for the actual values (ideally the last two. If the last two process data words are not used, another step is necessary during initialization.) For the process data words to appear in the actual values, the number of process data words must be increased manually by 2 in the configuration of the axis in the menu [Actual values] > [PI data]. Parameter 8364.212 is then inserted into the process data for the actual values (low word and high word).
1. In MOVISUITE®, open the "Basic settings" configuration menu of the axis and select "InterpolationFlexFull" as data module. This setting ensures that sufficient process data is available. Perform this step for each linked axis.

2. Generate an IEC project based on this configuration. See chapter "Generating an IEC project" (→ 21).
  3. Create an instance of the *PowerMonitor* function block.
 

```
⇒ fbPowerMonitor:SEW_MK_PES_DirectMode.SEW_PwrMon.PowerMonitor;
```
  4. Link the MDP92A or MDE90A axes using *LinkEnergyDevice*.
 

```
⇒ fbPowerMonitor.LinkEnergyDevice (
    xIsSupply:=TRUE,
    itfDevice:=MDP92A);
```
  5. Link the SEW MultiMotion axes using *LinkMuMoAxis*.
 

```
⇒ fbPowerMonitor.LinkMuMoAxis (
    itfAxisProcessData:=LogicalDevice_Axis1,
    uiPD_PowerIndex:=14, //Leistung wurde auf PE15 und PE16
    gemappt
    uiPriorityTask_CycleTime:=gc_uiTaskCycleTime);
```
  6. Call up the following function in the *CallHighPrio* task:
 

```
⇒ fbPowerMonitor.CallHighPrio();
```
  7. Alternatively, use the following functions to add power values from sources that are not linked:
 

```
⇒ fbPowerMonitor.AddPowerFromGrid(rPowerIn:=rPowerSupply);
⇒ fbPowerMonitor.AddPowerFromLoad(rPowerIn:=rForeignAxisPwr);
⇒ fbPowerMonitor.AddPowerFromStorage(rPowerIn:=rStoragePower);
```
- ⇒ The IEC library can be used.

## PowerMonitor

Variables for outputting power values.

| Variable name    | Description                                                     |
|------------------|-----------------------------------------------------------------|
| rActLoadPower    | Data type – REAL                                                |
|                  | Power values of loads (filtered) [W]                            |
| rActLoadPowerRaw | Data type – REAL                                                |
|                  | Power values of loads (unfiltered) [W]                          |
| rActStoragePower | Data type – REAL                                                |
|                  | Power [W] exchanged with the energy storage unit or the devices |
| rDCVoltage       | Data type – REAL                                                |
|                  | DC link voltage [V]                                             |

| Variable name        | Description                                                                                                                                                                                                                                                                                                                                                                      |
|----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| rPowerStock          | <p>Data type – REAL</p> <p>Total power flowing in or out of the DC link node [W]. This includes measurement inaccuracies, intrinsic losses, non-measured loads, and the power consumed or output by the storage unit.</p> <p>The sign indicates whether energy is charged or absorbed. Power supplied to the DC link has a negative sign, consumption power a positive sign.</p> |
| uiPD_PowerIndex_Axis | <p>Data type: UINT</p> <p>Start index of the process data word for the power of the axes. Counting starts with index 0. (All axes must use the same 2 process data words for this)</p>                                                                                                                                                                                           |

### LinkMuMoAxis

Variables for linking SEW MultiMotion axes.

| Variable name             | Description                                                                                                                    |
|---------------------------|--------------------------------------------------------------------------------------------------------------------------------|
| itfAxisProcessData        | <p>Data type – SEW_IDH.IProcessDataDirectAccess (LogicalDevice of the axis)</p> <p>Linking to the process data of the axis</p> |
| uiPD_PowerIndex           | <p>Data type: UINT</p> <p>Start index in the process data (index of LowWord and power). Counting starts with index 0.</p>      |
| uiPriorityTask_Cycle-Time | <p>Data type: UINT</p> <p>Bus cycle time in ms</p>                                                                             |

### LinkEnergyDevice

Variable for linking MDP92A or MDE90A axes.

| Variable name | Description                                                                                                                                             |
|---------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| itfDevice     | <p>Data type – SEW_PES_IEnHubCom.IBasicFct (EnergyHub)</p> <p>Linking with the energy node</p>                                                          |
| xlsSupply     | <p>Data type – BOOL</p> <ul style="list-style-type: none"> <li>TRUE – Connect supply module</li> <li>FALSE – Connect storage unit connection</li> </ul> |

## 7 Process data assignment

### 7.1 Fieldbus connection

If the fieldbus connection is "activated" (→ 20) in the configuration, a corresponding function block is added to the project when "generating the IEC project" (→ 21). Furthermore, method calls are generated for interconnection with the FieldbusHandler. As a result, the connection to the higher-level fieldbus runs automatically and no further manual adaptation is required.

The software modules require 8 process data words each for setpoints from a higher-level controller, and they send 8 process data words each via fieldbus.

### 7.2 Process output data

The following table shows the process output data from the higher-level controller to the inverter for control via fieldbus with 8 process data words.

| Word | Bit                                                                      | Function                                                                                                                                                                                                                                            |
|------|--------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PO 1 | Control word                                                             |                                                                                                                                                                                                                                                     |
|      | 0                                                                        | Enable/emergency stop                                                                                                                                                                                                                               |
|      | 1                                                                        | Reserved for "enable 2"                                                                                                                                                                                                                             |
|      | 2                                                                        | Reserved                                                                                                                                                                                                                                            |
|      | 3                                                                        | Reserved                                                                                                                                                                                                                                            |
|      | 4                                                                        | Reserved                                                                                                                                                                                                                                            |
|      | 5                                                                        | Reserved                                                                                                                                                                                                                                            |
|      | 6                                                                        | Reserved                                                                                                                                                                                                                                            |
|      | 7                                                                        | Start/stop                                                                                                                                                                                                                                          |
|      | 8                                                                        | Fault reset                                                                                                                                                                                                                                         |
|      | 9                                                                        | Reserved                                                                                                                                                                                                                                            |
|      | 10                                                                       | <ul style="list-style-type: none"> <li>"1": Control B-side</li> <li>"0": Control A-side</li> </ul> (applies only to the MDE90A device)                                                                                                              |
|      | 11                                                                       | Reserved                                                                                                                                                                                                                                            |
|      | 12                                                                       | Reserved                                                                                                                                                                                                                                            |
|      | 13                                                                       | Reserved for controller inhibit                                                                                                                                                                                                                     |
|      | 14                                                                       | Activate standby mode                                                                                                                                                                                                                               |
|      | 15                                                                       | MOVIKIT® Handshake In                                                                                                                                                                                                                               |
| PO 2 | Setpoint state of charge<br>(operating mode 500<br>StateOfChargeControl) |                                                                                                                                                                                                                                                     |
|      |                                                                          | Depending on the specified setpoint type: <ul style="list-style-type: none"> <li>Absolute voltage value [<math>10^{-1}</math> V]</li> <li>Percentage value of work envelope [<math>10^{-1}\%</math>]</li> <li>Absolute energy value [kW]</li> </ul> |

| Word |                                                                                       | Bit | Function                                                                                                                                                                                                      |
|------|---------------------------------------------------------------------------------------|-----|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PO 4 | Setpoint<br>Maximum charging capacity<br>(operating mode 500<br>StateOfChargeControl) |     | Depending on the specified setpoint type: <ul style="list-style-type: none"> <li>Absolute current [<math>10^{-1}</math> A]</li> <li>Power limit [<math>10^1</math> W].</li> </ul>                             |
| PO 5 | Digital outputs                                                                       | 0   | DO 00                                                                                                                                                                                                         |
|      |                                                                                       | 1   | DO 01                                                                                                                                                                                                         |
|      |                                                                                       | 2   | DO 02                                                                                                                                                                                                         |
|      |                                                                                       | 3   | DO 03                                                                                                                                                                                                         |
|      |                                                                                       | 4   | Relay output                                                                                                                                                                                                  |
| PO 6 | Target application mode                                                               |     | Operating mode selection: <ul style="list-style-type: none"> <li>0 – No operating mode activated<br/>The device remains in output stage inhibit state (FCB 51)</li> <li>500 (StateOfChargeControl)</li> </ul> |

### 7.3 Process input data

The following table shows the process input data from the inverter to the higher-level controller for control via fieldbus with 8 process data words.

| Word |                                                                           | Bit | Function                                                                                                                                                                                                                                                    |
|------|---------------------------------------------------------------------------|-----|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PI 1 | Status word                                                               | 0   | "1": Ready for operation                                                                                                                                                                                                                                    |
|      |                                                                           | 1   | Reserved                                                                                                                                                                                                                                                    |
|      |                                                                           | 2   | "1": Output stage enable                                                                                                                                                                                                                                    |
|      |                                                                           | 3   | "1": Power supply OK<br>All line phases are available and the voltage on all line phases is sufficient for normal operation.                                                                                                                                |
|      |                                                                           | 4   | "1": Supply active (B -> A)<br>The device feeds a current $\geq 1$ A into the DC link and the output stage of the device is enabled.                                                                                                                        |
|      |                                                                           | 5   | "1": Supply active (A -> B)<br>The device feeds a current $> 1$ A into the connected energy storage unit and the output stage of the device is enabled.                                                                                                     |
|      |                                                                           | 6   | Reserved                                                                                                                                                                                                                                                    |
|      |                                                                           | 7   | "1": Setpoint for state of charge reached (operating mode 500 – StateOfChargeControl)                                                                                                                                                                       |
|      |                                                                           | 8   | "1": Fault                                                                                                                                                                                                                                                  |
|      |                                                                           | 9   | "1": Warning                                                                                                                                                                                                                                                |
|      |                                                                           | 10  | <ul style="list-style-type: none"><li>"1": The B-side is the controlled side</li><li>"0": The A-side is the controlled side (applies only to the MDE90A device)</li></ul>                                                                                   |
|      |                                                                           | 11  | "1": State of charge low (warning)<br>The state of charge has a value below the defined operating range.                                                                                                                                                    |
|      |                                                                           | 12  | "1": State of charge high (warning)<br>The state of charge reached a level above the specified operating range.                                                                                                                                             |
|      |                                                                           | 13  | "1": Reserved                                                                                                                                                                                                                                               |
|      |                                                                           | 14  | "1": Standby mode active                                                                                                                                                                                                                                    |
|      |                                                                           | 15  | MOVIKIT® Handshake Out                                                                                                                                                                                                                                      |
| PI 2 | Actual value state of charge<br>(operating mode 500 StateOfChargeControl) |     | Depending on the specified setpoint type: <ul style="list-style-type: none"><li>Absolute voltage value [<math>10^{-1}</math> V]</li><li>Percentage value of work envelope [<math>10^{-1}\%</math>]</li><li>Absolute energy value [kW<sub>s</sub>]</li></ul> |

| Word |                                                                                | Bit | Function                                                                                                                                                                                                                                                                                  |
|------|--------------------------------------------------------------------------------|-----|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PI 3 | State<br>Fault subfault                                                        |     | <ul style="list-style-type: none"> <li>With active device fault:<br/>Bit 0..7 ErrorSubID, bit 8..15 ErrorID</li> <li>With active software module error:<br/>Error ID of the software module</li> <li>Without faults/errors or warnings:<br/>Active FCB of the connected device</li> </ul> |
| PI 4 | Actual value charging capacity<br>(operating mode 500<br>StateOfChargeControl) |     | Depending on the specified setpoint type: <ul style="list-style-type: none"> <li>Absolute current [<math>10^{-1}</math> A]</li> <li>Power [<math>10^1</math> W].</li> </ul>                                                                                                               |
| PI 5 | Digital inputs                                                                 | 0   | DI 00                                                                                                                                                                                                                                                                                     |
|      |                                                                                | 1   | DI 01                                                                                                                                                                                                                                                                                     |
|      |                                                                                | 2   | DI 02                                                                                                                                                                                                                                                                                     |
|      |                                                                                | 3   | DI 03                                                                                                                                                                                                                                                                                     |
| PI 6 | Actual application mode                                                        |     | Active operating mode (see PO 6)                                                                                                                                                                                                                                                          |
| PI 7 | Actual value voltage                                                           |     | Actual voltage A-side devices [ $10^{-1}$ V]                                                                                                                                                                                                                                              |
| PI 8 | Actual value voltage                                                           |     | Actual voltage B-side devices [ $10^{-1}$ V]                                                                                                                                                                                                                                              |

## 8 Error management

### 8.1 Error codes

#### 8.1.1 Device communication

| udiMessageID | Description                                                                                                                                                                                           |
|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 16#9000      | The process data channel could not be activated during the initialization of the function block. The device might not be connected to the SBUS <sup>PLUS</sup> or is not actively supplied with 24 V. |
| 16#9001      | The initialization of internal filters and blocks could not be completed.                                                                                                                             |
| 16#9002      | Certain parameters could not be read from the device during initialization. The SBUS <sup>PLUS</sup> might not be able to access the device.                                                          |
| 16#9003      | The initialization of the function block failed during the initial phase. It is possible that the license manager could not be initialized.                                                           |
| 16#9004      | The device signals a fault. The exact fault code of the device can be found in the "Inverter" structure.                                                                                              |
| 16#9005      | The device signals an active FCB (FunctionControlBlock) that is unknown to the control system. It is possible that the library version and the device firmware version do not match.                  |
| 16#9006      | The connected device is not compatible with the software module.                                                                                                                                      |
| 16#19001     | Communication error warning:<br>Process data could not be read from the device.                                                                                                                       |
| 16#19000     | The device signals a warning. You find the warning text in the "Inverter" structure.                                                                                                                  |

## Index

### A

Access rights ..... 24

### C

Concurrent access ..... 24

Configuration ..... 16, 17

Copyright notice ..... 6

### D

Decimal separator ..... 6

### E

Embedded safety notes ..... 6

EtherCAT®  
Beckhoff trademark ..... 6

### H

Hazard symbols  
Meaning ..... 6

### L

Licensing ..... 12

### M

Monitor access ..... 24

### N

Notes  
Designation in the documentation ..... 5

Meaning of the hazard symbols ..... 6

### P

Product names ..... 6

Project planning ..... 12

### R

Rights to claim under limited warranty ..... 6

### S

Safety notes

Bus systems ..... 8

Designation in the documentation ..... 5

Meaning of the hazard symbols ..... 6

Preliminary information ..... 8

Structure of embedded ..... 6

Structure of section-related ..... 5

Section-related safety notes ..... 5

Short designation ..... 7

Signal words in safety notes ..... 5

Startup ..... 13


### T


Target group ..... 8


Trademarks ..... 6

### U

Use, designated ..... 8









**SEW-EURODRIVE**  
Driving the world

**SEW**  
**EURODRIVE**

SEW-EURODRIVE GmbH & Co KG  
Ernst-Blickle-Str. 42  
76646 BRUCHSAL  
GERMANY  
Tel. +49 7251 75-0  
Fax +49 7251 75-1970  
sew@sew-eurodrive.com  
→ [www.sew-eurodrive.com](http://www.sew-eurodrive.com)