

MOVIDYN[®] Servo Controller

AFI 11A INTERBUS Option

User Manual

Edition 02/96



16/042/95

0922 7717 / 0499



SEW EURODRIVE

Preface

This *AFI 11A INTERBUS Option User Manual* describes the procedure for installing the *AFI 11A INTERBUS* option pcb in the servo controller and for commissioning the *MOVIDYN® 51..* servo controller when connected to an *INTERBUS* fieldbus system.

In addition to describing all the settings on the fieldbus option pcb, this manual further discusses the various options for connecting the servo controller to *INTERBUS* in the form of brief commissioning examples.

In addition to this *AFI 11A INTERBUS Option User Manual*, you should order the following more detailed documentation on fieldbuses in order to enable the *MOVIDYN® 51..* to be connected simply and efficiently to the *INTERBUS* fieldbus system

- *MOVIDYN® 51.. Fieldbus Unit Profile Manual*
- *MOVIDYN® 51.. Parameter List*

The *MOVIDYN® 51.. Fieldbus Unit Profile Manual* gives a detailed description of control concepts and discusses various application options in the form of brief examples.




The *MOVIDYN® 51.. Parameter List* contains a list of all the servo controller parameters that can be read or written via the various communication interfaces such as the RS-232, RS-485 and via the fieldbus interface.

Contents

| | |
|---|-----------|
| Important Instructions | 5 |
| 1. Introduction | 6 |
| 2. Assembly / Installation Instructions | 8 |
| 2.1. Scope of Delivery | 8 |
| 2.2. Supported Servo Controller Types | 8 |
| 2.3. Fitting the Option PCB | 8 |
| 2.4. Pin Assignment | 9 |
| 2.5. Screening and Laying of the Bus Cables | 10 |
| 2.6. Setting the Process Data Length | 11 |
| 2.7. Display Elements | 12 |
| 3. Configuring and Commissioning | 13 |
| 3.1. Commissioning of the Servo Controller | 13 |
| 3.1.1. Bus Topologies with MOVIDYN 51.. . . . | 14 |
| 3.1.2. Direct Connection to DCB Master Modules | 15 |
| 3.1.3. Connecting to DAB Master Modules | 15 |
| 3.1.4. Integration in 8-Wire Remote Bus Systems | 16 |
| 3.2. Servo Controller Module Identity | 17 |
| 3.3. Configuring the Master Module | 17 |
| 3.3.1. Configuring for 1 Process Data Word | 18 |
| 3.3.2. Configuring for 2 Process Data Words | 19 |
| 3.3.3. Configuring for 3 Process Data Words | 20 |
| 4. The PMS Interface | 21 |
| 4.1. PMS Services | 21 |
| 4.1.1. Initiate | 21 |
| 4.1.2. Abort | 22 |
| 4.1.3. Reject | 22 |
| 4.1.4. Identify | 22 |
| 4.1.5. Get-OV | 22 |
| 4.1.6. Status | 22 |
| 4.1.7. Read | 22 |
| 4.1.8. Write | 22 |
| 4.2. Object List | 23 |
| 4.2.1. Object Description of the Drive Parameters | 23 |
| 4.2.2. "Download Parameter Block" Object | 24 |
| 4.2.3. "Universal Write Parameter" Object | 25 |
| 4.2.4. "Universal-Read" Functionality Objects | 26 |
| 4.2.4.1. "Universal Read Pointer" Object | 28 |
| 4.2.4.2. "Universal Read Data" Object | 28 |
| 5. Parameter Adjustment Return Codes | 30 |
| 5.1. Internal Communications Error | 30 |
| 6. AFI 11A Option Technical Data | 31 |
| Appendix A | 32 |
| Index | 33 |

Important Instructions

- Please read this user manual carefully and thoroughly before installing and commissioning the MOVIDYN® servo controller with INTERBUS option.
It is assumed that engineers performing the work described within this user manual are familiar with the MOVIDYN® servo controller and especially with its installation and commissioning instructions.
- Safety Instructions
Strictly follow all warnings, precautions and safety instructions contained in this user manual.

| | |
|---|--|
|  | Electrical hazard, e.g. live working |
|  | Mechanical hazard, e.g. work on hoist |
|  | Important note for safe and trouble-free operation of the driven machine/system, e.g. presettings prior to commissioning. Failure to do so could result in serious injury to persons or damage to equipment. |

- **General safety instructions regarding bus systems:**
You are operating via a communications system which allows the MOVIDYN® servo controller to integrate within a wide range of equipment variations. As with all bus systems there exists a danger of unseen changes to parameters (in reference to the controller) and thereby controller behaviour. This can lead to unexpected (not uncontrolled) system behaviour.
- **Cross-references are identified in this user manual by an →, which means for example:**
(→ MD_SHELL) You can refer to the MD_SHELL user manual to complete the instructions or find more detailed information there.
(→ Sec. x.x) You will find additional information in section x.x of this user manual.
- Each unit is manufactured and tested in conformance with the applicable technical documentation by SEW-EURODRIVE. In the interest of technical progress, technical data and designs as well as the user interface described herein are subject to change without notice.
Follow the instructions contained in this manual to insure trouble-free operation and to satisfy eventual warranty claims. This manual also contains important service information. We therefore advise keeping it close to the unit.

1. Introduction

Thanks to its high-performance, universal fieldbus interface, the MOVIDYN® 51.. servo controller with the AFI 11A option enables connections to be made with higher-level automation systems via the open and standardized serial INTERBUS sensor/actuator bus system.

INTERBUS


INTERBUS is a high-speed universal sensor/actuator bus system for decentralized peripheral areas. The INTERBUS moves the input/output level away from the higher-level control system to the machine or the installation level. The INTERBUS is an open bus system, which is already supported by more than 200 equipment manufacturers from the most diverse industries. INTERBUS specifications are set forth in the DIN 19258 standard. INTERBUS bus functions comprise a process data and a parameter data channel offering easy, user-friendly control and parameter adjustment of intelligent digital actuators such as, e.g., servo controllers.

MOVIDYN® 51.. and INTERBUS

The controller unit profile for INTERBUS mode, i.e. the way the servo controller operates and responds when in INTERBUS mode, is independent of the type of fieldbus, and thus consistent for all fieldbus types. This allows the user to develop his drive applications independent of a particular fieldbus or change to another bus system, e.g. the open standardized PROFIBUS-DP/FMS (AFP 11A option) fieldbus system.

MOVIDYN® 51.. offers digital access to all drive parameters and functions via the INTERBUS interface. The servo controller is controlled by the high-speed cyclic process data. This process data channel provides the facility to specify setpoints such as setpoint speeds, ramp generator times for acceleration and deceleration etc., as well as various drive functions such as enable, controller inhibit, stop, rapid stop, etc. to be triggered. This channel can also be used to read back actual values from the servo controller, such as actual speed, current, unit status, error number or reference messages.

Whereas process data are generally exchanged in cycles, the drive parameters can only be read and written acyclically via the READ and WRITE services. This exchange of parameter data enables applications where all major drive parameters are stored in the higher-level automation unit to be implemented, thus avoiding manual adjustment of parameters on the servo controller itself, which can often be very time-consuming.



MD0337ED

Fig. 1: INTERBUS with MOVIDYN® 51..

The INTERBUS option pcb is designed so that all INTERBUS specific settings, such as the process data length, can be made on the option pcb by means of a hardware switch. These manual settings enable the servo controller to be integrated into the INTERBUS system and switched on in a very short space of time. Parameters can be set fully automatically by the higher-level INTERBUS master (parameter download). This forward-looking version offers benefits of a shorter commissioning period for the plant as well as simpler documentation of the application program, as all major drive parameter data can now be recorded directly in the control program.

The use of a fieldbus system in drive technology requires additional monitoring functions, such as fieldbus timeout or special emergency stop concepts. The monitoring functions of the MOVIDYN® 51.. can be matched to the specific application for which it is to be used. This feature enables you, for instance, to specify which error response the servo controller should trigger if an error should occur in the bus. A rapid stop will be practical for many applications, but it is also possible to freeze the last setpoints, so that the drive can continue with the last valid setpoints (e.g. conveyor belt). As the functionality of the control terminals is also ensured when the servo controller is operated in the fieldbus mode, fieldbus-independent emergency stop concepts can still be implemented via the servo controller's terminals.

The MOVIDYN® 51.. servo controller offers numerous diagnostic facilities for commissioning and servicing. For instance, both the setpoints transmitted from the higher-level control unit as well as the actual values can be checked with the integrated fieldbus monitor. It also provides you with a lot of additional information on the status of the fieldbus option pcb. The PC software MD_SHELL offers even more convenient diagnostic facilities in that it provides a detailed display of the fieldbus and unit status information as well as the facility to set all the drive parameters (including the fieldbus parameters).

2. Assembly/Installation Instructions

Unless the AFI 11A option is already installed in the MOVIDYN® 51.. servo controller, please check the scope of delivery for this option:

2.1. Scope of Delivery

The AFI 11A option comprises the following components:

- AFI 11A INTERBUS option pcb
- 1 housing cover

2.2. Supported Servo Controller Types

The AFI 11A option for connection to an *INTERBUS* system can be used with all servo controllers of the MOVIDYN® 51.. family.

To adjust the fieldbus parameters you need the MD_SHELL PC user interface, version V1.50!

2.3. Fitting the Option PCB

Please follow the instructions below when fitting the option pcb:

Before you start

Option pcbs

- Store in its original packaging and only take it out shortly before you fit it.
- Hold it by its edge and do not touch unnecessarily. Do not touch components.

Procedure for fitting the option pcb:

1. Ensure that the servo controller is voltage-free. Switch off the mains supply and, if connected, the external 24V supply.
2. Take off the black left front cover. Remove recessed head screws (2 screws).

Caution: When the unit cover is removed, the servo controller has enclosure IP00. Dangerous voltages may be present for up to ten minutes after the unit has been switched off!

3. Before you touch the pcb .take appropriate ESD measures (wrist strap, conductive shoes, etc).
4. Fit the option pcb with the backplane connector to the rear into the guide rails of the option pcb slot. Make sure that the pcb sits properly in the rear guide rails.
6. Push the backplane connector of the pcb into the socket in the housing. The sockets of the option pcb must be flush with the cover of the axis module.

6. Fit the supplied cover over the option pcb slot and fix with 2 screws.
7. Set the process data length with which you wish to operate the servo controller in the INTERBUS system on the DIP switches.
8. The AFI 11A option pcb is now completely fitted.




Fig. 2: The AFI 11A option

MD0338AE


Installation/Instructions:

When using the AFI11A Fieldbus option in a compact servo controller, the plastic front cover can no longer be mounted. To enclose all of the assembled electronic subassemblies, a front panel cover is included with the AFI11A option, which **must** be mounted to insure noise immunity.



2.4. Pin Assignment


On the AFI 11A option there is a 9-pin type D input (male) for the incoming remote bus and below a 9-pin type D output (female) for the outgoing remote bus. The MOVIDYN® 51.. servo controller is therefore connected to the INTERBUS sensor/actuator bus by a 9-pin type D connector on the remote bus cable. The onward remote bus cable is connected to the servo controller by a 9-pin type D connector. Fig. 3 shows the pin assignment of the 9-pin type D connector for the incoming remote bus as well as the bus cable signal lead colours used for the INTERBUS. Fig. 4 shows the pin assignment of the 9-pin type D connector for the onward remote bus. To prevent EMC problems, you should connect the copper screening braid of the outgoing remote bus to the equipotential bonding conductor or PE using the clamp provided (see Fig. 4).



MD0339AE

Fig. 3: Assignment of the 9-pin type D connector of the incoming remote bus cable

The MOVIDYN® 51.. servo controller is connected to the INTERBUS system via the 2-wire remote bus by a 6-core screened cable with twisted-pair signal leads. The 2-wire remote bus basically consists of an RS-485 Data Out channel (signal lines DO and /DO) as well as of the RS-485 Data In channel (signal lines DI and /DI).



MD0340AE

Fig. 4: Assignment of the 9-pin type D connector of the outgoing remote bus cable

2.5. Screening and Laying of the Bus Cables

The INTERBUS AFI 11A option pcb supports RS-485 transmission technology and requires as a physical medium the 6-core, screened, two-wire twisted-pair cable specified for INTERBUS.

Technically correct screening of the bus cable absorbs the electrical interference that can occur in an industrial environment. You will achieve the best screening results if you adopt the following measures:

- Hand-tighten the fixing screws of plugs, modules and equipotential bonding conductors.
- Only use plugs with metal or metal-plated housings.
- Connect the screening in the plug over as large an area as possible.
- Connect the screening at both ends of the bus cable.
- Do not lay signal and bus cables parallel to power cables (motor leads), but wherever possible in separate cable conduits.
- In an industrial environment use metallic, earthed cable trays.

- Run signal cables and the associated equipotential bonding conductor as close as possible to each other, using the shortest route.
- Avoid extending bus cables through the use of connectors.
- Run the bus cables close to existing earthed surfaces.

Important

In the event of fluctuations in the earth potential, a circulating current may flow through any screening which may be connected at both ends and connected to the earth potential (PE). In this case, ensure there is adequate equipotential bonding in accordance with the relevant VDE provisions.



In the event of further questions regarding the installation of the bus system, refer to the INTERBUS installation manual IBS SYS INST UM (Order No. 2754286, PHOENIX CONTACT), from which the points mentioned above were also taken.

2.6. Setting the Process Data Length

The MOVIDYN® 51.. servo controller communicates via INTERBUS with the higher-level control both via the rapid cyclical process data channel and via the acyclical parameter channel (PCP, Peripherals Communication Protocol). The number of process data words to be transmitted in the process data channel is variable and can be adjusted using the DIP switches on the AFI 11A option pcb (Fig. 5). In general you have a choice between one, two and three process data words. In all three cases, the servo controller can be parameterized at any time via the PCP channel.




Fig. 5: Setting the process data length in process data words

MD0341AE

An example of the DIP switch settings for all three data process lengths is shown in Fig. 6 below. Switches S3 and S4 are not allocated. These DIP switches are only evaluated when the servo controller is started up, i.e. when power is connected (mains and external 24V supply). This means that the servo controller has to be switched on again when the process data length is changed (mains and 24V).




Fig. 6: Examples for setting the process data length

MD0342AE

2.7. Display Elements

The AFI 11A option pcb has five LEDs for diagnosing the INTERBUS system. These LEDs provide information about the status of the INTERBUS system. Fig. 7 shows these diagnostic LEDs; the meaning of each is shown in Table 1.




Fig. 7: Diagnostic LEDs for INTERBUS

MD0343AE

| LED Name | Colour | Status | Meaning |
|------------|--------|-----------------|--|
| UL (green) | green | on | Logic voltage AFI 11A option pcb |
| RC (green) | green | on | Incoming remote bus ready for operation (remote bus link o.k.) |
| BA | green | on | Bus in operation |
| TR | green | on / flickering | Parameter data exchange via PCP channel |
| RD | red | on | Onward remote bus off |

Table 1: Meaning of the diagnostic LEDs for INTERBUS

3. Configuring and Commissioning

This section shows you how to configure and commission the MOVIDYN® 51.. servo controller with the AFI 11A option pcb in the INTERBUS master module.

3.1. Commissioning the Servo Controller

After installing the fieldbus option pcb the MOVIDYN® servo controller can be immediately parameterized via the fieldbus system without any other settings. This means, for example, that after switching on, all parameters can be downloaded directly from the higher-level control.

To control the servo controller via INTERBUS, however, it must first be switched to the appropriate setpoint source. This is possible using the P110 setpoint source = FIELDBUS parameter. The factory setting for this parameter is ANALOGUE INPUT. Using the INTERBUS parameter, the servo controller is programmed to accept setpoints from the INTERBUS. The MOVIDYN® servo controller now responds to process data sent from the higher-level control.


The activation of the FIELDBUS setpoint source is signalled to the higher-level control by the Fieldbus Mode Active bit in the status word.

For safety reasons, the servo controller must also be enabled on the terminal side as well to permit control via the fieldbus system. The terminals are therefore to be wired or programmed in such a way that the servo controller is enabled via the input terminals. The easiest way of enabling the servo controller on the terminal side is, for example, to connect input terminal X21.5 (/CONTROLLER INHIBIT function) to a +24V signal and program input terminals X21.6-8 to NO FUNCTION. Fig. 7 shows an example of the commissioning procedure for the MOVIDYN® 51.. servo controller with a fieldbus interface.

1. Switch on the output stage on the terminal side

Apply a +24V signal on input terminal X21.5 (/CONTROLLER INHIBIT function) (e.g. via jumper).

Use this jumper to switch on the output stage via the terminals!



2. Switch on the 24V supply

Switch on only the external 24V supply (not the mains supply!) to reprogram the servo controller to setpoint source "FIELDBUS" despite the installed jumper.

3. Input terminals X21.6 - 8 = NO FUNCTION

Program input terminals X21.6, X21.7 and X21.8 to NO FUNCTION

| | |
|------|--------------------------|
| P300 | MA (X21.6) = NO FUNCTION |
| P301 | MA (X21.7) = NO FUNCTION |
| P302 | MA (X21.8) = NO FUNCTION |

4. Setpoint Source = FIELDBUS

Program the setpoint source to FIELDBUS to control the servo controller via fieldbus.

| | |
|------|----------------------------|
| P110 | Setpoint source = FIELDBUS |
|------|----------------------------|

Fig. 8: Commissioning the MOVIDYN® 51.. servo controller

MD0244AE

For further information regarding the commissioning of the MOVIDYN® 51.. servo controller refer to the *Fieldbus Unit Profile Manual*.

3.1.1. Bus Topologies with MOVIDYN® 51..

The *AFI 11A* option pcb enables the MOVIDYN® 51.. servo controller to be integrated directly into the *INTERBUS* 2-wire remote bus. This results in much easier installation of the servo controller in the switch cabinet, for as the maximum remote bus length is 400 metres, the drives can also be installed further apart from each other without difficulty. As a result, the connecting costs are significantly reduced in comparison with an *INTERBUS* local bus interface, since no bus terminals are required any more for connecting the servo controller.

For historical reasons, the *INTERBUS* sensor/actuator bus distinguishes between two types of remote buses, both of which still exist today: the 8-wire and the 2-wire remote bus. The essential difference between the (older) 8-wire remote bus and the newer 2-wire remote bus is in the number of signal lines in the remote bus cable. Whereas there was a relatively large amount of wiring work required in preparing the 8-wire remote bus cable with its 25-pin connectors, 9-pin type D connectors can now be used with the 2-wire remote bus. With only 5 signal lines, these connectors can be quickly fitted to the remote bus cable.

The *IBS BK LC/2* bus terminal was developed to ensure as simple a transition as possible between these two types of remote bus. This terminal provides a simple and user-friendly way of converting from one type of remote bus to the other.

Different *INTERBUS* topologies involving *MOVIDYN*[®] 51.. are shown below as examples in which both types of remote bus are used.

3.1.2. Direct Connection to DCB Master Modules

The second generation *INTERBUS* master modules, such as the *IBS S5 DCB* module for Simatic S5, are always equipped with the 2-wire remote bus. Thus the servo controller can be connected directly to the DCB master module as shown in Fig. 8.




Fig. 9: Direct connection of the servo controller to DCB modules with 2-wire remote bus

MD0344AE

Since these DCB master modules generally support up to 256 remote bus stations, they are superbly suited for high-performance drive applications with many servo controllers.

3.1.3. Connecting to DAB Master Modules

First generation *INTERBUS* diagnostics interfaces (DAB), e.g. the *IBS S5 DAB* module for Simatic S5, only support the old 8-wire remote bus and 25-pin type D connector. *MOVIDYN*[®] 51.. servo controllers are connected by using a *IBS BK LC/2* bus terminal. This bus terminal makes possible the conversion from the old 8-wire remote bus to the new 2-wire system. Fig. 9 shows the connection of the *MOVIDYN*[®] 51.. to the DAB modules. A standard cable for 8-wire remote bus is employed from the DAB master module to the bus terminal. The connection from the bus terminal to the servo controller is achieved by an adapter cable from 25-pin type D to 9-pin type D.




Fig. 10: Connection of the servo controller to DAB master modules via IBS BK LC/2 bus terminal

MD0345AE

When using DAB master modules, take care not to exceed the maximum number of remote bus stations. These master modules with their 8-wire remote bus interface generally support up to 64 remote bus stations. More detailed information can be found in the master module documentation.

3.1.4. Integration in 8-Wire Remote Bus Systems

Conversion from both the 8-wire to the 2-wire remote bus, as well as from the 2-wire to the 8-wire remote bus, is achieved using the *IBS BK LC/2* bus terminal. This means, for example, that *MOVIDYN® 51..* servo controllers can also be integrated into existing INTERBUS networks employing the old 8-wire remote bus. Fig. 10 shows the integration options in an already existing system with an 8-wire remote bus.




Fig. 11: Integrating *MOVIDYN® 51..* servo controllers in already existing 8-wire remote bus systems

MD0346AE

MOVIDYN® 51.. servo controllers can be integrated into the existing 8-wire remote bus system at any point by splitting the 8-wire remote bus. This is done by feeding the incoming 8-wire remote bus to a *IBS BK LC/2* bus terminal. Using an appropriate adapter cable, you can now connect the first *MOVIDYN® 51..* servo controller to the bus terminal and network all the other servo controllers using the standard 2-wire remote bus cable. A further *IBS BK LC/2* bus terminal must then be connected following the last servo controller. This handles the conversion back to the 8-wire remote bus. Both the local bus interfaces of the newly inserted bus terminals can naturally also be used.

When extending an already existing *INTERBUS* 8-wire remote bus system, bear in mind that master modules with 8-wire remote bus interfaces generally support only 64 remote bus subscribers. More detailed information can be found in the master module documentation.

3.2. Servo Controller Module Identity

With the AFI 11A option, the MOVIDYN® 51.. is assigned the following identity code.

Module Ident: 227dec = E3hex

You must enter this identity code into the configuration list of the *INTERBUS* master module.

3.3. Configuring the Master Module

To initialize the *INTERBUS* master module, you must draw up various lists containing all the modules connected to the *INTERBUS*. These lists are made up of the following entries.

- Process data width with Module Ident code
- Peripheral bus address
- Input address
- Output address
- Group number (optional)
- Communication reference (optional)


The modules are shown in the configuration list in the order corresponding to their physical position in the *INTERBUS*. During the initialization of the bus system, the master module checks the planned bus configuration against the *INTERBUS* configuration read-in. If these configurations are different, the bus system will not start. This situation is indicated by an appropriate error message on the master module.

There are three initialization options for a MOVIDYN® 51.. servo controller with the AFI 11A option. Which option is used depends on the process data length selected.

While configuring, bear in mind that process data length 3 provides the most powerful application potential for the MOVIDYN® 51.. servo controller with *INTERBUS*. As a consequence of the direct insertion of process data into the I/O and/or peripheral area of the control, you should generally select process data length 3 if your application concept is not yet complete and if you do not definitely know with which process data length the servo controller is to be controlled.

3.3.1. Configuring for 1 Process Data Word

Setting the DIP switches on the option pcb to give process data length 1 requires that 1 process data word is specified in the ID code list. Fig. 11 shows examples of entries in the ID code list.



MD0347AE

Fig. 12: Example of ID code list with process data length set at 1

INTERBUS master modules for programmable controllers (e.g. IBS S5 DAB/DCB for Simatic S5) map the process data to the I/O and/or peripheral area of the control. You must therefore specify the start addresses for the input and output data in the I/O address list of the *INTERBUS* master module. Fig. 12 shows an example of how the process data word transferred via *INTERBUS* is mapped in the control.




Fig. 13: Process data word mapping in the PLC peripheral area

MD348AE

In this example, only one process data word is exchanged between the higher-level control and the servo controller. With this configuration, for example, the servo controller could be controlled using control word 1 and status word 1 (see SEW documentation *Fieldbus Unit Profile User Manual*). By specifying address 140 in both the input and output address list, the process data word is mapped to the peripheral word PW 140. The PLC access command will decide in this case whether the process input data word (e.g. status word 1 of the servo controller) is to be read with the load command L PW 140 or whether the process data output word (e.g. control word 1) is to be written with the transfer command T PW 140.


You can read out the current process data configuration on the servo controller at any time using the MD_SHELL user interface under item *P090 PD Configuration* on the PC. The MD_SHELL display value P090 now gives the message

090 PD Configuration 1PD+PARAM

and thereby signals that the current process data width is set at 1 PD and the servo controller can be parameterized via the PCP channel of the *INTER-BUS* (identification PARAM).

3.3.2. Configuring for 2 Process Data Words


Setting the DIP switches on the option pcb to give process data length 2 requires that 2 process data words are specified in the ID code list. Fig. 13 shows examples of entries in the ID code list.



MD0349AE

Fig. 14: Example of ID code list with process data length set at 2

With this setting, the servo controller uses two words in the peripheral area of the PLC. Fig. 14 shows an example of how the process data words transferred by *INTERBUS* are mapped in the control.



MD0350AE

Fig. 15: Process data word mapping in the PLC peripheral area

In this example, two process data words are exchanged between the higher-level control and the servo controller. With this configuration, for example, the higher-level control could send the process output data *Control Word 1* and *Speed Setpoint* to the servo controller and read the process input data *Status Word 1* and *Speed Actual Value* (see SEW documentation *Fieldbus Unit Profile User Manual*). By specifying address 140 in both the input and output address list, the process data words are mapped from peripheral word PW 140. The PLC access command will again decide whether the process input data words (e.g. status word and speed actual value) are to be read or whether the process data output words (e.g. control word and speed setpoint) are to be written. The *MD_SHELL* display value P090 now gives the message

090 PD Configuration 2PD+PARAM

and thereby signals that the current process data width is set at 2 PD and the servo controller can be parameterized via the PCP channel of the *INTERBUS* (identification PARAM).

3.3.3. Configuring for 3 Process Data Words

Setting the DIP switches on the option pcb to give process data length 3 requires that 3 process data words are specified in the ID code list. This configuration will allow you to implement very powerful drive applications. Fig. 16 shows examples of entries in the ID code list.




Fig. 16: Example of ID code list with process data length set at 3

MD0351AE

With this setting, the servo controller uses three words in the peripheral area of the PLC. Fig. 16 shows an example of how the process data words transferred by *INTERBUS* are mapped in the control.




Fig. 17: Process data word mapping in the PLC peripheral area

MD0352AE

In this example, three process data words are exchanged between the higher-level control and the servo controller. With this configuration, for example, the higher-level control could send the process output data *Control Word 1*, *Speed Setpoint* and *Process Ramp* to the servo controller and read the process input data *Status Word 1*, *Speed Actual Value* and *Apparent Current Actual Value* (see SEW documentation *Fieldbus Unit Profile User Manual*).

By specifying address 140 in both the input and output address list, the process data words are mapped from peripheral word PW 140. The PLC access command will again decide whether the process input data words are to be read or whether the process data output words are to be written.

MD_SHELL display value P090 now gives the message

090 PD Configuration 3PD+PARAM


and thereby signals that the current process data width is set at 3 PD and the servo controller can be parameterized via the PCP channel of the *INTERBUS* (identification PARAM).

4. The PMS Interface

The MOVIDYN® 51.. servo controller offers via the AFI 11A option a PMS (Peripherals Message Specification) interface conforming to the DIN 19245 Part 2. You can fully access all the drive parameters of the MOVIDYN® 51.. via this *INTERBUS* communication channel.

4.1. PMS Services

With the AFI 11A option, the MOVIDYN® 51.. servo controller supports the PMS services shown in Fig. 18.



MD0353AE

Fig. 18: PMS services supported by the MOVIDYN® 51.. servo controller

4.1.1. Initiate

With the PMS service Initiate (establish link), a communications link is established between an *INTERBUS* master and the MOVIDYN® 51.. servo controller.

The establishment of the link is always performed by the *INTERBUS* master. As the link is being established, various conventions regarding the communications link are checked, e.g. PMS services supported, user data length, etc. If the link is successfully established, the servo controller answers with a positive Initiate Response.

If the link could not be established, then the conventions regarding the communications link between the *INTERBUS* master and MOVIDYN® 51.. servo controller do not match. The servo controller will answer with an Initiate Error Response. In this event, compare the configured communications relationship list of the *INTERBUS* master with that of the servo controller (see section).

The attempt to establish an already existing communications link again generally leads to Abort. The communications link will then no longer exist so the PMS service Initiate will have to be performed a third time to reinstate the communications link.

4.1.2. Abort

An existing communications link between the *INTERBUS* master and the MOVIDYN® 51.. servo controller is cleared using the PMS service *Abort*. *Abort* is an unacknowledged PMS service and can be initiated both by the *INTERBUS* master as well as by the MOVIDYN® 51...

The attempt to establish an already existing communications link again generally leads to Abort. The communication link will then no longer exist so the PMS service *Initiate* will have to be performed a third time to reinstate the communications link.

4.1.3. Reject

With the PMS service *Reject*, the MOVIDYN® 51.. servo controller rejects an invalid PMS service. The servo controller uses this to signal to the *INTERBUS* master that a service is invalid or cannot be carried out.

4.1.4. Identify

With the PMS service *Identify*, the MOVIDYN® 51.. servo controller passes the following data to the *INTERBUS* master for definitive identification:

| | | |
|--------------|-----|--|
| vendor_name: | . | SEW-Eurodrive GmbH & Co |
| model_name: | . | MOVIDYN |
| revision: | . . | 821XXYYZZ (Number of servo controller system software) |

4.1.5. Get OV

With the PMS service *Get OV*, the *INTERBUS* master can retrieve the object description of the MOVIDYN® 51.. servo controller. In general all drive parameters are described as communications objects. More precise information about object descriptions can be found in Section 4.2. Object List.

The MOVIDYN® 51.. servo controller supports both the short as well as the long form of the PMS service *Get OV*.

4.1.6. Status

With the PMS service *Status*, the *INTERBUS* master can check the logical communications status of the *AFI 11A* option of the MOVIDYN® 51.. servo controller. The *Local Detail* attribute is not supported by the servo controller.

4.1.7. Read

With the PMS service *Read*, the *INTERBUS* master can read all the communications objects of the MOVIDYN® 51.. servo controller. All drive parameters as well as their codings are listed in detail in the documentation *MOVIDYN® 51.. Parameter List*.

4.1.8. Write

With the PMS service *Write*, the *INTERBUS* master can write all the drive parameters of the MOVIDYN® 51.. . If a drive parameter is assigned an invalid value (e.g. value too high), the servo controller generates a *Write Error Response* giving the precise cause of the error.

4.2. Object List

With the PMS services *Read* and *Write*, the *INTERBUS* master can access all the communications objects defined in the object.

All drive parameters that can be accessed via the bus system are described as communications objects in the static object list. All objects in the static object list are addressed via a fieldbus index. Table 2 shows the structure of the object list of the MOVIDYN® 51.. servo controller.

Normally, the whole object list is always generated when the servo controller is switched on. To also be able to guarantee full access to all parameters via *INTERBUS* if additional drive parameters are added in the future, the generated object list is larger than the number of drive parameters implemented. Access to objects that cannot be directly mapped to a drive parameter is rejected with a negative response.

The index area is divided into two logical areas. The drive parameters are addressed with indices from 1000_{dec}. The parameter index can be obtained from the SEW manual *MOVIDYN® 51.. Parameter List*. Indices below 1000_{dec} are handled directly by the option pcb and should not be regarded as drive parameters of the servo controller.

| Fieldbus index (decimal) | Name of the communications object |
|--------------------------|---|
| 996 | Download Parameter Block |
| 997 | Universal Write parameter |
| 998 | Universal Read Pointer |
| 999 | Universal Read parameter |
| 1000 + parameter index | Drive parameters for MOVIDYN® 51.. (Parameter index see SEW documentation MOVIDYN® 51.. Parameter List) |

Table 2: Structure of the MOVIDYN® 51.. static object list

4.2.1. Object Description of the Drive Parameters

The drive parameters of the MOVIDYN® 51.. servo controller are described in detail in the SEW documentation *MOVIDYN® 51.. Parameter List*. In addition to the parameter index, i.e. the number with which you can address the appropriate parameter via the communications interfaces of the servo controller, you will find further information about the coding, range of values and meaning of the parameter data.

To access all drive parameters via *INTERBUS*, you must add the value 1000_{dec} to the index shown in the parameter list to access the fieldbus index. In general, then, you can therefore read or write the drive parameters according to the formula:

$$\text{Fieldbus index} = \text{Parameter index} + 1000_{\text{dec}}$$


The object description in the object list is identical for all drive parameters. Even parameters that can only be read are given the attribute Read All/Write All in the object list, as the servo controller itself carries out the appropriate testing and if necessary supplies a return code. Table 3 shows the object descriptions of all drive parameters.

| | |
|-------------------|---------------------------------------|
| Index: | Parameter index + 1000 _{dec} |
| Object code: | 7 (Simple variable) |
| Data type index: | 10 (Octet string) |
| Length: | 4 |
| Local address: | - |
| Password: | - |
| Access groups: | - |
| Access rights: | Read all / Write all |
| Name[16]: | - |
| Extension length: | - |

Table 3: Object description of the MOVIDYN® 51.. drive parameters

4.2.2. Download-Parameter block object

The “Download Parameter Block” object enables a maximum of 38 MOVIDYN® 51.. drive parameters to be written at the same time with a single execution of the Write service. This means you can use this object to parameterize the servo controller in the start-up phase with only one Write service call. Since, as a rule, only a few parameters have to be altered, this parameter block with a maximum of 38 parameters is adequate for almost all applications. The user data area is fixed at 38 x 6 + 2 Byte = 230 Byte (octet string type). Fig. 19 shows the object descriptions of all drive parameters.



MD0354AE

Fig. 19: Structure of the Download Parameter Block object

The Download Parameter Block object is only handled locally on the fieldbus option pcb and is defined as shown in table 4.

| | |
|-------------------|---------------------|
| Index: | 996 |
| Object code: | 7 (Simple variable) |
| Data type index: | 10 (Octet string) |
| Length: | 230 |
| Local address: | - |
| Password: | - |
| Access groups: | - |
| Access rights: | Write all |
| Name[16]: | - |
| Extension length: | - |

Table 4: Definition of the Download Parameter Block object

With the WRITE service to the “Download Parameter Block” object, a parameterization mechanism is started in the fieldbus option pcb that successively sends all the parameters in the user data area of the object to the DPRAM, thus parameterizing the servo controller.

After successfully processing the Download Parameter Block, i.e. all parameters transferred from the *INTERBUS* master have been written, the Write service is ended with a positive Write Response. In the event of an error, a negative Write Response is returned. In this event, the return code will contain more precise details about the type of error and, in addition, the parameter number (1-38) where the error occurred (see Example 1).

```

Example 1: Error writing the 11th parameter
Write Error-Response:
Error Class: . . . 8 . . . Other
Error Code: . . . 0 . . . Other
Additional Code High: . . . 11dec Error writing parameter 11
Additional Code Low: . . . 15 hex Value too large

```


When using the Download Parameter Block, note the following:

- 1) Do not carry out any factory setting within the Download Parameter Block.
- 2) After deactivating the EEPROM memory function (change parameter to), all parameters subsequently written will not be memory-resident.
- 3) After activating the parameter lock, all parameters subsequently written will be rejected.

4.2.3. Universal Write Parameter Object

This object permits any parameter to be written, regardless of the size and content of the object list on the fieldbus option pcb.

The parameter value to be written is shown together with the index in a 10-byte data area of the Universal Write object. The parameter values can be four or eight bytes long depending on the drive parameter. The length can be obtained from the current parameter list for the respective unit. The parameter data must be entered left justified in every case (Fig. 20).



MD0355AE

Fig. 20: Structure of the “Universal Write” object

The “Universal Write” object is only handled locally on the fieldbus option pcb; i.e. it does not represent a drive parameter and is defined as shown in Table 5.

| | |
|-------------------|---------------------|
| Index: | 997 |
| Object code: | 7 (Simple variable) |
| Data type index: | 10 (Octet string) |
| Length: | 10 |
| Local address: | - |
| Password: | - |
| Access groups: | - |
| Access rights: | Write all |
| Name[16]: | - |
| Extension length: | - |

Table 5: Definition of the “Universal Write” object

4.2.4. “Universal Read” Functionality Objects

The Universal Read objects form the counterpart to Universal Write. The Universal Read objects permit indirect reading of any parameter independent of the object list being used. The execution of a Universal Read takes place in two steps using both the Universal Read Pointer and Universal Read Data objects.

In the “Universal Read Pointer” object, the desired fieldbus index to be read by the servo controller (read pointer) is first entered using the Write service. The value of the drive parameter is then read using the Read service via the “Universal Read Data” object. To avoid having to write the Read pointer again before reading consecutive parameters, the functionality of the Universal Read can also be carried out in what is known as auto-increment mode. Here, the Read pointer (“Universal Read Pointer” object) is increased by a predefined number each time it reads the “Universal Read Data” object. The number, together with the Read pointer, is set in the “Universal Read Pointer” object.

Fig. 21 shows an example of how Universal Read works without the auto-increment function.




Fig. 21: Universal Read service without auto-increment function

Fig. 22 shows an example of how Universal Read works using the auto-increment function.





Fig. 22: Universal Read service without auto-increment function

4.2.4.1. "Universal Read Pointer" Object

The Universal Read Pointer object contains within its 4 data bytes both the fieldbus index to be read as a read pointer as well as the number used in auto-increment mode. Fig. 23 shows the structure of this object.



MD0358AE

Fig. 23: Structure of the Universal Read Pointer parameter

When auto-increment mode is active (increment value greater than 0), the index is increased after reading the Universal Read Data object by the predefined increment value. The default value of this object is

Index: 1000_{dec}
Auto-increment: 0 = OFF


The auto-increment value is generally treated as having no sign, i.e. the value is generally added. The Universal Read Pointer object is only handled locally on the fieldbus option pcb and is defined as shown in Table 6.

| | |
|-------------------|----------------------|
| Index: | 998 |
| Object code: | 7 (Simple variable) |
| Data type index: | 10 (Octet string) |
| Length: | 4 |
| Local address: | - |
| Password: | - |
| Access groups: | - |
| Access rights: | Read all / Write all |
| Name[16]: | - |
| Extension length: | - |

Table 6: Definition of the "Universal Read Pointer" object

4.2.4.2. "Universal Read Data" Object

Accessing this parameter using the Read service returns the value of the read pointer held in the Universal Read Pointer object. Fig. 24 shows the structure of this object.



MD0359AE

Fig. 24: Structure of the Universal Read Data parameter

The length of the data can be determined from the SEW documentation *MOVIDYN® 51..* Parameter List. Data are generally entered left justified, i.e. beginning with the most significant byte in octet 1.

The Universal Read Data object is only handled locally on the fieldbus option pcb and is defined as shown in Table 7.

| | |
|-------------------|----------------------|
| Index: | 999 |
| Object code: | 7 (Simple variable) |
| Data type index: | 10 (Octet string) |
| Length: | 8 |
| Local address: | - |
| Password: | - |
| Access groups: | - |
| Access rights: | Read all / Write all |
| Name[16]: | - |
| Extension length: | - |

Table 7: Object description of the Universal Read Data parameter

5. Parameter Adjustment Return Codes

The return codes returned by the servo controller in the event of incorrect parameterization are clearly described in the Fieldbus Unit Profile Manual and are not part of this document. However, the following special case can arise in connection with *INTERBUS*.

5.1. Internal Communications Error

The return code listed in Table 8 is returned if a communications error has occurred between the option pcb and the servo controller system. The PMS service transferred by the fieldbus has possibly not been executed and should be repeated. If this error occurs repeatedly the servo controller must be switched off and then on again for reinitialization.

| | Code (dec) | Meaning |
|-----------------|------------|----------------|
| Error class: | 6 | Access |
| Error code: | 2 | Hardware fault |
| Add. code high: | 0 | - |
| Add. code low: | 0 | - |

Table 8: Return code for a communications error between fieldbus option pcb and servo controller

Error Rectification:

Repeat the Read or Write service. If an error recurs, you should briefly disconnect the servo controller from the mains supply and switch it on again. If the error persists, consult the SEW Service Department.

6. AFI 11A Option Technical Data


For use with MOVIDYN® 51..., configuration status: Circuit board 1 = service code 15 or higher

Module Ident: 227 dec = E3 hex

Number of process data words:

Selectable via DIP switch: 1, 2 or 3 process data words

Setting as supplied: 2 process data words



MD0341AE

Fig. 25: Setting the process data length in process data words

PCP channel:

Parameter setting is supported with one PCP word.

Connection technology:

2-wire remote bus interface, with 9-pin type D connectors

Pin assignment to INTERBUS specification

Commissioning tools:

MD_SHELL PC program, version V1.40 and higher

Appendix A

Even though the communications relationship list (KBL) of the MOVIDYN® 51.. servo controller complies with standard INTERBUS conventions, it is fully described in Table 9. The meaning of the individual KBL indications can be found in DIN 19245 Part 2.

| KR | Type | ATTR | RADR | SCG | RCC | SAC | RAC | ACI/CCI |
|----|------|------|------|-----|-----|-----|-----|---------|
| 0 | MMAZ | D | 0 | 1 | 1 | 1 | 1 | 0 |

| max PDU Size: | | Features supported | Supported PMS services |
|---------------|-----|--------------------|------------------------|
| Send HiPrio | 0 | 00 00 00 00 80 30 | Get-OV.indication |
| Send LoPrio | 243 | | Read.indication |
| Rec. HiPrio | 0 | | Write.indication |
| Rec. LoPrio | 243 | | |

| | |
|---|---------------------|
| Max. number of outstanding client services: | 1 |
| Max. number of outstanding server services: | 1 |
| Type of communication: | Connection oriented |

Table 9: INTERBUS KBL for MOVIDYN® 51.. with AFI 11A option

Index

- Bus topologies, 14
- Commissioning, 12
- Communications interface, 21
- Configuring, 12
- DAB master module, 15
- DCB master module, 14
- Diagnosis
 - *INTERBUS* application, see
Fieldbus Unit Profile User Manual
 - with the option pcbs LEDs, 10
- Display elements, 10
- Documentation on fieldbus connection, 1
- Download parameter block, 25
- Equipotential bonding, 9
- Features of the *INTERBUS* interface, 3
- Fieldbus index, 24
- Ident code, 16
- Installation
 - Fitting the option pcb, 5
 - of the *INTERBUS* system, 8
- LEDs, 10
- Module Ident, 16
- MOVIDYN® 51.. settings
 - Commissioning with fieldbus, 13
 - Terminal assignment for fieldbus mode, 12
- Parameter adjustment
 - Abort, 22
 - Download Parameter Block, 25
 - Error, 30
 - Initiate, 21
 - of the drive parameters, 24
 - Read, 23
 - Services, 21
 - Universal Read, 27
 - Universal Write, 26
 - Write, 23
- Pin assignment, 7
- PMS interface, 21
- Process data length, 9
 - 1PD, 17
 - 2PD, 18
 - 3 PD, 19
- Read, 23
- Remote bus
 - 8-wire remote bus, 15
- Return codes, 30
- Scope of delivery, 5
- Write, 23

Service and spare parts



| | | | | |
|----------------------|--|---|--|--|
| Germany | Headquarters Manufacture Sales, Service | Bruchsal | SEW-EURODRIVE GmbH & Co Ernst-Blickle-Straße 42 D-76646 Bruchsal Postfach 3023, D-76642 Bruchsal | Tel. (0 72 51) 75-0 Telefax (0 72 51) 75-19 70 Telex 7 822 391 http://www.SEW-EURODRIVE.com sew @ sew-eurodrive.com |
| | Manufacture | Graben | SEW-EURODRIVE GmbH & Co Ernst-Blickle-Straße 1 D-76676 Graben-Neudorf Postfach 1220, D-76671 Graben-Neudorf | Tel. (0 72 51) 75-0 Telefax (0 72 51) 75-29 70 Telex 7 822 276 |
| | Assembly Service | Garbsen (near Hannover) | SEW-EURODRIVE GmbH & Co Alte Ricklinger Straße 40-42 D-30823 Garbsen Postfach 110453, D-30804 Garbsen | Tel. (0 51 37) 87 98-30 Telefax (0 51 37) 87 98-55 |
| | | Kirchheim (near München) | SEW-EURODRIVE GmbH & Co Domagkstraße 5 · D-85551 Kirchheim | Tel. (0 89) 90 95 52-10 Telefax (0 89) 90 95 52-50 |
| | | Langenfeld (near Düsseldorf) | SEW-EURODRIVE GmbH & Co Siemensstraße 1, D-40764 Langenfeld | Tel. (0 21 73) 85 07-30 Telefax (0 21 73) 85 07-55 |
| | | Meerane (near Zwickau) | SEW-EURODRIVE GmbH & Co Dänkritzer Weg 1, D-08393 Meerane | Tel. (0 37 64) 76 06-0 Telefax (0 37 64) 76 06-30 |
| France | Headquarters Manufacture Service | Haguenau | SEW-USOCOME S.A 48-54, route de Soufflenheim B. P. 185 F-67506 Haguenau Cedex | Tel. 03 88 73 67 00 Telefax 03 88 73 66 00 Telex: 870 033 http://www.usocome.com sew@usocome.com |
| | Manufacture | Forbach | SEW-EUROCOME S.A. Zone industrielle Technopole Forbach Sud B. P. 30269, F-57604 Forbach Cedex | |
| | Assembly Service Technical Offices | Bordeaux | SEW-USOCOME Parc d'activités de Magellan 62, avenue de Magellan - B. P.182 F-33607 Pessac Cedex | Tel. 05 57 26 39 00 Telefax 05 57 26 39 09 |
| | | Paris | SEW-USOCOME Zone industrielle, 2, rue Denis Papin F-77390 Verneuil l' Etang | Tel. 01 64 42 40 80 Telefax 01 64 42 40 88 |
| Australia | Assembly Sales, Service | Melbourne | SEW-EURODRIVE PTY. LTD. 27 Beverage Drive Tullamarine, Victoria 3043 | Tel. (03) 93 38-79 11 Telefax (03) 93 30-32 31 + 93 35 35 41 |
| | | Sydney | SEW-EURODRIVE PTY. LTD. 9, Sleigh Place, Wetherill Park Sydney N. S. W. 2164 | Tel. (02) 97 56 10 55 Telefax (02) 97 56 10 05 |
| Austria | Assembly Sales, Service | Wien | SEW-EURODRIVE Ges.m.b. H. Industriestraße B4 A-2345 Brunn a. Geb. bei Wien | Tel. (0 22 36) 3 16 31 Telefax (0 22 36) 3 33 85 |
| Belgium | Assembly Sales, Service | Bruxelles | CARON-VECTOR S.A. Avenue Eiffel 5 B-1300 Wavre | Tel. (010) 23 13 11 Telefax (010) 23 13 36 http://www.caron-vector.be info@caron-vector.be |
| Brazil | Manufacture Sales, Service | São Paulo | SEW DO BRASIL Motores-Redutores Ltda. Caixa Postal 201-0711-970 Rodovia Presidente Dutra km 213 CEP 07210-000 Guarulhos-SP | Tel. (011) 64 60-6433 Telefax (011) 64 80-43 43 E-Mail: sew.brasil@originet.com.br |
| Canada | Assembly Sales, Service | Toronto | SEW-EURODRIVE CO. OF CANADA LTD. 210 Walker Drive, Bramalea, Ontario L6T3W1 | Tel. (905) 7 91-15 53 Telefax (905) 7 91-29 99 |
| | | Vancouver | SEW-EURODRIVE CO. OF CANADA LTD. 7188 Honeymann Street, Delta. B.C. V4G 1 E2 | Tel. (604) 2 72 42 88 + 9 46 55 35 Telefax (604) 946-2513 |
| | | Montreal | SEW-EURODRIVE CO. OF CANADA LTD. 2555 Rue Leger Street LaSalle, Quebec H8N 2V9 | Tel. (514) 3 67-11 24 Telefax (514) 3 67-36 77 |
| Chile | Assembly Sales, Service | Santiago de Chile | SEW-EURODRIVE CHILE Motores-Redutores LTDA. Panamericana Norte Nº 9261 Casilla 23-Correo Quilicura RCH-Santiago de Chile | Tel. (02) 6 23 82 03 + 6 23 81 63 Telefax (02) 6 23 81 79 |
| China | Manufacture Assembly Sales, Service | Tianjin | SEW-EURODRIVE (Tianjin) Co., LTD No. 46, 7th Avenue, TEDA Tianjin 300457 | Tel. (022) 25 32 26 12 Telefax (022) 25 32 26 11 |
| Denmark | Assembly Sales, Service | Kopenhagen | SEW-EURODRIVE A/S Geminivej 28-30, P.O. BoX 100 DK-2670 Greve | Tel. 4395 8500 Telefax 4395 8509 |
| Finland | Assembly Sales, Service | Lahti | SEW-EURODRIVE OY Vesimäentie 4, FIN-15860 Hollola2 | Tel. (3) 58 93 00 Telefax (3) 7 80 62 11 |
| Great Britain | Assembly Sales, Service | Normanton | SEW-EURODRIVE Ltd. Beckbridge Industrial Estate P.O. Box No.1 GB-Normanton, West-Yorkshire WF61 QR | Tel.1 /9 24 89 38 55 Telefax 1 /9 24 89 37 02 |
| Hong Kong | Assembly Sales, Service | Hong Kong | SEW-EURODRIVE LTD. Unit No.801-806, 8th Floor Hong Leong Industrial Complex No. 4, Wang Kwong Road Kowloon, Hong Kong | Tel. 2-7 96 04 77 + 7 96 04 65 Telefax 2-795-91 29 |

Service and spare parts



| | | | | |
|---------------------|--|------------------------|---|---|
| Italy | Assembly Sales, Service | Milano | SEW-EURODRIVE di R. Blickle & Co. s.a.s. Via Bernini, 14 I-20020 Solaro (Milano) | Tel. (02) 96 79 97 71 Telefax (02) 96 79 97 81 |
| Japan | Assembly Sales, Service | Toyoda-cho | SEW-EURODRIVE JAPAN CO., LTD. 250-1, Shimoman-no, Toyoda-cho, lwata-gun Shizuoka prefecture, P.O. Box 438-0818 | Tel. (053 83) 7 38 11-13 Telefax (053 83) 7 38 14 |
| Korea | Assembly Sales, Service | Ansan | SEW-EURODRIVE CO., LTD. B 601-4, Banweol Industrial Estate 1048-4, Shingil-dong, Ansan 425-120 | Tel. (03 45) 4 92-80 51 Telefax (03 45) 4 92-80 56 |
| Malaysia | Assembly Sales, Service | Johore | SEW-EURODRIVE Sdn. Bhd. 95, Jalan Seroja 39 81100 Johore Bahru, Johore | Tel. (07) 3 54 57 07 + 3 54 94 09 Telefax (07) 3 5414 04 |
| Netherlands | Assembly Sales, Service | Rotterdam | VECTOR Aandrijftechniek B.V. Industrieweg 175 NL-3044 AS Rotterdam Postbus 10085, N L-3004 AB Rotterdam | Tel. (010) 4 46 37 00 Telefax (010) 4 15 55 52 |
| New Zealand | Assembly Sales, Service | Auckland | SEW-EURODRIVE NEW ZEALAND LTD. P.O. Box 58-428 82 Greenmount Drive, East Tamaki, Auckland | Tel. (09) 2 74 56 27 2 74 00 77 Telefax (09) 2 74 01 65 |
| Norway | Assembly Sales, Service | Moss | SEW-EURODRIVE A/S Solgaard skog 71, N-1539 Moss | Tel. (69) 24 10 20 Telefax (69) 24 10 40 |
| Portugal | Assembly Sales, Service | Coimbra | SEW-EURODRIVE, LDA. Apartado 15, 3050 Mealhada | Tel. (031) 20 96 70 Telefax (031) 20 36 85 |
| Singapore | Assembly Sales, Service | Singapore | SEW-EURODRIVE PTE. LTD. No 9, Tuas Drive 2, Jurong Industrial Estate Singapore 638644 Jurong Point Post Office, P.O. Box 813 Singapore 916428 | Tel. 86 21 701-705 Telefax 8 61 28 27 Telex: 38 659 |
| South Africa | Assembly Sales, Service | Johannesburg | SEW-EURODRIVE (PROPRIETARY) LIMITED Eurodrive House Cnr. Adcock Ingram and Aerodrome Roads Aeroton Ext. 2, Johannesburg 2013 P.O. Box 27032, 2011 Benrose, Johannesburg | Tel. (2711) 4 94 43 80 Telefax (2711) 4 94 23 00 |
| | | Capetown | Gearedmotors of South Africa Pty. Ltd. No.1 Cor. Voortrekker & Beach Roads, P.O. Box 28 7405 Maitland, Cape | Tel. (021) 5 11 09 87 Telefax (021) 5 11 44 58 Telex: 576 062 |
| | | Durban | Gearedmotors of South Africa Pty. Ltd. 39 Circuit Road, Westmead, Pinetown P.O. Box 10433, Ashwood 3605 | Tel. (031) 7 00 34 51 Telex: 622 407 |
| Spain | Assembly Sales, Service | Bilbao | SEW-EURODRIVE ESPAÑA, S.L. Parque Tecnológico, Edificio, 302 E-48170 Zamudio (Vizcaya) | Tel. 9 44 31 84 70 Telefax 9 44 31 84 71 |
| Sweden | Assembly Sales, Service | Jönköping | SEW-EURODRIVE AB Gnejsvägen 6-8 S-55303 Jönköping | Tel. (036) 16 50 70 Telefax (036) 16 44 69 Telex: 70162 |
| Switzerland | Assembly Sales, Service | Basel | Alfred Imhof A.G. Jurastrasse 10 CH-4142 Münchenstein bei Basel | Tel. (061) 4 17 17 17 Telefax (061) 4 17 17 00 Telex: 963 231 |
| Thailand | Assembly | Chon Buri | SEW-EURODRIVE (Thailand) Ltd. Bangpakong Industrial Park 2 700/456, M007, Tambol Bonhuroh Muang District, Chon Buri 20000 | Tel. 0066-38 21 45 29/30 Telefax 0066-38 21 45 31 |
| Turkey | Assembly Sales, Service | Istanbul | SEW-EURODRIVE Hareket Sistemleri Ticaret Ltd. Sirketi Bagdat Cad. Koruma Cikmazi No. 3 TR-81540 Maltepe ISTANBUL | Telefon (216) 4 41 91 63 + 4 41 91 64 + 3 83 80 14 + 3 83 80 15 Telefax (216) 3 05 58 67 |
| USA | Manufacture Assembly Sales, Service | Greenville | SEW-EURODRIVE INC. 1275 Old Spartanburg Highway P.O. Box 518 Lyman, S.C. 29365 | Tel. (864) 4 39-75 37 Telefax Sales (864)439-78 30 Telefax Man. (864) 4 39-99 48 Telefax Ass. (864) 4 39-05 66 Telex: 805 550 |
| | | San Francisco | SEW-EURODRIVE INC. 30599 San Antonio Road P.O. Box 3910, Hayward California 94544 | Tel. (510) 4 87-35 60 Telefax (510) 4 87-63 81 |
| | Assembly Sales, Service | Philadelphia/PA | SEW-EURODRIVE INC. Pureland Ind. Complex 200 High Hill Road, P.O. Box 481 Bridgeport, New Jersey 08014 | Tel. (609) 4 67-22 77 Telefax (609) 8 45-31 79 |
| | | Dayton | SEW-EURODRIVE INC. 2001 West Main Street Troy, Ohio 45373 | Tel. (513) 3 35-00 36 Telefax (513) 2 22-41 04 Telex: 6 874 204 |
| | | Dallas | SEW-EURODRIVE INC. 3950 Platinum Way, Dallas, Texas 75237 | Tel. (214) 3 30-48 24 Telefax (214) 3 30-47 24 |
| Venezuela | Assembly Sales, Service | Caracas | Edif. Asea Brown Boveri Av. Diego Cisneros Los Ruices | Tel. (02) 2 39 64 33 + 2 38 24 22 + 2 38 24 11 Telefax (02) 2 39 63 83 + 2 39 58 34 Telex: 2 52 49 + 2 52 65 |

We are available, wherever you need us.
Worldwide.

SEW-EURODRIVE right around the globe is
your competent partner in matters of power

transmission with manufacturing and assem-
bly plants in most industrial countries.



SEW
EURODRIVE

EW-EURODRIVE GmbH & Co · P.O.Box 30 23 · D-76642 Bruchsal/Germany
Tel. +49-7251-75-0 · Fax +49-7251-75-19 70 · Telex 7 822 391
<http://www.ew-eurodrive.com> · sew@sew-eurodrive.com