




# Operating Instructions



## **Safety-Relevant BST Brake Module** for control cabinet installation





## Contents

<b>1</b>	<b>General Information .....</b>	<b>5</b>
1.1	How to use the operating instructions .....	5
1.2	Structure of the safety notes .....	5
1.3	Rights to claim under limited warranty .....	6
1.4	Exclusion of liability .....	6
1.5	Copyright notice .....	6
<b>2</b>	<b>Safety Notes .....</b>	<b>7</b>
2.1	Preliminary information .....	7
2.2	General information .....	7
2.3	Target group .....	8
2.4	Designated use .....	8
2.5	Transport .....	8
2.6	Installation/assembly .....	8
2.7	Startup/operation .....	9
2.8	Inspection/maintenance .....	9
2.9	Disposal .....	9
<b>3</b>	<b>Integrated Safety Technology .....</b>	<b>10</b>
3.1	Safe condition .....	10
3.2	Safety concept .....	10
3.3	Safety function .....	11
3.4	Restrictions .....	12
<b>4</b>	<b>Safety-Relevant Conditions .....</b>	<b>13</b>
4.1	Permitted unit combinations .....	13
4.2	Requirements on the installation .....	14
4.3	Requirements on external safety controller .....	16
4.4	Requirements on startup .....	17
4.5	Requirements on the operation .....	18
<b>5</b>	<b>Unit Design .....</b>	<b>19</b>
5.1	Nameplate, unit designation .....	19
5.2	Scope of delivery of BST .....	19
5.3	Safety-relevant BST brake module .....	20
5.4	Terminal assignment .....	20
<b>6</b>	<b>Installation .....</b>	<b>21</b>
6.1	Mechanical installation .....	21
6.2	Electrical installation .....	23
<b>7</b>	<b>Startup .....</b>	<b>26</b>
7.1	Operating states .....	26
<b>8</b>	<b>Inspection/Maintenance .....</b>	<b>27</b>
8.1	Inspection and maintenance intervals .....	27
8.2	Checking the brake function .....	28
8.3	Service .....	28
8.4	Unit replacement procedure .....	28



## Contents

<b>9</b>	<b>Applications</b> .....	<b>29</b>
9.1	Disconnection of single drives via inverter (MOVIDRIVE® B as example).....	30
9.2	Disconnection of single drives via inverter (MOVIAXIS® as example).....	31
9.3	Disconnection of single drives via inverter and DFS11B/21B fieldbus interface.....	32
9.4	Group disconnection via inverter .....	33
<b>10</b>	<b>Technical Data</b> .....	<b>34</b>
10.1	General technical data .....	34
10.2	Safety-related control voltage .....	35
10.3	Safety-related characteristic values .....	35
10.4	Dimension drawing of BST in control cabinet design.....	36
<b>11</b>	<b>Supply Module for BST (in preparation)</b> .....	<b>37</b>
11.1	Nameplate.....	37
11.2	Technical data.....	37
11.3	Terminal assignment.....	37
11.4	Wiring diagram.....	38
11.5	Dimension drawings.....	39
<b>12</b>	<b>Address List</b> .....	<b>40</b>
	<b>Index</b> .....	<b>50</b>



# 1 General Information


## 1.1 How to use the operating instructions







The operating instructions are an integral part of the product and contain important information for operation and service. The operating instructions are written for all persons who assemble, install, start up, and service this product.

The operating instructions must be legible and accessible at all times. Make sure that staff responsible for the plant and its operation, as well as persons who work independently on the unit, have read the operating instructions carefully and understood them. If you are unclear about any of the information in this documentation, or if you require further information, contact SEW-EURODRIVE.

## 1.2 Structure of the safety notes

The safety notes in these operating instructions are designed as follows:

Pictogram	! SIGNAL WORD
	<p>Type and source of danger.</p> <p>Possible consequence(s) if the safety notes are disregarded.</p> <ul style="list-style-type: none"> <li>• Measure(s) to prevent the danger.</li> </ul>

Pictogram	Signal word	Meaning	Consequences if disregarded
<p>Example:</p>  <p>General danger</p>  <p>Specific danger, e.g. electric shock</p>	<p> <b>DANGER</b></p> <p> <b>WARNING</b></p> <p> <b>CAUTION</b></p> <p><b>NOTICE</b></p>	<p>Imminent danger</p> <p>Possible dangerous situation</p> <p>Possible dangerous situation</p> <p>Possible damage to property</p>	<p>Severe or fatal injuries</p> <p>Severe or fatal injuries</p> <p>Minor injuries</p> <p>Damage to the drive system or its environment</p>
	<b>TIP</b>	<p>Useful information or tip. Simplifies the handling of the drive system.</p>	

**1.3 Rights to claim under limited warranty**

A requirement of fault-free operation and fulfillment of any rights to claim under limited warranty is that you adhere to the information in the operating instructions. Therefore, read the operating instructions before you start working with the unit

**1.4 Exclusion of liability**

You must comply with the information contained in these operating instructions to ensure safe operation of the BST and to achieve the specified product characteristics and performance features. SEW-EURODRIVE assumes no liability for injury to persons or damage to equipment or property resulting from non-observance of these operating instructions. In such cases, any liability for defects is excluded.

**1.5 Copyright notice**

© 2009 - SEW-EURODRIVE. All rights reserved.

Copyright law prohibits the unauthorized duplication, modification, distribution, and use of this document, in whole or in part.



## **2 Safety Notes**

The following basic safety notes must be read carefully to prevent injury to persons and damage to property. The operator must ensure that the basic safety notes are read and observed. Make sure that persons responsible for the plant and its operation, as well as persons who work independently on the unit, have read through the operating instructions carefully and understood them. If you are unclear about any of the information in this documentation, or if you require further information, please contact SEW-EURODRIVE.

### **2.1 Preliminary information**

This document contains safety-related conditions for the operation of the safety-relevant BST brake module with safe disconnection of the brake.

The classification to category 3 according to EN 954-1, or performance level d according to EN ISO 13849-1 applies to the control and not to the brake.

### **2.2 General information**

Never install or start up damaged products. Submit a complaint to the shipping company immediately in the event of damage.

All work related to transportation, storage, setup/mounting, connection, startup, maintenance and repair may only be carried out by qualified personnel, in strict observation of:

- The relevant detailed operating instructions
- The warning and safety signs
- All other project planning documents, operating instructions and wiring diagrams related to the drive
- The specific regulations and requirements for the system
- The national/regional regulations governing safety and the prevention of accidents

The requirements for the safety switching device and the permitted circuit variants are specified in detail in section "Requirements for external safety switching devices" (see page 16) and must be strictly observed.

The system/machine manufacturer must perform a system/machine-specific risk analysis. This is to take into account the safety-relevant BST brake module as well as the mechanical brake design.

Removing covers without authorization, improper use as well as incorrect installation or operation may result in severe injuries to persons or damage to property.

Refer to the documentation for additional information.



### **2.3 Target group**

Only qualified personnel is allowed to perform installation, startup, fault repair and servicing (observe IEC 60364 or CENELEC HD 384 or DIN VDE 0100 and IEC 60664 or DIN VDE 0110 as well as national accident prevention guidelines).

Qualified electricians in the context of these basic safety notes are persons familiar with installation, assembly, startup and operation of the product who possess the required qualifications.

Any activities regarding transportation, storage, operation, and disposal must be carried out by persons who have been instructed appropriately.

### **2.4 Designated use**

The safety-relevant BST brake module is responsible for the power supply and control of disk brakes from SEW-EURODRIVE. For the permitted combination of safety-relevant BST brake module and SEW disk brake, refer to the section "Permitted unit combinations" in the "Safety-Relevant Conditions" chapter. The safety-relevant BST brake module is intended for industrial systems and may only be used in accordance with the information provided in SEW-EURODRIVE's technical documentation and the information given on the nameplate.

### **2.5 Transport**

Inspect the shipment for any damage that may have occurred in transit as soon as you receive the delivery. Inform the shipping company immediately. It may be necessary to preclude startup.

### **2.6 Installation/assembly**

Observe the notes in section "Mechanical Installation" (see page 21).





## **2.7 Startup/operation**

- When the safety-related control voltage  $V_{24\text{ V safe}}$  / functional control voltage  $V_{24\text{ V in}}$  is disconnected, the DC link voltage  $V_{\text{DC link}}$  is still present at the brake module.
- The safety concept is only suitable for performing mechanical work on the system / machine components.
- All poles must be disconnected from the supply system when work is carried out on the electrical section of the system. Dangerous voltages may still be present for up to 10 minutes after disconnection from the power supply source.
- You have to take into account that, in case of a fault, the application time of the connected brake is longer, which means the drive might coast.
  - For maximum brake application times, refer to chapter "Technical Data" of the operating instructions for the BST and SEW disk brakes.
  - Note: If coasting to a halt results in application-dependent hazards, take additional protective measures (e.g. movable covers with closure), which cover the hazardous area until persons are no longer in danger.
  - The additional protective covers must be designed and integrated to meet the requirements stipulated in EN ISO 12100-1 and the requirements determined for the machine based on the risk analysis.
  - After activating the stop command, access to the machine must remain blocked until the drive has reached standstill, or the access time has to be determined to ensure that an adequate safety distance is maintained.
- The conditions of LED V1 and LED V2 must not be regarded as safety-relevant. The fact that the LED V1 and LED V2 are no longer illuminated does not indicate that the safety-relevant BST brake module is de-energized and the brake is applied. Even if LED V1 and LED V2 are not illuminated, DC link voltage  $V_{\text{DC link}}$  might be present at the BST brake module.

## **2.8 Inspection/maintenance**

Observe the notes in chapter "Inspection/Maintenance" (see page 27).

## **2.9 Disposal**

Dispose the BST in accordance with the material structure and the regulations in force for instance as:

- Iron
- Copper
- Aluminum
- Plastic



### 3 Integrated Safety Technology

The safety technology of the safety-relevant BST brake module described in this document has been developed and tested in accordance with the following safety requirements:

- Category 3 according to EN 954-1
- Performance level d according to EN ISO 13849-1

This was certified by TÜV Nord. Copies of the TÜV certificate and the corresponding report are available from SEW-EURODRIVE on request.

#### 3.1 Safe condition


Safety-relevant use of the BST brake module means the **de-energized condition of the connected brake is defined as safe condition**. This is the basis for the safety concept.

#### 3.2 Safety concept

- The safety-relevant BST brake module enables the connection of an external fail-safe safety switching device/safety controller. The safety switching device disconnects the safe control voltage  $V_{24\text{ V safe}}$  when a connected control device (e.g. emergency stop device) is activated.
- Disconnecting the safe control voltage  $V_{24\text{ V safe}}$  means the connected brake is disconnected from the power supply. The power supply required for releasing the connected brake is interrupted safely.
- Instead of separating the brake control galvanically from the power supply using contactors or switches, the disconnection procedure described here prevents the power semiconductors in the safety-relevant BST brake module from being activated, in this way ensuring safe disconnection. This means that all connected brakes are de-energized although the supply voltage is still present at the safety-relevant BST brake module.



### 3.2.1 Block diagram BST



1869444491

- [1] DC link voltage input  $V_{DC \text{ link}}$  (terminal 1/2)
- [2] Brake output (terminals 13/14/15)
- [3] Functional control voltage input  $V_{24 \text{ V in}}$  (terminal 3/4)
- [4] Safety-relevant control voltage input  $V_{24 \text{ V safe}}$  (terminal 5/6)

### 3.3 Safety function

The following drive-related safety function can be used:

- **SBC** (Safe Brake Control according to IEC 61800-5-2)

The SBC function safely de-energizes the connected brake by disconnecting the safety-relevant control voltage  $V_{24 \text{ V safe}}$ . The safety-relevant control voltage must be disconnected using a suitable external safety switching device/safety controller.



#### TIP

Safety-relevant brake control must be carried out using the safety-relevant control voltage  $V_{24 \text{ V safe}}$  (terminal 5/6) only.



### 3.4 Restrictions

	<p><b>! DANGER</b></p> <p>Voltage is still present at the DC link connection of the frequency inverter even when disconnecting the safety-relevant control voltage <math>V_{24\text{ V safe}}</math> / functional control voltage <math>V_{24\text{ V in}}</math>.</p> <p>Severe or fatal injuries from electric shock.</p> <ul style="list-style-type: none"> <li>• If work is carried out on the electrical section of the brake system, the supply voltage must be disconnected using an external maintenance switch.</li> </ul>
	<p><b>TIP</b></p> <ul style="list-style-type: none"> <li>• The safety concept is only suitable for performing mechanical work on the system / machine components.</li> <li>• A system/machine-specific risk analysis must be carried out by the system/ machine manufacturer and be observed when using the drive system with BST.</li> </ul>



## **4 Safety-Relevant Conditions**

The safety function of BST can only be used for safe operation of the system/machine if it is integrated correctly in an application-specific, higher-level safety function or safety system. It is essential that the system/machine manufacturer conducts a system/machine-specific risk analysis (e.g. according to EN ISO 14121) and validates the required safety conditions and functions prior to startup. The system/machine manufacturer and the operator are responsible for compliance of the system/machine with applicable safety regulations.

The following requirements are mandatory when installing and operating the BST brake module in safety-relevant applications.

The conditions are divided into the following sections:

- Approved device combinations
- Installation requirements (see page 14)
- Requirements for external safety controller (see page 16)
- Startup requirements (see page 17)
- Operation requirements (see page 18)

### **4.1 Permitted unit combinations**

Only approved SEW disk brakes may be connected to the BST module.

The following unit combinations with BST are permitted for safety-relevant applications:

Unit designation	Part number	Approved SEW disk brakes
BST 0.6S-460V-00	0 829 971 4	All brake coils with a coil voltage of AC 460 V and a coil power $\leq 120$ W. Several brake coils can be connected for redundant systems. In this case, the total power must not exceed 120 W.
BST 0.7S-400V-00	1 300 077 2	All brake coils with a coil voltage of AC 400 V and a coil power $\leq 120$ W. Several brake coils can be connected for redundant systems. In this case, the total power must not exceed 120 W.
BST 1.2S-230V-00	1 300 133 7	All brake coils with a coil voltage of AC 230 V and a coil power $\leq 120$ W. Several brake coils can be connected for redundant systems. In this case, the total power must not exceed 120 W.



#### 4.2 Requirements on the installation

The line between the safety switching device/safety controller and the safety-relevant BST brake module, terminal 5/6 ( $V_{24\text{ V safe}}$ ) is referred to as safety-relevant control line (for safe disconnection).

Observe the following requirements on the installation:


- Power lines and safety-related control lines have to be installed in separate cables.
- The total cable length between the safety switching device/safety controller and the safety-relevant BST brake module is limited to a maximum length of 100 m for EMC reasons.
- The total cable length between the safety-relevant BST brake module and the connected brake must not exceed 200 m.
- Wiring must comply with EN60204-1.
- The installation space (control cabinet) must have at least degree of protection IP54.
- The safety-relevant control lines must be routed according to EMC guidelines and as follows:
  - Outside an electrical installation space: Shielded cables must be routed permanently (fixed) and protected against external damage, or other equivalent measures.
  - Individual conductors can be routed inside an electrical installation space. Observe the respective regulations governing the application.
  - It is essential that you apply the shielding at both ends on the housing.
- The safety-relevant control voltage  $V_{24\text{ V safe}}$  may not be used for feedback.
- You have to make sure that there is no transient coupling to the safety-related control voltage  $V_{24\text{ V safe}}$ .
- When designing the safety circuits, always observe the values specified for safety components.
- For any DC 24 V voltage supply (safety-relevant control voltage  $V_{24\text{ V safe}}$  and functional control voltage  $V_{24\text{ V in}}$ ) of the safety-relevant BST brake module, only voltage sources with safe disconnection (SELV/PELV) according to IEC 60364 ( $\triangle$  VDE 0100) must be used.

In case of a single fault, the voltage between the outputs or between any output and grounded parts may not exceed DC 60 V.

- Do not interconnect brake cables of different brake control systems.
- For disconnection of group drives, observe the switching capacity of the safety switching device and the maximum permitted voltage drop on the safety-related control voltage  $V_{24\text{ V safe}}$ .
- Adhere to the technical data of the BST module and the brake.
- Adhere to the general installation regulations in the "Installation" chapter.



The following figure shows EMC compliant installation.



142874123



#### 4.3 Requirements on external safety controller

A safety switching device can be used as an alternative to a safety controller. The following requirements apply analogously.

- For safety-relevant applications up to category 3 to EN 954-1, the safety controller and all other safety-relevant subsystems must be approved for at least category 3 to EN 954-1 or performance level d to EN ISO 13849-1 or SIL 2 to EN 61508.
- For safety-relevant applications up to performance level d to EN ISO 13849-1, the safety controller and all other safety-relevant subsystems must be approved for at least performance level d to EN ISO 13849-1 or SIL 2 to EN 61508. For determining the performance level, the method described in EN ISO 13849-1 for combining several safety-relevant subsystems (without PFH value calculation) can be used. However, we recommend to determine the PFH value for the overall application.  $PFH = 0$  can be assumed for the safety-relevant BST brake module.

Application	Requirement on the safety controller
Category 3 according to EN 954-1	Category 3 according to EN 954-1 Performance level d according to EN ISO 13849-1 SIL 2 according to EN 61508
Performance level d according to EN ISO 13849-1	Performance level d according to EN ISO 13849-1 SIL 2 according to EN 61508

- The wiring of the safety controller must be suitable for the required safety class, (see manufacturer documentation). The safety-related control voltage  $V_{24\text{ V safe}}$  can be safely disconnected either at the positive, or the positive and negative pole. SEW-EURODRIVE recommends bipolar disconnection.
- The values specified for the safety controller must be strictly adhered to when designing the circuit.
- The switching capacity of the safety relays or the relay outputs of the safety controller must correspond at least to the maximally permitted, limited output current of the safety-relevant control voltage  $V_{24\text{ V safe}}$ . **Observe the manufacturer's instructions concerning the permitted contact loads and fusing that may be required for the safety contacts. If there are no manufacturer's instructions for fusing, the contacts must be protected with 0.6 times the nominal value of the maximum contact rating specified by the manufacturer.**
- To ensure protection against unintended restart in accordance with EN 1037, the safety controllers must be designed and connected in such a way that resetting the control device alone does not lead to a restart. A restart may only be carried out after a manual reset of the safety circuit.
- The input of the safety-relevant control voltage  $V_{24\text{ V safe}}$  of the safety-relevant BST brake module (terminal 5/6) is equipped with a serial polarity protection diode and a buffer capacitor with  $C = 6\text{ }\mu\text{F}$ . This must be considered as load when dimensioning the switching output.






### 4.3.1 Sample circuit for a "safety switching device"

The following figure shows the basic connection of an external safety switching device (according to the before mentioned requirements).

Observe the information in the respective manufacturer's data sheets for connection.



9007199399082635

## 4.4 Requirements on startup

- Startup must be documented and the functionality of the safety functions must be demonstrated. Observe the limitations for the safety functions of the BST brake module in chapter "Restrictions" for the verification of the safety functions. Non-safety-relevant parts and components that affect the result of the verification test (e.g. brake ramp of a frequency inverter) must be deactivated, if necessary.
- For using the BST brake module in safety-relevant applications, it is essential that you perform and record startup checks for the disconnecting device and correct wiring.
- During the startup procedure/function test, the correct assignment of the respective voltage supply connection must be checked by means of a measurement.
  - Safety-relevant control voltage  $V_{24\text{ V safe}}$ : Terminal 5/6
  - Functional control voltage  $V_{24\text{ V in}}$ : Terminal 3/4
- The function check must be carried out separately for all potentials.
- Observe the notes in the "Startup" chapter.



#### **4.5 Requirements on the operation**

- Operation is only allowed within the limits specified in the data sheets. This applies to both the external safety relay as well as the BST.
- The safety functions must be checked at regular intervals to ensure proper functioning. The period of time between the tests should be specified in accordance with the risk analysis.
- Also observe the information in the "Inspection/Maintenance" chapter.




## 5 Unit Design

### 5.1 Nameplate, unit designation


#### 5.1.1 Example: Unit designation

The following characteristic unit data can be read from the unit designation:



#### 5.1.2 Example: Nameplate

The following figure shows a nameplate of BST 0.6S-460V-00:



9007199397653515

### 5.2 Scope of delivery of BST


The scope of delivery includes:

- 1 safety-relevant BST brake module with installed holding fixture for support rail mounting
- 4 attached plug connectors for terminal connections



### 5.3 Safety-relevant BST brake module

The following figure shows the unit design of BST x.xS-xxxV-00:



9007199397613451

- [1] LED V1 for indicating the operating state
- [2] LED V2 for indicating the operating state
- [3] Terminals 13/14/15: Brake connection
- [4] Terminals 3/4 : For connecting the functional control voltage  $V_{24\text{ V in}}$
- [5] Terminals 5/6 : For connecting the safety-relevant control voltage  $V_{24\text{ V safe}}$
- [6] Terminals 1/2 : For DC link voltage  $+V_{\text{DC link}}$
- [7] PE connection
- [8] Retaining plate / shield plate

### 5.4 Terminal assignment

Terminal		Function
1	$+V_{\text{DC link}}$ $-V_{\text{DC link}}$	DC link voltage input
2		
5	SVI24	Safety-relevant control voltage $V_{24\text{ V safe}}$ input
6	S0V24	
		Reference potential for safety-relevant control voltage $V_{24\text{ V safe}}$
3	DBI24	Functional control voltage $V_{24\text{ V in}}$ input:
4	DGND	
		Reference potential for functional control voltage $V_{24\text{ V in}}$
13	RD	Brake output
14	WH	
15	BU	
⏏		Protective grounding




## 6 Installation

### 6.1 Mechanical installation


#### 6.1.1 Support rail mounting

The BST module is mounted onto a support rail in the control cabinet.



137090187

#### Mounting



1887424139

- [1] Safety-relevant BST brake module
- [2] Support rail
- [3] Upper holding fixture of the BST
- [4] Notch, lower holding fixture of the BST
- [5] Upper support rail edge
- [6] Lower support rail edge

1. The upper holding fixture of the BST [3] is spring-loaded. First, insert the BST into the upper support rail edge [5] with the upper holding fixture only.
2. Next, press the BST downward towards the support rail until the notch [4] clicks into place on the lower support rail edge [6].

The spring at the upper holding fixture causes the lower support rail edge to be pressed into the notch so that the BST [1] is secured onto the support rail [2].



## Installation


### Mechanical installation

#### Removal

1. Press onto the BST. This causes the lower support rail edge [6] to come off the notch [4]. At the same time, remove the BST from the lower holding fixture.
2. You can remove the BST from the support rail once the lower lock unfastens.

#### Minimum clearance and mounting position

- Leave 40 mm clearance at the top, 60 mm at the bottom and 15 mm at the sides for optimum cooling. Make sure air circulation in the clearance is not impaired by cables or other installation equipment.
- Ensure unobstructed cooling air supply and make sure that the units are not subjected to heated air from nearby components.
- Install the units vertically only. Do not install them horizontally, tilted or upside down.



9007199391829515

All dimensions in mm (in).



## 6.2 Electrical installation

	<b>TIP</b>
	All poles must be disconnected from the supply system when work is carried out on the electrical section of the system. Dangerous voltages may still be present for up to 10 minutes after disconnection from the power supply source.

### 6.2.1 Notes on electrical installation

*Supply cable  
(terminal 1/2)*

The supply cable must meet the following conditions:

- The supply cables to the BST carry a high DC voltage (max. DC 1000 V). The rated voltage of the cable must amount to at least  $V_0/V = 300 \text{ V} / 500 \text{ V}$  (in accordance with DIN VDE 0298).
- The inverter supply system must have a grounded star point (TT/TN). The operation is not permitted for IT systems or systems grounded via an outer conductor.
- Cable cross section:  $0.75 \text{ mm}^2 - 2.5 \text{ mm}^2$  (AWG 19 – AWG 13)
- Max. cable length: 100 m (328 ft)
- All poles of the supply cable are protected with two corresponding DC fuses F1/F2 (recommended  $1000 \text{ V}/4 \text{ A}$ ).

	<b>TIP</b>
	The fuses may not be required in compliance with IEC 60364-4-43 ((VDE 100 part 430) and EN 60204-1 if the supply cable to the BST is protected by the input fuse located in front of the inverter, or if the following conditions are met: <ul style="list-style-type: none"> <li>• Keep the cable length to the BST as short as possible. Maximum length: 3 m</li> <li>• Do not lay cables in the vicinity of inflammable substances.</li> <li>• Reduce the risk of short circuits to a minimum.</li> <li>• Use the greatest possible cable cross section.</li> </ul>

*Functional control  
cable (terminal 3/4)*

The functional control cable must meet the following conditions:

- Cable cross section of  $0.5 \text{ mm}^2 - 1.5 \text{ mm}^2$  (AWG 20 – AWG 16)
- Max. cable length: 100 m (328 ft)

*Safety-related  
control cable  
(terminal 5/6)*

The safety-related control cable must meet the following conditions:

- Cable cross section of  $0.5 \text{ mm}^2 - 1.5 \text{ mm}^2$  (AWG 20 – AWG 16)
- Max. cable length: 100 m (328 ft)


*Brake cable  
(terminal 13/14/15)*

- Cable cross section of  $0.75 \text{ mm}^2 - 2.5 \text{ mm}^2$  (AWG 19 – AWG 13)
- Max. cable length: 200 m (656 ft)




### 6.2.2 Double-pole safe disconnection

The following figure shows the wiring inside the installation space:



9007199388524427

The following figure shows the wiring outside the installation space:




9007199388555019






### 6.2.3 Single-pole safe disconnection

The following figure shows the wiring inside the installation space:



9007199388553355

The following figure shows the wiring outside the installation space:



9007199388551691



#### TIP

Safe single-pole disconnection is only permitted when short circuits in the safety-relevant control cable between safety relay and BST can be ruled out (fault elimination according to EN ISO 13849-2).

SEW-EURODRIVE recommends bipolar disconnection.



## 7 Startup

### 7.1 Operating states

- The brake is activated with the functional control voltage  $V_{24\text{ V in}}$  when the DC link voltage  $V_{\text{DC link}}$  and the safety-relevant control voltage  $V_{24\text{ V safe}}$  are present.  
 $V_{24\text{ V in}}$  is present  $\triangle$  Brake released.  
 $V_{24\text{ V in}}$  is not present  $\triangle$  Brake applied.
- If the safety-related control voltage  $V_{24\text{ V safe}}$  is disconnected, the brake is safely de-energized (**SBC**).
- If the DC link voltage  $V_{\text{DC link}}$  is disconnected, the brake is de-energized.

The brake is released with high-speed excitation.

Rapid brake application (DC and AC switch-off) occurs when it is controlled using the  $V_{24\text{ V in}}$  functional control voltage or the  $V_{24\text{ V safe}}$  safety-related control voltage.

The response time for releasing and applying the brake results from the response time of the BST  $t_R \leq 6\text{ ms}$  and the response or application time of the brake connected. For information on response or application times, refer to the applicable operating instructions for motors.

#### 7.1.1 Operating state display

LEDs V1 and V2 indicate the operating state of the control inputs.

- LED V1: State of the safety-relevant control voltage  $V_{24\text{ V safe}}$ .
- LED V2: State of the brake when the DC link voltage  $V_{\text{DC link}}$  is present.

LED V1	LED V2	$U_{24\text{ V safe}}$	$U_{24\text{ V in}}$	Operating state
Off	Off	Off	Off	Brake de-energized
Off	Off	Off	On	Brake de-energized
Lights orange	Off	On	Off	Brake de-energized
Lights orange	Lights green	On	On	Brake energized when $V_{\text{DC link}}$ is present






#### TIPS

- The states of LED V1 and LED V2 must not be regarded as safety-relevant.
- The fact that LED V1 and LED V2 are no longer illuminated does not indicate that the safety-relevant BST brake module is de-energized and the brake is applied.
- Even if LED V1 and LED V2 are not illuminated, DC link voltage  $V_{\text{DC link}}$  might be present at the BST brake module.



## 8 Inspection/Maintenance

	<p><b>! DANGER</b></p> <p>Risk of crushing if the hoist falls. Severe or fatal injuries.</p> <ul style="list-style-type: none"> <li>• Secure or lower hoist drives (danger of falling)</li> <li>• Isolate the inverter, the motor and the brake from the power supply before starting work, safeguarding them against accidental startup.</li> <li>• Only use genuine spare parts in accordance with the valid parts list.</li> <li>• Always install a new brake controller at the same time as replacing the brake coil.</li> <li>• Observe the notes in the operating instructions for AC motors and brakemotors.</li> <li>• Only qualified personnel may perform maintenance for the brake.</li> </ul>
	<p><b>! DANGER</b></p> <p>There may still be dangerous voltages inside the unit and at the terminal strips for up to 10 minutes after the BST has been disconnected from the power supply. Severe or fatal injuries from electric shock.</p> <ul style="list-style-type: none"> <li>• Disconnect the BST from the power supply and ensure that the unit cannot be switched on unintentionally.</li> <li>• Wait for 10 minutes before carrying out any maintenance or inspection work.</li> <li>• Prior to maintenance or inspection work, make sure that the BST is de-energized.</li> </ul>
	<p><b>! CAUTION</b></p> <p>The surface of the safety-relevant BST brake module can be very hot during operation. Danger of burns.</p> <ul style="list-style-type: none"> <li>• Let the BST cool down before you start working on it.</li> </ul>

### 8.1 Inspection and maintenance intervals

The required inspection/maintenance intervals must be calculated by the system manufacturer according to the specific project planning documents for individual applications, in accordance with the regionally valid standards.



#### 8.2 Checking the brake function

The brake function must be checked according to the instructions of the system manufacturer after inspection/maintenance work.

#### 8.3 Service

Have the following information available when you require assistance from the SEW-EURODRIVE service:

- Nameplate data (complete)
- Type and extent of the problem
- Time the problem occurred and any accompanying circumstances
- Assumed cause

#### 8.4 Unit replacement procedure

Proceed as follows to replace a BST:

- Observe the notes regarding inspection/maintenance work for the BST.

	<p><b>! DANGER</b></p> <p>There may still be dangerous voltages inside the unit and at the terminal strips for up to 10 minutes after the BST has been disconnected from the power supply.</p> <p>Severe or fatal injuries from electric shock.</p> <ul style="list-style-type: none"> <li>• Disconnect the BST from the power supply and ensure that the unit cannot be switched on unintentionally.</li> <li>• Wait for 10 minutes before carrying out any maintenance or inspection work.</li> <li>• Prior to maintenance or inspection work, make sure that the BST is de-energized.</li> </ul>
--	---

- Compare the data on the nameplate of the BST to be replaced with the new one.
- Remove all connecting terminals.
- Disconnect the PE and the shield clamps.
- Push lightly on the opposite side of the connection terminals and remove the BST from the support rail.
- Install the new BST on the support rail. Observe chapter "Mechanical Installation".
- Connect the PE and the shield.
- Connect all connection terminals.




## 9 Applications

The following figures show the wiring diagrams for SBC with simultaneous STO (Safe Torque Off).

	<table><tr><th data-bbox="414 407 1433 448">TIPS</th></tr><tr><td data-bbox="414 448 1433 602"><ul style="list-style-type: none"><li>• For safe single- and double-pole disconnection, refer to chapter "Electrical Installation" (see page 23)</li><li>• DC fuses F1/F2 are not required if the before mentioned requirements for the supply cable are met.</li><li>• Observe chapter "Electrical Installation" (see page 23).</li></ul></td></tr></table>	TIPS	<ul style="list-style-type: none"><li>• For safe single- and double-pole disconnection, refer to chapter "Electrical Installation" (see page 23)</li><li>• DC fuses F1/F2 are not required if the before mentioned requirements for the supply cable are met.</li><li>• Observe chapter "Electrical Installation" (see page 23).</li></ul>
TIPS			
<ul style="list-style-type: none"><li>• For safe single- and double-pole disconnection, refer to chapter "Electrical Installation" (see page 23)</li><li>• DC fuses F1/F2 are not required if the before mentioned requirements for the supply cable are met.</li><li>• Observe chapter "Electrical Installation" (see page 23).</li></ul>			




### 9.1 Disconnection of single drives via inverter (MOVIDRIVE® B as example)



9007199388411915




## 9.2 Disconnection of single drives via inverter (MOVIAXIS® as example)



9007200035631755



### 9.3 Disconnection of single drives via inverter and DFS11B/21B fieldbus interface





9007200035678603





## 9.4 Group disconnection via inverter








## 10 Technical Data

### 10.1 General technical data

Brake module	BST 1.2S-230V-00	BST 0.7S-400V-00	BST 0.6S-460V-00
Part number	1300 1337	1300 0772	0829 9714
Interference immunity	according to EN 61800-3		
Interference emission with EMC-compliant installation	according to EN 61800-3		
Degree of protection	IP20		
Mounting	on support rail in control cabinet (control cabinet must have at least degree of protection IP54)		
Ambient temperature $T_A$	-15 °C to +60 °C		
DC link voltage $V_{DC \text{ link}}$ Terminal 1/2	DC 350 V – 850 V (at $P_A \geq 95 \text{ W}$ at least DC 450 V)		
Power consumption $P_E$ Terminal 1/2	150 W, depending on brake type (holding coil) Short-term: max. 800 W / 200 ms (accelerator coil)		
Functional control voltage $V_{24 \text{ V in}}$ Terminal 3/4	Signal level according to DIN EN 61131-2 type 1 DC +15 V to +30 V (> 2mA) => 1 / contact closed DC -3 V to +5V (< 2 mA) => 0 / contact open For the control input at terminals 3 and 4, only use voltage sources with safe disconnection (SELV/PELV) in accordance with IEC 60364 ( $\triangle$ VDE 0100).		
Brake voltage $V_B$ Terminal 13/15	DC 96 V	DC 167 V	DC 190 V
AC brake coil voltage	AC 230 V	AC 400 V	AC 460 V
Rated output current $I_N$ Terminal 13/15	DC 1.2 A	DC 0.7 A	DC 0.6 A
Output current $I_{\text{brake warm}}$ Terminal 13/15	DC 1.0 A	DC 0.6 A	DC 0.5 A
	At $P_A = 120 \text{ W}$ , the rated output current reduces in warm state.		
Acceleration current $I_B$ Terminal 13/14	4 – 8.5 times the holding current depending on the brake type		
Max. output power $P_A$	$P_A \leq 120 \text{ W}$		
Brake output Terminal 13/14/15	The figures relate to the SEW standard brake coils (two-coil system) Holding coil: Terminal 13 <sub>red</sub> / 15 <sub>blue</sub> Accelerator coil: Terminal 13 <sub>red</sub> / 14 <sub>white</sub> Several brake coils can be connected for redundant systems. The sum of the individual power levels must not exceed the max. output power.		
Supply cable $V_{DC \text{ link}}$ Terminal 1/2	Rated cable voltage: min. $V_0 / V = 300 \text{ V} / 500 \text{ V}$ (to DIN VDE 0298) Cable cross section: 0.75 mm <sup>2</sup> – 2.5 mm <sup>2</sup> (AWG 19 – AWG 13) Max. cable length: 100 m (328 ft)		
Functional control cable $V_{24 \text{ V in}}$ Terminal 3/4	Cable cross section: 0.5 mm <sup>2</sup> – 1.5 mm <sup>2</sup> (AWG 20 – AWG 16) Max. cable length: 100 m (328 ft)		
Brake cable Terminal 13/14/15	Cable cross section of 0.75 mm <sup>2</sup> – 2.5 mm <sup>2</sup> (AWG 19 – AWG 13) Max. cable length: 200 m (656 ft) at min. 1.5 mm <sup>2</sup> (AWG 16)		
Power loss $P_V$	Max. 30 W		
Storage temperature	-20 °C to +70 °C (EN 60721-3-3, class 3K3)		
Dimensions W × H × D	134 mm × 70 mm × 135 mm (5.28 in × 2.76 in × 5.31 in)		
Weight	About 0.79 kg (1.7 lb)		
Switching cycles	500 000 switching cycles (brake released and brake applied)		



Brake module	BST 1.2S-230V-00	BST 0.7S-400V-00	BST 0.6S-460V-00
Minimum clock cycle of the control at $P_A \geq 70 \text{ W}$	<p>Clock cycle of the control <math>\geq 2 \text{ s}</math>. The timeout <math>t_{\text{off}}</math> must last at least 1 s.</p>  <p>Shorter cycle times are possible for teach mode. In this case, the timeout lasts 3 minutes.</p> 		


## 10.2 Safety-related control voltage

The following table shows the technical data for safety-related control voltage  $V_{24 \text{ V safe}}$  at terminals 5/6:

Safety-related control voltage $V_{24 \text{ V safe}}$	Min.	Typical	Max.
Input voltage range according to DIN EN 61131-2 DC 24 V	DC 20.4 V	DC 24 V	DC 28.8 V
Input capacitance		4.7 $\mu\text{F}$	6 $\mu\text{F}$
Switch-on/switch-off threshold		DC 10 V	
Input voltage for OFF state (brake de-energized)			DC 6 V
Duration from switching off the safety-related control voltage at BST until switching off the brake voltage $V_B$ plus the brake application time of the connected brake.			6 ms
Safety-related control cable			
• Cable length			100 m (328 ft)
• Cable cross section	0.5 mm <sup>2</sup> (AWG 20)		1.5 mm <sup>2</sup> (AWG 16)


## 10.3 Safety-related characteristic values

Brake module	BST 1.2S-230V-00	BST 0.7S-400V-00	BST 0.6S-460V-00
Part number	1300 1337	1300 0772	0829 9714
Safe condition	Brake de-energized		
Highest possible safety category	Performance level d according to EN ISO 13849-1 Safety category 3 according to EN 954-1		
Probability of dangerous failure per hour (PFH value)	0 (fault exclusion)		
Service life	Max. 20 years		



#### 10.4 Dimension drawing of BST in control cabinet design

The following figure shows the dimension drawings of BST in control cabinet design:



9007199388556683

All dimensions in mm (in).




## 11 Supply Module for BST (in preparation)

Part number: 08295557

The supply module is used when the inverter is not fitted with a DC link connection. In this case, the supply module provides the DC link voltage  $V_{DC \text{ link}}$  for the BST.

### 11.1 Nameplate

The following figure shows an example nameplate of the supply module:



1891730059

### 11.2 Technical data

Supply module	
Part number	08295557
Rated mains voltage	3 × AC 380 V – 500 V
Rated input current	4 A
Output voltage	DC 513 V – 680 V
Rated output current	DC 4.5 A
Temperature	0 °C to 40 °C

### 11.3 Terminal assignment

Terminal	Function
L1 L2 L3	Mains voltage input
+V <sub>DC link</sub> -V <sub>DC link</sub>	DC link voltage output
	Protective grounding




### 11.4 Wiring diagram



#### TIPS

- For safe single- and double-pole disconnection, refer to chapter "Electrical Installation" (see page 23)
- DC fuses F1/F2 are not required if the before mentioned requirements for the supply cable are met.
- Observe chapter "Electrical Installation" (see page 23).

Supply module for supplying the BST from a separate supply system:




9007200035631755



## 11.5 Dimension drawings


The supply module can be mounted either at the front or side of the support rail.  
All dimensions in mm (in).

### 11.5.1 Installation at the front of the support rail (standard)



1874835083

### 11.5.2 Installation at the side of the support rail



1889081227



## 12 Address List

Germany			
<b>Headquarters Production Sales</b>	<b>Bruchsal</b>	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 D-76646 Bruchsal P.O. Box Postfach 3023 • D-76642 Bruchsal	Tel. +49 7251 75-0 Fax +49 7251 75-1970 <a href="http://www.sew-eurodrive.de">http://www.sew-eurodrive.de</a> <a href="mailto:sew@sew-eurodrive.de">sew@sew-eurodrive.de</a>
<b>Service Compe- tence Center</b>	<b>Central</b>	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 1 D-76676 Graben-Neudorf	Tel. +49 7251 75-1710 Fax +49 7251 75-1711 <a href="mailto:sc-mitte@sew-eurodrive.de">sc-mitte@sew-eurodrive.de</a>
	<b>North</b>	SEW-EURODRIVE GmbH & Co KG Alte Ricklinger Straße 40-42 D-30823 Garbsen (near Hannover)	Tel. +49 5137 8798-30 Fax +49 5137 8798-55 <a href="mailto:sc-nord@sew-eurodrive.de">sc-nord@sew-eurodrive.de</a>
	<b>East</b>	SEW-EURODRIVE GmbH & Co KG Dänkritzer Weg 1 D-08393 Meerane (near Zwickau)	Tel. +49 3764 7606-0 Fax +49 3764 7606-30 <a href="mailto:sc-ost@sew-eurodrive.de">sc-ost@sew-eurodrive.de</a>
	<b>South</b>	SEW-EURODRIVE GmbH & Co KG Domagkstraße 5 D-85551 Kirchheim (near München)	Tel. +49 89 909552-10 Fax +49 89 909552-50 <a href="mailto:sc-sued@sew-eurodrive.de">sc-sued@sew-eurodrive.de</a>
	<b>West</b>	SEW-EURODRIVE GmbH & Co KG Siemensstraße 1 D-40764 Langenfeld (near Düsseldorf)	Tel. +49 2173 8507-30 Fax +49 2173 8507-55 <a href="mailto:sc-west@sew-eurodrive.de">sc-west@sew-eurodrive.de</a>
	<b>Electronics</b>	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 D-76646 Bruchsal	Tel. +49 7251 75-1780 Fax +49 7251 75-1769 <a href="mailto:sc-elektronik@sew-eurodrive.de">sc-elektronik@sew-eurodrive.de</a>
	<b>Drive Service Hotline / 24 Hour Service</b>		+49 180 5 SEWHELP +49 180 5 7394357
	Additional addresses for service in Germany provided on request!		
France			
<b>Production Sales Service</b>	<b>Haguenau</b>	SEW-USOCOME 48-54, route de Soufflenheim B. P. 20185 F-67506 Haguenau Cedex	Tel. +33 3 88 73 67 00 Fax +33 3 88 73 66 00 <a href="http://www.usocomme.com">http://www.usocomme.com</a> <a href="mailto:sew@usocomme.com">sew@usocomme.com</a>
<b>Production</b>	<b>Forbach</b>	SEW-EUROCOME Zone Industrielle Technopôle Forbach Sud B. P. 30269 F-57604 Forbach Cedex	Tel. +33 3 87 29 38 00
<b>Assembly Sales Service</b>	<b>Bordeaux</b>	SEW-USOCOME Parc d'activités de Magellan 62, avenue de Magellan - B. P. 182 F-33607 Pessac Cedex	Tel. +33 5 57 26 39 00 Fax +33 5 57 26 39 09
	<b>Lyon</b>	SEW-USOCOME Parc d'Affaires Roosevelt Rue Jacques Tati F-69120 Vaulx en Velin	Tel. +33 4 72 15 37 00 Fax +33 4 72 15 37 15
	<b>Paris</b>	SEW-USOCOME Zone industrielle 2, rue Denis Papin F-77390 Verneuil l'Etang	Tel. +33 1 64 42 40 80 Fax +33 1 64 42 40 88
Additional addresses for service in France provided on request!			





<b>Algeria</b>			
<b>Sales</b>	<b>Alger</b>	Réducom 16, rue des Frères Zagnoun Bellevue El-Harrach 16200 Alger	Tel. +213 21 8222-84 Fax +213 21 8222-84 reducom_sew@yahoo.fr
<b>Argentina</b>			
<b>Assembly Sales Service</b>	<b>Buenos Aires</b>	SEW EURODRIVE ARGENTINA S.A. Centro Industrial Garin, Lote 35 Ruta Panamericana Km 37,5 1619 Garin	Tel. +54 3327 4572-84 Fax +54 3327 4572-21 sewar@sew-eurodrive.com.ar http://www.sew-eurodrive.com.ar
<b>Australia</b>			
<b>Assembly Sales Service</b>	<b>Melbourne</b>	SEW-EURODRIVE PTY. LTD. 27 Beverage Drive Tullamarine, Victoria 3043	Tel. +61 3 9933-1000 Fax +61 3 9933-1003 http://www.sew-eurodrive.com.au enquires@sew-eurodrive.com.au
	<b>Sydney</b>	SEW-EURODRIVE PTY. LTD. 9, Sleigh Place, Wetherill Park New South Wales, 2164	Tel. +61 2 9725-9900 Fax +61 2 9725-9905 enquires@sew-eurodrive.com.au
<b>Austria</b>			
<b>Assembly Sales Service</b>	<b>Wien</b>	SEW-EURODRIVE Ges.m.b.H. Richard-Strauss-Strasse 24 A-1230 Wien	Tel. +43 1 617 55 00-0 Fax +43 1 617 55 00-30 http://sew-eurodrive.at sew@sew-eurodrive.at
<b>Belarus</b>			
<b>Sales</b>	<b>Minsk</b>	SEW-EURODRIVE BY Rybalko Str. 26 BY-220033 Minsk	Tel. +375 (17) 298 38 50 Fax +375 (17) 29838 50 sales@sew.by
<b>Belgium</b>			
<b>Assembly Sales Service</b>	<b>Brüssel</b>	<b>SEW Caron-Vector</b> Avenue Eiffel 5 B-1300 Wavre	Tel. +32 10 231-311 Fax +32 10 231-336 http://www.sew-eurodrive.be info@caron-vector.be
<b>Service Compe- tence Center</b>	<b>Industrial Gears</b>	<b>SEW Caron-Vector</b> Rue de Parc Industriel, 31 BE-6900 Marche-en-Famenne	Tel. +32 84 219-878 Fax +32 84 219-879 http://www.sew-eurodrive.be service-wallonie@sew-eurodrive.be
	<b>Antwerp</b>	<b>SEW Caron-Vector</b> Glasstraat, 19 BE-2170 Merksem	Tel. +32 3 64 19 333 Fax +32 3 64 19 336 http://www.sew-eurodrive.be service-antwerpen@sew-eurodrive.be
<b>Brazil</b>			
<b>Production Sales Service</b>	<b>Sao Paulo</b>	SEW-EURODRIVE Brasil Ltda. Avenida Amâncio Gaiolli, 152 - Rodovia Presi- dente Dutra Km 208 Guarulhos - 07251-250 - SP SAT - SEW ATENDE - 0800 7700496	Tel. +55 11 2489-9133 Fax +55 11 2480-3328 http://www.sew-eurodrive.com.br sew@sew.com.br
Additional addresses for service in Brazil provided on request!			
<b>Bulgaria</b>			
<b>Sales</b>	<b>Sofia</b>	BEVER-DRIVE GmbH Bogdanovetz Str.1 BG-1606 Sofia	Tel. +359 2 9151160 Fax +359 2 9151166 bever@fastbg.net



Cameroon			
Sales	Douala	Electro-Services Rue Drouot Akwa B.P. 2024 Douala	Tel. +237 33 431137 Fax +237 33 431137
Canada			
Assembly Sales Service	Toronto	SEW-EURODRIVE CO. OF CANADA LTD. 210 Walker Drive Bramalea, Ontario L6T3W1	Tel. +1 905 791-1553 Fax +1 905 791-2999 <a href="http://www.sew-eurodrive.ca">http://www.sew-eurodrive.ca</a> <a href="mailto:marketing@sew-eurodrive.ca">marketing@sew-eurodrive.ca</a>
	Vancouver	SEW-EURODRIVE CO. OF CANADA LTD. 7188 Honeyman Street Delta, B.C. V4G 1 E2	Tel. +1 604 946-5535 Fax +1 604 946-2513 <a href="mailto:marketing@sew-eurodrive.ca">marketing@sew-eurodrive.ca</a>
	Montreal	SEW-EURODRIVE CO. OF CANADA LTD. 2555 Rue Leger LaSalle, Quebec H8N 2V9	Tel. +1 514 367-1124 Fax +1 514 367-3677 <a href="mailto:marketing@sew-eurodrive.ca">marketing@sew-eurodrive.ca</a>
	Additional addresses for service in Canada provided on request!		
Chile			
Assembly Sales Service	Santiago de Chile	SEW-EURODRIVE CHILE LTDA. Las Encinas 1295 Parque Industrial Valle Grande LAMP RCH-Santiago de Chile P.O. Box Casilla 23 Correo Quilicura - Santiago - Chile	Tel. +56 2 75770-00 Fax +56 2 75770-01 <a href="http://www.sew-eurodrive.cl">http://www.sew-eurodrive.cl</a> <a href="mailto:ventas@sew-eurodrive.cl">ventas@sew-eurodrive.cl</a>
China			
Production Assembly Sales Service	Tianjin	SEW-EURODRIVE (Tianjin) Co., Ltd. No. 46, 7th Avenue, TEDA Tianjin 300457	Tel. +86 22 25322612 Fax +86 22 25322611 <a href="mailto:info@sew-eurodrive.cn">info@sew-eurodrive.cn</a> <a href="http://www.sew-eurodrive.cn">http://www.sew-eurodrive.cn</a>
Assembly Sales Service	Suzhou	SEW-EURODRIVE (Suzhou) Co., Ltd. 333, Suhong Middle Road Suzhou Industrial Park Jiangsu Province, 215021	Tel. +86 512 62581781 Fax +86 512 62581783 <a href="mailto:suzhou@sew-eurodrive.cn">suzhou@sew-eurodrive.cn</a>
	Guangzhou	SEW-EURODRIVE (Guangzhou) Co., Ltd. No. 9, JunDa Road East Section of GETDD Guangzhou 510530	Tel. +86 20 82267890 Fax +86 20 82267891 <a href="mailto:guangzhou@sew-eurodrive.cn">guangzhou@sew-eurodrive.cn</a>
	Shenyang	SEW-EURODRIVE (Shenyang) Co., Ltd. 10A-2, 6th Road Shenyang Economic Technological Development Area Shenyang, 110141	Tel. +86 24 25382538 Fax +86 24 25382580 <a href="mailto:shenyang@sew-eurodrive.cn">shenyang@sew-eurodrive.cn</a>
	Wuhan	SEW-EURODRIVE (Wuhan) Co., Ltd. 10A-2, 6th Road No. 59, the 4th Quanli Road, WEDA 430056 Wuhan	Tel. +86 27 84478398 Fax +86 27 84478388
Additional addresses for service in China provided on request!			
Colombia			
Assembly Sales Service	Bogotá	SEW-EURODRIVE COLOMBIA LTDA. Calle 22 No. 132-60 Bodega 6, Manzana B Santafé de Bogotá	Tel. +57 1 54750-50 Fax +57 1 54750-44 <a href="http://www.sew-eurodrive.com.co">http://www.sew-eurodrive.com.co</a> <a href="mailto:sewcol@sew-eurodrive.com.co">sewcol@sew-eurodrive.com.co</a>



<b>Croatia</b>			
<b>Sales Service</b>	<b>Zagreb</b>	KOMPEKS d. o. o. PIT Erdödy 4 II HR 10 000 Zagreb	Tel. +385 1 4613-158 Fax +385 1 4613-158 kompeks@inet.hr
<b>Czech Republic</b>			
<b>Sales</b>	<b>Praha</b>	SEW-EURODRIVE CZ S.R.O. Business Centrum Praha Lužná 591 CZ-16000 Praha 6 - Vokovice	Tel. +420 255 709 601 Fax +420 220 121 237 <a href="http://www.sew-eurodrive.cz">http://www.sew-eurodrive.cz</a> sew@sew-eurodrive.cz
<b>Denmark</b>			
<b>Assembly Sales Service</b>	<b>Kopenhagen</b>	SEW-EURODRIVEA/S Geminivej 28-30 DK-2670 Greve	Tel. +45 43 9585-00 Fax +45 43 9585-09 <a href="http://www.sew-eurodrive.dk">http://www.sew-eurodrive.dk</a> sew@sew-eurodrive.dk
<b>Egypt</b>			
<b>Sales Service</b>	<b>Cairo</b>	Copam Egypt for Engineering & Agencies 33 El Hegaz ST, Heliopolis, Cairo	Tel. +20 2 22566-299 + 1 23143088 Fax +20 2 22594-757 <a href="http://www.copam-egypt.com/">http://www.copam-egypt.com/</a> copam@datum.com.eg
<b>Service</b>	<b>Sharjah</b>	Copam Middle East (FZC) Sharjah Airport International Free Zone P.O. Box 120709 Sharjah <b>United Arab Emirates</b>	Tel. +971 6 5578-488 Fax +971 6 5578-499 copam_me@eim.ae
<b>Estonia</b>			
<b>Sales</b>	<b>Tallin</b>	ALAS-KUUL AS Reti tee 4 EE-75301 Peetri küla, Rae vald, Harjumaa	Tel. +372 6593230 Fax +372 6593231 veiko.soots@alas-kuul.ee
<b>Finland</b>			
<b>Assembly Sales Service</b>	<b>Lahti</b>	SEW-EURODRIVE OY Vesimäentie 4 FIN-15860 Hollola 2	Tel. +358 201 589-300 Fax +358 3 780-6211 sew@sew.fi <a href="http://www.sew-eurodrive.fi">http://www.sew-eurodrive.fi</a>
<b>Production Assembly Service</b>	<b>Karkkila</b>	SEW Industrial Gears Oy Valurinkatu 6, PL 8 FI-03600 Karkkila, 03601 Karkkila	Tel. +358 201 589-300 Fax +358 201 589-310 sew@sew.fi <a href="http://www.sew-eurodrive.fi">http://www.sew-eurodrive.fi</a>
<b>Gabon</b>			
<b>Sales</b>	<b>Libreville</b>	ESG Electro Services Gabun Feu Rouge Lalala 1889 Libreville Gabun	Tel. +241 741059 Fax +241 741059
<b>Great Britain</b>			
<b>Assembly Sales Service</b>	<b>Normanton</b>	SEW-EURODRIVE Ltd. Beckbridge Industrial Estate P.O. Box No.1 GB-Normanton, West- Yorkshire WF6 1QR	Tel. +44 1924 893-855 Fax +44 1924 893-702 <a href="http://www.sew-eurodrive.co.uk">http://www.sew-eurodrive.co.uk</a> info@sew-eurodrive.co.uk
<b>Greece</b>			
<b>Sales Service</b>	<b>Athen</b>	Christ. Boznos & Son S.A. 12, Mavromichali Street P.O. Box 80136, GR-18545 Piraeus	Tel. +30 2 1042 251-34 Fax +30 2 1042 251-59 <a href="http://www.boznos.gr">http://www.boznos.gr</a> info@boznos.gr



Hong Kong			
<b>Assembly Sales Service</b>	<b>Hong Kong</b>	SEW-EURODRIVE LTD. Unit No. 801-806, 8th Floor Hong Leong Industrial Complex No. 4, Wang Kwong Road Kowloon, Hong Kong	Tel. +852 36902200 Fax +852 36902211 contact@sew-eurodrive.hk
Hungary			
<b>Sales Service</b>	<b>Budapest</b>	SEW-EURODRIVE Kft. H-1037 Budapest Kunigunda u. 18	Tel. +36 1 437 06-58 Fax +36 1 437 06-50 office@sew-eurodrive.hu
India			
<b>Registered Office Assembly Sales Service</b>	<b>Vadodara</b>	SEW-EURODRIVE India Private Limited Plot No. 4, GIDC POR Ramangamdi • Vadodara - 391 243 Gujarat	Tel. +91 265 2831086 Fax +91 265 2831087 <a href="http://www.seweurodriveindia.com">http://www.seweurodriveindia.com</a> sales@seweurodriveindia.com subodh.ladwa@seweurodriveindia.com
<b>Assembly Sales Service</b>	<b>Chennai</b>	SEW-EURODRIVE India Private Limited Plot No. K3/1, Sipcot Industrial Park Phase II Mambakkam Village Sriperumbudur - 602105 Kancheepuram Dist, Tamil Nadu	Tel. +91 44 37188888 Fax +91 44 37188811 c.v.shivkumar@seweurodriveindia.com
Ireland			
<b>Sales Service</b>	<b>Dublin</b>	Alpert Engineering Ltd. 48 Moyle Road Dublin Industrial Estate Glasnevin, Dublin 11	Tel. +353 1 830-6277 Fax +353 1 830-6458 info@alperon.ie <a href="http://www.alperon.ie">http://www.alperon.ie</a>
Israel			
<b>Sales</b>	<b>Tel-Aviv</b>	Liraz Handasa Ltd. Ahofer Str 34B / 228 58858 Holon	Tel. +972 3 5599511 Fax +972 3 5599512 <a href="http://www.liraz-handasa.co.il">http://www.liraz-handasa.co.il</a> office@liraz-handasa.co.il
Italy			
<b>Assembly Sales Service</b>	<b>Milano</b>	SEW-EURODRIVE di R. Blickle & Co.s.a.s. Via Bernini,14 I-20020 Solaro (Milano)	Tel. +39 02 96 9801 Fax +39 02 96 799781 <a href="http://www.sew-eurodrive.it">http://www.sew-eurodrive.it</a> sewit@sew-eurodrive.it
Ivory Coast			
<b>Sales</b>	<b>Abidjan</b>	SICA Ste industrielle et commerciale pour l'Afrique 165, Bld de Marseille B.P. 2323, Abidjan 08	Tel. +225 2579-44 Fax +225 2584-36
Japan			
<b>Assembly Sales Service</b>	<b>Iwata</b>	SEW-EURODRIVE JAPAN CO., LTD 250-1, Shimoman-no, Iwata Shizuoka 438-0818	Tel. +81 538 373811 Fax +81 538 373814 <a href="http://www.sew-eurodrive.co.jp">http://www.sew-eurodrive.co.jp</a> sewjapan@sew-eurodrive.co.jp
Korea			
<b>Assembly Sales Service</b>	<b>Ansan-City</b>	SEW-EURODRIVE KOREA CO., LTD. B 601-4, Banweol Industrial Estate 1048-4, Shingil-Dong Ansan 425-120	Tel. +82 31 492-8051 Fax +82 31 492-8056 <a href="http://www.sew-korea.co.kr">http://www.sew-korea.co.kr</a> master@sew-korea.co.kr



<b>Korea</b>			
	<b>Busan</b>	SEW-EURODRIVE KOREA Co., Ltd. No. 1720 - 11, Songjeong - dong Gangseo-ku Busan 618-270	Tel. +82 51 832-0204 Fax +82 51 832-0230 master@sew-korea.co.kr
<b>Latvia</b>			
<b>Sales</b>	<b>Riga</b>	SIA Alas-Kuul Katlakalna 11C LV-1073 Riga	Tel. +371 7139253 Fax +371 7139386 <a href="http://www.alas-kuul.com">http://www.alas-kuul.com</a> info@alas-kuul.com
<b>Lebanon</b>			
<b>Sales</b>	<b>Beirut</b>	Gabriel Acar & Fils sarl B. P. 80484 Bourj Hammoud, Beirut	Tel. +961 1 4947-86 +961 1 4982-72 +961 3 2745-39 Fax +961 1 4949-71 ssacar@inco.com.lb
<b>Lithuania</b>			
<b>Sales</b>	<b>Alytus</b>	UAB Irseva Naujoji 19 LT-62175 Alytus	Tel. +370 315 79204 Fax +370 315 56175 info@irseva.lt <a href="http://www.sew-eurodrive.lt">http://www.sew-eurodrive.lt</a>
<b>Luxembourg</b>			
<b>Assembly Sales Service</b>	<b>Brüssel</b>	CARON-VECTOR S.A. Avenue Eiffel 5 B-1300 Wavre	Tel. +32 10 231-311 Fax +32 10 231-336 <a href="http://www.sew-eurodrive.lu">http://www.sew-eurodrive.lu</a> info@caron-vector.be
<b>Malaysia</b>			
<b>Assembly Sales Service</b>	<b>Johore</b>	SEW-EURODRIVE SDN BHD No. 95, Jalan Seroja 39, Taman Johor Jaya 81000 Johor Bahru, Johor West Malaysia	Tel. +60 7 3549409 Fax +60 7 3541404 sales@sew-eurodrive.com.my
<b>Mexico</b>			
<b>Assembly Sales Service</b>	<b>Quéretaro</b>	SEW-EURODRIVE MEXICO SA DE CV SEM-981118-M93 Tequisquiapan No. 102 Parque Industrial Quéretaro C.P. 76220 Quéretaro, México	Tel. +52 442 1030-300 Fax +52 442 1030-301 <a href="http://www.sew-eurodrive.com.mx">http://www.sew-eurodrive.com.mx</a> scmexico@seweurodrive.com.mx
<b>Morocco</b>			
<b>Sales</b>	<b>Casablanca</b>	Afit 5, rue Emir Abdelkader MA 20300 Casablanca	Tel. +212 22618372 Fax +212 22618351 ali.alami@premium.net.ma
<b>Netherlands</b>			
<b>Assembly Sales Service</b>	<b>Rotterdam</b>	VECTOR Aandrijftechniek B.V. Industrieweg 175 NL-3044 AS Rotterdam Postbus 10085 NL-3004 AB Rotterdam	Tel. +31 10 4463-700 Fax +31 10 4155-552 <a href="http://www.vector.nu">http://www.vector.nu</a> info@vector.nu



New Zealand			
Assembly Sales Service	Auckland	SEW-EURODRIVE NEW ZEALAND LTD. P.O. Box 58-428 82 Greenmount drive East Tamaki Auckland	Tel. +64 9 2745627 Fax +64 9 2740165 <a href="http://www.sew-eurodrive.co.nz">http://www.sew-eurodrive.co.nz</a> <a href="mailto:sales@sew-eurodrive.co.nz">sales@sew-eurodrive.co.nz</a>
	Christchurch	SEW-EURODRIVE NEW ZEALAND LTD. 10 Settlers Crescent, Ferryroad Christchurch	Tel. +64 3 384-6251 Fax +64 3 384-6455 <a href="mailto:sales@sew-eurodrive.co.nz">sales@sew-eurodrive.co.nz</a>
Norway			
Assembly Sales Service	Moss	SEW-EURODRIVE A/S Solgaard skog 71 N-1599 Moss	Tel. +47 69 24 10 20 Fax +47 69 24 10 40 <a href="http://www.sew-eurodrive.no">http://www.sew-eurodrive.no</a> <a href="mailto:sew@sew-eurodrive.no">sew@sew-eurodrive.no</a>
Peru			
Assembly Sales Service	Lima	SEW DEL PERU MOTORES REDUCTORES S.A.C. Los Calderos, 120-124 Urbanizacion Industrial Vulcano, ATE, Lima	Tel. +51 1 3495280 Fax +51 1 3493002 <a href="http://www.sew-eurodrive.com.pe">http://www.sew-eurodrive.com.pe</a> <a href="mailto:sewperu@sew-eurodrive.com.pe">sewperu@sew-eurodrive.com.pe</a>
Poland			
Assembly Sales Service	Lodz	SEW-EURODRIVE Polska Sp.z.o.o. ul. Techniczna 5 PL-92-518 Łódź	Tel. +48 42 676 53 00 Fax +48 42 676 53 45 <a href="http://www.sew-eurodrive.pl">http://www.sew-eurodrive.pl</a> <a href="mailto:sew@sew-eurodrive.pl">sew@sew-eurodrive.pl</a>
		24 Hour Service	Tel. +48 602 739 739 (+48 602 SEW SEW) <a href="mailto:sewis@sew-eurodrive.pl">sewis@sew-eurodrive.pl</a>
Portugal			
Assembly Sales Service	Coimbra	SEW-EURODRIVE, LDA. Apartado 15 P-3050-901 Mealhada	Tel. +351 231 20 9670 Fax +351 231 20 3685 <a href="http://www.sew-eurodrive.pt">http://www.sew-eurodrive.pt</a> <a href="mailto:infosew@sew-eurodrive.pt">infosew@sew-eurodrive.pt</a>
Romania			
Sales Service	București	Sialco Trading SRL str. Madrid nr.4 011785 Bucuresti	Tel. +40 21 230-1328 Fax +40 21 230-7170 <a href="mailto:sialco@sialco.ro">sialco@sialco.ro</a>
Russia			
Assembly Sales Service	St. Petersburg	ZAO SEW-EURODRIVE P.O. Box 36 195220 St. Petersburg Russia	Tel. +7 812 3332522 +7 812 5357142 Fax +7 812 3332523 <a href="http://www.sew-eurodrive.ru">http://www.sew-eurodrive.ru</a> <a href="mailto:sew@sew-eurodrive.ru">sew@sew-eurodrive.ru</a>
Senegal			
Sales	Dakar	SENEMECA Mécanique Générale Km 8, Route de Rufisque B.P. 3251, Dakar	Tel. +221 338 494 770 Fax +221 338 494 771 <a href="mailto:senemeca@sentoo.sn">senemeca@sentoo.sn</a>
Serbia			
Sales	Beograd	DIPAR d.o.o. Ustanicka 128a PC Košum, IV floor SCG-11000 Beograd	Tel. +381 11 347 3244 / +381 11 288 0393 Fax +381 11 347 1337 <a href="mailto:office@dipar.co.yu">office@dipar.co.yu</a>



<b>Singapore</b>			
<b>Assembly Sales Service</b>	<b>Singapore</b>	SEW-EURODRIVE PTE. LTD. No 9, Tuas Drive 2 Jurong Industrial Estate Singapore 638644	Tel. +65 68621701 Fax +65 68612827 <a href="http://www.sew-eurodrive.com.sg">http://www.sew-eurodrive.com.sg</a> <a href="mailto:sewsingapore@sew-eurodrive.com">sewsingapore@sew-eurodrive.com</a>
<b>Slovakia</b>			
<b>Sales</b>	<b>Bratislava</b>	SEW-Eurodrive SK s.r.o. Rybničná 40 SK-831 06 Bratislava	Tel. +421 2 33595 202 Fax +421 2 33595 200 <a href="mailto:sew@sew-eurodrive.sk">sew@sew-eurodrive.sk</a> <a href="http://www.sew-eurodrive.sk">http://www.sew-eurodrive.sk</a>
	<b>Žilina</b>	SEW-Eurodrive SK s.r.o. Industry Park - PChZ ulica M.R.Štefánika 71 SK-010 01 Žilina	Tel. +421 41 700 2513 Fax +421 41 700 2514 <a href="mailto:sew@sew-eurodrive.sk">sew@sew-eurodrive.sk</a>
	<b>Banská Bystrica</b>	SEW-Eurodrive SK s.r.o. Rudlovská cesta 85 SK-974 11 Banská Bystrica	Tel. +421 48 414 6564 Fax +421 48 414 6566 <a href="mailto:sew@sew-eurodrive.sk">sew@sew-eurodrive.sk</a>
	<b>Košice</b>	SEW-Eurodrive SK s.r.o. Slovenská ulica 26 SK-040 01 Košice	Tel. +421 55 671 2245 Fax +421 55 671 2254 <a href="mailto:sew@sew-eurodrive.sk">sew@sew-eurodrive.sk</a>
<b>Slovenia</b>			
<b>Sales Service</b>	<b>Celje</b>	Pakman - Pogonska Tehnika d.o.o. Ul. XIV. divizije 14 SLO - 3000 Celje	Tel. +386 3 490 83-20 Fax +386 3 490 83-21 <a href="mailto:pakman@siol.net">pakman@siol.net</a>
<b>South Africa</b>			
<b>Assembly Sales Service</b>	<b>Johannesburg</b>	SEW-EURODRIVE (PROPRIETARY) LIMITED Eurodrive House Cnr. Adcock Ingram and Aerodrome Roads Aeroton Ext. 2 Johannesburg 2013 P.O.Box 90004 Bertsham 2013	Tel. +27 11 248-7000 Fax +27 11 494-3104 <a href="http://www.sew.co.za">http://www.sew.co.za</a> <a href="mailto:info@sew.co.za">info@sew.co.za</a>
	<b>Cape Town</b>	SEW-EURODRIVE (PROPRIETARY) LIMITED Rainbow Park Cnr. Racecourse & Omuramba Road Montague Gardens Cape Town P.O.Box 36556 Chempet 7442 Cape Town	Tel. +27 21 552-9820 Fax +27 21 552-9830 Telex 576 062 <a href="mailto:cfoster@sew.co.za">cfoster@sew.co.za</a>
	<b>Durban</b>	SEW-EURODRIVE (PROPRIETARY) LIMITED 2 Monaco Place Pinetown Durban P.O. Box 10433, Ashwood 3605	Tel. +27 31 700-3451 Fax +27 31 700-3847 <a href="mailto:cdejager@sew.co.za">cdejager@sew.co.za</a>
<b>Spain</b>			
<b>Assembly Sales Service</b>	<b>Bilbao</b>	SEW-EURODRIVE ESPAÑA, S.L. Parque Tecnológico, Edificio, 302 E-48170 Zamudio (Vizcaya)	Tel. +34 94 43184-70 Fax +34 94 43184-71 <a href="http://www.sew-eurodrive.es">http://www.sew-eurodrive.es</a> <a href="mailto:sew.spain@sew-eurodrive.es">sew.spain@sew-eurodrive.es</a>



Sweden			
<b>Assembly Sales Service</b>	<b>Jönköping</b>	SEW-EURODRIVE AB Gnejsvägen 6-8 S-55303 Jönköping Box 3100 S-55003 Jönköping	Tel. +46 36 3442 00 Fax +46 36 3442 80 <a href="http://www.sew-eurodrive.se">http://www.sew-eurodrive.se</a> <a href="mailto:jonkoping@sew.se">jonkoping@sew.se</a>
Switzerland			
<b>Assembly Sales Service</b>	<b>Basel</b>	Alfred Imhof A.G. Jurastrasse 10 CH-4142 Münchenstein bei Basel	Tel. +41 61 417 1717 Fax +41 61 417 1700 <a href="http://www.imhof-sew.ch">http://www.imhof-sew.ch</a> <a href="mailto:info@imhof-sew.ch">info@imhof-sew.ch</a>
Thailand			
<b>Assembly Sales Service</b>	<b>Chonburi</b>	SEW-EURODRIVE (Thailand) Ltd. 700/456, Moo.7, Donhuaroh Muang Chonburi 20000	Tel. +66 38 454281 Fax +66 38 454288 <a href="mailto:sewthailand@sew-eurodrive.com">sewthailand@sew-eurodrive.com</a>
Tunisia			
<b>Sales</b>	<b>Tunis</b>	T. M.S. Technic Marketing Service Zone Industrielle Mghira 2 Lot No. 39 2082 Fouchana	Tel. +216 71 4340-64 + 71 4320-29 Fax +216 71 4329-76 <a href="mailto:tms@tms.com.tn">tms@tms.com.tn</a>
Turkey			
<b>Assembly Sales Service</b>	<b>Istanbul</b>	SEW-EURODRIVE Hareket Sistemleri San. ve Tic. Ltd. Sti. Bagdat Cad. Koruma Cikmazi No. 3 TR-34846 Maltepe ISTANBUL	Tel. +90 216 4419164, 3838014, 3738015 Fax +90 216 3055867 <a href="http://www.sew-eurodrive.com.tr">http://www.sew-eurodrive.com.tr</a> <a href="mailto:sew@sew-eurodrive.com.tr">sew@sew-eurodrive.com.tr</a>
Ukraine			
<b>Sales Service</b>	<b>Dnepropetrovsk</b>	SEW-EURODRIVE Str. Rabochaja 23-B, Office 409 49008 Dnepropetrovsk	Tel. +380 56 370 3211 Fax +380 56 372 2078 <a href="http://www.sew-eurodrive.ua">http://www.sew-eurodrive.ua</a> <a href="mailto:sew@sew-eurodrive.ua">sew@sew-eurodrive.ua</a>
USA			
<b>Production Assembly Sales Service Corporate Offices</b>	<b>Southeast Region</b>	SEW-EURODRIVE INC. 1295 Old Spartanburg Highway P.O. Box 518 Lyman, S.C. 29365	Tel. +1 864 439-7537 Fax Sales +1 864 439-7830 Fax Manufacturing +1 864 439-9948 Fax Assembly +1 864 439-0566 Fax Confidential/HR +1 864 949-5557 <a href="http://www.seweurodrive.com">http://www.seweurodrive.com</a> <a href="mailto:cslyman@seweurodrive.com">cslyman@seweurodrive.com</a>
<b>Assembly Sales Service</b>	<b>Northeast Region</b>	SEW-EURODRIVE INC. Pureland Ind. Complex 2107 High Hill Road, P.O. Box 481 Bridgeport, New Jersey 08014	Tel. +1 856 467-2277 Fax +1 856 845-3179 <a href="mailto:csbridgeport@seweurodrive.com">csbridgeport@seweurodrive.com</a>
	<b>Midwest Region</b>	SEW-EURODRIVE INC. 2001 West Main Street Troy, Ohio 45373	Tel. +1 937 335-0036 Fax +1 937 440-3799 <a href="mailto:cstroy@seweurodrive.com">cstroy@seweurodrive.com</a>
	<b>Southwest Region</b>	SEW-EURODRIVE INC. 3950 Platinum Way Dallas, Texas 75237	Tel. +1 214 330-4824 Fax +1 214 330-4724 <a href="mailto:csdallas@seweurodrive.com">csdallas@seweurodrive.com</a>
	<b>Western Region</b>	SEW-EURODRIVE INC. 30599 San Antonio St. Hayward, CA 94544	Tel. +1 510 487-3560 Fax +1 510 487-6433 <a href="mailto:cshayward@seweurodrive.com">cshayward@seweurodrive.com</a>
Additional addresses for service in the USA provided on request!			





Venezuela			
<b>Assembly</b>	<b>Valencia</b>	SEW-EURODRIVE Venezuela S.A.	Tel. +58 241 832-9804
<b>Sales</b>		Av. Norte Sur No. 3, Galpon 84-319	Fax +58 241 838-6275
<b>Service</b>		Zona Industrial Municipal Norte	<a href="http://www.sew-eurodrive.com.ve">http://www.sew-eurodrive.com.ve</a>
		Valencia, Estado Carabobo	<a href="mailto:ventas@sew-eurodrive.com.ve">ventas@sew-eurodrive.com.ve</a>
			<a href="mailto:sewfinanzas@cantv.net">sewfinanzas@cantv.net</a>



## Index

### A

#### Applications

Disconnection of single drives via inverter and DFS11B/21B fieldbus interface .....	32
Disconnection of single drives via inverter, example MOVIAXIS® .....	31
Disconnection of single drives via inverter, example MOVIDRIVE® B .....	30
Group disconnection via inverter .....	33

### B

#### Block diagram

BST .....	11
-----------	----

#### Brake function

Checking .....	28
----------------	----

#### BST

Block diagram .....	11
Dimension drawings .....	36
Mounting, support rail .....	21
Removal, support rail .....	22
Technical data .....	34
Unit replacement .....	28
Unit structure .....	20

### C

Copyright notice .....	6
------------------------	---

### D

Designated use .....	8
----------------------	---

#### Dimension drawings

BST .....	36
Supply module for BST .....	39

Disposal .....	9
----------------	---

Double-pole safe disconnection .....	24
--------------------------------------	----

### E

Electrical installation .....	23
-------------------------------	----

Exclusion of liability .....	6
------------------------------	---

#### External safety controller

Requirements .....	16
--------------------	----

### I

Inspection .....	27
------------------	----

Inspection intervals .....	27
----------------------------	----

#### Installation

Electrical .....	23
------------------	----

Mechanical .....	21
------------------	----

Requirements .....	14
--------------------	----

Integrated safety technology .....	10
------------------------------------	----

### M

Maintenance .....	27
-------------------	----

Maintenance intervals .....	27
-----------------------------	----

Mechanical installation .....	21
-------------------------------	----

### N

#### Nameplate

BST .....	19
-----------	----

Supply module for BST .....	37
-----------------------------	----

### O

Operating states .....	26
------------------------	----

#### Operation

Requirements .....	18
--------------------	----

### P

Permitted unit combinations .....	13
-----------------------------------	----

### R

#### Requirements

External safety controller .....	16
----------------------------------	----

Installation .....	14
--------------------	----

Operation .....	18
-----------------	----

Startup .....	17
---------------	----

Restrictions .....	12
--------------------	----

Rights to claim under limited warranty .....	6
--	---

### S

Safe condition .....	10
----------------------	----

#### Safe disconnection

Double-pole .....	24
-------------------	----

single-pole .....	25
-------------------	----

Safety concept .....	10
----------------------	----

#### Safety control, external

Requirements .....	16
--------------------	----

Safety function .....	11
-----------------------	----

Safety notes .....	7
--------------------	---

.....	5
-------	---


#### Safety switching device


Sample circuit .....	17
----------------------	----


#### Safety technology





Integrated .....	10
Safety-relevant conditions .....	13
Scope of delivery	
BST .....	19
Service .....	28
Single-pole safe disconnection .....	25
Startup .....	26
Startup requirements .....	17
Structure of the safety notes .....	5
Supply module	
Dimension drawings .....	39
for BST (in preparation) .....	37
Technical data .....	37
Wiring diagram .....	38
<b>T</b>	
Target group .....	8
Technical data	
BST .....	34
General .....	34
Safety-related characteristic values .....	35
Safety-related control voltage .....	35
Supply module .....	37
Terminal assignment	
BST .....	20
Supply module for BST .....	37
Transport .....	8
<b>U</b>	
Unit combinations	
Permitted .....	13
Unit design	
Safety-relevant BST brake module .....	19
Unit designation	
BST .....	19
Unit structure	
BST .....	20











**SEW-EURODRIVE**  
Driving the world

**SEW**  
**EURODRIVE**

SEW-EURODRIVE GmbH & Co KG  
P.O. Box 3023  
D-76642 Bruchsal/Germany  
Phone +49 7251 75-0  
Fax +49 7251 75-1970  
sew@sew-eurodrive.com

→ [www.sew-eurodrive.com](http://www.sew-eurodrive.com)