



SEW
EURODRIVE

Assembly and Operating Instructions



Gear Unit Series BS.F., PS.F. and PS.C..





Content

1	General Information	5
1.1	How to use the operating instructions	5
1.2	Structure of the safety notes	5
1.3	Rights to claim under limited warranty	6
1.4	Exclusion of liability	6
1.5	Copyright.....	6
1.6	Product name and trademarks.....	6
2	Safety Notes	7
2.1	Preface.....	7
2.2	General information	7
2.3	Target group	8
2.4	Designated use	8
2.5	Other applicable documentation	8
2.6	Transport.....	9
2.7	Installation/assembly.....	9
2.8	Startup/operation	9
2.9	Inspection/maintenance	9
3	Gear Unit Design	10
3.1	Basic structure – Gear unit	11
3.2	Basic structure – Adapter.....	15
3.3	Nameplate / type designation	18
4	Mechanical Installation.....	20
4.1	Required tools/resources	20
4.2	Prerequisites for installation.....	21
4.3	Installing the gear unit.....	22
4.4	Installation in a machine: BS.F.. helical-bevel gear unit	26
4.5	Installation in a machine: PS.F.. planetary gear units.....	28
4.6	Installation in a machine: PS.C.. planetary gear unit	28
4.7	Mounting output elements to solid shafts of BS.F., PS.F. and PS.C.. gear units	29
4.8	Mounting of couplings	32
4.9	Installing a torque arm on BS.F.. shaft-mounted gear units.....	33
4.10	Shaft-mounted gear units with keyway	34
4.11	Shaft-mounted gear unit with shrink disk	36
4.12	Motor mounting	40
4.13	Demounting the motor	47
5	Startup.....	48
5.1	Design-related special features	48
5.2	Measuring the surface temperature	49



6	Inspection and Maintenance	50
6.1	Preliminary work regarding gear unit inspection/maintenance	50
6.2	Inspection/maintenance intervals.....	51
6.3	Lubricant change intervals	51
7	Mounting Positions	53
7.1	Designation of the mounting positions	53
7.2	BS.F.. helical-bevel servo gearmotors	55
7.3	PS.F., PS.C.. planetary servo gearmotors	58
8	Technical Data	60
8.1	Lubricants	60
9	Malfunctions	65
9.1	Gear unit	65
9.2	Customer service	65
9.3	Disposal	66
10	Address List	67
	Index.....	79



1 General Information

1.1 How to use the operating instructions

The operating instructions are an integral part of the product and contain important information for operation and service. The operating instructions are written for all employees who assemble, install, startup, and service the product.

The operating instructions must be legible and accessible at all times. Make sure that staff responsible for the plant and its operation, as well as persons who work independently on the unit, have read the operating instructions carefully and understood them. If you are unclear about any of the information in this documentation, or if you require further information, contact SEW-EURODRIVE.

1.2 Structure of the safety notes

1.2.1 Meaning of signal words

The following table shows the grading and meaning of the signal words for safety notes, warnings regarding potential risks of damage to property, and other notes.

Signal word	Meaning	Consequences if disregarded
▲ DANGER	Imminent danger	Severe or fatal injuries
▲ WARNING	Possible dangerous situation	Severe or fatal injuries
▲ CAUTION	Possible dangerous situation	Minor injuries
NOTICE	Possible damage to property	Damage to the drive system or its environment
INFORMATION	Useful information or tip: Simplifies handling of the drive system.	

1.2.2 Structure of the section-related safety notes

Section-related safety notes do not apply to a specific action, but to several actions pertaining to one subject. The used symbols indicate either a general or a specific hazard.

This is the formal structure of a section-related safety note:



▲ SIGNAL WORD

Nature and source of danger.

Possible consequence(s) if disregarded.

- Measure(s) to avoid the danger.

1.2.3 Structure of the embedded safety notes

Embedded safety notes are directly integrated in the instructions just before the description of the dangerous action.

This is the formal structure of an embedded safety note:

- **▲ SIGNAL WORD Nature and source of danger.**
Possible consequence(s) if disregarded.
– Measure(s) to avoid the danger.

**1.3 Rights to claim under limited warranty**

Adhering to the operating instructions is a prerequisite for fault-free operation and the fulfillment of any right to claim under warranty. Read the operating instructions before you start working with the unit.

1.4 Exclusion of liability

Compliance with the information contained in these operating instructions is essential to ensure safe operation of the BS.F.. helical-bevel gear units and PS.F../PS.C.. planetary gear units and to achieve the specified product characteristics and performance requirements. SEW-EURODRIVE assumes no liability for injury to persons or damage to equipment or property resulting from non-observance of the documentation. In such cases, any liability for defects is excluded.

1.5 Copyright

© 2012 - SEW-EURODRIVE. All rights reserved.

Copyright law prohibits the unauthorized duplication, modification, distribution, and use of this document, in whole or in part.

1.6 Product name and trademarks

The brands and product names contained within this publication are trademarks or registered trademarks of the titleholders.



2 Safety Notes

The following basic safety notes must be read carefully to prevent injury to persons and damage to property. The operator must ensure that the basic safety notes are read and observed. Make sure that persons responsible for the plant and its operation, as well as persons who work independently on the unit, have read through the operating instructions carefully and understood them. If you are unclear about any of the information in this documentation, or if you require further information, please contact SEW-EURODRIVE.

2.1 Preface

The following safety notes are primarily concerned with the use of gear units. If using gearmotors, please also refer to the safety notes for motors in the corresponding operating instructions.

Also observe the supplementary safety notes in the individual sections of these operating instructions.

2.2 General information



⚠ WARNING

During operation, the motors and gearmotors can have live, bare and movable or rotating parts as well as hot surfaces, depending on their enclosure.

Severe or fatal injuries.

- All work related to transportation, storage, setup/mounting, connection, startup, maintenance and repair may only be carried out by qualified personnel, in strict observance of:
 - The relevant detailed operating instructions
 - The warning and safety signs on the motor/gearmotor
 - All other project planning documents, operating instructions and wiring diagrams related to the drive
 - The specific regulations and requirements for the system
 - The national/regional regulations governing safety and the prevention of accidents
- Never install damaged products
- Immediately report any damage to the shipping company

Removing covers without authorization, improper use as well as incorrect installation or operation may result in severe injuries to persons or damage to property.

Refer to the documentation for additional information.



2.3 Target group

Any mechanical work may only be performed by adequately qualified personnel. Qualified personnel in this context are persons who are familiar with the setup, mechanical installation, troubleshooting and maintenance for this product. Further, they are qualified as follows:

- Training in mechanical engineering, e.g. as a mechanic or mechatronics technician (final examinations must have been passed).
- They are familiar with these operating instructions.

Any electronic work may only be performed by adequately qualified electricians. Qualified electricians in this context are persons who are familiar with the electronic installation, startup, troubleshooting and maintenance for this product. Further, they are qualified as follows:

- Training in electrical engineering, e.g. as an electrician or mechatronics technician (final examinations must have been passed).
- They are familiar with these operating instructions.

All work in further areas of transportation, storage, operation and waste disposal must only be carried out by persons who are trained appropriately.

All qualified personnel must wear appropriate protective clothing.

2.4 Designated use

The gear units are intended for industrial systems and may only be used in accordance with the information provided in SEW-EURODRIVE's technical documentation and the information given on the nameplate. They fulfill the applicable standards and regulations.

According to the 2006/42/EC Machinery Directive, the gear units are components for the installation in machines and plants. In the scope of the Directive, you must not take the machinery into operation in the proper fashion until you have established that the end product complies with Machinery Directive 2006/42/EC.

Using these products in potentially explosive atmospheres is prohibited, unless specifically designated otherwise.

2.5 Other applicable documentation

The following publications and documents have to be observed as well:

- "AC Motors, Asynchronous Servomotors" operating instructions for gearmotors
- "Synchronous Servomotors" operating instructions
- Operating instructions of any attached options
- "Synchronous Servo Gearmotors" catalog
- "Asynchronous Servomotors" catalog
- "Gear Units" catalog and/or "Gearmotors" catalog
- "Servo Gear Units" catalog



2.6 *Transport*

Inspect the shipment for any damage that may have occurred in transit as soon as you receive the delivery. Inform the shipping company immediately. It may be necessary to preclude startup.

Tighten installed eyebolts. They are designed to only carry the weight of the motor/gear-motor; do not attach any additional loads.

The built-in lifting eyebolts meet DIN 580. Always observe the loads and regulations listed in this standard. If the gearmotor is equipped with 2 suspension eye lugs or lifting eyebolts, then both of the suspension eye lugs should be used for transportation. In this case, the tension force vector of the slings must not exceed a 45° angle according to DIN 580.

Use suitable, sufficiently rated handling equipment if necessary. Remove any transportation fixtures prior to startup.

2.7 *Installation/assembly*

Observe the notes in chapter "Mechanical Installation" (page 20).

2.8 *Startup/operation*

Before startup, check the oil level as described in chapter "Inspection/Maintenance".

Check that the direction of rotation is correct in **decoupled** status. Listen out for unusual grinding noises as the shaft rotates.

Secure keys for test mode without output elements. Do not deactivate monitoring and protection equipment even in test mode.

Switch off the gearmotor if in doubt whenever changes occur in relation to normal operation (e.g. increased temperature, noise, vibration). Determine the cause and contact SEW-EURODRIVE, if required.

2.9 *Inspection/maintenance*

Observe the notes in chapter "Inspection/Maintenance" (page 50).



3 Gear Unit Design

**INFORMATION**

For information about the scope of delivery and project planning, refer to the "Synchronous Servo Gearmotors" catalog and the operating instructions for the motor used to drive the gear unit.


**INFORMATION**

The following illustrations are intended to explain the general structure. They help you to assign components to the spare parts list. Discrepancies may occur depending on the gear unit size and variant.



3.1 Basic structure – Gear unit

3.1.1 BS.F.. helical-bevel gear units




1840072331

[1] Pinion	[19] Key	[85] Centering flange	[160] Closing plug
[2] Gear	[22] Gear unit housing	[88] Retaining ring	[166] Supporting ring
[5] Bevel pinion shaft	[23] Supporting ring	[89] Closing cap	[168] Protection cap
[6] Bevel gear	[25] Taper roller bearings	[98] Shrink disk	[183] Oil seal
[7a] Output shaft (BSF..)	[29] Adhesive and sealing compound	[99] Cover	[250] Retaining ring
[7b] Output shaft (BSKF..)	[42] Taper roller bearing	[103] O-ring	[251] Retaining ring
[7c] Key (BSKF..)	[43] Key	[113] Slotted nut	[335] Torque arm
[9] Oil seal	[45] Taper roller bearing	[116] Thread locker	[518] - Shims
[11] Taper roller bearing	[48] Supporting ring	[131] Closing cap	[523] - Shims
[12] Retaining ring	[49] O-ring	[142] Cylinder head screw	
[17] Supporting ring	[84] Shield ring ¹⁾	[153] Adhesive and sealing compound	

1) Only for mounting position M5



3.1.2 PSF../PSKF.. planetary gear units



1881393163


[1] Planet carrier for output, complete	[30] Shield ring ¹⁾	[109] Grooved ball bearing
[6] Key ²⁾	[39] Safety disk	[110] Retaining ring
[7] Shaft nut	[41] Countersunk pin	[112] Needle-roller assembly
[8] Oil seal	[46] Adhesive and sealing compound	[113] Planet gear
[12] Taper roller bearing	[55] Thrust plate	[114] Sun gear
[13] Taper roller bearing	[56] O-ring	[116] O-ring
[17] Planet gear	[58] Eyebolt	[118] Housing preliminary stage
[18] Needle-roller assembly	[100] Stud	[121] Snap ring
[22] Sun gear	[105] Thrust plate	[122] Safety disk
[24] Housing	[106] Planet carrier, complete	[123] Countersunk pin
[25] Screw plug	[107] Hex nut	[146] Adhesive and sealing compound

1) Only for mounting position M2

2) Only for PSKF



3.1.3 PSBF.. planetary gear units



1881492491


[1] Planet carrier for output	[25] Screw plug	[110] Retaining ring
[8] Oil seal	[46] Adhesive and sealing compound	[112] Needle roller
[12] Angular contact ball bearing ¹⁾	[56] O-ring	[113] Planet gear
[12] Taper roller bearings ²⁾	[57] Shaft nut	[114] Sun gear
[13] Angular contact ball bearing ¹⁾	[58] Eyebolt	[116] O-ring
[13] Taper roller bearings ²⁾	[100] Stud	[118] Housing preliminary stage
[16] Planetary gear axle	[105] Thrust plate	[121] Snap ring
[17] Planet gear	[106] Planet carrier, complete	[122] Safety disk
[18] Needle roller	[107] Hex nut	[123] Countersunk pin
[22] Sun gear	[109] Grooved ball bearing	[146] Adhesive and sealing compound
[24] Housing		

1) Only for PSBF222

2) Only for PSBF322 – 822



3.1.4 PS.C.. planetary gear units



1885879563


[1] Planet carrier for output	[18] Needle roller	[106] Preliminary stage planet carrier
[5] Hardened cylindrical pin	[21] Retaining ring	[111] Planetary gear axle
[6] Key ¹⁾	[22] Sun gear	[112] Needle roller
[8] Oil seal	[24] Drive flange	[113] Planet gear
[11] O-ring	[46] Adhesive and sealing compound	[114] Sun gear
[12] Grooved ball bearing	[55] Thrust plate	[116] O-ring
[13] Grooved ball bearing	[56] O-ring	[118] Annulus
[16] Planetary gear axle	[59] Annulus	[146] Adhesive and sealing compound
[17] Planet gear	[105] Thrust plate	[246] Adhesive and sealing compound

1) For PSKC and PSKCZ



3.2 Basic structure – adapter

3.2.1 EBH.. adapter for BS.F.. helical-bevel gear units



1840077707


[201]	Retaining ring/snap ring	[217]	Grooved ball bearing	[402]	Retaining ring
[202]	Key	[220]	Screw plug ¹⁾ / breather valve ²⁾	[404]	Retaining ring
[203]	Oil seal with optimized spring force	[223]	Grooved ball bearing	[442]	Adapter flange
[204]	Stud	[229]	Clamping ring	[470]	Machine screw
[205]	Tooth lock washer	[230]	Coupling sleeve	[471]	Tooth lock washer
[207]	Flange	[232]	Press-fit bolt	[483]	Coupling
[212]	Adapter shaft	[239]	Closing plug	[502] -	Shims
[216]	Adhesive and sealing compound			[503] -	Shims
				[504]	Shims

1) For mounting positions M1 – M3, M5, M6 only

2) For mounting position M4 only



3.2.2 EPH.. adapter for PS.F.. and PS.C.. planetary gear units




1881495179

[203]	Oil seal	[223]	Grooved ball bearing	[402]	Retaining ring
[204]	Stud	[229]	Clamping ring	[404]	Retaining ring
[206]	Hex nut	[230]	Coupling sleeve	[442]	Adapter flange
[207]	Flange	[231]	Closing cap	[470]	Machine screw
[212]	Adapter shaft	[247]	Shim washer	[471]	Toothed washer
[216]	Adhesive and sealing compound	[399]	Closing plug		



3.2.3 ECH.. adapter for PS.C.. planetary gear units



1885885323

[203] Oil seal
[204] Stud
[206] Hex nut

[207] Adapter flange
[212] Adapter shaft
[229] Setscrew

[230] Motor shaft sleeve
[399] Closing plug
[471] Washer



3.3 Nameplate / type designation




INFORMATION

The nameplate of the servo gearmotor is fixed to the servomotor.

3.3.1 Example: Nameplate of a PS.C.. planetary gear unit with ECH.. adapter

The following figure shows an example of a nameplate for a PS.C.. planetary gear unit with ECH adapter:




1872039435

i		Gear unit reduction ratio
IM		Mounting position
IP		Degree of protection
n _{epk}	[rpm]	Maximum permitted input speed
n _{apk}	[rpm]	Maximum permitted output speed
M _{apk}	[Nm]	Maximum permitted output torque

3.3.2 Example: Type designation of a PS.F.. planetary gear unit with EPH.. adapter


A planetary gear unit with adapter, for example, has the following type designation:





3.3.3 Example: Nameplate of a PS.C.. servo gearmotor with ECH.. adapter


The following figure shows an example of a nameplate for a PS.C.. planetary gear unit with ECH adapter:



i	Gear unit reduction ratio	n _N	[rpm]	Rated speed
IM	Mounting position	M ₀	[Nm]	Rated torque
IP	Degree of protection	I ₀	[A]	Rated current
n _{epk}	[rpm] Maximum permitted input speed	I _{max}	[A]	Maximum permitted current
n _{apk}	[rpm] Maximum permitted output speed	f _N	[Hz]	Rated frequency
M _{apk}	[Nm] Maximum permitted output torque	V _{max}	[V]	Maximum permitted voltage

3.3.4 Example: Type designation of a BS.F.. helical-bevel gear unit with CM motor

A helical-bevel servo gearmotor with brake, manual brake, positive temperature coefficient thermistor and plug connector with a connection cross section of 1.5 mm² has, for example, the following type designation:





4 Mechanical Installation

4.1 Required tools/resources

- Set of wrenches
- Torque wrench for:
 - Shrink disks
 - EBH / EPH / ECH motor adapter
- Set of screwdrivers with long hexagon shaft
- Mounting device
- Shims and distance rings if necessary
- Fixing devices for input and output elements
- Set of Allen keys
- Lubricant (e.g. NOCO® Fluid)
- Standard parts are not included in the delivery

4.1.1 Mounting tolerances

Shaft end	Flanges
Diameter tolerance in accordance with DIN 748 <ul style="list-style-type: none"> • ISO k6 for solid shafts with $\varnothing \leq 50$ mm • ISO m6 for solid shafts with $\varnothing > 50$ mm • ISO H7 for hollow shafts • Center bore in accordance with DIN 332, shape DR 	Centering shoulder tolerance to DIN 42948 <ul style="list-style-type: none"> • ISO j6 for $b1 \leq 230$ mm • ISO h6 with $b1 > 230$ mm



4.2 Prerequisites for installation



⚠ CAUTION

Risk of injury due to protruding gear unit parts.

Minor injuries.

- Ensure an adequate safety distance around the gear unit/gearmotor.



NOTICE

Damage to the gear unit/gearmotor due to improper installation.

Possible damage to property

- Strictly adhere to the notes in this chapter.

Ensure that the following requirements have been met:

- The entries on the nameplate of the gearmotor match the voltage supply system.
- The drive has not been damaged during transportation or storage.
- **For standard gear units:**
 - Ambient temperature according to the technical documentation, nameplate and lubricant table in chapter "Technical Data"/"Lubricants" (page 60).
 - No harmful oils, acids, gases, vapors, radiation etc. in the vicinity
- **For special designs:**
 - The drive is designed in accordance with the ambient conditions. Refer to the information on the nameplate.
- Clean the output shafts and flange surfaces thoroughly to ensure they are free of anti-corrosion agents, contamination or similar. Use a commercially available solvent. Do not expose the sealing lips of the oil seals to the solvent – damage to the material.
- When the drive is installed in abrasive ambient conditions, protect the output end oil seals against wear.
- Do not assemble the drive without having ensured that there will be sufficient ventilation after installation to prevent heat build-up.



4.3 Installing the gear unit



⚠ CAUTION

Improper assembly may result in damages to the gear unit/gearmotor.

Possible damage to property

- Strictly adhere to the notes in this chapter.
- Work on the gear unit only when the machine is not in use. Secure the drive unit against unintentional power-up.
- Protect the gear unit from direct cold air currents. Condensation may cause water to accumulate in the oil.

The gear unit or gearmotor is only allowed to be installed in the specified mounting position. Refer to the information on the nameplate.

The support structure must have the following characteristics:

- Level
- Vibration damping
- Torsionally rigid

The maximum permitted flatness error for foot and flange mounting (guide values with reference to DIN ISO 1101):

- | | |
|--|-------------|
| • Gear unit size PS.F / PS.C 120 – 520 : | Max. 0.2 mm |
| • Gear unit size PS.F / PS.C 620 – 920 : | Max. 0.4 mm |
| • Gear unit size BS.F 202 – 402: | Max. 0.4 mm |
| • Gear unit size BS.F 502 – 802: | Max. 0.5 mm |

Do not tighten the housing legs and mounting flanges against one another and ensure that you comply with the permitted overhung and axial loads! Observe chapter "Project Planning" in the Gear unit/gearmotor catalog for calculating the permitted overhung and axial loads.



INFORMATION

When installing the gear unit, make sure that the oil drain plugs as well as the breather plugs are easily accessible.

Use plastic inserts (2 – 3 mm thick) if there is a risk of electrochemical corrosion between the gear unit and the driven machine. The material used must have an electrical leakage resistance $< 10^9 \Omega$. Electrochemical corrosion can occur between various metals, for example, cast iron and high-grade steel. Also fit the bolts with plastic washers. Ground the housing additionally – use the grounding bolts on the motor.



4.3.1 Tightening torques for retaining screws

Mounting output elements

Adhere to the following information when mounting the output elements to the gear unit:

Machine screws with hexagon socket to DIN EN ISO 4762	Strength class	Tightening torque [Nm]
M4	12.9	5.1
M5	12.9	10
M6	12.9	18
M8	12.9	43
M10	12.9	84
M12	12.9	145

*Mounting gear unit
BS.F202 –
BS.F802 with B5
flange and
BS.F202B –
BS.F402B with
foot-mounting*

Mount the gearmotors with the following tightening torques:

Screw/nut	Strength class	Tightening torque [Nm]
M6	8.8	11
M8	8.8	25
M10	8.8	48
M12	8.8	86
M16	8.8	210
M20	8.8	410

Mounting gear units PS.F and PS.C with B5 flange, PS.C with B14 flange and BS.F502B – BS.F802B with foot-mounting

Mount the gearmotors with the following increased tightening torques:

Screw/nut	Strength class	Tightening torque [Nm]
M4	10.9	4.6
M5	10.9	8.6
M6	10.9	14
M8	10.9	35
M10	10.9	69
M12	10.9	120
M16	10.9	300
M20	10.9	600

4.3.2 Bolt sizes

Foot-mounted gear units

The following table shows the thread sizes of the gear units in foot-mounted design depending on the gear unit type and size:

Bolt	Gear unit type BS.F..B
M8	202
M10	302
M12	402 / 502
M16	602
M20	802



Gear units with B5 flange

The following table shows the thread sizes of the gear units with B5 flange depending on the gear unit type and size:

Screw	Gear unit type			
	BS.F..	PS.F..	PSBF..	PS.C..
M4	–	–	221, 222	–
M5	–	121, 122 / 221, 222	321, 322 / 521, 522	221, 222
M6	202	321, 322	621, 622	321, 322
M8	302	521, 522	721, 722 / 821, 822	521, 522
M10	402	621, 622	–	621, 622
M12	502	721, 722	–	–
M16	602 / 802	821, 822 / 921, 922	–	–

Gear units with B14 flange

The following table shows the thread sizes of the gear units with B14 flange depending on the gear unit type and size:

Bolt	Gear unit type PS.CZ
M5	221, 222
M6	321, 322
M8	521, 522
M10	621, 622

4.3.3 Installation in damp locations or in the open

Drives are supplied in corrosion-resistant versions with an according surface protection coating for use in damp areas or outdoors. Repair any damage to the paint work (e.g. on the breather valve or the eyebolts).

When mounting motors onto adapters, seal the flange areas with a suitable sealing compound, e.g. Loctite® 574.

Units installed outdoors must be protected from the sun. Suitable protective devices are required, such as covers or roofs. Avoid any heat accumulation. The operator must ensure that foreign objects do not impair the function of the gear unit (e.g. falling objects or coverings).



4.3.4 Gear unit ventilation

SEW-EURODRIVE supplies BS.F gear units with activated breather valve.

Exceptions:

SEW supplies the following gear units with a screw plug on the vent hole provided:


- Pivoted mounting positions, if possible
- Gear units for mounting on a slant

The breather valve is located in the motor terminal box. Before startup, replace the highest screw plug with the provided breather valve.

Activating the breather valve


Check whether the breather valve is activated. If the breather valve has not been activated, remove the transport fixture from the breather valve before starting up the gear unit.

1. Breather valve with transport fixture




211319051

2. Remove transport fixture



211316875

3. Activated breather valve



211314699



Mechanical Installation

Installation in a machine: BS.F.. helical-bevel gear units

4.3.5 Painting the gear unit



NOTICE

Breather valves and oil seals may be damaged during painting or re-painting.

Potential damage to property.

- Thoroughly cover the breather valves and the sealing lip of the oil seals with strips prior to painting.
- Remove the strips after painting.

If you want to paint the gear unit, check that the new paint is compatible with the existing protective varnish. If they are incompatible, the paint might be damaged, which means that the protective properties of the paint may no longer be ensured.

4.4 Installation in a machine: BS.F.. helical-bevel gear units

For a definition of mounting positions, refer to chapter "Mounting positions" (page 53).




INFORMATION

For the BS.F..202B – 402B gear unit variant, ensure that there is an engagement depth of 1.6-times the screw diameter in the gear unit's output flange.

For the BS.F..502B – 802B gear unit variant, ensure that there is an engagement depth of 1.25-times the screw diameter in the gear unit's output flange.

4.4.1 BS.F..: Mounted from the gear unit end via B5 flange:

The following figure shows the installation of BS.F.. helical-bevel gear units:




1839202059

- [1] Bolts of quality 8.8
[2] Nut



4.4.2 BSBF..B: Mounting at the foot end


The following figure shows foot-mounting of BSBF..B helical-bevel gear units:



1839204747

4.4.3 BSBF..B: Mounting at the front end

The following figure shows front-mounting of BSBF..B helical-bevel gear units:



1839207435




Mechanical Installation

Installation in a machine: PS.F.. planetary gear units

4.5 Installation in a machine: PS.F.. planetary gear units

4.5.1 PS.F.: Mounting the gear unit end via B5 flange:

The following figure shows the installation of PS.F.. planetary gear units:




1881669387

[1] Bolts of quality 10.9

4.6 Installation in a machine: PS.C.. planetary gear units

4.6.1 PS.C.: Mounting the gear unit end via B5 flange

The following figure shows the installation of PS.C.. planetary gear units:



1886151563


[1] Bolts of quality 10.9

[2] Washer



4.6.2 PS.CZ...: Mounting the gear unit end via B14 flange

The following figure shows the installation of PS.CZ.. planetary gear units:



1886154251

[1] Bolts of quality 10.9



INFORMATION

For the PS.CZ.. gear unit variant, ensure that there is an engagement depth of 1.6-times the screw diameter in the gear unit's output flange.

4.7 Mounting output elements to solid shafts of BS.F., PS.F. and PS.C.. gear units



NOTICE

Bearing, hosing or shaft may be damaged due to improper assembly.

Possible damage to property

- Only assemble the input and output components with a mounting device. Use the center bore and the thread on the shaft end for positioning.
- Never force belt pulleys, couplings, pinions, etc. onto the shaft end by hitting them with a hammer.
- In the case of belt pulleys, make sure the belt is tensioned correctly in accordance with the manufacturer's instructions.
- Power transmission elements should be balanced after fitting and must not give rise to any excessive radial or axial forces (see the "Synchronous Servo Gear-motors" catalog for permitted values).




Mechanical Installation

Mounting output elements to solid shafts of BS.F., PS.F. and PS.C. gear

4.7.1 Assembly with key

The following figure shows a sample mounting device for installing couplings [3] or hubs onto motor or gear unit shaft ends. It may be possible to dispense with the thrust bearing [2] on the mounting device.

The following figure shows assembly with mounting device:



1839217419

- [1] Shaft shoulder
- [2] Thrust bearing
- [3] Coupling hub



INFORMATION


The shaft shoulder [1] may be used as a defined stop point when mounting input or output elements to BSF. / BSKF. / PSF. / PSKF. / PS.C. / PSKC. / PS.CZ. / PSKCZ. gear units.

The output shafts are coated with an antirust agent on delivery. Remove the antirust agent before assembly, e.g. using a cleaning solvent.



4.7.2 Assembly without key

The following figures shows an example of shaft assembly with inner clamping set:



- [1] Shaft shoulder
- [2] Clamping set
- [3] Output element, e.g. gear or sprocket
- [4] Greased shaft areas
- [5] Ungreased clamping area




INFORMATION

When using clamping sets on smooth shaft ends, ensure that the shaft is free from residue and that any grease is removed. The clamping area [5] must be absolutely free of grease. Otherwise the shaft/hub connection may not function properly.

To prevent corrosion on the shaft, grease any uncovered areas [4] after assembly.

4.7.3 Avoiding excessive overhung loads

Avoid high overhung loads by: Installing the gear or chain sprocket according to figure B if possible.



- [1] Hub
- [A] Unfavorable
- [B] Correct




INFORMATION

Mounting is easier if you first apply lubricant to the output element or heat it up briefly (to 80 – 100 °C).

4.7.4 Flange block shaft mounting

The following figure shows the correct mounting arrangement of a shaft connection in combination with an inner and outer centering ring using the example of a BSBF.. flange block:



1839238283

- [1] Flange block
- [2] Gear/belt pulley with inner centering ring
- [3] Bolts of quality 12.9
- [4] Gear/belt pulley with outer centering ring

4.8 Mounting of couplings



⚠ CAUTION


Input and output components such as belt pulleys, couplings etc. are in fast motion during operation.

Risk of jamming and crushing.

- Cover input and output components with a touch guard.

Adjust the following misalignments according to the coupling manufacturer's specifications when mounting couplings.

- a) Maximum and minimum clearance
- b) Axial offset
- c) Angular offset




211395595

4.9 Installing a torque arm on BS.F.. shaft-mounted gear units

Do not place torque arms under strain during installation.

The following illustration shows the possible torque arm positions for BS.F.. gear units:



1839381771

Tighten the retaining screws according to the following table:

Gear unit size	Number, size, and strength class of screws according to DIN EN ISO 4762	Number, size, and strength class of screws according to DIN EN ISO 4762	Tightening torque in Nm
202	4 x M6x35-8.8	4 x M6	11
302	4 x M8x40-8.8	4 x M8	25
402	4 x M10x45-8.8	4 x M10	48
502	4 x M12x40-8.8	4 x M12	86
602	4 x M16x55-8.8	4 x M16	210
802	4 x M16x55-8.8	4 x M16	210

For aluminum parts, you must use suitable lock washers.



4.10 Shaft-mounted gear units with keyway




INFORMATION

Concerning the configuration of the customer shaft, please also refer to the design notes in the Gearmotors catalog!


4.10.1 Assembly notes

1. Apply NOCO[®] fluid and thoroughly spread it.



211516171

2. Install the shaft and secure it axially
(using a mounting device facilitates installation).




211518347

- [1] Short retaining screw (standard scope of delivery)
- [2] Lock washer
- [3] Washer
- [4] Retaining ring
- [5] Customer shaft



3. Tighten the retaining screw to the appropriate torque (see table).



211524875

Screw	Tightening torque [Nm]
M5	5
M6	8
M10/12	20
M16	40
M20	80
M24	200



INFORMATION

To avoid contact corrosion, SEW-EURODRIVE recommends that the customer shaft should additionally be lathed down between the 2 contact surfaces.



4.11 Shaft-mounted gear unit with shrink disk

4.11.1 Assembly notes



NOTICE

Tightening the screws without installed shaft may result in the hollow shaft being deformed.


Possible damage to property

- Only tighten the locking screws with the shaft installed.


BSHF.. helical-bevel servo gear units

BSHF../I helical-bevel servo gear units

1. Carefully degrease the hollow shaft hole and the machine shaft.



1839244043




1839272331

▲ CAUTION Risk of crushing for feet due to falling shrink disk.


Possible injury to persons.

- Always tighten the shrink disk immediately after positioning it on the shaft.

2. Hollow shaft/machine shaft after degreasing



1839275019




1839277707




BSHF.. helical-bevel servo gear units¹⁾

BSHF../I helical-bevel servo gear units

3. Apply NOCO[®] fluid to the machine shaft in the area of the bushing.




1839280395




1839283083

4. Install the shaft and make sure the locking collars of the shrink disk are installed in parallel to each other.²⁾



1839312139



1839314827

- 1) It is essential to make sure that the clamping area of the shrink disk is free from grease! For this reason, never apply NOCO[®] fluid directly to the bushing as the paste may be able to get into the clamping area of the shrink disk when the machine shaft is put on.
- 2) After assembly, grease the outside of the hollow shaft in the area of the shrink disk to prevent corrosion.







Mechanical Installation

Shaft-mounted gear unit with shrink disk





BSHF.. helical-bevel servo gear units

BSHF../I helical-bevel servo gear units

5. Tighten the locking bolts by working round several times from one bolt to the next (not in diametrically opposite sequence). Tightening torques are given in the table below.



1839317515



1839320203

Gear unit type	Screw	Tightening torque [Nm]	max. ¹⁾
BSHF202	M5 x 16 - 8.8	5	60°
BSHF302	M5 x 16 - 8.8	5	
BSHF402	M6 x 25 - 10.9	12	
BSHF502	M6 x 25 - 10.9	12	
BSHF602	M6 x 30 - 10.9	12	
BSHF802	M8 x 40 - 10.9	30	

1) Maximum tightening angle per rotation



CAUTION

Hazard caused by rotating gear unit parts.

Possible injury to persons.

- Install the supplied rotating cover or another, suitable protective cover at the shrink disk.



4.11.2 Notes on disassembling the shrink disk



⚠ CAUTION

Risk of jamming and crushing due to improper removal of heavy components.

Risk of injury.

- Observe the following removal notes.
- Removing the shrink disk properly.

1. Loosen the locking screws one after the other by a quarter rotation to avoid tilting the outer rings.
2. Unscrew the locking bolts evenly one after the other. Do not remove the locking screws completely.
3. Remove the shaft or pull the hub off the shaft (remove any rust that may have formed between the hub and the end of the shaft beforehand).
4. Remove the shrink disk from the hub.

4.11.3 Cleaning and lubricating the shrink disk

The shrink disk needs to be cleaned and re-greased if it is contaminated.

It is not necessary to disassemble and regrease the removed shrink disk before installing it again.

Use one of the following solid lubricants for the tapered surfaces:

Lubricant (Mo S ₂)	Sold as
Molykote 321 (lube coat)	Spray
Molykote spray (powder spray)	Spray
Molykote G Rapid	Spray or paste
Aemasol MO 19P	Spray or paste
AemasolDIO-sétral 57 N (lube coat)	Spray

Grease the locking bolts with a multipurpose grease such as Molykote BR 2 or similar.



4.12 Motor mounting



NOTICE


Torque is not transferred properly if the servomotor is tilted or jammed when mounting/removing the EBH.. / EPH.. / ECH.. adapter.

Possible unit fault

- The motor must only be installed/removed by qualified personnel.
- Observe the notes for removal in the operating instructions.

4.12.1 Motor mounting via EBH.. and EPH.. adapters

The following figure shows an example for mounting a motor to adapter EPH..:



1882119691

- | | | | |
|-----|---------------|------|-----------------|
| [1] | Torque wrench | [6] | Clamping screw |
| [2] | Closing plug | [7] | Coupling sleeve |
| [3] | Motor shaft | [8] | Clamping ring |
| [4] | Motor | [9] | Adapter shaft |
| [5] | Face | [10] | EPH adapter |

4.12.2 Sequence for mounting a motor to EBH.. and EPH.. adapters

A motor [4] with a minimum rotational accuracy to DIN 42955 can be mounted in any position.

Observe the following sequence for installation:

1. Check the plane surfaces [5] of the motor and adapter for scoring and smooth them if necessary.
2. Clean and de-grease the hollow shaft hole of the adapter shaft [9], the coupling sleeve [7] and the motor shaft [3].
3. Remove one of the 4 closing plugs [2].
4. Turn the adapter shaft [9] with the clamping ring [8] until the screw head of the clamping screw [6] is in alignment with the open mounting hole in the adapter housing. Loosen the clamping screw [6].
 - For motors with a keyway: Turn the keyway by 90° to the slots in the adapter shaft. To compensate imbalance, we recommend inserting a half key in the keyway.
5. If using coupling sleeves [7], make sure that the slots in the coupling sleeve [7] are in alignment with the slots in the adapter shaft [9] and clamping ring [8].
6. Carefully push the gear unit and motor [4] together.



7. Insert the connecting screws through the holes of the motor flange into the threads of the adapter flange and tighten the screws slightly.
8. Tighten the screws diagonally with even force.
9. Use a torque wrench [1] to tighten the clamping screw [6] to the prescribed tightening torque as described in the relevant table.

Adapter type EBH:

Adapter type	Motor shaft diameter [mm]	Number of clamping screws	Tightening torque of the clamping screw [Nm]	Wrench size
EBH03	≤ 14	1	18	5
EBH04	≤ 19	1	18	5
EBH05	≤ 24	1	43	6
EBH06	≤ 35	1	43	6
EBH07	≤ 35	1	43	6
EBH08	≤ 38	1	83	8
EBH09	≤ 42	1	83	8
EBH10	≤ 55	1	145	10


Adapter type EPH:

Adapter type	Motor shaft diameter [mm]	Number of clamping screws	Tightening torque of the clamping screw [Nm]	Wrench size
EPH01	≤ 11	1	10	4
EPH02	≤ 14	1	18	5
EPH03	≤ 14	1	18	5
EPH04	≤ 19	1	18	5
EPH05	≤ 24	1	43	6
EPH06	≤ 35	1	43	6
EPH07	≤ 32	1	43	6
EPH08	≤ 38	1	83	8
EPH09	≤ 42	1	83	8
EPH10	≤ 55	1	145	10



4.12.3 Motor mounting via ECH.. adapter

The following figure shows motor mounting via ECH.. adapter:



1886657931

- | | | | |
|-----|---------------|-----|--------------------|
| [1] | Torque wrench | [6] | Clamping screws |
| [2] | Closing plug | [7] | Motor shaft sleeve |
| [3] | Motor shaft | [8] | Adapter shaft |
| [4] | Motor | [9] | ECH.. adapter |
| [5] | Face | | |

4.12.4 Sequence for mounting a motor to ECH.. adapters

A motor [4] with a minimum rotational accuracy to DIN 42955 can be mounted in any position.

Observe the following sequence for installation:

1. Check the plane surfaces [5] of the motor and adapter for scoring and smooth them if necessary.
2. Clean and de-grease the hollow shaft hole of the adapter shaft [8], the motor shaft sleeve [7] and the motor shaft [3].
3. Remove both closing plugs [2].
4. Loosen the clamping screws [6] until both screws project around 3 threads into the mounting hole of the adapter.
 - For motors with a keyway: Turn the keyway so that it is in alignment with the slot of the motor shaft sleeve [7]. To compensate imbalance, we recommend inserting a half key in the keyway.
5. Make sure that the slot of the motor shaft sleeve [7] is at a 45° angle to the two clamping screws [6].
6. Carefully push the gear unit and motor [4] together.
7. Push the connection screws through the holes of the motor flange. Turn the screws into the threaded holes of the adapter flange and tighten them slightly.
8. Tighten the screws diagonally with even force.
9. Use a suitable torque wrench [1] to first tighten the clamping screws [6] one after the other to 25% of the stipulated torque. In a second step, tighten them to the full torque.




Adapter type ECH:

Adapter type	Motor shaft diameter [mm]	Number of clamping screws	Tightening torque of the clamping screw [Nm]	Wrench size
ECH02	≤ 11	2	10	4
ECH03	≤ 14	2	23	5
ECH05	≤ 19	2	45	6
ECH06	≤ 24	2	100	8



4.12.5 Permitted maximum weights of motors connected to BS.F., PS.F. and PS.C. gear units

The following figure shows the allowed force application points of the permitted maximum weights using a BS.F. gearmotor as an example:



1839378315

- ⊗ Motor's center of gravity
- X Distance from adapter flange to the middle of the motor
- F_q Overhung load

Gear unit type	Adapter type EBH..	X [mm]	F_q [N] ¹⁾
BSF..202 BSF..302	EBH03/01-14	182	157
	EBH04/12-15	182	157
	EBH05/14-20, EBH05/26	220	273
BSF..402	EBH03/01-14	182	157
	EBH04/12-15	182	157
	EBH05/14-20, EBH05/26	220	273
	EBH06/19	290	312
	EBH07/20-22, EBH07/27-28	290	312
BSF..502 BSF..602	EBH03/01-14	182	157
	EBH04/12-15	182	157
	EBH05/14-20, EBH05/26	220	273
	EBH06/19	290	312
	EBH07/20-22, EBH07/27-28	290	312
	EBH08/21-22	351	600
BSF..802	EBH05/14-20, EBH05/26	220	273
	EBH06/19	290	312
	EBH07/20-22, EBH07/27-28	290	312
	EBH08/21-22	351	600
	EBH09/22-25	400	680
	EBH10/22-25	400	680



Gear unit type	Adapter type EPH..	X [mm]	F _q [N] ¹⁾
PSF..121 PSF..122 PSF..222	EPH01/01-03	100	120
	EPH02/04-13	120	150
PSF..221 PSF..322	EPH01/01-03	100	120
	EPH02/04-08	120	150
	EPH03/01-14	182	157
	EPH04/01-15	182	157
PSF..321 PSF..522	EPH04/01-15	182	157
	EPH05/14-20, EPH05/26	220	273
PSF..521 PSF..622 PSF..722	EPH04/01-15	182	157
	EPH05/14-20, EPH05/26	220	273
	EPH06/19	290	312
	EPH07/20-22, EPH07/27-28	290	312
PSF..621 PSF..822	EPH05/14-20, EPH05/26	220	273
	EPH06/19	290	312
	EPH07/20-22, EPH07/27-28	290	312
	EPH08/21-22	351	600
PSF..721 PSF..922	EPH05/14-20, EPH05/26	220	273
	EPH06/19	290	312
	EPH07/20-22, EPH07/27-28	290	312
	EPH08/21-22	351	600
PSF..821	EPH09/22-25	400	680
	EPH10/22-25	400	680
PSF..921	EPH09/22-25	400	680
	EPH10/22-25	400	680

Gear unit type	Adapter type ECH..	X [mm]	F _q [N] ¹⁾
PS.C..221 PS.C..222	ECH02/01	90	40
	ECH02/08	130	94
PS.C..321 PS.C..322	ECH03/08	130	94
	ECH03/13	155	170
PS.C..521 PS.C..522	ECH05/13	155	170
	ECH05/14	200	306
PS.C..621 PS.C..622	ECH06/14	200	306
	ECH06/20	235	530

- 1) Maximum load values for connection screws of strength class 8.8. The maximum permitted weight of the attached motor F_{qmax} must be reduced proportionally as the distance between the adapter flange and the middle of the motor x increases. When this distance is reduced, F_{qmax} cannot be increased.



Gear unit type	Adapter type EPH..	X [mm]	F _q [N]
PS.C..221 PS.C..222	EPH01/01-03	100	120
	EPH02/04-08	120	150
	EPH03/01-14	182	157
	EPH04/01-15	182	157
PS.C..321 PS.C..322	EPH04/01-15	182	157
	EPH05/14-20, EPH05/26	220	273
PS.C..521 PS.C..522	EPH04/01-15	182	157
	EPH05/14-20, EPH05/26	220	273
	EPH06/19	290	312
	EPH07/20-22, EPH07/27-28	290	312
PS.C..621 PS.C..622	EPH05/14-20, EPH05/26	220	273
	EPH06/19	290	312
	EPH07/20-22, EPH07/27-28	290	312
	EPH08/21-22	351	600

4.12.6 Mounting motors to gear units directly



NOTICE

Mounting the motor to the gear unit may cause malfunctions.

Possible fault

- Never mount a motor directly to the gear unit.



4.13 Demounting the motor



NOTICE

Demounting the adapter from the gear unit may cause malfunctions.

Possible fault

- Never demount the adapter EBH.., EPH.. or ECH.. from the gear unit yourself.



NOTICE

Demounting the motor from the gear unit may cause malfunctions.

Possible fault

- Never demount a motor from the gear unit yourself.

Proper functioning will no longer be assured and the right to claim on warranty is no longer valid if you remove the motor yourself.

4.13.1 Sequence for demounting the motor from adapter EBH.., EPH.. or ECH..

Adhere to the following sequence when demounting the EBH.. adapter:

1. Switch off the drive
2. Secure the load
3. Turn off the power supply to the motor
4. Allow the drive to cool
5. Unscrew the clamping screws
6. Unscrew the connection screws between the motor and adapter
7. Remove the motor without tilting or jamming it



5 Startup

Check for the correct direction of rotation in decoupled state. Listen out for unusual grinding noises as the shaft rotates.



⚠ WARNING

Uncontrolled unit behavior.

Severe or fatal injuries.

- Secure key for test mode without output elements.
 - Do not deactivate monitoring and protection equipment even in test mode.
-

Switch off the gearmotor if in doubt whenever changes occur in relation to normal operation, e.g. noises or vibrations. Determine the cause of the fault and, if necessary, contact SEW-EURODRIVE.

Gear unit with motor adapter

For gear units with an adapter, ensure that the data specified on the nameplate and in the project planning documents for the gear unit are not exceeded. It is essential that the gear unit is not overloaded.

Inverter-operated gearmotors

The parameter settings made for the inverter must prevent the gear unit from being overloaded. Refer to the nameplate and the project planning documents for the correct gear unit data.

5.1 *Design-related special features*

5.1.1 BS.F.. helical-bevel gear units for mounting position M5



INFORMATION


With mounting position M5, it is important that you only operate the gear unit at a maximum of 50% of the limit speed for the first 24 hours of operation.

5.1.2 PSF../PSKF.. planetary gear units for mounting position M2



INFORMATION

With mounting position M2, it is important that you only operate the gear unit at a maximum of 50% of the limit speed for the first 24 hours of operation.



5.2 Measuring the surface temperature

It is absolutely necessary to measure the surface temperature at maximum load during startup of the gear unit. A commercially available thermometer is sufficient for this measurement.

Measure the surface temperature at the transition space between gear unit and adapter or motor where the position of the terminal box prevents venting by the motor fan. The maximum surface temperature will be reached after approximately three hours and may not exceed 95 °C.



NOTICE

Lubricant damage due to overheating.

Gear unit damage due to lubricant failure.

- Monitor the surface temperature during startup
- If the surface temperature is > 95 °C, stop the drive immediately and contact SEW-EURODRIVE.



6 Inspection and Maintenance

6.1 Preliminary work regarding gear unit inspection/maintenance

Observe the following notes before you start with the inspection/maintenance work.



⚠ WARNING

Risk of crushing if the drive starts up unintentionally.

Severe or fatal injuries.

- Disconnect the gearmotor from the power supply before starting work and protect it against unintentional re-start.
- Before releasing shaft connections, be sure that there are no active torsional moments present (tensions within the system).



⚠ WARNING

Danger of burns due to hot gear unit and hot gear unit oil.

Severe injuries.

- Let the gear unit cool down before you begin with your work.
- Only remove the oil level and oil drain plug very carefully.



NOTICE

Filling in the wrong oil may result in significantly different lubricant characteristics.

Potential damage to property

- Do not mix different synthetic lubricants and do not mix synthetic with mineral lubricants.



NOTICE

Improper maintenance may result in damage to the gear unit.

Possible damage to property.

- Heed the information in this chapter.



INFORMATION

The position of the oil drain plug and the breather valve depends on the mounting position. Refer to the diagrams of the mounting positions. See chapter "Mounting positions".

- Strict adherence to the inspection and maintenance intervals is absolutely necessary to ensure safe working conditions.
- Prevent foreign bodies from entering into the gear unit during maintenance and inspection work.
- Do not clean the gear unit with a high-pressure cleaning system as water might enter the gear unit and the seals might be damaged.
- Perform safety and function tests following all maintenance and repair work.




6.2 Inspection/maintenance intervals

Time interval	Required steps
<ul style="list-style-type: none"> Every 3000 operating hours, at least every 6 months 	<ul style="list-style-type: none"> Check running noise for possible bearing damage Visually check the seals and the adapter for leakage For gear units with a torque arm: Check and replace the rubber buffers, if necessary
<ul style="list-style-type: none"> Depending on the operating conditions (see illustration below), every 5 years at the latest according to oil temperature 	<ul style="list-style-type: none"> Replace anti-friction bearing grease (recommendation) Replace oil seal (do not install it in the same track)
<ul style="list-style-type: none"> Varying (depending on external factors) 	<ul style="list-style-type: none"> Touch up or renew the surfaces/anticorrosion coating

6.3 Lubricant change intervals

The following figure shows the change intervals for servo gear units under normal environmental conditions. Change the oil more frequently when using special versions subject to more severe/aggressive environmental conditions!



18729611

- | | |
|---------------------------------------|----------------------|
| [1] Operating hours | [3] CLP PG / CLP PG |
| [2] Sustained oil bath temperature | [4] [3] CLP HC / HCE |
| ● Average value per oil type at 70 °C | [5] CLP / HLP / E |






6.3.1 Measuring the oil temperature

The oil temperature must be measured to determine the lubricant change intervals stipulated in chapter "Inspection and Maintenance". To do so, measure the temperature at the bottom of the gear unit. Add 10 K to the measured value. Use this temperature value to determine the lubricant change interval.


7 Mounting Positions

7.1 Designation of the mounting positions

SEW-EURODRIVE distinguishes between gear unit mounting positions M1 to M6. The following figure shows the spatial orientation of the gear unit in mounting positions M1 to M6 with the output end A, using helical-bevel servo gear units as an example:



1942068619



Mounting Positions

Designation of the mounting positions



INFORMATION

Note the following information regarding the way in which shafts are depicted in the mounting position sheets:

- **For gear units with solid shaft:** The displayed shaft is always on the A end.
- **For shaft-mounted gear units:** The shaft with dashed lines represents the customer shaft. The output end is always shown on the A end.

7.1.1 Symbols used

The following table shows the symbols used in the mounting position sheets and what they mean:



Symbol	Meaning
	Breather valve
3	Cable entry position "Normal"

kVA	n
f	
i	P
	H_z

7.2 BS.F.. helical-bevel servo gearmotors



7.2.1 BS.F202 – 802

56 037 00 03






7.2.2 BSHF202 – 802 /T


56 043 00 03



7.2.3 BS.F202 B – 802 B

56 040 00 03






Mounting Positions


PS.F., PS.C.. planetary servo gearmotors

7.3 PS.F., PS.C.. planetary servo gearmotors

7.3.1 PS.F121 – 922, PS.C221 – 622






58 001 00 03



7.3.2 PSBF221 – 822

58 002 00 03





8 Technical Data

8.1 Lubricants

Unless a special arrangement is made, SEW-EURODRIVE supplies the drives with a lubricant fill adapted for the specific gear unit and mounting position. The mounting position (M1 – M6 section "Mounting positions") must be specified with the order. If you change the mounting position later, you must adapt the lubricant fill quantity accordingly.

8.1.1 General information

Unless a special arrangement is made, SEW-EURODRIVE supplies the drives with a lubricant fill adapted for the specific gear unit and mounting position. The decisive factor is the mounting position (M1 – M6) specified when ordering the drive.




INFORMATION

SEW-EURODRIVE fills the gear units with the amount of oil specified for the specific mounting positions. If the mounting position is changed, the amount of oil must be adapted as required. Consequently, a mounting position may only be changed after consultation with SEW-EURODRIVE, otherwise your right to claim under warranty no longer applies.

The following lubricant tables show the permitted standard lubricants for BS.F.. helical-bevel gear units and PS.F.. planetary gear units from SEW-EURODRIVE. A lubricant change is not necessary for PS.C.. gear units.

8.1.2 Anti-friction bearing greases

The anti-friction bearings in gear units and motors are given a factory-fill with the greases listed below. SEW-EURODRIVE recommends regreasing anti-friction bearings with a grease fill at the same time as changing the oil.


	Ambient temperature	Manufacturer	Type
Gear unit rolling bearings	-40 °C ... +80 °C	Fuchs	Renolit CX-TOM 15
	-40 °C ... +80 °C	Klüber	Petamo GHY 133 N
	-40 °C ... +40 °C	Castrol	Obeon FS 2



INFORMATION

The following grease quantities are required:

- **For fast-running bearings (gear unit input end):**
Fill the cavities between the rolling elements one-third full with grease.
- **For slow-running bearings (gear unit input side):**
Fill the cavities between the rolling elements two-thirds full with grease.





8.1.3 Lubricant table

The lubricant table on the following page shows the permitted lubricants for SEW-EURODRIVE gear units. Observe the following legend with regard to the lubricant table.

Key to the lubricant table

Abbreviations, meaning of shading and notes:

- CLP = Mineral oil
- CLP PG = Polyglycol (W gear units, conforms to USDA-H1)
- CLP HC = Synthetic hydrocarbons
- E = Ester oil (water hazard classification 1)
- HCE = Synthetic hydrocarbons + ester oil (USDA - H1 certification)
- HLP = Hydraulic oil
-  = Synthetic lubricant (= synthetic-based roller bearing grease)
-  = Mineral lubricant (= mineral-based rolling bearing grease)


- 1) Helical-worm gear units with PG oil: consult SEW-EURODRIVE.
- 2) Special lubricant for SPIROPLAN® gear units only
- 3) Recommendation: Select SEW $f_B \geq 1.2$
- 4) Observe the critical starting behavior at low temperatures.
- 5) Low-viscosity grease
- 6) Ambient temperature
- 7) Grease



Lubricant for the food industry (food grade oil)



Biodegradable oil (lubricant for agriculture, forestry, and water management)




Lubricant table

01 751 08 04

	6)	DIN (ISO)	ISO, NLGI	Mobil®	Shell	bp	TESCO	Castrol	FUCHS	TOTAL
R...		CLP (CC)	VG 220	Mobilgear 600 XP 220	Shell Omala S2 G 220	BP Energol GR-XP 220	Klüberoil GEM 1-220 N	Tribol 1100/220	Renolin CLP 220	Carter EP 220
K... (HK...)	Standard -15 +40	CLP PG	VG 220	Mobil Glycoyle 220	Shell Omala S4 WE 220	BP Energol SG-XP 220	Klüberoil GH 6-220	Optiflex A 220	Renolin PG 220	Carter SY 220
F...	-20 +60	CLP HC	VG 220	Mobil SHC 630	Shell Omala S4 GX 220		Klüberoil GEM 4-220 N	Optigear Synthetic X 220	Renolin Unisyn CLP 220	
	-40 +40	CLP HC	VG 150	Mobil SHC 629	Shell Omala S4 GX 150		Klüberoil GEM 4-150 N	Optigear Synthetic X 150	Renolin Unisyn CLP 150	Carter SH 150
	-20 +25	CLP (CC)	VG 150	Mobilgear 600 XP 150	Shell Omala S2 G 150	BP Energol GR-XP 150	Klüberoil GEM 1-150 N	Optigear BM 100	Renolin CLP 150	Carter EP 150
	-40 +20	CLP HC	VG 68	Mobil SHC 626	Shell Omala S4 GX 68				Renolin Unisyn CLP 68	
	-40 +0	CLP HC	VG 32	Mobil SHC 624			Klüber-Summit HySyn FG-32	Optileb HY 32	Renolin Unisyn OL 32	Dacnis SH 32
S... (HS...)	Standard 0 +40	CLP (CC)	VG 680	Mobilgear 600 XP 680	Shell Omala S2 G 680	BP Energol GR-XP 680	Klüberoil GEM 1-680 N	Optigear BM 680	Renolin SEW 680	Carter EP 680
	-20 +80	CLP PG	VG 680	Mobil Glycoyle 680	Shell Omala S4 WE 680	BP Energol SG-XP 680	Klüberoil GH 6-680	Optiflex A 680	Renolin PG 680	
	-20 +60	CLP HC	VG 460	Mobil SHC 634	Shell Omala S4 GX 460		Klüberoil GEM 4-460 N	Optigear Synthetic X 460	Renolin Unisyn CLP 460	
	-40 +30	CLP HC	VG 150	Mobil SHC 629	Shell Omala S4 GX 150		Klüberoil GEM 4-150 N	Optigear Synthetic X 150	Renolin Unisyn CLP 150	Carter SH 150
	-20 +10	CLP (CC)	VG 150	Mobilgear 600 XP 150	Shell Omala S2 G 150	BP Energol GR-XP 150	Klüberoil GEM 1-150 N	Optigear BM 150	Renolin CLP 150	Carter EP 150
	-20 +40	CLP PG	VG 220	Mobil Glycoyle 220	Shell Omala S4 WE 220	BP Energol SG-XP 220	Klüberoil GH 6-220	Optiflex A 220	Renolin PG 220	Carter SY 220
	-40 +20	CLP HC	VG 68	Mobil SHC 626	Shell Omala S4 GX 68				Renolin Unisyn CLP 68	
	-40 0	CLP HC	VG 32	Mobil SHC 624			Klüber-Summit HySyn FG-32	Alphasyn T32	Renolin Unisyn OL 32	Dacnis SH 32
R..., K... (HK...), F..., S... (HS...)	-10 +40	CLPHC NSF H1	VG 460				Klüberoil 4UH1-460 N	Optileb GT 460	Cassida Fluid GL 460	
	-20 +30		VG 220				Klüberoil 4UH1-220 N	Optileb GT 220	Cassida Fluid GL 220	
	-40 0	E	VG 68				Klüberoil 4UH1-68 N	Optileb GT 68	Cassida Fluid HF 68	
	-20 +40		VG 460		Shell Naturelle Gear Fluid EP460		Klüberbio CA2-460		Plantogear 460 S	
W... (HW...)	Standard -20 +40	SEW PG	VG 460				Klüber SEW HT-460-5			
	-40 +10	API GL5	SAE 75W/90 (-VG 100)	Mobil Synth Gear Oil 75 W90						
	-20 +60	H1 PG	VG 460				Klüberoil UH1 6-460			
PS.F.	Standard -20 +80	CLP PG	VG 220				Klüberoil GH 6-220			
	-20 +60	H1 PG	VG 460				Klüberoil UH1 6-460			
	-40 0	CLP HC	VG 32	Mobil SHC 624						
PS.C..	Standard -10 +40	CLP (CC)	VG 220	Mobilgear 600 XP 220						
	-20 +40	DIN 51 818	00	Mobilux EP 004						
	-20 +40	DIN 51 818	1				Klüberoil UH1 14-151			
	-40 0	CLP HC	VG 32	Mobil SHC 624						
BS.F.	Standard -20 +60	CLP PG	VG 220				Klüberoil GH 6-220			
	-20 +60	H1 PG	VG 460				Klüberoil UH1 6-460			

2845002123



8.1.4 Fill quantities depending on the mounting position for BS.F.. helical-bevel gear units

The following tables show guide values for lubricant fill quantities in relation to the mounting position M1 - M6.

Fill quantities for
BS.F.. helical-bevel
gear units

BS.F.. helical-bevel gear units	Fill quantity in liters					
	M1	M2	M3	M4	M5	M6
BS.F202	0.15	0.25	0.25	0.30	0.25	0.25
BS.F302	0.25	0.50	0.50	0.55	0.35	0.35
BS.F402	0.45	0.80	0.80	1.05	0.65	0.65
BS.F502	1.00	1.80	1.80	2.50	1.50	1.50
BS.F602	1.60	2.50	2.80	4.10	2.00	2.60
BS.F802	3.30	5.30	5.70	7.90	4.50	4.50

Fill quantity tolerances for BS.F..


Fill quantity in liters [l]	Tolerance
up to 1 l	0.01 l
> 1 l	1% of the fill quantity

8.1.5 Fill quantities depending on the mounting position for PS.F.. planetary gear units

The following tables show guide values for lubricant fill quantities in relation to the mounting position M1 – M6.

Fill quantities for
PS(K)F.. planetary
gear units

PS(K)F.. planetary gear unit	Adapter mounting Fill quantity in liters [l]			Direct motor mounting Fill quantity in liters [l]		
	M1 (M3, M5, M6)	M2	M4	M1 (M3, M5, M6)	M2	M4
PS(K)F121	0.023	0.025	0.023	0.023	0.037	0.023
PS(K)F122	0.035	0.056	0.054	0.035	0.068	0.054
PS(K)F221	0.035	0.052	0.035	0.035	0.063	0.035
PS(K)F222	0.045	0.075	0.085	0.045	0.085	0.085
PS(K)F321	0.070	0.100	0.070	0.07	0.12	0.07
PS(K)F322	0.095	0.170	0.190	0.095	0.185	0.19
PS(K)F521	0.140	0.215	0.150	0.14	0.245 (0.270) ¹⁾	0.15
PS(K)F522	0.200	0.360	0.395	0.2	0.38	0.395
PS(K)F621	0.300	0.465	0.320	0.3	0.500 (0.550) ¹⁾	0.32
PS(K)F622	0.410	0.680	0.780	0.41	0.71	0.78
PS(K)F721	0.600	0.930	0.650	0.6	1.060	0.65
PS(K)F722	0.750	1.230	1.645	0.75	1.280	1.645
PS(K)F821	1.000	1.750	1.350	–	–	–
PS(K)F822	1.550	2.550	3.350	1.550	2.640	3.350
PS(K)F921	1.400	2.450	1.900	–	–	–
PS(K)F922	2.050	3.500	4.350	2.050	3.650	4.350



Fill quantities for
PSBF.. planetary
gear units

PSBF.. plane- tary gear unit	Adapter mounting Fill quantity in liters [l]			Direct motor mounting Fill quantity in liters [l]		
	M1 (M3, M5, M6)	M2	M4	M1 (M3, M5, M6)	M2	M4
PSBF221	0.025	0.040	0.025	0.025	0.051	0.025
PSBF222	0.035	0.061	0.060	0.035	0.074	0.06
PSBF321	0.045	0.068	0.050	0.045	0.085	0.05
PSBF322	0.070	0.135	0.130	0.07	0.145	0.13
PSBF521	0.093	0.143	0.103	0.093	0.168 (0.193) ¹⁾	0.103
PSBF522	0.143	0.288	0.273	0.143	0.308	0.273
PSBF621	0.198	0.318	0.188	0.198	0.358 (0.408) ¹⁾	0.188
PSBF622	0.298	0.538	0.498	0.298	0.568	0.498
PSBF721	0.474	0.684	0.314	0.404	0.544	0.314
PSBF722	0.564	0.884	1.004	0.544	0.834	1.004
PSBF821	0.495	0.995	0.695	–	–	–
PSBF822	0.995	1.795	1.995	0.995	1.895	1.995

1) Fill quantity for direct mounting of CFM90 servomotors

Fill quantity
tolerances for
PS.F..

Planetary gear unit	Fill quantity in liters [l]
PS.F121/122	± 0.001
PS.F221/222	± 0.001
PS.F321/322	± 0.002
PS.F521/522	± 0.005
PS.F621/622	± 0.005
PS.F721/722	± 0.010
PS.F821/822	± 0.010
PS.F921/922	± 0.010



9 Malfunctions

9.1 Gear unit

Fault	Possible cause	Remedy
Unusual, regular running noise	Meshing/grinding noise: Bearing damage	Contact customer service.
	Knocking noise: Irregularity in the gearing Incorrect controller setting	Check controller setting. Contact customer service.
Unusual, irregular running noise	Foreign bodies in the oil.	<ul style="list-style-type: none"> Check the oil → see Sec. "Inspection and Maintenance" (page 50), Stop the drive, contact customer service
Oil leakage ¹⁾ <ul style="list-style-type: none"> From the motor flange From the motor oil seal From the gear unit flange From the output end oil seal 	Seal defective.	Contact customer service.
	Only for BSF.. gear units in mounting position M4: Gear unit not ventilated.	Vent the gear unit → see "Activating the breather valve" (page 25).
Only for BSF.. Mounting position M4: Oil leaking from breather valve	Too much oil.	Contact customer service.
	Drive operated in incorrect mounting position.	Mount the gear unit in the correct Mounting position (page 53).
	Frequent cold starts (oil foams) and/or high oil level.	Install oil expansion tank.
Output shaft does not turn although the motor is running or the input shaft is rotated	Shaft-hub connection in the gear unit interrupted.	Send in the gear unit/gearmotor for repair.
Housing temperature is > 95 °C	<ul style="list-style-type: none"> Restricted air supply Speed/torque is too high 	<ul style="list-style-type: none"> Ensure unrestricted air supply and/or contact customer service. Check project planning and/or contact customer service.

1) Short-term oil / grease leakage at the oil seal is possible in the run-in phase (48 hours running time).

9.2 Customer service

Please have the following information to hand if you require the assistance of our customer service:

- Nameplate data (complete)
- Type and extent of the problem
- Time the problem occurred and any accompanying circumstances
- Assumed cause



9.3 Disposal

Dispose gear units in accordance with the regulations in force regarding respective materials:

- Steel scrap
 - Housing parts
 - Gears
 - Shafts
 - Roller bearing
- Parts of the worm gears are made of non-ferrous metals. Dispose of the worm gears as appropriate.
- Collect waste oil and dispose of it according to the regulations in force.



10 Address List

Germany			
Headquarters Production Sales	Bruchsal	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 D-76646 Bruchsal P.O. Box Postfach 3023 • D-76642 Bruchsal	Tel. +49 7251 75-0 Fax +49 7251 75-1970 http://www.sew-eurodrive.de sew@sew-eurodrive.de
Production / Industrial Gears	Bruchsal	SEW-EURODRIVE GmbH & Co KG Christian-Pähr-Str.10 D-76646 Bruchsal	Tel. +49 7251 75-0 Fax +49 7251 75-2970
Service Competence Center	Central	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 1 D-76676 Graben-Neudorf	Tel. +49 7251 75-1710 Fax +49 7251 75-1711 sc-mitte@sew-eurodrive.de
	North	SEW-EURODRIVE GmbH & Co KG Alte Ricklinger Straße 40-42 D-30823 Garbsen (near Hannover)	Tel. +49 5137 8798-30 Fax +49 5137 8798-55 sc-nord@sew-eurodrive.de
	East	SEW-EURODRIVE GmbH & Co KG Dänkritzer Weg 1 D-08393 Meerane (near Zwickau)	Tel. +49 3764 7606-0 Fax +49 3764 7606-30 sc-ost@sew-eurodrive.de
	South	SEW-EURODRIVE GmbH & Co KG Domagkstraße 5 D-85551 Kirchheim (near München)	Tel. +49 89 909552-10 Fax +49 89 909552-50 sc-sued@sew-eurodrive.de
	West	SEW-EURODRIVE GmbH & Co KG Siemensstraße 1 D-40764 Langenfeld (near Düsseldorf)	Tel. +49 2173 8507-30 Fax +49 2173 8507-55 sc-west@sew-eurodrive.de
	Electronics	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 D-76646 Bruchsal	Tel. +49 7251 75-1780 Fax +49 7251 75-1769 sc-elektronik@sew-eurodrive.de
	Drive Service Hotline / 24 Hour Service		+49 180 5 SEWHELP +49 180 5 7394357 14 euro cents/min on the German land-line network. Max 42 euro cents/min from a German mobile network. Prices for mobile and international calls may differ.
	Additional addresses for service in Germany provided on request!		

France			
Production Sales Service	Haguenau	SEW-USOCOME 48-54 route de Soufflenheim B. P. 20185 F-67506 Haguenau Cedex	Tel. +33 3 88 73 67 00 Fax +33 3 88 73 66 00 http://www.usocomme.com sew@usocomme.com
Production	Forbach	SEW-USOCOME Zone industrielle Technopôle Forbach Sud B. P. 30269 F-57604 Forbach Cedex	Tel. +33 3 87 29 38 00
Assembly Sales Service	Bordeaux	SEW-USOCOME Parc d'activités de Magellan 62 avenue de Magellan - B. P. 182 F-33607 Pessac Cedex	Tel. +33 5 57 26 39 00 Fax +33 5 57 26 39 09
	Lyon	SEW-USOCOME Parc d'affaires Roosevelt Rue Jacques Tati F-69120 Vaulx en Velin	Tel. +33 4 72 15 37 00 Fax +33 4 72 15 37 15



France			
	Nantes	SEW-USOCOME Parc d'activités de la forêt 4 rue des Fontenelles F-44140 Le Bignon	Tel. +33 2 40 78 42 00 Fax +33 2 40 78 42 20
	Paris	SEW-USOCOME Zone industrielle 2 rue Denis Papin F-77390 Verneuil l'Etang	Tel. +33 1 64 42 40 80 Fax +33 1 64 42 40 88
Additional addresses for service in France provided on request!			
Algeria			
Sales	Algiers	REDUCOM Sarl 16, rue des Frères Zaghounne Bellevue 16200 El Harrach Alger	Tel. +213 21 8214-91 Fax +213 21 8222-84 info@reducom-dz.com http://www.reducom-dz.com
Argentina			
Assembly Sales	Buenos Aires	SEW EURODRIVE ARGENTINA S.A. Centro Industrial Garin, Lote 35 Ruta Panamericana Km 37,5 1619 Garin	Tel. +54 3327 4572-84 Fax +54 3327 4572-21 sewar@sew-eurodrive.com.ar http://www.sew-eurodrive.com.ar
Australia			
Assembly Sales Service	Melbourne	SEW-EURODRIVE PTY. LTD. 27 Beverage Drive Tullamarine, Victoria 3043	Tel. +61 3 9933-1000 Fax +61 3 9933-1003 http://www.sew-eurodrive.com.au enquires@sew-eurodrive.com.au
	Sydney	SEW-EURODRIVE PTY. LTD. 9, Sleigh Place, Wetherill Park New South Wales, 2164	Tel. +61 2 9725-9900 Fax +61 2 9725-9905 enquires@sew-eurodrive.com.au
Austria			
Assembly Sales Service	Wien	SEW-EURODRIVE Ges.m.b.H. Richard-Strauss-Strasse 24 A-1230 Wien	Tel. +43 1 617 55 00-0 Fax +43 1 617 55 00-30 http://www.sew-eurodrive.at sew@sew-eurodrive.at
Belarus			
Sales	Minsk	SEW-EURODRIVE BY RybalkoStr. 26 BY-220033 Minsk	Tel.+375 17 298 47 56 / 298 47 58 Fax +375 17 298 47 54 http://www.sew.by sales@sew.by
Belgium			
Assembly Sales Service	Brussels	SEW-EURODRIVE n.v./s.a. Researchpark Haasrode 1060 Evenementenlaan 7 BE-3001 Leuven	Tel. +32 16 386-311 Fax +32 16 386-336 http://www.sew-eurodrive.be info@sew-eurodrive.be
Service Competence Center	Industrial Gears	SEW-EURODRIVE n.v./s.a. Rue de Parc Industriel, 31 BE-6900 Marche-en-Famenne	Tel. +32 84 219-878 Fax +32 84 219-879 http://www.sew-eurodrive.be service-wallonie@sew-eurodrive.be
Brazil			
Production Sales Service	São Paulo	SEW-EURODRIVE Brasil Ltda. Avenida Amâncio Gaiolli, 152 - Rodovia Presidente Dutra Km 208 Guarulhos - 07251-250 - SP SAT - SEW ATENDE - 0800 7700496	Tel. +55 11 2489-9133 Fax +55 11 2480-3328 http://www.sew-eurodrive.com.br sew@sew.com.br



Brazil			
Assembly Sales Service	Rio Claro	SEW-EURODRIVE Brasil Ltda. Rodovia Washington Luiz, Km 172 Condomínio Industrial Conpark Caixa Postal: 327 13501-600 – Rio Claro / SP	Tel. +55 19 3522-3100 Fax +55 19 3524-6653 montadora.rc@sew.com.br
	Joinville	SEW-EURODRIVE Brasil Ltda. Rua Dona Francisca, 12.346 – Pirabeiraba 89239-270 – Joinville / SC	Tel. +55 47 3027-6886 Fax +55 47 3027-6888 filial.sc@sew.com.br
	Indaiatuba	SEW-EURODRIVE Brasil Ltda. Estrada Municipal Jose Rubim, 205 Rodovia Santos Dumont Km 49 13347-510 - Indaiatuba / SP	Tel. +55 19 3835-8000 sew@sew.com.br
Bulgaria			
Sales	Sofia	BEVER-DRIVE GmbH Bogdanovetz Str.1 BG-1606 Sofia	Tel. +359 2 9151160 Fax +359 2 9151166 bever@bever.bg
Cameroon			
Sales	Douala	Electro-Services Rue Drouot Akwa B.P. 2024 Douala	Tel. +237 33 431137 Fax +237 33 431137 electrojemba@yahoo.fr
Canada			
Assembly Sales Service	Toronto	SEW-EURODRIVE CO. OF CANADA LTD. 210 Walker Drive Bramalea, ON L6T 3W1	Tel. +1 905 791-1553 Fax +1 905 791-2999 http://www.sew-eurodrive.ca l.watson@sew-eurodrive.ca
	Vancouver	SEW-EURODRIVE CO. OF CANADA LTD. Tilbury Industrial Park 7188 Honeyman Street Delta, BC V4G 1G1	Tel. +1 604 946-5535 Fax +1 604 946-2513 b.wake@sew-eurodrive.ca
	Montreal	SEW-EURODRIVE CO. OF CANADA LTD. 2555 Rue Leger Lasalle, PQ H8N 2V9	Tel. +1 514 367-1124 Fax +1 514 367-3677 a.peluso@sew-eurodrive.ca
Additional addresses for service in Canada provided on request!			
Chile			
Assembly Sales Service	Santiago	SEW-EURODRIVE CHILE LTDA. Las Encinas 1295 Parque Industrial Valle Grande LAMP RCH-Santiago de Chile P.O. Box Casilla 23 Correo Quilicura - Santiago - Chile	Tel. +56 2 75770-00 Fax +56 2 75770-01 http://www.sew-eurodrive.cl ventas@sew-eurodrive.cl
China			
Production Assembly Sales Service	Tianjin	SEW-EURODRIVE (Tianjin) Co., Ltd. No. 46, 7th Avenue, TEDA Tianjin 300457	Tel. +86 22 25322612 Fax +86 22 25323273 info@sew-eurodrive.cn http://www.sew-eurodrive.cn
Assembly Sales Service	Suzhou	SEW-EURODRIVE (Suzhou) Co., Ltd. 333, Suhong Middle Road Suzhou Industrial Park Jiangsu Province, 215021	Tel. +86 512 62581781 Fax +86 512 62581783 suzhou@sew-eurodrive.cn



China			
	Guangzhou	SEW-EURODRIVE (Guangzhou) Co., Ltd. No. 9, JunDa Road East Section of GETDD Guangzhou 510530	Tel. +86 20 82267890 Fax +86 20 82267922 guangzhou@sew-eurodrive.cn
	Shenyang	SEW-EURODRIVE (Shenyang) Co., Ltd. 10A-2, 6th Road Shenyang Economic Technological Development Area Shenyang, 110141	Tel. +86 24 25382538 Fax +86 24 25382580 shenyang@sew-eurodrive.cn
	Wuhan	SEW-EURODRIVE (Wuhan) Co., Ltd. 10A-2, 6th Road No. 59, the 4th Quanli Road, WEDA 430056 Wuhan	Tel. +86 27 84478388 Fax +86 27 84478389 wuhan@sew-eurodrive.cn
	Xi'An	SEW-EURODRIVE (Xi'An) Co., Ltd. No. 12 Jinye 2nd Road Xi'An High-Technology Industrial Development Zone Xi'An 710065	Tel. +86 29 68686262 Fax +86 29 68686311 xian@sew-eurodrive.cn
Additional addresses for service in China provided on request!			
Colombia			
Assembly Sales Service	Bogotá	SEW-EURODRIVE COLOMBIA LTDA. Calle 22 No. 132-60 Bodega 6, Manzana B Santafé de Bogotá	Tel. +57 1 54750-50 Fax +57 1 54750-44 http://www.sew-eurodrive.com.co sewcol@sew-eurodrive.com.co
Croatia			
Sales Service	Zagreb	KOMPEKS d. o. o. Zeleni dol 10 HR 10 000 Zagreb	Tel. +385 1 4613-158 Fax +385 1 4613-158 kompeks@inet.hr
Czech Republic			
Sales Assembly Service	Prague	SEW-EURODRIVE CZ s.r.o. Floriánova 2459 253 01 Hostivice	Tel. +420 255 709 601 Fax +420 235 350 613 http://www.sew-eurodrive.cz sew@sew-eurodrive.cz
		SEW-EURODRIVE CZ s.r.o. Lužná 591 16000 Praha 6 - Vokovice	
	Drive Service Hotline / 24 Hour Service	HOT-LINE +420 800 739 739 (800 SEW SEW)	Servis: Tel. +420 255 709 632 Fax +420 235 358 218 servis@sew-eurodrive.cz
Denmark			
Assembly Sales Service	Copenhagen	SEW-EURODRIVEA/S Geminivej 28-30 DK-2670 Greve	Tel. +45 43 9585-00 Fax +45 43 9585-09 http://www.sew-eurodrive.dk sew@sew-eurodrive.dk
Egypt			
Sales Service	Cairo	Copam Egypt for Engineering & Agencies 33 El Hegaz ST, Heliopolis, Cairo	Tel. +20 2 22566-299 +1 23143088 Fax +20 2 22594-757 http://www.copam-egypt.com/ copam@datum.com.eg



Estonia			
Sales	Tallin	ALAS-KUUL AS Reti tee 4 EE-75301 Peetri küla, Rae vald, Harjumaa	Tel. +372 6593230 Fax +372 6593231 veiko.soots@alas-kuul.ee
Finland			
Assembly Sales Service	Lahti	SEW-EURODRIVE OY Vesimäentie 4 FIN-15860 Hollola 2	Tel. +358 201 589-300 Fax +358 3 780-6211 http://www.sew-eurodrive.fi sew@sew.fi
Production Assembly	Karkkila	SEW Industrial Gears Oy Valurinkatu 6, PL 8 FI-03600 Karkkila, 03601 Karkkila	Tel. +358 201 589-300 Fax +358 201 589-310 sew@sew.fi http://www.sew-eurodrive.fi
Gabon			
Sales	Libreville	ESG Electro Services Gabun Feu Rouge Lalala 1889 Libreville Gabun	Tel. +241 741059 Fax +241 741059 esg_services@yahoo.fr
Great Britain			
Assembly Sales Service	Normanton	SEW-EURODRIVE Ltd. Beckbridge Industrial Estate Normanton West Yorkshire WF6 1QR	Tel. +44 1924 893-855 Fax +44 1924 893-702 http://www.sew-eurodrive.co.uk info@sew-eurodrive.co.uk
Drive Service Hotline / 24 Hour Service			Tel. 01924 896911
Greece			
Sales	Athens	Christ. Boznos & Son S.A. 12, K. Mavromichali Street P.O. Box 80136 GR-18545 Piraeus	Tel. +30 2 1042 251-34 Fax +30 2 1042 251-59 http://www.boznos.gr info@boznos.gr
Hong Kong			
Assembly Sales Service	Hong Kong	SEW-EURODRIVE LTD. Unit No. 801-806, 8th Floor Hong Leong Industrial Complex No. 4, Wang Kwong Road Kowloon, Hong Kong	Tel. +852 36902200 Fax +852 36902211 contact@sew-eurodrive.hk
Hungary			
Sales Service	Budapest	SEW-EURODRIVE Kft. H-1037 Budapest Kunigunda u. 18	Tel. +36 1 437 06-58 Fax +36 1 437 06-50 http://www.sew-eurodrive.hu office@sew-eurodrive.hu
India			
Registered Office Assembly Sales Service	Vadodara	SEW-EURODRIVE India Private Limited Plot No. 4, GIDC POR Ramangamdi • Vadodara - 391 243 Gujarat	Tel. +91 265 3045200, +91 265 2831086 Fax +91 265 3045300, +91 265 2831087 http://www.seweurodriveindia.com salesvadodara@seweurodriveindia.com



India			
Assembly Sales Service	Chennai	SEW-EURODRIVE India Private Limited Plot No. K3/1, Sipcot Industrial Park Phase II Mambakkam Village Sriperumbudur - 602105 Kancheepuram Dist, Tamil Nadu	Tel. +91 44 37188888 Fax +91 44 37188811 saleschennai@seweurodriveindia.com
Ireland			
Sales Service	Dublin	Alpertown Engineering Ltd. 48 Moyle Road Dublin Industrial Estate Glasnevin, Dublin 11	Tel. +353 1 830-6277 Fax +353 1 830-6458 info@alpertown.ie http://www.alpertown.ie
Israel			
Sales	Tel-Aviv	Liraz Handasa Ltd. Ahofer Str 34B / 228 58858 Holon	Tel. +972 3 5599511 Fax +972 3 5599512 http://www.liraz-handasa.co.il office@liraz-handasa.co.il
Italy			
Assembly Sales Service	Solaro	SEW-EURODRIVE di R. Blicke & Co.s.a.s. Via Bernini, 14 I-20020 Solaro (Milano)	Tel. +39 02 96 9801 Fax +39 02 96 799781 http://www.sew-eurodrive.it sewit@sew-eurodrive.it
Ivory Coast			
Sales	Abidjan	SICA Société Industrielle & Commerciale pour l'Afrique 165, Boulevard de Marseille 26 BP 1173 Abidjan 26	Tel. +225 21 25 79 44 Fax +225 21 25 88 28 sicamot@aviso.ci
Japan			
Assembly Sales Service	Iwata	SEW-EURODRIVE JAPAN CO., LTD 250-1, Shimoman-no, Iwata Shizuoka 438-0818	Tel. +81 538 373811 Fax +81 538 373855 http://www.sew-eurodrive.co.jp sewjapan@sew-eurodrive.co.jp
Kazakhstan			
Sales	Almaty	ТОО "СЕВ-ЕВРОДРАЙВ" пр.Райымбека, 348 050061 г. Алматы Республика Казахстан	Тел. +7 (727) 334 1880 Факс +7 (727) 334 1881 http://www.sew-eurodrive.kz sew@sew-eurodrive.kz
Kenya			
Sales	Nairobi	Barico Maintenances Ltd Kamutaga Place Commercial Street Industrial Area P.O.BOX 52217 - 00200 Nairobi	Tel. +254 20 6537094/5 Fax +254 20 6537096 info@barico.co.ke
Latvia			
Sales	Riga	SIA Alas-Kuul Katlakalna 11C LV-1073 Riga	Tel. +371 6 7139253 Fax +371 6 7139386 http://www.alas-kuul.com info@alas-kuul.com



Lebanon			
Sales Lebanon	Beirut	Gabriel Acar & Fils sarl B. P. 80484 Bourj Hammoud, Beirut	Tel. +961 1 510 532 Fax +961 1 494 971 ssacar@inco.com.lb
		After Sales Service	service@medrives.com
Sales Jordan / Kuwait / Saudi Ara- bia / Syria	Beirut	Middle East Drives S.A.L. (offshore) Sin El Fil. B. P. 55-378 Beirut	Tel. +961 1 494 786 Fax +961 1 494 971 info@medrives.com http://www.medrives.com
		After Sales Service	service@medrives.com
Lithuania			
Sales	Alytus	UAB Irseva Statybininku 106C LT-63431 Alytus	Tel. +370 315 79204 Fax +370 315 56175 irmantas@irseva.lt http://www.sew-eurodrive.lt
Luxembourg			
Assembly Sales Service	Brussels	SEW-EURODRIVE n.v./s.a. Researchpark Haasrode 1060 Evenementenlaan 7 BE-3001 Leuven	Tel. +32 16 386-311 Fax +32 16 386-336 http://www.sew-eurodrive.lu info@sew-eurodrive.be
Madagascar			
Sales	Antananarivo	Ocean Trade BP21bis. Andraharo Antananarivo. 101 Madagascar	Tel. +261 20 2330303 Fax +261 20 2330330 oceanrabp@moov.mg
Malaysia			
Assembly Sales Service	Johor	SEW-EURODRIVE SDN BHD No. 95, Jalan Seroja 39, Taman Johor Jaya 81000 Johor Bahru, Johor West Malaysia	Tel. +60 7 3549409 Fax +60 7 3541404 sales@sew-eurodrive.com.my
Mexico			
Assembly Sales Service	Quéretaro	SEW-EURODRIVE MEXICO SA DE CV SEM-981118-M93 Tequisquiapan No. 102 Parque Industrial Quéretaro C.P. 76220 Quéretaro, México	Tel. +52 442 1030-300 Fax +52 442 1030-301 http://www.sew-eurodrive.com.mx scmexico@seweurodrive.com.mx
Morocco			
Sales Service	Mohammedia	SEW-EURODRIVE SARL 2, rue El Jahidz 20800 Mohammedia	Tel. +212 523 32 27 80/81 Fax +212 523 32 27 89 sew@sew-eurodrive.ma http://www.sew-eurodrive.ma
Namibia			
Sales	Swakopmund	DB Mining & Industrial Services Einstein Street Strauss Industrial Park Unit1 Swakopmund	Tel. +264 64 462 738 Fax +264 64 462 734 sales@dbmining.in.na



Netherlands			
Assembly Sales Service	Rotterdam	SEW-EURODRIVE B.V. Industrieweg 175 NL-3044 AS Rotterdam Postbus 10085 NL-3004 AB Rotterdam	Tel. +31 10 4463-700 Fax +31 10 4155-552 Service: 0800-SEWHELP http://www.sew-eurodrive.nl info@sew-eurodrive.nl
New Zealand			
Assembly Sales Service	Auckland	SEW-EURODRIVE NEW ZEALAND LTD. P.O. Box 58-428 82 Greenmount drive East Tamaki Auckland	Tel. +64 9 2745627 Fax +64 9 2740165 http://www.sew-eurodrive.co.nz sales@sew-eurodrive.co.nz
	Christchurch	SEW-EURODRIVE NEW ZEALAND LTD. 10 Settlers Crescent, Ferryroad Christchurch	Tel. +64 3 384-6251 Fax +64 3 384-6455 sales@sew-eurodrive.co.nz
Norway			
Assembly Sales Service	Moss	SEW-EURODRIVE A/S Solgaard skog 71 N-1599 Moss	Tel. +47 69 24 10 20 Fax +47 69 24 10 40 http://www.sew-eurodrive.no sew@sew-eurodrive.no
Pakistan			
Sales	Karachi	Industrial Power Drives Al-Fatah Chamber A/3, 1st Floor Central Com- mercial Area, Sultan Ahmed Shah Road, Block 7/8, Karachi	Tel. +92 21 452 9369 Fax +92-21-454 7365 seweurodrive@cyber.net.pk
Peru			
Assembly Sales Service	Lima	SEW DEL PERU MOTORES REDUCTORES S.A.C. Los Calderos, 120-124 Urbanizacion Industrial Vulcano, ATE, Lima	Tel. +51 1 3495280 Fax +51 1 3493002 http://www.sew-eurodrive.com.pe sewperu@sew-eurodrive.com.pe
Poland			
Assembly Sales Service	Lodz	SEW-EURODRIVE Polska Sp.z.o.o. ul. Techniczna 5 PL-92-518 Łódź	Tel. +48 42 676 53 00 Fax +48 42 676 53 49 http://www.sew-eurodrive.pl sew@sew-eurodrive.pl
	Service	Tel. +48 42 6765332 / 42 6765343 Fax +48 42 6765346	Linia serwisowa Hotline 24H Tel. +48 602 739 739 (+48 602 SEW SEW) serwis@sew-eurodrive.pl
Portugal			
Assembly Sales Service	Coimbra	SEW-EURODRIVE, LDA. Apartado 15 P-3050-901 Mealhada	Tel. +351 231 20 9670 Fax +351 231 20 3685 http://www.sew-eurodrive.pt infosew@sew-eurodrive.pt
Romania			
Sales Service	Bucharest	Sialco Trading SRL str. Madrid nr.4 011785 Bucuresti	Tel. +40 21 230-1328 Fax +40 21 230-7170 sialco@sialco.ro



Russia			
Assembly Sales Service	St. Petersburg	ZAO SEW-EURODRIVE P.O. Box 36 RUS-195220 St. Petersburg	Tel. +7 812 3332522 +7 812 5357142 Fax +7 812 3332523 http://www.sew-eurodrive.ru sew@sew-eurodrive.ru
Senegal			
Sales	Dakar	SENEMECA Mécanique Générale Km 8, Route de Rufisque B.P. 3251, Dakar	Tel. +221 338 494 770 Fax +221 338 494 771 senemeca@sentoo.sn http://www.senemeca.com
Serbia			
Sales	Beograd	DIPAR d.o.o. Ustanicka 128a PC Košum, IV sprat SRB-11000 Beograd	Tel. +381 11 347 3244 / +381 11 288 0393 Fax +381 11 347 1337 office@dipar.rs
Singapore			
Assembly Sales Service	Singapore	SEW-EURODRIVE PTE. LTD. No 9, Tuas Drive 2 Jurong Industrial Estate Singapore 638644	Tel. +65 68621701 Fax +65 68612827 http://www.sew-eurodrive.com.sg sewsingapore@sew-eurodrive.com
Slovakia			
Sales	Bratislava	SEW-Eurodrive SK s.r.o. Rybničná 40 SK-831 06 Bratislava	Tel. +421 2 33595 202 Fax +421 2 33595 200 sew@sew-eurodrive.sk http://www.sew-eurodrive.sk
	Žilina	SEW-Eurodrive SK s.r.o. Industry Park - PChZ ulica M.R.Štefánika 71 SK-010 01 Žilina	Tel. +421 41 700 2513 Fax +421 41 700 2514 sew@sew-eurodrive.sk
	Banská Bystrica	SEW-Eurodrive SK s.r.o. Rudlovská cesta 85 SK-974 11 Banská Bystrica	Tel. +421 48 414 6564 Fax +421 48 414 6566 sew@sew-eurodrive.sk
	Košice	SEW-Eurodrive SK s.r.o. Slovenská ulica 26 SK-040 01 Košice	Tel. +421 55 671 2245 Fax +421 55 671 2254 sew@sew-eurodrive.sk
Slovenia			
Sales Service	Celje	Pakman - Pogonska Tehnika d.o.o. Ul. XIV. divizije 14 SLO - 3000 Celje	Tel. +386 3 490 83-20 Fax +386 3 490 83-21 pakman@siol.net
South Africa			
Assembly Sales Service	Johannesburg	SEW-EURODRIVE (PROPRIETARY) LIMITED Eurodrive House Cnr. Adcock Ingram and Aerodrome Roads Aeroton Ext. 2 Johannesburg 2013 P.O.Box 90004 Bertsham 2013	Tel. +27 11 248-7000 Fax +27 11 494-3104 http://www.sew.co.za info@sew.co.za



South Africa			
	Cape Town	SEW-EURODRIVE (PROPRIETARY) LIMITED Rainbow Park Cnr. Racecourse & Omuramba Road Montague Gardens Cape Town P.O.Box 36556 Chempet 7442 Cape Town	Tel. +27 21 552-9820 Fax +27 21 552-9830 Telex 576 062 cfoster@sew.co.za
	Durban	SEW-EURODRIVE (PROPRIETARY) LIMITED 2 Monaco Place Pinetown Durban P.O. Box 10433, Ashwood 3605	Tel. +27 31 700-3451 Fax +27 31 700-3847 cdejager@sew.co.za
	Nelspruit	SEW-EURODRIVE (PTY) LTD. 7 Christie Crescent Vintonia P.O.Box 1942 Nelspruit 1200	Tel. +27 13 752-8007 Fax +27 13 752-8008 robermeyer@sew.co.za
South Korea			
Assembly Sales Service	Ansan	SEW-EURODRIVE KOREA CO., LTD. B 601-4, Banweol Industrial Estate #1048-4, Shingil-Dong, Danwon-Gu, Ansan-City, Kyunggi-Do Zip 425-839	Tel. +82 31 492-8051 Fax +82 31 492-8056 http://www.sew-korea.co.kr master.korea@sew-eurodrive.com
	Busan	SEW-EURODRIVE KOREA Co., Ltd. No. 1720 - 11, Songjeong - dong Gangseo-ku Busan 618-270	Tel. +82 51 832-0204 Fax +82 51 832-0230 master@sew-korea.co.kr
Spain			
Assembly Sales Service	Bilbao	SEW-EURODRIVE ESPAÑA, S.L. Parque Tecnológico, Edificio, 302 E-48170 Zamudio (Vizcaya)	Tel. +34 94 43184-70 Fax +34 94 43184-71 http://www.sew-eurodrive.es sew.spain@sew-eurodrive.es
Swaziland			
Sales	Manzini	C G Trading Co. (Pty) Ltd PO Box 2960 Manzini M200	Tel. +268 2 518 6343 Fax +268 2 518 5033 engineering@cgtrading.co.sz
Sweden			
Assembly Sales Service	Jönköping	SEW-EURODRIVE AB Gnejsvägen 6-8 S-55303 Jönköping Box 3100 S-55003 Jönköping	Tel. +46 36 3442 00 Fax +46 36 3442 80 http://www.sew-eurodrive.se jonkoping@sew.se
Switzerland			
Assembly Sales Service	Basel	Alfred Imhof A.G. Jurastrasse 10 CH-4142 Münchenstein bei Basel	Tel. +41 61 417 1717 Fax +41 61 417 1700 http://www.imhof-sew.ch info@imhof-sew.ch
Thailand			
Assembly Sales Service	Chonburi	SEW-EURODRIVE (Thailand) Ltd. 700/456, Moo.7, Donhuaroh Muang Chonburi 20000	Tel. +66 38 454281 Fax +66 38 454288 sewthailand@sew-eurodrive.com



Tunisia			
Sales	Tunis	T. M.S. Technic Marketing Service Zone Industrielle Mghira 2 Lot No. 39 2082 Fouchana	Tel. +216 79 40 88 77 Fax +216 79 40 88 66 http://www.tms.com.tn tms@tms.com.tn
Turkey			
Assembly Sales Service	Istanbul	SEW-EURODRIVE Hareket Sistemleri Sanayi Ticaret Limited Şirketi Gebze Organize Sanayi Bölgesi 400.Sokak No:401 TR-41480 Gebze KOCAELİ	Tel. +90-262-9991000-04 Fax +90-262-9991009 http://www.sew-eurodrive.com.tr sew@sew-eurodrive.com.tr
Ukraine			
Assembly Sales Service	Dnipropetrovsk	ООО «СЕВ-Евродрайв» ул.Рабочая, 23-В, офис 409 49008 Днепропетровск	Тел. +380 56 370 3211 Факс. +380 56 372 2078 http://www.sew-eurodrive.ua sew@sew-eurodrive.ua
United Arab Emirates			
Sales Service	Sharjah	Copam Middle East (FZC) Sharjah Airport International Free Zone P.O. Box 120709 Sharjah	Tel. +971 6 5578-488 Fax +971 6 5578-499 copam_me@eim.ae
USA			
Production Assembly Sales Service	Southeast Region	SEW-EURODRIVE INC. 1295 Old Spartanburg Highway P.O. Box 518 Lyman, S.C. 29365	Tel. +1 864 439-7537 Fax Sales +1 864 439-7830 Fax Manufacturing +1 864 439-9948 Fax Assembly +1 864 439-0566 Fax Confidential/HR +1 864 949-5557 http://www.seweurodrive.com cslyman@seweurodrive.com
Assembly Sales Service	Northeast Region	SEW-EURODRIVE INC. Pureland Ind. Complex 2107 High Hill Road, P.O. Box 481 Bridgeport, New Jersey 08014	Tel. +1 856 467-2277 Fax +1 856 845-3179 csbridgeport@seweurodrive.com
	Midwest Region	SEW-EURODRIVE INC. 2001 West Main Street Troy, Ohio 45373	Tel. +1 937 335-0036 Fax +1 937 332-0038 cstroy@seweurodrive.com
	Southwest Region	SEW-EURODRIVE INC. 3950 Platinum Way Dallas, Texas 75237	Tel. +1 214 330-4824 Fax +1 214 330-4724 csdallas@seweurodrive.com
	Western Region	SEW-EURODRIVE INC. 30599 San Antonio St. Hayward, CA 94544	Tel. +1 510 487-3560 Fax +1 510 487-6433 cshayward@seweurodrive.com
	Additional addresses for service in the USA provided on request!		
Venezuela			
Assembly Sales Service	Valencia	SEW-EURODRIVE Venezuela S.A. Av. Norte Sur No. 3, Galpon 84-319 Zona Industrial Municipal Norte Valencia, Estado Carabobo	Tel. +58 241 832-9804 Fax +58 241 838-6275 http://www.sew-eurodrive.com.ve ventas@sew-eurodrive.com.ve sewfinanzas@cantv.net



Vietnam			
Sales	Ho Chi Minh City	All sectors except harbor, steel, coal power and offshore: Nam Trung Co., Ltd 250 Binh Duong Avenue, Thu Dau Mot Town, Binh Duong Province HCM office: 91 Tran Minh Quyen Street District 10, Ho Chi Minh City	Tel. +84 8 8301026 Fax +84 8 8392223 namtrungco@hcm.vnn.vn truongtantam@namtrung.com.vn khanh-nguyen@namtrung.com.vn
		Harbor and offshore: DUC VIET INT LTD Industrial Trading and Engineering Services A75/6B/12 Bach Dang Street, Ward 02, Tan Binh District, 70000 Ho Chi Minh City	Tel. +84 8 62969 609 Fax +84 8 62938 842 totien@ducvietint.com
		Coal power and steel: Thanh Phat Co Ltd DMC Building, L11-L12, Ward3, Binh Thanh Dist, Ho Chi Minh City	Tel. +84 835170381 Fax +84 835170382 sales@thanh-phat.com
	Hanoi	Nam Trung Co., Ltd R.205B Tung Duc Building 22 Lang ha Street Dong Da District, Hanoi City	Tel. +84 4 37730342 Fax +84 4 37762445 namtrunghn@hn.vnn.vn
Zambia			
Sales	Kitwe	EC Mining Limited Plots No. 5293 & 5294, Tangaanyika Road, Off Mutentemuko Road, Heavy Industrial Park, P.O.BOX 2337 Kitwe	Tel. +260 212 210 642 Fax +260 212 210 645 sales@ecmining.com http://www.ecmining.com



Index

A

Adapter	
EBH.....	40
ECH.....	42
EPH.....	40
Mounting	40
Adapter EPH	18
Amount of oil	60
Anti-friction bearing greases	60
Assembly	
Prerequisites	21
With key	30
Without key	31

B

Breather valve	25
Activation	25
BS.F..	
Fill quantities	63
Fill quantities dependent on mounting position	63
Fill quantity tolerances	63
Installation in the machine	26
Mounting positions	55

C

Centering ring	
Inner	32
Outer	32
Change in mounting position	60
Clamping area.....	31
Copyright.....	6
Corrosion	31
Corrosion, electrochemical.....	22
Coupling mounting	32
Customer service	65

D

Damp locations	24
Demounting the motor	47
Design	
PS.F.. planetary gear units	12
Design of the gear unit.....	10
Designation	18
Direction of rotation, check.....	48
Disposal	66
Documentation	8

E

Embedded safety notes	5
EPH adapter	18
Exclusion of liability.....	6

F

Fill quantities	
BS.F	63
PS.F	63, 64
Fill quantities dependent on mounting position	
PS.F.....	63
Fill quantities depending on mounting position	
BS.F.....	63
Fill quantity tolerances	
BS.F.....	63
PS.F.....	64
Flange block	32
Flatness defects.....	22
Flatness errors	22
Foot mounting	27
Front-end mounting	27

G

Gear unit	
Fastening	23
Installation.....	22
Painting.....	26
Ventilation	25
Grounding	22

I


Initial startup	48
Inner centering ring	32
Inner clamping set	31
Inspection	50
Intervals	51
Installation	
Gear unit.....	22
In damp locations or in the open.....	24
Mechanical.....	20
Prerequisites.....	21
Installation in the machine	
BS.F.....	26
PS.C..	28
PS.F.....	28



Intervals		Mounting positions	53
Inspection	51	BS.F.	55
Lubrication change	51	PS.C.	58
Maintenance	51	PS.F.	58
Inverter operation	48	Symbols used	54
		M1 to M6, mounting positions	53
L			
Limit speed	48	N	
Lubricant		Nameplate	18
Change intervals	51	Nomenclature	18
Lubricant fill quantity	60	Normal operation	48
Lubricant table	62	Notes	
Lubricants	60	Identification in the documentation	5
General information	60		
Service life	60	O	
		Oil temperature, measuring	49
M		Operation	
Machine		Initial startup	48
Installation of BS.F.. gear unit	26	Other applicable documentation	8
Installation of PS.F.. gear unit	28	Outer centering ring	32
PS.C.. gear unit installation	28	Output elements, mounting to solid shafts	29
Maintenance	50	Overhung loads, avoiding	31
Intervals	51		
Malfunctions	65	P	
Gear unit	65	Painting the gear unit	26
Maximum weights of motors	44	Permitted maximum weights	44
Measuring, surface and oil temperatures	49	PS.C..	
Mechanical installation	20	Installation in the machine	28
Motor adapter	48	Mounting positions	58
Motor mounting		PS.F..	
With EBH.. adapter	40	Fill quantities	63, 64
With ECH.. adapter	42	Fill quantities dependent on mounting position	63
With EPH.. adapter	40	Fill quantity tolerances	64
Motor, demounting	47	Installation in the machine	28
Mounting		Mounting positions	58
Couplings	32		
Gear unit fastening	23	R	
Motor mounting	40	Repair	65
Output elements to solid shafts	29	Rights to claim under limited warranty	6
Sequence	40		
Shrink disks	36	S	
Torque arm for BS.F.. shaft-mounted gear units	33	Safety Notes	
With key	30	Structure of the embedded	5
With mounting device	30	Structure of the section-related	5
Without key	31	Safety notes	
Mounting device	30	Identification in the documentation	5
		Screw quality	22
		Screws	22



Section-related safety notes	5	Structure	
Sequence for mounting	40	Adapter	15, 17
Service	65	BS.F.. helical-bevel gear unit.....	11
Shaft connection, mounting arrangement	32	PS.C.. planetary gear unit.....	14
Shaft-mounted gear unit		Surface temperature, measuring	49
Keyway	34		
Shaft-mounted gear units		T	
Torque arm for BS.F.. gear units	33	Technical data	60
Shrink disk		Tightening torques	22, 23
Cleaning	39	Tolerances for shafts and flanges.....	20
Lubrication	39	Torque arm	
Shrink disks, (dis-) assembly	36	For BS.F.. shaft-mounted gear units.....	33
Signal words in the safety notes	5	Transport fixture.....	25
Solvents	21	Type designation	18
Startup	48		







SEW-EURODRIVE
Driving the world

SEW
EURODRIVE

SEW-EURODRIVE GmbH & Co KG
P.O. Box 3023
D-76642 Bruchsal/Germany
Phone +49 7251 75-0
Fax +49 7251 75-1970
sew@sew-eurodrive.com

→ www.sew-eurodrive.com