



SEW
EURODRIVE

Product Manual



Application Inverter
MOVIDRIVE® technology



Table of contents

1	Product description.....	6
1.1	MOVIDRIVE® technology	6
1.2	MOVIDRIVE® technology at a glance	11
1.3	Product overview of MOVIDRIVE® technology	17
1.4	Product overview of accessories	19
1.5	FCB concept	26
1.6	Control modes.....	33
1.7	Energy-saving functions.....	37
1.8	MOVISUITE® engineering software	37
1.9	MOVIKIT® software modules	39
1.10	Digital motor integration with MOVILINK® DDI interface	40
2	Technical data.....	42
2.1	Marks	42
2.2	General technical data	47
2.3	Environmental conditions.....	48
2.4	Technical data of basic device.....	49
2.5	Accessories part numbers	54
2.6	Electronics data – signal terminals	56
2.7	Electronics data – safety subfunction	57
2.8	Dimension sheets	58
2.9	Technical data of the keypads	65
2.10	Technical data of the cards.....	66
2.11	Technical data of encoder interfaces.....	77
2.12	Technical data of braking resistors, filters, and chokes	78
2.13	USM21A interface adapter.....	104
3	Project planning.....	105
3.1	SEW-Workbench	105
3.2	Schematic workflow for project planning.....	106
3.3	Drive selection	107
3.4	Recommendations for motor and inverter selection	118
3.5	Motor/inverter assignments.....	123
3.6	Inverter selection.....	124
3.7	Braking resistor selection.....	129
3.8	Supply system cables and motor cables.....	152
3.9	Signal cables.....	154
3.10	EMC-compliant installation according to EN 61800-3.....	154
3.11	Line components.....	156
3.12	Components on the output side	158
3.13	24 V supply voltage selection	161
4	Prefabricated cables	163
4.1	Meaning of the symbols	163
4.2	Power cables for CM3C.. motors.....	164
4.3	Encoder cables for CM3C.. motors.....	167

4.4	Power cables for CMP.. motors	169
4.5	Encoder cables for CMP.. motors	175
4.6	Power cables for CFM.. motors	178
4.7	Encoder cables for CFM.. motors	183
4.8	Encoder cables for DR.. motors	186
4.9	Cables for MOVILINK® DDI	197
4.10	Motor cables for motors with MOVILINK® DDI interface	203
4.11	System bus and module bus cables	209
5	General information.....	212
5.1	About this documentation	212
5.2	Structure of the safety notes	212
5.3	Decimal separator in numerical values	214
5.4	Rights to claim under limited warranty	214
5.5	Content of the documentation	214
5.6	Other applicable documentation	214
5.7	Product names and trademarks	214
5.8	Copyright notice	215
5.9	Short designation	215
6	Safety notes	216
6.1	Preliminary information	216
6.2	Duties of the user	216
6.3	Target group	217
6.4	IT security of the environment.....	217
6.5	Designated use	218
6.6	Functional safety technology	218
6.7	Installation/assembly	219
6.8	Electrical installation	220
6.9	Protective separation	220
6.10	Startup/operation	221
7	Device structure	222
7.1	Connection variants	222
7.2	Nameplates.....	223
7.3	MOVIDRIVE® technology type code	224
7.4	Device structure of the inverter	225
7.5	Card slots	232
8	Installation.....	233
8.1	Permitted tightening torques	233
8.2	Permitted terminal cross sections	234
8.3	Special aspects when transporting the devices	236
8.4	Mechanical installation.....	238
8.5	Covers.....	241
8.6	Control cabinet installation.....	244
8.7	Electrical installation	249
8.8	Installing options and accessories	263

8.9	BW.. braking resistors	273
8.10	NF.. line filter	283
8.11	EMC-compliant installation	283
8.12	Terminal assignment of basic device	289
8.13	Wiring diagrams	296
8.14	Information regarding UL	310
9	Startup	315
9.1	General	315
9.2	Setting the EtherCAT® ID	316
9.3	Startup requirements	317
9.4	Startup with MOVISUITE® engineering software	318
9.5	Connection to the service interface	319
9.6	Setting the module bus operating mode	321
9.7	Startup with the CBG11A keypad	322
9.8	Startup with the CBG21A keypad	324
9.9	Startup with the CBG22A keypad	326
9.10	Engineering accesses of the inverter	329
10	Operation	330
10.1	General information	330
10.2	CMM11A memory module	331
10.3	7-segment display	332
10.4	Operating displays	333
10.5	Fault description on basic device	345
10.6	Power section fault description	417
10.7	Fieldbus interface fault description	427
10.8	Responses to fault acknowledgement	430
10.9	Fault responses	432
11	Service	435
11.1	Electronics Service by SEW-EURODRIVE	435
11.2	Extended storage	435
11.3	Device replacement	435
11.4	Shutdown	437
11.5	Waste disposal	437
12	Functional safety	438
12.1	General information	438
12.2	Integrated safety technology	438
12.3	Safety conditions	444
12.4	Connection designs	449
12.5	Safety characteristics	454
13	Appendix	455
13.1	Abbreviation key	455
	Index	457
14	Address list	463

1 Product description

With its brand MOVI-C®, SEW-EURODRIVE is launching a new generation of drive and automation technology. MOVI-C® is the modular automation system that enables the highest level of system and machine automation. MOVI-C® comprises drive technology, motion control, control technology, and visualization.

1.1 MOVIDRIVE® technology

In this case, MOVIDRIVE® technology is the application inverter for direct line connection. It is suited to a wide variety of applications, ranging from simple open-loop speed control to servo drives with kinematic model. The product range is used for direct connection to controllers via industrial communication networks, such as PROFINET or EtherNet/IP™.

MOVIDRIVE® technology consists of the following:

- Application inverter basic device
- Application level for using MOVIKIT® software modules of the Drive category
- Optional keypads
- Cards for connecting to industrial communication networks
- Cards for functional safety in functionally different versions
- Cards for connecting additional distance encoders
- Cards for upgrading digital and analog inputs and outputs
- Accessories for EMC-compliant installation
- Accessories for connecting and controlling motors and brakes
- Prefabricated motor and encoder cables

For use in harsh environments, the inverters can be supplied with painted PCBs. The coating of the printed circuit boards increases their resistance against environmental influences.

1.1.1 Main features


The inverter has the following main features:

Consistency:	Entire MOVI-C® portfolio
Engineering software:	MOVISUITE®
Software modules:	MOVIKIT®
Connection to controllers via:	<ul style="list-style-type: none"> • PROFINET • PROFIBUS • EtherNet/IP™ • Modbus TCP • EtherCAT® • POWERLINK • Safety over EtherCAT® • ISOFAST®
Data management:	Via portable memory module

Nominal line voltage:	<ul style="list-style-type: none"> • 3 × 380 to 500 V • 3 × 200 to 240 V
Degree of protection:	IP20 in accordance with EN 60529
Overload capacity:	200%
EtherCAT®/SBus ^{PLUS} :	Integrated
Multi-encoder interface:	Integrated
Digital motor integration interface:	Integrated
STO PI e safety function:	Integrated
Output current:	<ul style="list-style-type: none"> • 2 – 588 A (400 V) • 7 – 108 A (230 V)
Control mode:	<ul style="list-style-type: none"> • V/f for simple applications with asynchronous motors • VFC^{PLUS} for precise control of asynchronous motors • CFC for asynchronous and synchronous servomotors • ELSM® for synchronous motors without encoders
Functions:	<ul style="list-style-type: none"> • Speed control • Torque control • Positioning control
Operable motors:	<ul style="list-style-type: none"> • Rotary and linear asynchronous motors with and without encoders • Rotary and linear synchronous motors with and without encoders
DC 24 V switched-mode power supply:	<ul style="list-style-type: none"> • MDX90A-...: Without DC 24 V switched-mode power supply • MDX91A-...: With DC 24 V switched-mode power supply
Card slot 1:	For connection to PROFINET, PROFIBUS, EtherNet/IP™, Modbus TCP, POWERLINK
Card slot 2:	For safety module and/or additional encoder
Card slot 3:	For I/O extension

1.1.2 Topologies

MOVI-C® single-axis automation




The following devices are connected directly to the higher-level master via fieldbus interfaces:

- MOVIDRIVE® technology application inverter
- MOVITRAC® advanced standard inverter
- MOVIGEAR® performance decentralized drive unit
- MOVIMOT® advanced decentralized drive unit
- MOVIMOT® performance decentralized drive unit
- MOVIMOT® flexible decentralized inverter

The drive function is delivered at speed and safely with graphic editors using the pre-defined MOVIKIT® software modules. Each drive axis is controlled individually via the network.

Data is stored via a data exchange function, for example, on a memory card in the application inverters and decentralized units.

POWERLINK



The CiA402 profile for controlling inverters has established itself in systems with highly specific motion control applications that are calculated in the higher-level master controller.

For control via the CiA402 communication profile, the following devices can be connected to the controller via the integrated EtherCAT® or POWERLINK interface:

- MOVIDRIVE® application inverter
- MOVITRAC® inverter
- MOVIGEAR® performance decentralized drive unit
- MOVIMOT® flexible decentralized inverter

This means integration into the higher-level controller is particularly quick and easy, without any need for extensive conversion work.


1.1.3 Engineering software

The MOVISUITE® engineering software is the central component of the MOVI-C® modular automation system. This software allows for intuitive operation with modern operating concepts.





Central functions of MOVISUITE®:




- Network scan
- Device startup and parameterization
- Data storage and data management
- Scope and diagnostics
- Programming environment for MOVI-C® CONTROLLER
- Parameterization for functional safety
- Parameterization and diagnostics environment for application modules




1.2 MOVIDRIVE® technology at a glance



MOVIDRIVE® technology	
	<p>Description: (→ 17)</p> <p>Technical data: (→ 58)</p> <ul style="list-style-type: none"> Nominal output current: 2 to 588 A Voltage ranges: 3 × 380 to 500 V, 3 × 200 to 240 V Frequency range: 50 to 60 Hz Overload capacity: Up to 200% of the nominal output current System bus: EtherCAT®/SBus^{PLUS} <p>For more information on the device, refer to the following documents:</p> <ul style="list-style-type: none"> "DC Link Connection" manual "MOVI-C® with regenerative power supply MDR60A0150-503-00" manual Addendum to the "Information about the EU Ecodesign Regulation 2019/1781" operating instructions



Accessories	
Prefabricated motor and encoder cables	"Description and technical data:"
Braking resistors	"Description and technical data:" (→ 78)
Line filter	"Description and technical data:" (→ 93)
Output filter	"Description and technical data:" (→ 97)
Line choke	"Description and technical data:" (→ 95)
DC link choke	"DC link chokes ZD.." (→ 101)
Output choke	"Description and technical data:" (→ 99)
Valid motor encoders	(→ 116)

Keypads	
<p>CBG11A</p> 	<p>Description: (→ 19)</p> <p>Technical data: (→ 65)</p> <ul style="list-style-type: none"> • 1.5" monochrome display (38 mm) • Startup of simple applications (asynchronous motors without an encoder) • Diagnostics • Saving and copying a parameter set • Connection to MOVISUITE® engineering software via keypad • Language: EN
<p>CBG21A</p> 	<p>Description: (→ 20)</p> <p>Technical data: (→ 65)</p> <ul style="list-style-type: none"> • 2.4" color display (61 mm) • Language selection. Selectable languages: DE/EN/FR/IT/ES/PT/HU/ZH/RU • Startup of motor, brake, encoder • Diagnostics • Saving and copying several parameter sets • Connection to MOVISUITE® engineering software via keypad
<p>CBG22A</p> 	<p>Description: (→ 21)</p> <p>Technical data: (→ 65)</p> <ul style="list-style-type: none"> • Simple and intuitive manual mode for maintaining operation in the event of a malfunction in the facility • Extensive diagnostics options • Exclusively read-only access to parameters in order to protect against incorrect use • Optional access to functions and states of the control elements and data transfer for Ethernet-based communication methods of the drive systems
Door mounting frame	
<p>COG11A</p> 	<p>Door mounting frame for the following keypads:</p> <ul style="list-style-type: none"> • CBG11A • CBG21A • CBG22A <p>For information on this device, refer to the "Installation instructions for COG11A".</p>

Cards		
Input/output card		Description: (→ 23) Technical data: (→ 66)
<div>CIO21A</div> 	<div>CID21A</div> 	<p>CIO21A</p> <ul style="list-style-type: none">• 4 digital inputs• 4 digital outputs• 2 analog inputs• 2 analog outputs <p>CID21A</p> <ul style="list-style-type: none">• 4 digital inputs• 4 digital outputs
<div>CES11A multi-encoder card</div> 	<p>Description: (→ 23) Technical data: (→ 68)</p> <p>The multi-encoder card makes it possible to evaluate additional encoders.</p> <p>For information on this card, refer to the following document:</p> <ul style="list-style-type: none">• "Multi-encoder card CES11A" manual	

Cards		
<p>CSS31A/CSB31A safety card</p> 	<p>CSS21A/CSB21A safety card</p> 	<p>Description: (→ 25)</p> <p>Technical data: (→ 75)</p> <p>The basic device already contains the safety function STO with activation via safe inputs. Higher-level functional safety requirements can be added by inserting a CS.. safety card. Four different variants are used to implement safety functions of varying quality.</p> <p>Safety card properties:</p> <ul style="list-style-type: none"> • SIL3 in accordance with EN 61800-5-2, EN 61508 • PL e in line with EN ISO 13849-1 • Can be inserted retrospectively at any time, with no additional external cables needed. Internal connection to motor encoder, safe communication, and STO • Safety card parameters are included in the device data set • Easy replacement during servicing due to pluggable safety key on the safety card • Parameterization and diagnostics using the MOVISUITE® engineering software • Process data and safety data in the same Scope recording • Safe output for activating functionally safe braking systems <p>For information on this card, refer to the following document:</p> <ul style="list-style-type: none"> • "MOVISAFE® CS..A Safety Card" manual
<p>CSA31A safety card</p> 		

Fieldbus interfaces	
<div><div>CFE21A</div><div>EtherNet/IP™, Modbus TCP</div><div></div></div>	<div><div>Description: (→ 24)</div><div>Technical data: (→ 69)</div><div>The CFE21A card acts as the interface to the EtherNet/IP™ and Modbus TCP communication protocols.</div><div>The POWERLINK fieldbus interface can only be used in the L-0. device variant of the MOVIDRIVE® technology application inverter.</div></div>
<div><div>CFN21A</div><div>PROFINET</div><div></div></div>	<div><div>Description: (→ 24)</div><div>Technical data: (→ 70)</div><div>The CFN21A card acts as the interface to the PROFINET communication protocol. The POWERLINK fieldbus interface can only be used in MOVIDRIVE® technology with the L-0. device variant.</div></div>

Fieldbus interfaces	
<div> <div>CFL21A</div> <div>POWERLINK</div>  </div>	<div> Description: (→ 25) Technical data: (→ 74) The CFL21A card acts as the interface to the POWERLINK communication protocol. </div>
<div> <div>CFP21A</div> <div>PROFIBUS</div>  </div>	<div> Description: (→ 24) Technical data: (→ 72) The CFP21A card acts as the interface to the PROFIBUS communication protocol. </div>
Engineering software	
Engineering software	MOVISUITE®
Software modules	
MOVIKIT®	<ul style="list-style-type: none"> • MOVIKIT® Velocity Drive • MOVIKIT® Positioning Drive • MOVIKIT® RapidCreepPositioning Drive

1.3 Product overview of MOVIDRIVE® technology

- Characteristics
- Coverage of a wide range of power ratings with finely graded performance classes
 - Universal use due to a wide voltage range for line connection
 - Suitable for TN/TT and IT voltage supply systems
 - The EtherCAT®/SBus^{PLUS} system bus and the EtherNet/IP™, Modbus TCP, PROFINET, PROFIBUS and POWERLINK fieldbus interfaces are available for communication
 - 4-quadrant capability due to integrated brake chopper
 - High overload capacity of up to 200% of the nominal output current
 - Optimized control modes with and without encoder feedback for asynchronous and synchronous motors
 - Integrated flux optimization for partial load operation of asynchronous motors and standby mode
 - Integrated drive safety function for safe disconnection of PL e in accordance with EN 13849, see chapter "Functional safety"
 - Simplified motor startup for asynchronous motors and synchronous motors, and for unknown motors supported by measuring the motor parameters
 - Consistent operation in user units

Device data 3 × AC 230 V

Type designation	Nominal output current at the smallest possible PWM frequency	Recommend- ed motor power ASM	Nominal line current	Size	Technical data
	A	kW	A		
MDX9.A-0070-2E3-4-T..	7	1.5	6.4	2	(→ 52)
MDX9.A-0093-2E3-4-T..	9.3	2.2	8.4		
MDX9.A-0140-2E3-4-T..	14	3.7	12.4	3	
MDX9.A-0213-203-4-T..	21.3	5.5	18.9	4	
MDX9.A-0290-203-4-T..	29	7.5	27.4		
MDX9.A-0420-203-4-T..	42	11	40.8	5	
MDX9.A-0570-203-4-T..	57	15	52		
MDX91A-0840-203-4-T..	84	22	76	6	
MDX91A-1080-203-4-T..	108	30	86		

Device data 3 × AC 400 V


Type designation	Nominal output current at the smallest possible PWM frequency	Recommend- ed motor power ASM	Nominal line current	Size	Technical data
	A	kW	A		
MDX9.A-0020-5E3-4-T..	2	0.55	1.9	1	(→ 49)
MDX9.A-0025-5E3-4-T..	2.5	0.75	2.3		
MDX9.A-0032-5E3-4-T..	3.2	1.1	2.9		
MDX9.A-0040-5E3-4-T..	4	1.5	3.6		
MDX9.A-0055-5E3-4-T..	5.5	2.2	5	2	
MDX9.A-0070-5E3-4-T..	7	3	6.3		
MDX9.A-0950-5E3-4-T..	9.5	4	8.6		
MDX9.A-0125-5E3-4-T..	12.5	5.5	11.3	3	
MDX9.A-0160-5E3-4-T..	16	7.5	14.4		
MDX9.A-0240-503-4-T..	24	11	22	4	
MDX9.A-0320-503-4-T..	32	15	29		
MDX9.A-0460-503-4-T..	45	22	42	5	
MDX9.A-0620-503-4-T..	62	30	56		
MDX9.A-0750-503-4-T..	75	37	68		
MDX91A-0910-503-4-T..	91	45	82	6	(→ 49)
MDX91A-1130-503-4-T..	113	55	102		
MDX91A-1490-503-4-T..	149	75	135		
MDX91A-1770-503-4-T..	177	90	160	7	
MDX91A-2200-503-4-T..	220	110	198		
MDX91A-2500-503-4-T..	250	132	225		
MDX91A-3000-503-4-T..	300	160	280		
MDX91A-3800-503-4-T..	380	200	340	8	
MDX91A-4700-503-4-T..	470	250	435		
MDX91A-5880-503-4-T..	588	315	545		

1.4 Product overview of accessories

1.4.1 CBG11A keypad

The keypad enables convenient startup, operation, parameterization, and diagnostics of inverters of the MOVI-C® modular automation system due to the full-text display.

The keypad has a mini USB interface with gateway function. A connection from the inverter to a PC can be established using this interface for engineering with MOVISUITE®.



30556389899

Range of functions of CBG11A:


- Startup of asynchronous motors without encoder, with or without brake, with motor sensor
- Brake selection
- Temperature sensor selection
- Determining the load inertia
- Access to all parameters

A COG11A door mounting frame is available for the keypad.

1.4.2 CBG21A keypad

The keypad enables convenient startup, operation, parameterization, and diagnostics of inverters of the MOVI-C® modular automation system due to the full-text display.

The keypad has a mini USB interface with gateway function. A connection from the inverter to a PC can be established using this interface for engineering with MOVISUITE®.



30556392331

Range of functions of CBG21A:


- Startup of asynchronous motors
- Startup of synchronous motors
- Brake selection
- Temperature sensor selection
- Selection of encoders
- Determining the load inertia
- Optimization of the drive train in terms of clearance and stiffness
- Access to all parameters

A COG11A door mounting frame is available for the keypad.

1.4.3 CBG22A keypad

The full-text display of the keypad allows for a convenient display of customer-specific information texts of the higher-level controller. It also allows for the operator to perform diagnostics and manual operation.

The keypad has a mini USB interface with gateway function. A connection from the inverter to a PC can be established using this interface for engineering with MOVISUITE®.




35206062859

Range of functions of the CBG22A:

- Can be used for diagnostic purposes


A COG11A door mounting frame is available for the keypad.

1.4.4 CMM11A or CMM21A memory module



25585405451

The pluggable memory module is supplied independently of the device variant.



18014424052791691

[1] Memory module

All device data is always stored up-to-date on the memory module. If a device needs to be replaced, the system can be started up again in next to no time without additional tools by simply removing the memory module from the old device and plugging it into the replacement.

The memory module can be simply removed or plugged in when it is switched off.

1.4.5 CID21A input/output card

This input/output card is used to increase the number of digital inputs and outputs of the basic device.

- 4 digital inputs
- 4 digital outputs

1.4.6 CIO21A input/output card

This input/output card is used to increase the number of digital and analog inputs and outputs of the basic device.

- 4 digital inputs
- 4 digital outputs
- 2 analog inputs (current/voltage)
- 2 analog outputs (current/voltage)

1.4.7 CES11A multi-encoder card

The CES11A multi-encoder card enables evaluation of an additional encoder. The additional encoder can be used as an external encoder or as a motor encoder.

The following encoders are supported:

HTL 12/24 V (differential)
TTL (differential)
RS422
SIN/COS 1 V _{PP} (differential)
HIPERFACE® with sin/cos signals 1 V _{PP}
SEW encoder (RS485) with sin/cos signals 1 V _{PP} , e.g. AK8W, AS7W, AG7W
EnDat 2.1 with sin/cos signals 1 V _{PP}
SSI encoder with/without sin/cos signals 1 V _{PP}
CANopen encoder

Besides the encoders listed above, further encoders that can be used are described in chapter "Applicable motor encoders from SEW-EURODRIVE".

1.4.8 Fieldbus interface for EtherNet/IP™ and Modbus TCP CFE21A fieldbus card

The fieldbus interface makes it possible to connect the inverter to EtherNet/IP™ or Modbus TCP-based, higher-level automation, project planning, and visualization systems. The fieldbus interface has the following characteristics:

- EtherNet/IP™ or Modbus TCP
- Media redundancy
- Integrated switch with cut-through procedure

When using the fieldbus interface, you can communicate directly with the devices via Ethernet and use the MOVISUITE® engineering software for startup, diagnostics, and parameterization purposes.

An integrated web server also makes it possible to access diagnostic values quickly and easily using a standard Internet browser. You can access this web server at the following address: *http: ///IP address of the device.*

1.4.9 Fieldbus interface for PROFINET CFN21A fieldbus card

The fieldbus interface makes it possible to connect the inverter to PROFINET-based, higher-level automation, project planning and visualization systems.

When using the fieldbus interface, you can communicate directly with the devices via Ethernet and use the MOVISUITE® engineering software for startup, diagnostics, and parameterization purposes.

An integrated web server also makes it possible to access diagnostic values quickly and easily using a standard Internet browser. You can access this web server at the following address: *http: ///IP address of the device.*

1.4.10 Fieldbus interface for PROFIBUS CFP21A fieldbus card

This fieldbus interface makes it possible to connect the inverter to PROFIBUS-based, higher-level automation, project planning and visualization systems.

The fieldbus interface has the following characteristics:

- PROFIBUS DP/DP-V1 – cyclic and acyclic communication

For communication, the engineering PC with the USM21A interface adapter or the CBG21A keypad must be connected to the inverter.

1.4.11 Fieldbus interface for POWERLINK CFL21A fieldbus card

The fieldbus interface makes it possible to connect the inverter to POWERLINK-based, higher-level automation, project planning and visualization systems, as well as the CiA402 device profile.

The fieldbus interface has the following characteristics:

- POWERLINK slave (CiA402 drive profile)
- Integrated switch with cut-through procedure

The POWERLINK fieldbus interface can only be used in the L-0. device variant of the MOVIDRIVE® technology application inverter.

When using the fieldbus interface, you can communicate directly with the devices via POWERLINK and use the MOVISUITE® engineering software for startup, diagnostics, and parameterization purposes. The POWERLINK fieldbus interface can only be used in MOVIDRIVE® technology with the L-0. device variant.

An integrated web server also makes it possible to access diagnostic values quickly and easily using a standard Internet browser. You can access this web server at the following address: <http://IP address of the device>.

1.4.12 CS..A safety cards

The MOVISAFE® CS..A safety cards provide further functional safety functions according to EN IEC 61800-5-2 in addition to STO. The MOVISAFE® CS..A safety cards and the CES11A multi-encoder card are intended to be used in the same card slot and thus cannot be used simultaneously. For this reason, the CS.31A safety cards are available with an additional multi-encoder input.

For a detailed description, refer to the "MOVISAFE® CS..A Safety Card" manual.

	CSB21A	CSB31A	CSS21A	CSS31A	CSA31A
Safe inputs	4	4	4	4	4
Safe outputs	-	2	2	2	2
Safe stop functions	STO, SS1-t	STO, SS1-t, SBC	STO, SS1-t, SBC	STO, SS1-t, SBC	STO, SS1-t, SBC
Safe movement functions	-	-	SOS, SS1-r, SS2, SLS, SSR, SLA, SSM, SDI	SOS, SS1-r, SS2, SLS, SSR, SLA, SSM, SDI	SOS, SS1-r, SS2, SLS, SSR, SLA, SSM, SDI
Safe positioning functions	-	-	SLI	SLI	SLI, SLP, SCA
Other functions	-	-	-	-	SBT
Multi-encoder input	-	yes	-	yes	yes
Safe communication	PROFIsafe, FSoE, ISOFAST®				

1.5 FCB concept

FCB = Function Control Block

The FCB concept describes the modular firmware design of MOVI-C® inverters. This feature ensures that a wide range of drive functions can be selected or deselected quickly and easily using control words.

All primary functions are selected as FCBs. For example, positioning control requires the FCB 09, while speed control is implemented with FCB 05.

You can switch between different FCBs at any time. Switching to another FCB is performed with a maximum delay of 0.5 ms.

Different priorities are assigned to the FCBs. If an FCB with a higher priority than the currently active FCB is selected, the FCB with the higher priority is activated.

The FCBs are sorted in descending order of their priority in the following list:

- FCB 01 Output stage inhibit
- FCB 14 Emergency stop
- FCB 13 Stop at application limits
- FCB 18 Rotor position identification
- FCB 25 Motor parameter measurement
- FCB 12 Reference travel
- FCB 04 Manual mode
- FCB 20 Jog mode
- FCB 19 Position hold control
- FCB 21 Brake test
- FCB 10 Interpolated position control
- FCB 09 Position control
- FCB 06 Interpolated speed control
- FCB 05 Speed control
- FCB 08 Interpolated torque control
- FCB 07 Torque control
- FCB 26 Stop at user limits
- FCB 02 Default stop

1.5.1 Description of the FCBs

FCB 01 Output stage inhibit

Activating FCB 01 stops the connected motor via the motor brake. If no brake is installed, the motor coasts to a stop.

FCB 02 Default stop

FCB 02 stops the drive with the preset profile value "Maximum deceleration". This value is limited by "Application limit – deceleration".

FCB 02 is active (default) when no other FCB is selected.

FCB 02 is selected by the system, not by the operator.

FCB 04 Manual mode

The function block can be selected and activated via the function "Manual mode" using the MOVISUITE® engineering software. Manual mode is used for startup or for teach mode without higher-level controller.

FCB 04 is selected by the system, not by the operator.

FCB 05 Speed control

The inverter can be operated as a speed-controlled axis.

The user can specify profile values for acceleration, deceleration, and jerk as the basic conditions for speed control. The actual speed setpoint for the drive controller is generated in the controller cycle by a profile generator integrated in the inverter using the specified limit values.

FCB 06 Interpolated speed control

FCB 06 is used for cyclical speed setpoint inputs from higher-level controllers.

In multi-axis applications, a controller often calculates a path profile for several drive axes. The axis is only assigned setpoints (speed/torque and torque limits/precontrol values/inertia) that it has to follow. The axis limits the setpoints using the application limits. The course of the path curve profile is controlled by the controller.

The setpoint cycle of the controller usually does not correspond to the setpoint cycle of the axis. If the axis were to "see" the same setpoint for several cycles, a step-shaped actual value would result. To prevent this from happening, the axis interpolates intermediate values. To do so, the setpoint cycle of the controller has to be known.

FCB 07 Torque control

The inverter can be operated as a torque-controlled axis.

The user can specify profile values for deceleration and jerk as the basic conditions for torque control. The actual torque setpoint for the drive controller is generated in the controller cycle by a profile generator integrated in the inverter using the specified limit values.

During torque control, the maximum speed is restricted by the speed limits so that the drive cannot permanently accelerate with the preset setpoint torque while the counter-torque is too low.

FCB 08 Interpolated torque control

FCB 08 is used for cyclical torque setpoint input from a higher-level controller.

This higher-level controller usually calculates a track profile for several drive axes. The axis is then assigned just one setpoint (torque, torque limits, precontrol values, inertia) that it has to follow.

The inverter limits the setpoints using the application limits. The path curve profile is controlled by the controller.

The cycle in which the controller sends the setpoints to the axis does not usually correspond to the setpoint processing cycle of the inverter. If the inverter were to "see" the same controller setpoint for several cycles, a step-shaped actual torque value would result.

To prevent this from happening, the axis can calculate (interpolate) intermediate values if it knows the controller cycle. The inverter can be set to different cycle times of higher-level controllers.

FCB 09 Position control

FCB 09 is used for positioning to make it possible to use a position profile for reaching the target position. This position profile is parameterized by the profile generator.

The inverter additionally provides several positioning modes, which are described as follows:

Absolute positioning:

The position setpoint in user units is interpreted as an absolute target and is converted and executed in system units.

The travel range in system units is -2^{31} to $2^{31} - 1$. If the travel range is exceeded after calculation, the FCB issues an error.

Relative positioning:

The position setpoint in user units is interpreted as an offset to the latest setpoint and is added to the last setpoint after conversion into system units.

If the time calculated in system units is outside the travel range of -2^{31} to $2^{31} - 1$, the FCB issues an error.

Modulo in positive direction with absolute position specification:

The position setpoint in user units is interpreted as the absolute position. It must be within the modulo range of the active drive:

Lower limit = "Modulo min."

Upper limit = "Modulo max."

If the position setpoint is outside this range, an error is issued. The drive always turns in a positive direction to reach the position.

Modulo in negative direction with absolute position specification:

The position setpoint in user units is interpreted as the absolute position. It must be within the modulo range of the active drive:

Lower limit = "Modulo min."

Upper limit = "Modulo max."

If the position setpoint is outside this range, an error is issued. The drive always turns in a negative direction to reach the position.

Modulo with shortest distance with absolute position specification:

The position setpoint in user units is interpreted as the absolute position. It must be within the modulo range of the active drive:

Lower limit = "Modulo min."

Upper limit = "Modulo max."

If the position setpoint is outside this range, an error is issued.

The direction of the drive is determined using the last setpoint position (= current actual position after activation without an "In position" message) and the current setpoint position. From here, the shortest distance is determined and the direction of rotation for positioning is specified accordingly.

FCB 10 Interpolated position control

FCB 10 is used for cyclic preselected position setpoints of higher-level controllers.

In multi-axis applications, a higher-level controller usually calculates a track profile for several drive axes. The axis is only assigned setpoints (position, speed, torque, torque limits, precontrol values, inertia) that it has to follow. The axis limits the setpoints using the application limits. The course of the profile of the path curve is controlled by the controller.

The setpoint cycle of the controller does usually not correspond to the setpoint cycle of the axis. If the axis were to "see" the same setpoint for several cycles, a step-shaped actual value would result. To prevent this from happening, the axis can interpolate intermediate values. To do so, the setpoint cycle of the controller has to be known.

FCB 12 Reference travel

To perform positioning operations, a drive has to be referenced to a defined start or reference position within the permitted travel distance.

From this reference position, positions such as the machine zero can be specified and approached. With each restart of the inverter, referencing the position encoders is always necessary if position encoders do not have an absolute position detection. When using absolute encoders, the absolute position is immediately known when starting the system. An absolute encoder still has to be referenced to match the displayed position with the plant's reference system.

Several reference travel types are available for referencing and for finding the reference point:

- 0: Deactivated
- 1: Zero pulse – negative end
- 2: Reference cam – negative end
- 3: Reference cam – positive end
- 4: Positive limit switch
- 5: Negative limit switch
- 6: Reference cam flush – limit switch positive
- 7: Reference cam flush – limit switch negative
- 8: Referencing to reference travel
- 9: Positive fixed stop
- 10: Negative fixed stop
- 11: Absolute position of encoder

FCB 13 Stop at application limits

When FCB 13 is activated, the drive stops with speed control using the preset application limit deceleration.

FCB 14 Emergency stop

When FCB 14 is activated, the drive stops with the preset emergency stop deceleration.

Note that the application limits are not taken into account.

FCB 18 Rotor position identification

For the operation of permanent magnet synchronous motors, the exact position information of the rotor is required for closed-loop control.

FCB 18 is required for the encoder calibration of rotary and linear synchronous motors with encoder. FCB 18 requires an electrical startup of the drive.

The drive must be disconnected from the load, which means also from the gear unit.

For a third-part motor, it is recommended to run FCB 25 before performing rotor position identification.

FCB 19 Position hold control

When FCB 19 is activated, the drive stops with speed control. After the standstill of the drive, the position is kept with position control as long as FCB 19 is active.

FCB 20 Jog mode

FCB 20 is used for setup mode when a higher-level controller is used.

FCB 20 can only be activated in operating modes with encoder feedback.

FCB 20 allows the user to move an axis in positive and negative direction.

Control is performed via control signals that are specified by means of control words, via digital inputs of a higher-level controller or via input terminals.

For startup or for setup mode without higher-level controller, use the manual mode of the MOVISUITE® engineering software, see "FCB 04" (→ 27).

FCB 21 Brake test

The FCB 21 tests the function and performance of up to 2 brakes. The function separately applies an adjustable torque (static test) to the applied brakes.

The brake test can be adapted to the various requirements. The test result "passed" or "failed" is available as feedback for each brake. Other measured values are also available.

An application-specific load torque must be taken into account when specifying the torque. The user can specify values. Alternatively, FCB 21 can determine the current load situation itself, which simplifies startup and offers more flexibility.

FCB 21 works with drive train 1. An encoder feedback (motor encoder or external encoder) that matches the used VFC^{PLUS} or CFC control mode is required.

When testing a brake, the brake control is integrated via DB0/DB00.

When testing two brakes, additional wiring is required in the brake control.

FCB 25 Motor parameter measurement

FCB 25 is used for determining the necessary parameters from the electric equivalent wiring diagram during startup.

The nameplate data of the connected motor is required for motor parameter measurement.

After the motor parameter measurement has been completed, the motor is completely started up electrically. Values that are not yet final at this stage, such as maximum speed and maximum torque, are estimated. The values have to be corrected at a later time to reach the full performance of the motor.

The FCB 25 should only be called up if no output filter is used. Otherwise, the FCB provides incorrect results because of the output filter inductance.

Calling FCB 25 is generally recommended for third-party motors. FCB 18 must be executed afterward for encoder calibration with synchronous motors, if required.

FCB 26 Stop at user limits

FCB 26 is used for stops at user limits. The user limits are either available as local setpoints or initiate the deceleration ramp set via the fieldbus.

You can choose between a speed-controlled ramp and a position-controlled ramp. In contrast to other stop FCBs (FCB 13/FCB 14), the FCB 26 has a very low priority.

This allows you to select FCB 26 as default (e.g. bit in the control word that selects this FCB is always TRUE). This means that FCB 26 is always active when all other FCBs are deactivated. This makes it possible to always stop with position control.

FCB 26 provides lag error monitoring in position-controlled mode.

When the stop is reached, the brake remains released and the motor remains energized.

1.5.2 Setpoints and limits in the FCBs

Setpoint connection

The following table shows which setpoints are used by which FCBs:

Parameter	FCB						
	05	06	07	08	09	10	20
Position					x	x	
Speed	x	x				o	o
Torque			x	x			
Acceleration precontrol		o				o	
Mass moment of inertia		o		x		o	
Torque precontrol		o		x		o	
Correcting value of external position controllers		o					

x Always active

o Depending on FCB setting

INFORMATION

In the V/f control mode, only the "Speed" setpoint is used.



Profile value connection

The following table shows which profile values are used by which FCBs:

Parameter	FCB										
	02	05	06	07	08	09	10	13	14	20	26
Maximum positive speed				x	x	x					
Maximum negative speed				x	x	x					
Maximum acceleration		x				x				o	
Maximum deceleration	x	x				x				o	x
Jerk time		x		x		x				o	x
Maximum torque Q1 to Q4		x	x	x	x	x	x	o	o		

x Always active

o Depending on FCB setting

INFORMATION



In the V/f control mode, the "Maximum torque Q1 to Q4" profile value is not used.

Limit values

The following table shows which limit values are used by which FCBs:

Parameter	FCB														
	02	04	05	06	07	08	09	10	12	13	14	19	20	21	26
Positive speed		x	x	x	x	x	x	x	x				x		
Negative speed		x	x	x	x	x	x	x	x				x		
Acceleration		x	x				x		x			x	x		
Deceleration	x	x	x				x		x	x		x	x	+	x
Jerk time	x	x	x		x		x		x	x	x	x	x	+	x
Torque	x	x	x	x	x	x	x	x	x	x	x	x	x	+	x
Apparent output current	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
Voltage limit	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
Emergency stop deceleration											x				

x Always active

+ Only active if FCB 21 is activated with a rotating drive. With these parameters, the drive is stopped before FCB 21 is executed.

INFORMATION



In the V/f control mode, the "Torque" limit value is not used.

1.6 Control modes

The following control modes are available:

- V/f
- VFC^{PLUS}
- CFC
- ELSM[®]

1.6.1 Description of the control modes

The characteristics of the motor connected to the inverter are influenced by the control modes used.

V/f

V/f control is intended for easy controlled operation of asynchronous motors without encoder feedback. The procedure operates an asynchronous machine on a parameterizable voltage/frequency characteristic. To keep the magnetizing current on a constant level, the voltage (V) is adjusted in proportion to the frequency (f).

The actual slip is estimated and can be compensated.

V/f control is suitable for applications with a limited speed setting range, where no dynamic step changes in load occur and where there are small requirements regarding the control characteristics.

V/f control is suitable for group drives. A group drive is an electrical parallel connection of several identical or different motors at one inverter. The motors do not have a rigid mechanical connection.

Speed control

The V/f mode is an encoder-less mode and calculates the actual speed value. The calculation is always based on the electrical values of the motors. Therefore, information from a potentially existing encoder system is not used.

If an encoder is parameterized in the encoder assignment as "Actual speed source", the speed measured by this encoder is issued as the actual speed by the inverter. Otherwise, the model speed calculated by the V/f method based on stator frequency and slip, is issued as the actual speed.

The V/f mode does not have a higher-level speed controller, speed controller parameterization is therefore not possible. An acceleration and torque precontrol is also not possible.

VFC^{PLUS}

VFC^{PLUS} is a high-performance control mode that is able to operate asynchronous motors with very high torque dynamics with or without rotary encoder.

The control mode can be operated as speed or torque control.

This control mode calculates all important state variables for controlling the motor by using a motor model. As a result, optimal magnetic conditions are always achieved for the motor.

For applications with a large speed setting range (especially for low speeds through to idle state) and high requirements regarding the control characteristics or for drives with high dynamic step changes in load, a rotary encoder is absolutely necessary.

For applications with low requirements regarding the speed control characteristics and the torque dynamics, an encoder is not necessary. Without a rotary encoder, the electric rotor frequency is calculated in a model. In this case, stable stationary operation of the mode at < 0.5 Hz is not possible.

Due to the good torque dynamics, the VFC^{PLUS} control mode remains stable even in the event of sudden load changes and has a high torque accuracy. Typical applications for the VFC^{PLUS} control mode are speed-controlled asynchronous machines with high demands on the speed and torque stability.

Switching to a rotating motor is possible (flying start function).

Speed control

A higher-level speed control loop that has to be parameterized accordingly is always used for speed control.

If the control mode is operated without an encoder, the actual speed of the motor is calculated by the control mode.

If an encoder is used, the angle information of this encoder is used for the control mode. The actual speed of the motor is calculated from this encoder. The maximum dynamics of the control loop are reached with a high-resolution encoder.

Torque control

The torque control operating mode can be selected independently of an encoder and does not need an encoder. With an encoder, however, stable stationary operation at stator frequency 0 Hz is also possible.

A higher-level speed control loop that has to be parameterized accordingly is always used for torque control.

Position control

Position-controlled operation is only possible with an encoder, as the actual position is calculated from the parameterized encoder. This encoder can either be mounted on the track or on the motor.

The accuracy of the position control can be increased with a motor encoder.

CFC

The CFC control mode is a current-controlled control mode. The CFC control mode allows the operation of asynchronous and synchronous motors with maximum torque dynamics. For this purpose, the current components for the magnetic flux and for the torque generation are controlled separately.

The control mode requires information about the rotor angle and the motor speed. For this reason, an encoder feedback (motor encoder) is always necessary.

For asynchronous motors, only the relative rotor angle is necessary. Thus, an incremental encoder is sufficient.

The control mode requires the absolute position for synchronous motors. In the case of encoder types that do not provide an absolute value, a commutation must be performed before every first enable after booting the system (FCB 18).

The advantage of the CFC control mode is the very high dynamics that can be achieved, as a control reserve for reaching the dynamic maximum torque is always available. For this reason, the CFC control mode is suitable for drives with highly dynamic motion control.

ELSM®

The ELSM® control mode allows the operation of permanent-field synchronous servomotors without encoder.

This procedure is exclusively intended for applications in horizontal materials handling technology with one single motor. It is not permitted to use it in vertical drives, inclining tracks or as a group drive.

Make sure that the inverter provides at least 150% I_0 of the motor throughout the rotor alignment process.

Switching to a rotating motor is possible (flying start function). Continuous operation is only permitted above a transition speed of approx. 2% of the nominal motor speed.

Rotor adjustment/rotor position measurement

When the inverter is enabled in ELSM® control mode, the rotor position of the permanent-field synchronous motors is unknown. For this reason, the rotor position has to be determined first or the rotor has to be adjusted by turning so that its angular position is defined.

Measuring the rotor position

The rotor position of the synchronous motor is measured with test pulses for each enable. This occurs at standstill. If a brake is used, this brake remains applied. The measurement is finished after a maximum of 50 ms. After the measurement is completed, the synchronous motor accelerates to the setpoint speed. A prerequisite for the measurement is the one-time determination of the complete motor parameters with the FCB 25 motor parameter measurement.

SEW-EURODRIVE recommends measuring the rotor position.

Adjusting the rotor

If the complete motor data is not known, the rotor is moved to a defined position at each enable. During adjustment, a motor movement takes place depending on the number of poles of the motor. If a brake is used, this brake is released. The adjustment is completed after 1 s.

Speed control

For operation of synchronous motors in the ELSM® control mode, there are two modes, i.e. open-loop and closed-loop operation.

Open-loop operation is active when starting from standstill and below a transition speed. The transition speed is about 2% of the nominal speed. Above this transition speed value, the drive is operated in closed-loop operation.

The time during which the drive is in open-loop operation should be as short as possible since the position of the rotor is not detected in this mode and the drive is only operated in speed-controlled mode.

If the drive is in open-loop operation, a current of at least 150% of the standstill current of the connected motor is impressed to stabilize the drive, which is why the motor heats up significantly at standstill and at low speeds.

Torque control

The ELSM® control mode enables the "Torque control" operating mode; however, only above the transition speed in closed-loop operation.

Practical meaning: The FCB 07 "Torque control" can only be activated when the flying start function is active and above the transition speed (example: winding drive). If the speed is too low, the system shuts down with a fault message.

The transition speed can be reached either by an external drive or by speed control of the inverter in the FCB 05.

Flying start function

If it cannot be ensured that the motor is at standstill when starting, the flying start function must be activated. This way, the ELSM® control mode can also be enabled for a turning motor.

If the speed can be calculated plausibly, the control mode proceeds to speed-controlled operation. If this is not the case, the drive proceeds to the "rotor adjustment" or "rotor measurement" function and then to open-loop operation.

1.7 Energy-saving functions

1.7.1 Flux optimization

Flux optimization is a function that allows for operating an asynchronous motor in control mode VFC^{PLUS} with minimal losses. Depending on the torque setpoint, the magnetic flux is managed in such a way that the motor is operated with minimum current. In partial load operation, as well as in case of overload, the total losses of the motor can be significantly reduced. This function has no influence in the range of the nominal torque or a bit below, as the motor is usually operated at almost optimum conditions.

For system-related reasons, the torque control times are longer with flux optimization than without flux optimization, due to necessary changes in flux. The flux optimization is especially suitable for applications with little dynamics, such as fans, pumps, escalators, and conveyor systems with constant speed.

The flux optimization can reduce magnetization losses in the motor by up to 70%.

1.7.2 Standby mode

Standby mode is intended for times in which operation is paused. The main difference between disconnection of the DC 24 V supply voltage and standby mode is that switching from standby mode to operation only takes approx. 500 ms and that bus communication is maintained. This allows for reducing the energy consumption even during short pauses.

The following functions are deactivated in standby mode:

- 7-segment display
- STO function
- Digital outputs on basic device and cards
- Analog outputs on card
- Power section control
- Fan in power section
- Encoder supply and encoder evaluation on basic device and card (optional)

Standby mode can be activated via a digital input or via a control word bit. Bus communication is active without restrictions in standby mode.

Energy consumption in standby mode

Size	DC 24 V power consumption in standby mode
1 – 5	3.6 W
6	10.3 W
7	8.4 W

The energy-saving function "standby operation" can reduce the DC 24 V power consumption by 89%.

1.8 MOVISUITE® engineering software


With its innovative design of the user interface and optimal user guidance, MOVISUITE® is a future-oriented engineering software from SEW-EURODRIVE.

The MOVISUITE® engineering software is the operating platform for all hardware and software components of the MOVI-C® modular automation system. The concept of the user interface enables users to configure, parameterize, as well as start up, and monitor their applications almost intuitively (simple auto startup with MOVILINK® DDI).

Using the various views, the users can switch to the suitable display mode depending on their requirements.

Circle view


In the circle view, for example, single components can be edited in a clear structure.



24502901643

Tree view

The tree view provides an overview of the entire network. The tree view shows large systems and machines in a clear manner. With various analysis functions (digital scope) already integrated in the standard scope, MOVISUITE® allows for a coordinated position/speed/torque controller for dynamic setting of the applications.



9007218526745867

26860791/EN – 07/2022

The view can be selected depending on the application and personal preferences; the functionality is identical in both views.

The user interface concept of MOVISUITE® allows the system structure to be arranged using freely definable structure nodes. These structure nodes are displayed with a varying level of detail in the views mentioned above.

The data management has clearly marked transfer directions, and thus is clearly structured during data transmission.

The scan function enables the reading of available devices, and the creation of these devices as projects in MOVISUITE®.

The drive train can be set up from motor to gear unit using the product catalog. Furthermore, encoders, brakes, control modes, and user units can be selected and parameterized.

The data required for the drive train can typically be read off the nameplates of the motor and gear unit and entered, or selected via a catalog function in the engineering software.

Another variant is automatic identification of the gear unit motor data by output of the electronic nameplate stored in the motor encoder. During startup, the engineering software checks whether an electronic nameplate is present in the encoder and suggests the use of this data.

The Scope recording function is available for diagnostic purposes. This enables a diagnostics overview of connected devices and functions. Long-term data acquisition on the engineering PC hard disk is also possible.

Manual mode can be intuitively used for each application via the new interface.

1.9 MOVIKIT® software modules

The inverter can be ordered with a specific application level. The use of MOVIKIT® software modules in the Drive category is allocated to every application level.

Application level	MOVIKIT® Drive category software module
0	Standard delivery state: e.g. activation for MOVIKIT® Velocity
1	e.g. activation for MOVIKIT® Positioning
2	e.g. activation for customer-specific solutions

MOVIKIT® software modules are standardized control programs with a defined process data interface and a user-friendly configuration and diagnostics interface. The MOVIKIT® software modules in the Drive category make it much easier to connect to a higher-level control program.

Features

- Wide range of functions
- User-friendly user interface
- You only have to enter the parameters needed for the application
- Guided parameter setting instead of complicated programming
- No programming experience required
- No lengthy training, therefore quick project planning and startup
- All motions are controlled directly in the application inverter

1.10 Digital motor integration with MOVILINK® DDI interface

1.10.1 Digital motor integration

With the "digital motor integration", SEW-EURODRIVE presents solutions for integrating drive technology into the networked world. The MOVILINK® DDI digital data interface connects the inverter with the drive and integrates the previously unconnected drive into the data network.

Features:

- Voltage supply of the MOVILINK® DDI electronics in the drive
- Detection of the drive, its options and their properties
- Data transmission for identification, startup, operation, and diagnostics
 - Electronic nameplate
 - Encoder data
 - Motor temperature
 - Data of additionally integrated or external sensors, such as sensors for detecting brake wear

Assistance functions:

- Automatic startup of the drive (motor, gear unit, sensors, actuators)
- Simple startup of the speed controller with adjusted dynamics settings
- Automatic detection of a drive replacement. Simple new startup in case of a modified drive

This makes detection, startup and communication with the drive as simple as with a USB interface between a computer and an external device.

1.10.2 Key features of MOVILINK® DDI

Detect: Motor functions

- MOVILINK® DDI communication unit in the motor, connection of optional sensors
- Integrated data memory for automatic startup of the motor
- Optional sensors detect, for example:
 - Motor temperature and motor protection via temperature sensor
 - Motor position via different encoders
 - Integrated brake control with wear measurement
 - Vibration
 - Acceleration
 - Mounting position
 - Humidity
 - Air pressure
 - Magnetic fields
- Connection to the motor via hybrid connector or cable gland
- Available for asynchronous motors, synchronous motors, linear motors

Transfer: Interface

- Digital interface between motor and inverter
- Transfer of process data

- Transfer of functionally safe data (in preparation)
- Coaxial cable for data transmission with high bandwidth and high interference immunity
- Cable length up to 200 m
- Voltage supply with modulated data transmission
- Single-cable technology for controlling motor, brake control, and data transmission

Receive: Inverter functions

- Automatic startup using startup data saved in the motor
- Automatic detection of motor replacement
- Automatic new startup if the replacement motor is different
- Display and processing of motor data
- Provision of the voltage supply for motor electronics
- Transfer of sensor data to the PLC or to a DriveRadar® edge processing unit or to the DriveRadar® Smart Data Collector

1.10.3 MOVILINK® DDI interface

The MOVILINK® DDI interface connects inverters of the MOVI-C® modular automation system with drives. The MOVILINK® DDI interface is based on a coaxial signal cable. The coaxial signal cable is used for supplying the motor electronics with power and for communication with the drive.

The inverters can be connected to the drive in different ways depending on the requirements:









- Hybrid cable for single-cable connection (alternatively for fixed installation and for cable carrier installation) consisting of:
 - Motor cable
 - Brake control
 - PE
 - Coaxial signal cable
- Separate coaxial signal cable in addition to the motor cable for two-cable connection, especially for large cross sections for controlling the motor.
- The motor can be connected via cable glands on the terminal box or at the plug connector.



2 Technical data

2.1 Marks

2.1.1 Basic device

The application inverter complies with the following directives and guidelines:

Mark	Definition
	The CE mark states compliance with the following European directives: <ul style="list-style-type: none"> • Low Voltage Directive 2014/35/EU¹⁾ • EMC Directive 2014/30/EU • Machinery Directive 2006/42/EC • Directive 2011/65/EU for limiting the use of certain hazardous substances in electric and electronic equipment • Ecodesign Directive 2009/125/EC
	The waste disposal of this product is performed in compliance with the WEEE Directive 2012/19/EU.
	The EAC mark states compliance with the requirements of the technical regulations of the Customs Union (Eurasian Economic Union), Armenia, Belarus, Kazakhstan, Kyrgyzstan, and Russia.
	The RCM mark declares compliance with the technical regulations of the Australian Communications and Media Authority (ACMA).
	The China RoHS mark states compliance with Directive SJ/T 11364-2014 for limiting the use of hazardous substances in electric and electronic equipment and their packaging.
	The NM mark states compliance with the following Moroccan directives ²⁾ : <ul style="list-style-type: none"> • Low Voltage Directive no. 2573-14 (16 July, 2015) • EMC Directive N° 2574-14 (16 July, 2015)
	The UA.TR mark declares conformity with the technical regulations of Ukraine.
	The KC mark declares compliance with §3 of Article 58-2 for the Korean Radio Wave Act.

Mark	Definition
	The UKCA mark states compliance with the following British directives ²⁾ <ul style="list-style-type: none"> • Low Voltage Directive S.I. 2016/1101³⁾ • EMC S. I. 2016/1091 • Machinery Safety S. I. 2008/1597 • Directive S. I. 2012/3032 for limiting the use of certain hazardous substances in electrical and electronic equipment • Ecodesign Regulation S. I. 2019/539
	The UL and cUL marks state UL approval. ⁴⁾ cUL is equivalent to CSA approval.

1) For products with functional safety, the requirements from the Low Voltage Directive are fulfilled by the Machinery Directive.






2) The selectable approvals UKCA (Great Britain) and NM (Morocco) are mutually exclusive.

3) For products with functional safety, the requirements from the Low Voltage Directive are fulfilled by the Machinery Safety S.I. 2008/1597.






4) The UL and cUL mark for the following devices is still in preparation at the time of publication of this document: MDX91A-1770 – 3000-5_3-..

2.1.2 Accessories






BW.. braking resistors

Mark	Definition
	The CE mark states compliance with the following European directives: <ul style="list-style-type: none"> • Low Voltage Directive 2014/35/EU • Directive 2011/65/EU for limiting the use of certain hazardous substances in electric and electronic equipment
	The waste disposal of this product is performed in compliance with the WEEE Directive 2012/19/EU.
	The China RoHS mark declares compliance with the Directive SJ/T 11364-2014 regarding the restriction of use of certain hazardous substances in electrical and electronic equipment and its packaging.
	The UKCA mark states compliance with the following British guidelines: <ul style="list-style-type: none"> • Low Voltage Directive S. I. 2016/1101 • Directive S. I. 2012/3032 for limiting the use of certain hazardous substances in electric and electronic equipment
	The cUR mark states the UL approval for this component.






NF.. line filters

Mark	Definition
	The CE mark states compliance with the following European directives: <ul style="list-style-type: none"> • Low Voltage Directive 2014/35/EU • Directive 2011/65/EU for limiting the use of certain hazardous substances in electric and electronic equipment
	The waste disposal of this product is performed in compliance with the WEEE Directive 2012/19/EU.
	The China RoHS mark declares compliance with the Directive SJ/T 11364-2014 regarding the restriction of use of certain hazardous substances in electrical and electronic equipment and its packaging.
	The UKCA mark states the compliance with the following British guidelines: <ul style="list-style-type: none"> • Low Voltage Directive S. I. 2016/1101 • Directive S. I. 2012/3032 for limiting the use of certain hazardous substances in electrical and electronic equipment
	The cUR mark states the UL approval for this component.






ND.. line chokes

Mark	Definition
	The CE mark states compliance with the following European directives: <ul style="list-style-type: none"> • Low Voltage Directive 2014/35/EU • Directive 2011/65/EU for limiting the use of certain hazardous substances in electric and electronic equipment
	The waste disposal of this product is performed in compliance with the WEEE Directive 2012/19/EU.
	The China RoHS mark declares compliance with the directive SJ/T 11364-2014 regarding the restriction of use of certain hazardous substances in electrical and electronic equipment and its packaging.
	The UKCA mark states compliance with the following British guidelines: <ul style="list-style-type: none"> • Low Voltage Directive S. I. 2016/1101 • Directive S. I. 2012/3032 for limiting the use of certain hazardous substances in electric and electronic equipment
	The cUR mark states the UL approval for this component.






HF.. output filters

Mark	Definition
	The CE mark states compliance with the following European directives: <ul style="list-style-type: none"> • Low Voltage Directive 2014/35/EU • Directive 2011/65/EU for limiting the use of certain hazardous substances in electric and electronic equipment
	The waste disposal of this product is performed in compliance with the WEEE Directive 2012/19/EU.
	The China RoHS mark declares compliance with the directive SJ/T 11364-2014 regarding the restriction of use of certain hazardous substances in electrical and electronic equipment and its packaging.
	The UKCA mark states compliance with the following British guidelines: <ul style="list-style-type: none"> • Low Voltage Directive S. I. 2016/1101 • Directive S. I. 2012/3032 for limiting the use of certain hazardous substances in electric and electronic equipment
	The cUR mark states the UL approval for this component.

HD.. output chokes

Mark	Definition
	The CE mark states compliance with the following European directives: <ul style="list-style-type: none"> • Low Voltage Directive 2014/35/EU • Directive 2011/65/EU for limiting the use of certain hazardous substances in electric and electronic equipment
	The waste disposal of this product is performed in compliance with the WEEE Directive 2012/19/EU.
	The China RoHS mark declares compliance with the directive SJ/T 11364-2014 regarding the restriction of use of certain hazardous substances in electrical and electronic equipment and its packaging.
	The UKCA mark states compliance with the following British guidelines: <ul style="list-style-type: none"> • Low Voltage Directive S. I. 2016/1101 • Directive S. I. 2012/3032 for limiting the use of certain hazardous substances in electric and electronic equipment
	The cUR mark states the UL approval for this component.

ZD.. DC link chokes

Mark	Definition
	The CE mark states compliance with the following European directives: <ul style="list-style-type: none"> • Low Voltage Directive 2014/35/EU • Directive 2011/65/EU for limiting the use of certain hazardous substances in electric and electronic equipment
	The waste disposal of this product is performed in compliance with the WEEE Directive 2012/19/EU.
	The China RoHS mark declares compliance with the directive SJ/T 11364-2014 regarding the restriction of use of certain hazardous substances in electrical and electronic equipment and its packaging.
	The UKCA mark states the compliance with the following British guidelines: <ul style="list-style-type: none"> • Low Voltage Directive S. I. 2016/1101 • Directive S. I. 2012/3032 for limiting the use of certain hazardous substances in electrical and electronic equipment
	The cUR mark states the UL approval for this component.

2.2 General technical data

The following table lists the technical data for all inverters independent of

- Type
- Design
- Size
- Power rating

General data	
Interference immunity	Meets EN 61800-3; 2. Environment
Interference emission	Limit value class C2 according to EN 61800-3. From size 4, a line filter is required for limit class C2. The interference suppression level can be improved with relevant measures. Refer to chapter "EMC-compliant installation according to EN 61800-3" in the product manual for further information.
Ambient temperature ϑ_{amb}	0 °C to +40 °C without derating 40 °C to +60 °C with derating ¹⁾ For further information, refer to chapter "Selection of an inverter > Derating".
Type of cooling	Increased air cooling due to an installed, temperature-controlled fan.
Short-circuit current	The uninfluenced short-circuit current according to EN 61800-5-1 (I _{cc}) is 5000 A.
Degree of protection	Sizes 1 – 4: IP20 in accordance with EN 60529 From size 5: IP10 according to EN 60529 (IP20 optional)
Pollution class	2 in accordance with IEC 60664-1
Overvoltage category	III in accordance with IEC 60664-1
Installation altitude	Up to h ≤ 1000 m without restrictions. The following restrictions apply to altitudes > 1000 m: <ul style="list-style-type: none"> • From 1000 m to max. 3800 m: I_N reduction by 1% per 100 m • From 2000 m to max. 3800 m: To maintain protective separation and the air gaps and creepage distances in accordance with EN 61800-5-1, you have to connect an overvoltage protection device in order to reduce the overvoltages from category III to category II.

1) When using a CS.A card, the ambient temperature is limited to a maximum of 55 °C.

2.3 Environmental conditions

Environmental conditions	
Climatic conditions	<ul style="list-style-type: none"> Long-term storage (weatherproof): EN 60721-3-1 class 1K2 temperature -25 °C to +70 °C (deviating from the standard) Non-condensing; no moisture condensation Transport (weatherproof): EN 60721-3-2 class 2K3 temperature -25 °C to +70 °C Non-condensing; no moisture condensation Operation (fixed installation, weatherproof): EN 60721-3-3 class 3K3 temperature 0 °C to +40 °C (deviating from the standard) Non-condensing; no moisture condensation
Chemically active substances	<ul style="list-style-type: none"> Extended storage (weatherproof): EN 60721-3-1 class 2C2, no corrosive gases, no salt mist (deviating from the standard) Transport (weatherproof): EN 60721-3-2 class 2C2, no corrosive gases, no salt mist, no sea water (deviating from the standard) Operation (fixed installation, weatherproof): EN 60721-3-3 class 3C2, no corrosive gases, no salt mist
Mechanically active substances	<ul style="list-style-type: none"> Extended storage (weatherproof): EN 60721-3-1 class 1S1, no conductive dust Transport (weatherproof): EN 60721-3-2 class 2S1 Operation (fixed installation, weatherproof): EN 60721-3-3 class 3S1, no conductive dust

2.4 Technical data of basic device

2.4.1 Performance data 3 × AC 400 V

	Unit	MDX9.A-.....5.3-4-...								
Type		0020	0025	0032	0040	0055	0070	0095	0125	0160
Size		1				2			3	
Nominal output current I _N at f _{PWM} = 4 kHz	A	2	2.5	3.2	4	5.5	7	9.5	12.5	16
Input										
Nominal line voltage (according to EN 50160) AC V _{line}		3 × 380 – 500 V								
Nominal line current AC I _{line}	A	1.8	2.25	2.88	3.6	4.95	6.3	8.55	11.3	14.4
Line frequency f _{line}	Hz	50 – 60 ± 5%								
Controlled rectifier		No								
X1 connection contacts		Plug connector – 1 conductor: 0.25 – 4 mm ² – 2 conductors: 0.25 – 2.5 mm ² (Twin conductor end sleeve)								
Output										
Output voltage V _{out}	V	0 – V _{line}								
Motor power ASM P _{Mot}	kW	0.55	0.75	1.1	1.5	2.2	3	4	5.5	7.5
Nominal output current I _N at f _{PWM} = 4 kHz	A	2	2.5	3.2	4	5.5	7	9.5	12.5	16
Overload capacity		200%: 3 s at f _{PWM} = 4 kHz								
Continuous output current at f = 0 Hz		100% × I _N at f _{PWM} = 4 kHz								
Apparent output power S _N	kVA	1.4	1.7	2.2	2.8	3.8	4.8	6.6	8.7	11.1
Nominal DC link voltage V _{NDCL}	V	DC 560								
Frequency f _{PWM}	kHz	4, 8, 16 (adjustable)								
Max. output frequency f _{max}	Hz	599 Recommendation: VFC ^{PLUS} maximum 250 Hz, do not exceed all other control modes f _{PWM} /10.								
X2 connection contacts		Plug connector – 1 conductor: 0.25 – 4 mm ² – 2 conductors: 0.25 – 2.5 mm ² (Twin conductor end sleeve)								
General										
Power consumption 24 V	W	20								
Power section nominal power loss ¹⁾	W	16	20	27	34	45	58	83	112	147
Permitted number of times power may be switched on/off	min ⁻¹	1								
Minimum switch-off time for power off	s	10								
Power section interference suppression		EMC filter limit value category C2 to EN 61800-3								
PE connection		Rigid wire or conductor end sleeve (max. 2.5 mm ²) on bracket with M4 screw, either basic device or shield plate							Rigid wire/conductor end sleeve (max. 2.5 mm ²) on bracket with M4 screw or M6 bolt on shield plate	
Mass	kg	4.1				4.4			5.7	
Brake chopper and braking resistor										
Minimum braking resistance value R _{BWmin}	Ω	90				42			24	
Brake chopper continuous power	kW	1.4	1.7	2.2	2.8	3.8	4.8	6.6	8.7	11.1
Brake chopper peak power		200% × apparent output power S _N × 0.9								
Connection contacts		Plug connector – 1 conductor: 0.25 – 4 mm ² – 2 conductors: 0.25 – 2.5 mm ² (Twin conductor end sleeve)								
Dimensions										
Width	mm	95				105			105	
Height of the basic device	mm	350				350			350	
Height of basic device with shield plates	mm	479				479			494	
Depth	mm	215				215			260	

1) To calculate the thermal power loss, add the values of "Power consumption 24 V" and "Power section nominal power loss".

	Unit	MDX9.A-....-5.3-4-...					MDX91A-....-5.3-4-...		
Type		0240	0320	0460	0620	0750	0910	1130	1490
Size		4		5			6		
Nominal output current I _N at f _{PWM} = 4 kHz	A	24	32	46	62	75	91	113	149
Input									
Nominal line voltage (according to EN 50160) AC V _{line}		3 × 380 – 500 V							
Nominal line current AC I _{line}	A	21.6	28.8	41.4	55.8	67.5	81.9	102	134
Line frequency f _{line}	Hz	50 – 60 ± 5%							
Controlled rectifier		Yes							
X1 connection contacts		Plug connector – 1 conductor: 0.5 – 16 mm ² – 2 conductors: 0.25 – 6 mm ² (twin CES) ¹⁾			M8		M10		
Output									
Output voltage V _{out}	V	0 – V _{line}							
Motor power ASM P _{Mot}	kW	11	15	22	30	37	45	55	75
Nominal output current I _N at f _{PWM} = 4 kHz	A	24	32	46	62	75	91	113	149
Overload capacity		200%: 3 s at f _{PWM} = 4 kHz							
Continuous output current at f = 0 Hz		100% × I _N at f _{PWM} = 4 kHz							
Apparent output power S _N	kVA	16.6	22.2	31.9	43	52	63	78	103
Nominal DC link voltage V _{NDCL}	V	DC 560							
Frequency f _{PWM}	kHz	4, 8, 16 (adjustable)							
Max. output frequency f _{max}	Hz	599 Recommendation: VFC ^{PLUS} maximum 250 Hz, do not exceed all other control modes f _{PWM} /10.							
X2 connection contacts		Plug connector – 1 conductor: 0.5 – 16 mm ² – 2 conductors: 0.25 – 6 mm ² (twin CES) ¹⁾			M8		M10		
General									
Power consumption 24 V	W	30		15			20		
Power section nominal power loss ²⁾	W	202	282	419	600	760	931	968	1332
Permitted number of times power may be switched on/off	min ⁻¹	1							
Minimum switch-off time for power off	s	10							
Power section interference suppression		Basic interference suppression integrated							
PE connection		M6 stud		M8 stud			M10 stud		
Mass	kg	6.6		12.1			24.1		
Brake chopper and braking resistor									
Minimum braking resistance value R _{BW/min}	Ω	13		9	5.4		4.2	2.7	
Brake chopper continuous power	kW	16.6	22.2	31.9	43	52	63	78	103
Brake chopper peak power		200% × apparent output power S _N × 0.9							
Connection contacts		Plug connector – 1 conductor: 0.5 – 16 mm ² – 2 conductors: 0.25 – 6 mm ² (twin CES) ¹⁾			M8		M10		
Dimensions									
Width	mm	135		196			240		
Height of the basic device	mm	350		471			544		
Height of basic device with shield plates	mm	494		471			544		
Depth	mm	260		293			328		

1) CES: Conductor end sleeve

2) To calculate the thermal power loss, add the values of "Power consumption 24 V" and "Power section nominal power loss".

	Unit	MDX91A-....-5.3 -...						
Type		1770	2200	2500	3000	3800	4700	5880
Size		7				8 ¹⁾		
Nominal output current I _N at the smallest possible PWM frequency	A	177	220	250	300	380	470	588
Input								
Nominal line voltage (according to EN 50160) AC V _{line}		3 × 380 – 500 V						
Nominal line current AC I _{line}	A	159	198	225	270	342	423	529
Line frequency f _{line}	Hz	50 – 60 ± 5%						
Controlled rectifier		Yes						
X1 connection contacts		M12				M12, each terminal is available twice		
Output								
Output voltage V _{out}	V	0 – V _{line}						
Motor power ASM P _{Mot}	kW	90	110	132	160	200	250	315
Nominal output current I _N at the smallest possible PWM frequency	A	177	220	250	300	380	470	588
Overload capacity		200% at f _{PWM} = 4 kHz		200% at f _{PWM} = 2.5 kHz	150% at f _{PWM} = 2.5 kHz	150% at f _{PWM} = 2.5 kHz		
Continuous output current at f = 0 Hz		100% × I _N at f _{PWM} = 4 kHz		100% × I _N at f _{PWM} = 2.5 kHz				
Apparent output power S _N	kVA	123	152	173	208	263	326	407
Nominal DC link voltage V _{NDCL}	V	DC 560						
Frequency f _{PWM}	kHz	4, 8 (adjustable)		2.5, 4, 8 (adjustable)		2.5, 4 (adjustable)		
Max. output frequency f _{max}	Hz	599 Recommendation: VFC ^{PLUS} maximum 250 Hz, do not exceed all other control modes f _{PWM} /10.						
X2 connection contacts		M12				M12, double design		
General								
Power consumption 24 V	W	20				Not available		
Power section nominal power loss ²⁾	W	1725	2164	2131	2631	Not available		
Permitted number of times power may be switched on/off	min ⁻¹	1						
Minimum switch-off time for power off	s	10						
Power section interference suppression		Basic interference suppression integrated						
PE connection		M12 stud						
Mass	kg	84				Not available		
Brake chopper and braking resistor								
Minimum braking resistance value R _{BWmin}	Ω	2				0.9		
Brake chopper continuous power	kW	123	152	173	208	263	326	407
Brake chopper peak power		200% × apparent output power S _N × 0.9						
Connection contacts		M12				M12, each terminal is available twice		
Dimensions								
Width	mm	320				Not available		
Height of the basic device	mm	990						
Height of basic device with shield plates	mm	990						
Depth	mm	410						

1) Size 8 is not yet available.

2) To calculate the thermal power loss, add the values of "Power consumption 24 V" and "Power section nominal power loss".

2.4.2 Performance data 3 × AC 230 V

	Unit	MDX9.A-...-2.3-4-...		
Type		0070	0093	0140
Size		2		3
Nominal output current I _N at f _{PWM} = 4 kHz	A	7	9.3	14
Input				
Nominal line voltage (according to EN 50160) AC V _{line}		3 × 200 – 240 V		
Nominal line current AC I _{line}	A	6.3	8.37	12.6
Line frequency f _{line}	Hz	50 – 60 ± 5%		
Controlled rectifier		No		
X1 connection contacts		Plug connector – 1 conductor: 0.25 – 4 mm ² – 2 conductors: 0.25 – 2.5 mm ² (Twin conductor end sleeve)		
Output				
Output voltage V _{out}	V	0 – V _{line}		
Motor power ASM P _{Mot}	kW	1.5	2.2	3.7
Nominal output current I _N at f _{PWM} = 4 kHz	A	7	9.3	14
Overload capacity		200%: 3 s at f _{PWM} = 4 kHz		
Continuous output current at f = 0 Hz		100% × I _N at f _{PWM} = 4 kHz		
Apparent output power S _N	kVA	2.8	3.7	5.6
Nominal DC link voltage V _{NDCL}	V	DC 325		
Frequency f _{PWM}	kHz	4, 8, 16 (adjustable)		
Max. output frequency f _{max}	Hz	599 Recommendation: VFC ^{PLUS} maximum 250 Hz, do not exceed all other control modes f _{PWM} /10.		
X2 connection contacts		Plug connector – 1 conductor: 0.25 – 4 mm ² – 2 cores: 0.25 – 2.5 mm ² (Twin conductor end sleeve)		
General				
Power consumption 24 V	W	20		
Power section nominal power loss ¹⁾	W	51	72	105
Permitted number of times power may be switched on/off	min ⁻¹	1		
Minimum switch-off time for power off	s	10		
Power section interference suppression		EMC filter limit value category C2 to EN 61800-3		
PE connection		Rigid wire or conductor end sleeve (max. 2.5 mm ²) on bracket with M4 screw, either basic device or shield plate		Rigid wire or conductor end sleeve (max. 2.5 mm ²) on bracket with M4 screw on basic device or M6 bolt on shield plate
Mass		4.4		5.7
Brake chopper and braking resistor				
Minimum braking resistance value R _{BWmin}	Ω	24		13
Brake chopper continuous power	kW	2.8	3.7	5.6
Brake chopper peak power		200% × apparent output power S _N × 0.9		
Connection contacts		Plug connector – 1 conductor: 0.25 – 4 mm ² – 2 conductors: 0.25 – 2.5 mm ² (Twin conductor end sleeve)		
Dimensions				
Width	mm	105		105
Height of the basic device	mm	350		350
Height with shield plates	mm	479		494
Depth	mm	215		260




1) To calculate the thermal power loss, add the values of "Power consumption 24 V" and "Power section nominal power loss".




	Unit	MDX9.A-...-2.3-4-...				MDX91A-...-2.3-4-...	
Type		0213	0290	0420	0570	0840	1080
Size		4		5		6	
Nominal output current I_N at $f_{PWM} = 4$ kHz	A	21.3	29	42	57	84	108
Input							
Nominal line voltage (according to EN 50160) AC V_{line}		3 × 200 – 240 V				???	???
Nominal line current AC I_{line}	A	19.2	26.1	37.8	51.3	75.6	97.2
Line frequency f_{line}	Hz	50 – 60 ± 5%					
Controlled rectifier		Yes					
X1 connection contacts		Plug connector – 1 conductor: 0.5 – 16 mm ² - 2 cores: 0.25 – 6 mm ² (Twin conductor end sleeve)		M8		M10	
Output							
Output voltage V_{out}	V	0 – V_{line}					
Motor power ASM P_{Mot}	kW	5.5	7.5	11	15	22	30
Nominal output current I_N at $f_{PWM} = 4$ kHz	A	21.3	29	42	57	84	108
Overload capacity		200%: 3 s at $f_{PWM} = 4$ kHz					
Continuous output current at $f = 0$ Hz		100% × I_N at $f_{PWM} = 4$ kHz					
Apparent output power S_N	kVA	8.5	11.6	16.7	22.7	33.5	43
Nominal DC link voltage V_{NDCL}	V	DC 325					
Frequency f_{PWM}	kHz	4, 8, 16 (adjustable)					
Max. output frequency f_{max}	Hz	599 Recommendation: VFC^{PLUS} maximum 250 Hz, do not exceed all other control modes $f_{PWM}/10$.					
X2 connection contacts		Plug connector – 1 conductor: 0.5 – 16 mm ² - 2 cores: 0.25 – 6 mm ² (Twin conductor end sleeve)		M8		M10	
General							
Power consumption 24 V	W	30		15		20	
Power section nominal power loss ¹⁾	W	152	218	315	459	729	764
Permitted number of times power may be switched on/off	min ⁻¹	1					
Minimum switch-off time for power off	s	10					
Power section interference suppression		Basic interference suppression integrated					
PE connection		M6 bolt on basic device		M8 bolt on basic device		M10 bolt on basic device	
Mass		6.6		12.1		24.1	
Brake chopper and braking resistor							
Minimum braking resistance value R_{BWmin}	Ω	6.7		4.7	3	2	
Brake chopper continuous power	kW	8.5	11.6	16.7	22.7	33.5	43
Brake chopper peak power		200% × apparent output power S_N × 0.9					
Connection contacts		Plug connector – 1 conductor: 0.5 – 16 mm ² - 2 cores: 0.25 – 6 mm ² (Twin conductor end sleeve)		M8		M10	
Dimensions							
Width	mm	135		196		240	
Height of the basic device	mm	350		471		544	
Height with shield plates	mm	494		471		544	
Depth	mm	260		293		328	

1) To calculate the thermal power loss, add the values of "Power consumption 24 V" and "Power section nominal power loss".

2.5 Accessories part numbers

2.5.1 Installation accessories












Size	Plastic cover	Quantity	Scope of delivery	Description	Part number
Size 5		10	Not included in the delivery	(→  252)	28243625
Size 6		10			28244540
Size 7		12			28257677
Size 8		24			Not available

Size	Carrying aid	Quantity	Scope of delivery	Description	Part number
Size 6		1	Included in the delivery	(→  236)	28106229
Size 7					28257685

Size	Shielding	Part number of "shield terminals" accessory pack
Sizes 1 – 8	Control unit shielding	28220250
Sizes 1 – 2	Motor and encoder cable shielding	28209060
Sizes 3– 4		28222725
Size 5	Encoder cable shielding	28270789

2.5.2 Connector

The following list is used for re-ordering connectors.

Representation	Slot	Function	Size	Part number
	X1	Line connection	Sizes 1 – 3	19148429
	X2	Motor connection	Sizes 1 – 3	19148437
	X1	Line connection	Size 4	19148496
	X2	Motor connection	Size 4	19148380
	X5	DC 24 V supply voltage	All	19148410
	X10	Brake control	Sizes 1 – 4	19151314
	X10	Brake control	Sizes 5 – 8	19147392
	X20	Signal connection 1	All	19148615
	X21	Signal connection 2	All	19148623
	X22	Signal connection 3	All	19148631
	X6	STO single connector (without jumpers)	All	19155611
		STO E-connector (with jumpers)	All	18177905

2.5.3 CMM11A memory module

Type designation	Part number
CMM11A memory module	28230760

2.6 Electronics data – signal terminals

NOTICE

Connection of inductive loads to digital outputs.

Destruction of digital outputs.

If inductive loads are connected to digital outputs, you must install an external protective element (freewheeling diode).

General	Terminal designation	Specification
Design	-	In accordance with IEC 61131-2
Supply voltage		
Connection	-	External power supply unit 24 V according to IEC 61131, 24 V +20%, -10%
Assignment	X5:24 V	DC 24 V supply voltage
	X5:GND	Reference potential
Connection contacts	X5	Plug connector: <ul style="list-style-type: none"> – 1 conductor: 0.25 – 2.5 mm² – 2 conductors: 0.5 – 1.5 mm² (Twin conductor end sleeve)
Digital inputs		
Cycle time input	-	1 ms / 500 µs
Quantity	-	8
Response time	-	100 µs plus cycle time
Assignment	X20:1 – 8	DI00: with fixed "Output stage enable" assignment. DI01 – DI07: For the selection option, see the parameter menu. All inputs are suitable for Touchprobe function. Latency period < 100 µs, max. 2 Touchprobe inputs can be configured. DI04, DI05: HTL low-resolution encoder connection. DI04: Counter input Current consumption: 3 mA at 30 V
	X20:9	GND
Connection contacts	-	Plug connector: <ul style="list-style-type: none"> – 1 conductor: 0.25 – 2.5 mm² – 2 conductors: 0.5 – 1.5 mm² (Twin conductor end sleeve)
Digital outputs		
Cycle time output	-	1 ms / 500 µs
Quantity	-	4
Response time	-	175 µs plus cycle time
Output current	-	I _{max} = 50 mA
Short-circuit protection	-	Yes
Assignment	X21:1	24 V supply voltage, maximum output current = 50 mA
	X21:2 – 5	DO00 – DO03: For the selection option, see the parameter menu.
	X21:6	GND
Connection contacts	-	Plug connector: <ul style="list-style-type: none"> – 1 conductor: 0.25 – 2.5 mm² – 2 cores: 0.5 – 1.5 mm² (Twin conductor end sleeve)
Relay output		
Assignment	X22:1:DO01-C	Shared relay contact
	X22:2:DO01-NO	NO contact
	X22:3:DO01-NC	NC contact
		Current-carrying capacity of relay contacts: U _{max} = DC 30 V, I _{max} = DC 2 A
	X22:4:VO24	Reserved
	X22:5:GND	GND

Brake control		
Assignment	X10:DB0 X10:DB00	DB00: - Brake control – Control braking contactor DC 24 V, max. 150 mA
	X10:GND	GND
	X10:TF1	Sensor input for temperature evaluation of the motor
Connection contacts	-	See chapter "Permitted terminal cross sections" (→ 234)

Encoder output		
	X15:13	DC 24 V, $I_{\max} = 500 \text{ mA}$
	X15:15	DC 12 V, $I_{\max} = 500 \text{ mA}$
Maximum permitted cable length	-	- HTL encoders ES7C, EG7C and EK8C ¹⁾ : 300 m - TTL encoder EK8R: 300 m - Standard HTL encoder: 200 m - Other encoders: 100 m

1) EK8C encoders in preparation.

Digital motor integration with MOVILINK® DDI		
Maximum permitted cable length	X16	200 m

2.7 Electronics data – safety subfunction

The table below shows the technical data of the application inverter relating to the integrated safety technology.

The safe digital inputs comply with type 3 according to IEC 61131-2.

Reference potential for the F_STO_P1 and F_STO_P2 is STO_M (contact at terminal X6:2).



		Terminal designation	General electronics data		
Safety contact STO		X6			
Electrical data of inputs F_STO_P1, F_STO_P2			Minimum	Typical	Maximum
Input voltage range		X6:1 and X6:3	DC -3 V	DC 24 V	DC 30 V
Input capacitance against STO_M			–	300 pF	500 pF
Input capacitance against GND			–	300 pF	500 pF
Power consumption at DC 24 V:	F_STO_P1		–	150 mW	200 mW
	F_STO_P2		–	150 mW	200 mW
	Sum ¹⁾		–	300 mW	400 mW
Input voltage for ON status (STO)			DC 11 V	–	–
Input voltage for OFF status (STO)			–	–	DC 5 V
Permitted leakage current of the external safety controller			–	–	1 mA
Technical data					
Time from disconnecting the safety voltage until deactivation of the rotating field			–	1.5 ms	10 ms 2 ms ²⁾
Time from connecting the safety voltage until activation of the rotating field			–	–	110 ms
Connection contacts			Plug connector – 1 conductor: 0.25 – 1.5 mm ² – 2 conductors: 0.25 – 0.5 mm ² (Twin conductor end sleeve)		

1) Each drive unit always requires a power consumption of 300 mW.

2) Only when STO is used and controlled via a MOVISAFE® CS..A card.

2.8 Dimension sheets



2.8.1 Size 1



28874919051

26860791/EN – 07/2022


2.8.2 Size 2



28874522891


2.8.3

Size 3




28874525323

2.8.4 Size 4




28874527755

2.8.5 Size 5




28874530187

2.8.6 Size 6



28874532619

2.8.7 Size 7



35736251659

2.9 Technical data of the keypads

	CBG11A	CBG21A	CBG22A
Part number	28233646	28238133	28277554
Operating temperature	0 – 60 °C		
Degree of protection	IP40 in accordance with EN 60529		
Power consumption in W	0.6	1.4	
Dimensions W x H x D in mm	45 × 100 × 20	65 × 110 × 20	
Screen size W × H in mm	28.5 × 23	49 × 37	
Screen diagonal in mm	38 (1.5")	61 (2.4")	
Screen resolution W × H in px	78 × 64	320 × 240	
Screen type	Monochrome display	Color display	
Engineering interface	Mini-USB socket		
Connection interface	D-sub, 9-pin		

2.10 Technical data of the cards

2.10.1 CIO21A and CID21A input/output cards

The CIO21A input/output card provides digital/analog inputs and outputs; the CID21A cards provide digital inputs and outputs.

NOTICE

Connection of inductive loads to digital outputs.

Destruction of digital outputs.

If inductive loads are connected to digital outputs, you must install an external protective element (freewheeling diode).

	Terminal designation/ specification		Specification
	CIO21A	CID21A	
Part number	28229495	28229487	
General			
Design			In accordance with IEC 61131-2 (type 3 for digital inputs)
Cycle time			1 ms
Power consumption	1.2 W	0.4 W	Base load (exclusively total power at outputs)
Connection contacts			Plug connector – 1 conductor: 0.25 – 0.5 mm² (shield terminals for control cables are available)
Digital inputs			
Quantity			4
Response time			160 µs plus cycle time
Assignment	X52:1 – 4		DI10 – DI13: For the selection option, see parameter menu
	X52:5		GND
Digital outputs			
Quantity			4
Response time			175 µs plus cycle time
Output current			I ≤ 50 mA
Capacitive load			≤ 300 nF
Inductive load			Not permitted
Protection device			Short-circuit-proof, protected against external voltage DC 0 – 30 V
Assignment	X52:6 – 9		DO10 – DO13: For the selection option, see parameter menu
	X52:10		GND
Analog inputs			
Quantity			2
Type			Differential/can be switched to current input
Range of values			0 to +10 V, -10 V to +10 V 0(4) – 20 mA
Assignment	X50:2 X50:3	-	Analog input AI21 Reference of analog input AI21
	X50:4 X50:7	-	GND
	X50:5 X50:6	-	Analog input AI31 Reference of analog input AI31
Voltage input			
Resolution			0 to +10 V (11 bit), -10 V to +10 V (12 bit)
Tolerance			±0.5%
Electric strength			DC -20 V to DC +20 V
Input resistance			≥ 10 kΩ

Current input			
Resolution			0(4) – 20 mA (11 bit)
Tolerance			± 2%
Load impedance			Internal 250 Ω
Electric strength			DC -10 V to DC +10 V
Analog outputs			
Quantity			2
Short-circuit protection			Yes
Assignment	X51:1 X51:4		Analog voltage output AOV2/AOV3
	X51:2 X51:5		Analog current output AOC2/AOC3
	X51:3 X51:6		GND
Voltage output			
Tolerance			± 5%
Capacitive load			≤ 300 nF
Inductive load			≤ 500 µH
Load resistance			≥ 1 kΩ
Resolution			12 bit
Reset state			0 V
Output value			-10 V to +10 V ≤ 10 mA
Current output			
Tolerance			± 3%
Capacitive load			≤ 300 nF
Inductive load			None
Load resistance			≤ 500 Ω
Resolution			11 bit
Reset state			0 mA
Measuring range			0(4) – 20 mA
Reference voltage output			
Short-circuit protection			Yes
Output voltage			DC -10 V, DC +10 V
Tolerance			± 0.5%
Noise			≤ 10 mA
Output current			≤ 3 mA
Capacitive load			≤ 300 nF
Inductive load			≤ 500 µH
Assignment	X50:1		REF1 (DC +10 V)
	X50:8		REF2 (DC -10 V)

2.10.2 CES11A multi-encoder card

Voltage supply

The multi-encoder card is supplied by the basic device.

Technical data of encoder supply

	Terminal designation	Specification
Part number		28229479
Power consumption		
Power consumption 24 V		0.8 W
Maximum power consumption 24 V (card including encoder supply)		12.8 W
Encoder supply		
12 V	X17:15	DC 12 V \pm 10%
24 V	X17:13	DC 24 V -10%, +20%
Nominal output current 12 V or 24 V		500 mA
Peak current I_{max} for 150 μ s		1000 mA
Capacitive load		< 220 μ F
Inductive load		< 500 μ H
Short-circuit protection for encoder supply		Yes, a permanent short circuit is not permitted.
Evaluable temperature sensor		TF / TH / KTY84-130 / Pt1000


Encoder connection

Encoder connection	Specification
Connection on encoder card end	15-pin socket
Maximum encoder cable length	<ul style="list-style-type: none"> – HTL encoders ES7C, EG7C, and EK8C: 300 m – TTL encoder EK8R: 300 m – Standard HTL encoder: 200 m – Other encoders: 100 m

2.10.3 CFE21A EtherNet/IP™ and Modbus TCP fieldbus interface

CFE21A EtherNet/IP™ and Modbus TCP fieldbus interface	
Part number	28249984
Power consumption	2 W
Application protocols	EtherNet/IP™, Modbus TCP, HTTP, SNMP, DHCP, SEW Application Services
Port numbers used	67/68, 80, 161, 310, 502, 2222, 44818
Network protocols	ARP, ICMP
Media redundancy (DLR)	Yes
Baud rate	100 MBaud/10 MBaud full duplex/half duplex
Connection technology	RJ45
Ethernet switch	Integrated
Ethernet switch switching technology	Cut through
Ethernet switch latency period	5.5 µs
Manufacturer ID	013Bhex (EtherNet/IP™)
Application profiles	CIP Safety™

Connections and LEDs on the fieldbus interface




34407292939

No.	Designation	Terminal/LED	Function
[1]	Status LED	MS	Operating state of the fieldbus
[2]	Status LED	NS	Bus fault
[3]	Status LED	L/A	Status of the fieldbus connection
[4]	Fieldbus card nameplate	–	MAC address of the fieldbus card
[5]	Fieldbus interface (RJ45 socket)	X40	Ethernet connection (port 1)
[6]	Fieldbus interface (RJ45 socket)	X41	Ethernet connection (port 2)

2.10.4 CFN21A PROFINET fieldbus interface

CFN21A PROFINET fieldbus interface	
Part number	28231694
Power consumption	2 W
PROFINET	RT IRT (Isochronous Realtime)
Conformance class	C
Netload class	3
Topology detection (LLDP)	Yes
Automatic addressing (LLDP, DCP)	Yes
Media redundancy (MRP)	Yes
I&M data	I&M0 – I&M5
Application profiles	PROFIsafe, PROFIenergy
Shared device	Yes
Manufacturer ID	010Ahex
Baud rate	100 MBaud, full duplex
Connection technology	RJ45
Ethernet switch	Integrated
Ethernet switch switching technology	Cut through
Ethernet switch latency period	5.5 µs
Ethertype 8892hex	PROFINET
Ethertype 88B5	SEW MOVI-C® Address Editor
Port numbers used	<ul style="list-style-type: none"> • 80 (http) • 161 (SNMP) • 310 (SEW Data Streaming) • PROFINET DCE/RPC Ports (dynamic via end point mapper)
GSD file name	GSDML-Vx.xy-SEW-MOVI-C-MOVIDRIVE-yyymmdd-hhmmss

Connections and LEDs on the fieldbus interface




25706642827

No.	Designation	Terminal/LED	Function
[1]	Status LED	US1	Operating state of the fieldbus
[2]	Status LED	BF	Bus error
[3]	Status LED	L/A	Status of the fieldbus connection
[4]	Fieldbus interface nameplate	–	MAC address of the fieldbus interface
[5]	Fieldbus interface (RJ45 socket)	X40	PROFINET port (port 1)
[6]	Fieldbus interface (RJ45 socket)	X41	PROFINET port (port 2)

2.10.5 Fieldbus card CFP21A PROFIBUS

Fieldbus card CFP21A PROFIBUS	
Part number	28231708
Power consumption	2 W
PROFIBUS protocol variants	PROFIBUS DP and DP-V1 according to IEC 61158
Automatic baud rate detection	9.6 kBaud – 12 MBaud
Connection technology	<ul style="list-style-type: none"> • Via 9-pin D-sub connector • Pin assignment acc. to IEC 61158 <ul style="list-style-type: none"> – Pin 3: RxD/TxD-P – Pin 4: CNTR-P – Pin 5: DGND – Pin 6: VP – Pin 8: RxD/TxD-N
Bus termination	Not integrated, implement using suitable PROFIBUS connector with connection resistors that can be activated.
Station address	1 – 125, can be set via DIP switch
GSD file name	SEW_6011.gsd
DP ID number	6011hex = 24593dez
Set-Pm-UserData	Length: 3 bytes Hex parameterization C4 00 00 = DP diagnostic alarm = OFF Hex parameterization C4 20 00 = DP diagnostic alarm = ON
DP configurations for DDLM-ChkCfg	00 hex = empty space C0 hex, C0 hex, C0 hex = 1 process data word (1 I/O word) C0 hex, C1 hex, C1 hex = 2 process data word (2 I/O words) C0 hex, C2 hex, C2 hex = 3 process data word (3 I/O words) C0 hex, C3 hex, C3 hex = 4 process data word (4 I/O words) C0 hex, C4 hex, C4 hex = 5 process data word (5 I/O words) C0 hex, C5 hex, C5 hex = 6 process data word (6 I/O words) C0 hex, C6 hex, C6 hex = 7 process data word (7 I/O words) C0 hex, C7 hex, C7 hex = 8 process data word (8 I/O words) C0 hex, C8 hex, C8 hex = 9 process data word (9 I/O words) C0 hex, C9 hex, C9 hex = 10 process data word (10 I/O words) C0 hex, CA hex, CA hex = 11 process data word (11 I/O words) C0 hex, CB hex, CB hex = 12 process data word (12 I/O words) C0 hex, CC hex, CC hex = 13 process data word (13 I/O words) C0 hex, CD hex, CD hex = 14 process data word (14 I/O words) C0 hex, CE hex, CE hex = 15 process data word (15 I/O words) C0 hex, CF hex, CF hex = 16 process data word (16 I/O words)
Diagnostics data	Standard diagnostics 6 bytes Max. byte 18: <ul style="list-style-type: none"> • Standard diagnostics 6 bytes • Status diagnostics block 5 bytes • Alarm block 7 bytes
Tools for startup	MOVISUITE® CBG11A or CBG21A (diagnostics only)
Maximum number of PDs	16 words (see above)

Connections and LEDs on the fieldbus interface



34407949579

No.	Designation	Terminal/LED	Function
[1]	DIP switch		DIP switch for setting the PROFIBUS address
[2]	Status LED	RUN	Operating state of the fieldbus
[3]	Status LED	BF	State of the PROFIBUS interface
[4]	Fieldbus interface	X40	PROFIBUS connection

2.10.6 CFL21A POWERLINK fieldbus card


INFORMATION



The fieldbus card can only be used with the MDX9.A-....-503-4-L00 device variant.

POWERLINK CFL21A fieldbus card	
Part number	28281039
Power consumption	2 W
Automatic baud rate detection	Yes, full duplex
Supported baud rate	100 MBaud
Connection technology	2 × RJ45
XDD file name	SEW-MOVI-C-MOVIDRIVE.xdd
Application profiles	CiA402
Vendor ID	59 _{hex}
Device family	MOVI-C®
Application protocols	POWERLINK, SEW Application Services
Permitted cable types	Category 5 and higher, class D according to IEC 11801
Maximum cable length	100 m

Connections and LEDs on the card



34487706251

No.	Designation	Terminal/LED	Function
[1]	Status LED	BE	Operating state
[2]	Status LED	BS	Operating state
[3]	Status LED	L/A	Status
[4]	Nameplate	-	MAC address
[5]	Fieldbus interface	X40	Connection
[6]	Fieldbus interface	X41	Connection

2.10.7 CS..A safety cards

General technical data

MOVIDRIVE® technology

	Value
Ambient temperature for storage of the safety card	$\geq -25\text{ °C}$ to $\leq 85\text{ °C}$
Ambient temperature for MOVIDRIVE® technology, all sizes (Derating, see "MOVIDRIVE® technology" operating instructions)	<ul style="list-style-type: none"> with MOVISAFE® CS..A: $0\text{ °C} - 40\text{ °C}$ without derating with MOVISAFE® CSB..A, CSS..A: $40\text{ °C} - 55\text{ °C}$ with derating with MOVISAFE® CSA31A: $40\text{ °C} - 50\text{ °C}$ with derating
Installation altitude	Maximum 3800 m above sea level

Part numbers of the safety cards

Safety card	Part number
MOVISAFE® CSB21A	28233360
MOVISAFE® CSS21A	28233379
MOVISAFE® CSB31A	28233387
MOVISAFE® CSS31A	28233395
MOVISAFE® CSA31A	28266412

Safe digital inputs

F-DI00 – F-DI03	Value/description
Properties	DC 24 V input pursuant to EN 61131-2, type 3
Signal level	<ul style="list-style-type: none"> Logic "0" = LOW input: $\leq 5\text{ V}$ or $\leq 1.5\text{ mA}$ Logic "1" = HIGH input: $\geq 11\text{ V}$ and $\geq 2\text{ mA}$
Reference ground	GND
Input current	$\leq 15\text{ mA}$
Input resistance	$\leq 4\text{ k}\Omega$ at DC 24 V
Input filter time, parameterizable	4 ms – 250 ms
Permitted cable length	30 m
Error response time with single-pole connection	Not greater than the response time without error
Edge steepness of input signal	$> 120\text{ V/s}$
Input capacitance	$< 500\text{ pF}$

Sensor supply

F-SS0, F-SS1	Value/description
Properties	<ul style="list-style-type: none"> DC 24 V output pursuant to EN 61131-2 Short circuit and overload protection No galvanic isolation
Rated current	150 mA
Inrush current (≤ 10 ms)	300 mA
Short-circuit protection	1.2 A
Internal voltage drop	< DC 1.3 V
Pulsed voltage supply (if activated)	<ul style="list-style-type: none"> 2 ms open (LOW) Period duration, pulsed voltage supply: 8 ms
Permitted cable length	30 m (per sensor)
Leakage current (F-SSx disabled)	< 0.1 mA

Safe digital outputs

F-DO00_P/M, F-DO01_P/M	Value/description
Properties	<ul style="list-style-type: none"> DC 24 V output pursuant to EN 61131-2 Short circuit and overload protection
Rated current	150 mA
Inrush current (≤ 10 ms)	300 mA
Leakage current (F-DOx disabled)	< 0.1 mA
Maximum switching frequency	<ul style="list-style-type: none"> 10 Hz during operation < 1 minute 0.5 Hz during operation > 1 minute
Overload protection	210 mA
Minimum current for wire break monitoring	15 mA
Permitted cable length	30 m
Load capacitance (max. test pulse duration)	≤ 300 nF
Load capacitance (1 ms test pulse duration)	≤ 50 nF
Capacitance to GND/PE (sourcing output only)	≤ 10 nF
Load capacitance with diode decoupling	≤ 12 μ F
Load inductance	≤ 100 μ H
Load inductance with freewheeling diode	≤ 40 H
Minimum load resistance	> 130 Ω

2.11 Technical data of encoder interfaces

2.11.1 Basic device

	Terminal designation	Specification
Encoder interface	X15:1 – 15	Supported encoders
		Resolver
		sin/cos
		TTL/HTL
		HIPERFACE®
		Encoders with RS422 signals
Maximum input frequency		250 kHz
Connection contacts		15-pin socket
Encoder supply		
Voltage supply 1	X15:15	DC 12 V ± 10%
Voltage supply 2	X15:13	DC 24 V -10%, +20%
I_{\max}		500 mA
I_{peak} for 150 µs		1000 mA
Short-circuit protection for encoder supply		Yes, a permanent short circuit is not permitted.

2.11.2 MOVILINK® DDI

	Terminal designation	Specification
Interface	X16	DC 24 V, I_{\max} = 500 mA

2.11.3 CES11A multi-encoder card

	Terminal designation	Specification
Encoder interface	X17:1 – 15	Supported encoders
		sin/cos
		TTL/HTL
		HIPERFACE®
		EnDat 2.1 with sin/cos signals
		SSI
		CANopen
		Encoders with RS422 signals
Maximum input frequency		250 kHz
Connection contacts		15-pin socket
Encoder supply		
Voltage supply 1	X17:15	DC 12 V ± 10%
Voltage supply 2	X17:13	DC 24 V -10%, +20%
I_{\max}		500 mA
I_{peak} for 150 µs		1000 mA
Short-circuit protection for encoder supply		Yes, a permanent short circuit is not permitted.

2.12 Technical data of braking resistors, filters, and chokes

2.12.1 BW.../BW...-T braking resistors

General

The BW.../BW...-T braking resistors are adapted to the technical characteristics of the inverter.

Braking resistors with different continuous and peak braking powers are available.

The braking resistors can be protected against overload and overtemperature by the customer when a thermal overload relay is used. The tripping current is set to the value I_F ; for this, see the following tables "Technical data and assignment to an inverter".

A PTC resistor protects itself (reversible) against regenerative overload by changing abruptly to high resistance and no longer consuming any more energy. The inverter then switches off and signals an "overvoltage" fault.

A flat-type resistor has internal thermal protection (fuse cannot be replaced) that interrupts the current circuit in the event of overload. The configuration guidelines and the documented assignments of the drive inverter and braking resistor must be adhered to.

INFORMATION



Use of protection devices.

Use only the protection devices listed in the following section:

- Internal temperature switch T
- External bimetallic relay

→ See also the chapter "Protection of the braking resistor against thermal overload".

UL and cURus approval

The listed braking resistors have a cURus approval independent of the inverter.

Parallel connection of braking resistors

Identical braking resistors must be connected in parallel for some inverter/resistor combinations.

In this case, protect each braking resistor against overload and overtemperature using a thermal overload relay.

The temperature switches must be connected in series for braking resistors of the BW...-T series.

Technical data and assignment to an inverter

Technical data

Braking resistor	Unit	BW120-001	BW100-002/M	BW100-001	BW100-002	BW100-006-T
Part number		18176011	25664514	08281718	08281653	18204198
Current-carrying capacity at 100% cdf	kW	0.03	0.15	0.1	0.2	0.6
Resistance value R _{BW}	Ω	117	100	100 ± 10%		
Tripping current I _{trip}	A	-	1.2	0.8	1	2.4
Design		PTC sub-mounting resistor	Submounting resistor in flat design	Flat-type resistor		Wire resistor
Power connections		Single conductors				Ceramic terminal 2.5 mm ²
Wire length	mm	170	300	510		-
Cable cross section	mm ²	0.5		1.5		-
Tightening torque	Nm	-				0.5
PE connection		-				M4
PE tightening torque	Nm	-				1.8
Degree of protection in accordance with EN 60529		IP20	IP40	IP54		IP20
Ambient temperature ϑ_{amb}		-20 °C to +40 °C (reduction 4% P _N /10K to +60 °C)				
Mass	kg	0.95	1.4	0.3	0.6	3

Assignment

The assignment considers the maximum peak braking power of the inverter.

Braking resistor	BW120-001	BW100-002/M	BW100-001	BW100-002	BW100-006-T
MDX9.A-....-5.3-...	0020		0020		
	0025		0025		
	0032		0032		
	0040		0040		

Technical data

Braking resistor	Unit	BW047-010-T	BW147-T	BW247-T
Part number		17983207	18201342	18200842
Current-carrying capacity at 100% cdf	kW	1	1.2	2
Resistance value R_{BW}	Ω	47 \pm 10%		
Tripping current I_{trip}	A	4.6	5.1	6.5
Design		Wire resistor		
Power connections		Ceramic terminal 2.5 mm ²		
Tightening torque	Nm	0.5		
PE connection		M4		
PE tightening torque	Nm	1.8		
Degree of protection		IP20		
Ambient temperature ϑ_{amb}		-20 °C to +40 °C		
Mass	kg	4	4.9	6.7

Assignment

The assignment considers the maximum peak braking power of the inverter.

Braking resistor	BW047-010-T	BW147-T	BW247-T
MDX9.A-....-5.3-...	0055		
	0070		
	0095		

Technical data

Braking resistor	Unit	BW027-016-T	BW027-024-T	BW027-042-T
Part number		17983215	17983231	19155301
Current-carrying capacity at 100% cdf	kW	1.6	2.4	4.2
Resistance value R_{BW}	Ω	$27 \pm 10\%$		
Tripping current I_{trip}	A	7.7	9.4	12.5
Design		Wire resistor		Frame resistor
Power connections		Ceramic terminal 2.5 mm ²		
Tightening torque	Nm	0.5		
PE connection		M4		M5
PE tightening torque	Nm	1.8		2.5
Degree of protection		IP20		
Ambient temperature ϑ_{amb}		$-20\text{ °C to }+40\text{ °C}$		
Mass	kg	5.8	8	10

Assignment

The assignment considers the maximum peak braking power of the inverter.

Braking resistor	BW027-016-T	BW027-024-T	BW027-042-T
MDX9.A-....-5.3-...	0125 0160		
MDX9.A-....-2.3-...	0070 0093		

Technical data

Braking resistor	Unit	BW015-016	BW015-042-T	BW015-075-T	BW915-T
Part number		17983258	19155328	19155271	18204139
Current-carrying capacity at 100% cdf	kW	1.6	4.2	7.5	16
Resistance value R _{BW}	Ω	15 ± 10%			
Tripping current I _{trip}	A	10.3	16.7	22.4	32.7
Design		Wire resistor	Frame resistor	Grid resistor mounting position 1	
Power connections		Ceramic terminal 2.5 mm ²	Ceramic terminal 4 mm ²	M8 stud	
Tightening torque	Nm	0.5	0.9	6	
PE connection		M4	M5	M6 stud	
PE tightening torque	Nm	1.8	2.5	3	
Degree of protection		IP20			
Ambient temperature ϑ _{amb}		-20 °C to +40 °C			
Mass	kg	5.8	10	12	32

Assignment

The assignment considers the maximum peak braking power of the inverter.

Braking resistor	BW015-016	BW015-042-T	BW015-075-T	BW915-T
MDX9.A-....-5.3-...	0240 0320 0620 (Parallel connection of 2 braking resistors) 0750 (Parallel connection of 2 braking resistors)			
MDX9.A-....-2.3-...	0140 0213 (Parallel connection of 2 braking resistors) 0290 (Parallel connection of 2 braking resistors)			

Technical data

Braking resistor	Unit	BW010-024	BW010-050-T	BW010-108-T
Part number		17983266	17983274	19155298
Current-carrying capacity at 100% cdf	kW	2.4	5	10.8
Resistance value R _{BW}	Ω	10 ± 10%		
Tripping current I _{trip}	A	15.5	22.4	32.9
Design		Wire resistor	Grid resistor mounting position 1	
Power connections		Ceramic terminal 2.5 mm ²	M8 stud	
Tightening torque	Nm	0.5	6	
PE connection		M4 stud	M6 stud	
PE tightening torque	Nm	1.8	3	
Degree of protection		IP20		
Ambient temperature ϑ _{amb}		-20 °C to +40 °C		
Mass	kg	8	11	17.5

Assignment

The assignment considers the maximum peak braking power of the inverter.

Braking resistor	BW010-024	BW010-050-T	BW010-108-T
MDX9.A-....-5.3-...	0460 0910 (Parallel connection of 2 braking resistors) 1130 (Parallel connection of 2 braking resistors)		
MDX9.A-....-2.3-...	0213 0290 0420 (Parallel connection of 2 braking resistors)		

Technical data

Braking resistor	Unit	BW006-025-01 ¹⁾	BW006-050-01 ¹⁾	BW106-T	BW206-T
Part number		18200117	18200125	18200834	18204120
Current-carrying capacity at 100% cdf	kW	2.5	5	13.5	18
Resistance value R_{BW}	Ω	$6 \pm 10\%$			
Tripping current I_{trip}	A	20.4	28.9	47.4	54.8
Design		Grid resistor mounting position 1			
Power connections		M8 stud			
Tightening torque	Nm	6			
PE connection		M6 stud			
PE tightening torque	Nm	3			
Degree of protection		IP20			
Ambient temperature ϑ_{amb}		$-25\text{ °C to }+40\text{ °C}$			
Mass	kg	7.5	12	30	40

1) Braking resistor has a 1 Ω tap

Assignment

The assignment considers the maximum peak braking power of the inverter.

Braking resistor	BW006-025-01	BW006-050-01	BW106-T	BW206-T
MDX9.A-....-5.3-...	0620 0750 1490 (Parallel connection of 2 braking resistors)			
MDX9.A-....-2.3-...	0570 (Parallel connection of 2 braking resistors)			

Technical data

Braking resistor	Unit	BW005-070	BW005-170-T	BW004-050-01	BW004-070-01
Part number		17983282	17983290	18200133	17967678
Current-carrying capacity at 100% cdf	kW	7	17	5	7
Resistance value R_{BW}	Ω	$4.7 \pm 10\%$		$3.6 \pm 10\%$	
Tripping current I_{trip}	A	38.6	60.1	32.6	38.6
Design		Grid resistor mounting position 1			
Power connections		M8 stud			
Tightening torque	Nm	6			
PE connection		M6 stud			
PE tightening torque	Nm	3			
Degree of protection		IP20			
Ambient temperature ϑ_{amb}		$-20\text{ °C to }+40\text{ °C}$			
Mass	kg	13	33	13	

Assignment

The assignment considers the maximum peak braking power of the inverter.

Braking resistor	BW005-070	BW005-170-T	BW004-050-01	BW004-070-01
MDX9.A-....-5.3-...	0910 1130 1770 (Parallel connection of 2 braking resistors) 2200 (Parallel connection of 2 braking resistors) 2500 (Parallel connection of 2 braking resistors) 3000 (Parallel connection of 2 braking resistors)		1490	
MDX9.A-....-2.3-...	0420 0840 (Parallel connection of 2 braking resistors) 1080 (Parallel connection of 2 braking resistors)		0570	

Technical data

Braking resistor	Unit	BW003-420-T	BW002-070
Part number		13302345	17983304
Current-carrying capacity at 100% cdf	kW	42	7
Resistance value R_{BW}	Ω	$2.5 \pm 10\%$	$2.3 \pm 10\%$
Tripping current I_{trip}	A	135.1	55.2
Design		Grid resistor mounting position 2	Grid resistor mounting position 1
Power connections		M12 stud	M8 stud
Tightening torque	Nm	15.5	6
PE connection		M10 stud	M6 stud
PE tightening torque	Nm	10	3
Degree of protection		IP20	
Ambient temperature ϑ_{amb}		-20 °C to +40 °C	
Mass	kg	93	33

Assignment

The assignment considers the maximum peak braking power of the inverter.

Braking resistor	BW003-420-T	BW002-070
MDX9.A-....-5.3-...	1770	
	2200	
	2500	
	3000	
	3800 (Parallel connection of 2 braking resistors)	
	4700 (Parallel connection of 2 braking resistors)	
	5880 (Parallel connection of 2 braking resistors)	
MDX9.A-....-2.3-...	0840	
	1080	

Technical data

Braking resistor	Unit	BW1.0-170
Part number		17985455
Current-carrying capacity at 100% cdf	kW	17
Resistance value R_{BW}	Ω	$1 \pm 10\%$
Tripping current I_{trip}	A	130.4
Design		Grid resistor mounting position 2
Power connections		M12 stud
Tightening torque	Nm	15.5
PE connection		M10 stud
PE tightening torque	Nm	10
Degree of protection		IP20
Ambient temperature ϑ_{amb}		-25 °C to +40 °C
Mass	kg	45

Assignment

The assignment considers the maximum peak braking power of the inverter.


Braking resistor	BW1.0-170
MDX9.A-....-5.3-...	3800
	4700
	5880

Technical data BW...-T signal contact

Specifications for BW...-T	Design
Signal contact connection cross section	$1 \times 2.5 \text{ mm}^2$
Tightening torque of the signal contact	1 Nm
Switching capacity signal contact	DC 2 A / DC 24 V (DC11) AC 2 A / AC 230 V (AC11)
Switch contact (NC contact)	According to EN 60730

Dimension sheets and dimensions


Wire resistor



9007218129604875

Braking resistor	Main dimensions in mm			Mounting dimensions in mm				Cable gland
	A	B	C	a	b	d	x	
BW100-006-T	549	92	125	430	80	6.5	8	M25 + M12
BW047-010-T	749	92	125	630	80	6.5	8	M25 + M12
BW147-T	549	185	125	430	150	6.5	8	M25 + M12
BW247-T	749	185	125	630	150	6.5	8	M25 + M12
BW027-016-T	649	185	125	530	150	6.5	8	M25 + M12
BW027-024-T	649	275	125	530	240	6.5	8	M25 + M12
BW015-016	649	185	125	530	150	6.5	8	M25
BW010-024	649	275	125	530	240	6.5	8	M25


Grid resistor mounting position 1



18874868747

Braking resistor	Main dimensions in mm			Mounting dimensions in mm				Cable gland
	A	B	C	a	b	d	x	
BW015-075-T	415	500	270	395	380	9	—	—
BW106-T	795	490	270	770	380	10.5	—	—
BW206-T	995	490	270	970	380	10.5	—	—
BW915-T	795	490	270	770	380	10.5	—	—
BW010-050-T	395	490	260	370	380	10.5	—	—
BW010-108-T	525	500	270	505	380	9	—	—
BW004-050-01	395	490	260	370	380	10.5	—	—
BW005-070	395	490	260	370	380	10.5	—	—
BW002-070	395	490	260	370	380	10.5	—	—
BW005-170-T	490	795	270	380	770	10.5	—	—
BW006-025-01	295	490	260	270	380	10.5	—	—
BW006-050-01	395	490	260	370	380	10.5	—	—


Grid resistor mounting position 2



18874876043

Braking resistor	Main dimensions in mm			Mounting dimensions in mm				Cable gland
	A	B	C	a	b	d	x	
BW003-420-T	995	490	710	970	380	10.5	—	—
BW1.0-170	490	795	490	380	770	10.5	—	—


Frame resistor



9007218129614603

Braking resistor	Main dimensions in mm			Mounting dimensions in mm				Cable gland
	A	B	C	a	b	d	x	
BW027-042-T	570	390	180	380	370	6.5	55	M25 + M12
BW015-042-T	570	390	180	380	370	6.5	55	M25 + M12


Flat-type resistor



18874878475


Braking resistor	Main dimensions in mm			Mounting dimensions in mm				Connection length in mm
	A	B	C	a	b	d	x	
BW100-001	110	80	15	98	60	—	—	300
BW100-002	216	80	15	204	60	—	—	300

BW120-001 resistor



Length of connections: 130 mm


BW100-002/M resistor



BS.. touch guard

A BS.. touch guard is available for braking resistors in flat design.

Touch guard	BS003	BS005
Part number	8131511	813152X
Braking resistor	BW100-001	BW100-002

Dimension drawing of BS...

1455849867

[1] Grommet

[2] Support rail mounting

Type	Main dimensions in mm			Mounting dimensions in mm					Mass in kg
	A	B	C	b	d	e	a	x	
BS-003	60	160	146	125	40	20	6	17.5	0.35
BS-005	60	160	252	125	4	20	6	17.5	0.5

Mounting rail installation

A mounting rail attachment HS001 is available from SEW-EURODRIVE, part number 8221944, for mounting the touch guard on a mounting rail.

2.12.2 NF.. line filter

Line filters are used to suppress interference emission on the line side of inverters.

INFORMATION



Do not switch between the NF.. line filter and inverter.

UL and cURus approval

The listed line filters have a cURus approval independent of the inverter.


Technical data

Line filter	Unit	NF0055-503	NF0120-503	NF0220-503	NF0420-513	NF0910-523	NF1800-523	NF2700-503
Part number		17984319	17984270	17984300	17983789	17987504	17987865	18000576
Nominal line voltage (according to EN 50160) AC V_{line}	V	3 × 230 – 500 V						
Line frequency f_{line}	Hz	50 – 60 ± 5%						
Nominal current I_N	A	5.5	12	22	42	91	180	270
Nominal power loss	W	4	6	30	30	51.5	89	103
Ambient temperature ϑ_{amb}		0 °C to 45 °C (reduction: 3% I_N up to maximum 60 °C)						
Connection contacts L1/L2/L3 – L1'/L2'/L3'		Cage clamp terminals			Screw terminal			M12 stud
Cross section L1/L2/L3 – L1'/L2'/L3'	mm ²	Max. 6			2.5 – 16	10 – 50	16 – 120	–
Tightening torque L1/L2/L3 – L1'/L2'/L3'	Nm	–			2 – 4	3.5 – 6	12 – 20	14 – 20
PE connection contacts		M4 screw		M5 screw	M6 stud	M8 stud	M10 stud	M12 stud
PE tightening torque	Nm	1.5		3	6	12	23	30
Degree of protection		IP20 according to EN 60529						
Mass	kg	1	1	1.4	3	5	9	15.8

Assignment to an inverter


Line filter	NF0055-503	NF0120-503	NF0220-503	NF0420-513	NF0910-523	NF1800-523	NF2700-503
MDX9.A-...-5.3-...	0020 – 0040	0055 – 0095	0125 – 0160	0240 – 0320	0460 – 0750	0910 – 1490	1770 – 3000
MDX9.A-...-2.3-...	–	0070 – 0093	0140	0213 – 0290	0420 – 0570	0840 – 1080	–

Dimension sheets and dimensions



18891135115

Line filter	Main dimensions in mm				Mounting dimensions in mm			Connection
	A	B	C	E	a	b	d	PE
NF0055-503	200	50	97	-	186	25	5.5	M4
NF0120-503	200	50	97	-	186	25	5.5	M4
NF0220-503	230	55	102	-	216	30	5.5	M4



9007218145873675

Line filter	Main dimensions in mm				Mounting dimensions in mm			Connection
	A	B	C	E	a	b	d	PE
NF0420-513	250	88	98	255	235	60	5.5	M6
NF0910-523	270	97	152	322	255	65	6.5	M8
NF1800-523	360	131	182	464	365	102	6.5	M10
NF2700-503	450	231	284	463	435	172	6.5	M12

2.12.3 ND.. line chokes

Line chokes are used as follows:

- To support overvoltage protection
- To smoothen the line current, to reduce harmonics
- For protection in the event of distorted line voltage
- To limit the charging current when several inverters are connected together in parallel on the input end with a shared line contactor (nominal current of line choke = total of inverter currents)

UL and cURus approval

The listed line chokes have cURus approvals independent of the inverter.

Technical data


Technical data

Line choke	Unit	ND0070-503	ND0160-503	ND0300-503	ND0420-503	ND0910-503	ND1800-503	ND3000-503
Part number		17984173	17984181	17983800	17983819	17987520	17987539	18001211
Nominal line voltage (ac- cording to EN 50160) AC V_{line}	V	3 × 230 – 500 V						
Nominal current I_N	A	7	16	30	42	91	180	300
Line frequency f_{line}	Hz	50 – 60 ± 5%						
Nominal inductance	mH	0.36	0.2	0.1	0.045	0.035	0.018	0.05
Nominal power loss	W	4	9	11	13	53	116	280
Ambient temperature ϑ_{amb}		-10 °C to 45 °C (reduction: 3% I_N up to maximum 60 °C)						
Connection contacts L1/L2/L3 – L1'/L2'/L3'		Screw terminal						M12 stud
Cross section L1/L2/L3 – L1'/L2'/L3'	mm ²	0.2 – 4		0.2 – 10	2.5 – 16	10 – 50	16 – 120	–
Tightening torque L1/L2/L3 – L1'/L2'/L3'	Nm	0.5 – 1		1.2 – 2	2.5	3.5 – 6	12 – 20	15.5
PE connection contacts		M4 screw		M5 screw		M8 stud	M10 stud	2 × M10 stud
PE tightening torque	Nm	1.5		3		12	20	20
Degree of protection accord- ing to EN 60529		IPXXB				IPXXA		IP00
Mass	kg	0.5	1.3	1.95	1.82	4.4	10	36

Assignment to an inverter


Line choke	ND0070-503	ND0160-503	ND0300-503	ND0420-503	ND0910-503	ND1800-503	ND3000-503
MDX9.A-...-5.3-...	0020 – 0040	0055 – 0095	0125 – 0160	0240 – 0320	0460 – 0750	0910 – 1490	1770 – 3000
MDX9.A-...-2.3-...	-	0070 – 0093	0140	0213 – 0290	0420 – 0570	0840 – 1080	-

Dimension sheets and dimensions



18891130251

Line choke	Main dimensions in mm				Mounting dimensions in mm			Connection
	A	B	C	E	a	b	d	PE
ND0070-503	78	57	105	56	65	40	4.8	M4
ND0160-503	96	70	120	65	71	54	4.8	M4
ND0300-503	121	86	145	86	105	70	4.8	M5
ND0420-503	121	86	150	90	105	70	4.8	M5



20917778571

Line choke	Main dimensions in mm				Mounting dimensions in mm			Connection
	A	B	C	E	a	b	d	PE
ND0910-503	156	96	220	120	135	80	5.8	M8
ND1800-503	187	121	260	153	166	93	6.2	M10
ND3000-503	280	-	286	188	255	144	11 × 22 slot- ted hole	M10

2.12.4 HF.. output filters

Description of the output filter

HF.. type output filters are sine filters used to smooth the output voltages of inverters.

- Discharge currents in the motor cables are suppressed.
- Motor winding insulations of third-party motors that are not suitable for inverters are protected.
- For long motor cables (> 100 m), overvoltage peaks are prevented.

UL and cURus approval

The listed output filters have a cURus approval independent of the inverter.


Technical data

Output filter	Unit	HF0055-503	HF0125-503	HF0240-503	HF0460-503	HF0650-503	HF1150-503
Part number		17985110	17985129	17985137	17985145	17991277	17991269
Nominal line voltage (ac- cording to EN 50160) AC V_{line}	V	3 × 230 – 500 V					
Nominal current I_N	A	5.5	12.5	24	46	65	115
Line frequency f_{line}	Hz	50 – 60 ± 5%					
Nominal power loss	W	80	120	200	400	500	900
Ambient temperature ϑ_{amb}		0 °C to 45 °C (reduction: 3% I_N/K up to maximum 60 °C)					
Connection contacts U1/V1/W1/UDC – U2/V2/W2		Screw terminal					
Cross section U1/V1/W1/UDC – U2/V2/W2	mm ²	0.2 – 10		2.5 – 16		16 – 50	16 – 95
Tightening torque U1/V1/W1/UDC – U2/V2/W2	Nm	1.2 – 2		2 – 4		3 – 6	12 – 20
PE connection contacts		M6 stud				M8 stud	M10 stud
PE tightening torque	Nm	6				12	23
Degree of protection in accordance with EN 60529		IPXXB				IPXXA	
Mass	kg	8	18	25	40	48	68

Assignment to an inverter

Output filter	HF0055-503	HF0125-503	HF0240-503	HF0460-503	HF0650-503	HF1150-503
MDX9.A-....-5.3-...	0020 – 0040	0055 – 0095	0125 – 0160	0240 – 0320	0460 0910 (parallel connection of 2 filters)	0620 – 0750 1130 – 1490 (parallel connection of 2 filters)
MDX9.A-....-2.3-...	-	0070 – 0093	0140	0213 – 0290	0420	0570

Dimension sheets and dimensions



9007218523812619

Output filter	Main dimensions in mm				Mounting dimensions in mm				Connection
	A	B	C	E	a	b	d	x	PE
HF0055-503	310	105	160	-	290	75	6.5	7	M6
HF0125-503	390	120	215	-	370	90	6.5	7	M6
HF0240-503	450	135	270	-	430	100	6.5	7	M6
HF0460-503	450	160	310	-	430	120	6.5	7	M6
HF0650-503	635	210	285	637	610	174	8.5	10	M8
HF1150-503	725	260	273	755	700	224	8.5	10	M10

2.12.5 HD.. output chokes

Description of output chokes

HD.. type output chokes suppress interference emitted from unshielded motor cables.

UL and cURus approval

The listed output chokes have a cURus approval independent of the inverter.


Technical data

Output choke	Unit	HD0125-503	HD0240-503	HD0460-503	HD1000-503	HD2000-503	HD6000-503
Part number		17985153	17985188	17985161	17991307	17991250	17963362
Nominal line voltage (ac- cording to EN 50160) AC V_{line}	V	3 × 230 – 500 V					
Nominal current I_N	A	12.5	24	46	100	200	600
Line frequency f_{line}	Hz	50 – 60 ± 5%					
Nominal power loss	W	2.9	6	14	37	83	162
Ambient temperature ϑ_{amb}		0 °C to 45 °C (reduction: 3% I_N/K up to maximum 60 °C)					
Connection contacts U1/V1/W1/UDC – U2/V2/W2		Screw terminal					Copper rail
Cross section U1/V1/W1/UDC – U2/V2/W2	mm ²	0.2 – 10	2.5 – 16		16 – 50	16 – 150	30 × 8, bore Ø M12 mm
Tightening torque U1/V1/W1/UDC – U2/V2/W2	Nm	1.2 – 2	2 – 4		6 – 8	12 – 20	-
PE connection contacts		M6 stud			M8 stud	M10 stud	M12 × 50
PE tightening torque	Nm	6			12	23	30
Degree of protection in accordance with EN 60529		IPXXB			IPXXA		IP00
Mass	kg	0.85	1.46	2.35	3	6.5	16

Assignment to an inverter


Output choke	HD0125-503	HD0240-503	HD0460-503	HD1000-503	HD2000-503	HD6000-503
MDX9.A-...-5.3-...	0020 – 0095	0125 – 0160	0240 – 0320	0460 – 0750	0910 – 1490	1770 – 3000
MDX9.A-...-2.3-...	0070 – 0093	0140	0213 – 0420	0420 – 0840	1080	-

Dimension sheets and dimensions



9007218145873675

Output choke	Main dimensions in mm				Mounting dimensions in mm			Connection
	A	B	C	E	a	b	d	PE
HD0125-503	153	62.5	72.5	151	138	40	5.5	M6
HD0240-503	173	92.5	82.5	178	158	65	5.5	M6
HD0460-503	185	122.5	112.5	189	170	90	5.5	M6
HD1000-503	255	116	143.5	265	240	82	6.5	M8
HD2000-503	300	178	175	330	286	120	6.5	M10



35975896715

Output choke	Main dimensions in mm				Mounting dimensions in mm				Connection
	A	B	C	E	a	b	d	e	PE
HD6000-503	300	260	116	395	240	240	13	13	M12

2.12.6 DC link chokes ZD..

The necessity of a DC link choke must be checked according to the information in the "Project planning" chapter.

Technical data


DC link choke	Unit	ZD010-0200	ZD040-0070	ZD140-0020	ZD330-0006
Part number		17968437	17968402	17968410	17968429
Nominal line voltage (according to EN 50160) AC V_{line}	V	3 × 380 – 500 V			
Nominal current DC I_N	A	10	40	140	330
Line frequency f_{line}	Hz	50 – 60 ± 5%			
Power loss at I_N P_V	W	7	17	29	40
Ambient temperature ϑ_{amb}	°C	-10 – 40			
Degree of protection		IP10			
Connection contacts $+U_Z$ / $-U_Z$ / $+U_Z'$ / $-U_Z'$		Terminal strips	M6 stud	M10 stud	M12 stud
Cross section	mm ²	4	–	–	–
PE connection contacts		M5 stud	M6 stud	M8 stud	M8 stud
Tightening torque	Nm	0.6 – 0.8	3	M10: 10 PE: 6	M12: 15.5 PE: 6
Assignment					
MDX9.A-...-5.3-...		0020 – 0070	0095 – 0240	0320 – 0750	0910 – 1490
MDX9.A-...-2.3-...		0070	0093 – 0213	0290 – 0570	0840 – 1080

UL and cURus approval

The listed DC link chokes have a cURus approval independent of the inverter.

Dimension sheets and dimensions


DC link choke ZD010..



- [1] Connecting terminal
[2] Ground stud

DC link choke	Main dimensions in mm				Mounting dimensions in mm				Mass
	A	B	C	C1	a	b	x1	c	kg
ZD010-0200	80	64.75	62	95	70	35	13.25	5.3	0.56

DC link choke ZD040.. / ZD140.. / ZD330.. with and without cover



3879622795

[1] Terminal stud

[2] Ground stud

DC link choke	Main dimensions in mm						Mounting dimensions in mm					Mass
	A	B	B1	C	C1	C2	a	b	c	x1	x2	kg
ZD040-0070	130	94	98	116	145	156	120	60	5.3	15	17	2
ZD140-0020	190	130	134	110	150	164.5	170	100	6.5	15	17	4.5
ZD330-0006	250	170	174	180	240	254	230	140	6.5	15	17	8.8

26860791/EN – 07/2022

2.13 USM21A interface adapter

With the USM21A interface adapter, it is possible to connect an engineering PC with a USB interface to the X32 Service interface of the inverter.

USM21A	Technical data
Part number	28231449
Ambient temperature	0 °C to 40 °C
Storage temperature	-25 °C to 70 °C
Degree of protection	IP20
Dimensions	
Width	42 mm
Height	89 mm
Depth	25 mm

An order using part number 28231449 includes the following parts:


- USM21A interface adapter
- USB connection cable for the USM21A – PC connection
- Serial interface cable with 2 RJ10 connectors



INFORMATION

To connect the inverter to the USM21A, you need an additional serial interface cable with an RJ10 connector and a 9-pin D-sub connector, part number 18123864.

This cable must be ordered separately.



26663013387

3 Project planning

3.1 SEW-Workbench

The SEW-Workbench is the central configuration software for inverters from SEW-EURODRIVE.

It can process any required configurations, from entering the application to gear unit, motor and inverter calculations. Other features are optimization of the various axis cycles including the selection of accessories and a fault check of the entire drive system configuration.

Of course, the Workbench can also be used to select and dimension all other products from SEW-EURODRIVE (such as decentralized drives and gearmotors). This means the SEW-Workbench allows for thoroughly specifying drive solutions from the entire range of products from SEW-EURODRIVE. The straightforward operation saves a great deal of time and minimizes complexity.

The key features of the SEW-Workbench are:


- Application selection
- Gear unit and motor calculation
- Price-optimized configuration
- Comparison of different solutions
- Inverter calculation
- Multi-axis optimization
- Parameterization of cable and accessories selection
- Dimensioning error check
- Parts list generation
- Electronic catalog with all products

The configuration software SEW-Workbench is available for download from the official SEW-EURODRIVE website.

To use SEW-Workbench, all you need to do is to register via the Online Support once you have downloaded and installed the software or received the data DVD. An Internet update service ensures that the products and functions are always up to date.

3.2 Schematic workflow for project planning

The following flow diagram illustrates the drive selection procedure for a positioning drive. The drive consists of a gearmotor that is supplied by an application inverter.



3.3 Drive selection

For drive selection, in addition to the travel diagram that describes the exact travel cycle, a large number of additional specifications must be made about the operating and ambient conditions.

It is first necessary to have data for the machine to be driven such as mass, setting range, speed, information about the mechanical design and so on in order to select the drive correctly. The appropriate drive can be determined with the calculated torques and speeds of the drive while taking other mechanical requirements such as environmental and operating conditions into account.

For selecting the drive, a decision is to be taken if an asynchronous motor or a synchronous motor is to be used. The extensive product range of SEW-EURODRIVE is available for this purpose.

3.3.1 Characteristics of the control modes

INFORMATION



The values in the following tables only apply in case of a basic clock frequency of 4 kHz.

Overview of the control modes

	V/f	VFC ^{PLUS}		CFC		ELSM [®]
Principle	Voltage controlled according to characteristic curve	Field-oriented, voltage-controlled, stator flux controller, torque controller		Field-oriented, current controller		Field-oriented, current controller
Motor	ASM/LSPM	ASM	ASM	ASM	SM	SM
Encoder	Without	Without	With	With	With	Without
Dynamics	+	+++	++++	+++++	+++++	++
Energy efficiency	+	+++	+++	++	+++++	+++++
Speed control	Yes ¹⁾	Yes		Yes		Yes
Torque control	No	Yes		Yes		Yes
Positioning	No	No	Yes	Yes		No
Flying start	No ²⁾	Yes		Yes		Yes
Typical applications	Group drive, multi-motor drives	General materials handling technology, horizontal drives, vertical drives, pumps/fans, winding drives		Packaging technology, handling technology, highly-dynamic positioning		Horizontal materials handling technology
Characteristics	Maximum robustness	Maximum precision		Maximum dynamics		Maximum energy efficiency

1) Open-loop speed control

2) DC braking

Characteristic values for dynamics

	V/f	VFC ^{PLUS}	CFC	ELSM [®]
Torque control time	—	≥ 2 ms ¹⁾	≥ 150 μs	≥ 150 μs
Time constant speed controller	—	≥ 4 – 6 ms	≥ 2 ms	≥ 6 ms
Speed ripple	The speed ripple is mainly determined by the total mass moment of inertia, the torque ripple and in particular the mechanical structure. It is therefore not possible to specify a general value.			

1) Valid in voltage control range, in field weakening range < 5 ms.

Characteristic values for setpoint resolution

	V/f	VFC ^{PLUS}	CFC	ELSM [®]
Torque	-	32 bits 0.001% M _{NMot}	32 bits 0.001% M _{NMot}	32 bits 0.001% M _{NMot}
Speed	32 bits 0.0001 min ⁻¹	32 bits 0.0001 min ⁻¹	32 bits 0.0001 min ⁻¹	32 bits 0.0001 min ⁻¹
Position (increment/revolution)	-	16 bits	16 bits	-
Position (absolute increment)	-	32 bits	32 bits	-

Characteristic values for accuracy of torque and speed

	VFC ^{PLUS} without encoder		VFC ^{PLUS} with encoder	
	Motor temperature sensor		Motor temperature sensor	
	Without	With	Without	With
Accuracy of the calculated torque	depends on the accuracy of the motor parameters INFORMATION: The more accurate the motor parameters, the more accurate the torque. For greater torque accuracy, measure the motor parameters with FCB25.			
Deviation with FCB25	< 5% M _N	< 5% M _N	< 5% M _N	< 5% M _N
Typical deviation	< 10% M _N	< 10% M _N	< 10% M _N	< 10% M _N
Maximum deviation ¹⁾	< 15% M _N	< 15% M _N	< 25% M _N	< 15% M _N

1) If n is permanently < 20% of the nominal speed.

	CFC without temperature sensor	CFC with temperature sensor
Accuracy of the calculated torque	depends on the accuracy of the motor parameters and motor temperature	depends on the accuracy of the motor parameters, typical deviation: < 5% M _N

	VFC ^{PLUS} without encoder	All control modes with encoders
Accuracy of the calculated speed¹⁾	depends on the accuracy of the motor parameters, typical deviation: $0.2 \times f_{\text{nominal slip}}$	Maximum deviation: 0.007% n _{setp} , 10 ⁻⁴ min ⁻¹

1) Stationary inaccuracy is the deviation between the mean value of the exact physical speed and the speed setpoint.

Maximum output frequency

f_{PWM}	V/f	VFC ^{PLUS}	CFC	ELSM [®]
2.5 kHz	250 Hz	250 Hz	250 Hz	250 Hz
4 kHz	400 Hz	250 Hz	400 Hz	400 Hz
≥ 8 kHz	599 Hz	250 Hz	500 Hz	500 Hz

FCBs that can be activated for selected control mode

FCB no.	Designation	V/f	VFC ^{PLUS}	CFC	ELSM [®]
01	Output stage inhibit	+	+	+	+
02	Default stop	+	+	+	+
04	Manual mode	+	+	+	+
05	Speed control	+	+	+	+
06	Interpolated speed control	+	+	+	+
07	Torque control	–	+	+	+
08	Interpolated torque control	–	+	+	+
13	Stop at application limits	+	+	+	+
14	Emergency stop	+	+	+	+
25	Motor parameter measurement	+	+	+	+
26	Stop at user limits	+	+	+	+
FCBs requiring a position encoder					
09	Positioning control	–	+	+	–
10	Interpolated positioning control	–	+	+	–
12	Reference travel	–	+	+	+
18	Rotor position identification	–	–	+	–
19	Position hold control	–	+	+	–
20	Jog	–	+	+	–
21	Brake test	–	+	+	–

3.3.2 General requirements for motors

Motors that can be connected

- Asynchronous motors with squirrel-cage rotor
- Permanent-field synchronous motors

When third-party motors are operated with inverters, SEW-EURODRIVE cannot ensure that the specified performance data is reached.

Dielectric strength of the motor

The operation of an AC motor with a frequency inverter places a much greater load on the motor winding than in the case of operation on the supply system. All AC motors by SEW-EURODRIVE have the required voltage endurance.

The connected third-party motor has to be designed in inverter mode for these DC link voltages.

At a line voltage of AC 3×400 V, the nominal DC link voltage is DC 560 V. In regenerative operation, the DC link voltage can rise to 980 V.

The inverters pulse the DC voltage of the DC link U_{DC} to the supply cables to the motor. At SEW-EURODRIVE, the pulsed voltage supply is available with 2.5 kHz, 4 kHz, 8 kHz, or 16 kHz. As a result, the motor is loaded with voltage peaks, high amplitude and very short rise times.

For operation of third-party motors on inverters by SEW-EURODRIVE, their suitability must be checked.

Requirements for third-party motors

The connected third-party motor has to be designed in inverter mode for the relevant DC link voltage.

The inverters pulse the DC voltage of the DC link U_{DC} to the supply cables to the motor. At SEW-EURODRIVE, the pulsed voltage supply is available with 2.5 kHz, 4 kHz, 8 kHz, or 16 kHz. As a result, the motor is loaded with voltage peaks, high amplitude and very short rise times.

The technical data of the motors must lie within the following ranges:

	Permitted input values	Realistic area
Nominal motor speed	0 – 36000 min ⁻¹	0 – 36000 min ⁻¹
Nominal motor current	0 – 10000 A	0 – 900 A
Nominal motor voltage	0 – 2000 V	0 – 690 V
Nominal motor torque	0 – 50000 Nm	0 – 50000 Nm
Rated motor frequency	0 – 20000 Hz	0 – 599 Hz
Number of pole pairs asynchronous/synchronous motor	1 – 64	1 – 64

Thermal motor protection

Thermal motor protection avoids overheating and, therefore, prevents irreparable damage from being caused to the motor. For this purpose, temperature sensors detect the winding temperature. As standard, the inverters can evaluate the following temperature sensors:

Motor protection	Number of sensors	SEW designation
PTC thermistor	3	TF
Bimetallic temperature switch	3	TH
Semiconductor temperature sensor KTY84 – 130	1	KY/KTY
Pt1000 platinum temperature sensor, mounted in winding	1	PK
Pt1000 platinum temperature sensor, mounted in stator housing	1	PI ¹⁾

1) In preparation.

Motor series	Temperature sensor	Motor protection
CM..	KTY84 – 130, Pt1000	Comprehensive protection ¹⁾
CM..	TF	Limited protection ²⁾
DR..	TF, TH	Comprehensive protection ³⁾
DR..	KTY84 – 130	Limited protection ⁴⁾
DR..	Pt1000 (PK)	Limited protection ⁴⁾
DR..	Pt1000 (PI)	Comprehensive protection ¹⁾
Third-party motors	PTC thermistor, Bimetallic temperature switch	Comprehensive protection ³⁾
Third-party motors	KTY84 – 130, Pt1000	Limited protection ⁴⁾

1) Comprehensive protection, as a thermal model protects the winding in addition to the measured value.

2) Depending on the motor size.

3) Comprehensive protection, as one sensor per motor phase is included.

4) If the temperature measured by the temperature sensor exceeds the limit temperature of the set thermal class of the motor, the inverter issues a fault message. There is no evaluation of the motor model. Thermal overload of windings is possible since the sensor is only installed in one winding.

For additional information on the thermal motor protection, refer to the documentation of the motors.

Thermal motor protection without temperature sensor

Thermal motor protection without temperature sensor is an inverter function that can protect motors without temperature sensors (e.g. PTC thermistors, bimetallic switches) against thermal overload. The level of protection is similar to that of a thermal overload relay. However, the reduced cooling is taken into account, especially at lower speeds.

- Insufficient cooling conditions and increased ambient temperature are influencing factors that cannot be taken into account.
- In the event of overloads in the low speed range, it cannot be ruled out that increased winding temperatures may occur which may damage the winding or lead to premature aging of the motor.
- The cooling of the motor is stronger at low temperatures. A temperature sensor only measures and triggers an overtemperature at increased motor utilization. This increased motor utilization is not possible with thermal motor protection without a sensor.

This means that thermal motor protection without a temperature sensor only represents basic protection. For complete thermal motor protection, SEW-EURODRIVE recommends using a temperature sensor.

Requirements

The following table lists the requirements that must be met to use thermal motor protection without a temperature sensor.

Category	Requirements
Firmware version	Version 7.0 or later
Motor series	DRN.., DR2S..
Motor size	63 – 132M
Number of poles	4

Boundary conditions

The following table shows the framework conditions that must be met in order to be able to use thermal motor protection without a temperature sensor.

Category	Requirements
Type of cooling	fan-cooled
Ambient temperature	-20 °C to +40 °C
Thermal class of winding	155(F), 180(H)
Installation altitude	< 1000 m

For motors with forced cooling fans as well as fan-free and non-ventilated motors, the thermal motor protection must not be used without a temperature sensor.

In the case of multi-motor drives and group drives, as well as third-party motors, it is not possible to use the thermal motor protection without a temperature sensor.

For motors with speed sensor, SEW-EURODRIVE recommends using a thermal sensor.

Further information

The thermal motor protection without temperature sensor is active as long as the inverter is in operation and supplied with at least DC 24 V.

The thermal motor protection without temperature sensor has no memory, i.e. it does not take into account the current motor temperature after a switch-on/switch-off process. Therefore, it must be avoided that an overheated motor is immediately subject to another overload by switching the inverter off and on again. SEW-EURODRIVE recommends performing a fault reset in the event of a fault message of the thermal motor protection without temperature sensor.

3.3.3 Startup of third-party motors

Asynchronous motors	<p>The nameplate data must be entered during startup, a calibration function then determines further data not specified on the nameplate. While the calibration function is running, the rotor does not turn and the brake is not released.</p> <p>In case of asynchronous motors, at least the nameplate data must be known. The parameters required for startup are calculated based on the nameplate data and the motor is taken into operation. This only works in online mode.</p> <p>An additional parameter measurement can be performed for enhanced control characteristics. In case of asynchronous motors, the measurement is performed while the motor is at standstill; if a brake is available, it can be and should remain applied. The duration of the measurement depends on the motor parameters.</p>
Synchronous motors	<p>For synchronous motors without encoder, the startup procedure is performed in the same way as with asynchronous motors using the nameplate data.</p> <p>For synchronous motors with encoder, the correct encoder offset must be ensured after startup. This is performed using the function "Rotor position identification". The rotor turns during the rotor position identification. Make sure that the rotor can turn freely. For this reason, the motor must be separated from the gear unit or system.</p> <p>In case of synchronous motors the nameplate data alone is not sufficient, but an additional parameter calibration must be performed. In addition to the nameplate data, other values must also be known, such as the number of pole pairs, maximum speed, maximum current, or maximum torque and mass moment of inertia.</p> <p>With synchronous motors, the brake is released (if available) during the measurement to align the rotor electrically. No load must be attached to the motor during the measurement, i.e. the motor must be in no-load operation. Otherwise, a correct calibration of the motor parameters cannot be guaranteed. The entire measurement only takes a few seconds with synchronous motors. After the measurement has been successfully performed, the motor is taken into operation electrically.</p> <p>In case of drives with permanent magnet synchronous motors, encoder operation always requires knowledge of the absolute rotor position. The knowledge of the initial rotor position angle offset is called "commutation". The offset of the rotor position angle can be determined using FCB18 and saved to the inverter. No load must be attached to the motor during the calibration, otherwise, a correct commutation cannot be guaranteed.</p>

3.3.4 Group drive and multi-motor drive

Group drive of asynchronous motors

A group drive is a group of asynchronous motors of any power rating. The motors do not have a rigid mechanical connection or only have a connection that is subject to slip and are connected to an electrically parallel inverter.

After a suitable startup, operation is possible.

If motors with different power ratings are operated at the inverter in parallel, the motor with the largest power rating has to be set up.

- The total of the motor currents must not exceed the nominal output current of the inverter.

The maximum number of motors depends on the control mode:

Control mode	Number of motors
V/f	64

Multi-motor drive of asynchronous motors

Multi-motor drive means the electrical parallel connection of several identical asynchronous motors at 1 inverter, that are rigidly and mechanically coupled and drive a load.

Parallel operation of several identical asynchronous motors is possible provided the strict compliance with the following conditions:

- Only use gearmotors of the same type and with the same winding data.
- The rotor position of the individual motors must not differ in more than the following mechanical angle:

$$Z_p \times \Delta\phi_{\text{mech_max}} < 20^\circ$$

$$Z_p = \text{Number of motor pole pairs}$$

$$\Delta\phi_{\text{mech_max}} = \text{Maximum torsion angle of the shaft connection in regard of the motor shaft}$$

This must be ensured by the mechanics, even for maximally different torque loads of the motor shafts.

- If encoder feedback is used, just one of the motors needs to be equipped with an encoder. This encoder must be installed on the gearmotor which has the greatest clearance or elasticity with respect to the load inertia.

The maximum number of motors depends on the control mode:

Control mode	Number of motors
V/f	64
VFC ^{PLUS}	10
CFC	10

Temperature evaluation for group drive/multi-motor drive

- Preferably use bimetallic temperature switches TH.
- The series connection of the TH contacts (normally closed) is not subject to any restriction if joint monitoring is provided.
- If the TF temperature sensors are available in motors, the temperature sensors of up to 3 motors can be connected in series.

Permitted cable length for group drive/multi-motor drive

Note the permitted length of all motor cables connected in parallel:

$$l_{tot} \leq \frac{l_{max}}{n} \qquad l_{tot} = \sum_{i=1}^n l_i$$

l_{tot} = Maximum total length of motor cables connected in parallel

l_{max} = Permitted motor cable length

l_i = Cable length of the inverter to the motor

n = Number of motors connected in parallel

3.3.5 Connecting explosion-protected AC motors

Observe the following instructions when connecting explosion-protected AC motors to the inverters:

- The inverter must be installed outside of the potentially explosive atmosphere.
- Observe industry and country-specific regulations.
- Observe the regulations and information of the motor manufacturer with regard to operation on a frequency inverter, e.g. mandatory sine filter.
- All operating resources used in potentially explosive atmospheres must adhere to the relevant standards, such as Directive 94/9/EC (ATEX 100a) or IEC 60079.
- The sensor input of the motor's temperature monitoring must not be used in potentially-explosive areas. For thermal monitoring use a monitoring device approved for potentially explosive atmospheres.
- In case of motors with speed feedback, the speed sensor must also be approved for potentially explosive atmospheres. The speed sensor can be directly connected to the inverter.

INFORMATION

For more information on the operation of explosion-protected AC motors, refer to the "Explosion-Protected AC Motors, Asynchronous Servomotors" operating instructions. You can order the operating instructions from SEW-EURODRIVE.

3.3.6 General requirements for encoders

Applicable motor encoders from SEW-EURODRIVE

The following overview shows the motor encoders that can be used. For information on the respective encoder cables, refer to chapter "Prefabricated cables".

Last letter of the encoder type designation	Interface on the inverter
...C	X15
...R	
...T	
...S	
...W	
...H	
...L	
...M	
...Z	X16
...C	X17
...R	
...T	
...S	
...W	
...H	
...Y	

Encoder with electronic nameplate

Electronic nameplates can only be evaluated when using encoders from SEW-EURODRIVE.

The electronic nameplate allows for automatic identification of the drive. This channel can also be used to transmit further information to the inverter.

Advantages:

- Complete and correct identification of motor and gear unit
- No manual data entry necessary
- Easy drive identification, even with drives that are difficult to access
- Significant time savings during startup

3.3.7 General requirements for brake control

Refer to the motor catalogs for extensive information and technical data regarding the brakes.

Brake control

Brakes are controlled via digital output X10: (DB0; DB00) on the inverter. When using a CS..A safety card, brake control can also be performed via an assigned safe F-DOx digital output of the safety card. It is not permitted to control them via other electronic devices or via controllers.

The digital output (DB0; DB00) is designed as an output for operating a relay with protection circuit with a DC 24 V control voltage, a maximum current of 150 mA and a power rating of 3.6 W.

With this, a power contactor with DC 24 V coil voltage or a suitable brake rectifier from SEW-EURODRIVE can be controlled. This power contactor is used to switch the brake.

The technical data of the safe digital outputs of the CS..a safety card is described in the corresponding documentation.

Direct switching of the brake via (DB0; DB00; D-DOx) is not permitted.

Three-wire brake with accelerator coil (BE, BM, BMG)

With this brake type, the brakes are controlled using brake control units.

24 V holding brake (BP, BK)

In every application, a holding brake can be controlled via a customer relay with varistor overvoltage protection or via the BMV brake control unit from SEW-EURODRIVE.

Permitted load of brake control and brake

One complete switching sequence (opening and closing) must not be repeated more often than a maximum of every 2 seconds. SEW-EURODRIVE brakes must remain switched off for at least 100 ms before they can be switched on again.

3.4 Recommendations for motor and inverter selection

The basis for motor selection are the limit characteristic curves of the motors in inverter operation. The limit characteristic curve states the torque characteristic of the motor depending on the speed.

The dynamic and thermal limits must be observed when selecting the motor.

3.4.1 Thermal limit characteristic curve

The mean motor speed and the effective torque are calculated during drive selection to determine the thermal utilization of the motor. The operating point of the motor must lie below the thermal limit characteristic curve of the motor; otherwise the motor will be thermally overloaded.


3.4.2 Dynamic limit characteristic curve

The dynamic limit characteristic curve depicts the maximum torque the motor can generate at a certain speed. Note that the inverter must supply sufficient current for the motor to reach its maximum torque.

The base speed is especially important for configuration. The base speed is the available speed up to the maximum motor torque. In inverter operation, the base speed indicates the beginning of field weakening. The motor torque is limited by the voltage limit characteristic curve in the field-weakening range, and decreases with increasing speed.

M_N is determined by the motor. M_{max} and n_{base} depend on the motor/inverter combination. The values for M_{max} and n_{base} in the VFC^{PLUS}, CFC, ELSM[®] control modes can be found in the motor selection tables in chapter "Motor/inverter assignments".


Typical characteristic curve of asynchronous motors



24537317259

- [1] S1 operation with self-cooling
- [2] S1 operation with external cooling
- [3] Mechanical limit for gearmotors

Typical characteristic curve of synchronous motors



9007217201768843

- [1] Thermal limit characteristic curve S1 operation
- [2] Dynamic limit torque

3.4.3 Motor selection for asynchronous motors

Asynchronous motors are mainly operated in VFC^{PLUS} control mode. The control mode efficiently adjusts the motor magnetization to the respective operating point. It simultaneously enables dynamic responses to load shocks on the drive train.

The mechanical resistance of the motor against the overload, which might exceed the permitted limit values, must be strictly checked.

M_{pk} and n_{base} depend on the motor/inverter combination, as well as on the control mode used.

3.4.4 Asynchronous motors in control mode VFC^{PLUS}

The control mode VFC^{PLUS} without encoder allows dynamic use of the entire speed range of the drive. Reversing and moving through speed 0 is also possible.

However, continuous operation of asynchronous motors without encoder at low speeds is not possible. The minimum speeds that must not be permanently undercut during operation without encoder are:

- Motor mode: 1% of the asynchronous motor nominal speed
- Generator mode: 10% of the asynchronous motor nominal speed

The described restrictions do not apply in control mode VFC^{PLUS} with encoder. In comparison to operation without encoder, higher dynamic properties can be achieved with an encoder.

When determining the maximum speed, note that the breakdown torque M_k is reduced in a quadratic relationship in the field weakening range.


3.4.5 Asynchronous motors in control mode CFC

Either standard asynchronous motors (e.g. DRN.. motors) or asynchronous servomotors (e.g. DR2L../DRL.. motors) can be used in control mode CFC. SEW-EURODRIVE recommends using asynchronous servomotors to achieve optimum benefit from the advantages of the control mode CFC.

Standard asynchronous motors in control mode CFC

In comparison to control mode VFC^{PLUS} , higher dynamic properties can be achieved using CFC. The full motor magnetization is maintained in each operating state, so that the highest dynamic requirements are met. Due to the voltage reserves required for this, standard asynchronous motors are operated with a lower base speed in this operating mode than in operating mode VFC^{PLUS} . Power yield and energy efficiency are consequently lower.

Speed/torque characteristic for VFC^{PLUS} and CFC in comparison:



Asynchronous servomotors in control mode CFC

The high-quality mechanical design of the DRL../DR2L.. series asynchronous AC servomotors allows for dynamic overload values that exceed the values of the standard asynchronous motors in line or inverter operation. Due to these characteristics, the values of a synchronous servomotor are almost reached.

SEW-EURODRIVE provides the DRL../DR2L.. motors in two dynamics packages:

Package	Overload capacity in relation to the nominal torque
Dynamics package 1 (D1)	190 – 220%
Dynamics package 2 (D2)	300 – 350%

To obtain an optimal adjustment of the motor speed to the required controller output limit of the application, SEW-EURODRIVE offers DRL../DR2L.. servomotors with the following 4 rated speeds:

- 1200 min⁻¹
- 1700 min⁻¹
- 2100 min⁻¹
- 3000 min⁻¹

3.4.6 Synchronous servomotors in control mode CFC

In general, synchronous servomotors and the corresponding inverters are designed for a high short-time overload capacity. This allows a multiple of the nominal torque.

When using the following motors in the higher speed ranges, it is recommended to only set the PWM frequencies 8 kHz or 16 kHz.

- CMP40/..50/..63 for speeds above 4500 min⁻¹
- CMP71/..80/..100 for speeds above 3000 min⁻¹
- CM3C63/..71/..80/..100 for speeds above 3000 min⁻¹

SEW-EURODRIVE recommends using the following temperature sensors:

- KTY84 – 130 (SEW-EURODRIVE designation: KY)
- Pt1000 (SEW-EURODRIVE designation: PK)

3.4.7 Synchronous servomotors in control mode ELSM®

The control mode ELSM® allows for dynamic use of the entire speed range of the drive. Reversing and moving through speed 0 is also possible. The speed must not permanently drop below the minimum speed of approx. 2% of the nominal motor speed.

When the control mode ELSM® is operated without encoder, the maximum motor torque is 150% M_0 of the connected motor.

The nominal output current of the inverter must not be lower than $1.5 \times I_0$ of the connected motor.

The maximum speed must not be dimensioned higher than the rated speed of the motor.

When using the following motors in the higher speed ranges, it is recommended to only set the PWM frequencies 8 kHz or 16 kHz.

- CMP40/..50/..63 for speeds above 4500 min⁻¹
- CMP71/..80/..100 for speeds above 3000 min⁻¹
- CM3C63/..71/..80/..100 for speeds above 3000 min⁻¹

SEW-EURODRIVE recommends using the following temperature sensors:

- KTY84 – 130 (SEW-EURODRIVE designation: KY)
- Pt1000 (SEW-EURODRIVE designation: PK)

Using the ELSM® control mode for hoists and inclining tracks is not permitted.

3.5 Motor/inverter assignments

For motor/inverter assignments, refer to the SEW-EURODRIVE homepage.

3.6 Inverter selection

The inverter is selected based on the course of the output current over time. The required current has to be determined from the required torque characteristic of the connected motor.

The inverters are dimensioned for a nominal output current I_N . In many applications, there is a demand for short-time overload operation. For this purpose, the inverters can be operated with up to 200% of the nominal output current for a short period of time.

For overload operation, make sure that the inverter is not thermally overloaded. For protection of the power components, inverters have various monitoring mechanisms.

The following thermal monitoring functions are available:

- Dynamic utilization

The periodic current load of the switching power semiconductors lets them heat and cool down cyclically. Due to the different thermal time constants, large temperature differences can occur between power semiconductor and heat sink. Dynamic utilization monitors the permitted temperature of the barrier layer of the power semiconductors.

- Thermal capacity utilization

The power semiconductors are limited by the maximum permitted temperature during operation. Thermal utilization monitors the heat sink temperature of the power semiconductors.

- Electromechanical utilization (I^2t utilization)

Electromechanical utilization protects the components that have a large thermal time constant compared to the power semiconductors.


Due to the complexity of the utilization curves, the calculation can only be performed using software. The SEW-Workbench software offers support for dimensioning an inverter.

For a rough selection of the inverter without using software, characteristic load cycles are provided in the following section.

3.6.1 Overload capacity

Load cycle with base load current – typical for the selection of asynchronous motors and servomotors

The characteristic load cycle consists of a load and a load relief period. In the load relief period, the output current must not exceed the specified value. After this load relief period, overload is possible again.



18014415982173963

Examples of permitted current profiles

Overload capacity

This table applies to inverter sizes 1 to 6 (exception: BG5 MDX9.A-0750-...):

Overload capacity at $V_{line} = 400\text{ V}$, smallest possible PWM frequency, $f_A \geq 3\text{ Hz}$, $\vartheta_{amb} = 40\text{ °C}$

Overload current I_{out1}/I_N	Overload time t_1	Base load current I_{out2}/I_N	Required base load time t_2
200%	3 s	50%	7 s
200%	3 s	100%	17 s
150%	60 s	100%	60 s
150%	60 s	50%	30 s

This table applies to size 5 MDX9.A-0750-... inverters:

Overload capacity at $V_{line} = 400\text{ V}$, smallest possible PWM frequency, $f_A \geq 3\text{ Hz}$, $\vartheta_{amb} = 40\text{ °C}$

Overload current I_{out1}/I_N	Overload time t_1	Base load current I_{out2}/I_N	Required base load time t_2
200%	3 s	50%	7 s
200%	3 s	100%	17 s
150%	60 s	25%	60 s

This table applies to size 7 inverters (up to MDX91A-2500-.. inverters):

Overload capacity at $V_{line} = 400\text{ V}$, smallest possible PWM frequency, $f_A \geq 3\text{ Hz}$, $\vartheta_{amb} = 40\text{ °C}$

Overload current $I_{out\ 1}/I_N$	Overload time t_1	Base load current $I_{out\ 2}/I_N$	Required base load time t_2
150%	60 s	50%	60 s

This table applies to size 7 MDX91A-3000-.. inverters and to size 8:

Overload capacity at $V_{line} = 400\text{ V}$, smallest possible PWM frequency, $f_A \geq 3\text{ Hz}$, $\vartheta_{amb} = 40\text{ °C}$

Overload current $I_{out\ 1}/I_N$	Overload time t_1	Base load current $I_{out\ 2}/I_N$	Required base load time t_2
150%	30 s	50%	150 s


3.6.2 Derating

Due to the following operating and ambient conditions, a reduction of the output current may be necessary.

Derating due to the rotary field frequency

The specified nominal output current I_N of the inverter is the effective value. The increased load on the power semiconductors has to be considered especially for slow rotating fields and rotating fields at standstill. In case of a rotating field at standstill, direct current that can correspond to the peak value of the sine current depending on the phase position is flowing.

It is particularly important to consider output frequencies $f_A < 3$ Hz.



[1] Continuous output current at the smallest possible PWM frequency

[2] Time-limited overload current

Derating due to the installation altitude

SEW-EURODRIVE frequency inverters are designed for overvoltage category III and for altitudes up to 2000 m according to EN 61800-5-1. The air pressure and the air density decrease depending on the installation altitude. This leads to a reduced cooling capacity and to a reduced electrical isolation effect of the air.

Up to $h < 1000$ m: without restrictions.

The following restrictions apply to heights ≥ 1000 m:

- From 1000 m to max. 3800 m: I_N reduction by 1% per 100 m
- From 2000 m to max. 3800 m: To maintain protective separation and the air gaps and creepage distances according to EN 61800-5-1, you have to connect an overvoltage protection device in order to reduce the overvoltages from category III to category II.

Derating due to the line voltage and temperature

Derating depending on the line voltage V_{line} and the ambient temperature T :

Inverter	f_{PWM}	$V_{line}: 3 \times 400 \text{ V}$	$V_{line}: 3 \times 500 \text{ V}$
		Continuous current I_{cont}	
Size 1	4 kHz	$I_{duration}/I_N = 125\% - (T - 40^\circ\text{C}) \times 2.5\%$	$I_{duration}/I_N = 114\% - (T - 40^\circ\text{C}) \times 2.3\%$
	8 kHz	$I_{duration}/I_N = 94\% - (T - 40^\circ\text{C}) \times 2.15\%$	$I_{duration}/I_N = 81\% - (T - 40^\circ\text{C}) \times 1.85\%$
	16 kHz	$I_{duration}/I_N = 63\% - (T - 40^\circ\text{C}) \times 1.5\%$	$I_{duration}/I_N = 50\% - (T - 40^\circ\text{C}) \times 1.7\%$
Size 2	4 kHz	$I_{duration}/I_N = 132\% - (T - 40^\circ\text{C}) \times 2.65\%$	$I_{duration}/I_N = 120\% - (T - 40^\circ\text{C}) \times 2.45\%$
	8 kHz	$I_{duration}/I_N = 99\% - (T - 40^\circ\text{C}) \times 2.25\%$	$I_{duration}/I_N = 86\% - (T - 40^\circ\text{C}) \times 2\%$
	16 kHz	$I_{duration}/I_N = 66\% - (T - 40^\circ\text{C}) \times 1.6\%$	$I_{duration}/I_N = 53\% - (T - 40^\circ\text{C}) \times 1.8\%$
Size 3	4 kHz	$I_{duration}/I_N = 128\% - (T - 40^\circ\text{C}) \times 2.55\%$	$I_{duration}/I_N = 116\% - (T - 40^\circ\text{C}) \times 2.35\%$
	8 kHz	$I_{duration}/I_N = 96\% - (T - 40^\circ\text{C}) \times 2.2\%$	$I_{duration}/I_N = 83\% - (T - 40^\circ\text{C}) \times 1.9\%$
	16 kHz	$I_{duration}/I_N = 64\% - (T - 40^\circ\text{C}) \times 1.55\%$	$I_{duration}/I_N = 51\% - (T - 40^\circ\text{C}) \times 1.7\%$
Size 4	4 kHz	$I_{duration}/I_N = 133\% - (T - 40^\circ\text{C}) \times 2.65\%$	$I_{duration}/I_N = 121\% - (T - 40^\circ\text{C}) \times 2.45\%$
	8 kHz	$I_{duration}/I_N = 100\% - (T - 40^\circ\text{C}) \times 2.25\%$	$I_{duration}/I_N = 87\% - (T - 40^\circ\text{C}) \times 2\%$
	16 kHz	$I_{duration}/I_N = 67\% - (T - 40^\circ\text{C}) \times 1.6\%$	$I_{duration}/I_N = 53\% - (T - 40^\circ\text{C}) \times 1.8\%$
Size 5	4 kHz	$I_{duration}/I_N = 121\% - (T - 40^\circ\text{C}) \times 2.4\%$	$I_{duration}/I_N = 110\% - (T - 40^\circ\text{C}) \times 2.25\%$
	8 kHz	$I_{duration}/I_N = 91\% - (T - 40^\circ\text{C}) \times 2.05\%$	$I_{duration}/I_N = 79\% - (T - 40^\circ\text{C}) \times 1.85\%$
	16 kHz	$I_{duration}/I_N = 51\% - (T - 40^\circ\text{C}) \times 1.6\%$	$I_{duration}/I_N = 41\% - (T - 40^\circ\text{C}) \times 1.55\%$
Size 6	4 kHz	$I_{duration}/I_N = 119\% - (T - 40^\circ\text{C}) \times 2.4\%$	$I_{duration}/I_N = 108\% - (T - 40^\circ\text{C}) \times 2.2\%$
	8 kHz	$I_{duration}/I_N = 89\% - (T - 40^\circ\text{C}) \times 2\%$	$I_{duration}/I_N = 77\% - (T - 40^\circ\text{C}) \times 1.75\%$
	16 kHz	$I_{duration}/I_N = 59\% - (T - 40^\circ\text{C}) \times 1.4\%$	$I_{duration}/I_N = 48\% - (T - 40^\circ\text{C}) \times 1.65\%$
Size 7 MDX91A-1770 – 2200-...-5.3-..	4 kHz	$I_{duration}/I_N = 114\% - (T - 40^\circ\text{C}) \times 2.7\%$	$I_{duration}/I_N = 103\% - (T - 40^\circ\text{C}) \times 2.5\%$
	8 kHz	$I_{duration}/I_N = 80\% - (T - 40^\circ\text{C}) \times 2.25\%$	$I_{duration}/I_N = 72\% - (T - 40^\circ\text{C}) \times 2.05\%$
Size 7 MDX91A-2500-....-5.3-..	2.5 kHz	$I_{duration}/I_N = 120\% - (T - 40^\circ\text{C}) \times 2.45\%$	$I_{duration}/I_N = 109\% - (T - 40^\circ\text{C}) \times 2.25\%$
	4 kHz	$I_{duration}/I_N = 104\% - (T - 40^\circ\text{C}) \times 2.25\%$	$I_{duration}/I_N = 95\% - (T - 40^\circ\text{C}) \times 2.1\%$
	8 kHz	$I_{duration}/I_N = 72\% - (T - 40^\circ\text{C}) \times 1.85\%$	$I_{duration}/I_N = 65\% - (T - 40^\circ\text{C}) \times 1.7\%$
Size 7 MDX91A-3000-....-5.3-..	2.5 kHz	$I_{duration}/I_N = 100\% - (T - 40^\circ\text{C}) \times 2.05\%$	$I_{duration}/I_N = 91\% - (T - 40^\circ\text{C}) \times 1.9\%$
	4 kHz	$I_{duration}/I_N = 87\% - (T - 40^\circ\text{C}) \times 1.9\%$	$I_{duration}/I_N = 79\% - (T - 40^\circ\text{C}) \times 1.75\%$
	8 kHz	$I_{duration}/I_N = 60\% - (T - 40^\circ\text{C}) \times 1.55\%$	$I_{duration}/I_N = 54\% - (T - 40^\circ\text{C}) \times 1.4\%$

Inverter	f_{PWM}	$V_{line}: 3 \times 230 \text{ V}$
		Continuous current I_{cont}
Size 2	4 kHz	$I_{duration}/I_N = 132\% - (T - 40^\circ\text{C}) \times 2.65\%$
	8 kHz	$I_{duration}/I_N = 99\% - (T - 40^\circ\text{C}) \times 2.25\%$
	16 kHz	$I_{duration}/I_N = 66\% - (T - 40^\circ\text{C}) \times 1.6\%$
Size 3	4 kHz	$I_{duration}/I_N = 128\% - (T - 40^\circ\text{C}) \times 2.55\%$
	8 kHz	$I_{duration}/I_N = 96\% - (T - 40^\circ\text{C}) \times 2.2\%$
	16 kHz	$I_{duration}/I_N = 64\% - (T - 40^\circ\text{C}) \times 1.55\%$
Size 4	4 kHz	$I_{duration}/I_N = 133\% - (T - 40^\circ\text{C}) \times 2.65\%$
	8 kHz	$I_{duration}/I_N = 100\% - (T - 40^\circ\text{C}) \times 2.25\%$
	16 kHz	$I_{duration}/I_N = 67\% - (T - 40^\circ\text{C}) \times 1.6\%$
Size 5	4 kHz	$I_{duration}/I_N = 121\% - (T - 40^\circ\text{C}) \times 2.4\%$
	8 kHz	$I_{duration}/I_N = 91\% - (T - 40^\circ\text{C}) \times 2.05\%$
	16 kHz	$I_{duration}/I_N = 51\% - (T - 40^\circ\text{C}) \times 1.6\%$
Size 6	4 kHz	$I_{duration}/I_N = 119\% - (T - 40^\circ\text{C}) \times 2.4\%$
	8 kHz	$I_{duration}/I_N = 89\% - (T - 40^\circ\text{C}) \times 2\%$
	16 kHz	$I_{duration}/I_N = 59\% - (T - 40^\circ\text{C}) \times 1.4\%$

3.7 Braking resistor selection

3.7.1 Tables of braking resistors

The following braking resistors are intended for use with MOVIDRIVE® system/technology. The technical data applies within a temperature range of -20 °C to +40 °C.

Information on ambient temperature

For ambient temperatures above +40 °C, the continuous power must be reduced by 4% for every 10 K. The tripping current must be reduced by 2% for every 10 K. Do not exceed a maximum ambient temperature of 80 °C.

Braking resistors

Braking resistor type BW..		Unit	BW120-001	BW100-001	BW100-002	BW100-002/M	BW100-006-T
Part number			18176011	08281718	08281653	25664514	18204198
Peak braking power		kW		6.9		9.4	6.9
Continuous braking power	100% cdf	kW	0.03	0.1	0.2	0.15	0.6
	50% cdf	kW	0.06	0.15	0.3	0.27	1.1
	25% cdf	kW	0.1	0.3	0.6	0.45	1.9
	12% cdf	kW	0.18	0.5	1	0.75	3.6
	6% cdf	kW	0.3	0.9	1.8	1.23	5.7
Load-bearing capacity		Observe the regenerative power limit of the inverter. (See chapter "Technical data – Basic device": Peak power brake chopper 200% × apparent output power × 0.9)					
Resistance R_{BW}		Ω	117	100	100 ± 10%		
Tripping current I_{trip}		A	-	0.8	1	1.2	2.4
Design			PTC submounting resistor	Flat-type resistor		Submounting resistor in flat design	Wire resistor

Braking resistor type BW..		Unit	BW047-010-T	BW147-T	BW247-T	BW027-016-T	BW027-024-T	BW027-042-T	
Part number			17983207	18201342	18200842	17983215	17983231	19155301	
Peak braking power		kW	14.6			25.4			
Continuous braking power	100% cdf	kW	1	1.2	2	1.6	2.4	4.2	
Load-bearing capacity	50% cdf	kW	1.8	2.20	3.6	2.9	4.3	7.6	
	25% cdf	kW	3.2	3.80	6.4	5.1	7.7	13.3	
	12% cdf	kW	6	7.20	12.0	9.6	14.4	23.9	
	6% cdf	kW	9.5	11.40	14.6	15.2	22.8	25.4	
			Observe the regenerative power limit of the inverter. (See chapter "Technical data – Basic device": Peak power brake chopper 200% × apparent output power × 0.9)						
Resistance R _{BW}		Ω	47 ± 10%			27 ± 10%			
Tripping current I _{trip}		A	4.6	5.1	6.5	7.7	9.4	12.5	
Design			Wire resistor						Frame resistor
Braking resistor type BW..		Unit	BW015-016		BW015-042-T	BW015-075-T		BW915-T	
Part number			17983258		19155328	19155271		18204139	
Peak braking power		kW	45.7						
Continuous braking power	100% cdf	kW	1.6		4.2	7.5		16	

Braking resistor type BW..		Unit	BW015-016	BW015-042-T	BW015-075-T	BW915-T
Load-bearing capacity	50% cdf	kW	2.9	7.6	12.8	27.2
	25% cdf	kW	5.1	13.3	22.5	45.7
	12% cdf	kW	9.6	23.9	33.8	45.7
	6% cdf	kW	15.2	41.8	45.7	45.7
	Observe the regenerative power limit of the inverter. (See chapter "Technical data – Basic device": Peak power brake chopper 200% × apparent output power × 0.9)					
Resistance R_{BW}		Ω	15 ± 10%			
Tripping current I_{trip}		A	10.3	46.7	22.4	32.7
Design			Wire resistor	Frame resistor	Grid resistor mounting position 1	

Braking resistor type BW..		Unit	BW010-024	BW010-050-T	BW010-108-T
Part number			17983266	17983274	19155298
Peak braking power		kW	57.2		
Continuous braking power	100% cdf	kW	2.4	5	10.8
Load-bearing capacity	50% cdf	kW	4.3	8.5	18.4
	25% cdf	kW	7.7	15.0	32.4
	12% cdf	kW	14.4	22.5	48.6
	6% cdf	kW	22.8	38.0	57.2
	Observe the regenerative power limit of the inverter. (See chapter "Technical data – Basic device": Peak power brake chopper 200% × apparent output power × 0.9)				
Resistance R_{BW}		Ω	10 ± 10%		
Tripping current I_{trip}		A	15.5	22.4	32.9
Design			Wire resistor	Grid resistor mounting position 1	

Braking resistor type BW..		Unit	BW006-025-01	BW006-050-01	BW106-T	BW206-T
Part number			18200117	18200125	18200834	18204120
Peak braking power		kW	114.3			
Continuous braking power	100% cdf	kW	2.5	5	13.5	18
Load-bearing capacity	50% cdf	kW	4.3	8.5	23.0	30.6
	25% cdf	kW	7.5	15.0	40.5	54.0
	12% cdf	kW	11.3	22.5	60.8	81.0
	6% cdf	kW	19.0	38.0	102.6	114.3
			Observe the regenerative power limit of the inverter. (See chapter "Technical data – Basic device": Peak power brake chopper 200% × apparent output power × 0.9)			
Resistance R _{BW}		Ω	6 ± 10%			
Tripping current I _{trip}		A	20.4	28.9	47.4	54.8
Design			Grid resistor mounting position 1			
Braking resistor type BW..		Unit	BW005-070	BW005-170-T	BW004-050-01	BW004-070-01
Part number			17983282	17983290	18200133	17967678
Peak braking power		kW	146		190.6	
Continuous braking power	100% cdf	kW	7	17	5	7
Load-bearing capacity	50% cdf	kW	11.9	28.9	8.5	11.9
	25% cdf	kW	21.0	51.0	15.0	21.0
	12% cdf	kW	31.5	76.5	22.5	31.5
	6% cdf	kW	53.2	129.2	38.0	53.2
			Observe the regenerative power limit of the inverter. (See chapter "Technical data – Basic device": Peak power brake chopper 200% × apparent output power × 0.9)			
Resistance R _{BW}		Ω	4.7 ± 10%		3.6 ± 10%	
Tripping current I _{rin}		A	38.6	60.1	32.6	38.6

Braking resistor type BW..	Unit	BW005-070	BW005-170-T	BW004-050-01	BW004-070-01
Design		Grid resistor mounting position 1			

Braking resistor type BW..	Unit	BW003-420-T	BW002-070	BW1.0-170
Part number		13302345	17983304	17985455
Peak braking power	kW	274.4	298.3	686
Continuous braking power	100% cdf kW	42	7	17
Load-bearing capacity	50% cdf kW	71.4	11.9	28.9
	25% cdf kW	126.0	21.0	51.0
	12% cdf kW	189.0	31.5	76.5
	6% cdf kW	274.4	53.2	129.2
	Observe the regenerative power limit of the inverter. (See chapter "Technical data – Basic device": Peak power brake chopper 200% × apparent output power × 0.9)			
Resistance R_{BW}	Ω	2.5 ± 10%	2.3 ± 10%	1 ± 10%
Tripping current I_{trip}	A	135.1	55.2	130.4
Design		Grid resistor mounting position 2	Grid resistor mounting position 1	Grid resistor mounting position 2

3.7.2 Selection criteria

The braking resistor is selected in the SEW-Workbench. The necessary selection parameters for the braking resistor are calculated during the project planning procedure. Depending on these selection parameters, a braking resistor is selected from the table.

The following selection parameters are the basis for selecting the braking resistor.

Continuous braking power

The minimum required continuous braking power (braking power at 100% cdf) of the braking resistor for load cycles can be calculated using the relative cyclic duration factor cdf and the overload factor k.

If the cyclic duration factor cdf is unknown, it can be calculated from the cycle duration t_{tot} and the braking time t_B using the following formula:

$$cdf = \frac{t_B}{t_{tot}} \times 100 \%$$

9007219434171531

ED Cyclic duration factor
 t_B Braking time
 t_{tot} Cycle duration

INFORMATION



The cycle duration must not exceed 120 s.

The overload factor k can be determined using the diagrams in chapter "Overload factor k" (→ 132) and the cyclic duration factor ED (cdf).

The value of the average braking power P_B is taken from the project planning data of the application.

$$P_B = \frac{\sum_{i=1}^n P_i}{\sum_{i=1}^n t_i}$$

9007219434177547

P_B Average braking power
 P_i Braking power section i
 t_i Braking time section i

The minimum required braking power at 100% cdf is calculated using the following formula:

$$P_{100\%ED} = \frac{P_B}{k}$$


20179441035

$P_{100\%cdf}$ Braking power at 100% cdf
 P_B Average braking power
 k Overload factor

The braking power required by the application at 100% cdf must be smaller than or equal to the typical braking power at 100% cdf (continuous braking power) of the braking resistor.

Overload factor k

Flatpack resistors




X Cyclic duration factor in % (cdf)
Y Overload factor k (OF)

20532478731

26860791/EN – 07/2022

cdf in %	1	3	6	15	25	40	60	80	100
OF	35	15	9	4.3	3	2	1.4	1.2	1


Wire resistors, frame resistors



X Cyclic duration factor in % (cdf)
Y Overload factor k (OF)

cdf in %	1	3	6	15	25	40	60	80	100
OF	30	15	9.5	5	3.2	2.2	1.5	1.12	1

Grid resistors



X Cyclic duration factor in % (cdf)
Y Overload factor k (OF)

26860791/EN – 07/2022

cdf in %	1	3	6	15	25	40	60	80	100
OF	20	12	7.6	4	3	2.2	1.5	1.12	1

Peak braking power

The maximum peak braking power that can be achieved is specified by the resistance value and the DC link voltage. It is calculated as follows:

$$P_{\max} = \frac{U_{ZK \max}^2}{R \times 1.4}$$

P_{\max} Maximum peak braking power that the braking resistor can absorb

V_{DCL_max} Maximum DC link voltage:

- 650 V for MDX9.A-....-2.3-4-...
- 980 V for MDX9.A-....-5.3-4-...

R Braking resistance value

The maximum peak braking power required by the application is calculated from the regenerative parts within a cycle.

The peak braking power required by the application must be lower than the maximum peak braking power that can be achieved and absorbed by the braking resistor.

The peak braking power for each braking resistor is specified in the chapter "Braking resistors".

Current-carrying capacity of the brake chopper

The resistance value of the braking resistor R_{BR} must not be lower than the minimum permitted braking resistance R_{BRmin} , see the chapter "Technical data of basic device". This ensures that the brake chopper is not damaged.

$$R_{BR} \geq R_{BRmin}$$

The continuous braking power toward the braking resistor must not exceed the apparent output power of the inverter.

3.7.3 Calculation example

Given:	<p>Peak braking power: 13 kW</p> <p>Average braking power: 6 kW</p> <p>Braking time: 7 s</p> <p>Cycle duration: 28 s</p> <p>Inverter used: MDX90A-0095-5-3-4-S00</p>
Required:	BW.. braking resistor
Calculation:	<p>1) Determine the cyclic duration factor</p> <p>Cyclic duration factor cdf = braking time/cycle duration</p> <p>Cyclic duration factor cdf = $(7 \text{ s}/28 \text{ s}) \times 100\% = 25\%$</p> <p>When selecting the braking resistor, observe the assignment of inverter and braking resistor, see chapter "Technical data and assignment to an inverter" (→ 139).</p> <p>2) Determine the overload capacity</p> <p>Determine the overload factor, e.g. for a wire resistor at a cyclic duration factor cdf of 25% from the respective diagram.</p> <p>Overload factor $k = 3.2$</p> <p>3) Calculate the braking power at 100% cdf</p> <p>Braking power 100% cdf = average braking power/overload factor</p> <p>Braking power 100% cdf = $6 \text{ kW}/3.2 = 1.88 \text{ kW}$</p> <p>The braking power of the braking resistor at 100% cdf must be $\geq 1.88 \text{ kW}$.</p> <p>4) Select the braking resistor</p> <p>The minimum permitted braking resistance value is $= 47 \text{ } \Omega$ for the MDX90A-0095-5-3-4-S00 inverter that is used, see chapter "Technical data and assignment to an inverter" (→ 139).</p> <p>Selected braking resistor: BW247-T.</p> <p>Resistance value $R_{BW} = 47 \text{ } \Omega$</p> <p>Peak braking power: 14.3 kW, see chapter "Tables of braking resistors" (→ 129).</p> <p>Current-carrying capacity at 100% cdf: 2 kW</p>

3.7.4 Supply cable for braking resistor

Use only shielded or twisted cables.

The cable cross section depends on the tripping current I_F .

The nominal voltage of the cable must be at least $U_0/U = 450 \text{ V}/750 \text{ V}$.

The maximum permitted cable length between the inverter/power supply module and the braking resistor is 100 m.

When the braking resistor is connected to its protection device, the shield of the supply cable must be routed via an additional shield terminal.

3.7.5 Protection against thermal overload of the braking resistor

To avoid thermal damage of the braking resistor as well as subsequent damage, the braking resistor has to be thermally monitored. SEW-EURODRIVE suggests the following options:

- Integrated temperature switch –T

Braking resistors with the label –T are equipped with an integrated temperature switch. The temperature switch is thermally coupled to the braking resistor and switches an NC contact in case of overtemperature of the braking resistor. The braking resistor-inverter connection is not interrupted. In case of thermal overload, the regenerative operation has to be terminated. SEW-EURODRIVE recommends shielding the connection cable of the temperature switch.

- Thermal overload relay

A thermal overload relay is installed in the control cabinet, connected to the supply cable to the braking resistor and set to the tripping current of the braking resistor. If the measured mean current exceeds the tripping current, an NC contact switches and reports an overload of the braking resistor. The braking resistor-inverter connection is not interrupted. In case of thermal overload, the regenerative operation has to be terminated.

Wiring diagrams for the situations described above can be found in the operating instructions in chapter "Protection of braking resistor against thermal overload".

3.7.6 Parallel connection of braking resistors

It is permitted to connect several identical braking resistors in parallel. The following applies:

- The power connections of the braking resistors must be connected to +R and -R in parallel.
- Each braking resistor requires separate protection against thermal overload.
- The signal contacts (NC contacts) of the protection devices must be connected in series.

3.7.7 Technical data

BW.../BW...-T braking resistors

General

The BW.../BW...-T braking resistors are adapted to the technical characteristics of the inverter.

Braking resistors with different continuous and peak braking powers are available.

The braking resistors can be protected against overload and overtemperature by the customer when a thermal overload relay is used. The tripping current is set to the value I_F ; for this, see the following tables "Technical data and assignment to an inverter".

A PTC resistor protects itself (reversible) against regenerative overload by changing abruptly to high resistance and no longer consuming any more energy. The inverter then switches off and signals an "overvoltage" fault.

A flat-type resistor has internal thermal protection (fuse cannot be replaced) that interrupts the current circuit in the event of overload. The configuration guidelines and the documented assignments of the drive inverter and braking resistor must be adhered to.

INFORMATION



Use of protection devices.

Use only the protection devices listed in the following section:

- Internal temperature switch T
- External bimetallic relay

→ See also the chapter "Protection of the braking resistor against thermal overload".

UL and cURus approval

The listed braking resistors have a cURus approval independent of the inverter.

Technical data and assignment to an inverter

Technical data

Braking resistor	Unit	BW120-001	BW100-002/M	BW100-001	BW100-002	BW100-006-T
Part number		18176011	25664514	08281718	08281653	18204198
Current-carrying capacity at 100% cdf	kW	0.03	0.15	0.1	0.2	0.6
Resistance value R _{BW}	Ω	117	100	100 ± 10%		
Tripping current I _{trip}	A	-	1.2	0.8	1	2.4
Design		PTC sub-mounting resistor	Submounting resistor in flat design	Flat-type resistor		Wire resistor
Power connections		Single conductors				Ceramic terminal 2.5 mm ²
Wire length	mm	170	300	510		-
Cable cross section	mm ²	0.5		1.5		-
Tightening torque	Nm	-				0.5
PE connection		-				M4
PE tightening torque	Nm	-				1.8
Degree of protection in accordance with EN 60529		IP20	IP40	IP54		IP20
Ambient temperature ϑ _{amb}		-20 °C to +40 °C (reduction 4% P _N /10K to +60 °C)				
Mass	kg	0.95	1.4	0.3	0.6	3

Assignment

The assignment considers the maximum peak braking power of the inverter.

Braking resistor	BW120-001	BW100-002/M	BW100-001	BW100-002	BW100-006-T
MDX9.A-....-5.3-...	0020		0020		
	0025		0025		
	0032		0032		
	0040		0040		

Technical data

Braking resistor	Unit	BW047-010-T	BW147-T	BW247-T
Part number		17983207	18201342	18200842
Current-carrying capacity at 100% cdf	kW	1	1.2	2
Resistance value R_{BW}	Ω	47 \pm 10%		
Tripping current I_{trip}	A	4.6	5.1	6.5
Design		Wire resistor		
Power connections		Ceramic terminal 2.5 mm ²		
Tightening torque	Nm	0.5		
PE connection		M4		
PE tightening torque	Nm	1.8		
Degree of protection		IP20		
Ambient temperature ϑ_{amb}		-20 °C to +40 °C		
Mass	kg	4	4.9	6.7

Assignment

The assignment considers the maximum peak braking power of the inverter.

Braking resistor	BW047-010-T	BW147-T	BW247-T
MDX9.A-....-5.3-...	0055		
	0070		
	0095		

Technical data

Braking resistor	Unit	BW027-016-T	BW027-024-T	BW027-042-T
Part number		17983215	17983231	19155301
Current-carrying capacity at 100% cdf	kW	1.6	2.4	4.2
Resistance value R_{BW}	Ω	$27 \pm 10\%$		
Tripping current I_{trip}	A	7.7	9.4	12.5
Design		Wire resistor		Frame resistor
Power connections		Ceramic terminal 2.5 mm ²		
Tightening torque	Nm	0.5		
PE connection		M4		M5
PE tightening torque	Nm	1.8		2.5
Degree of protection		IP20		
Ambient temperature ϑ_{amb}		$-20\text{ °C to }+40\text{ °C}$		
Mass	kg	5.8	8	10

Assignment

The assignment considers the maximum peak braking power of the inverter.

Braking resistor	BW027-016-T	BW027-024-T	BW027-042-T
MDX9.A-....-5.3-...	0125 0160		
MDX9.A-....-2.3-...	0070 0093		

Technical data

Braking resistor	Unit	BW015-016	BW015-042-T	BW015-075-T	BW915-T
Part number		17983258	19155328	19155271	18204139
Current-carrying capacity at 100% cdf	kW	1.6	4.2	7.5	16
Resistance value R _{BW}	Ω	15 ± 10%			
Tripping current I _{trip}	A	10.3	16.7	22.4	32.7
Design		Wire resistor	Frame resistor	Grid resistor mounting position 1	
Power connections		Ceramic terminal 2.5 mm ²	Ceramic terminal 4 mm ²	M8 stud	
Tightening torque	Nm	0.5	0.9	6	
PE connection		M4	M5	M6 stud	
PE tightening torque	Nm	1.8	2.5	3	
Degree of protection		IP20			
Ambient temperature ϑ _{amb}		-20 °C to +40 °C			
Mass	kg	5.8	10	12	32

Assignment

The assignment considers the maximum peak braking power of the inverter.

Braking resistor	BW015-016	BW015-042-T	BW015-075-T	BW915-T
MDX9.A-....-5.3-...	0240 0320 0620 (Parallel connection of 2 braking resistors) 0750 (Parallel connection of 2 braking resistors)			
MDX9.A-....-2.3-...	0140 0213 (Parallel connection of 2 braking resistors) 0290 (Parallel connection of 2 braking resistors)			

Technical data

Braking resistor	Unit	BW010-024	BW010-050-T	BW010-108-T
Part number		17983266	17983274	19155298
Current-carrying capacity at 100% cdf	kW	2.4	5	10.8
Resistance value R _{BW}	Ω	10 ± 10%		
Tripping current I _{trip}	A	15.5	22.4	32.9
Design		Wire resistor	Grid resistor mounting position 1	
Power connections		Ceramic terminal 2.5 mm ²	M8 stud	
Tightening torque	Nm	0.5	6	
PE connection		M4 stud	M6 stud	
PE tightening torque	Nm	1.8	3	
Degree of protection		IP20		
Ambient temperature ϑ _{amb}		-20 °C to +40 °C		
Mass	kg	8	11	17.5

Assignment

The assignment considers the maximum peak braking power of the inverter.

Braking resistor	BW010-024	BW010-050-T	BW010-108-T
MDX9.A-....-5.3-...	0460 0910 (Parallel connection of 2 braking resistors) 1130 (Parallel connection of 2 braking resistors)		
MDX9.A-....-2.3-...	0213 0290 0420 (Parallel connection of 2 braking resistors)		

Technical data

Braking resistor	Unit	BW006-025-01 ¹⁾	BW006-050-01 ¹⁾	BW106-T	BW206-T
Part number		18200117	18200125	18200834	18204120
Current-carrying capacity at 100% cdf	kW	2.5	5	13.5	18
Resistance value R_{BW}	Ω	$6 \pm 10\%$			
Tripping current I_{trip}	A	20.4	28.9	47.4	54.8
Design		Grid resistor mounting position 1			
Power connections		M8 stud			
Tightening torque	Nm	6			
PE connection		M6 stud			
PE tightening torque	Nm	3			
Degree of protection		IP20			
Ambient temperature ϑ_{amb}		$-25\text{ °C to }+40\text{ °C}$			
Mass	kg	7.5	12	30	40

1) Braking resistor has a 1 Ω tap

Assignment

The assignment considers the maximum peak braking power of the inverter.

Braking resistor	BW006-025-01	BW006-050-01	BW106-T	BW206-T
MDX9.A-....-5.3-...	0620 0750 1490 (Parallel connection of 2 braking resistors)			
MDX9.A-....-2.3-...	0570 (Parallel connection of 2 braking resistors)			

Technical data

Braking resistor	Unit	BW005-070	BW005-170-T	BW004-050-01	BW004-070-01
Part number		17983282	17983290	18200133	17967678
Current-carrying capacity at 100% cdf	kW	7	17	5	7
Resistance value R_{BW}	Ω	$4.7 \pm 10\%$		$3.6 \pm 10\%$	
Tripping current I_{trip}	A	38.6	60.1	32.6	38.6
Design		Grid resistor mounting position 1			
Power connections		M8 stud			
Tightening torque	Nm	6			
PE connection		M6 stud			
PE tightening torque	Nm	3			
Degree of protection		IP20			
Ambient temperature ϑ_{amb}		$-20\text{ °C to }+40\text{ °C}$			
Mass	kg	13	33	13	

Assignment

The assignment considers the maximum peak braking power of the inverter.

Braking resistor	BW005-070	BW005-170-T	BW004-050-01	BW004-070-01
MDX9.A-....-5.3-...	0910 1130 1770 (Parallel connection of 2 braking resistors) 2200 (Parallel connection of 2 braking resistors) 2500 (Parallel connection of 2 braking resistors) 3000 (Parallel connection of 2 braking resistors)		1490	
MDX9.A-....-2.3-...	0420 0840 (Parallel connection of 2 braking resistors) 1080 (Parallel connection of 2 braking resistors)		0570	

Technical data

Braking resistor	Unit	BW003-420-T	BW002-070
Part number		13302345	17983304
Current-carrying capacity at 100% cdf	kW	42	7
Resistance value R_{BW}	Ω	$2.5 \pm 10\%$	$2.3 \pm 10\%$
Tripping current I_{trip}	A	135.1	55.2
Design		Grid resistor mounting position 2	Grid resistor mounting position 1
Power connections		M12 stud	M8 stud
Tightening torque	Nm	15.5	6
PE connection		M10 stud	M6 stud
PE tightening torque	Nm	10	3
Degree of protection		IP20	
Ambient temperature ϑ_{amb}		-20 °C to +40 °C	
Mass	kg	93	33

Assignment

The assignment considers the maximum peak braking power of the inverter.

Braking resistor	BW003-420-T	BW002-070
MDX9.A-....-5.3-...	1770	
	2200	
	2500	
	3000	
	3800 (Parallel connection of 2 braking resistors)	
	4700 (Parallel connection of 2 braking resistors)	
	5880 (Parallel connection of 2 braking resistors)	
MDX9.A-....-2.3-...	0840	
	1080	

Technical data

Braking resistor	Unit	BW1.0-170
Part number		17985455
Current-carrying capacity at 100% cdf	kW	17
Resistance value R_{BW}	Ω	$1 \pm 10\%$
Tripping current I_{trip}	A	130.4
Design		Grid resistor mounting position 2
Power connections		M12 stud
Tightening torque	Nm	15.5
PE connection		M10 stud
PE tightening torque	Nm	10
Degree of protection		IP20
Ambient temperature ϑ_{amb}		-25 °C to +40 °C
Mass	kg	45

Assignment

The assignment considers the maximum peak braking power of the inverter.


Braking resistor	BW1.0-170
MDX9.A-....-5.3-...	3800
	4700
	5880

Technical data BW...-T signal contact

Specifications for BW...-T	Design
Signal contact connection cross section	$1 \times 2.5 \text{ mm}^2$
Tightening torque of the signal contact	1 Nm
Switching capacity signal contact	DC 2 A / DC 24 V (DC11) AC 2 A / AC 230 V (AC11)
Switch contact (NC contact)	According to EN 60730

Dimension sheets and dimensions


Wire resistor



9007218129604875

Braking resistor	Main dimensions in mm			Mounting dimensions in mm				Cable gland
	A	B	C	a	b	d	x	
BW100-006-T	549	92	125	430	80	6.5	8	M25 + M12
BW047-010-T	749	92	125	630	80	6.5	8	M25 + M12
BW147-T	549	185	125	430	150	6.5	8	M25 + M12
BW247-T	749	185	125	630	150	6.5	8	M25 + M12
BW027-016-T	649	185	125	530	150	6.5	8	M25 + M12
BW027-024-T	649	275	125	530	240	6.5	8	M25 + M12
BW015-016	649	185	125	530	150	6.5	8	M25
BW010-024	649	275	125	530	240	6.5	8	M25


Grid resistor mounting position 1



18874868747

Braking resistor	Main dimensions in mm			Mounting dimensions in mm				Cable gland
	A	B	C	a	b	d	x	
BW015-075-T	415	500	270	395	380	9	—	—
BW106-T	795	490	270	770	380	10.5	—	—
BW206-T	995	490	270	970	380	10.5	—	—
BW915-T	795	490	270	770	380	10.5	—	—
BW010-050-T	395	490	260	370	380	10.5	—	—
BW010-108-T	525	500	270	505	380	9	—	—
BW004-050-01	395	490	260	370	380	10.5	—	—
BW005-070	395	490	260	370	380	10.5	—	—
BW002-070	395	490	260	370	380	10.5	—	—
BW005-170-T	490	795	270	380	770	10.5	—	—
BW006-025-01	295	490	260	270	380	10.5	—	—
BW006-050-01	395	490	260	370	380	10.5	—	—


Grid resistor mounting position 2



18874876043

Braking resistor	Main dimensions in mm			Mounting dimensions in mm				Cable gland
	A	B	C	a	b	d	x	
BW003-420-T	995	490	710	970	380	10.5	—	—
BW1.0-170	490	795	490	380	770	10.5	—	—


Frame resistor



9007218129614603


Braking resistor	Main dimensions in mm			Mounting dimensions in mm				Cable gland
	A	B	C	a	b	d	x	
BW027-042-T	570	390	180	380	370	6.5	55	M25 + M12
BW015-042-T	570	390	180	380	370	6.5	55	M25 + M12

Flat-type resistor




18874878475

Braking resistor	Main dimensions in mm			Mounting dimensions in mm				Connection length in mm
	A	B	C	a	b	d	x	
BW100-001	110	80	15	98	60	—	—	300
BW100-002	216	80	15	204	60	—	—	300

BW120-001 resistor


Length of connections: 130 mm

BW100-002/M resistor*BS.. touch guard*

A BS.. touch guard is available for braking resistors in flat design.

Touch guard	BS003	BS005
Part number	8131511	813152X
Braking resistor	BW100-001	BW100-002

Dimension drawing of BS...



1455849867

[1] Grommet

[2] Support rail mounting

Type	Main dimensions in mm			Mounting dimensions in mm					Mass in kg
	A	B	C	b	d	e	a	x	
BS-003	60	160	146	125	40	20	6	17.5	0.35
BS-005	60	160	252	125	4	20	6	17.5	0.5

Mounting rail installation

A mounting rail attachment HS001 is available from SEW-EURODRIVE, part number 8221944, for mounting the touch guard on a mounting rail.

3.8 Supply system cables and motor cables

3.8.1 Supply system cable

The supply system cable is generally dimensioned system-specifically and depends on the design of the line connection. Line connection is shown in the chapter "Power connection" (→ 296). Observe the country-specific and system-specific regulations when selecting the cross section of the supply system cable.

Recommended cross section for nominal operation

The cross section of the supply system cables must be dimensioned based on the nominal line current I_{line} .

SEW-EURODRIVE suggests the cable cross sections listed in the table. Cables with these cross sections can be used if the following conditions are met:

- The single-core cables are made of copper with PVC insulation.
- The cables are routed in cable ducts according to IEC 60204-1 installation type C at an ambient temperature of 40 °C.

MDX9.A-....-5.3-...		0020	0025	0032	0040	0055	0070	0095	0125	0160	0240	0320	0460	0620	0750
Nominal line current AC I_{line}	A	1.9	2.3	2.9	3.6	5	6.3	8.6	11.3	14.4	22	32	42	56	68
Supply system cable L1/L2/L3	mm ²	1.5							2.5		4	6	10	16	25
Fuse/miniature circuit breaker	A	10							16		25	32	50	63	80

MDX9.A-....-2.3-...		0070		0093	0140		0213	0290		0420		0570
Nominal line current AC I_{line}	A	6.4 A		8.4 A	12.4 A		18.9 A	27.4 A		40.8 A		52 A
Supply system cable L1/L2/L3	mm ²	1.5 mm ²			2.5 mm ²			6 mm ²		10 mm ²		16 mm ²
Fuse/miniature circuit breaker	A	10 A			16 A		20 A	32 A		50 A		63 A

INFORMATION



Recommended cross section

The values are only recommendations. They are no substitute for detailed project planning of the cables depending on the concrete application and considering the applicable regulations.

INFORMATION



Securing the supply system cable

Secure the supply system cable with appropriate safety elements.

When selecting the supply system cable, make sure that the selected cross section is in the range of the connectable cross section of the terminals.

3.8.2 Motor cable

Cable length

A maximum motor cable length must not be exceeded when connecting a motor.

The following configuration guidelines must be observed:

- When shielded motor cables are used, a capacitance core/shield of maximum 280 pF/m must not be exceeded.

MDX9.A-...-5.3 With $V_{line} = 3 \times AC 400 V$	0020 – 0040	0055	0070	0095	0125	0160	0240 – 1490	1770 – 2200	2500 – 3000	3800 – 5880
	Maximum motor cable length in m									
	Shielded cable									
PWM frequency	-	-	-	-	-	-	-	-	400	400
2.5 kHz	-	-	-	-	-	-	-	-	400	400
4 kHz	120	200	250	300	300	400	400	400	300	300
8 kHz	80	120	150	250	250	300	300	300	200	-
16 kHz	40	60	100	150	150	200	200	-	-	-

MDX9.A-...-5.3 With $V_{line} = 3 \times AC 400 V$	0020 – 0040	0055	0070	0095	0125	0160	0240 – 1490	1770 – 2200	2500 – 3000	3800 – 5880
	Maximum motor cable length in m									
	Unshielded cable									
PWM frequency	-	-	-	-	-	-	-	-	1200	1200
2.5 kHz	-	-	-	-	-	-	-	-	900	900
4 kHz	360	600	750	900	900	1200	1200	1200	900	900
8 kHz	240	360	450	750	750	900	900	900	600	-
16 kHz	120	180	300	450	450	600	600	-	-	-

MDX9.A-...-5.3 With $V_{line} = 3 \times AC 230 V$	0070	0093	0140	0213 – 0290	0420 – 1080
	Maximum motor cable length in m				
	Shielded cable				
PWM frequency	120	200	250	300	400
4 kHz	120	200	250	300	400
8 kHz	80	120	150	250	300
16 kHz	40	60	100	150	200

INFORMATION



If the use of a residual current device is not mandatory according to the standards, SEW-EURODRIVE recommends not using a residual current device. Leakage currents caused by cable capacitances can lead to false tripping.

Voltage drop

Select the cable cross section of the motor cable so the voltage drop is as small as possible. An excessively high voltage drop means that the full motor torque is not achieved.

3.9 Signal cables

3.9.1 Encoder cables

Connection/encoder	Maximum cable length
HTL encoders ES7C, EG7C, and EK8C	300 m
TTL encoder EK8R	300 m
Standard HTL encoder	200 m
MOVILINK® DDI	200 m
Other encoders	100 m

3.9.2 Digital inputs/outputs and DC 24 V supply

The maximum permitted cable length of the connections on the inputs and outputs and on terminal X6 (STO) is 30 m.

3.9.3 Digital motor integration

The maximum permitted cable length with or without encoder is 200 m.

3.10 EMC-compliant installation according to EN 61800-3

The inverters are designed for use as components for installation in machinery and systems. They comply with the EMC product standard EN 61800-3 "Adjustable-speed electrical drives".

Provided the EMC-compliant installation is observed, the appropriate requirements for a CE marking are met on the basis of the EMC Directive 2014/30/EU.

3.10.1 Interference emission

The cable length must be as short as possible for EMC-compliant installation. SEW-EURODRIVE recommends using low-capacity cables. To comply with limit classes C1 and C2 in accordance with EN 61800-3, take the measures listed in the tables.

Limit class C1

Inverter	Measures		
	On the line side	On the motor side	
	Line filter NF..	Output filter HF.. Output choke HD..	Shielded cables
Sizes 1 – 3	NF..	-	yes

Limit class C2

Inverter	Measures		
	On the line side	On the motor side	
	Line filter NF..	Output filter HF.. Output choke HD..	Shielded cables
Sizes 1 – 3	-	-	yes
Sizes 1 – 7	NF..	-	yes
Sizes 1 – 4	NF..	HD..	no
Sizes 5 – 7	NF..	HD..	no
Sizes 1 – 4	NF..	HF..	no
Sizes 5 – 6	NF..	HF..	no

INFORMATION



No EMC limit values are specified for interference emission in voltage supply systems without a grounded star point (IT systems).

INFORMATION



During startup, "Operation with output filter" must be set if the relevant criteria are met.

INFORMATION



EMC limit values

No EMC limit values are specified for interference emission in voltage supply systems without a grounded star point (IT systems). The effectiveness of filters is severely limited.

3.11 Line components

3.11.1 Line fuses and miniature circuit breakers

Line fuses and miniature circuit breakers are used for protecting the supply system cables. For fusing, use fuses and miniature circuit breakers with the following properties:

Type class	Requirement
Fuses in utilization categories gL, gG	Fusing voltage \geq nominal line voltage
Miniature circuit breaker with characteristics B, C, D	Nominal miniature circuit breaker voltage \geq nominal line voltage
	Nominal currents of the miniature circuit breaker must be 10% higher than the nominal line current of the inverter

Adhere to the country-specific and system-specific regulations when carrying out the fusing. If required, observe the notes in the chapter "UL-compliant installation".

3.11.2 Line contactor

A line contactor is used to separate the inverter from the supply system in the event of an error and to switch the power supply on and off.

For more information on operation with a line contactor, refer to the chapter "Line connection".

INFORMATION



If necessary, use a line contactor in utilization category AC-3 (IEC 158-1) or better. The line contactor must be installed before the line filter and the line choke.

INFORMATION



Observe the information for electrical installation of a line contactor.

3.11.3 NF.. line filters

A line filter reduces interference emission via the supply system cable, which is generated by the inverter. The line filter mainly serves to meet interference voltage limit requirements in the frequency range from 150 kHz to 30 MHz at the line connection. In addition, a line filter dampens the interference from the grid affecting the inverter. The selection of the line filter depends on the nominal line current and the line voltage of the frequency inverter.

Select the line filter type based on the following table.

3.11.4 ND.. line chokes

The main reason for using line chokes is the reduction of grid disturbances that may occur due to harmonic currents. In addition, line chokes improve the overvoltage protection.

For 5 or more 3-phase units, connect a line choke to limit the inrush current.

Select the line choke based on the following table.

3.11.5 Residual current device



▲ WARNING

No protection against electric shock if an incorrect type of residual current device is used.

Severe or fatal injuries.

- The product can cause direct current in the PE conductor. If a residual current device (RCD) or a residual current monitoring device (RCM) is used for protection in the event of a direct or indirect contact, only a type B RCD or RCM is permitted on the supply end of the product.
- If the use of a residual current device is not mandatory according to the standards, SEW-EURODRIVE recommends not using a residual current device.

3.12 Components on the output side

3.12.1 HD.. output chokes

SEW-EURODRIVE recommends using output chokes to suppress interference emission when using unshielded motor cables.

3.12.2 HF.. output filters

Observe the following information when using an output filter:

- Output filters may only be used in inverter operating modes V/f and VFC plus.
- Output filters may be used up to a maximum inverter output frequency of 250 Hz.
- When selecting the output filter, make sure that it is assigned correctly to the inverter.
- Maintain a ventilation clearance of at least 100 mm below and above the output filter. There is no need for a clearance on the side.
- Limit the length of the cable between the inverter and the output filter to the required length. Maximum permitted length:
 - 1 m with unshielded cable
 - 10 m with shielded cable
- An unshielded motor supply cable is sufficient when using an output filter.

For technical data, see chapter "HF.. output filters".

Operating modes of output filters

Output filters can be operated with or without DC link connection. The recommended operation with DC link connection improves the filter effect between the phases and PE. This increases the device utilization.

Observe the following notes:

- Operation with DC link connection
 - Nominal filter current ≥ 65 A: Minimum clock frequency = 8 kHz, this must be set permanently.
- Operation without DC link connection
 - Maximum clock frequency = 8 kHz
 - The maximum shielded motor cable length is 200 m.

Voltage drop

Observe the following voltage drop at the output filter during project planning:

- At 400 V $\leq 6.5\%$
- At 500 V $\leq 5\%$

These values refer to an output frequency of 50 Hz.

Derating

Derating refers to the current dependency of the following operating parameters.

- Operating parameters: Line voltage, clock frequency, ambient temperature
 - The output filters do not require derating beyond that of the inverter if the permitted control modes are observed.
- Operating parameters: Output frequency

150 – 250 Hz

- Nominal filter current ≤ 46 A

Derating: Filter current = $100\% - 0.1\% \times (\text{output frequency} - 150 \text{ Hz})$

- Nominal filter current ≥ 65 A

Derating: Filter current = $100\% - 0.2\% \times (\text{output frequency} - 150 \text{ Hz})$

0 – 20 Hz

- 400 V without/with DC link connection, 500 V without DC link connection:

No derating

- 500 V DC link connection, nominal filter current ≤ 46 A

Derating: Filter current = $70\% + 1.5\% \times \text{output frequency}$ (in the range from 0 to 20 Hz)


- 500 V DC link connection, nominal filter current ≥ 65 A

Derating: Filter current = $10\% + 9\% \times \text{output frequency}$ (in the range from 0 to 10 Hz)

Short-time operation without speed derating (e.g. startup)

- Filter current 100% for 5 min every 60 min permitted

Wiring diagram



- [1] Grid
- [2] Inverter
- [3] Output filter
- [4] Motor

33412335115

3.13 24 V supply voltage selection

The MDX90A-... application inverter requires an external 24 V voltage supply for the electronics.

The MDX91.A-... application inverter has an internal 24 V voltage supply (80 W) that can also be supported externally.

3.13.1 Project planning for 24 V supply power

For dimensioning the 24 V supply voltage, it is necessary to know the power and current consumption of the application inverter.

INFORMATION



Commercially available switched-mode power supplies can reliably switch on the maximum occurring capacities.

3.13.2 Power consumption of the 24 V supply

Tables for the power demand of the 24 V supply depending on the modules in use and on the installed options.

Inverter

Size	Unit	Power consumption without I/O, encoder, motor brake
Sizes 1 – 3	W	20
Size 4		30
Size 5		15
Sizes 6 – 7		20

Cards

Card	Unit	Power consumption without I/O, encoder	Maximum power consumption
CIO21A	W	1.2	6.5
CID21A		0.4	5.2
CES11A		0.8	12.8

Safety cards

Card	Unit	Power consumption without I/O, encoder	Maximum power consumption
CSB21A	W	17.7	17.7
CSS21A			26.4
CSB31A			38.4
CSS31A			38.4
CSA31A			38.4

3.13.3 Project planning example

The following example illustrates the project planning of the 24 V voltage supply for the MDX9.A-0040-5E3-4-.00 application inverter with CES11A multi-encoder card and I/O extension CID21A.

The inverter supplies the DI00 digital input (output stage enable) with voltage.

The motor brake is controlled via DB00. The coil of the brake relay requires DC 100 mA at DC 24 V.

The 4 outputs of the CID21A option are each subject to a load of DC 50 mA.

Power demand of the basic device: 20 W + 1 × motor encoder: 5 W

Power demand of the CES11A option without encoder: 0.8 W

1 × external encoder: 12 W

Power demand of the CID21A option without terminals: 0.4 W

Power demand of the inputs (basic device): 1 × 0.1 W = 0.1 W









Power demand of the brake control at DB00: 24 V × 0.1 A = 2.4 W

Power demand of the binary outputs: 4 × 24 V × 0.05 A = 4.8 W

The total power demand is: 45.6 W


4 Prefabricated cables

4.1 Meaning of the symbols

Symbol	Meaning
	Connection cable: Connector → connector for fixed installation
	Connection cable extension: Connector → connector for fixed installation
	Connection cable: Connector → encoder connection cover for fixed installation
	Connection cable: Connector → encoder connection cover for cable carrier installation
	Connection cable: Connector → connector for cable carrier installation
	Connection cable extension: Connector → connector for cable carrier installation
	Connection cable: Connector → open end for fixed installation
	Connection cable: Connector → open end for cable carrier installation

4.2 Power cables for CM3C.. motors

4.2.1 Overview



18014431390159883

- [1] Motor cable ../SM.. " "
- [2] Motor extension cable ../SM.. " "
- [3] Brakemotor cable ../SB.. for /BK and /BZD brakes " "
- [4] Brakemotor cable ../SB.. for /BZ brakes " "
- [5] Brakemotor extension cable ../SB.. for /BK, /BZD and /BZ brakes " "

4.2.2 Power cables for fixed installation

Cable type	Con- nector type	Thread	Cable cross section	Part number	
				Prefabricated cable	Replacement mating con- nectors ¹⁾
Motor cable	SM11	M23	4 × 1.5 mm ²	28125002	13354698
	SM12		4 × 2.5 mm ²	28125029	13354698
	SM14		4 × 4 mm ²	28125045	13354264
	SMB6	M40	4 × 6 mm ²	28125061	13421778
	SMB10		4 × 10 mm ²	28125096	13421751
	SMB16		4 × 16 mm ²	28125126	13421670
Brakemotor cable BK.. brake ²⁾ or BZ.D	SB11	M23	4 × 1.5 mm ² + 3 × 1 mm ²	28125207	13354698
	SB12		4 × 2.5 mm ² + 3 × 1 mm ²	28125223	13354698
	SB14		4 × 4 mm ² + 3 × 1 mm ²	28125258	13354264
	SBB6	M40	4 × 6 mm ² + 3 × 1.5 mm ²	28125274	13421778
	SBB10		4 × 10 mm ² + 3 × 1.5 mm ²	28125290	13421751
	SBB16		4 × 16 mm ² + 3 × 1.5 mm ²	28125312	13421670
Brakemotor cable BZ.. brake	SB11	M23	4 × 1.5 mm ² + 3 × 1 mm ²	28125339	13354698
	SB12		4 × 2.5 mm ² + 3 × 1 mm ²	28125355	13354698
	SB14		4 × 4 mm ² + 3 × 1 mm ²	28125371	13354264
	SBB6	M40	4 × 6 mm ² + 3 × 1.5 mm ²	28125401	13421778
	SBB10		4 × 10 mm ² + 3 × 1.5 mm ²	28125436	13421751
	SBB16		4 × 16 mm ² + 3 × 1.5 mm ²	28125452	13421670

1) The complete connector service pack always includes the following parts: Power connector, insulation inserts, female contacts. No differentiation is made between motor and brakemotor plug connectors.

2) Power cable for brakemotors with BK.. brake: 3-core cable, only 2 cores are used.

4.2.3 Power cables for cable carrier installation


Cable type	Con- nector type	Thread	Cable cross section	Part number	
				Prefabricated cable	Replacement mating con- nectors ¹⁾
Motor cable	SM11	M23	4 × 1.5 mm ²	28125010	13354698
	SM12		4 × 2.5 mm ²	28125037	13354256
	SM14		4 × 4 mm ²	28125053	13354264
	SMB6	M40	4 × 6 mm ²	28125088	13421778
	SMB10		4 × 10 mm ²	28125118	13421751
	SMB16		4 × 16 mm ²	28125134	13421670
Brakemotor cable BK.. brake ²⁾ or BZ.D	SB11	M23	4 × 1.5 mm ² + 3 × 1 mm ²	28125215	13354256
	SB12		4 × 2.5 mm ² + 3 × 1 mm ²	28125231	13354256
	SB14		4 × 4 mm ² + 3 × 1 mm ²	28125266	13354264
	SBB6	M40	4 × 6 mm ² + 3 × 1.5 mm ²	28125282	13421751
	SBB10		4 × 10 mm ² + 3 × 1.5 mm ²	28125304	13421751
	SBB16		4 × 16 mm ² + 3 × 1.5 mm ²	28125320	13421670
Brakemotor cable BZ.. brake	SB11	M23	4 × 1.5 mm ² + 3 × 1 mm ²	28125347	13354256
	SB12		4 × 2.5 mm ² + 3 × 1 mm ²	28125363	13354256
	SB14		4 × 4 mm ² + 3 × 1 mm ²	28125398	13354264
	SBB6	M40	4 × 6 mm ² + 3 × 1.5 mm ²	28125428	13421751
	SBB10		4 × 10 mm ² + 3 × 1.5 mm ²	28125444	13421751
	SBB16		4 × 16 mm ² + 3 × 1.5 mm ²	28125460	13421670

1) The complete connector service pack always includes the following parts: Power connector, insulation inserts, female contacts. No differentiation is made between motor and brakemotor plug connectors.

2) Power cable for brakemotors with BK.. brake: 3-core cable, only 2 cores are used.

4.3 Encoder cables for CM3C.. motors

4.3.1 Overview



18014431391548811

All prefabricated encoder cables with connectors on the motor side are designed in SpeedTec.

- D-sub →
- X15

Encoder connection basic device (resolvers can only be connected to X15)
- X17

Encoder connection multi-encoder card

26860791/EN – 07/2022

4.3.2 Signal cables

Fixed installation


Signal encoder	Connection (motor)	Cable cross section	Part number	
			Prefabricated cable	Replacement mating connector
RH1M resolver	M23	$5 \times 2 \times 0.25 \text{ mm}^2$	28125622	16447115
AK1H, EK1H, AK0H encoders		$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	28125665	
RH1M resolver	Open end	$5 \times 2 \times 0.25 \text{ mm}^2$	13356356	—
AK1H, EK1H, AK0H encoders		$6 \times 2 \times 0.25 \text{ mm}^2$	13356291	—

Cable carrier installation

Signal encoder	Connection (motor)	Cable cross section	Part number	
			Prefabricated cable	Replacement mating connector
RH1M resolver	M23	$5 \times 2 \times 0.25 \text{ mm}^2$	28125630	16447115
AK1H, EK1H, AK0H encoders		$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	28125673	
RH1M resolver	Open end	$5 \times 2 \times 0.25 \text{ mm}^2$	13356364	—
AK1H, EK1H, AK0H encoders		$6 \times 2 \times 0.25 \text{ mm}^2$	13356305	—

4.4 Power cables for CMP.. motors


4.4.1 Overview



18014413264996619

4.4.2 Motor cables with connector at motor side


Illustration of motor cable



Types of CMP.. motor cables

Plug connector	Number of cores and cable cross section	Part number	Installation type
SM11	4 × 1.5 mm ²	05904544	Fixed installation
SM11	4 × 1.5 mm ²	05906245	Cable carrier installation
SM12	4 × 2.5 mm ²	05904552	Fixed installation
SM12	4 × 2.5 mm ²	05906253	Cable carrier installation
SM14	4 × 4 mm ²	05904560	Fixed installation
SM14	4 × 4 mm ²	05904803	Cable carrier installation
SMB6	4 × 6 mm ²	13350269	Fixed installation
SMB6	4 × 6 mm ²	13350293	Cable carrier installation
SMB10	4 × 10 mm ²	13350277	Fixed installation
SMB10	4 × 10 mm ²	13350307	Cable carrier installation
SMB16	4 × 16 mm ²	13350285	Fixed installation
SMB16	4 × 16 mm ²	13350315	Cable carrier installation
SMC16	4 × 16 mm ²	18148476	Fixed installation
SMC16	4 × 16 mm ²	18148484	Cable carrier installation
SMC25	4 × 25 mm ²	18148581	Cable carrier installation
SMC35	4 × 35 mm ²	18148697	Cable carrier installation

Illustration of motor extension cable




Types of CMP.. motor extension cables

Plug connector	Number of cores and cable cross section	Part number	Installation type
SM11	4 × 1.5 mm ²	13332457	Cable carrier installation
SM12	4 × 2.5 mm ²	13332465	Cable carrier installation
SM14	4 × 4 mm ²	13332473	Cable carrier installation
SMB6	4 × 6 mm ²	13350021	Cable carrier installation
SMB10	4 × 10 mm ²	13350048	Cable carrier installation
SMB16	4 × 16 mm ²	13350056	Cable carrier installation
SMC16	4 × 16 mm ²	18156819	Cable carrier installation
SMC25	4 × 25 mm ²	18156827	Cable carrier installation
SMC35	4 × 35 mm ²	18156835	Cable carrier installation

4.4.3 Brakemotor cables for BP/BK brake with connector at motor side

Illustration of CMP.. brakemotor cable



24323160075

Types of CMP.. brakemotor cables

Plug connector	Number of cores and cable cross section	Part number	Installation type
SB11	$4 \times 1.5 \text{ mm}^2 + 3 \times 1 \text{ mm}^2$	13354345	Fixed installation
SB11	$4 \times 1.5 \text{ mm}^2 + 3 \times 1 \text{ mm}^2$	13354388	Cable carrier installation
SB12	$4 \times 2.5 \text{ mm}^2 + 3 \times 1 \text{ mm}^2$	13354353	Fixed installation
SB12	$4 \times 2.5 \text{ mm}^2 + 3 \times 1 \text{ mm}^2$	13354396	Cable carrier installation
SB14	$4 \times 4 \text{ mm}^2 + 3 \times 1 \text{ mm}^2$	13354361	Fixed installation
SB14	$4 \times 4 \text{ mm}^2 + 3 \times 1 \text{ mm}^2$	13421603	Cable carrier installation
SBB6	$4 \times 6 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	13350196	Fixed installation
SBB6	$4 \times 6 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	13350234	Cable carrier installation
SBB10	$4 \times 10 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	13350218	Fixed installation
SBB10	$4 \times 10 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	13350242	Cable carrier installation
SBB16	$4 \times 16 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	13350226	Fixed installation
SBB16	$4 \times 16 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	13350250	Cable carrier installation


INFORMATION



As for the power cables for brakemotors with BP/BK brake, only two signal cables are required, the third signal core is cut off during cable assembly.

4.4.4 Brakemotor cables for BY brake with connector at motor side

Illustration of CMP.. brakemotor cable




Types of CMP.. brakemotor cables

Plug connector	Number of cores and cable cross section	Part number	Installation type
SB11	$4 \times 1.5 \text{ mm}^2 + 3 \times 1 \text{ mm}^2$	13354272	Fixed installation
SB11	$4 \times 1.5 \text{ mm}^2 + 3 \times 1 \text{ mm}^2$	13354302	Cable carrier installation
SB12	$4 \times 2.5 \text{ mm}^2 + 3 \times 1 \text{ mm}^2$	13354280	Fixed installation
SB12	$4 \times 2.5 \text{ mm}^2 + 3 \times 1 \text{ mm}^2$	13354310	Cable carrier installation
SB14	$4 \times 4 \text{ mm}^2 + 3 \times 1 \text{ mm}^2$	13354299	Fixed installation
SB14	$4 \times 4 \text{ mm}^2 + 3 \times 1 \text{ mm}^2$	13354329	Cable carrier installation
SBB6	$4 \times 6 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	13350129	Fixed installation
SBB6	$4 \times 6 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	13350153	Cable carrier installation
SBB10	$4 \times 10 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	13350137	Fixed installation
SBB10	$4 \times 10 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	13350161	Cable carrier installation
SBB16	$4 \times 16 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	13350145	Fixed installation
SBB16	$4 \times 16 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	13350188	Cable carrier installation
SBC16	$4 \times 16 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	18148514	Fixed installation
SBC16	$4 \times 16 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	18148522	Cable carrier installation

4.4.5 Extension cable for BP.., BK.., BY.. brakes

Illustration of brakemotor extension cable




Types of CMP.. brakemotor extension cables

Plug connector	Number of cores and cable cross section	Part number	Installation type
SB11	$4 \times 1.5 \text{ mm}^2 + 3 \times 1 \text{ mm}^2$	13354221	Cable carrier installation
SB12	$4 \times 2.5 \text{ mm}^2 + 3 \times 1 \text{ mm}^2$	13354248	Cable carrier installation
SB14	$4 \times 4 \text{ mm}^2 + 3 \times 1 \text{ mm}^2$	13354337	Cable carrier installation
SBB6	$4 \times 6 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	13350099	Cable carrier installation
SBB10	$4 \times 10 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	13350102	Cable carrier installation
SBB16	$4 \times 16 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	13350110	Cable carrier installation
SBC16	$4 \times 16 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	18156843	Cable carrier installation

4.5 Encoder cables for CMP.. motors


4.5.1 Overview



18014413270582027

4.5.2 Resolver


Illustration of RH1M resolver cable



Types of RH1M resolver cables

Number of cores and cable cross section	Part number	Installation type
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	13327429	Fixed installation
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	13327437	Cable carrier installation


Illustration of RH1M extension cable



Types of RH1M extension cables

Number of cores and cable cross section	Part number	Installation type
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	01995421	Fixed installation
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	01995413	Cable carrier installation

Illustration of RH1M resolver cable for terminal box



RH1M resolver cables for terminal box

Number of cores and cable cross section	Part number	Installation type
$5 \times 2 \times 0.25 \text{ mm}^2$	13356356	Fixed installation
$5 \times 2 \times 0.25 \text{ mm}^2$	13356364	Cable carrier installation

4.5.3 HIPERFACE® encoders


Illustration of HIPERFACE® encoder cable



Types of HIPERFACE® encoder cables

Number of cores and cable cross section	Part number	Installation type
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	13324535	Fixed installation
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	13324551	Cable carrier installation


Illustration of HIPERFACE® encoder extension cable



Types of HIPERFACE® encoder extension cables

Number of cores and cable cross section	Part number	Installation type
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	01995391	Fixed installation
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	01995405	Cable carrier installation

Illustration of HIPERFACE® encoder cable for terminal box




Types of HIPERFACE® encoder cables for terminal box

Number of cores and cable cross section	Part number	Installation type
$6 \times 2 \times 0.25 \text{ mm}^2$	13356291	Fixed installation
$6 \times 2 \times 0.25 \text{ mm}^2$	13356305	Cable carrier installation

4.6 Power cables for CFM.. motors

4.6.1 Overview




- [1] Motor cables ../SM.. (→ 179)
- [2] Motor extension cables ../SM.. (→ 180)
- [3] Brakemotor cables ../SB.. /BR (→ 181)
- [4] Brakemotor extension cables ../SB.. /BR (→ 182)

27021612574006283

26860791/EN – 07/2022

4.6.2 Motor cables

Illustration of motor cable




Types of motor cables

The cables are equipped with a connector for motor connection and conductor end sleeves for inverter connection.

Plug connector	Number of cores and cable cross section	Part number	Installation type
SM51/SM61	4 × 1.5 mm ²	01991795	Fixed installation
SM51/SM61	4 × 1.5 mm ²	13331140	Cable carrier installation
SM52/SM62	4 × 2.5 mm ²	01991817	Fixed installation
SM52/SM62	4 × 2.5 mm ²	13331159	Cable carrier installation
SM54/SM64	4 × 4 mm ²	01991833	Fixed installation
SM54/SM64	4 × 4 mm ²	01991841	Cable carrier installation
SM56/SM66	4 × 6 mm ²	0199185X	Fixed installation
SM56/SM66	4 × 6 mm ²	01991868	Cable carrier installation
SM59/SM69	4 × 10 mm ²	01991876	Fixed installation
SM59/SM69	4 × 10 mm ²	01991884	Cable carrier installation

4.6.3 Motor extension cables

Illustration of motor extension cable




Types of motor extension cables

The cables are equipped with a connector and adapter for extending the CFM.. motor cable.

Plug connector	Number of cores and cable cross section	Part number	Installation type
SM51/SM61	4 × 1.5 mm ²	01995499	Fixed installation
SM51/SM61	4 × 1.5 mm ²	13331183	Cable carrier installation
SM52/SM62	4 × 2.5 mm ²	01995510	Fixed installation
SM52/SM62	4 × 2.5 mm ²	13331191	Cable carrier installation
SM54/SM64	4 × 4 mm ²	01995537	Fixed installation
SM54/SM64	4 × 4 mm ²	01995545	Cable carrier installation
SM56/SM66	4 × 6 mm ²	01995553	Fixed installation
SM56/SM66	4 × 6 mm ²	01995561	Cable carrier installation
SM59/SM69	4 × 10 mm ²	0199557X	Fixed installation
SM59/SM69	4 × 10 mm ²	01995588	Cable carrier installation

4.6.4 Brakemotor cables

Illustration of brakemotor cable




Types of brakemotor cables

Plug connector	Number of cores and cable cross section	Part number	Installation type
SB51/SB61	$4 \times 1.5 \text{ mm}^2 + 3 \times 1.0 \text{ mm}^2$	01991892	Fixed installation
SB51/SB61	$4 \times 1.5 \text{ mm}^2 + 3 \times 1.0 \text{ mm}^2$	13331167	Cable carrier installation
SB52/SB62	$4 \times 2.5 \text{ mm}^2 + 3 \times 1.0 \text{ mm}^2$	01991914	Fixed installation
SB52/SB62	$4 \times 2.5 \text{ mm}^2 + 3 \times 1.0 \text{ mm}^2$	13331175	Cable carrier installation
SB54/SB64	$4 \times 4 \text{ mm}^2 + 3 \times 1.0 \text{ mm}^2$	01991930	Fixed installation
SB54/SB64	$4 \times 4 \text{ mm}^2 + 3 \times 1.0 \text{ mm}^2$	01991949	Cable carrier installation
SB56/SB66	$4 \times 6 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	01991957	Fixed installation
SB56/SB66	$4 \times 6 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	01991965	Cable carrier installation
SB59/SB69	$4 \times 10 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	01991973	Fixed installation
SB59/SB69	$4 \times 10 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	01991981	Cable carrier installation

4.6.5 Brakemotor extension cables

Illustration of brakemotor extension cable




Types of brakemotor extension cables

Plug connector	Number of cores and cable cross section	Part number	Installation type
SK51/SK61	$4 \times 1.5 \text{ mm}^2 + 3 \times 1.0 \text{ mm}^2$	0199199X	Fixed installation
SK51/SK61	$4 \times 1.5 \text{ mm}^2 + 3 \times 1.0 \text{ mm}^2$	13331205	Cable carrier installation
SK52/SK62	$4 \times 2.5 \text{ mm}^2 + 3 \times 1.0 \text{ mm}^2$	01992015	Fixed installation
SK52/SK62	$4 \times 2.5 \text{ mm}^2 + 3 \times 1.0 \text{ mm}^2$	13331213	Cable carrier installation
SK54/SK64	$4 \times 4 \text{ mm}^2 + 3 \times 1.0 \text{ mm}^2$	01992031	Fixed installation
SK54/SK64	$4 \times 4 \text{ mm}^2 + 3 \times 1.0 \text{ mm}^2$	0199204X	Cable carrier installation
SK56/SK66	$4 \times 6 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	01992058	Fixed installation
SK56/SK66	$4 \times 6 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	01992066	Cable carrier installation
SK59/SK69	$4 \times 10 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	01992074	Fixed installation
SK59/SK69	$4 \times 10 \text{ mm}^2 + 3 \times 1.5 \text{ mm}^2$	01992082	Cable carrier installation

4.7 Encoder cables for CFM.. motors

4.7.1 Overview




18014413319274123

D-sub → X15 Encoder connection basic device (resolvers can only be connected to X15)
X17 Encoder connection multi-encoder card

4.7.2 Resolver


Illustration of RH1M/RH1L resolver cable



Types of RH1M/RH1L resolver cables

Number of cores and cable cross section	Part number	Installation type
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	13327429	Fixed installation
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	13327437	Cable carrier installation


Illustration of RH1M/RH1L extension cable



Types of RH1M/RH1L extension cables

Number of cores and cable cross section	Part number	Installation type
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	01995421	Fixed installation
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	01995413	Cable carrier installation

Illustration of RH1M/RH1L resolver cable for terminal box



Types of RH1M/RH1L resolver cables for terminal box

Number of cores and cable cross section	Part number	Installation type
$5 \times 2 \times 0.25 \text{ mm}^2$	13327623	Fixed installation
$5 \times 2 \times 0.25 \text{ mm}^2$	13327631	Cable carrier installation

4.7.3 HIPERFACE® encoders


Illustration of HIPERFACE® encoder cable



Types of HIPERFACE® encoder cables

Number of cores and cable cross section	Part number	Installation
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	13324535	Fixed installation
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	13324551	Cable carrier installation


Illustration of HIPERFACE® encoder extension cable



Types of HIPERFACE® encoder extension cables

Number of cores and cable cross section	Part number	Installation
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	01995391	Fixed installation
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	01995405	Cable carrier installation

Illustration of HIPERFACE® encoder cable for terminal box




Types of HIPERFACE® encoder cables for terminal box

Number of cores and cable cross section	Part number	Installation
$6 \times 2 \times 0.25 \text{ mm}^2$	13356291	Fixed installation
$6 \times 2 \times 0.25 \text{ mm}^2$	13356305	Cable carrier installation


4.8 Encoder cables for DR.. motors

4.8.1 Overview



45036011090014603

D-sub → X15 Encoder connection basic device (resolvers can only be connected to X15)
X17 Encoder connection multi-encoder card (A..Y encoders can only be connected to X17)




36028821502253707


- D-sub →
- X15 Encoder connection basic device (resolvers can only be connected to X15)
- X17 Encoder connection multi-encoder card (A..Y encoders can only be connected to X17)
- [1] Motors with integrated plug connector for encoder signals **without** connection cover, connection type A2GA. The signals for thermal monitoring of the motor are not present in the encoder cable.
- [2] Motors with integrated plug connector for encoder signals **with** connection cover, connection type A1GA. The signals for thermal monitoring of the motor are not present in the encoder cable.

4 Prefabricated cables

Encoder cables for DR.. motors



35990983179




D-sub → X15 Encoder connection basic device (resolvers can only be connected to X15)
X17 Encoder connection multi-encoder card (A..Y encoders can only be connected to X17)

- [1] Motors with terminal strip in the terminal box for encoder signals and thermal monitoring. The signals for thermal monitoring of the motor are **not** present in the encoder cable.
- [2] Motors with M23 plug connector at the terminal box for encoder signals, connection type AIGA. The signals for thermal monitoring of the motor are **not** present in the encoder cable.
- [3] Motors with terminal strip in the terminal box for encoder signals and thermal monitoring. The signals for thermal monitoring of the motor are present in the encoder cable.
- [4] Motors with M23 plug connector at the terminal box for encoder signals and thermal monitoring, connection type AIGB. The signals for thermal monitoring of the motor are present in the encoder cable.

4.8.2 Encoder cables with connection cover and D-sub

Illustration of encoder cable




Types of encoder cables

Number of cores and cable cross section	Part number	Installation type
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	13617621	Fixed installation
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	13617648	Cable carrier installation

4.8.3 Encoder cable with conductor end sleeves and D-sub

Illustration of encoder cable




14818291467

Types of encoder cables

Number of cores and cable cross section	Part number	Installation type
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	13622021	Fixed installation
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	13622048	Cable carrier installation
$5 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	28111508	Fixed installation
$5 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	28111516	Cable carrier installation

4.8.4 Encoder cable with M23 and D-sub

Illustration of encoder cable




14818370059

Types of encoder cables

Number of cores and cable cross section	Part number	Installation type
5 × 2 × 0.25 mm ²	13602659	Fixed installation
5 × 2 × 0.25 mm ²	13623206	Cable carrier installation

4.8.5 Encoder extension cable with connection cover and M23

Illustration of encoder extension cable




14818380043

Types of encoder extension cables

Number of cores and cable cross section	Part number	Installation type
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	13621963	Fixed installation
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	18140394	Cable carrier installation

4.8.6 Encoder extension cable with conductor end sleeves and M23

Illustration of encoder extension cable




1481838875

Types of encoder extension cables

Number of cores and cable cross section	Part number	Installation type
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	13623184	Fixed installation
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	18140408	Cable carrier installation
$5 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	28111486	Fixed installation
$5 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	28111494	Cable carrier installation

4.8.7 Encoder extension cable with two M23

Illustration of encoder extension cable




14818397963

Types of encoder extension cables

Number of cores and cable cross section	Part number	Installation type
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	13623192	Fixed installation
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	13621971	Cable carrier installation
$5 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	28111451	Fixed installation
$5 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	28111478	Cable carrier installation

4.8.8 Encoder extension cable with M23 and D-sub

Illustration of encoder extension cable



14818406795

Types of encoder extension cables

Number of cores and cable cross section	Part number	Installation type
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	13621998	Fixed installation
$4 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	18195393	Cable carrier installation
$5 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	28111435	Fixed installation
$5 \times 2 \times 0.25 \text{ mm}^2 + 2 \times 0.5 \text{ mm}^2$	28111443	Cable carrier installation

4.9 Cables for MOVILINK® DDI

The MOVILINK® DDI interface requires a coaxial cable for data transmission between motor and inverter.

If the motor control requires a cross section of up to 10 mm², the coaxial cable is routed in a hybrid cable.

With cross sections larger than 10 mm², the motor and brake control and the coaxial cable are routed in separate cables.

SEW-EURODRIVE offers prefabricated cables with M23/M40 plug connectors. If the connection is made via a cable gland, a FAKRA connector is required on the coaxial cable.

If hybrid cables with open ends on both sides are used, the coaxial cable is connected to the motor and inverter with one FAKRA connector each.

SEW-EURODRIVE also offers hybrid cables that are already equipped with the FAKRA connector on both sides, or raw cables on a roll, for which the FAKRA connectors must be attached. The FAKRA connectors can be assembled using the "MOVILINK® DDI Tool Set 1".

Single-cable technology up to 10 mm²

Prefabricated hybrid cables for motors with MOVILINK® DDI interface are structured as follows:

- 1 conductor for PE
- 3 conductors for controlling the motor
- 4 conductors for control of the brake
- 1 coaxial cable for MOVILINK® DDI

With this universal hybrid cable, all variants of the brake can be controlled.


Multi-cable technology larger than 10 mm²

For cross sections larger than 10 mm², the coaxial cable is routed separately in a cable. Individual coaxial cables are available as prefabricated cables.

Six plugging positions are available.


An M23 plug connector is always used for the coaxial cable on the motor side.

4.9.1 Hybrid cables with connector on the motor side, open end on the inverter side



9007228746393611


4.9.2 Hybrid cables with open end on the motor side, open end on the inverter side



18014428001137035

4.9.3 Coaxial cables with connector on the motor side, open end on the inverter side

The coaxial cable is needed with a cross-section of greater than 10 mm² for the conductors for controlling the motor, and contains the signal cable for the MOVILINK® DDI connection. The cable for controlling the motor and the brake must be routed separately.



4.9.4 Cable tables

Number	Part number	Cross section in mm ²	Installation type	Motor connection	Motor side	Inverter side
[1]	28123808	4 × 1.5 + 4 × 1 + coaxial cable	Fixed installation	SD1/KD1	M23	open
[2]	28123816	4 × 2.5 + 4 × 1 + coaxial cable	Fixed installation	SD1/KD1	M23	open
[3]	28123824	4 × 4 + 4 × 1 + coaxial cable	Fixed installation	SD1/KD1	M23	open
[4]	28123832	4 × 6 + 4 × 1.5 + coaxial cable	Fixed installation	SDB/KDB	M40	open
[5]	28123840	4 × 10 + 4 × 1.5 + coaxial cable	Fixed installation	SDB/KDB	M40	open
[6]	28123743	4 × 1.5 + 4 × 1 + coaxial cable	Cable carrier installation	SD1/KD1	M23	open
[7]	28123751	4 × 2.5 + 4 × 1 + coaxial cable	Cable carrier installation	SD1/KD1	M23	open
[8]	28123778	4 × 4 + 4 × 1 + coaxial cable	Cable carrier installation	SD1/KD1	M23	open
[9]	28123786	4 × 6 + 4 × 1.5 + coaxial cable	Cable carrier installation	SDB/KDB	M40	open
[10]	28123794	4 × 10 + 4 × 1.5 + coaxial cable	Cable carrier installation	SDB/KDB	M40	open
[11]	28123905	4 × 1.5 + 4 × 1 + coaxial cable	Fixed installation	SD1/KD1	M23	M23
[12]	28123913	4 × 2.5 + 4 × 1 + coaxial cable	Fixed installation	SD1/KD1	M23	M23

Number	Part number	Cross section in mm ²	Installation type	Motor connection	Motor side	Inverter side
[13]	28123921	4 × 4 + 4 × 1 + coaxial cable	Fixed installation	SD1/KD1	M23	M23
[14]	28123948	4 × 6 + 4 × 1.5 + coaxial cable	Fixed installation	SDB/KDB	M40	M40
[15]	28123956	4 × 10 + 4 × 1.5 + coaxial cable	Fixed installation	SDB/KDB	M40	M40
[16]	28123859	4 × 1.5 + 4 × 1 + coaxial cable	Cable carrier installation	SD1/KD1	M23	M23
[17]	28123867	4 × 2.5 + 4 × 1 + coaxial cable	Cable carrier installation	SD1/KD1	M23	M23
[18]	28123875	4 × 4 + 4 × 1 + coaxial cable	Cable carrier installation	SD1/KD1	M23	M23
[19]	28123883	4 × 6 + 4 × 1.5 + coaxial cable	Cable carrier installation	SDB/KDB	M40	M40
[20]	28123891	4 × 10 + 4 × 1.5 + coaxial cable	Cable carrier installation	SDB/KDB	M40	M40
[21]	28124367	4 × 1.5 + 4 × 1 + coaxial cable	Fixed installation	KD	open	M23
[22]	28124375	4 × 2.5 + 4 × 1 + coaxial cable	Fixed installation	KD	open	M23
[23]	28124383	4 × 4 + 4 × 1 + coaxial cable	Fixed installation	KD	open	M23
[24]	28143884	4 × 6 + 4 × 1.5 + coaxial cable	Fixed installation	KD	open	M40
[25]	28143892	4 × 10 + 4 × 1.5 + coaxial cable	Fixed installation	KD	open	M40
[26]	28124332	4 × 1.5 + 4 × 1 + coaxial cable	Cable carrier installation	KD	open	M23
[27]	28124340	4 × 2.5 + 4 × 1 + coaxial cable	Cable carrier installation	KD	open	M23
[28]	28124359	4 × 4 + 4 × 1 + coaxial cable	Cable carrier installation	KD	open	M23
[29]	28143868	4 × 6 + 4 × 1.5 + coaxial cable	Cable carrier installation	KD	open	M40
[30]	28143876	4 × 10 + 4 × 1.5 + coaxial cable	Cable carrier installation	KD	open	M40
[31]	28152395	4 × 1.5 + 4 × 1 + coaxial cable	Fixed installation	KD	open	open
[32]	28152409	4 × 2.5 + 4 × 1 + coaxial cable	Fixed installation	KD	open	open
[33]	28152417	4 × 4 + 4 × 1 + coaxial cable	Fixed installation	KD	open	open

Number	Part number	Cross section in mm ²	Installation type	Motor connection	Motor side	Inverter side
[34]	28152425	4 × 6 + 4 × 1.5 + coaxial cable	Fixed installation	KD	open	open
[35]	28152433	4 × 10 + 4 × 1.5 + coaxial cable	Fixed installation	KD	open	open
[36]	28152441	4 × 1.5 + 4 × 1 + coaxial cable	Cable carrier installation	KD	open	open
[37]	28152468	4 × 2.5 + 4 × 1 + coaxial cable	Cable carrier installation	KD	open	open
[38]	28152476	4 × 4 + 4 × 1 + coaxial cable	Cable carrier installation	KD	open	open
[39]	28152484	4 × 6 + 4 × 1.5 + coaxial cable	Cable carrier installation	KD	open	open
[40]	28152492	4 × 10 + 4 × 1.5 + coaxial cable	Cable carrier installation	KD	open	open
[41]	28129431	Coaxial cable	Cable carrier installation	SMCD/ SB CD/ KDD	M23	open
[42]	28138376	Coaxial cable	Cable carrier installation	SMCD/ SB CD/ KDD	M23	M23

The prefabricated cables "open on the motor side" and "open on the inverter side" (lines 31 – 40) can also be supplied as cable reels in lengths 30 m, 100 m, and 200 m (lines 43 – 52). These cables are not prefabricated.

For more information on assembly, refer to the addendum to the "MOVILINK® DDI Tool Set 1" operating instructions.

Number	Part number	Cross section in mm ²	Installation type	Motor connection	Motor side	Inverter side
[43]	28123395	4 × 1.5 + 4 × 1 + coaxial cable	Fixed installation	KD	open	open
[44]	28123409	4 × 2.5 + 4 × 1 + coaxial cable	Fixed installation	KD	open	open
[45]	28123417	4 × 4 + 4 × 1 + coaxial cable	Fixed installation	KD	open	open
[46]	28123425	4 × 6 + 4 × 1.5 + coaxial cable	Fixed installation	KD	open	open
[47]	28123433	4 × 10 + 4 × 1.5 + coaxial cable	Fixed installation	KD	open	open
[48]	28123336	4 × 1.5 + 4 × 1 + coaxial cable	Cable carrier installation	KD	open	open
[49]	28123344	4 × 2.5 + 4 × 1 + coaxial cable	Cable carrier installation	KD	open	open

Number	Part number	Cross section in mm ²	Installation type	Motor connection	Motor side	Inverter side
[50]	28123352	4 × 4 + 4 × 1 + coaxial cable	Cable carrier installation	KD	open	open
[51]	28123360	4 × 6 + 4 × 1.5 + coaxial cable	Cable carrier installation	KD	open	open
[52]	28123379	4 × 10 + 4 × 1.5 + coaxial cable	Cable carrier installation	KD	open	open


4.10 Motor cables for motors with MOVILINK® DDI interface

4.10.1 Connecting motor cables for motors without brake with MOVILINK® DDI interface

Connecting cables with connectors at the motor side for the following motors:

- DRN../DR2S../DR2L.. asynchronous motors
- CMP../CM3C.. synchronous motors
- MOVIGEAR® classic drive unit

The following table shows the conductor assignment of the cables:

Motor side		Inverter side					
							
Contact M23	M40	Signal	Con- ductor color	Conductor color IEC 60757	Identi- fication	Assembly	Description
U	U	U	Black	BK	U/L1	Not prefabricated	Motor connection phase U
V	V	V	Black	BK	V/L2	Not prefabricated	Motor connection phase V
W	W	W	Black	BK	W/L3	Not prefabricated	Motor connection phase W
A	1	Reserved	Yellow	YE	A	Not prefabricated	Do not connect
B	+	Reserved	Orange	OG	B	Not prefabricated	Do not connect
C	N	Reserved	Pink	PK	C	Not prefabricated	Do not connect
D	2	Reserved	Violet	VT	D	Not prefabricated	Do not connect
PE	PE	PE	Yellow/ green	YE/GN		Not prefabricated	PE connection
DDI	DDI	DDI	Violet	VT		Coaxial connector	MOVILINK® DDI

Insulate each unconnected conductor end.

4.10.2 Connecting motor cables for motors with BE or BZ brake with MOVILINK® DDI interface

Connecting cables with connectors on the motor side for the following motors:

- DRN../DR2S../DR2L.. asynchronous motors
- CM3C.. synchronous motors

The following table shows the conductor assignment of the cables:

Motor side		Inverter side					
Contact		Signal	Con- ductor color	Conductor color IEC 60757	Identi- fication	Assembly	Description
M23	M40						
U	U	U	Black	BK	U/L1	Not prefabricated	Motor connection phase U
V	V	V	Black	BK	V/L2	Not prefabricated	Motor connection phase V
W	W	W	Black	BK	W/L3	Not prefabricated	Motor connection phase W
A	1	Reserved	Yellow	YE	A	Not prefabricated	Do not connect
B	+	15	Orange	OG	B	Not prefabricated	Brake connection 15
C	N	13	Pink	PK	C	Not prefabricated	Brake connection 13
D	2	14	Violet	VT	D	Not prefabricated	Brake connection 14
PE	PE	PE	Yellow/ green	YE/GN		Not prefabricated	PE connection
DDI	DDI	DDI	Violet	VT		Coaxial connector	MOVILINK® DDI


Insulate each unconnected conductor end.

4.10.3 Connecting motor cables for motors with BK or BP brake with MOVILINK® DDI interface

Connecting cables with connectors on the motor side for the following motors:

- CMP../CM3C.. synchronous motors

The following table shows the conductor assignment of the cables:

Motor side		Inverter side					
							
Contact M23	M40	Signal	Con- ductor color	Conductor color IEC 60757	Identi- fication	Assembly	Description
U	U	U	Black	BK	U/L1	Not prefabricated	Motor connection phase U
V	V	V	Black	BK	V/L2	Not prefabricated	Motor connection phase V
W	W	W	Black	BK	W/L3	Not prefabricated	Motor connection phase W
A	1	Brake -	Yellow	YE	A	Not prefabricated	Brake connection -
B	+	Reserved	Orange	OG	B	Not prefabricated	Do not connect
C	N	Reserved	Pink	PK	C	Not prefabricated	Do not connect
D	2	Brake +	Violet	VT	D	Not prefabricated	Brake connection +
PE	PE	PE	Yellow/ green	YE/GN		Not prefabricated	PE connection
DDI	DDI	DDI	Violet	VT		Coaxial connector	MOVILINK® DDI

Insulate each unconnected conductor end.

4.10.4 Connecting motor cables for motors with integrated BGZ brake control

Connecting cables with connectors on the motor side for the following motors:

- DRN../DR2S../DR2L.. asynchronous motors
- CMP../CM3C.. synchronous motors

The following table shows the conductor assignment of the cables:

Motor side		Inverter side					
Contact M23	M40	Signal	Con- ductor color	Conductor color IEC 60757	Identi- fication	Assembly	Description
U	U	U	Black	BK	U/L1	Not prefabricated	Motor connection phase U
V	V	V	Black	BK	V/L2	Not prefabricated	Motor connection phase V
W	W	W	Black	BK	W/L3	Not prefabricated	Motor connection phase W
A	1	Reserved	Yellow	YE	A	Not prefabricated	Do not connect
B	+	L2	Orange	OG	B	Not prefabricated	L2 (N) connection
C	N	Reserved	Pink	PK	C	Not prefabricated	Do not connect
D	2	L1	Violet	VT	D	Not prefabricated	L1 connection
PE	PE	PE	Yellow/ green	YE/GN		Not prefabricated	PE connection
DDI	DDI	DDI	Violet	VT		Coaxial connector	MOVILINK® DDI


Insulate each unconnected conductor end.

4.10.5 Connecting motor cables for motors with integrated BS.Z brake control

Connecting cables with connectors on the motor side for the following motors:

- CMP../CM3C.. synchronous motors

The following table shows the conductor assignment of the cables:

Motor side		Inverter side					
							
Contact M23	M40	Signal	Con- ductor color	Conductor color IEC 60757	Identi- fication	Assembly	Description
U	U	U	Black	BK	U/L1	Not prefabricated	Motor connection phase U
V	V	V	Black	BK	V/L2	Not prefabricated	Motor connection phase V
W	W	W	Black	BK	W/L3	Not prefabricated	Motor connection phase W
A	1	GND	Yellow	YE	A	Not prefabricated	GND connection
B	+	DC 23 V	Orange	OG	B	Not prefabricated	DC 24 V connection
C	N	Reserved	Pink	PK	C	Not prefabricated	Do not connect
D	2	Reserved	Violet	VT	D	Not prefabricated	Do not connect
PE	PE	PE	Yellow/ green	YE/GN		Not prefabricated	PE connection
DDI	DDI	DDI	Violet	VT		Coaxial connector	MOVILINK® DDI

Insulate each unconnected conductor end.

4.10.6 Connecting motor cables for motors with integrated braking resistor

Connecting cables with connectors on the motor side for the following motors:

- MOVIGEAR® classic drive unit

The following table shows the conductor assignment of the cables:

Motor side		Inverter side					
Contact		Signal	Con- ductor color	Conductor color IEC 60757	Identi- fication	Assembly	Description
M23	M40						
U	U	U	Black	BK	U/L1	Not prefabricated	Motor connection phase U
V	V	V	Black	BK	V/L2	Not prefabricated	Motor connection phase V
W	W	W	Black	BK	W/L3	Not prefabricated	Motor connection phase W
A	1	Reserved	Yellow	YE	A	Not prefabricated	Do not connect
B		Braking resistor	Orange	OG	B	Not prefabricated	Braking resistor connection
C		Braking resistor	Pink	PK	C	Not prefabricated	Braking resistor connection
D	2	Reserved	Violet	VT	D	Not prefabricated	Do not connect
PE	PE	PE	Yellow/ green	YE/GN		Not prefabricated	PE connection
DDI	DDI	DDI	Violet	VT		Coaxial connector	MOVILINK® DDI

Insulate each unconnected conductor end.

4.10.7 Connecting coaxial cables with separate routing of power and signal cable

The power and signal cables can only be routed together up to a cable cross section of 10 mm². With larger cable cross sections, the power cable is routed separately from the signal cable.

Motor side		Inverter side					
Contact		Signal	Con- ductor color	Conductor color IEC 60757	Identi- fication	Assembly	Description
M23							
DDI		DDI	Violet	VT		Coaxial connector	MOVILINK® DDI

4.11 System bus and module bus cables

The RJ45 connectors of the system bus and module bus cables, the connectors that are preassembled in the field, and the sockets in the application inverters have been tested by SEW-EURODRIVE for mechanical stability and contact reliability. SEW-EURODRIVE recommends using the system bus and module bus cables listed below. If other cables and connectors are used, SEW-EURODRIVE makes no statement about the quality of the plug-in connection.

NOTICE


Use of the wrong cables.

Damage to the application inverter.

Only 4-pin cables are permitted for use as system bus cables. If an 8-pin cable is used, malfunctions or failures may occur at the connected devices.

4.11.1 System bus and module bus cabling

Example of system bus and module bus cabling



9007217271733643

- [1] Module bus cable: EtherCAT®/SBus^{PLUS} and internal signals, 8-pin, color: Anthracite gray
- [2] System bus cable: EtherCAT®/SBus^{PLUS}, 4-pin, color: Light gray
- [3] MOVI-C® CONTROLLER power UHX85A
- [4] MOVIDRIVE® modular
- [5] MOVIDRIVE® system/technology with DC link connection
- [6] MOVIDRIVE® system/technology
- [7] Other EtherCAT® stations on the EtherCAT®/SBus^{PLUS}

4.11.2 System bus cables

Figure



[1] Connector, red

[2] Connector, red

The 4-pin system bus cable [2] for EtherCAT® and SBus^{PLUS} is used between the automation components as shown in the figure. Some of these components are listed here as examples:

- MOVI-C® CONTROLLER
- Application inverter
- PC with MOVISUITE® engineering software
- MOVI-PLC® I/O system
- Other EtherCAT® stations on the EtherCAT®/SBus^{PLUS}

Cable assignment

The cable is available in the following lengths for fixed installation:

Cable length	Part number
0.23 m	18179932
0.26 m	18179940
0.29 m	18179959 ¹⁾
0.44 m	18179967 ²⁾
0.75 m	18167039 ³⁾
1.5 m	18179975 ³⁾
3 m	18167047 ³⁾
5 m	18179983 ³⁾
10 m	18179991 ³⁾

1) Sizes 1 – 3 with devices directly next to each other

2) Sizes 4 – 6 with devices directly next to each other

3) With devices not directly next to each other

If you use system bus cables from other manufacturers, it is necessary to comply with the relevant requirements of the "EtherCAT® Technology Group" (ETG). On this subject, note the "EtherCAT® Installation Guideline" from the ETG.

Pin assignment

The prefabricated system bus cables are assigned according to EIA/TIA-568A. Also use this assignment for prefabrication in the field.

Contact	Conductor color	Function
1	White/green	RX+
2	Green	RX-
3	White/orange	TX+
4	Reserved	–
5	Reserved	–
6	Orange	TX-
7	Reserved	–
8	Reserved	–

4.11.3 Module bus cable

Figure



18027071371

[1] Connector, black

[2] Connector, red

The module bus cable is used when two inverters are connected with one another in the DC link, see also the "DC link connection" manual.

Cable assignment

The cable is available in the following lengths for fixed installation:

Cable length	Part number
0.2 m	18166970
0.23 m	18166989
0.26 m	18166997
0.29 m	18167004 ¹⁾
0.35 m	18167012
0.44 m	18167020 ²⁾
0.59 m	28124251
0.75 m	28118618
1.6 m	18174205 ³⁾
2.6 m	28123549 ³⁾

1) Sizes 1 – 3 with devices directly next to each other

2) Sizes 4 – 6 with devices directly next to each other

3) With devices not directly next to each other

5 General information

5.1 About this documentation

The documentation at hand is the original.

This documentation is an integral part of the product. The documentation is intended for all employees who perform work on the product.

Make sure this documentation is accessible and legible. Ensure that persons responsible for the systems and their operation as well as persons who work on the product independently have read through the documentation carefully and understood it. If you are unclear about any of the information in this documentation or if you require further information, contact SEW-EURODRIVE.

5.2 Structure of the safety notes

5.2.1 Meaning of signal words

The following table shows the grading and meaning of the signal words for safety notes:

Signal word	Meaning	Consequences if disregarded
▲ DANGER	Imminent hazard	Severe or fatal injuries
▲ WARNING	Possible dangerous situation	Severe or fatal injuries
▲ CAUTION	Possible dangerous situation	Minor injuries
NOTICE	Possible damage to property	Damage to the product or its environment
INFORMATION	Useful information or tip: Simplifies handling of the product.	

5.2.2 Structure of section-related safety notes

Section-related safety notes do not apply to a specific action but to several actions pertaining to one subject. The hazard symbols used either indicate a general hazard or a specific hazard.

This is the formal structure of a safety note for a specific section:



SIGNAL WORD






Type and source of hazard.

Possible consequence(s) if disregarded.

- Measure(s) to prevent the hazard.

Meaning of the hazard symbols

The hazard symbols in the safety notes have the following meaning:

Hazard symbol	Meaning
	General hazard
	Warning of dangerous electrical voltage
	Warning of hot surfaces
	Warning about suspended load
	Warning of automatic restart

5.2.3 Structure of embedded safety notes

Embedded safety notes are directly integrated into the instructions just before the description of the dangerous action.

This is the formal structure of an embedded safety note:

⚠ SIGNAL WORD! Type and source of hazard. Possible consequence(s) if disregarded. Measure(s) to prevent the hazard.

5.3 Decimal separator in numerical values

In this document, a period is used to indicate the decimal separator.

Example: 30.5 kg

5.4 Rights to claim under limited warranty

Read the information in this documentation. This is essential for fault-free operation and fulfillment of any rights to claim under limited warranty. Read the documentation before you start working with the product.

5.5 Content of the documentation

This documentation contains additional safety-related information and conditions for operation in safety-related applications.

5.6 Other applicable documentation

Observe the corresponding documentation for all additional components.

5.6.1 Information on the EU Ecodesign Regulation

For information on the guideline, refer to the addendum to the "Information about the EU Ecodesign Regulation 2019/1781" operating instructions.

5.7 Product names and trademarks

The brands and product names in this documentation are trademarks or registered trademarks of their respective titleholders.

5.7.1 Trademark of Beckhoff Automation GmbH

EtherCAT® is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

EtherCAT® 

5.7.2 Trademark of Beckhoff Automation GmbH

Safety over EtherCAT® is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.



25798632331

5.7.3 Trademarks of ODVA, Inc.

EtherNet/IP™, CIP™, CIP Safety™, ODVA® and ODVA CONFORMANT® are registered trademarks of ODVA, Inc.

5.8 Copyright notice

© 2022 SEW-EURODRIVE. All rights reserved. Unauthorized reproduction, modification, distribution or any other use of the whole or any part of this documentation is strictly prohibited.

5.9 Short designation

The following short designations are used in this document.

Type designation	Short designation
MOVIDRIVE® technology application inverter	Inverter

6 Safety notes

6.1 Preliminary information

The following general safety notes serve the purpose of preventing injury to persons and damage to property. They primarily apply to the use of products described in this documentation. If you use additional components, also observe the relevant warning and safety notes.

6.2 Duties of the user

As the user, you must ensure that the basic safety notes are observed and complied with. Make sure that persons responsible for the machinery and its operation as well as persons who work on the device independently have read through the documentation carefully and understood it.

As the user, you must ensure that all of the work listed in the following is carried out only by qualified specialists:

- Setup and installation
- Installation and connection
- Startup
- Maintenance and repairs
- Shutdown
- Disassembly

Ensure that the persons who work on the product pay attention to the following regulations, conditions, documentation, and information:

- National and regional safety and accident prevention regulations
- Warning and safety signs on the product
- All other relevant project planning documents, installation and startup instructions, and wiring diagrams
- Do not assemble, install or operate damaged products
- All system-specific specifications and conditions

Ensure that systems in which the product is installed are equipped with additional monitoring and protection devices. Observe the applicable safety regulations and legislation governing technical work equipment and accident prevention regulations.

6.3 Target group

Specialist for mechanical work	<p>Any mechanical work may be performed only by adequately qualified specialists. Specialists in the context of this documentation are persons who are familiar with the design, mechanical installation, troubleshooting, and maintenance of the product who possess the following qualifications:</p> <ul style="list-style-type: none"> • Qualifications in the field of mechanics in accordance with the national regulations • Familiarity with this documentation
Specialist for electrotechnical work	<p>Any electrotechnical work may be performed only by electrically skilled persons with a suitable education. Electrically skilled persons in the context of this documentation are persons who are familiar with electrical installation, startup, troubleshooting, and maintenance of the product who possess the following qualifications:</p> <ul style="list-style-type: none"> • Qualifications in the field of electrical engineering in accordance with the national regulations • Familiarity with this documentation
Additional qualifications	<p>In addition to that, these persons must be familiar with the valid safety regulations and laws, as well as with the requirements of the standards, directives, and laws specified in this documentation.</p> <p>The persons must have the express authorization of the company to operate, program, parameterize, label, and ground devices, systems, and circuits in accordance with the standards of safety technology.</p>
Instructed persons	<p>All work in the areas of transport, storage, installation, operation and waste disposal may only be carried out by persons who are trained and instructed appropriately. These instructions must enable the persons to carry out the required activities and work steps safely and in accordance with regulations.</p>

6.4 IT security of the environment



For drive and control components that are integrated in a network (e.g. fieldbus or Ethernet network), settings can even be made from more remote locations. There is a risk that a change of parameters that cannot be detected externally may result in unexpected, but not uncontrolled, system behavior and may have a negative impact on operational safety, system availability, or data security.

Ensure that unauthorized access is prevented, particularly with respect to Ethernet-based networked systems and engineering interfaces. Using IT-specific security standards, such as network segmentation, adds to the protection of access to the ports. For an overview of the ports and of the services provided by the communication interfaces, refer to chapter "Technical data" (→ 42). The IT security of the product is only guaranteed when used in an environment secured by defense-in-depth strategies.

Ensure that clear responsibility for security is ensured during operation. SEW-EURODRIVE recommends an IT security management system in accordance with ISO/IEC 27001 and ISO/IEC 62443-2-4.

6.5 Designated use

The product is intended for control cabinet installation in electrical systems or machines.

In case of installation in electrical systems or machines, startup of the product is prohibited until it is determined that the machine meets the requirements stipulated in the local laws and directives. For Europe, Machinery Directive 2006/42/EC as well as the EMC Directive 2014/30/EU apply. Observe EN 60204-1 (Safety of machinery - electrical equipment of machines). The product meets the requirements stipulated in the Low Voltage Directive 2014/35/EU.

The standards given in the declaration of conformity apply to the product.

The systems can be mobile or stationary.

Do not connect any other loads to the product. Never connect capacitive loads to the product.

The product can be used to operate the following motors in industrial and commercial systems:

- AC asynchronous motors with squirrel-cage rotor
- Permanent-field AC synchronous motors

Technical data and information on the connection conditions are provided on the nameplate and in chapter "Technical data" in the documentation. Always comply with the data and conditions.

Unintended or improper use of the product may result in severe injury to persons and damage to property.

6.5.1 Restrictions under the European WEEE Directive 2012/19/EU

Options and accessories from SEW-EURODRIVE may only be used in combination with products from SEW-EURODRIVE.

6.5.2 Lifting applications

To avoid danger of fatal injury due to falling hoists, observe the following points when using the product in lifting applications:

- Use mechanical protection devices.
- Perform a hoist startup.

Application in ELSM® control mode

When the inverter is operated in ELSM® control mode, using it in lifting applications is not permitted. In this control mode only applications of horizontal materials handling are permitted.

6.6 Functional safety technology

The product must not perform any safety functions without a higher-level safety system unless explicitly allowed by the documentation.

6.7 Installation/assembly

Ensure that the product is installed and cooled in accordance with the regulations in the documentation.

Protect the product from excessive mechanical strain. The product and its mounted components must not protrude into the path of persons or vehicles. Ensure that no components are deformed or no insulation spaces are modified, particularly during transportation. Electrical components must not be mechanically damaged or destroyed.

Observe the notes in chapter "Mechanical installation" in the documentation.

6.7.1 Restrictions of use

The following applications are prohibited unless the device is explicitly designed for such use:

- Use in potentially explosive atmospheres
- Use in areas exposed to harmful oils, acids, gases, vapors, dust, and radiation
- Operation in applications with impermissibly high mechanical vibration and shock loads in excess of the regulations stipulated in EN 61800-5-1
- Use at an elevation of more than 3800 m above sea level

The product can be used at altitudes above 1000 m above sea level up to 3800 m above sea level under the following conditions:

- The reduction of the nominal output current and/or the line voltage is considered according to the data in chapter "Technical data" (→ 42) in the documentation.
- Above 2000 m above sea level, the air and creepage distances are only sufficient for overvoltage class II according to EN 60664. At altitudes above 2000 m above sea level, limiting measures must therefore be taken that reduce the line side overvoltage from category III to category II for the entire system.
- If a protective electrical separation (in accordance with EN 61800-5-1 and EN 60204-1) is required, then implement this outside the product at altitudes of more than 2000 m above sea level.

6.8 Electrical installation

Ensure that all of the required covers are correctly attached after the electrical installation.

Make sure that preventive measures and protection devices comply with the applicable regulations (e.g. EN 60204-1 or EN 61800-5-1).

6.8.1 Required preventive measure

Make sure that the product is correctly attached to the ground connection.

6.8.2 Stationary application

Necessary preventive measure for the product:

Type of energy transfer	Preventive measure
Direct power supply	<ul style="list-style-type: none"> • Ground connection

6.8.3 Regenerative operation

The drive is operated as a generator due to the kinetic energy of the system/machine. Before opening the connection box, secure the output shaft against rotation.

6.9 Protective separation

The product meets all requirements for protective separation of power and electronics connections in accordance with EN 61800-5-1. The connected signal circuits must meet requirements according to SELV (**S**afety **E**xtra **L**ow **V**oltage) or PELV (**P**rotective **E**xtra **L**ow **V**oltage) to ensure protective separation. The installation must meet the requirements for protective separation.

In order to avoid exceeding the permitted contact voltages in SELV or PELV power circuits in the event of a fault, continuous equipotential bonding is required in the vicinity of these power circuits. If this is not possible, other preventive measures must be taken. These preventive measures are described in EN 61800-5-1.

6.10 Startup/operation

Observe the safety notes in chapters "Startup" (→ 315) and "Operation" (→ 330) in this documentation.

Make sure the connection boxes are closed and screwed before connecting the supply voltage.

Depending on the degree of protection, products may have live, uninsulated, and sometimes moving or rotating parts as well as hot surfaces during operation.

When the device is switched on, dangerous voltages are present at all power connections as well as at any connected cables and terminals. This also applies even when the product is inhibited and the motor is at standstill.

Risk of burns due to arcing: Do not disconnect power connections during operation. Do not connect power connections during operation.

If you disconnect the product from the voltage supply, do not touch any live components or power connections because capacitors might still be charged. Observe the following minimum switch-off time:

10 minutes.

Observe the corresponding information signs on the product.

The fact that the operation LED and other display elements are no longer illuminated does not indicate that the product has been disconnected from the supply system and no longer carries any voltage.

Mechanical blocking or internal protective functions of the product can cause a motor standstill. Eliminating the cause of the problem or performing a reset may result in the drive restarting automatically. If, for safety reasons, this is not permitted for the drive-controlled machine, first disconnect the product from the supply system and then start troubleshooting.

Risk of burns: The surface temperature of the product can exceed 60 °C during operation. Do not touch the product during operation. Let the product cool down before touching it.

6.10.1 Energy storage unit


Products with a connected energy storage unit are not necessarily de-energized when they have been disconnected from the supply system. Usually, the energy storage unit stores sufficient energy to continue operation of the connected motors for a limited period of time. It is not sufficient to observe a minimum switch-off time.

Perform a shutdown as described in the documentation in the chapter "Service" > "Shutdown".

7 Device structure

7.1 Connection variants

The MOVIDRIVE® technology application inverter is used for direct control via fieldbus systems. The communication interfaces are inserted into the basic device using cards.




25926993419

- [1] Line voltage
- [2] Industrial communication
- [3] MOVIDRIVE® technology

7.2 Nameplates

The nameplates are presented as an example.


7.2.1 System nameplate



27021619314465675

- [1] Device status
- [2] Serial number
- [3] Year of manufacture as part of the serial number. Example: 15 → year of manufacture 2015
- [4] Free text


7.2.2 Performance data nameplate



9007223162722955

- [1] Device status

7.2.3 Product label


	Product label with QR code. The QR code can be scanned. You will be re-directed to the digital services of SEW-EURODRIVE. There, you have access to product-specific data, documents, and further services.
---	---

7.3 MOVIDRIVE® technology type code

Example: MDX90A-0125-5E3-X-T00		
Product family	MD	MOVIDRIVE®
Device type	X	<ul style="list-style-type: none"> X = Single-axis inverter
Series	90	<ul style="list-style-type: none"> 90 = Without DC 24 V switched-mode power supply 91 = With DC 24 V switched-mode power supply
Version	A	<ul style="list-style-type: none"> A = Version status of the device series
Power class	0.125	<ul style="list-style-type: none"> 0125 = Nominal output current – e.g. 0125 = 12.5 A
Connection voltage	5	<ul style="list-style-type: none"> 2 = AC 200 – 240 V 5 = AC 380 – 500 V
Power section variant EMC	E	<ul style="list-style-type: none"> 0 = Basic interference suppression integrated E = EMC filter limit value category C2 in accordance with EN 61800-3
Connection type	3	<ul style="list-style-type: none"> 3 = 3-phase connection type
Operating mode	X	<ul style="list-style-type: none"> 4 = 4-quadrant operation X = Not relevant
Device variant	T	<ul style="list-style-type: none"> 0 = Not relevant T = MOVIDRIVE® technology: Control via fieldbus L = Inverter with POWERLINK CiA402
Technology level	0	<ul style="list-style-type: none"> 0 = Standard design
Application level	0	<ul style="list-style-type: none"> 0 = Standard/MOVIKIT® Velocity Drive 1 = MOVIKIT® Positioning Drive 2 = Customized solution
Options		<ul style="list-style-type: none"> /L = Design with coated printed circuit boards <p>The following list is an example:</p> <ul style="list-style-type: none"> /CES11A = Multi-encoder card /CID21A, /CIO21A = Input/output cards /CFE21A = EtherNet/IP™ and Modbus TCP /CFN21A = PROFINET /CFP21A = PROFIBUS /CFL21A = POWERLINK

7.4 Device structure of the inverter

7.4.1 Size 1



9007220017827595

A: View from top

- [1] X1: Mains and DC link connection
- [2] X5: 24 V supply voltage
- [3] X30 OUT: System bus
- [4] X30 IN: System bus
- [5] X6: STO input


B: View from front

- [6] 4 × PE connection at housing
- [7] EtherCAT® ID switch
- [8] X32: Operator interface
- [9] Status LEDs EtherCAT®/SBus^{PLUS} "RUN", "ERROR"
- [10] Memory module
- [11] 7-segment display
- [12] S3: Switch for module bus operating mode
- [13] X20: Digital inputs
- [14] X21: Digital outputs
- [15] X22: Isolated relay contact
- [16] Shield plate
- [17] Card slot

C: View from bottom

- [18] X15: Motor encoder connection
- [19] X10: Brake control and motor temperature monitoring
- [20] X2: Motor and braking resistor connection
- [21] X16: Digital motor integration connection

7.4.2 Size 2



9007220017830027

A: View from top

- [1] X1: Mains and DC link connection
- [2] X5: 24 V supply voltage
- [3] X30 OUT: System bus
- [4] X30 IN: System bus
- [5] X6: STO input


B: View from front

- [6] 4 × PE connection at housing
- [7] EtherCAT® ID switch
- [8] X32: Operator interface
- [9] Status LEDs EtherCAT®/SBus^{PLUS} "RUN", "ERROR"
- [10] Memory module
- [11] 7-segment display
- [12] S3: Switch for module bus operating mode
- [13] X20: Digital inputs
- [14] X21: Digital outputs
- [15] X22: Isolated relay contact
- [16] Shield plate
- [17] Card slot

C: View from bottom

- [18] X15: Motor encoder connection
- [19] X10: Brake control and motor temperature monitoring
- [20] X2: Motor and braking resistor connection
- [21] X16: Digital motor integration connection

7.4.3 Size 3



9007220017832459

A: View from top

- [1] X1: Mains and DC link connection
- [2] X5: 24 V supply voltage
- [3] X30 OUT: System bus
- [4] X30 IN: System bus
- [5] X6: STO input


B: View from front

- [6] 4 × PE connection at housing
- [7] EtherCAT® ID switch
- [8] X32: Operator interface
- [9] Status LEDs EtherCAT®/SBus^{PLUS} "RUN", "ERROR"
- [10] Memory module
- [11] 7-segment display
- [12] S3: Switch for module bus operating mode
- [13] X20: Digital inputs
- [14] X21: Digital outputs
- [15] X22: Isolated relay contact
- [16] Shield plate
- [17] Card slot

C: View from bottom

- [18] X15: Motor encoder connection
- [19] X10: Brake control and motor temperature monitoring
- [20] X2: Motor and braking resistor connection
- [21] X16: Digital motor integration connection

7.4.4 Size 4



9007220017834891

A: View from top

- [1] X1: Mains and DC link connection
- [2] X5: 24 V supply voltage
- [3] X30 OUT: System bus
- [4] X30 IN: System bus
- [5] X6: STO input


B: View from front

- [6] 4 × PE connection at housing
- [7] EtherCAT® ID switch
- [8] X32: Operator interface
- [9] Status LEDs EtherCAT®/SBus^{PLUS} "RUN", "ERROR"
- [10] Memory module
- [11] 7-segment display
- [12] S3: Switch for module bus operating mode
- [13] X20: Digital inputs
- [14] X21: Digital outputs
- [15] X22: Isolated relay contact
- [16] Shield plate
- [17] Card slot

C: View from bottom

- [18] X15: Motor encoder connection
- [19] X10: Brake control and motor temperature monitoring
- [20] X2: Motor and braking resistor connection
- [21] X16: Digital motor integration connection

7.4.5 Size 5



9007220736103947

A: View from top

- [1] X1: Mains and DC link connection
- [2] X5: 24 V supply voltage
- [3] X30 OUT: System bus
- [4] X30 IN: System bus
- [5] X6: STO input


B: View from front

- [6] 4 × PE connection at housing
- [7] EtherCAT® ID switch
- [8] X31: SEW-EURODRIVE Service interface
- [9] Status LEDs EtherCAT®/SBus^{PLUS} "RUN", "ERROR"
- [10] Memory module
- [11] 7-segment display
- [12] S3: Switch for module bus operating mode
- [13] X20: Digital inputs
- [14] X21: Digital outputs
- [15] X22: Isolated relay contact
- [16] Shield plate
- [17] X2: Motor connection
- [18] Card slot
- [19] X2: Braking resistor connection

C: View from bottom

- [20] X15: Motor encoder connection
- [21] X10: Brake control and motor temperature monitoring
- [22] X16: Digital motor integration connection

7.4.6 Size 6



23876712075

A: View from top

- [1] X5: 24 V supply voltage
- [2] X1: Mains and DC link connection
- [3] X30 OUT: System bus
- [4] X30 IN: System bus
- [5] X6: STO input


B: View from front

- [6] 4 × PE connection at housing
- [7] EtherCAT® ID switch
- [8] X31: SEW-EURODRIVE Service interface
- [9] Status LEDs EtherCAT®/SBus^{PLUS} "RUN", "ERROR"
- [10] Memory module
- [11] 7-segment display
- [12] S3: Switch for module bus operating mode
- [13] X20: Digital inputs
- [14] X21: Digital outputs
- [15] X22: Isolated relay contact
- [16] Shield plate
- [17] X2: Motor connection
- [18] Card slot
- [19] X2: Braking resistor connection

C: View from bottom

- [20] X16: Digital motor integration connection
- [21] X15: Motor encoder connection
- [22] X10: Brake control and motor temperature monitoring

7.4.7 Size 7



37500406027

A: View from top

- [1] X5: 24 V supply voltage
- [2] X1: Connection for supply system
- [3] X30 OUT: System bus
- [4] X30 IN: System bus
- [5] X6: STO input
- [6] DC link connection

B: View from front

- [7] 4 × PE connection at housing
- [8] EtherCAT® ID switch
- [9] X32: SEW-EURODRIVE Service interface
- [10] Card slot
- [11] 7-segment display
- [12] Memory module
- [13] S3: Switch for module bus operating mode
- [14] X20: Digital inputs
- [15] X21: Digital outputs
- [16] X22: Isolated relay contact
- [17] Shield plate
- [18] Shield terminal
- [19] X2: Motor connection
- [20] Card slot
- [21] X2: Braking resistor connection


C: View from bottom

- [22] X16: Digital motor integration connection
- [23] X15: Motor encoder connection
- [24] X10: Brake control and motor temperature monitoring

7.5 Card slots

Inverters can accommodate up to 3 cards. The following section describes the assignment of the slots and possible combinations of cards.

Type designation	Description	Slot
CFE21A, CFN21A, CFP21A, CFL21A	Fieldbus cards	[2]
CES11A	Multi-encoder card	[3]
CS..A	Safety card	[3]
CID21A, CIO21A	Input/output cards	[4]



20605002507

- [1] Connector panel of basic device
- [2] Fieldbus card slot
- [3] Slot for safety card/multi-encoder card
- [4] Slot for input/output cards

8 Installation

8.1 Permitted tightening torques

NOTICE

Failure to adhere to prescribed tightening torques.

Possible inverter damage.

- Always adhere to the stipulated tightening torques. Otherwise, excessive heat can develop, causing damage to the inverter.

Size		1	2	3	4	5	6	7	8
Screw connection		Tightening torques in Nm							
Connection for supply system	X1	0.5 – 0.6			1.7 – 1.8	8.5 – 9.5	10 – 15	14 – 20	
Motor and braking resistor connection	X2	0.5 – 0.6			1.7 – 1.8	8.5 – 9.5	10 – 15	14 – 20	
Terminal screw for TN/IT systems	EMC	1 – 1.2							
PE connection		1.2 – 1.5	M4: 1.2 – 1.5 or M6: 2.5 – 3		2.5 – 3	6 – 10	10 – 15	14 – 20	
Fastening the cards		0.6 – 0.8							

8.2 Permitted terminal cross sections

8.2.1 Single conductor, without conductor end sleeve, rigid and flexible

Inverter	Terminal	Terminal type	Stripping length in mm	Cable cross section in mm ²			
				Rigid		Flexible	
				Minimum	Maximum	Minimum	Maximum
Control unit							
Sizes 1 – 8	X20	Spring terminal	10	0.2	2.5	0.2	2.5
	X21		10	0.2	2.5	0.2	2.5
	X22		10	0.2	2.5	0.2	2.5
	X6		10	0.2	1.5	0.2	1.5
Power section							
Sizes 1 – 8	X5	Spring terminal	10	0.2	2.5	0.2	2.5
Sizes 1 – 4	X10		10	0.2	1.5	0.2	1.5
Sizes 5 – 8	X10		10	0.2	2.5	0.2	2.5
Sizes 1 – 3	X1/X2	Screw terminal ¹⁾	10	0.2	10	0.2	6
Size 4	X1/X2		12	0.75	16	0.75	16

1) SEW-EURODRIVE recommends using conductor end sleeves for installation with screw terminals and flexible cable.

8.2.2 Single conductor, flexible, with conductor end sleeve, with or without plastic collar

Inverter	Terminal	Terminal type	Stripping length in mm	Cable cross section in mm ²			
				Plastic collar			
				With		Without	
				Minimum	Maximum	Minimum	Maximum
Control unit							
Sizes 1 – 8	X20	Spring terminal	10	0.25	2.5	0.25	2.5
	X21		10	0.25	2.5	0.25	2.5
	X22		10	0.25	2.5	0.25	2.5
	X6		10	0.25	0.75	0.25	1.5
Power section							
Sizes 1 – 8	X5	Spring terminal	10	0.25	2.5	0.25	2.5
Sizes 1 – 4	X10		10	0.25	0.75	0.25	1.5
Sizes 5 – 8	X10		10	0.25	2.5	0.25	2.5
Sizes 1 – 3	X1/X2	Screw terminal ¹⁾	10	0.25	4	0.25	6
Size 4	X1/X2		12	0.5	10	0.5	16

1) SEW-EURODRIVE recommends using conductor end sleeves for installation with screw terminals and flexible cable.

8.2.3 Double conductor, flexible, with conductor end sleeve, with plastic collar

Inverter	Terminal designation	Terminal type	Stripping length in mm	Double conductor, same cross section in mm ² , Twin conductor end sleeve			
				Plastic collar			
				With		Without	
				Minimum	Maximum	Minimum	Maximum
Control unit							
Sizes 1 – 8	X20	Spring terminal	10	0.5	1.5	–	–
	X21		10	0.5	1.5	–	–
	X22		10	0.5	1.5	–	–
	X6		–	–	–	–	–
Power section							
Sizes 1 – 8	X5	Spring terminal	10	0.5	1.5	–	–
Sizes 1 – 4	X10		10	–	–	–	–
Sizes 5 – 8	X10		10	0.5	2.5	–	–
Sizes 1 – 3	X1/X2	Screw terminal ¹⁾	10	0.25	2.5	0.25	1.5
Size 4	X1/X2		12	0.5	6	0.5	4

"–" Not permitted

1) SEW-EURODRIVE recommends using conductor end sleeves for installation with screw terminals and flexible cable.

8.3 Special aspects when transporting the devices

NOTICE


Improper lifting and transportation of the inverter.

Improper lifting and transportation of the inverter on the plastic parts or on the covers will cause damage.

- Observe the following notes before lifting and transporting the inverter:
- Hold inverters of size 5 by the handling points provided on the rear panel of the housing.
- Transport inverters of sizes 6 – 7 using the supporting aids provided for this purpose.

8.3.1 Size 5

The rear panel of the housing of size 5 inverters is designed in such a way that you can grip them securely by hand to lift and transport the inverters without damaging them.




21435628299

8.3.2 Sizes 6 – 7

Due to their weight, the following inverters must be transported using a supporting aid:


- **Lifting eye** for size 6 inverters

The lifting eye is attached to the top of the housing and can be attached to lifting devices using suitable lifting equipment.



24550948491

- **Carrying bar** for size 7 inverters



35809245451

If a crane is not available, you can push a carrying bar [1] through the rear panel to facilitate installation (included in the delivery). Secure the carrying bar against axial displacement using the two split pins [2].

8.4 Mechanical installation



⚠ CAUTION

Risk of injury to persons and damage to property.

Never install defective or damaged products.

- Before installing any products, check them for external damage. Replace any damaged products.
-

NOTICE


Risk of damage to property due to mounting surfaces with poor conductivity.

Inverter damage.

- The mounting plate in the control cabinet must be conductive over a large area for the mounting surface of the inverter (metallically pure, good conductivity). An EMC-compliant installation of the inverter can only be achieved with a mounting plate that is conductive over a large area.
-

8.4.1 Bore patterns

Size	Dimensions of the device base plate in mm						
	A	B	C	D	E	F	G
Size 1	95	50	350	325	12	6	18
Size 2	105	50	350	325	12	6	18
Size 3	105	80	350	325	12	6	18
Size 4	135	80	350	325	12	6	18
Size 5	196	160	471	440	13	7	18
Size 6	240	200	544	510	13	7	18
Size 7	320	220	990	950	23	11	25



9007215129195275

8.4.2 Minimum clearance and mounting position

When installing the inverters in the control cabinet, observe the following:

- To ensure unobstructed cooling, leave a minimum clearance of 100 mm above and below the inverter housings. Ensure that the air circulation in this clearance is not impaired by cables or other installation equipment.
- Make sure that the inverters are not within the area of the warm exhaust air of other devices.
- Install the inverters only vertically. Do not install them horizontally, tilted or upside down.
- Clearance at the side is not necessary. The units can be arranged directly next to one another.



INFORMATION


Special bending spaces are required according to EN 61800-5-1 for cables with a cross section of 10 mm² and larger. This means the clearance must be increased if required.

8.5 Covers

8.5.1 Covers

The application inverter is equipped with a safety cover [1].


Removing the
safety cover



9007213554135563

1. The safety cover [1] has a latching mechanism at the bottom. Pull the lower part of the safety cover away from the application inverter to unlatch it.
2. Pivot the safety cover forward and lift it to remove it from the application inverter.

Installing the
safety cover




9007213833196299

3. Place the safety cover [1] into the upper recess and move it towards the application inverter until it clicks into place.
4. Always attach the cover [1] after having carried out installation work.

8.5.2 Touch guards

For inverters of size 5 and higher, touch guard covers must be removed for the line connection and the connection of the motor and braking resistor.


Line connection



21425921035

1. Remove the 2 screws [1] on the upper touch guard cover [2].
2. Remove the touch guard cover [2].

Connection of motor/braking resistor



21425950603


3. Press the plastic clips of the touch guard cover [1] inwards and remove the touch guard cover [1] by pulling it to the front.
4. Remove the 2 screws [2] and remove the touch guard cover [3] to the front.

8.6 Control cabinet installation

8.6.1 Inverter and bottom shield plate

The retaining screws [1] and [2] are screwed into the prepared tapped holes in the mounting plate in the control cabinet but are not tightened.

1. Place the application inverter with the slotted holes in the device base plate onto the retaining screws [1] from the top.




9007214280974347

2. Push the application inverter backwards to insert the retaining screws [2] into the upper holes in the device base plate.
3. Lower the application inverter.
4. Install the shield plate [3] as shown above. This step applies to inverters of sizes 1 – 4.
5. Tighten the retaining screws [1] and [2].

Shield plate for
motor and encoder

✓ This step applies to inverters of sizes 1 – 2.




34494059147

6. Install the shield plate as shown above and tighten the screws [4].

8.6.2 Top shield plate


1. Insert the shield plate [2] so that you can fasten it to the device housing [3] with the screw [1].



27521510667

8.6.3 Shield plate at bottom of control unit


1. Insert the shield plate [2] so that you can fasten it with the screw [1] in the position [3] shown in the figure.



27521507083

8.6.4 Shield plate at the bottom – encoder

- ✓ This step applies to inverters of size 5.
1. Insert the shield plate [2] so that you can fasten it with the screw [1] in the position [3] shown in the figure.




9007233739470987

8.6.5 Installation with submounting resistor BW120-001, BW100-002/M

Size 1 inverters can be installed in the control cabinet together with a braking resistor. The braking resistor is located on the rear panel of the inverter and therefore has the same mounting hole pattern as the inverter.

Note that the retaining screws [1] and [2] must be 20 mm longer for installation with a braking resistor.




20363406219

1. Place the braking resistor at the desired position in the control cabinet as shown in the figure, and screw in the 4 retaining screws [1] and [2] without tightening them.
2. Place the inverter with the slotted holes in the device base plate onto the retaining screws [1] from the top.
3. Push the inverter backwards to insert the retaining screws [2] into the upper holes in the device base plate.
4. Lower the inverter.
5. Install the shield plate; see the chapter "Control cabinet installation" (→ 244).
6. Tighten the retaining screws [1] and [2].

The submounting resistor can be installed next to an application inverter; see the following figure.

The hole distance of the submounting braking resistor must be larger than the hole distance of the application inverter.



20363403787

8.7 Electrical installation



⚠ DANGER

Dangerous voltage levels may still be present inside the device and at the terminal strips up to 10 minutes after the application inverter has been disconnected from the power supply.

Severe or fatal injuries from electric shock.

To prevent electric shocks:

- Disconnect the application inverter from the power supply and wait 10 minutes before removing the protective covers.



⚠ DANGER

A leakage current > 3.5 mA can occur during operation of the application inverter.

Severe or fatal injuries from electric shock.

To avoid dangerous shock currents in accordance with EN 61800-5-1, strictly observe the following:

- Supply system cable < 10 mm²:
 - Route a second PE conductor with the cable cross-section of the supply system cable in parallel to the protective earth via separate terminals or use a copper PE conductor with a cable cross-section of 10 mm².
- Supply system cable 10 mm² – 16 mm²:
 - Route a copper PE conductor with the cable cross-section of the supply system cable.
- Supply system cable 16 mm² – 35 mm²:
 - Route a copper protective earth conductor with a cable cross-section of 16 mm².
- Supply system cable > 35 mm²:
 - Route a copper protective earth conductor with half the cross-section of the supply system cable.
- If an earth leakage circuit breaker is used for protection against direct and indirect contact in isolated cases, it must be universal current-sensitive (RCD type B).

INFORMATION



Installation with protective separation.

The application inverter meets all requirements for protective separation of power and electronics connections in accordance with EN 61800-5-1. The connected signal circuits must meet requirements according to SELV (**S**afety **E**xtra **L**ow **V**oltage) or PELV (**P**rotective **E**xtra **L**ow **V**oltage) to ensure protective separation. The installation must meet the requirements for protective separation.

8.7.1 General information

- Take suitable measures to prevent the motor starting up inadvertently, for example by removing the electronics terminal block X20. Take additional safety measures depending on the application to prevent possible injuries to people and damage to machinery.
- Only use closed cable lugs or conductor end sleeves for connection to the screws to prevent litz strands from emerging.

8.7.2 Permitted voltage systems


Information on voltage systems	Information on permissibility
TN and TT systems – voltage systems with directly grounded star point.	Use is possible without restrictions.
IT systems – voltage systems with non-grounded star point.	Use is only permitted adhering to specific measures. The measures are described in chapter "Use in IT systems".
Voltage systems with grounded outer conductor.	Use only for nominal line voltages up to max. 240 V.

8.7.3 Use in IT systems



To ensure IT system capability, the terminal screw shown in the following figures must be removed from the application inverter.

When converting to an IT network, mark this on the nameplate in the "IT system activated" box provided for this purpose.

Size	Position of the terminal screw
Size 1, size 2	On the back of the application inverter.



15144351755

Size	Position of the terminal screw
<p>Sizes 3, 4, 6, 7</p>	<p>On the right side of the application inverter.</p>  <p>9007214280971403</p>
<p>Size 5</p>	<p>One screw on the top, another screw on the right side of the application inverter.</p>  <p>21425923467</p>


8.7.4 Line fuses, fuse types

Type class	Requirement
Fuses in utilization categories gL, gG	Fusing voltage \geq nominal line voltage
Miniature circuit breaker with characteristics B, C, D	Nominal miniature circuit breaker voltage \geq nominal line voltage
	Nominal currents of the miniature circuit breaker must be 10% higher than the nominal line current of the inverter


8.7.5 Special aspects for connecting power terminals

Note that for inverters from size 5 upwards, degree of protection IP20 is only achieved if the terminal studs (for connecting the grid, motor, braking resistor, and DC link) are protected against contact with plastic covers. The plastic covers can be ordered optionally, see chapter "Installation accessories" (→ 54).


1. Connect the cables.



2. The plastic covers must be removed in different ways depending on the cross section used.



3. Attach the plastic covers at the individual connections.



8.7.6 Line connection

- The line contactor must always be located upstream of the line filter.
- Use only line contactors of utilization category AC-3 (EN 60947-4-1) or higher.
- Do not use the line contactor for jog mode, but only for switching the inverter on and off. The FCB 20 "Jog" must be used for jog mode.
- Observe the required dimensioning of the cable cross-section for UL-compliant installation.

For the terminal assignment for line connection of the various sizes, refer to chapter "Terminal assignment".

Observe a minimum switch-off time of 10 s for the inverter. Do not switch the power on more than once per minute.

NOTICE

Non-compliance with the minimum switch-on/switch-off times

Inverter damage.

- Observe a minimum switch-off time of 10 s before switching on the power supply again.
- Do not switch on the supply system more than once per minute/every 2 minutes.

8.7.7 Motor connection

For the terminal assignment for the motor connection of the various devices, refer to chapter "Terminal assignment".

8.7.8 Line contactor

The following table provides an overview of when a line contactor is required and what kind of preventive measures must be taken for the braking resistor used, see chapter "Protection against thermal overload of the braking resistor" (→ 276).

Inverter	Braking resistor	Protective element/ preventive measure	Line contactor required?
Sizes 1 – 3	No braking resistor	-	No
	BW... flat design	-	No
	BW... as PTC	-	No
	BW...	External bimetallic relay	Yes
	BW...-T	External bimetallic relay	Yes
From size 4	No braking resistor	-	No
	BW... flat design	-	No
	BW... as PTC	-	no
	BW...	External bimetallic relay	No
	BW...-T	Temperature contact evaluation	No

If a braking resistor is connected to the inverter from size 4 without using a line contactor, an external DC 24 V voltage supply must be provided on the inverter.


8.7.9 24 V supply voltage

The MDX90A-... application inverter requires an external 24 V voltage supply for the electronics.

The MDX91.A-... application inverter has an internal 24 V voltage supply (80 W) that can also be supported externally.

The maximum cable cross section is 2.5 mm². The maximum permitted length of the 24 V supply cable is 30 m.

Whether an external 24 V supply is required for MDX91A-.. depends on the load, e.g. the encoder supply and the outputs.



15027024779

Select the cross section of the supply cable according to the power demand of the devices to be supplied.

8.7.10 Motor output

NOTICE

Connecting capacitive loads to the application inverter.

Destruction of the application inverter.

- Only connect ohmic/inductive loads (motors).
- Never connect capacitive loads.

8.7.11 Brake chopper output

NOTICE

Connecting capacitive loads to the output of the brake chopper.

Connecting inductive loads to the output of the brake chopper.

Damage to the inverter.

- Only connect ohmic loads (braking resistors) to the output of the brake chopper.
- Never connect capacitive or inductive loads to the output of the brake chopper.

The braking resistor is connected to the +R and -R terminals of the inverter.

The maximum permitted cable length between braking resistor and inverter is 100 m.

8.7.12 Temperature evaluation of the motor

The temperature evaluation unit can be connected in 3 ways:

- The encoder cable includes the cables of the temperature evaluation unit.
- The temperature evaluation unit is connected to terminal X10 via connections TF1 and GND.
- Temperature evaluation via MOVILINK® DDI



⚠ WARNING

Dangerous contact voltages at the terminals of the inverter when connecting the wrong temperature sensors.

Severe or fatal injuries from electric shock.

- Connect only temperature sensors with protective separation from the motor winding to the temperature evaluation unit. Otherwise, the requirements for protective separation are not met. Dangerous contact voltages can occur at the terminals of the inverter via the signal electronics in the event of a fault.
- It is preferable to use TH bimetallic temperature switches for group drives on one inverter.
- The series connection of the TH contacts (normally closed) is not subject to any restriction if joint monitoring is provided.
- If TF temperature sensors are available in motors that are intended for a group drive, the temperature sensors of a maximum of 3 motors may be connected in parallel.

8.7.13 Brake output

INFORMATION



- If the brake connection and the motor connection are combined in one power cable, the brake cable must be shielded separately. The shielding of the power cable and the brake cable must be connected to the motor and inverter over a large area.
- SEW-EURODRIVE recommends also using a shielded brake cable for separate brake cable routing.
- Note the different project planning criteria to determine the length of brake cable and motor cable.

8.7.14 Inputs/outputs

NOTICE

Damage to the digital inputs and digital outputs.

The digital inputs and digital outputs are not electrically isolated. Incorrectly applied voltages can damage the digital inputs and digital outputs.

- Do not apply a voltage > DC 30 V to the digital inputs and digital outputs.
- The digital inputs and outputs are dimensioned according to IEC 61131-2.

If you route the cables outside the control cabinet, you have to shield them irrespective of the length.


When connecting the shielding, ensure equipotential bonding.

8.7.15 Encoders

Installation notes for encoder connection

Encoder cables

- Use shielded cables with twisted pair cores. Connect the shield over a wide area at both ends:
 - At the encoder in the cable gland or in the encoder plug.
 - To the application inverter in the housing of the D-sub connector.



13887834891

- Route the encoder cable separately from the power cables.
- Connect the shield on the inverter end in the housing of the D-sub connector over a large area.

On the encoder/resolver

- To ensure a flawless shield connection, an EMC screw fitting must be used for the cable entry of the signal cable.
- For drives with a plug connector, connect the shield on the encoder plug.

Prefabricated cables

SEW-EURODRIVE offers prefabricated cables for connecting encoders. SEW-EURODRIVE recommends using these prefabricated cables.

Encoder connection/cable lengths

Connection/encoder	Cable length
HTL encoders ES7C, EG7C, and EK8C	300 m
TTL encoder EK8R	300 m
Standard HTL encoder	200 m
MOVILINK® DDI	200 m
Other encoders	100 m

INFORMATION




The maximum cable length might be reduced depending on the technical data of the respective encoder. Observe the manufacturer's specifications.

8.7.16 Installation notes for MOVILINK® DDI

Removing the MOVILINK® DDI connector

Observe the following notes before removing the MOVILINK® DDI connector:

- Remove the MOVILINK® DDI connector only when the 24 V voltage supply is switched off or when standby mode is activated.
- Before removing the MOVILINK® DDI connector X16, press the lock [1] on the connector, see the example figure.



9007229789287051

Connection with hybrid cable


When connecting MOVILINK® DDI with a hybrid cable, observe the following notes:

- Apply the shielding of the hybrid cable over the entire circumference over a large area.
- For inverters of sizes 1 – 4, use the shield plates provided for this purpose on the basic device for the shield connection.
- Keep the distance or cable length between the shield connection and the connection for the cable conductors as short as possible.
- The exposed length of the coaxial cable should not exceed 50 cm.

Connection when power and coaxial cables are routed separately

Sizes 1 – 6


Connect the shield of the coaxial cable to the terminal [1] provided for this purpose.



35756481419

Sizes 7 – 8

Route the coaxial cable in such a way that it passes through the two lugs [2]. Connect the shield of the coaxial cable to the terminal [1] provided for this purpose.



35801464203

Maximum line length

The MOVILINK® DDI interface supports a total cable length of the coaxial cable or coaxial line between the drive and MOVILINK® DDI connection X16 on the inverter of up to 200 m.


Permitted number of connection or cable disconnection points

A maximum of 4 connection or cable disconnection points are permitted at the MOVILINK® DDI interface when using a hybrid cable or a solo coaxial cable. The connection points that are implemented directly on the inverter or in the drive by means of FAKRA connectors are not included in the count. Communication errors can occur if there are more than 4 connection or cable disconnection points.

8.7.17 Installation of the fieldbus cables and cable routing


Proceed as follows to route the fieldbus cables:

1. Remove the safety cover; see the chapter "Covers" (→ 241).
2. Connect both the cables to the connections X40 and X41 on the card.




26077413387

3. Route the cables as shown and press both the cables into the clips.



26077416971

4. Attach the safety cover again.



26077420555


8.8 Installing options and accessories

8.8.1 Installing a card

Observe the safety notes in chapter "Electrical installation" (→ 249).


For information on which option card can be installed in which slot, refer to chapter "Card slots" (→ 232).

1. Disconnect the application inverter from the power supply. Switch off the external 24 V voltage supply for the electronics and the main voltage supply.
2. Before starting work, ensure electrostatic discharge with suitable measures. Suitable measures for equipotential bonding include, for example, using a discharge strap or wearing conductive shoes.
3. Remove the safety cover [1] from the front of the application inverter. The slot in which the card is installed depends on the card used.



9007213554135563

4. Remove the plastic cover [1] of the card slot using a screwdriver.




15160620811

INFORMATION




Hold the card by its edges only.

5. Take the card [1] and insert it into the slot with slight pressure.




15160623243

6. Tighten the card with the specified tightening torque (→ 233).



15160625675

7. Attach the safety cover [1] to the front of the application inverter again.



9007213833196299

8.8.2 CIO21A and CID21A input/output card**INFORMATION**

Technical data of the cards

For technical data and a detailed description of the encoder interface, refer to chapter "Technical data of the cards".

Voltage supply

The I/O cards are supplied by the basic device via the 24 V voltage supply.

Short-circuit behavior of digital outputs

The digital outputs are short-circuit-proof.

As soon as the short circuit is remedied, the target output voltage is output, meaning the output does not switch off.

Short circuit behavior of analog outputs

The analog outputs are short-circuit-proof.

In the event of a short circuit, the output current is limited to a maximum value of 30 mA. The short circuit current is not pulsating.

As soon as the short circuit is remedied, the target output voltage is output, meaning the output does not switch off.

Connecting inductive loads at digital outputs

For inductive loads an external protective element (e.g. freewheeling diode) is required.

Connecting 2 digital outputs in parallel






Connecting digital outputs in parallel is possible. The possible output current is doubled. Ensure identical parameterization of the digital outputs.

Cable lengths and shielding

The maximum cable length of connections on the inputs and outputs is 30 m.



Cables outside the control cabinet must be shielded.

CIO21A terminal assignment

CIO21A	Terminal	Conne- ction	Brief description	
			S50/1 on: Current input active for AI2x S50/2 on: Current input active for AI3x S50/1 off ¹⁾ : Voltage input active for AI2x S50/2 off ¹⁾ : Voltage input active for AI3x	
		X50:1	REF1	+10 V DC reference voltage output
		X50:2	AI21	Analog current and voltage input
		X50:3	AI22	Analog current and voltage input, reference for AI21
		X50:4	GND	Reference potential
		X50:5	AI31	Analog current and voltage input
		X50:6	AI32	Analog current and voltage input, reference for AI31
		X50:7	GND	Reference potential
		X50:8	REF2	-10 V DC reference voltage output
		X51:1	AOV2	Analog voltage output, freely programmable
		X51:2	AOC2	Analog current output, freely programmable
		X51:3	GND	Reference potential for the outputs AOV2 and AOC2
		X51:4	AOV3	Analog voltage output, freely programmable
		X51:5	AOC3	Analog current output, freely programmable
		X51:6	GND	Reference potential for the outputs AOV3 and AOC3
		X52:1	DI10	Digital input 1, freely programmable
		X52:2	DI11	Digital input 2, freely programmable
		X52:3	DI12	Digital input 3, freely programmable
		X52:4	DI13	Digital input 4, freely programmable
		X52:5	GND	Reference potential for the digital inputs DI10 – DI13
		X52:6	DO10	Digital output 1, freely programmable
		X52:7	DO11	Digital output 2, freely programmable
		X52:8	DO12	Digital output 3, freely programmable
		X52:9	DO13	Digital output 4, freely programmable
		X52:10	GND	Reference potential for the digital outputs DO10 – DO13

1) Delivery state

CID21A terminal assignment

CID21A	Terminal		Conne- ction	Brief description
		X52:1	DI10	Digital input 1, freely programmable
		X52:2	DI11	Digital input 2, freely programmable
		X52:3	DI12	Digital input 3, freely programmable
		X52:4	DI13	Digital input 4, freely programmable
		X52:5	GND	Reference potential for the digital inputs DI10 – DI13
		X52:6	DO10	Digital output 1, freely programmable
		X52:7	DO11	Digital output 2, freely programmable
		X52:8	DO12	Digital output 3, freely programmable
		X52:9	DO13	Digital output 4, freely programmable
		X52:10	GND	Reference potential for the digital outputs DO10 – DO13

8.8.3 CES11A multi-encoder card

INFORMATION



Technical data of the cards

For technical data and a detailed description of the encoder interface, refer to the chapter "Technical data of the cards".

Overview of functions

The CES11A multi-encoder card expands the functionality of the application inverter in a way that an additional encoder can be evaluated. The encoder connected to the CES11A multi-encoder card can be used as a motor encoder or external encoder.

Supported encoder types

The following encoder types can be evaluated by the CES11A multi-encoder card:

HTL 12/24 V (differential)
TTL (differential)
RS422
sin/cos 1 V _{PP} (differential)
HIPERFACE® with sin/cos signals 1 V _{PP}
SEW encoder (RS485) with sin/cos signals 1 V _{PP} , e.g. AS7W, AG7W
EnDat 2.1 with sin/cos signals 1 V _{PP}
SSI encoder with/without sin/cos signals 1 V _{PP}
CANopen encoder

Encoder connection/cable lengths



Connection/encoder	Cable length
HTL encoders ES7C, EG7C, and EK8C	300 m
TTL encoder EK8R	300 m
Standard HTL encoder	200 m
MOVILINK® DDI	200 m
Other encoders	100 m

INFORMATION





The maximum cable length might be reduced depending on the technical data of the respective encoder. Observe the manufacturer's specifications.

Terminal assignment of TTL, HTL, sin/cos encoders


Card	Terminal		Connection	Brief description
		X17:1	A (cos+) (K1)	Signal track A (cos+) (K1)
		X17:2	B (sin+) (K2)	Signal track B (sin+) (K2)
		X17:3	C	Signal track C (K0)
		X17:4	DATA+ ¹⁾	Data cable for electronic nameplate
		X17:5	Reserved	—
		X17:6	-TEMP_M	Motor temperature evaluation
		X17:7	Reserved	—
		X17:8	GND	Reference potential
		X17:9	\bar{A} (cos-) ($\bar{K1}$)	Negated signal track \bar{A} (cos-) ($\bar{K1}$)
		X17:10	\bar{B} (sin-) ($\bar{K2}$)	Negated signal track \bar{B} (sin-) ($\bar{K2}$)
		X17:11	\bar{C}	Negated signal track \bar{C} ($\bar{K0}$)
		X17:12	DATA- ¹⁾	Data cable for electronic nameplate
		X17:13	V _{S24VG}	Encoder supply 24 V
		X17:14	+TEMP_M	Motor temperature evaluation
		X17:15	V _{S12VG}	Encoder supply 12 V

1) For encoders from SEW-EURODRIVE with electronic nameplate of type E.7S


Terminal assignment of HIPERFACE® and SEW-EURODRIVE encoders (RS485)

Card	Terminal		Connection	Brief description
		X17:1	A (cos+) (K1)	Signal track A (cos+) (K1)
		X17:2	B (sin+) (K2)	Signal track B (sin+) (K2)
		X17:3	Reserved	–
		X17:4	DATA+	Data line
		X17:5	Reserved	–
		X17:6	-TEMP_M	Motor temperature evaluation
		X17:7	Reserved	–
		X17:8	GND	Reference potential
		X17:9	\bar{A} (cos-) ($\bar{K1}$)	Negated signal track \bar{A} (cos-) ($\bar{K1}$)
		X17:10	\bar{B} (sin-) ($\bar{K2}$)	Negated signal track \bar{B} (sin-) ($\bar{K2}$)
		X17:11	Reserved	–
		X17:12	DATA-	Data line
		X17:13	U _{S24VG}	Encoder supply 24 V
		X17:14	+TEMP_M	Motor temperature evaluation
		X17:15	U _{S12VG}	Encoder supply 12 V



Terminal assignment for EnDat 2.1 encoder

Card	Terminal	Connection	Brief description
	X17:1	A (cos+)	Signal track A (cos+)
	X17:2	B (sin+)	Signal track B (sin+)
	X17:3	PULSE+	Clock signal
	X17:4	DATA+	Data line
	X17:5	Reserved	–
	X17:6	-TEMP_M	Motor temperature evaluation
	X17:7	Reserved	–
	X17:8	GND	Reference potential
	X17:9	\bar{A} (cos-)	Negated signal track \bar{A} (cos-)
	X17:10	\bar{B} (sin-)	Negated signal track \bar{B} (sin-)
	X17:11	PULSE-	Clock signal
	X17:12	DATA-	Data line
	X17:13	U _{S24VG}	Encoder supply 24 V
	X17:14	+TEMP_M	–
	X17:15	U _{S12VG}	Encoder supply 12 V



Terminal assignment of SSI encoders

Card	Terminal	Connection	Brief description
	X17:1	Reserved	–
	X17:2	Reserved	–
	X17:3	PULSE+	Clock signal
	X17:4	DATA+	Data line RS485
	X17:5	Reserved	–
	X17:6	-TEMP_M	Motor temperature evaluation
	X17:7	Reserved	–
	X17:8	GND	Reference potential
	X17:9	Reserved	–
	X17:10	Reserved	–
	X17:11	PULSE-	Clock signal
	X17:12	DATA-	Data line
	X17:13	V _{S24VG}	24 V encoder supply
	X17:14	+TEMP_M	Motor temperature evaluation
	X17:15	V _{S12VG}	12 V encoder supply

Terminal assignment of SSI and sin/cos combination encoders

Card	Terminal		Connection	Brief description
		X17:1	A (cos+)	Signal track A (cos+)
		X17:2	B (sin+)	Signal track B (sin+)
		X17:3	PULSE+	Clock signal
		X17:4	DATA+	Data line
		X17:5	Reserved	—
		X17:6	-TEMP_M	Motor temperature evaluation
		X17:7	Reserved	—
		X17:8	GND	Reference potential
		X17:9	\bar{A} (cos-)	Negated signal track \bar{A} (cos-)
		X17:10	\bar{B} (sin-)	Negated signal track \bar{B} (sin-)
		X17:11	PULSE-	Clock signal
		X17:12	DATA-	Data line
		X17:13	U _{S24VG}	Encoder supply 24 V
		X17:14	+TEMP_M	Motor temperature evaluation
		X17:15	U _{S12VG}	Encoder supply 12 V

Terminal assignment of CANopen encoders

Card	Terminal		Connection	Brief description
		X17:1	Reserved	—
		X17:2	Reserved	—
		X17:3	Reserved	—
		X17:4	CAN_H	CAN high data cable
		X17:5	Reserved	—
		X17:6	-TEMP_M	Motor temperature evaluation
		X17:7	Reserved	—
		X17:8	GND	Reference potential
		X17:9	Reserved	—
		X17:10	Reserved	—
		X17:11	Reserved	—
		X17:12	CAN_L	CAN low data cable
		X17:13	V _{S24VG}	24 V encoder supply
		X17:14	+TEMP_M	Motor temperature evaluation
		X17:15	V _{S12VG}	12 V encoder supply

8.9 BW.. braking resistors

The supply cables to the braking resistors carry a high pulsed DC voltage during operation.



⚠ DANGER

Dangerous pulsed DC voltage of up to 980 V.

Severe or fatal injuries from electric shock.

- Disconnect the inverter from the power supply and wait 10 minutes before working on a braking resistor or its supply cables.
- Never operate the inverter without touch guards and installed closing covers.



⚠ WARNING

The surfaces of the braking resistors will reach temperatures of up to 250 °C when the braking resistors are loaded with the nominal power.

Severe burns.

- Do not touch any braking resistor.
- Select a suitable installation location for the braking resistors such as the control cabinet roof.

8.9.1 Permitted installation of braking resistors

The surfaces of the resistors become very hot if loaded with nominal power. The installation location of the resistor must be designed in accordance with the high temperatures. For this reason, braking resistors are usually mounted on the control cabinet roof.

The following minimum clearances must be observed for convection cooling depending on the continuous braking power and the mounting type.

Continuous braking power at 100% cdf	Mounting type	Lateral clearance or clearance between resistors in mm	Downward clearance in mm	Upward clearance in mm
Up to 1 kW	Horizontal	200	0	350
	Vertical	150	250	300
Up to 10 kW	Horizontal	300	0	650
	Vertical	250	350	600
Up to 22 kW	Horizontal	400	0	750
	Vertical	350	400	700
Up to 44 kW	Horizontal	500	0	850
	Vertical	Not permitted	Not permitted	Not permitted




NOTICE

Overheating of the braking resistor.

Non-permissible installation might lead to heat build-up in the braking resistor due to reduced convection. A tripping temperature contact or an overheated braking resistor can lead to a system standstill.

Observe the following permitted mounting positions when installing the resistors:


- Grid resistor, frame resistor



27021616276683147


Braking resistors BW003-420-T and BW1.0-170 may only be used in position 1.

- Wire resistor



18512455307

- Flat-type resistor



18512457739

8.9.2 Protection against thermal overload of the braking resistor

INFORMATION



PTC braking resistor

A PTC braking resistor becomes highly resistive in the event of an overload.

INFORMATION



Flat-type resistor

Flat-type resistors have internal thermal protection (fuse cannot be replaced) that interrupts the current circuit in the event of overload. The configuration guidelines and the documented assignments of the drive inverter and braking resistor must be adhered to.

Parallel connection of braking resistors


It is permitted to connect several identical braking resistors in parallel. The following applies:

- The power connections of the braking resistors must be connected to +R and -R in parallel.
- Each braking resistor requires separate protection against thermal overload.
- The signal contacts (NC contacts) of the protection devices must be connected in series.

Internal temperature switch -T

Inverters of size 1 – 3

If a BW...-T braking resistor with internal temperature switch is used with these application inverters, there are 3 possible connections.



[1] Line contactor

[3] Inverter

[2] Braking resistor

[4] PLC

Note that the reference potential GND of the digital inputs on the controller must be the same as the reference potential of the application inverter when connection 1 is used.

- Connection 1

The digital input of the application inverter connected to the signal contact of the internal temperature switch must be parameterized to the function "External braking resistor error".

- If the thermal circuit breaker trips, the signal is evaluated in the application inverter and the PLC.
- If the thermal circuit breaker trips, the PLC must interrupt the power supply.
- If the thermal circuit breaker trips, the application inverter switches to "Output stage inhibit".


- Connection 2

- If the thermal circuit breaker trips, the signal is evaluated only in the PLC.
- If the thermal circuit breaker trips, the PLC must interrupt the power supply.
- If the thermal circuit breaker trips, there is no direct response in the application inverter.

- With connection 2, it is possible that the PLC finishes the current travel cycle although the thermal circuit breaker has tripped. Only then is the power supply disconnected. In this case, the residual braking energy $W_{\text{Rest}} = P_{\text{BRnom}} \times 20 \text{ s}$ must not be exceeded.
- Connection 3
 - If the thermal circuit breaker trips, the signal directly affects the line contactor.
 - This does not require a response by the PLC.
 - If the thermal circuit breaker trips, there is no direct response in the application inverter.

Inverters of size 4 and larger

If a BW...-T braking resistor with internal temperature switch is used with these application inverters, there are 3 possible connections.



[1] Line contactor

[2] Braking resistor

[3] Inverter

[4] PLC

• Connection 1

The digital input of the application inverter connected to the signal contact of the internal temperature switch must be parameterized to the function "External braking resistor error".

- If the thermal circuit breaker trips, the signal is evaluated in the application inverter.
- This does not require a response by the PLC.
- It is not required to disconnect the supply system connection with an external switching device.
- If an internal short circuit in the brake chopper is detected by the application inverter, the application inverter interrupts the energy supply by inhibiting the rectifier.

- If the thermal circuit breaker trips, the application inverter switches all axis modules to "Output stage inhibit".

INFORMATION




When using connection variant 1 (connection of braking resistor without line contactor), the application inverter must be supplied with external DC 24 V.

- Connection 2
 - If the thermal circuit breaker trips, the signal is evaluated only in the PLC.
 - If the thermal circuit breaker trips, the PLC must interrupt the power supply.
 - If the thermal circuit breaker trips, there is no direct response in the application inverter.
 - With connection 2, it is possible that the PLC finishes the current travel cycle although the thermal circuit breaker has tripped. Only then is the power supply disconnected. In this case, the residual braking energy $W_{Rest} = P_{BRnom} \times 20 \text{ s}$ must not be exceeded.
- Connection 3
 - If the thermal circuit breaker trips, the signal directly affects the line contactor.
 - This does not require a response by the PLC.
 - If the thermal circuit breaker trips, there is no direct response in the application inverter.

External bimetallic relay

Inverters of size 1 – 3

If an external bimetallic relay is used with the application inverter, there are 3 possible connections.



[1] Line contactor

[3] Inverter

[2] Braking resistor

[4] PLC

Note that the reference potential GND of the digital inputs on the controller must be the same as the reference potential of the application inverter when connection 1 is used.

- Connection 1

The digital input of the application inverter connected to the signal contact of the external bimetallic relay must be parameterized to the function "External braking resistor error".

- If the thermal circuit breaker trips, the signal is evaluated in the application inverter and the PLC.
- If the thermal circuit breaker trips, the PLC must interrupt the power supply.
- If the thermal circuit breaker trips, the application inverter switches to "Output stage inhibit".

- Connection 2


- If the thermal circuit breaker trips, the signal is evaluated only in the PLC.
- If the thermal circuit breaker trips, the PLC must interrupt the power supply.
- If the thermal circuit breaker trips, there is no direct response in the application inverter.
- With connection 2, it is possible that the PLC finishes the current travel cycle although the thermal circuit breaker has tripped. Only then is the power supply disconnected. In this case, the residual braking energy $W_{\text{Rest}} = P_{\text{BRnom}} \times 20 \text{ s}$ must not be exceeded.

- Connection 3

- If the thermal circuit breaker trips, the signal directly affects the line contactor.
- This does not require a response by the PLC.
- If the thermal circuit breaker trips, there is no direct response in the application inverter.

Inverters of size 4 and larger

If an external bimetallic relay is used with the application inverter, there are 3 possible connections.



[1] Line contactor

[2] Braking resistor

[3] Inverter

[4] PLC

- Connection 1

The digital input of the application inverter connected to the signal contact of the external bimetallic relay must be parameterized to the function "External braking resistor error".

- If the thermal circuit breaker trips, the signal is evaluated in the application inverter.
- This does not require a response by the PLC.
- It is not required to disconnect the supply system connection with an external switching device.
- If the thermal circuit breaker trips, the application inverter switches to the operating state "Output stage inhibit".
- If an internal short circuit in the brake chopper is detected by the application inverter, the application inverter interrupts the energy supply by inhibiting the rectifier.

INFORMATION

When using connection variant 1 (connection of braking resistor without line contactor), the application inverter must be supplied with external DC 24 V.


- Connection 2

- If the thermal circuit breaker trips, the signal is evaluated only in the PLC.
- If the thermal circuit breaker trips, the PLC must interrupt the power supply.

- If the thermal circuit breaker trips, there is no direct response in the application inverter.
- With connection 2, it is possible that the PLC finishes the current travel cycle although the thermal circuit breaker has tripped. Only then is the power supply disconnected. In this case, the residual braking energy $W_{\text{Rest}} = P_{\text{BRnom}} \times 20 \text{ s}$ must not be exceeded.
- Connection 3
 - If the thermal circuit breaker trips, the signal directly affects the line contactor.
 - This does not require a response by the PLC.
 - If the thermal circuit breaker trips, there is no direct response in the application inverter.

8.9.3 Connection of the braking resistor with center tap

The following figure shows a braking resistor with center tap.



9007202044405771

- [1] Stepped ohm value
[2] Total ohm value

8.10 NF.. line filter

- Install the line filter close to the inverter but outside the minimum clearance for cooling. The line filter must not be heated by the exhaust air of the application inverter.
- No other consumers may be wired between the line filter and the inverter.
- The connection cable between the line filter and inverter does not have to be shielded.
- Limit the length of the cable between the line filter and the inverter to the required length.
- No switching is allowed between the line filter and the inverter.

8.11 EMC-compliant installation


The information in this chapter will help you to optimize the system with respect to electromagnetic compatibility, or to eliminate already existing EMC interferences.

The notes in this chapter are not legal regulations, but rather recommendations for improving the electromagnetic compatibility of your plant.

For further notes on EMC-compliant installation, refer to the publication Drive Engineering – Practical Implementation edition "EMC in Drive Engineering – Basic Theoretical Principles – EMC-Compliant Installation in Practice".

Compliance with limit classes C1 and C2 has been tested in a CE-typical drive system. SEW-EURODRIVE can provide detailed information on request.

8.11.1 Installation example



19508519307

- | | |
|---|-------------------------------|
| [1] Galvanized mounting plate | [8] Braking resistor |
| [2] Line filter | [9] Braking resistor cable |
| [3] Inverter | [10] Motor cable |
| [4] PE busbar | [11] Brake cable |
| [5] HF connection of PE busbar/
mounting plate | [12] Grounding clamp |
| [6] Supply system cable | [13] Electronics shield plate |
| [7] Power shield plate | [14] HF connection |

8.11.2 Control cabinet

Use control cabinets with electrically conductive (galvanized) mounting plates. If several mounting plates are used, connect them in such a way that they are conductive over a large area.

Mount the line filter and inverter on a shared mounting plate if possible. Make sure they are connected over a large area and with good conductivity.

8.11.3 HF equipotential bonding in the system

Make sure that there is a suitable equipotential bonding between the system, the control cabinet, the machine structure, the cable ducts, and the drives.

Connect the individual sections together in an HF-compatible manner.

From an electrical safety perspective, the PE busbar is the star point. However, the PE connection does not replace either the HF grounding or the shielding.

In terms of EMC, it is advantageous if the mounting plate is used as a star point with respect to HF equipotential bonding.

Perform the following measures for a suitable HF equipotential bonding:

- Connect the PE busbar to the mounting plate in an HF-compatible manner.
- Connect the sheet metal cable ducts to the control cabinet in an HF-compatible manner.
- Connect the cable ducts to the mounting plate in the control cabinet using a high frequency litz wire.
- Connect the parts of the sheet metal cable ducts together in an HF-compatible manner.
- Connect the sheet metal cable ducts to the gearmotor in an HF-compatible manner.

8.11.4 Cable installation

Route the power cables, such as the motor cable and the brake cable, separately from the supply system cable and the control cables.

Route all cables as closely to the reference potential as possible, e.g. the mounting plate.

Keep all cables as short as possible. Avoid spare loops.

8.11.5 Supply system cable connection

The supply system cable can be connected to the line choke and/or line filter using twisted unshielded single conductors or using unshielded cables.

If necessary, shielded cables may improve EMC.


8.11.6 Line filter connection

Limit the length of the connection lead between the line filter and the inverter to the absolute minimum needed.

You must never route filtered and unfiltered cables together. For this reason, route incoming and outgoing line filter cables separately.

8.11.7 Braking resistor connection

For connecting braking resistors, use two closely twisted cores or a shielded power cable. In the case of shielded cables, connect the braided shields over the entire circumference. Use the designated shield plates on the basic device to connect the shield.




19508521739

8.11.8 Motor and brake connection

Use shielded motor cables only. Connect the braided shield of the motor cable at both ends over its entire circumference to the power shield plate at the inverter.

Provide shielded cables for the brake supply. The shield of the brake cable can be connected to the power shield plate at the inverter.

If the motor cable and brake cable are combined in a shared cable, the cable must have an inner shield separating the brake cables from the motor cores. The cables also possess an overall shield.



19508524171


SEW-EURODRIVE recommends the use of prefabricated cables.

In the event of especially high EMC requirements, an additional connection point for the shield is recommended. To limit the emitted interference, the motor shield can additionally be grounded to the control cabinet outlet using commercial installation materials (grounding clamps or EMC screw fittings).

8.11.9 Control cable connection

Ensure that the digital inputs are connected with unshielded individual cores. Shielded cables increase the EMC. Use the designated shield plates to connect the shield.

For routing outside of the control cabinet, you must use shielded cables.



19508526603

8.11.10 Encoder connection

SEW-EURODRIVE recommends the use of prefabricated encoder cables.

The shield of prefabricated cables from SEW-EURODRIVE is connected via the connector.

8.11.11 Shielding connection

Ensure that there is an HF-compatible shield connection, e.g. by using grounding clamps or EMC cable glands, so that the braided shield has a large connection surface.

8.12 Terminal assignment of basic device

INFORMATION



Reference potentials inside the device.

The device-internal reference potential is designated as GND in the following table.

All reference potentials GND are internally connected to PE.

INFORMATION





The assignment "Reserved" means that no cable may be connected to this connection.

INFORMATION







The technical data for the power and control electronics connections is provided in chapter "Technical data".

8.12.1 Sizes 1 – 3

Illustration	Terminal	Connection	Assignment
	X1:L1	L1	Line connection
	X1:L2	L2	
	X1:L3	L3	
	X1:-U _Z	-U _Z	DC link connection
	X1:+U _Z	+U _Z	
	⊕	PE	PE connection
	X2:U	U	Motor connection
	X2:V	V	
	X2:W	W	
	X2:+R	+R	Braking resistor connection
	X2:-R	-R	
	⊕	PE	PE connection

8.12.2 Size 4



Illustration	Terminal	Connection	Assignment
 	X1:L1	L1	Line connection
	X1:L2	L2	
	X1:L3	L3	
	X1:-U _z	-U _z	DC link connection
	X1:+U _z	+U _z	
	⊕	PE	PE connection
 	X2:U	U	Motor connection
	X2:V	V	
	X2:W	W	
	X2:+R	+R	Braking resistor connection
	X2:-R	-R	
	⊕	PE	PE connection

8.12.3 Sizes 5 – 8

INFORMATION



Size 8 is not yet available.

Illustration	Terminal	Connection	Assignment
	X1:L1	L1	Line connection
	X1:L2	L2	
	X1:L3	L3	
	X1:-U _z	-U _z	DC link connection
	X1:+U _z	+U _z	
	⊕	PE	PE connection
	X2:U	U	Motor connection
	X2:V	V	
	X2:W	W	
	X2:+R	+R	Braking resistor connection
	X2:-R	-R	
	⊕	PE	PE connection

8.12.4 Sizes 7 – 8

INFORMATION



Size 8 is not yet available.

Illustration	Terminal	Connection	Assignment
	-U _Z *	-U _Z	Connection in front of DC link choke
	+U _Z *	+U _Z	





8.12.5 Sizes 1 – 8

INFORMATION




Size 8 is not yet available.


Illustration	Terminal	Connection	Assignment
	X5:24 V	V _I 24 V	DC 24 V supply voltage
	X5:GND	GND	Reference potential
	X10:DB0	DB00	Brake control
	X10:DB00		
	X10:GND	GND	Reference potential
	X10:TF1	TF1	Sensor input for temperature evaluation of the motor
	X10:GND	GND	Reference potential
	X30 OUT		EtherCAT®/SBus ^{PLUS} system bus
	X30 IN		
	X32		SEW-EURODRIVE Service interface Interface for keypad

Illustration	Terminal	Connection	Assignment
	X20:1	DI00	Digital input 1, with fixed assignment "Output stage enable"
	X20:2	DI01	Digital input 2, fixed setpoints – positive direction of rotation
	X20:3	DI02	Digital input 3, fixed setpoints – negative direction of rotation
	X20:4	DI03	Digital input 4, fixed speed setpoint bit 0
	X20:5	DI04	Digital input 5, fixed speed setpoint bit 1
	X20:6	DI05	Digital input 6, fault reset
	X20:7	Reserved	–
	X20:8	Reserved	–
	X20:9	GND	Reference potential
	X21:1	+24 V	DC 24 V voltage output
	X21:2	DO00	Digital output 1, operational
	X21:3	DO01	Digital output 2, output stage enable
	X21:4	DO02	Fault at digital output 3
	X21:5	DO03	Digital output 4, STO active
	X21:6	GND	Reference potential
	X22:1	DOR-C	Shared relay contact
	X22:2	DOR-NO	NO contact
	X22:3	DOR-NC	NC contact
	X22:4	Reserved	–
	X22:5	GND	GND
	X6:1	F_STO_P1	DC +24 V input F_STO_P1
	X6:2	F_STO_M	DC 0 V input F_STO_M
	X6:3	F_STO_P2	DC +24 V input F_STO_P2
	X6:4	GND	Reference potential
	X6:5	24 V STO_OUT	U_{out} = DC 24 V supply of F_STO_P1 and F_STO_P2

8.12.6 X15: Motor encoder – resolver


Illustration	Terminal	Connection	Assignment
	X15:1	S2 (sin+)	Signal track
	X15:2	S1 (cos+)	Signal track
	X15:3	Reserved	-
	X15:4	Reserved	-
	X15:5	R1 (REF+)	Supply voltage of resolver
	X15:6	-TEMP_M	Motor temperature evaluation
	X15:7	Reserved	-
	X15:8	Reserved	-
	X15:9	S4 (sin-)	Signal track
	X15:10	S3 (cos-)	Signal track
	X15:11	Reserved	-
	X15:12	Reserved	-
	X15:13	R2 (REF-)	Supply voltage of resolver
	X15:14	+TEMP_M	Motor temperature evaluation
	X15:15	Reserved	-

8.12.7 X15: Motor encoder – sin/cos encoder


Illustration	Terminal	Connection	Assignment
	X15:1	A (cos+) (K1)	Signal track A (cos+) (K1)
	X15:2	B (sin+) (K2)	Signal track B (sin+) (K2)
	X15:3	C (K0)	Signal track C (K0)
	X15:4	DATA+ ¹⁾	Data cable for electronic nameplate
	X15:5	Reserved	–
	X15:6	-TEMP_M	Motor temperature evaluation
	X15:7	Reserved	–
	X15:8	GND	Reference potential
	X15:9	\bar{A} (cos -) ($\bar{K1}$)	Negated signal track \bar{A} (cos-) ($\bar{K1}$)
	X15:10	\bar{B} (sin-) ($\bar{K2}$)	Negated signal track \bar{B} (sin-) ($\bar{K2}$)
	X15:11	\bar{C} ($\bar{K0}$)	Negated signal track \bar{C} ($\bar{K0}$)
	X15:12	DATA- ²⁾	Data cable for electronic nameplate
	X15:13	V _{S24VG}	Encoder supply 24 V
	X15:14	+TEMP_M	Motor temperature evaluation
	X15:15	V _{S12VG}	Encoder supply 12 V

1) For encoders from SEW-EURODRIVE with electronic nameplate.


8.12.8 X15: Motor encoder – TTL encoder

Illustration	Terminal	Connection	Assignment
	X15:1	A (K1)	Signal track A (K1)
	X15:2	B (K2)	Signal track B (K2)
	X15:3	C (K0)	Signal track C (K0)
	X15:4	Reserved	–
	X15:5	Reserved	–
	X15:6	-TEMP_M	Motor temperature evaluation
	X15:7	Reserved	–
	X15:8	GND	Reference potential
	X15:9	\bar{A} ($\overline{K1}$)	Negated signal track \bar{A} ($\overline{K1}$)
	X15:10	\bar{B} ($\overline{K2}$)	Negated signal track \bar{B} ($\overline{K2}$)
	X15:11	\bar{C} ($\overline{K0}$)	Negated signal track \bar{C} ($\overline{K0}$)
	X15:12	Reserved	–
	X15:13	V _{S24VG}	Encoder supply 24 V
	X15:14	+TEMP_M	Motor temperature evaluation
	X15:15	V _{S12VG}	Encoder supply 12 V


8.12.9 X15: HIPERFACE® motor encoder, SEW-EURODRIVE encoder

Illustration	Terminal	Connection (RS485)	Assignment
	X15:1	A (cos+) (K1)	Signal track A (cos+) (K1)
	X15:2	B (sin+) (K2)	Signal track B (sin+) (K2)
	X15:3	Reserved	–
	X15:4	DATA+	Data line RS485
	X15:5	Reserved	–
	X15:6	-TEMP_M	Motor temperature evaluation
	X15:7	Reserved	–
	X15:8	GND	Reference potential
	X15:9	\bar{A} (cos -) ($\overline{K1}$)	Negated signal track \bar{A} (cos-) ($\overline{K1}$)
	X15:10	\bar{B} (sin-) ($\overline{K2}$)	Negated signal track \bar{B} (sin-) ($\overline{K2}$)
	X15:11	Reserved	–
	X15:12	DATA-	Signal cable
	X15:13	V _{S24VG}	Encoder supply 24 V
	X15:14	+TEMP_M	Motor temperature evaluation
	X15:15	V _{S12VG}	Encoder supply 12 V

8.12.10 X15: SEW-EURODRIVE encoder with RS485 interface

Illustration	Terminal	Connection (RS485)	Assignment
	X15:1	A (cos+) (K1)	Signal track A (cos+) (K1)
	X15:2	B (sin+) (K2)	Signal track B (sin+) (K2)
	X15:3	Reserved	–
	X15:4	DATA+	Data line RS485
	X15:5	Reserved	–
	X15:6	-TEMP_M	Motor temperature evaluation
	X15:7	Reserved	–
	X15:8	GND	Reference potential
	X15:9	\bar{A} (cos -) ($\overline{K1}$)	Negated signal track \bar{A} (cos-) ($\overline{K1}$)
	X15:10	\bar{B} (sin-) ($\overline{K2}$)	Negated signal track \bar{B} (sin-) ($\overline{K2}$)
	X15:11	Reserved	–
	X15:12	DATA-	Signal cable
	X15:13	V_{S24VG}	Encoder supply 24 V
	X15:14	+TEMP_M	Motor temperature evaluation
	X15:15	V_{S12VG}	Encoder supply 12 V

8.12.11 X16: MOVILINK® DDI interface

Illustration	Terminal	Connection	Assignment
	X16	Coaxial connection	MOVILINK® DDI


8.13 Wiring diagrams

8.13.1 General information on the wiring diagrams

- For technical data of the power electronics and the control electronics, refer to chapter "Technical data".
- For the terminal assignment and connections, refer to chapter "Terminal assignment of basic device" (→ 289).

8.13.2 Power connection

Wiring of the power connections with line contactor, line choke, line filter, and output choke



- [1] Fuses
- [2] Line contactor
- [3] Line choke (optional)
- [4] Line filter (optional)

- [5] Braking resistor (optional)
- [6] Output choke and/or output filter (both optional)
- [7] Motor

63050408662092427

Wiring of the power connections with line choke, line filter, output choke, without line contactor

Refer to the table in chapter "Line contactor" (→ 254) to find out which application inverters can be operated without a line contactor.

NOTICE

Operation without line contactor.


If the required measures are not taken, operation of an application inverter with connected braking resistor without line contactor may result in severe damage to property.

Refer to the chapter "Line contactor" (→ 254) for the necessary measures.



INFORMATION

For line connection without line contactor, the temperature evaluation of the braking resistor must be ensured via a digital input on the application inverter. The connected digital input must be parameterized for monitoring the braking resistor temperature evaluation.




54043209407696267


- | | |
|----------------------------|---|
| [1] Fuses | [4] Braking resistor (optional) |
| [2] Line choke (optional) | [5] Output choke and/or output filter (both optional) |
| [3] Line filter (optional) | [6] Motor |

8.13.3 Brake control


Key:




Cut-off in the DC and AC circuits
(rapid brake application)




Cut-off in the DC circuit




Brake
BS = Accelerator coil
TS = Coil section



DC brake with one brake coil



Auxiliary terminal strip in terminal box



Control cabinet limit

WH

White

RD

Red

BU


Blue

INFORMATION




The selection of the brake control and the shown connection diagrams only represent one of the many possibilities. Observe the catalogs and operating instructions of the motors for more information and installation notes.


BMK. brake control




BMV brake control – 2 coils




BMV brake control – 1 coil




BMS, BME brake control




BMP brake control




BG, BGE brake control



BSG brake control




Brake control SBM with 1 control cable



- [1] Connection of the brake with 3-wire technology (standard)
- [2] Connection of the brake with 2-wire technology (optional). In this case, there is no connection from terminal X14:14 of the brake module to terminal 3a of the auxiliary terminal strip.

Brake control SBM with 2 control cables



9007232118783115


- [1] Connection of the brake with 3-wire technology (standard)
- [2] Connection of the brake with 2-wire technology (optional). In this case, there is no connection from terminal X14:14 of the brake module to terminal 3a of the auxiliary terminal strip.

8.13.4 Electronics connection

For the assignment of the signal terminals and connections, refer to chapter "Terminal assignment of basic device" (→ 289).

Wiring of the control electronics – front

The assignment of the digital inputs and outputs shown here is the factory setting.




18014424112917771

S3 Module bus operating mode
X20 Digital inputs
X21 Digital outputs
X22 Isolated relay contact

Wiring of the control electronics – top and bottom

The assignment of the digital inputs and outputs shown here is the factory setting.




9007223162791691

- X5 24 V supply voltage
- X6 Connection for Safe Torque Off (STO)
With installed CS.A card, the cable bridges are removed at the factory.
If no CS.A card is installed upon delivery, the cable bridges are installed at the factory.
- X10 Connection of brake control and motor temperature monitoring
- X15 Motor encoder connection
- X16 Connection of MOVILINK® DDI digital motor integration
- X30 SBus^{PLUS}/EtherCAT® system bus

8.13.5 Connection diagram CIO21A and CID21A input/output card


Digital inputs and outputs



18014412829087243


[1] Higher-level controller

Voltage input



9007213575393675


Connection to the terminals AI31 and AI32 is carried out analogously to the connection to the terminals AI21 and AI22 shown in the wiring diagrams.



18014412830137099

Connection to the terminals REF2 and AI31 is carried out analogously to the connection to the terminals REF1 and AI21 shown in the wiring diagrams.


Current input



9007213575398539

Observe the switch position of "DIP switch S50" (→ 267) when activating the current input.


Voltage output



18014412830141963

Connection to the terminals AOV2 and GND is carried out analogously to the connection to the terminals AOV1 and GND shown in the wiring diagram.

Current output



18014412830272395

Connection to the terminals AOC2 and GND is carried out analogously to the connection to the terminals AOC1 and GND shown in the wiring diagram.

8.14 Information regarding UL

INFORMATION



- Use only tested units with a limited output voltage ($V_{\max} = \text{DC } 30 \text{ V}$) and limited output current ($I_{\max} = 8 \text{ A}$) as an external DC 24 V voltage source.
- UL certification does not apply to operation in voltage supply systems with a non-grounded star point (IT systems).

8.14.1 Field wiring power terminals

- Use 60/75 °C copper wire only.
- Tighten terminals to in-lbs (Nm) as follows:

Tightening torque in-lbs (Nm)				
		Line connection		Motor and braking resistor terminals
MDX9.A-...-5.3-...				
0020 - 0160	X1	4.43 – 7.08 (0.5 – 0.8) Wire sizes 14 – 12 AWG	X2	4.43 – 7.08 (0.5 – 0.8) Wire sizes 14 – 12 AWG
0240 - 0320	X1	15.05 – 15.93 (1.7 – 1.8)	X2	15.05 – 15.93 (1.7 – 1.8)
0460 - 0750	X1	75.2 – 84.1 (8.5 – 9.5)	X2	75.2 – 84.1 (8.5 – 9.5)
0910 - 1490	X1	159.3 – 194.7 (18 – 22)	X2	159.3 – 194.7 (18 – 22)
MDX9.A-...-2.3-...				
		Line connection		Motor and braking resistor terminals
0070 - 0140	X1	4.43 – 7.08 (0.5 – 0.8) Wire sizes 14 – 12 AWG	X2	4.43 – 7.08 (0.5 – 0.8) Wire sizes 14 – 12 AWG
0213 - 0290	X1	15.05 – 15.93 (1.7 – 1.8)	X2	15.05 – 15.93 (1.7 – 1.8)
0420 - 0570	X1	75.2 – 84.1 (8.5 – 9.5)	X2	75.2 – 84.1 (8.5 – 9.5)
0840 - 1080	X1	159.3 – 194.7 (18 – 22)	X2	159.3 – 194.7 (18 – 22)
All modules		PE connection		
		M4: 8.85 – 10.62 (1.0 – 1.2) M6: 26.55 – 35.4 (3.0 – 4.0)		

8.14.2 Short circuit current rating

Suitable for use on a circuit capable of delivering not more than

- 5,000/10,000 rms symmetrical amperes when protected by circuit breakers and Type E combination motor controllers as described in the tables below.
- 65,000 rms symmetrical amperes when protected by fuses, circuit breakers and Type E combination motor controllers as described in the tables below.

Max. voltage is limited to 240 V (230 V units only) or 500 V (400 V units only).

8.14.3 Branch circuit protection

Integral solid state short circuit protection does not provide branch circuit protection. Branch circuit protection must be provided in accordance with the National Electrical Code and any additional local codes.

- If you use cable cross sections that are dimensioned for a smaller current than the rated current of the unit, make sure that the fuse is dimensioned for the used cable cross section.
- For information on selecting cable cross sections, refer to the project planning manual.
- Comply with the country-specific installation regulations in addition to the above notes.

AC 380 – 500 V devices

MDX9.A-..	SCCR: 5 kA/ 500 V		
	Non semiconductor fuses (currents are maximum values)	Inverse-time circuit breaker (currents are maximum values)	Type E Combination Motor Controller
0020-5.3-4-y (size 1)	-	50 A/500 V min.	Siemens Sirius 3RV2011-1CA10 1.8 – 2.5 A, 480 V
0025-5.3-4-y (size 1)	-	50 A/500 V min.	Siemens Sirius 3RV2011-1CA10 1.8 – 2.5 A, 480 V
0032-5.3-4-y (size 1)	-	50 A/500 V min.	Siemens Sirius 3RV2011-1EA10 2.8 – 4 A, 480 V
0040-5.3-4-y (size 1)	-	50 A/500 V min.	Siemens Sirius 3RV2011-1EA10 2.8 – 4 A, 480 V
0055-5.3-4-y (size 2)	-	50 A/500 V min.	Siemens Sirius 3RV2011-1GA10 4.5 – 6.3 A, 480 V
0070-5.3-4-y (size 2)	-	50 A/500 V min.	Siemens Sirius 3RV2011-1HA10 5.5 – 8 A, 480 V
0095-5.3-4-y (size 2)	-	50 A/500 V min.	Siemens Sirius 3RV2011-1JA10 7 – 10 A, 480 V
0125-5.3-4-y (size 3)	-	50 A/500 V min.	Siemens Sirius 3RV2011-4AA10 10 – 16 A, 480 V
0160-5.3-4-y (size 3)	-	50 A/500 V min.	Siemens Sirius 3RV2011-4AA10 10 – 16 A, 480 V
0240-5.3-4-y (size 4)	-	60 A/500 V min.	Siemens Sirius 3RV2021-4DA10 18 – 25 A, 480 V
0320-5.3-4-y (size 4)	-	60 A/500 V min.	Siemens Sirius 3RV2031-4EA10 22 – 32 A, 480 V
0460-5.3-4-y (size 5)	-	125 A/500 V min.	Siemens Sirius 3RV2031-4VA10 35 – 45 A, 480 V
0620-5.3-4-y (size 5)	-	125 A/500 V min.	Siemens Sirius 3RV2041-4JA10 45 – 63 A, 480 V
0750-5.3-4-y (size 5)	-	125 A/500 V min.	Siemens Sirius 3RV2041-4KA10 57 – 75 A, 480 V

MDX9.A-..	SCCR: 10 kA/ 500 V		
	Non semiconductor fuses (currents are maximum values)	Inverse-time circuit breaker (currents are maximum values)	Type E Combination Motor Controller
0910-5.3-4-y (size 6)	-	225 A/500 V min.	Siemens Sirius 3RV2041-4YA10 75 – 93 A, 480 V
1130-5.3-4-y (size 6)	-	225 A/500 V min.	-
1490-5.3-4-y (size 6)	-	225 A/500 V min.	-

MDX9.A-..	SCCR: 65 kA/ 500 V		
	Non semiconductor fuses (currents are maximum values)	Inverse-time circuit breaker (currents are maximum values)	Type E Combination Motor Controller

MDX9.A-..	SCCR: 65 kA/ 500 V		
0020-5.3-4-y (size 1)	50 A/600 V Class: CA, CB, CD, CF, G, J, K-1, K-5, RK1, RK5, T	50 A/500 V min.	Siemens Sirius 3RV2011-1CA10 1.8 – 2.5 A, 480 V
0025-5.3-4-y (size 1)	50 A/600 V Class: CA, CB, CD, CF, G, J, K-1, K-5, RK1, RK5, T	50 A/500 V min.	Siemens Sirius 3RV2011-1CA10 1.8 – 2.5 A, 480 V
0032-5.3-4-y (size 1)	50 A/600 V Class: CA, CB, CD, CF, G, J, K-1, K-5, RK1, RK5, T	50 A/500 V min.	Siemens Sirius 3RV2011-1EA10 2.8 – 4 A, 480 V
0040-5.3-4-y (size 1)	50 A/600 V Class: CA, CB, CD, CF, G, J, K-1, K-5, RK1, RK5, T	50 A/500 V min.	Siemens Sirius 3RV2011-1EA10 2.8 – 4 A, 480 V
0055-5.3-4-y (size 2)	50 A/600 V Class: CA, CB, CD, CF, G, J, K-1, K-5, RK1, RK5, T	50 A/500 V min.	Siemens Sirius 3RV2011-1GA10 4.5 – 6.3 A, 480 V
0070-5.3-4-y (size 2)	50 A/600 V Class: CA, CB, CD, CF, G, J, K-1, K-5, RK1, RK5, T	50 A/500 V min.	Siemens Sirius 3RV2011-1HA10 5.5 – 8 A, 480 V
0095-5.3-4-y (size 2)	50 A/600 V Class: CA, CB, CD, CF, G, J, K-1, K-5, RK1, RK5, T	50 A/500 V min.	Siemens Sirius 3RV2011-1JA10 7 – 10 A, 480 V
0125-5.3-4-y (size 3)	50 A/600 V Class: CA, CB, CD, CF, G, J, K-1, K-5, RK1, RK5, T	50 A/500 V min.	Siemens Sirius 3RV2011-4AA10 10 – 16 A, 480 V
0160-5.3-4-y (size 3)	50 A/600 V Class: CA, CB, CD, CF, G, J, K-1, K-5, RK1, RK5, T	50 A/500 V min.	Siemens Sirius 3RV2011-4AA10 10 – 16 A, 480 V
0240-5.3-4-y (size 4)	60 A/600 V Class: CA, CB, CD, CF, G, J, K-1, K-5, RK1, RK5, T	60 A/500 V min.	Siemens Sirius 3RV2021-4DA10 18 – 25 A, 480 V
0320-5.3-4-y (size 4)	60 A/600 V Class: CA, CB, CD, CF, G, J, K-1, K-5, RK1, RK5, T	60 A/500 V min.	Siemens Sirius 3RV2031-4EA10 22 – 32 A, 480 V
0460-5.3-4-y (size 5)	125 A/600 V Class: J, K-1, RK1, T	125 A/500 V min.	Siemens Sirius 3RV2031-4VA10 35 – 45 A, 480 V
0620-5.3-4-y (size 5)	125 A/600 V Class: J, K-1, RK1, T	125 A/500 V min.	Siemens Sirius 3RV2041-4JA10 45 – 63 A, 480 V
0750-5.3-4-y (size 5)	125 A/600 V Class: J, K-1, RK1, T	125 A/500 V min.	Siemens Sirius 3RV2041-4KA10 57 – 75 A, 480 V
0910-5.3-4-y (size 6)	225 A/600 V Class: J, T	225 A/500 V min.	Siemens Sirius 3RV2041-4YA10 75 – 93 A, 480 V
1130-5.3-4-y (size 6)	225 A/600 V Class: J, T	225 A/500 V min.	-
1490-5.3-4-y (size 6)	225 A/600 V Class: J, T	225 A/500 V min.	-

AC 200 – 240 V devices

MDX9.A-..	SCCR: 5 kA/ 240 V		
	Non semiconductor fuses (currents are maximum values)	Inverse-time circuit breaker (currents are maximum values)	Type E Combination Motor Controller
0070-2.3-4-y (size 2)	-	50 A/500 V min.	Siemens Sirius 3RV2011-1HA10 5.5 – 8 A, 480 V
0093-2.3-4-y (size 2)	-	50 A/500 V min.	Siemens Sirius 3RV2011-1JA10 7 – 10 A, 480 V
0140-2.3-4-y (size 3)	-	50 A/500 V min.	Siemens Sirius 3RV2011-4AA10 10 – 16 A, 480 V

MDX9.A-..	SCCR: 5 kA/ 240 V		
0213-2.3-4-y (size 4)	-	60 A/500 V min.	Siemens Sirius 3RV2021-4DA10 18 – 25 A, 480 V
0290-2.3-4-y (size 4)	-	60 A/500 V min.	Siemens Sirius 3RV2031-4EA10 22 – 32 A, 480 V
0420-2.3-4-y (size 5)	-	125 A/500 V min.	Siemens Sirius 3RV2031-4VA10 35 – 45 A, 480 V
0570-2.3-4-y (size 5)	-	125 A/500 V min.	Siemens Sirius 3RV2041-4JA10 45 – 63 A, 480 V
0840-2.3-4-y (size 6)	-	225 A/500 V min.	Siemens Sirius 3RV2041-4YA10 75 – 93 A, 480 V
1080-2.3-4-y (size 6)	-	225 A/500 V min.	Siemens Sirius 3RV2041-4YA10 75 – 93 A, 480 V

MDX9.A-..	SCCR: 65 kA/ 240 V		
	Non semiconductor fuses (currents are maximum values)	Inverse-time circuit breaker (currents are maximum values)	Type E Combination Motor Controller
0070-2.3-4-y (size 2)	50 A/600 V Class: CA, CB, CD, CF, G, J, K-1, K-5, RK1, RK5, T	50 A/500 V min.	Siemens Sirius 3RV2011-1HA10 5.5 – 8 A, 480 V
0093-2.3-4-y (size 2)	50 A/600 V Class: CA, CB, CD, CF, G, J, K-1, K-5, RK1, RK5, T	50 A/500 V min.	Siemens Sirius 3RV2011-1JA10 7 – 10 A, 480 V
0140-2.3-4-y (size 3)	50 A/600 V Class: CA, CB, CD, CF, G, J, K-1, K-5, RK1, RK5, T	50 A/500 V min.	Siemens Sirius 3RV2011-4AA10 10 – 16 A, 480 V
0213-2.3-4-y (size 4)	60 A/600 V Class: CA, CB, CD, CF, G, J, K-1, K-5, RK1, RK5, T	60 A/500 V min.	Siemens Sirius 3RV2021-4DA10 18 – 25 A, 480 V
0290-2.3-4-y (size 4)	60 A/600 V Class: CA, CB, CD, CF, G, J, K-1, K-5, RK1, RK5, T	60 A/500 V min.	Siemens Sirius 3RV2031-4EA10 22 – 32 A, 480 V
0420-2.3-4-y (size 5)	125 A/600 V Class: J, K-1, RK1, T	125 A/500 V min.	Siemens Sirius 3RV2031-4VA10 35 – 45 A, 480 V
0570-2.3-4-y (size 5)	125 A/600 V Class: J, K-1, RK1, T	125 A/500 V min.	Siemens Sirius 3RV2041-4JA10 45 – 63 A, 480 V
0840-2.3-4-y (size 6)	225 A/600 V Class: J, T	225 A/500 V min.	Siemens Sirius 3RV2041-4YA10 75 – 93 A, 480 V
1080-2.3-4-y (size 6)	225 A/600 V Class: J, T	225 A/500 V min.	Siemens Sirius 3RV2041-4YA10 75 – 93 A, 480 V

8.14.4 Motor overload protection

The units are provided with load and speed-sensitive overload protection and thermal memory retention upon shutdown or power loss.

The trip current is adjusted to 150% of the rated motor current.

8.14.5 Ambient temperature

The units are suitable for a maximum surrounding air temperature of 40 °C, max. 60 °C with derated output current.

To determine output current rating at higher than 40 °C, the output current should be derated 3.0% per °C between 40 °C and 60 °C.

8.14.6 Environmental conditions

The units are for use in pollution degree 2 environments.

8.14.7 Wiring Diagrams

For wiring diagrams, refer to chapter "Wiring Diagrams" in Operating Instructions "MOVIDRIVE® system" or "MOVIDRIVE® technology".

9 Startup

9.1 General

9.1.1 Lifting applications



⚠ WARNING

Danger of fatal injury if the hoist falls.

Severe or fatal injuries.

- The inverter is not designed for use as a safety device in lifting applications. Use monitoring systems or mechanical protection devices to ensure safety.



INFORMATION

Lifting application with encoder

The controller must be designed in such a way that the direction of rotation of the drive can only be reversed when it is at a standstill (with the brake applied).

If the direction of rotation should be changed without standstill, a motor encoder must be used.

9.1.2 Connecting power

NOTICE

Undercutting the minimum switch-off time of the line contactor.

Irreparable damage to the inverter or unforeseeable malfunctions.

Adhere to the specified times and intervals.

- After disconnection from the supply system, observe a minimum switch-off time of 10 s.
- Do **not** turn the power of the supply system on or off **more than once per minute**.

9.1.3 Connecting the cables

NOTICE

Cables may only be connected and plugged in a de-energized state.

Irreparable damage to the inverter or unforeseeable malfunctions.

- De-energize the inverter.

9.2 Setting the EtherCAT® ID

An EtherCAT® ID can be permanently assigned to the application inverter using the hexadecimal switches S1 and S2. With these switches, you can set a decimal EtherCAT® ID between 1 and 255 in hexadecimal notation.

The ID serves as a unique device identification of the respective EtherCAT® slave for the EtherCAT® master. The EtherCAT® ID is not an EtherCAT® address.


In the delivery state of the application inverter, the ID is set to 0 by default (S1 = 0 and S2 = 0).

Setting an EtherCAT® ID is not mandatory. The slaves are automatically addressed by the master by default.

The EtherCAT® ID must only be set at the application inverter if the use of EtherCAT® IDs was preset in the hardware configuration of the master.


Required ID, decimal	ID, hexadecimal	Setting S1 (× 10)	Setting S2 (× 1)
3	03	0	3
18	12	1	2
25	19	1	9
100	64	6	4
110	6E	6	E
255	FF	F	F

S1 EtherCAT® ID (×10)



6

S2 EtherCAT® ID (×1)



E

The EtherCAT® ID "110" is set as an example in the illustration above.

9.3 Startup requirements

The following requirements apply to startup:

- You have installed the application inverter correctly, both mechanically and electrically.
- You have configured the application inverter and connected drives correctly.
- Safety measures prevent accidental startup of the drive.
- Safety precautions prevent danger to persons or machines.

You can perform startup in different ways:

- If you use a power-adjusted motor, you can dispense with startup (operation without startup), depending on the requirements.
- You can perform startup using the MOVISUITE® engineering software.

9.3.1 Required hardware for startup with MOVISUITE®

- USM21A interface adapter (28231449)
- Serial interface cable RJ10 ↔ D-sub 9 (18123864)
or
- Keypad CBG11A, CBG21A or CBG22A
- USB cable A ↔ mini B
or
- Ethernet cable (category 6) and access via EtherCAT®/Ethernet/PROFINET

Part number	Scope of delivery
28231449	<ul style="list-style-type: none"> • USM21A interface adapter • Serial interface cable with 2 × RJ10 connectors • USB cable (A-B)
18123864	<ul style="list-style-type: none"> • Serial interface cable RJ10 ↔ D-sub 9

9.4 Startup with MOVISUITE® engineering software

The inverters are started up using the MOVISUITE® engineering software from SEW-EURODRIVE.



9007214897993483

The motor is started up in drive train 1 or drive train 2.

When using a motor from SEW-EURODRIVE, select the motor type from the catalog.


When using a third-party motor, enter the corresponding nominal motor data. SEW-EURODRIVE recommends performing a motor parameter measurement using the FCB 25 for third-party motors.

The engineering software can be operated intuitively and is not described further in this document.

9.5 Connection to the service interface

There are 2 possibilities for connecting the inverter to a PC:

1. With the interface adapter USM21A



[1] USM21A interface adapter

[2] Serial interface cable with an RJ10 connector and a 9-pin D-sub connector, part number 18123864.


This cable is necessary for the connection of the interface adapter to MOVIDRIVE® technology, and must be ordered separately.

[3] Commercially available USB connection cable, type USB A-B. The cable is included in the scope of delivery of the interface adapter.

With the interface adapter USM21A, it is possible to connect an engineering PC with a USB interface to the X32 Service interface of the inverter. For more information, refer to the "USM21A interface adapter" manual.

The data is transferred according to the USB 2.0 standard. It is also possible to work with a USB 3.0 device.

2. With the CBG21A or CBG11A keypad with USB interface



[1] USB cable, type USB A-Mini-B,
25643517


[2] Keypad, here the CBG21A as an ex-
ample

9.6 Setting the module bus operating mode

If 2 inverters are connected via a DC link connection, they require the information whether they are "module bus master" or "module bus slave" in the network.

This is set using switch S3 "Module bus operating mode". For further information, refer to the "DC link connection" manual.

If the inverters are not connected to each other via a DC link connection, always set switch "S3" to switch position "Master".



20763162123

[1] "Master" switch setting

[2] "Slave" switch setting


9.7 Startup with the CBG11A keypad

You can perform the startup intuitively with a CBG11A keypad using the symbols and functions shown in the display.

Only asynchronous motors without encoder can be started up with the CBG11A keypad. The startup of other motors can only be performed with the CBG21A keypad or with the MOVISUITE® engineering software.

9.7.1 CBG11A keypad

The user interface of this keypad is in English.



9007225173448203

[1] Display

[2] Esc key

a = Navigate in the menu

[3] Right/left arrow keys

[4] Confirm entry

[5] Up/down arrow keys

b = Manual mode operating range

[6] RUN key

[7] STOP key

To open the main menu, press the <Esc> key. Press the <right/left> arrow keys to select functions in the main menu. Confirm your selection with the <OK> key.

When entering numbers, you must confirm the proposed or entered number with the <OK> key. The digit of the number that is currently editable is then shown underlined. You can use the <up/down> arrow keys to change the value of the digit. Use the <right/left> arrow keys to switch the digit to be edited within the number.

Symbols used

The available functions are shown with pictograms in the keypad display.



Diagnostics



Data management



Startup



Manual mode



Parameter tree



Keypad settings


9.8 Startup with the CBG21A keypad

You can perform the startup intuitively with a CBG21A keypad using the symbols and functions shown in the display.

Asynchronous motors and synchronous motors can be started up with the CBG21A keypad.

9.8.1 CBG21A keypad

The user interface of this keypad is multilingual.



25894023563

- [1] Color display
- [2] 4 function keys that are assigned according to the context. The assigned functions are shown in the display above the keys

a = Permanently assigned with Back/Next

b = Navigate in the menu

- [3] Up/down arrow keys

- [4] Confirm entry

- [5] Right/left arrow keys

c = Manual mode operating range

- [6] STOP key

- [7] Information key

- [8] RUN key

Choice boxes are activated with <OK>, and the selection is then made with the <up/down> arrow keys. Confirm the selection with <OK>.

When entering numbers, you must confirm the proposed or entered number with the <OK> key. The digit of the number that is currently editable is then shown with a colored background. You can use the <up/down> arrow keys to change the value of the digit. Use the <right/left> arrow keys to switch the digit to be edited within the number.

Symbols used



Startup



Manual mode



Drive train optimization



Application



Diagnostics



Parameters



Data management



Keypad settings



Start menu



MOVISAFE® CS..



Gateway



Back



Next


9.9 Startup with the CBG22A keypad

The CBG22 keypad offers the following functions:

- Simple and intuitive manual mode for maintaining operation in the event of a malfunction in the facility
- Extensive diagnostics options
- Exclusively read-only access to parameters in order to protect against incorrect use
- Optional access to functions and states of the control elements and data transfer for Ethernet-based communication methods of the drive systems

9.9.1 CBG22A keypad

The following figure shows the CBG22A keypad (front and rear):




34005940491

- [1] Color display
- [2] Function keys (function according to bottom line on color display)
- [3] USB 2.0 Mini B interface, female (PC connection)
- [4] Locking element
- [5] D-Sub interface, 9-pin, female
- [6] Nameplate
- [7] Info key (for information about the selected menu)

Keys

The following figure shows the required keys of the CBG22A keypad:









- [1] Key 1 "▲"
- [2] Key 2 "▼"
- [3] Key 3 "◀"
- [4] Key 4 "▶"
- [5] Key 5 "OK"
- [6] Key 6 "STOP"
- [7] Key 7 "RESET"



Symbols used


The display of the keypad shows the selectable functions in the form of icons.

Icon	Meaning
	Start menu
	Monitoring
	MOVISAFE® CS..
	DIP switch
	Process data
	Digital inputs/outputs
	Operating and energy data



Icon	Meaning
	Device information
	Fault memory
	Gateway operation
	Settings
	Main menu
	Manual mode
	Direct control mode active
	Indirect control mode active

9.10 Engineering accesses of the inverter

The following table shows the access options from an engineering PC to the inverter.

Connection to device	Connection: Via the USB interface of the PC		
	Cable PC – USM21A	Cable USM21 – device	Interface adapter USM21A
Part number	–	18123864	28231449
X32 D-sub plug connector , 9-pin, male	USB 2.0 connection cable ¹⁾	RJ10/D-sub connection cable, Length: 1.5 m	

1) Included in the delivery of the interface adapter.

Connection to device	Connection: Via the USB interface of the PC			
	Cable PC – CBG..	Cable CBG.. – device	Keypad	
			CBG21A	CBG11A
Part number	25643517	–	28238133	28233646
X32 D-sub plug connector , 9-pin, male	Connection cable USB-A/USB-2.0 Mini B Length: 3 m	Directly plugged		

10 Operation

10.1 General information



⚠ DANGER

Dangerous voltages present at cables and motor terminals.

Severe or fatal injuries from electric shock.

- Dangerous voltages are present at the output terminals and the cables and motor terminals connected to them when the device is switched on. This also applies even when the device is inhibited and the motor is at standstill.
- The fact that the operation LED is no longer illuminated does not indicate that the inverter has been disconnected from the power supply and no longer carries any voltage.
- Before you touch the power terminals, check that the inverter has been disconnected from the power supply.
- Observe the general safety notes in the chapter "Safety notes" and the notes in the chapter "Electrical installation" (→ 249).



⚠ DANGER

Risk of crushing if the motor starts up unintentionally.

Severe or fatal injuries.

- Ensure that the motor cannot start inadvertently, for example by removing the electronics terminal block X20.
- Additional safety precautions must be taken, depending on the application, to avoid injury to personnel and damage to machinery.


NOTICE

Switching the motor output at the inverter with enabled output stage.

Damage to the inverter.


- The motor output of the inverter may only be switched or disconnected when the output stage is inhibited.

10.2 CMM11A memory module



25585405451

The plug-in memory module is included in the scope of delivery and installed in the basic device.



9007224798050699


[1] Memory module

All device data is always stored up-to-date on the memory module. If a device needs to be replaced, the system can be started up again quickly without additional tools by simply replugging the memory module.

The memory module can be simply unplugged or plugged in.

10.3 7-segment display

10.3.1 Operating displays



- The two 7-segment displays indicate the operating state of the inverter.


10.3.2 Fault display

The inverter detects any faults that occur and displays them as a fault code. Each fault is clearly defined by its fault code and corresponding attributes, as shown below:

- Fault response
- Final state after executing the fault response
- Type of reset response.

The fault codes are displayed as flashing numeric values in the inverter.

The fault code is displayed in the following display sequence:



12082058123

In the example, a 2-digit fault code with subfault is shown; in this example, fault 07.01.

10.4 Operating displays

10.4.1 7-segment display

Display	Description	State	Comment/action
Displays during boot process			
b0	Device passes through several states when loading firmware (boot) to become ready for operation	<ul style="list-style-type: none"> Status: Not ready Output stage is inhibited. Communication is not yet possible. 	<ul style="list-style-type: none"> Waiting for boot process to finish. Device stays in this condition: Device is defective.
b1			
b2			
b3			
br			
Display	Description	State	Comment/action
Displays of different device states			
.	Energy-saving mode		Energy-saving mode active
00	DC link voltage missing	<ul style="list-style-type: none"> Status: Not ready Output stage is inhibited. Communication is possible. 	Check the supply system.
C0 Flashing	Module bus not ready		Check the module bus connection.
C1 Flashing	Startup state		Startup state is active.
C2 Flashing	STO active	<ul style="list-style-type: none"> Status: Not ready Output stage is inhibited. Communication is possible. 	The Safe Torque Off function is active.
C3 Flashing	Synchronization with bus incorrect. Process data processing not ready.		<ul style="list-style-type: none"> Check the bus connection. Check the synchronization setting at the device and controller. Check the process data settings at the device and controller.
C4 Flashing	Encoder evaluation not ready		<ul style="list-style-type: none"> Encoders are being initialized. Device stays in this condition: <ul style="list-style-type: none"> – No encoder selected. – "Source actual speed" or "Actual position" parameter shows an encoder that does not exist.
C5 Flashing	Motor management not ready		
C6 Flashing	Internal device supply incomplete		
C7 Flashing	Power section not ready		

Display	Description	State	Comment/action
C8 Flashing	External device not ready		
C9 Flashing	Data flexibilization layer not ready		
Cd Flashing	Parameter download running		
CA	MOVILINK® DDI not ready		MOVILINK® DDI interface not ready.

Display	Description	State	Comment/action
Displays during initialization processes (parameters will be reset to default values)			
d0 Flashing	Basic initialization	<ul style="list-style-type: none"> Status: Not ready Output stage is inhibited. Communication is possible. 	Waiting for initialization to finish.
d1 Flashing	Initialization at delivery state		

Display	Description	State	Comment/action
Displays in normal operation			
01	Output stage inhibit	<ul style="list-style-type: none"> Output stage is inhibited. 	The drive is not actuated by the output stage. The brake is applied; without the brake, the motor coasts to a halt. FCB 01 can be selected from various sources.
AC	Auto Configuration	Data is transferred to the inverter via MOVILINK® DDI interface.	The motor is started up via the MOVILINK® DDI interface.

Display	Description	State	Comment/action
02	Default stop	For further information, refer to the description of the FCBs.	Drive function (FCB) "Default stop" active if no other FCB is selected and the system is ready.
04	Manual mode		Manual mode is active.
05	Speed control		Speed control with internal ramp generator.
06	Interpolated speed control		Speed control with setpoints cyclically via bus. The ramp generator is located externally, e.g. in the higher-level controller.
07	Torque control		Torque control.
08	Interpolated torque control		Torque control with setpoints cyclically via bus.
09	Positioning control		Positioning mode with internal ramp generator.
10	Interpolated positioning control		Positioning mode with setpoints cyclically via bus. The ramp generator is located externally, e.g. in the higher-level controller.
12	Reference travel		The drive performs reference travel.
13	Stop at application limits		Deceleration at the application limit. FCB 13 is active if no other FCB is selected with the default FCB 02.
14	Emergency stop		Deceleration at the emergency stop limit.
18	Rotor position identification		Encoder commutation for synchronous motors.
19	Position hold control		Position control on current position.
20	Jog		Jog mode is active.
21	Brake test		Brake is tested by applying a torque when the brake is applied.
25	Motor parameter measurement		Motor parameter measurement is active.
26	Stop at user limits		Serves to stop at user limits.

10.4.2 LED displays – basic device

"RUN" LED

LED	Meaning
Off	"INIT" state The interface is in the "INIT" state.
Green Flashing	"PRE_OPERATIONAL" state Mailbox communication is possible. Process data communication is not possible.
Green Flashing once	"SAFE_OPERATIONAL" state Mailbox and process data communication is possible. Safety-related output signals are not output.
Green Illuminated	"OPERATIONAL Mode" state Mailbox and process data communication is possible.

"ERR" LED

LED	Meaning
Off	No error The interface is in operating state.
Red Flickering	Boot error A BOOT error has occurred. "INIT" state has not been reached. However the "Change" parameter is set to "0x01:change/error".
Red Flashing	Invalid configuration A general configuration error has occurred.
Red Flashing once	Unprompted state change The slave application has changed the state automatically. The "Change" parameter is set to "0x01:change/error".
Red Flashing twice	Application watchdog timeout A watchdog timeout error has occurred in the application.
Red Illuminated	PDI ¹⁾ Watchdog Timeout A PDI watchdog timeout error has occurred.

1) PDI = Process Data Interface

"LNK/ACT" LED

LED	Meaning
Off	No link available. No physical connection to a neighboring device was detected.
Green Illuminated	Link available, no bus activity. A physical connection to a neighboring device was detected. No data is being exchanged via the Ethernet port.
Green Flickering	Link available, bus activity. A physical connection to a neighboring device was detected. Data is being exchanged via the Ethernet port.

10.4.3 PROFINET CFN21A fieldbus card

"BF" LED

This LED indicates the status of the PROFINET interface. The state includes communication link, bus error and process data configuration.

Status	Possible cause	Measure
Off	Fault-free operating state. The PROFINET device is exchanging data with the PROFINET controller (Data Exchange state).	—
Red Permanently lit	Connection to the PROFINET controller has failed.	Check the PROFINET connection of the PROFINET device.
	Bus communication has been interrupted.	Check all the cables in the PROFINET network.
	The PROFINET controller is not in operation.	Check the PROFINET controller.
Yellow Permanently lit	The PROFINET device does not detect a PROFINET baud rate.	Check the configuration of the PROFINET controller.
	There is a connection to the PROFINET controller, but the configuration of the PROFINET network is faulty. The following faults may have occurred: <ul style="list-style-type: none"> • A hardware module was selected that does not support the PROFINET interface. • The standard process data and the safe process data have been assigned mixed to the PROFINET device. 	Check the configuration of the PROFINET controller.

"US1" LED

This LED indicates the status of the PROFINET interface. The state includes the start-up, normal operation, error mode and energy-saving operation operating modes.

Status	Possible cause	Measure
Yellow, flashing Cyclic duration factor: 250 ms Switch-off time: 250 ms	The PROFINET interface box is just starting up after a reset.	—
Green Permanently lit	The PROFINET interface is operating without faults.	—

Status	Possible cause	Measure
Green, flashing Cyclic duration factor: 500 ms Switch-off time: 3000 ms	The PROFINET interface is in energy-saving mode (PROFInergy mode).	–
Red Permanently lit	The PROFINET interface box has detected a fault. Information: A timeout of the PROFINET connection is not an internal fault.	Switch the device off and back on again. If the fault occurs repeatedly, contact SEW-EURODRIVE Service.

"LNK/ACT" LED

Status	Meaning
All LEDs Green Permanently lit	A physical connection to another Ethernet node was detected. Currently, no data is being exchanged via the Ethernet port.
All LEDs Flashing green Cyclic duration factor: 500 ms Switch-off time: 500 ms	The flashing test has been activated to localize the Ethernet nodes visually.
All LEDs Off	No physical connection to further Ethernet nodes was detected.
LED at the respective Ethernet port Green/yellow, flashing	Data is being sent or received via the Ethernet port.

10.4.4 EtherNet/IP™ and Modbus TCP CFE fieldbus card

"NS" LED

LED	Meaning	Measure
– Off	Device is switched off.	<ul style="list-style-type: none"> Check the DC 24 V voltage supply. Switch on the device again.
	No DC 24 V supply.	
	The IP address is not set.	<ul style="list-style-type: none"> Set the IP address.
Green Flashing	<p>The connection to the Ethernet master has failed.</p> <p>The device does not detect a connection to the Ethernet master (bus error).</p>	<ul style="list-style-type: none"> Check the Ethernet connection of the device. Check all Ethernet connections.
Green Illuminated	The IP address is set. The Ethernet connection has been established.	–
Red Flashing	<p>Timeout delay of the controlling connection has expired.</p> <p>The state is reset by restarting communication.</p>	<ul style="list-style-type: none"> Check the fieldbus connection. Check the master/scanner. Check all Ethernet connections.
Red Illuminated	Conflict detected in IP address assignment.	<ul style="list-style-type: none"> Check whether there is another device with the same IP address in the network. Change the IP address of the device. Check the DHCP settings for IP address assignment of the DHCP server (only when using a DHCP server).
Red/green Flashing	<p>The device performs a LED test.</p> <p>This state may only be active for a short time during startup.</p>	–
	<p>The device has received the designated target unit network ID (TUNID).</p> <p>The LED will keep flashing until the device has received the APPLY_TUNID service and the validation is successfully completed.</p>	

"MS" LED

LED	Meaning	Measure
– Off	No power supply or DC 24 V supply.	<ul style="list-style-type: none"> Check the voltage supply.
Green Flashing	The device has not been configured yet.	<ul style="list-style-type: none"> Configure the device. Check the DHCP server connection (only if DHCP is activated and in persistent status).

LED	Meaning	Measure
Green Illuminated	Device OK.	–
Red Flashing	A correctable fault has occurred on the device.	<ul style="list-style-type: none"> • Check whether there is another device with the same IP address in the network. • Change the IP address of the device. • Check the DHCP settings for IP address assignment of the DHCP server (only when using a DHCP server).
Red Illuminated	A fault that cannot be corrected has occurred on the device.	<ul style="list-style-type: none"> • Switch on the device again. • Reset the device to the factory settings. • If this fault occurs repeatedly, replace the device or contact SEW-EURODRIVE Service.
Red/green Flashing	The device performs a LED test. This state may only be active for a short time during startup.	–
	The device is waiting for a target unit network ID (TUNID).	Assign a target unit network ID (TUNID) to the device.
	Device parameter setting is required.	Check the parameterization of the CSB51A/CSL51A safety option.

"LNK/ACT" LED

Status	Meaning
All LEDs Green Permanently lit	A physical connection to another Ethernet node was detected. Currently, no data is being exchanged via the Ethernet port.
All LEDs Flashing green Cyclic duration factor: 500 ms Switch-off time: 500 ms	The flashing test has been activated to localize the Ethernet nodes visually.
All LEDs Off	No physical connection to further Ethernet nodes was detected.
LED at the respective Ethernet port Green/yellow, flashing	Data is being sent or received via the Ethernet port.

10.4.5 CFL21A POWERLINK fieldbus card

"BS" LED

LED	Meaning
Off	"INIT" state The interface is in "INIT" state.
Green Flickering	"BASIC ETHERNET Mode" state None of the SoA, SoC, PReq, or PRes message types detected.
Green Flashing once	"PRE_OPERATIONAL_1Mode" state Only acyclic communication is possible.
Green Flashing twice	"PRE_OPERATIONAL_2Mode" state Acyclic and cyclic communication are possible. Process data not valid.
Green Flashing three times	"READY_TO_OPERATE_Mode" state
Green Flashing	"STOPPED_Mode" state
Green Illuminated	"OPERATIONAL Mode" state

"BE" LED

LED	Meaning	Measure
Off	Transition to "OPERATIONAL_Mode" state	–
	Software reset of the NMT state machine (start basic node initialization)	–
	Transition to "BASIC_ETHERNET_Mode" state after a timeout of the SoC, PReq, Pres, and SoA message types.	–
Red Illuminated	POWERLINK cycle time exceeded.	Check/adjust the network.
	The number of managing nodes (MN) in the POWERLINK network is > 1.	Check/adjust the network. Configure only 1 managing node.
	Invalid Ethernet frame format, e.g. wrong Ethernet CRC (redundancy checksum)	Check/adjust the network.
	Loss of frame	Check/adjust the network.
	Frame collision	Check/adjust the network.
	Invalid IP address	Set a valid IP address.

"LNK/ACT" LED

Status	Meaning
All LEDs Green Permanently lit	A physical connection to another Ethernet node was detected. Currently, no data is being exchanged via the Ethernet port.
All LEDs Flashing green Cyclic duration factor: 500 ms Switch-off time: 500 ms	The flashing test has been activated to localize the Ethernet nodes visually.
All LEDs Off	No physical connection to further Ethernet nodes was detected.
LED at the respective Ethernet port Green/yellow, flashing	Data is being sent or received via the Ethernet port.

10.4.6 PROFIBUS CFP21A fieldbus card

"BF" LED

The "BF" LED indicates communication errors on the PROFIBUS interface.

		Measure
Off	Error-free operating state. The device is exchanging data with the PROFIBUS master (data exchange state).	–
Red Illuminated	<ul style="list-style-type: none"> PROFIBUS master not in operation. The connection to the PROFIBUS master has failed. The device does not detect a PROFIBUS baud rate. Bus communication has been interrupted. 	<ul style="list-style-type: none"> Check the PROFIBUS connection of the device. Check all the cables in the PROFIBUS network. Check the configuration of the PROFIBUS master.
Red Flashing with 2 Hz	<ul style="list-style-type: none"> The device detects the PROFIBUS baud rate but is not addressed by the PROFIBUS master. The device was not configured or was configured incorrectly in the PROFIBUS master. 	<ul style="list-style-type: none"> Check the PROFIBUS address set in the device and in the engineering tool of the PROFIBUS master. Check the configuration of the PROFIBUS master. Check whether you are using the appropriate device description file ().

"RUN" LED

The "RUN" LED indicates whether the bus electronics is functioning properly.

		Measure
Green	PROFIBUS hardware OK. Bus electronics without faults.	–
Red Illuminated	The hardware of the bus electronics is faulty.	<p>Switch the device off and back on again.</p> <p>If the fault occurs repeatedly, contact SEW-EURODRIVE Service.</p>
Red Flashing with 2 Hz	The PROFIBUS address is set to 0 or to a value greater than 125.	<ul style="list-style-type: none"> Check the PROFIBUS address set in the device. Reset the device.

10.5 Fault description on basic device

10.5.1 Fault 1 Output stage monitoring

Subfault: 1.1		
Description: Short circuit in motor output terminals		
	Response: Output stage inhibit	
	Cause	Measure
	Overcurrent in output stage or faulty output stage control detected, and output stage inhibited by hardware.	Possible causes for overcurrent are short circuit at the output, excessive motor current, or a defective power output stage.

Subfault: 1.2		
Description: Overcurrent in output stage		
	Response: Output stage inhibit	
	Cause	Measure
	Motor current too high.	Connect a smaller motor.
	Current supply	Check the current supply.
	Current transformer	Check the current transformer.
	Ramp limit deactivated and set ramp time too short.	Increase the ramp time.
	Phase module defective.	Check the phase module.
	DC 24 V supply voltage unstable.	Check the DC 24 V supply voltage.
	Interruption or short circuit on signal lines of phase modules.	Check the signal lines.

10.5.2 Fault 3 Ground fault

Subfault: 3.1		
Description: Ground fault		
	Response: Output stage inhibit	
	Cause	Measure
	Ground fault in the motor lead.	Eliminate the ground fault in the motor lead.
	Ground fault in the inverter.	Eliminate the ground fault in the inverter.
	Ground fault in the motor.	Eliminate the ground fault in the motor.
	Ground fault in line components.	Eliminate the ground fault in the line components.

10.5.3 Fault 4 Brake chopper

Subfault: 4.1		
Description: Brake chopper overcurrent		
	Response: Output stage inhibit	
	Cause	Measure
	Excessive regenerative power.	Extend the deceleration ramps.
	Short circuit detected in braking resistor circuit.	Check the supply cable to the braking resistor.
	Braking resistance too high.	Check the technical data of the braking resistor.
Subfault: 4.2		
Description: Brake chopper defective		
	Response: Output stage inhibit	
	Cause	Measure
	Output stage of brake chopper defective.	Replace the defective brake chopper.

10.5.4 Fault 6 Line fault

Subfault: 6.1		
Description: Line phase failure		
	Response: Line phase failure	
	Cause	Measure
	Missing line phase detected.	Check the supply system cable.
	DC link voltage periodically too low.	Check the configuration of the supply system.
	Inadequate line voltage quality.	Check the supply (fuses, contactor).

10.5.5 Fault 7 DC link

Subfault: 7.1		
Description: DC link overvoltage		
	Response: Output stage inhibit	
	Cause	Measure
	Maximum permitted DC link voltage limit exceeded and output stage inhibited by hardware.	– Extend the deceleration ramps.
		– Check the supply cable to the braking resistor.
		– Check the technical data of the braking resistor.
Subfault: 7.2		
Description: DC link discharge failed		
	Response: Warning	
	Cause	Measure
	DC link voltage level not dropped below discharge threshold within discharge time.	Contact SEW-EURODRIVE Service.

10.5.6 Fault 8 Speed monitoring

Subfault: 8.1

Description: Speed monitoring – motor mode

Response: Output stage inhibit		
Cause	Measure	
Speed controller operates at setting limit (mechanical overload or phase failure in supply system or motor).	Increase the delay time set for speed monitoring, or reduce the load.	
Encoder not connected correctly.	Check the encoder connection and direction of rotation. If necessary, increase the current limiting or reduce the acceleration values.	
Encoder has incorrect direction of rotation.	<ul style="list-style-type: none"> – Check the encoder connection and direction of rotation. If necessary, increase the current limiting or reduce the acceleration values. – Check the motor lead and motor, check line phases. 	

Subfault: 8.2

Description: Speed monitoring – generator mode

Response: Output stage inhibit		
Cause	Measure	
Speed controller operates at setting limit (mechanical overload or phase failure in supply system or motor).	Increase the delay time set for speed monitoring, or reduce the regenerative load.	
Encoder not connected correctly.	Check the encoder connection and direction of rotation. If necessary, increase the current limiting or reduce the deceleration values.	
Encoder has incorrect direction of rotation.	<ul style="list-style-type: none"> – Check the encoder connection and direction of rotation. If necessary, increase the current limiting or reduce the deceleration values. – Check the motor lead and motor. – Check the line phases. 	

Subfault: 8.3

Description: Maximum speed at motor shaft

Response: Output stage inhibit		
Cause	Measure	
Actual speed exceeded "Maximum speed at motor shaft" limit value (index 8360.9 / 8361.9). This limit value is set at startup matching the motor and gear unit.	Reduce the maximum speed.	

10.5.7 Fault 9 Control mode

Subfault: 9.1**Description: Magnetization of motor not possible**

Response: Output stage inhibit		
Cause		Measure
The user-defined current limit or output stage monitoring have reduced the possible maximum current to such a degree that the required magnetizing current cannot be set.		<ul style="list-style-type: none"> – Reduce the output stage utilization, e.g. by reducing the PWM frequency or reducing the load. – Increase the user-defined current limit.

Subfault: 9.2**Description: Requested operating mode not possible with active control mode**

Response: Output stage inhibit		
Cause		Measure
The current FCB activated an operating mode. The active control mode does not support this operating mode, for example "position control" or "torque control" with U/f control mode.		<ul style="list-style-type: none"> – Use a control mode that supports the required operating mode. Connect an encoder if necessary. – Select an operating mode that is supported by the current control mode.

Subfault: 9.3**Description: Absolute rotor position not available**

Response: Output stage inhibit		
Cause		Measure
The current control mode requires an absolute rotor position. The encoder selected for "Source of actual speed" does not provide an absolute rotor position.		Use an absolute encoder, or identify the rotor position using FCB 18.

Subfault: 9.4**Description: Correct current supply of motor not possible**

Response: Output stage inhibit		
Cause		Measure
Failed to set required current during premagnetization.		Check the cabling, or disable the function "Current monitoring during premagnetization".

Subfault: 9.5**Description: Maximum output frequency exceeded**

Response: Output stage inhibit		
Cause		Measure
Maximum output frequency exceeded.		Reduce the maximum speed.

Subfault: 9.6**Description: Maximum model speed exceeded**

	Response: Output stage inhibit	
	Cause	Measure
	Speed of drive calculated in ELSM® control mode too high for motor control.	If possible, minimize the "Speed/position controller sampling cycle", or reduce the speed.

Subfault: 9.8**Description: Motor protection function – demagnetization**

	Response: Output stage inhibit	
	Cause	Measure
	<p>The fault can be caused as follows:</p> <ul style="list-style-type: none"> – The motor is blocked. – The motor has already been operated at a speed below the transition speed for too long. – The motor has not been started up properly. 	<ul style="list-style-type: none"> – Check the motor for blockage. – Check the drive selection. – Optimize the speed controller. – Perform motor startup again and run the drive function "FCB 25 Motor parameter measurement". – If the fault occurs repeatedly, contact SEW-EURODRIVE Service.

Subfault: 9.9**Description: Parameter measurement not possible with active motor type**

	Response: Output stage inhibit	
	Cause	Measure
	Parameter measurement is possible only with "asynchronous" and "synchronous" motor types. No magnetic reluctance motors and LSPM motors.	Select the correct motor type.

Subfault: 9.10**Description: Rotor stall monitoring**

	Response: Output stage inhibit	
	Cause	Measure
	The current control cannot hold the load torque. The deviation between stationary setpoint voltage and actual voltage is too large.	Reduce the load torque (hoist) in the controlled system.

Subfault: 9.11**Description: Standstill current function**

	Response: Output stage inhibit	
	Cause	Measure
	With the ELSM method, the standstill current function is possible only in combination with rotor position measurement.	<ul style="list-style-type: none"> – Enable rotor position measurement. – Check motor data.

10.5.8 Fault 10 Data flexibility

Subfault: 10.1**Description: Initialization**

Response: Application stop + output stage inhibit		
	Cause	Measure
	Init task error.	The init task has issued a return code ! = 0. Check the program.

Subfault: 10.2**Description: Illegal program command**

Response: Application stop + output stage inhibit		
	Cause	Measure
	The version of the MOVIKIT® software module in use is not compatible with the current firmware version of the device.	<ul style="list-style-type: none"> – Use the latest firmware version of the device. – Adjust the firmware version of the device according to the version overview in the installation notes. – Adjust the version of the MOVIKIT® software module according to the version overview in the installation notes. – In the shortcut menu of the device, execute the "Adjust version and device" menu command.
	Unknown program command (illegal opcode) detected in Data Flexibility program.	Contact SEW-EURODRIVE Service.

Subfault: 10.3**Description: Memory access**

Response: Application stop + output stage inhibit		
	Cause	Measure
	Memory area violated while accessing array.	For example, an array access results in writing beyond the permitted memory range. Check the program.

Subfault: 10.4**Description: Stack**

Response: Application stop + output stage inhibit		
	Cause	Measure
	Overflow of Data Flexibility stack detected.	Check the program.

Subfault: 10.5**Description: Division by 0**

Response: Application stop + output stage inhibit		
	Cause	Measure
	Division by 0.	Check the program.

Subfault: 10.6

Description: Runtime

	Response: Application stop + output stage inhibit	
	Cause	Measure
	Runtime error/watchdog	Check the program. The program execution time exceeds the permitted time.
	PDI or PDO tasks.	Check the program. The execution time of the PDI or PDO task exceeds the permitted time.

Subfault: 10.7

Description: Calculation result of multiplication/division command too large

	Response: Application stop + output stage inhibit	
	Cause	Measure
	Calculation result of multiplication/division command exceeds 32 bits.	Check the program.
	Failed to write calculation result of multiplication/division command into result variable.	Check the program.

Subfault: 10.8

Description: Illegal connection

	Response: Application stop + output stage inhibit	
	Cause	Measure
	Index used in connect not allowed.	Check the program. The index used either does not exist or is not permitted for access via process data – see parameter list.

Subfault: 10.9

Description: CRC code

	Response: Application stop + output stage inhibit	
	Cause	Measure
	Wrong CRC checksum of code.	Load the program again. The program memory is corrupt. Unauthorized write access to the program memory.

Subfault: 10.10

Description: Setpoint cycle time not supported

	Response: Application stop + output stage inhibit	
	Cause	Measure
	Non-supported setpoint cycle time parameterized.	Set the setpoint cycle time to the default value 1 ms.

Subfault: 10.11		
Description: No application program loaded		
	Response: Output stage inhibit	
	Cause	Measure
	No Data Flexibility application program loaded.	Load the program or disable Data Flexibility.
Subfault: 10.12		
Description: Runtime warning		
	Response: Warning	
	Cause	Measure
	The program requires more runtime than configured.	Check the program.
Subfault: 10.99		
Description: Unknown fault		
	Response: Application stop + output stage inhibit	
	Cause	Measure
	Unknown Data Flexibility error.	Contact SEW-EURODRIVE Service.

10.5.9 Fault 11 Temperature monitoring

Subfault: 11.1		
Description: Heat sink overtemperature		
	Response: Output stage inhibit	
	Cause	Measure
	Maximum permitted heat sink temperature exceeded. The capacity utilization is possibly too high.	<ul style="list-style-type: none"> – Reduce the load. – Reduce the rms value of the current. – Reduce the PWM frequency. – Ensure sufficient cooling. – Reduce the ambient temperature.
Subfault: 11.2		
Description: Heat sink utilization – prewarning		
	Response: Heat sink utilization – prewarning	
	Cause	Measure
	High thermal load on heat sink of device, and pre-warning threshold reached.	<ul style="list-style-type: none"> – Reduce the load. – Reduce the rms value of the output current. – Reduce the PWM frequency. – Ensure sufficient cooling. – Reduce the ambient temperature.

Subfault: 11.3

Description: Device utilization

Response: Output stage inhibit		
	Cause	Measure
	The temperature has reached or exceeded the switch-off threshold. Possible causes: Mean output current too high.	Reduce the load.
	PWM frequency too high.	Reduce the PWM frequency.
	Ambient temperature too high.	Ensure sufficient cooling.
	Unfavorable air convection.	Check air convection.
	Fan defective.	Check the fan and replace if necessary.

Subfault: 11.5

Description: Electromechanical capacity utilization

Response: Output stage inhibit		
	Cause	Measure
	Electromechanical components of device overloaded by excessive continuous current.	Reduce the load. If necessary, reduce the rms value of the current.

Subfault: 11.6

Description: Electromechanical capacity utilization – prewarning

Response: Electromechanical capacity utilization – prewarning		
	Cause	Measure
	High load on electromechanical components of device due to high continuous current. Prewarning threshold reached.	<ul style="list-style-type: none"> – Reduce the load. – Reduce the PWM frequency. – Reduce the rms value of the current. – Reduce the ambient temperature.

Subfault: 11.7

Description: Wire break at temperature sensor of heat sink

Response: Output stage inhibit		
	Cause	Measure
	Wire break at temperature sensor of heat sink.	Contact SEW-EURODRIVE Service.

Subfault: 11.8

Description: Short circuit at temperature sensor of heat sink

Response: Output stage inhibit		
	Cause	Measure
	Short circuit at temperature sensor of heat sink.	Contact SEW-EURODRIVE Service.

10.5.10 Fault 12 Brake

Subfault: 12.20**Description: Digital motor integration fault – critical**

	Response: Output stage inhibit with self-reset	
	Cause	Measure
	The intelligent brake rectifier of digital motor integration has detected a critical component fault.	For the exact cause of the fault and for information on how to correct it, refer to the fault detected by the subcomponent.

Subfault: 12.21**Description: Digital motor integration fault**

	Response: Emergency stop + output stage inhibit with self-reset	
	Cause	Measure
	The intelligent brake rectifier of digital motor integration has detected a component fault.	For the exact cause of the fault and for information on how to correct it, refer to the fault detected by the subcomponent.

Subfault: 12.22**Description: Digital motor integration warning**

	Response: Warning with self-reset	
	Cause	Measure
	The intelligent brake rectifier of digital motor integration signaled a warning.	For the exact cause of the fault and for information on how to correct the warning, refer to the fault signaled by the subcomponent.

Subfault: 12.23**Description: Digital motor integration timeout**

	Response: Output stage inhibit	
	Cause	Measure
	Communication with intelligent brake rectifier disrupted.	Check the connection.

10.5.11 Fault 13 Encoder 1

Subfault: 13.1**Description: Position comparison check**

Response: Encoder 1 – latest critical fault		
Cause		Measure
Fault detected when comparing raw position and track counter of absolute encoder.		<ul style="list-style-type: none"> – Check the track signal wiring. – Check interference sources (e.g. from the area of EMC). – Replace the encoder. – Replace the encoder card. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 13.2**Description: Unknown encoder type**

Response: Encoder 1 – latest critical fault		
Cause		Measure
Encoder type not known and not supported by device.		<ul style="list-style-type: none"> – Check the encoder type. – Contact SEW-EURODRIVE Service. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 13.3**Description: Invalid data**

Response: Encoder 1 – latest critical fault		
Cause		Measure
Invalid encoder nameplate data (measuring steps/pulses per revolution/multi-turn).		<ul style="list-style-type: none"> – Check the startup parameters. – Replace the encoder. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 13.4**Description: Track measurement error**

Response: Encoder 1 – latest critical fault		
	Cause	Measure
	Error during track measurement.	<ul style="list-style-type: none"> – Switch the device off and on again. – Check the wiring. – Check interference sources (e.g. from the area of EMC). – Check the encoder. Replace if necessary. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 13.5**Description: Internal warning**

Response: Encoder – warning		
	Cause	Measure
	Encoder signaled warning.	<ul style="list-style-type: none"> – Check the wiring. – Check interference sources (light beam interrupted, reflector, signal cables, etc.). – Clean the sensor.

Subfault: 13.6**Description: Signal level too low**

Response: Encoder 1 – latest critical fault		
	Cause	Measure
	The value established from the level of the two track signals A and B is below the permitted limit.	<ul style="list-style-type: none"> – Check the wiring. – Check interference sources (e.g. from the area of EMC). – Check the encoder. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 13.7

Description: Signal level too high

	Response: Encoder 1 – latest critical fault	
	Cause	Measure
	The value established from the level of the two track signals A and B exceeds the permitted limit.	<p>Check the gear ratio of the resolver in use.</p> <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 13.8

Description: Signal level monitoring

	Response: Encoder 1 – latest critical fault	
	Cause	Measure
	The value established from the level of the two track signals A and B exceeds the permitted limit.	<p>Check the resolver mounting position.</p> <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 13.9

Description: Quadrant check

	Response: Encoder 1 – latest critical fault	
	Cause	Measure
	Error checking quadrants (sine encoder).	<ul style="list-style-type: none"> – Switch the device off and on again. – Check the wiring. – Check interference sources (e.g. from the area of EMC). – Check the encoder. Replace if necessary. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 13.10**Description: Position tolerance range exceeded**

Response: Encoder 1 – latest critical fault		
Cause		Measure
Position outside tolerance range.		<ul style="list-style-type: none"> – Check the startup parameters. – Check the wiring. – Check interference sources (light beam interrupted, reflector, signal cables, etc.). – Replace the encoder. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 13.11**Description: Encoder data timeout**

Response: Encoder 1 – latest critical fault		
Cause		Measure
Encoder process data triggered timeout state.		<ul style="list-style-type: none"> – Check interference sources (e.g. from the area of EMC). – Check the startup parameters. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 13.12**Description: Emergency**

Response: Encoder 1 – latest critical fault		
Cause		Measure
Encoder signaled emergency.		<ul style="list-style-type: none"> – Check interference sources (e.g. from the area of EMC). – Check the startup parameters. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 13.13**Description: Error during initialization**

Response: Encoder 1 – latest fault		
Cause		Measure
Communication error during initialization.		<p>With encoders from SEW-EURODRIVE:</p> <ul style="list-style-type: none"> – Check the wiring. <p>With encoders of other manufacturers:</p> <ul style="list-style-type: none"> – Check the wiring. – Check the parameter setting in MOVISUITE®. – Compare the settings via DIP switches, display, USB interface, etc. on the encoder with the specifications in the operating instructions of the inverter or option (e.g. baud rate, node ID). <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 13.14**Description: Communication error**

Response: Encoder 1 – latest fault		
Cause		Measure
Faulty communication with encoder.		<ul style="list-style-type: none"> – Check the voltage supply. – Check interference sources (e.g. from the area of EMC). – Check the wiring. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 13.15**Description: System error**

Response: Encoder 1 – latest critical fault		
Cause		Measure
System error while evaluating encoder.		<ul style="list-style-type: none"> – Ensure that the multi-turn encoder is within the configured track range. – Check the limits. – Check for correct settings of encoder numerator/denominator factors. – Check interference sources (e.g. from the area of EMC). – Check the startup parameters. – Switch the device off and on again. – If the fault occurs repeatedly, contact SEW-EURODRIVE Service. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 13.16**Description: Permanent high level in signal cable – critical**

Response: Encoder 1 – latest critical fault		
Cause		Measure
Permanent high level of data signal detected.		<ul style="list-style-type: none"> – Check the wiring. – Check the encoder. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 13.17**Description: Permanent high level in signal cable**

Response: Encoder 1 – latest fault		
Cause		Measure
Permanent high level of data signal detected.		<ul style="list-style-type: none"> – Check the wiring. – Check the encoder. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 13.18**Description: Permanent low level in signal cable – critical**

Response: Encoder 1 – latest critical fault		
Cause		Measure
Permanent low level of data signal detected.		<ul style="list-style-type: none"> – Check the wiring. – Check the encoder. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 13.19**Description: Permanent low level in signal cable**

Response: Encoder 1 – latest fault		
Cause		Measure
Permanent low level of data signal detected.		<ul style="list-style-type: none"> – Check the wiring. – Check the encoder. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 13.20**Description: SSI encoder – critical fault**

Response: Encoder 1 – latest critical fault		
Cause		Measure
SSI encoder signaled a critical fault.		<ul style="list-style-type: none"> – Check the startup parameters. – Check the settings on the SSI encoder. – Check the wiring. – Check interference sources (light beam interrupted, reflector, signal cables, etc.). – Replace the encoder. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive even with a faulty external position encoder.</p>

Subfault: 13.21**Description: SSI encoder – fault**

Response: Encoder 1 – latest fault		
Cause		Measure
SSI encoder signaled a fault.		<ul style="list-style-type: none"> – Check the startup parameters. – Check the settings on the SSI encoder. – Check the wiring. – Check interference sources (light beam interrupted, reflector, signal cables, etc.). – Replace the encoder. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive even with a faulty external position encoder.</p>

Subfault: 13.22**Description: Internal fault – critical**

Response: Encoder 1 – latest critical fault		
Cause		Measure
Encoder signaled internal fault.		<ul style="list-style-type: none"> – Check the wiring. – Check interference sources (light beam interrupted, reflector, signal cables, etc.). – Replace the encoder. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 13.23**Description: Internal fault**

Response: Encoder 1 – latest fault		
Cause		Measure
Encoder signaled internal fault.		<ul style="list-style-type: none"> – Check the wiring. – Check interference sources (light beam interrupted, reflector, signal cables, etc.). – Replace the encoder. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 13.24

Description: Travel range exceeded

	Response: Encoder 1 – latest fault	
	Cause	Measure
	Current position mode does not allow for larger travel range.	<p>Check the travel range.</p> <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 13.25

Description: Error during encoder startup

	Response: Output stage inhibit	
	Cause	Measure
	Fatal error during encoder startup.	<p>Switch the device off and on again.</p> <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 13.26

Description: Digital motor integration fault – critical

	Response: Encoder 1 – latest critical fault	
	Cause	Measure
	Encoder of digital motor integration detected a component fault.	<p>– Check interference sources.</p> <p>– Replace the encoder.</p>

Subfault: 13.27

Description: Digital motor integration fault

	Response: Encoder 1 – latest fault	
	Cause	Measure
	Encoder of digital motor integration detected a component fault.	<p>– Check interference sources.</p> <p>– Replace the encoder.</p>

Subfault: 13.28

Description: Digital motor integration warning

	Response: Encoder – warning	
	Cause	Measure
	Encoder of digital motor integration signaled a warning.	Check interference sources.

Subfault: 13.29**Description: Absolute position invalid**

Response: Encoder 1 – latest fault		
Cause		Measure
Diagnostics error detected while evaluating absolute encoder position. Referencing is canceled.		<ul style="list-style-type: none"> – Reference the drive again. – If the fault occurs repeatedly, contact SEW-EURODRIVE Service. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

10.5.12 Fault 14 Encoder 2**Subfault: 14.1****Description: Position comparison check**

Response: Encoder 2 – latest critical fault		
Cause		Measure
Fault detected when comparing raw position and track counter of absolute encoder.		<ul style="list-style-type: none"> – Check the track signal wiring. – Check interference sources (e.g. from the area of EMC). – Replace the encoder. – Replace the encoder card. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 14.2**Description: Unknown encoder type**

Response: Encoder 2 – latest critical fault		
Cause		Measure
Encoder type not known and not supported by device.		<ul style="list-style-type: none"> – Check the encoder type. – Contact SEW-EURODRIVE Service. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 14.3

Description: Invalid data

Response: Encoder 2 – latest critical fault		
Cause		Measure
Invalid encoder nameplate data (measuring steps/pulses per revolution/multi-turn).		<ul style="list-style-type: none"> – Check the startup parameters. – Replace the encoder. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 14.4

Description: Track measurement error

Response: Encoder 2 – latest critical fault		
Cause		Measure
Error during track measurement.		<ul style="list-style-type: none"> – Switch the device off and on again. – Check the wiring. – Check interference sources (e.g. from the area of EMC). – Check the encoder. Replace if necessary. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 14.5

Description: Internal warning

Response: Encoder – warning		
Cause		Measure
Encoder signaled warning.		<ul style="list-style-type: none"> – Check the wiring. – Check interference sources (light beam interrupted, reflector, signal cables, etc.). – Clean the sensor.

Subfault: 14.6**Description: Signal level too low**

	Response: Encoder 2 – latest critical fault	
	Cause	Measure
	The value established from the level of the two track signals A and B is below the permitted limit.	<ul style="list-style-type: none"> – Check the wiring. – Check interference sources (e.g. from the area of EMC). – Check the encoder. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 14.7**Description: Signal level too high**

	Response: Encoder 2 – latest critical fault	
	Cause	Measure
	The value established from the level of the two track signals A and B exceeds the permitted limit.	<p>Check the gear ratio of the resolver in use.</p> <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 14.8**Description: Signal level monitoring**

	Response: Encoder 2 – latest critical fault	
	Cause	Measure
	The value established from the level of the two track signals A and B exceeds the permitted limit.	<p>Check the resolver mounting position.</p> <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 14.9

Description: Quadrant check

	Response: Encoder 2 – latest critical fault	
	Cause	Measure
	Error checking quadrants (sine encoder).	<ul style="list-style-type: none"> – Switch the device off and on again. – Check the wiring. – Check interference sources (e.g. from the area of EMC). – Check the encoder. Replace if necessary. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 14.10

Description: Position tolerance range exceeded

	Response: Encoder 2 – latest critical fault	
	Cause	Measure
	Position outside tolerance range.	<ul style="list-style-type: none"> – Check the startup parameters. – Check the wiring. – Check interference sources (light beam interrupted, reflector, signal cables, etc.). – Replace the encoder. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 14.11

Description: Encoder data timeout

	Response: Encoder 2 – latest critical fault	
	Cause	Measure
	Encoder process data triggered timeout state.	<ul style="list-style-type: none"> – Check interference sources (e.g. from the area of EMC). – Check the startup parameters. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 14.12**Description: Emergency**

Response: Encoder 2 – latest critical fault		
Cause		Measure
Encoder signaled emergency.		<ul style="list-style-type: none"> – Check interference sources (e.g. from the area of EMC). – Check the startup parameters. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 14.13**Description: Error during initialization**

Response: Encoder 2 – latest fault		
Cause		Measure
Communication error during initialization.		<p>With encoders from SEW-EURODRIVE:</p> <ul style="list-style-type: none"> – Check the wiring. <p>With encoders of other manufacturers:</p> <ul style="list-style-type: none"> – Check the wiring. – Check the parameter setting in MOVISUITE®. – Compare the settings via DIP switches, display, USB interface, etc. on the encoder with the specifications in the operating instructions of the inverter or option (e.g. baud rate, node ID). <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 14.14**Description: Communication error**

Response: Encoder 2 – latest fault		
Cause		Measure
Faulty communication with encoder.		<ul style="list-style-type: none"> – Check the voltage supply. – Check interference sources (e.g. from the area of EMC). – Check the wiring. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 14.15**Description: System error**

Response: Encoder 2 – latest critical fault		
Cause		Measure
System error while evaluating encoder.		<ul style="list-style-type: none"> – Make sure that the multi-turn encoder is within the configured track area. – Check the limits. – Check for correct settings of encoder numerator/denominator factors. – Check interference sources (e.g. from the area of EMC). – Check the startup parameters. – Switch the device off and on again. – If the fault occurs repeatedly, contact SEW-EURODRIVE Service. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 14.16**Description: Permanent high level in signal cable – critical**

Response: Encoder 2 – latest critical fault		
Cause		Measure
Permanent high level of data signal detected.		<ul style="list-style-type: none"> – Check the wiring. – Check the encoder. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 14.17**Description: Permanent high level in signal cable**

Response: Encoder 2 – latest fault		
Cause		Measure
Permanent high level of data signal detected.		<ul style="list-style-type: none"> – Check the wiring. – Check the encoder. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 14.18**Description: Permanent low level in signal cable – critical**

Response: Encoder 2 – latest critical fault		
Cause		Measure
Permanent low level of data signal detected.		<ul style="list-style-type: none"> – Check the wiring. – Check the encoder. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 14.19**Description: Permanent low level in signal cable**

Response: Encoder 2 – latest fault		
Cause		Measure
Permanent low level of data signal detected.		<ul style="list-style-type: none"> – Check the wiring. – Check the encoder. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 14.20**Description: SSI encoder – critical fault**

Response: Encoder 2 – latest critical fault		
Cause		Measure
SSI encoder detected a critical fault.		<ul style="list-style-type: none"> – Check the startup parameters. – Check the settings on the SSI encoder. – Check the wiring. – Check interference sources (light beam interrupted, reflector, signal cables, etc.). – Replace the encoder. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive even with a faulty external position encoder.</p>

Subfault: 14.21**Description: SSI encoder – fault**

	Response: Encoder 2 – latest fault	
	Cause	Measure
	SSI encoder detected a fault.	<ul style="list-style-type: none"> – Check the startup parameters. – Check the settings on the SSI encoder. – Check the wiring. – Check interference sources (light beam interrupted, reflector, signal cables, etc.). – Replace the encoder. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive even with a faulty external position encoder.</p>

Subfault: 14.22**Description: Internal fault – critical**

	Response: Encoder 2 – latest critical fault	
	Cause	Measure
	Encoder signaled internal fault.	<ul style="list-style-type: none"> – Check the wiring. – Check interference sources (light beam interrupted, reflector, signal cables, etc.). – Replace the encoder. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 14.23**Description: Internal fault**

	Response: Encoder 2 – latest fault	
	Cause	Measure
	Encoder signaled internal fault.	<ul style="list-style-type: none"> – Check the wiring. – Check interference sources (light beam interrupted, reflector, signal cables, etc.). – Replace the encoder. <p>INFORMATION</p> <p>In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.</p>

Subfault: 14.24**Description: Travel range exceeded**

	Response: Encoder 2 – latest fault	
	Cause	Measure
	Current position mode does not allow for larger travel range.	Check the travel range. INFORMATION In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.

Subfault: 14.25**Description: Error during encoder startup**

	Response: Output stage inhibit	
	Cause	Measure
	Fatal error during encoder startup.	Switch the device off and on again. INFORMATION In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.

Subfault: 14.29**Description: Absolute position invalid**

	Response: Encoder 2 – latest fault	
	Cause	Measure
	Diagnostics error detected while evaluating absolute encoder position. Referencing is canceled.	– Reference the drive again. – If the fault occurs repeatedly, contact SEW-EURODRIVE Service. INFORMATION In "Emergency mode" manual mode, you can move the drive using the motor encoder even if the external position encoder is faulty.

10.5.13 Fault 16 Startup**Subfault: 16.1****Description: Motor not started up**

	Response: Output stage inhibit	
	Cause	Measure
	Motor not started up or not started up completely.	Perform complete motor startup.

Subfault: 16.2

Description: Cannot calculate controller parameters

	Response: Output stage inhibit	
	Cause	Measure
	Delay of encoder in use too long to calculate required filter coefficients.	Use an encoder with a shorter delay, or contact SEW-EURODRIVE Service.

Subfault: 16.3

Description: Thermal motor model not possible

	Response: Output stage inhibit	
	Cause	Measure
	Invalid parameters for thermal motor model or for drive enable although starting up thermal model not yet completed.	Check the parameters of the thermal motor model, and perform startup.

Subfault: 16.5

Description: Current limit smaller than magnetizing current of the motor

	Response: Output stage inhibit	
	Cause	Measure
	Current limit smaller than magnetizing current of the motor calculated by active control mode.	Increase the current limit. Required magnetizing current: See diagnostics parameters of control mode.

Subfault: 16.6

Description: Control mode not possible

	Response: Output stage inhibit	
	Cause	Measure
	Wrong control mode selected for the motor.	Choose a control mode that matches the selected motor.

Subfault: 16.7

Description: PWM frequency not possible

	Response: Output stage inhibit	
	Cause	Measure
	The motor cannot be operated with the inverter. The motor requires a higher PWM frequency than the inverter can provide.	Use an inverter with a suitable PWM frequency range.
	Specified PWM frequency not allowed for this power output stage.	Choose another PWM frequency. The possible PWM frequencies can be found in the device configuration data.

Subfault: 16.8**Description: Temperature sensor motor 1**

	Response: Output stage inhibit	
	Cause	Measure
	Faulty startup of temperature sensor of motor 1.	Perform startup again.

Subfault: 16.9**Description: Temperature sensor motor 2**

	Response: Output stage inhibit	
	Cause	Measure
	Faulty startup of temperature sensor of motor 2.	Perform startup again.

Subfault: 16.10**Description: Actual position source not assigned**

	Response: Application stop + output stage inhibit	
	Cause	Measure
	Active control mode requires an encoder for position mode.	<ul style="list-style-type: none"> – Assign actual position source in encoder assignment of the active drive train (index 8565.3 or 8566.3). – If no encoder is installed, activate the FCBs only using "torque control" or "speed control" operating modes.

Subfault: 16.11**Description: Motor data calculation error**

	Response: Output stage inhibit	
	Cause	Measure
	Motor startup not possible because of inconsistent motor data or wrong device configuration data.	Check the motor data for plausibility, or contact SEW-EURODRIVE Service.

Subfault: 16.12**Description: Motor data write sequence**

	Response: Output stage inhibit	
	Cause	Measure
	Subindex 1 not written to zero before writing electrical startup parameters (index 8357, 8360, 8394, 8420 or 8358, 8361, 8395, 8421).	Reset the error. Set parameters 8360/1 or 8361/1 to "0" before writing additional parameters.

Subfault: 16.13

Description: Several motor protection models are active

	Response: Output stage inhibit	
	Cause	Measure
	More than one model active at the same time in thermal motor monitoring, e.g. for asynchronous motor and synchronous motor.	If the startup parameters were changed manually, switch off motor monitoring. In all other cases, contact SEW-EURODRIVE Service.

Subfault: 16.20

Description: Nominal speed too high or nominal frequency too low

	Response: Output stage inhibit	
	Cause	Measure
	During startup using nameplate data: Nominal speed too high or nominal frequency too low. The resulting number of pole pairs is 0.	Enter plausible motor data (nominal speed and nominal frequency).

Subfault: 16.21

Description: Nominal slip negative

	Response: Output stage inhibit	
	Cause	Measure
	During startup using nameplate data, the calculated nominal slip is negative: Nominal frequency too low, or nominal speed too high, or number of pole pairs too high.	Enter plausible motor data (nominal frequency, nominal speed, number of pole pairs).

Subfault: 16.22

Description: Specify the number of pole pairs

	Response: Output stage inhibit	
	Cause	Measure
	During startup using nameplate data: It is not possible to calculate the number of pole pairs accurately from nominal frequency and nominal speed.	Enter the number of pole pairs.

Subfault: 16.23

Description: Plausibility check failed

	Response: Output stage inhibit	
	Cause	Measure
	During startup using nameplate data: The estimated nominal power does not match the entered nominal power.	Check entered nameplate data for plausibility.

Subfault: 16.24**Description: Speed controller sampling cycle not possible with current PWM frequency or current control mode**

Response: Application stop + output stage inhibit		
Cause		Measure
At a PWM frequency of "2.5 kHz", only the speed controller sampling cycle of 2 ms is permitted. For the ELSM® control mode, the only permitted speed controller sampling cycles are 1 ms and 2 ms.		Increase the PWM frequency or increase the sampling cycle of the speed controller to 2 ms. Set the sampling cycle to 1 ms or 2 ms for ELSM® control mode.

Subfault: 16.25**Description: User-defined current limit too low for standstill current**

Response: Output stage inhibit		
Cause		Measure
User-defined current limit value too small for minimum standstill current.		Increase the user-defined current limit, or disable the standstill current function.

Subfault: 16.26**Description: Nominal values incomplete or implausible**

Response: Output stage inhibit		
Cause		Measure
During startup using nameplate data: Nominal voltage, nominal current, nominal speed or nominal torque are not entered or are not plausible.		Enter or check nominal voltage, nominal current, nominal speed, and nominal torque.

Subfault: 16.27**Description: Maximum current or maximum torque not plausible**

Response: Output stage inhibit		
Cause		Measure
During startup using nameplate data: Maximum current or maximum torque not entered, or maximum current and maximum torque not plausible.		Check the maximum current and maximum torque.

Subfault: 16.30**Description: Faulty EtherCAT® EEPROM configuration status**

Response: Warning		
Cause		Measure
Faulty EtherCAT®/SBusPLUS EEPROM configuration status. EEPROM not loaded; binary file not loaded.		Contact SEW-EURODRIVE Service.
Faulty EEPROM loading procedure.		Contact SEW-EURODRIVE Service.
Faulty EEPROM checksum.		Contact SEW-EURODRIVE Service.

Subfault: 16.60**Description: Parameter setting for 3-wire control not valid**

	Response: Warning	
	Cause	Measure
	No 3-wire control stop terminal configured.	Set stop terminal parameters.

10.5.14 Fault 17 Internal processor fault**Subfault: 17.7****Description: Exception error**

	Response: Output stage inhibit	
	Cause	Measure
	Exception trap in CPU.	Contact SEW-EURODRIVE Service.

10.5.15 Fault 18 Software error**Subfault: 18.1****Description: Motor management**

	Response: Output stage inhibit System state: Fault acknowledgment with CPU reset	
	Cause	Measure
	Error detected at motor management interface.	<ul style="list-style-type: none"> – Switch the device off and on again. – Contact SEW-EURODRIVE Service if the fault persists.

Subfault: 18.3**Description: Task system warning**

	Response: Warning	
	Cause	Measure
	Error while processing internal task system. This may be a timeout for cyclical tasks, for example.	<ul style="list-style-type: none"> – Acknowledge the warning. – Contact SEW-EURODRIVE Service if the warning occurs regularly.

Subfault: 18.4**Description: Task system**

	Response: Output stage inhibit System state: Fault acknowledgment with CPU reset	
	Cause	Measure
	A fault was detected during the processing of the internal task system. This may be a timeout for cyclical tasks, for example.	<ul style="list-style-type: none"> – Switch the device off and on again. – Contact SEW-EURODRIVE Service if the fault persists.

Subfault: 18.7**Description: Fatal error**

	Response: Output stage inhibit System state: Fault acknowledgment with CPU reset	
	Cause	Measure
	Fatal software error.	<ul style="list-style-type: none"> – Switch the device off and on again. – If the fault occurs repeatedly, replace the device and send it together with the fault number to SEW-EURODRIVE. For further support, contact SEW-EURODRIVE Service.

Subfault: 18.8**Description: Invalid fault code**

	Response: Output stage inhibit	
	Cause	Measure
	Invalid fault code requested.	<ul style="list-style-type: none"> – Switch the device off and on again. – Contact SEW-EURODRIVE Service if the fault persists.

Subfault: 18.9**Description: Internal software error**

	Response: Output stage inhibit System state: Fault acknowledgment with CPU reset	
	Cause	Measure
	The software reports an unexpected event.	<ul style="list-style-type: none"> – Switch the device off and on again. – If the fault occurs repeatedly, replace the device and send it together with the fault number to SEW-EURODRIVE. For further support, contact SEW-EURODRIVE Service.

Subfault: 18.10**Description: Watchdog**

	Response: Output stage inhibit	
	Cause	Measure
	Software no longer operates within intended cycle time.	<ul style="list-style-type: none"> – Switch the device off and on again. – Contact SEW-EURODRIVE Service if the fault persists.

Subfault: 18.12		
Description: Configuration data		
	Response: Output stage inhibit System state: Fault acknowledgment with CPU reset	
	Cause	Measure
	Configuration data not plausible or cannot be interpreted by active firmware version.	Update the firmware or load valid configuration data.

Subfault: 18.13		
Description: Calibration data		
	Response: Output stage inhibit System state: Fault acknowledgment with CPU reset	
	Cause	Measure
	Calibration data not plausible.	Load valid calibration data.

10.5.16 Fault 19 Process data

Subfault: 19.1		
Description: Torque setpoint violation		
	Response: Application stop + output stage inhibit	
	Cause	Measure
	Implausible values specified as torque setpoints.	Adjust torque setpoints.

Subfault: 19.2		
Description: Position setpoint violation		
	Response: Application stop + output stage inhibit	
	Cause	Measure
	Position setpoint outside software limit switches.	Check the position setpoint.
	Position setpoint outside modulo range.	Check the position setpoint.
	Position in user unit generates number overflow in the system unit.	Check the position in user unit.

Subfault: 19.3		
Description: Speed setpoint violation		
	Response: Application stop + output stage inhibit	
	Cause	Measure
	Specified rotational speed setpoints not plausible.	Adjust rotational speed setpoints.

Subfault: 19.4**Description: Acceleration setpoint violation**

Response: Emergency stop + output stage inhibit		
	Cause	Measure
	The specified acceleration setpoints are not plausible. Only a value range of ≥ 0 is permitted.	Adjust acceleration setpoints.

Subfault: 19.5**Description: Drive function does not exist**

Response: Application stop + output stage inhibit		
	Cause	Measure
	Non-existing drive function (FCB) selected via process data.	Specify an existing FCB number for FCB activation via process data.

Subfault: 19.6**Description: Mass moment of inertia setpoint violation**

Response: Emergency stop + output stage inhibit		
	Cause	Measure
	Implausible values specified as mass moment of inertia setpoints. Only a value range of ≥ 0 is permitted.	Adjust the setpoints for the mass moment of inertia.

Subfault: 19.7**Description: Referencing missing**

Response: Application stop + output stage inhibit		
	Cause	Measure
	Activated function permitted only with referenced encoder.	Reference the encoder first, then activate the function.

Subfault: 19.8**Description: Drive train changeover not allowed**

Response: Application stop + output stage inhibit		
	Cause	Measure
	Drive train changeover requested while output stage is enabled.	Inhibit the output stage before changing to another drive train.

Subfault: 19.9**Description: Jerk setpoint violation**

Response: Application stop + output stage inhibit		
	Cause	Measure
	Jerk values not plausible.	Adjust the jerk setpoints.

10.5.17 Fault 20 Device monitoring

Subfault: 20.1**Description: Supply voltage fault**

Response: Output stage inhibit

System state: Fault acknowledgment with CPU reset

Cause	Measure
Internal electronics supply voltage or externally connected DC 24 V standby supply voltage outside permitted voltage range.	<p>Check the voltage level of the external DC 24 V standby supply voltage and check for correct connection. If required, correct.</p> <ul style="list-style-type: none"> – Acknowledge the fault. – If the fault occurs repeatedly, replace the device. For further support, contact SEW-EURODRIVE Service.

Subfault: 20.2**Description: Supply voltage overload**

Response: Output stage inhibit

Cause	Measure
For MOVIDRIVE® system, the current load of the current paths of the DC 24 V standby supply voltage inside the device is too high. The device signal output of the device was de-energized because of the fault message.	<p>Identify the consumer that is overloading the internal supply voltage:</p> <ol style="list-style-type: none"> 1. Remove all external consumers: <ul style="list-style-type: none"> – At the digital outputs of the basic unit. – At options that may be present. – At all encoder connections. – At other consumers at the DC 24 V output voltage terminals. 2. Acknowledge the error. 3. Reconnect the consumers with the device, one after the other, until the fault message appears once again. 4. To eliminate the fault, connect a consumer with a lower current consumption or eliminate the short circuit.

Subfault: 20.7**Description: Internal hardware fault**

Response: Output stage inhibit

System state: Fault acknowledgment with CPU reset

Cause	Measure
Fault in the device hardware.	<ul style="list-style-type: none"> – Acknowledge the fault. – If the fault occurs repeatedly, replace the device. For further support, contact SEW-EURODRIVE Service.

Subfault: 20.8		
Description: Fan warning		
	Response: Warning with self-reset	
	Cause	Measure
	Fan function impaired.	Check the fan for proper functioning.
Subfault: 20.9		
Description: Fan fault		
	Response: Application stop + output stage inhibit	
	Cause	Measure
	Fan defective.	Contact SEW-EURODRIVE Service.
Subfault: 20.10		
Description: Fan supply voltage fault		
	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	Supply voltage of fan missing.	Check the connection or establish a connection.
Subfault: 20.11		
Description: STO – switching delay		
	Response: Output stage inhibit	
	Cause	Measure
	Switching delay between STO signals F-STO_P1 and F-STO_P2.	<ul style="list-style-type: none"> – Check the STO wiring. – Before acknowledging the fault, make sure that both STO signals are switched to low level.
Subfault: 20.23		
Description: Power section temperature detection		
	Response: Output stage inhibit	
	Cause	Measure
	Fault in the device hardware. Power section does not provide temperature data.	<ul style="list-style-type: none"> – Acknowledge the fault. – If the fault occurs repeatedly, replace the device. For further support, contact SEW-EURODRIVE Service.

10.5.18 Fault 21 Digital motor integration 1

Subfault: 21.1		
Description: Communication error		
	Response: Output stage inhibit	
	Cause	Measure
	Communication error detected on the interface of digital motor integration.	Check the cabling.

Subfault: 21.2		
Description: Slave required		
	Response: Digital motor integration	
	Cause	Measure
	Device started up with a drive with digital motor integration but no drive with digital motor integration is connected.	Connect a suitable drive with digital motor integration for startup, or perform a new startup.

Subfault: 21.3		
Description: Incompatible driving motor		
	Response: Output stage inhibit	
	Cause	Measure
	Connected drive not compatible with started-up drive.	Connect a drive that matches startup, or perform a new startup.

Subfault: 21.4		
Description: Invalid label		
	Response: Output stage inhibit	
	Cause	Measure
	The connected drive contains invalid data.	Replace the drive.

Subfault: 21.5		
Description: Incompatible slave		
	Response: Output stage inhibit	
	Cause	Measure
	The connected slave of digital motor integration cannot be used with this inverter firmware.	Update the inverter or the slave.

Subfault: 21.6		
Description: Overload/short circuit on the interface		
	Response: Output stage inhibit	
	Cause	Measure
	Short circuit in the cabling of components of digital motor integration.	Check the cabling of the digital motor integration component.
	Voltage of digital motor integration component too low.	Check the voltage supply of the component.

Subfault: 21.7		
Description: Continuous supply current of slave too high		
	Response: Output stage inhibit	
	Cause	Measure
	The continuous supply current of the slave is too large for operation on the device.	Use a slave with lower supply current.

Subfault: 21.8**Description: Parameter error**

	Response: Output stage inhibit	
	Cause	Measure
	Error while processing data from digital motor integration slave.	Repeat the process in configuration state.
	The connected drive contains invalid data.	Replace the drive.

Subfault: 21.9**Description: Illegal hot plug**

	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	A slave of digital motor integration was connected while the drive was enabled.	Set the device to configuration state or switch it off. Connect the slave.
	A slave of digital motor integration was connected while the device was in standby mode without switching off the encoder supply.	Switch off encoder supply in standby mode. Connect the slave.

Subfault: 21.20**Description: Slave fault – critical**

	Response: Output stage inhibit	
	Cause	Measure
	A slave of digital motor integration detected a critical component fault.	For the exact cause of the fault and for information on how to remedy it, refer to the fault signaled by the subcomponent.

Subfault: 21.21**Description: Slave fault**

	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	A slave of digital motor integration detected a component fault.	For the exact cause of the fault and for information on how to remedy it, refer to the fault signaled by the subcomponent.

Subfault: 21.22**Description: Slave warning**

	Response: Warning	
	Cause	Measure
	A slave of digital motor integration issued a warning.	For the exact cause of the fault and for information on how to correct the warning, refer to the fault signaled by the subcomponent.

10.5.19 Fault 23 Power section

Subfault: 23.1		
Description: Warning		
	Response: Warning with self-reset	
	Cause	Measure
	Power section fault with fault response of the type "Warning".	See also "Power section subcomponent" fault status.
Subfault: 23.2		
Description: Fault		
	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	Power section fault with fault response of the type "Standard".	See also "Power section subcomponent" fault status.
Subfault: 23.3		
Description: Critical fault		
	Response: Output stage inhibit	
	Cause	Measure
	Power section fault with fault response of the type "Critical fault".	See also "Power section subcomponent" fault status.
Subfault: 23.4		
Description: Hardware fault		
	Response: Output stage inhibit	
	Cause	Measure
	A fault occurred in a hardware component of the power section, e.g.: Overcurrent hardware comparator.	<ul style="list-style-type: none"> – Check the current supply. – Increase the ramp time. – Check for correct motor size (the motor current is too high). – Contact SEW-EURODRIVE Service.
	Switched-mode power supply fault, hardware fault.	<ul style="list-style-type: none"> – Check the current supply. – Check the DC 24 V supply voltage.
	Fault at the gate driver of an IGBT.	Defect in the power output stage. Contact SEW-EURODRIVE Service.
	Invalid process data configuration. Status of control section and power section are not compatible.	Contact SEW-EURODRIVE Service.
Subfault: 23.5		
Description: Invalid process data configuration		
	Response: Output stage inhibit	
	Cause	Measure
	Invalid process data configuration.	Contact SEW-EURODRIVE Service.

Subfault: 23.6**Description: Process data timeout**

	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	Power section communication interface detected process data timeout.	If the fault occurs repeatedly, contact SEW-EURODRIVE Service.

Subfault: 23.7**Description: Parameter communication timeout**

	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	Power section communication interface detected timeout in parameter communication.	If the fault occurs repeatedly, contact SEW-EURODRIVE Service.

Subfault: 23.8**Description: Parameter communication error**

	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	Power section communication interface detected error in parameter communication.	If the fault occurs repeatedly, contact SEW-EURODRIVE Service.

Subfault: 23.9**Description: Firmware of power section corrupt**

	Response: Output stage inhibit	
	Cause	Measure
	Failed to update firmware on power section.	Update the firmware again.

10.5.20 Fault 24 Cam switch**Subfault: 24.1****Description: Cam window limits interchanged**

	Response: Warning	
	Cause	Measure
	Left cam window limit larger than right limit.	Check cam window limits and adjust.

Subfault: 24.2**Description: Cam window limit not within modulo range**

	Response: Warning	
	Cause	Measure
	Cam window limits outside modulo range.	Check cam window limits and adjust.

Subfault: 24.3		
Description: Overlapping cam windows in track		
	Response: Warning	
	Cause	Measure
	Cam window limits of a track overlap.	Adjust the cam window limits in such a way that they are flush.

Subfault: 24.4		
Description: Modulo limits swapped		
	Response: Warning	
	Cause	Measure
	The left limit of the modulo range is larger than the right limit.	Check the limits of the modulo range and adjust accordingly.

10.5.21 Fault 25 Parameter memory monitoring

Subfault: 25.1		
Description: Timeout warning		
	Response: Warning with self-reset	
	Cause	Measure
	Access to memory (R/W) takes longer than expected.	The error will be reset automatically after completed memory access.

Subfault: 25.2		
Description: NV memory – runtime error		
	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	Runtime error of non-volatile memory system.	<ul style="list-style-type: none"> – Reset the device. – If this error occurs repeatedly, replace the device. Contact SEW-EURODRIVE Service.

Subfault: 25.6**Description: Incompatible device configuration**

Response: Output stage inhibit		
	Cause	Measure
	The data set in the device was copied from another device, which differs from the current device in the device family, power, or voltage.	<ul style="list-style-type: none"> – Check whether the configuration is correct and repeat the startup, if necessary. – Acknowledge the fault by manual reset with parameter set acceptance. Setting under [Diagnostics] > [Status] > [Fault status] parameter "Manual fault reset".
	Replaceable memory module used by another device. Power, device family, or voltage differs from the current device.	<ul style="list-style-type: none"> – Check whether the configuration is correct and repeat the startup, if necessary. – Acknowledge the fault by manual reset with parameter set acceptance. Setting under [Diagnostics] > [Status] > [Fault status] parameter "Manual fault reset".
	The power section was replaced and differs in its power rating or voltage from the original power section.	<ul style="list-style-type: none"> – Check whether the configuration is correct and repeat the startup, if necessary. – Acknowledge the fault by manual reset with parameter set acceptance. Setting under [Diagnostics] > [Status] > [Fault status] parameter "Manual fault reset".

Subfault: 25.7**Description: NV memory initialization – error**

Response: Output stage inhibit		
	Cause	Measure
	Error initializing non-volatile memory system.	<ul style="list-style-type: none"> – Reset the device. – If this error occurs repeatedly, replace the device. Contact SEW-EURODRIVE Service.

Subfault: 25.10**Description: Power section configuration data – version conflict**

Response: Output stage inhibit		
	Cause	Measure
	Wrong version of configuration data of power section.	Contact SEW-EURODRIVE Service.

Subfault: 25.12**Description: Power section configuration data – CRC error**

Response: Output stage inhibit		
	Cause	Measure
	Faulty configuration data of power section.	Contact SEW-EURODRIVE Service.

Subfault: 25.13

Description: Control electronics configuration data – CRC error

	Response: Output stage inhibit	
	Cause	Measure
	Faulty configuration data of control electronics.	Contact SEW-EURODRIVE Service.

Subfault: 25.14

Description: Calibration data of power section – version conflict

	Response: Output stage inhibit	
	Cause	Measure
	Wrong version of calibration data of power section.	Contact SEW-EURODRIVE Service.

Subfault: 25.15

Description: Calibration data of control electronics – version conflict

	Response: Output stage inhibit	
	Cause	Measure
	Wrong version of calibration data of control electronics.	Contact SEW-EURODRIVE Service.

Subfault: 25.16

Description: Power section calibration data – CRC error

	Response: Output stage inhibit	
	Cause	Measure
	Faulty calibration data of power section.	Contact SEW-EURODRIVE Service.

Subfault: 25.17

Description: Control electronics calibration data – CRC error

	Response: Output stage inhibit	
	Cause	Measure
	Faulty calibration data of control electronics.	Contact SEW-EURODRIVE Service.

Subfault: 25.18

Description: Power section QA data – CRC error

	Response: Warning	
	Cause	Measure
	Faulty quality assurance data of power section.	Contact SEW-EURODRIVE Service.

Subfault: 25.19**Description: Control electronics QA data – CRC error**

	Response: Warning	
	Cause	Measure
	Faulty quality assurance data of control electronics.	Contact SEW-EURODRIVE Service.

Subfault: 25.20**Description: Initialization error – basic unit memory**

	Response: Output stage inhibit	
	Cause	Measure
	Initialization error of the basic unit memory.	Contact SEW-EURODRIVE Service.

Subfault: 25.21**Description: Runtime error – basic unit memory**

	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	Runtime error in memory of basic unit.	Contact SEW-EURODRIVE Service.

Subfault: 25.30**Description: Initialization error – replaceable memory module**

	Response: Output stage inhibit	
	Cause	Measure
	The formatting of the replaceable memory module does not match.	Restore delivery state. NOTICE All the data on the replaceable memory module will be reset to default.
	Initialization error of replaceable memory module after delivery state.	Contact SEW-EURODRIVE Service.

Subfault: 25.31**Description: Runtime error – replaceable memory module**

	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	Runtime error of replaceable memory module.	Contact SEW-EURODRIVE Service.

Subfault: 25.32**Description: Replaceable memory module not compatible**

	Response: Output stage inhibit System state: Fault acknowledgment with CPU reset	
	Cause	Measure
	The inserted replaceable memory module cannot be used.	Replace the memory module.

Subfault: 25.50		
Description: Runtime error – replaceable safety memory module		
	Response: Output stage inhibit System state: Fault acknowledgment with CPU reset	
	Cause	Measure
	Runtime error of the replaceable safety memory module.	Contact SEW-EURODRIVE Service.

Subfault: 25.51		
Description: Initialization error – replaceable safety memory module		
	Response: Warning	
	Cause	Measure
	Initialization error of the replaceable safety memory module.	Contact SEW-EURODRIVE Service.

Subfault: 25.61		
Description: Failure – restore point		
	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	Failed to create restore point.	Delete restore point.

Subfault: 25.70		
Description: Incompatible card configuration		
	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	The current configuration of the cards does not match the state of the stored startup. For example, a card was removed that was still present during startup.	<ul style="list-style-type: none"> – Restore the original configuration of the cards. – Acknowledge the fault by manual reset with parameter set acceptance. Setting under [Diagnostics] > [Status] > [Fault status] parameter "Manual fault reset".

10.5.22 Fault 26 External fault

Subfault: 26.1		
Description: Terminal		
	Response: External fault	
	Cause	Measure
	Fault message about external fault source.	Programmable via 8622.5 (default: application stop (with output stage inhibit)).

Subfault: 26.2**Description: Emergency shutdown**

	Response: Output stage inhibit	
	Cause	Measure
	Another module bus station requested external emergency shutdown.	Check other module bus stations for faults.

Subfault: 26.3**Description: Power section emergency shutdown**

	Response: Output stage inhibit	
	Cause	Measure
	Power section requested external emergency shutdown because it detected critical fault.	Contact SEW-EURODRIVE Service.

Subfault: 26.4**Description: External braking resistor fault**

	Response: Response to external braking resistor fault	
	Cause	Measure
	External braking resistor's temperature switch connected to terminal tripped.	<ul style="list-style-type: none"> – Check the resistor mounting position. – Clean the resistor. – Check the configuration of the resistor. – Install a larger resistor. – Check the trip switch settings. – Optimize the travel cycle so that less regenerative operation energy arises.

10.5.23 Fault 28 FCB drive functions**Subfault: 28.1****Description: FCB 11/12 – Timeout while searching zero pulse**

	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	Failed to find zero pulse of encoder's C track within specified search time during reference travel.	Check the encoder wiring.

Subfault: 28.2**Description: FCB 11/12 – Hardware limit switch upstream of reference cam**

	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	The hardware limit switch was reached during reference travel. The reference cam was not detected.	Make sure that the reference cam is not installed downstream of the hardware limit switch.

Subfault: 28.3

Description: FCB 11/12 – Hardware limit switch and reference cam not flush

Response: Emergency stop + output stage inhibit		
	Cause	Measure
	Hardware limit switch and reference cam not mounted flush.	Make sure that the reference cam and the hardware limit switch are mounted flush.

Subfault: 28.4

Description: FCB 11/12 – Reference offset error

Response: Emergency stop + output stage inhibit		
	Cause	Measure
	Error while determining reference offset.	<ul style="list-style-type: none"> – Make sure that the reference offset is smaller than the "Modulo maximum" limit value. – When using a single-turn absolute encoder, make sure that the reference offset is larger than one encoder revolution.

Subfault: 28.5

Description: FCB 11/12 – Referencing not possible

Response: Emergency stop + output stage inhibit		
	Cause	Measure
	In the active drive train, the "Actual position source" parameter is set to "No encoder".	Assign "Actual position source", or do not perform any referencing.

Subfault: 28.6

Description: FCB 11/12 – Limit switch/reference cam not flush/overlapping with fixed stop

Response: Emergency stop + output stage inhibit		
	Cause	Measure
	Hardware limit switch or reference cam that has not been selected was approached during reference travel to fixed stop.	Check whether the parameters set for reference travel are correct.
	During reference travel to fixed stop with selected hardware limit switch or reference cam, the fixed stop was reached without hitting the hardware limit switch or reference cam.	Check whether the parameters set for reference travel are correct.

Subfault: 28.7

Description: FCB 21 – Total torque greater than maximum torque at motor shaft

Response: Output stage inhibit		
	Cause	Measure
	The required total torque from the torque input and load torque is greater than the permitted maximum torque at the motor shaft.	Reduce the torque input.

Subfault: 28.8**Description: FCB 21 – Total torque not reached**

	Response: Output stage inhibit	
	Cause	Measure
	The required total torque from torque input and load torque is limited internally.	<ul style="list-style-type: none"> – Reduce the torque input. – Check limit values.

Subfault: 28.9**Description: FCB 18 – Rotor position identification not possible**

	Response: Output stage inhibit	
	Cause	Measure
	Rotor position identification started with incremental encoder but aborted prematurely.	<ul style="list-style-type: none"> – Restart the rotor position identification. – Check whether the encoder is connected correctly. – Check whether the encoder is defective.
	Result of rotor position identification cannot be stored in encoder.	Select "Inverter" as storage location.
	Combination of "Automatic" operating mode and "Encoder" storage location not permitted.	Set the operating mode to "Manual" or the storage location to "Inverter".

Subfault: 28.10**Description: FCB 25 – Asymmetrical motor phases**

	Response: Output stage inhibit	
	Cause	Measure
	Significantly different values determined in the 3 phases while measuring stator resistances.	<ul style="list-style-type: none"> – Check whether the motor is connected correctly. – Check all contact points on the motor and inverter. – Check the motor and motor cable for damage.

Subfault: 28.11**Description: FCB 25 – At least one phase with high resistance**

	Response: Output stage inhibit	
	Cause	Measure
	At least one motor phase could not be measured during motor parameter measurement.	<ul style="list-style-type: none"> – Check whether the motor is connected correctly. – Check all contact points on the motor and inverter. – Check the motor and motor cable for damage.

Subfault: 28.12

Description: FCB 25 – Timeout during stator resistance measurement

Response: Output stage inhibit		
	Cause	Measure
	Motor parameter measurement activated while motor is turning.	<ul style="list-style-type: none"> – Stop the motor. – Start motor parameter measurement when the motor is at standstill.

Subfault: 28.13

Description: FCB 25 – Characteristic curve identification not possible

Response: Output stage inhibit		
	Cause	Measure
	Motor parameter measurement does not allow for unique identification of the characteristic curve.	Contact SEW-EURODRIVE Service.

Subfault: 28.14

Description: Modulo min. and max. swapped

Response: Emergency stop + output stage inhibit		
	Cause	Measure
	In the active data set, the value for "Modulo minimum" is greater than the value for "Modulo maximum"; see Monitoring functions\Limit values 1 or Monitoring functions\Limit values 2.	Swap the values for modulo minimum and modulo maximum.

Subfault: 28.15

Description: FCB 25 – Timeout

Response: Output stage inhibit		
	Cause	Measure
	Measuring rotor resistance, LSigma, or stator inductance not completed.	Contact SEW-EURODRIVE Service.

Subfault: 28.17

Description: FCB only possible for drive train 1

Response: Output stage inhibit		
	Cause	Measure
	The activated FCB can only be operated if drive train 1 is set as the active drive train.	Select drive train 1 as the active drive train.

Subfault: 28.18**Description: FCB 21 – Brake missing**

	Response: Application stop + output stage inhibit	
	Cause	Measure
	No brake is parameterized. Only brakes controlled by the inverter are tested during the brake test.	<ul style="list-style-type: none"> – Connect the brake to the inverter and parameterize it. – Start FCB 21 again.

Subfault: 28.19**Description: FCB 21 – Motor encoder missing**

	Response: Application stop + output stage inhibit	
	Cause	Measure
	No encoder is parameterized. An encoder is required for the brake test to detect the movement of the drive.	<ul style="list-style-type: none"> – Mount the encoder to the motor and parameterize it. – Start the FCB again.

10.5.24 Fault 29 HW limit switches**Subfault: 29.1****Description: Positive limit switch hit**

	Response: HW limit switch – current drive train	
	Cause	Measure
	Positive hardware limit switch hit.	<ul style="list-style-type: none"> – Check the wiring of the hardware limit switch. – Check the target position. – Move clear of the hardware limit switch at negative speed.

Subfault: 29.2**Description: Negative limit switch hit**

	Response: HW limit switch – current drive train	
	Cause	Measure
	Negative hardware limit switch hit.	<ul style="list-style-type: none"> – Check the wiring of the hardware limit switch. – Check the target position. – Move clear of the hardware limit switch at positive speed.

Subfault: 29.3		
Description: Limit switch missing		
	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	Both positive and negative hardware limit switches hit at the same time.	<ul style="list-style-type: none"> – Check the wiring of the hardware limit switch. – Check the parameter setting of the digital inputs. – Check the parameter setting of the process output data.
Subfault: 29.4		
Description: Limit switches swapped		
	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	Positive hardware limit switch hit at negative speed, or negative hardware limit switch hit at positive speed.	Check whether hardware limit switch connections are swapped.

10.5.25 Fault 30 Software limit switches

Subfault: 30.1		
Description: Positive limit switch hit		
	Response: SW limit switches – current drive train	
	Cause	Measure
	Positive software limit switch hit.	<ul style="list-style-type: none"> – Check software limit switch position. – Check the target position. – Move clear of software limit switch at negative speed.
Subfault: 30.2		
Description: Negative limit switch hit		
	Response: SW limit switches – current drive train	
	Cause	Measure
	Negative software limit switch hit.	<ul style="list-style-type: none"> – Check software limit switch position. – Check the target position. – Move clear of software limit switch at positive speed.

Subfault: 30.3**Description: Limit switches swapped**

	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	Position value of negative software limit switch greater than position value of positive software limit switch.	Check software limit switch positions.

10.5.26 Fault 31 Thermal motor protection**Subfault: 31.1****Description: Temperature sensor wire break – motor 1**

	Response: Application stop + output stage inhibit	
	Cause	Measure
	Connection to temperature sensor of motor 1 interrupted.	Check the wiring of the temperature sensor.

Subfault: 31.2**Description: Temperature sensor short circuit – motor 1**

	Response: Application stop + output stage inhibit	
	Cause	Measure
	Short circuit in connection with temperature sensor of motor 1.	Check the wiring of the temperature sensor.

Subfault: 31.3**Description: Temperature sensor overtemperature – motor 1**

	Response: Output stage inhibit	
	Cause	Measure
	Temperature sensor of motor 1 signals overtemperature.	<ul style="list-style-type: none"> – Allow the motor to cool down. – Check for motor overload. – Check whether the correct temperature sensor KY (KTY) was parameterized instead of PK (PT1000).

Subfault: 31.4**Description: Temperature model overtemperature – motor 1**

	Response: Output stage inhibit	
	Cause	Measure
	Temperature model of motor 1 signals overtemperature.	<ul style="list-style-type: none"> – Allow the motor to cool down. – Check for motor overload. – Check whether the correct temperature sensor KY (KTY) was parameterized instead of PK (PT1000).

Subfault: 31.5

Description: Temperature sensor prewarning – motor 1

	Response: Thermal motor protection 1 – prewarning threshold	
	Cause	Measure
	Temperature signaled by temperature sensor of motor 1 exceeds prewarning threshold.	Check for motor overload.

Subfault: 31.6

Description: Temperature model prewarning – motor 1

	Response: Thermal motor protection 1 – prewarning threshold	
	Cause	Measure
	Temperature signaled by temperature model of motor 1 exceeds prewarning threshold.	Check for motor overload.

Subfault: 31.7

Description: UL temperature monitoring

	Response: Output stage inhibit	
	Cause	Measure
	Temperature model of active motor signals over-temperature.	Check for motor overload.

Subfault: 31.8

Description: Communication timeout temperature sensor – motor 1

	Response: Output stage inhibit	
	Cause	Measure
	Communication with temperature sensor is disrupted, e.g. via MOVILINK® DDI.	Check the cabling.

Subfault: 31.9

Description: Temperature too low – temperature sensor – motor 1

	Response: Warning with self-reset	
	Cause	Measure
	Temperature signaled by temperature sensor of motor 1 below -50 °C.	<ul style="list-style-type: none"> – Check if a KTY temperature sensor is installed in the motor but the parameterization has been carried out for a PT1000 temperature sensor. – Heat the motor.

Subfault: 31.11

Description: Temperature sensor wire break – motor 2

	Response: Application stop + output stage inhibit	
	Cause	Measure
	Connection to temperature sensor of motor 2 interrupted.	Check the wiring of the temperature sensor.

Subfault: 31.12**Description: Temperature sensor short circuit – motor 2**

	Response: Application stop + output stage inhibit	
	Cause	Measure
	Short circuit in connection with temperature sensor of motor 2.	Check the wiring of the temperature sensor.

Subfault: 31.13**Description: Temperature sensor overtemperature – motor 2**

	Response: Output stage inhibit	
	Cause	Measure
	Temperature sensor of motor 2 signals overtemperature.	<ul style="list-style-type: none"> – Allow the motor to cool down. – Check for motor overload. – Check whether the correct temperature sensor KY (KTY) was parameterized instead of PK (PT1000).

Subfault: 31.14**Description: Temperature model overtemperature – motor 2**

	Response: Output stage inhibit	
	Cause	Measure
	Temperature model of motor 2 signals overtemperature.	<ul style="list-style-type: none"> – Allow the motor to cool down. – Check for motor overload. – Check whether the correct temperature sensor KY (KTY) was parameterized instead of PK (PT1000).

Subfault: 31.15**Description: Temperature sensor prewarning – motor 2**

	Response: Thermal motor protection 2 – prewarning threshold	
	Cause	Measure
	Temperature signaled by temperature sensor of motor 2 exceeds prewarning threshold.	Check for motor overload.

Subfault: 31.16**Description: Temperature model prewarning – motor 2**

	Response: Thermal motor protection 2 – prewarning threshold	
	Cause	Measure
	Temperature signaled by temperature model of motor 2 exceeds prewarning threshold.	Check for motor overload.

Subfault: 31.19

Description: Temperature too low – temperature sensor – motor 2

Response: Warning with self-reset		
	Cause	Measure
	Temperature signaled by temperature sensor of motor 2 below -50 °C.	<ul style="list-style-type: none"> – Check if a KTY temperature sensor is installed in the motor but the parameterization has been carried out for a PT1000 temperature sensor. – Heat the motor.

10.5.27 Fault 32 Communication

Subfault: 32.2

Description: EtherCAT®/SBus^{PLUS} process data timeout

Response: Fieldbus – timeout response		
	Cause	Measure
	Timeout in process data transfer during EtherCAT®/SBus ^{PLUS} communication.	<ul style="list-style-type: none"> – Check the wiring of the system bus and module bus. – Check that the EtherCAT®/SBus^{PLUS} configuration is set correctly in the MOVI-C® CONTROLLER. – Check the EtherCAT®/SBus^{PLUS} timeout configuration in the device.

Subfault: 32.3

Description: Faulty synchronization signal

Response: External synchronization		
	Cause	Measure
	Faulty synchronization signal period.	Make sure that the EtherCAT®/SBus ^{PLUS} configuration is set correctly in the MOVI-C® CONTROLLER.

Subfault: 32.4

Description: No synchronization signal

Response: External synchronization		
	Cause	Measure
	No synchronization signal present.	Make sure that the EtherCAT®/SBus ^{PLUS} configuration is set correctly in the MOVI-C® CONTROLLER.

Subfault: 32.5**Description: Synchronization timeout**

	Response: External synchronization	
	Cause	Measure
	Timeout while synchronizing to synchronization signal.	Make sure that the EtherCAT®/SBus ^{PLUS} configuration is set correctly in the MOVI-C® CONTROLLER.

Subfault: 32.6**Description: Copy parameter set**

	Response: Output stage inhibit	
	Cause	Measure
	Error while downloading parameter set to device.	<ul style="list-style-type: none"> – Check the wiring of the system bus and module bus. – Restart download.

Subfault: 32.7**Description: Application heartbeat timeout**

	Response: Application heartbeat – timeout response	
	Cause	Measure
	Communication interrupted between IEC program in MOVI-C® CONTROLLER and device.	<ul style="list-style-type: none"> – Check the status of the IEC program. – Restart the IEC program.

Subfault: 32.8**Description: User-timeout timeout**

	Response: User timeout – timeout response	
	Cause	Measure
	The timeout time of the user timeout function elapsed.	Write the parameter for triggering the user timeout function cyclically before the timeout time elapses.

Subfault: 32.12**Description: Manual mode timeout**

	Response: Manual mode – timeout response	
	Cause	Measure
	Communication connection to device interrupted in manual mode.	<ul style="list-style-type: none"> – Check whether too many programs are open on the engineering PC. – Increase the timeout time in manual mode.
	New Scope project created.	<ul style="list-style-type: none"> – Reset the fault. – Restart manual mode.
	Scope measurement loaded from device.	<ul style="list-style-type: none"> – Reset the fault. – Restart manual mode.

10.5.28 Fault 33 System initialization

Subfault: 33.1		
Description: Offset determination current measurement		
	Response: Output stage inhibit	
	System state: Fault acknowledgment with CPU reset	
	Cause	Measure
	Error detected during current measurement.	Contact SEW-EURODRIVE Service.
Subfault: 33.2		
Description: Firmware CRC check		
	Response: Output stage inhibit	
	System state: Fault acknowledgment with CPU reset	
	Cause	Measure
	Error checking firmware.	Contact SEW-EURODRIVE Service.
Subfault: 33.6		
Description: FPGA configuration		
	Response: Output stage inhibit	
	Cause	Measure
	Error checking FPGA configuration.	Contact SEW-EURODRIVE Service.
Subfault: 33.7		
Description: Function block compatibility error		
	Response: Output stage inhibit	
	Cause	Measure
	Error checking compatibility of function block.	Contact SEW-EURODRIVE Service.
Subfault: 33.8		
Description: SW function block configuration		
	Response: Output stage inhibit	
	Cause	Measure
	Error detected while checking configuration of software function block.	Contact SEW-EURODRIVE Service.
Subfault: 33.10		
Description: Run-up timeout		
	Response: Output stage inhibit	
	System state: Fault acknowledgment with CPU reset	
	Cause	Measure
	Timeout during system run-up.	Contact SEW-EURODRIVE Service.

26860791/EN – 07/2022

Subfault: 33.11**Description: Hardware compatibility error**

	Response: Output stage inhibit	
	Cause	Measure
	Firmware does not match device.	Contact SEW-EURODRIVE Service.

Subfault: 33.12**Description: Memory module plugged in**

	Response: Output stage inhibit System state: Fault acknowledgment with CPU reset	
	Cause	Measure
	A plugged-in memory module was detected during device start. The setting for the device parameter source is set to "Internal memory".	<ul style="list-style-type: none"> – Switch off the device. Remove the memory module and restart the device. – Change the parameter "Non-volatile memory source" to "Arbitrary" or "Replaceable memory module". Switch the device off and on again.

Subfault: 33.13**Description: Memory module removed**

	Response: Output stage inhibit System state: Fault acknowledgment with CPU reset	
	Cause	Measure
	The device was started without a memory module. This device variant can be operated without memory module.	Switch off the device, insert the memory module, and switch on the device again.
	The device was started without a memory module. For the parameter "NV memory source", however, the setting "Replaceable memory module" was defined.	<ul style="list-style-type: none"> – Switch off the device, insert the memory module, and switch on the device again. – Change the setting of the "NV memory source" to "Internal memory". Switch the device off and on again.
	Replaceable memory module removed during on-going operation.	<ul style="list-style-type: none"> – Switch off the device, insert the memory module, and switch on the device again. – Change the setting of the "NV memory source" to "Internal memory". Switch the device off and on again.

Subfault: 33.14**Description: EtherCAT® slave controller cannot be accessed**

	Response: Output stage inhibit System state: Fault acknowledgment with CPU reset	
	Cause	Measure
	EtherCAT® slave controller cannot be accessed.	Contact SEW-EURODRIVE Service.

Subfault: 33.15		
Description: Firmware configuration		
	Response: Output stage inhibit	
	System state: Fault acknowledgment with CPU reset	
	Cause	Measure
	The Device Update Manager detected a modified version of the application firmware.	Acknowledge the error. Doing so will update the configuration data of the Device Update Manager.
	The error occurs repeatedly several times. The Device Update Manager is outdated and cannot save the configuration.	Update the Device Update Manager.

Subfault: 33.18		
Description: Fieldbus configuration		
	Response: Output stage inhibit	
	System state: Fault acknowledgment with CPU reset	
	Cause	Measure
	<p>The fieldbus variant is not compatible with the firmware variant of the main firmware:</p> <ul style="list-style-type: none"> – With CiA402 firmware variants, only POWER-LINK or EtherCAT® is possible. – With standard firmware variants, POWERLINK is not possible. 	<ul style="list-style-type: none"> – Load the appropriate variant of the main firmware. – Load the appropriate variant of the fieldbus firmware. – For devices with pluggable fieldbus card, replace the card.

10.5.29 Fault 34 Process data configuration

Subfault: 34.1		
Description: Changed process data configuration		
	Response: Application stop + output stage inhibit	
	Cause	Measure
	Process data configuration changed during active process data operation.	<ul style="list-style-type: none"> – Stop the process data and make your changes. Then start the process data again. – Perform a reset. Doing so will stop the process data, apply the changes, and restart the process data.

10.5.30 Fault 35 Function activation

Subfault: 35.1		
Description: Activation level – invalid activation key		
	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	The activation key was entered incorrectly.	Enter the activation key again.
	The activation key was not created for this device.	Check the activation key.
	When using a double axis, the activation key for the wrong instance was entered in the device.	Enter the activation key for the allocated instance.
	Activation key entered for technology level in parameter "Application level – activation key".	Enter the activation key in the correct parameter.
Subfault: 35.2		
Description: Application level too low		
	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	The activated software module requires a higher application level.	Activation key was entered for required application level. You can read the required level from the parameter "Application level – Required level".
Subfault: 35.3		
Description: Technology level too low		
	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	An activated technology function requires a higher technology level.	Enter an activation key for the required technology level. You can find the required level in the parameter 8438.13 "Technology level – Required level".
Subfault: 35.4		
Description: Technology level – invalid activation key		
	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	The activation key was entered incorrectly.	Enter the activation key again.
	The activation key was not created for this device.	Check the activation key.
	When using a double axis, the activation key for the wrong instance was entered in the device.	Enter the activation key for the allocated instance.
	Activation key entered for application level in parameter "Technology level – activation key".	Enter the activation key in the correct parameter.

10.5.31 Fault 42 Lag error

Subfault: 42.1		
Description: Positioning lag error		
	Response: Positioning lag error	
	Cause	Measure
	A lag error occurred during positioning. Incorrect encoder connection.	Check the connection of the encoder.
	Position encoder inverted or not installed correctly at the track.	Check the installation and connection of the position encoder.
	Wiring faulty.	Check the wiring of encoder, motor, and line phases.
	Acceleration ramps too short.	Extend the acceleration ramps.
	P component of the position controller too small.	Set the P component of the position controller to a larger value.
	Speed controller parameters set incorrectly.	Check the controller parameters.
	Value of lag error tolerance too small.	Increase the lag error tolerance.
	Mechanical components cannot move freely or are blocked.	Make sure mechanical parts can move freely, and check whether they are blocked.

Subfault: 42.2		
Description: Jog mode lag error		
	Response: Output stage inhibit	
	Cause	Measure
	A lag error occurred in jog mode (FCB 20). Incorrect encoder connection.	Check the connection of the encoder.
	Position encoder inverted or not installed correctly at the track.	Check the installation and connection of the position encoder.
	Wiring faulty.	Check the wiring of encoder, motor, and line phases.
	Acceleration ramps too short.	Extend the acceleration ramps.
	P component of the position controller too small.	Set the P component of the position controller to a larger value.
	Speed controller parameters set incorrectly.	Check the controller parameters.
	Value of lag error tolerance too small.	Increase the lag error tolerance.
	Mechanical components cannot move freely or are blocked.	Make sure mechanical parts can move freely, and check whether they are blocked.

26860791/EN – 07/2022

Subfault: 42.3**Description: Standard lag error**

Response: Output stage inhibit	
Cause	Measure
A lag error has occurred outside a positioning process. Incorrect encoder connection.	Check the connection of the encoder.
Position encoder inverted or not installed correctly at the track.	Check the installation and connection of the position encoder.
Wiring faulty.	Check the wiring of encoder, motor, and line phases.
Acceleration ramps too short.	Extend the acceleration ramps.
P component of the position controller too small.	Set the P component of the position controller to a larger value.
Speed controller parameters set incorrectly.	Check the controller parameters.
Value of lag error tolerance too small.	Increase the lag error tolerance.

10.5.32 Fault 45 Fieldbus card**Subfault: 45.1****Description: No response from fieldbus interface**

Response: Emergency stop + output stage inhibit		
Cause		Measure
The fieldbus interface does not start properly and is therefore not functional.		– Switch the power off and on again/perform a reset.
		– If the fault occurs repeatedly, replace the fieldbus interface or device and send it together with the fault number to SEW-EURODRIVE. For further support, contact SEW-EURODRIVE Service.

Subfault: 45.2**Description: Fieldbus interface – fault**

Response: Fieldbus – timeout response		
Cause		Measure
Device detected fault on device-internal connection to fieldbus interface.		– Switch the device off and on again.
		– If the fault occurs repeatedly, replace the fieldbus interface or device and send it together with the fault number to SEW-EURODRIVE. For further support, contact SEW-EURODRIVE Service.

Subfault: 45.3**Description: Process output data timeout**

Response: Fieldbus – timeout response		
	Cause	Measure
	Fieldbus interface detected timeout of process output data.	<ul style="list-style-type: none"> – Check the communication connection between the fieldbus master and the fieldbus interface for interruption. – Check the configuration of the fieldbus master. – Adjust the fieldbus timeout monitoring.

Subfault: 45.5**Description: Engineering interface**

Response: Warning		
	Cause	Measure
	Engineering via fieldbus interface no longer works, or only works to a limited extent.	<ul style="list-style-type: none"> – Switch the device off and on again. – If the fault occurs repeatedly, replace the fieldbus interface or device and send it together with the fault number to SEW-EURODRIVE. For further support, contact SEW-EURODRIVE Service.

Subfault: 45.7**Description: Invalid process output data**

Response: Fieldbus – timeout response		
	Cause	Measure
	<ul style="list-style-type: none"> – The fieldbus master sends invalid process output data. – The fieldbus interface has detected an internal fault in the exchange of process data exchange and marks the process output data as invalid. 	<ul style="list-style-type: none"> – Check whether the PLC is in "Stop" state. – Restart the PLC. – Check the configuration of the fieldbus master. – In the event of an error in the internal exchange of process data, switch the device off and then on again.

Subfault: 45.9**Description: Fieldbus interface – warning**

Response: Warning		
	Cause	Measure
	Device detected non-critical fault on device-internal connection to fieldbus interface.	<ul style="list-style-type: none"> – Switch the device off and on again. – If the fault occurs repeatedly, replace the fieldbus interface or device and send it together with the fault number to SEW-EURODRIVE. For further support, contact SEW-EURODRIVE Service.

Subfault: 45.50**Description: Fieldbus card – warning**

	Response: Warning with self-reset	
	Cause	Measure
	Fieldbus interface signals subcomponent fault of the type "warning".	Refer to the subcomponent fault of the fieldbus interface and take the measures required for eliminating the fault.

Subfault: 45.51**Description: Fieldbus card – fault**

	Response: Fieldbus – timeout response	
	Cause	Measure
	Fieldbus interface signals subcomponent fault of the type "standard".	Refer to the subcomponent fault of the fieldbus interface and take the measures required for eliminating the fault.

Subfault: 45.52**Description: Fieldbus card – critical fault**

	Response: Fieldbus – timeout response	
	Cause	Measure
	Fieldbus interface signals subcomponent fault of the type "Critical fault".	Refer to the subcomponent fault of the fieldbus interface and take the measures required for eliminating the fault.

10.5.33 Fault 46 Safety card**Subfault: 46.1****Description: No response**

	Response: Output stage inhibit	
	Cause	Measure
	Failed to synchronize with subcomponent.	<ul style="list-style-type: none"> – Check the device assignment of the basic unit and the option. – Check the card slot and the installation, and correct if necessary. – Restart the device. – Contact SEW-EURODRIVE Service.

Subfault: 46.2

Description: Invalid variant

Response: Output stage inhibit		
	Cause	Measure
	Plugged safety card design does not match inverter type.	<ul style="list-style-type: none"> – Remove the safety card. – Use the correct safety card design.
	For double axes, only designs without encoder interface can be used.	<ul style="list-style-type: none"> – Remove the option. – Use the design without encoder interface.
	For double axes, no encoder option must be plugged in.	Remove the option.

Subfault: 46.3

Description: Internal communication timeout

Response: Output stage inhibit		
	Cause	Measure
	Communication interrupted between inverter and safety card.	Check the card slot and installation of the card, and correct if necessary. Contact SEW-EURODRIVE Service if the error is still present.
	Safety card signals subcomponent fault of the type "warning".	Check the card slot and installation of the card, and correct if necessary. Contact SEW-EURODRIVE Service if the error is still present.

Subfault: 46.50

Description: Warning

Response: Warning with self-reset		
	Cause	Measure
	Safety card signals subcomponent fault of the type "warning".	Observe the subcomponent fault of the safety card and take measures according to the sub-component fault.

Subfault: 46.51

Description: Fault

Response: Emergency stop + output stage inhibit with self-reset		
	Cause	Measure
	Safety card signals subcomponent fault of the type "standard fault".	Observe the subcomponent fault of the safety card and take measures according to the sub-component fault.

Subfault: 46.52**Description: System error**

	Response: Output stage inhibit with self-reset	
	Cause	Measure
	Safety card signals subcomponent fault of the type "system error" or "critical fault".	Observe the subcomponent fault of the safety card and take measures according to the subcomponent fault.

10.5.34 Fault 47 Supply unit**Subfault: 47.1****Description: Supply unit – warning**

	Response: Warning with self-reset	
	Cause	Measure
	The supply unit signals a fault with response type "warning". The fault is only displayed.	For the exact cause of the fault and for information on how to remedy it, refer to the fault signaled by the subcomponent.

Subfault: 47.2**Description: Supply unit – standard fault**

	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	The supply unit signals a fault with response type "standard". The driver implemented on the axis or the module bus slave determines a fault response. The axis or module bus slave performs the fault response.	For the exact cause of the fault and for information on how to remedy it, refer to the fault signaled by the subcomponent.

Subfault: 47.3**Description: Supply unit – critical fault**

	Response: Output stage inhibit	
	Cause	Measure
	The supply unit signals a fault with response type "critical fault". The driver implemented on the axis or the module bus slave determines a fault response. The axis or module bus slave performs the fault response.	For the exact cause of the fault and for information on how to remedy it, refer to the fault signaled by the subcomponent.

10.5.35 Fault 48 Module bus

Subfault: 48.1		
Description: Incompatible		
	Response: Output stage inhibit	
	Cause	Measure
	Module bus slave and module bus master not compatible with each other.	Update the firmware of the module bus at the supply unit or the axis modules to a compatible version.

Subfault: 48.2		
Description: Timeout		
	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	Timeout detected via module bus.	Check the cable connections and voltage supply of the module bus stations.

Subfault: 48.3		
Description: Number of module bus slaves exceeded		
	Response: Output stage inhibit	
	Cause	Measure
	Too many module bus slaves are connected.	Reduce the number of module bus slaves.

Subfault: 48.4		
Description: CRC error		
	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	CRC error during module bus communication.	<ul style="list-style-type: none"> – Restart the device. – Reset the fault. – Contact SEW-EURODRIVE Service if the fault is still present.

10.5.36 Fault 50 I/O card

Subfault: 50.1		
Description: Boot synchronization timeout		
	Response: Output stage inhibit	
	Cause	Measure
	I/O card is plugged in device but cannot be addressed.	<ul style="list-style-type: none"> – Check the device assignment of the basic unit and the option. – Check the card slot and installation of the I/O card, and correct if necessary. – Restart the device.

26860791/EN – 07/2022

Subfault: 50.2**Description: CRC error of FPGA driver**

	Response: Output stage inhibit	
	Cause	Measure
	Communication between FPGA and I/O card does not work, or is interrupted.	<ul style="list-style-type: none"> – Check the card slot and installation of the I/O card, and correct if necessary. – Check for EMC-compliant installation. – Restart the device.

Subfault: 50.3**Description: CRC error of I/O card**

	Response: Output stage inhibit	
	Cause	Measure
	I/O card signals CRC error on SPI bus.	<ul style="list-style-type: none"> – Check the card slot and installation of the I/O card, and correct if necessary. – Check for EMC-compliant installation. – Restart the device.

Subfault: 50.4**Description: Timeout error of I/O card**

	Response: Output stage inhibit	
	Cause	Measure
	I/O card signals timeout error on SPI bus.	<ul style="list-style-type: none"> – Check the card slot and installation of the I/O card, and correct if necessary. – Check for EMC-compliant installation. – Restart the device.

Subfault: 50.5**Description: Watchdog error of I/O card**

	Response: Output stage inhibit	
	Cause	Measure
	Microcontroller of I/O card signals a watchdog error.	<ul style="list-style-type: none"> – Check the card slot and installation of the I/O card, and correct if necessary. – Check for EMC-compliant installation. – Restart the device.

Subfault: 50.6		
Description: Ready signal timeout		
	Response: Output stage inhibit	
	Cause	Measure
	I/O card booted but cyclic communication is not possible.	<ul style="list-style-type: none"> – Check the card slot and installation of the I/O card, and correct if necessary. – Check for EMC-compliant installation. – Restart the device.

Subfault: 50.7		
Description: Frame error of I/O card		
	Response: Output stage inhibit	
	Cause	Measure
	Faulty communication between I/O card and basic unit.	<ul style="list-style-type: none"> – Replace the I/O card. – Replace the basic unit.

10.5.37 Fault 51 Analog processing

Subfault: 51.1		
Description: Analog current input 4 mA limit		
	Response: Warning with self-reset	
	Cause	Measure
	Input current below 4 mA.	Check the input current.

10.5.38 Fault 52 Category 2 explosion protection function

Subfault: 52.1		
Description: Startup error		
	Response: Output stage inhibit	
	Cause	Measure
	No valid startup available.	Perform startup.

Subfault: 52.2		
Description: Impermissible system function		
	Response: Output stage inhibit	
	Cause	Measure
	Impermissible system function activated.	Disable impermissible functions when the Ex protection function is active, such as "Activate standstill current" = "On" in the active control mode.

Subfault: 52.3**Description: Inverter too large**

	Response: Output stage inhibit	
	Cause	Measure
	Ratio of inverter current to nominal motor current too large.	Check the assignment of motor and inverter, and check the dimensioning of the system.

Subfault: 52.4**Description: Parameterization of current limit characteristic**

	Response: Output stage inhibit	
	Cause	Measure
	Error while setting parameters for current limit characteristic.	<ul style="list-style-type: none"> – Parameterize the current limit characteristic. – Perform startup again.

Subfault: 52.5**Description: Time duration exceeded $f < 5$ Hz**

	Response: Emergency stop + output stage inhibit	
	Cause	Measure
	Duration of 60 s for $f < 5$ Hz exceeded.	Check the dimensioning of the system: If speed control = FCB05, increase the speed. If speed = 0, inhibit output stage / with stop FCBs, activate the brake function if a brake is installed.

10.6 Power section fault description

10.6.1 Fault 6 Line fault

Subfault: 6.1		
Description: Line phase failure		
	Response: No response	
	Cause	Measure
	Missing line phase detected.	Check the supply system cable.
	DC link voltage periodically too low.	Check the configuration of the supply system.
	Inadequate line voltage quality.	Check the supply (fuses, contactor).
Subfault: 6.3		
Description: Line overvoltage		
	Response: No response	
	Cause	Measure
	Line voltage exceeds permitted upper threshold value.	Check the nominal line voltage of the project planning.
	Inadequate line voltage quality.	Check the quality of the power system.
Subfault: 6.4		
Description: Line undervoltage		
	Response: No response	
	Cause	Measure
	Line voltage dropped below permitted lower threshold value.	Check the nominal line voltage of the project planning.
	Inadequate line voltage quality.	Check the quality of the power system.
	Supply system cable missing.	Check the wiring.
Subfault: 6.5		
Description: Grid quality		
	Response: No response	
	Cause	Measure
	Insufficient line voltage quality.	Check the quality of the power system.

10.6.2 Fault 7 DC link

Subfault: 7.1**Description: DC link overvoltage**

Response: Remote – critical fault		
Cause		Measure
Maximum permitted DC link voltage limit exceeded and output stage inhibited by hardware.		<ul style="list-style-type: none"> – Extend the deceleration ramps. – Check the supply cable to the braking resistor. – Check the technical data of the braking resistor.

Subfault: 7.11**Description: DC link overvoltage at rectifier**

Response: Remote – critical fault		
Cause		Measure
Maximum permitted limit of DC link voltage of rectifier exceeded or AC component of DC link voltage too high. The emergency shutdown is triggered and the output stage is inhibited.		<ul style="list-style-type: none"> – Remove the ground fault on the motor side, also on adjacent drives. – When operated on an Ethernet network: Remove both the supply ground fault and the ground fault on the motor side, also on adjacent drives. – Check impermissible high line voltage distortion and line voltage.

10.6.3 Fault 11 Temperature monitoring

Subfault: 11.7**Description: Wire break at temperature sensor of heat sink**

Response: Remote – warning with self-reset		
Cause		Measure
Wire break at temperature sensor of heat sink.		Contact SEW-EURODRIVE Service.

Subfault: 11.8**Description: Short circuit at temperature sensor of heat sink**

Response: Remote – warning with self-reset		
Cause		Measure
Short circuit at temperature sensor of heat sink.		Contact SEW-EURODRIVE Service.

10.6.4 Fault 17 Internal processor fault

Subfault: 17.6**Description: Watchdog**

Response: Disable rectifier		
Cause		Measure
CPU watchdog tripped.		Contact SEW-EURODRIVE Service.

Subfault: 17.7		
Description: Exception error		
	Response: Disable rectifier	
	Cause	Measure
	Exception trap in CPU.	Contact SEW-EURODRIVE Service.

10.6.5 Fault 18 Software error

Subfault: 18.7		
Description: Fatal error		
	Response: Disable rectifier	
	Cause	Measure
	Fatal software error.	<ul style="list-style-type: none"> – Switch the device off and on again. – If the fault occurs repeatedly, replace the device and send it together with the fault number to SEW-EURODRIVE. For further support, contact SEW-EURODRIVE Service.

Subfault: 18.8		
Description: Invalid fault code		
	Response: Remote – standard fault	
	Cause	Measure
	Invalid fault code requested.	<ul style="list-style-type: none"> – Switch the device off and on again. – Contact SEW-EURODRIVE Service if the fault persists.

10.6.6 Fault 20 Device monitoring

Subfault: 20.1		
Description: Supply voltage fault		
	Response: Remote – critical fault	
	Cause	Measure
	Internal electronics supply voltage or externally connected DC 24 V standby supply voltage outside permitted voltage range.	<p>Check the voltage level of the external DC 24 V standby supply voltage and check for correct connection. If required, correct.</p> <ul style="list-style-type: none"> – Acknowledge the fault. – If the fault occurs repeatedly, replace the device. For further support, contact SEW-EURODRIVE Service.

Subfault: 20.8**Description: Fan warning**

	Response: Remote – warning with self-reset	
	Cause	Measure
	Fan function impaired.	Check the fan for proper functioning.

Subfault: 20.9**Description: Fan fault**

	Response: Remote – standard fault	
	Cause	Measure
	Fan defective.	Contact SEW-EURODRIVE Service.

10.6.7 Fault 23 Power section**Subfault: 23.5****Description: Invalid process data configuration**

	Response: No response	
	Cause	Measure
	Invalid process data configuration.	Contact SEW-EURODRIVE Service.

Subfault: 23.6**Description: Process data timeout**

	Response: No response	
	Cause	Measure
	Power section communication interface detected process data timeout.	If the fault occurs repeatedly, contact SEW-EURODRIVE Service.

Subfault: 23.7**Description: Parameter communication timeout**

	Response: No response	
	Cause	Measure
	Power section communication interface detected timeout in parameter communication.	If the fault occurs repeatedly, contact SEW-EURODRIVE Service.

Subfault: 23.8**Description: Parameter communication error**

	Response: No response	
	Cause	Measure
	Power section communication interface detected error in parameter communication.	If the fault occurs repeatedly, contact SEW-EURODRIVE Service.

Subfault: 23.9		
Description: Firmware of power section corrupt		
	Response: No response	
	Cause	Measure
	Failed to update firmware on power section.	Update the firmware again.

10.6.8 Fault 25 Parameter memory monitoring

Subfault: 25.1		
Description: Timeout warning		
	Response: Remote – warning with self-reset	
	Cause	Measure
	Access to memory (R/W) takes longer than expected.	The error will be reset automatically after completed memory access.

Subfault: 25.2		
Description: NV memory – runtime error		
	Response: Remote – standard fault	
	Cause	Measure
	Runtime error of non-volatile memory system.	<ul style="list-style-type: none"> – Reset the device. – If this error occurs repeatedly, replace the device. Contact SEW-EURODRIVE Service.

Subfault: 25.3		
Description: NV data import – error		
	Response: Remote – standard fault	
	Cause	Measure
	Error importing non-volatile memory data from non-volatile memory.	<ul style="list-style-type: none"> – Reset the device. – If this error occurs repeatedly, replace the device. Contact SEW-EURODRIVE Service.

Subfault: 25.4		
Description: NV setup – error		
	Response: Remote – standard fault	
	Cause	Measure
	Error while performing delivery state or during basic initialization of the parameters.	<ul style="list-style-type: none"> – Reset the device. – If this error occurs repeatedly, replace the device. Contact SEW-EURODRIVE Service.

Subfault: 25.5**Description: NV data error**

	Response: Remote – standard fault	
	Cause	Measure
	Faulty data detected in non-volatile memory system.	The data on the (mobile) non-volatile memory might have been formatted for another unit. You can rectify the error by reformatting the data (basic initialization).

Subfault: 25.6**Description: Incompatible device configuration**

	Response: Remote – standard fault	
	Cause	Measure
	The data set in the device was copied from another device, which differs from the current device in the device family, power, or voltage.	<ul style="list-style-type: none"> – Check whether the configuration is correct and repeat the startup, if necessary. – Acknowledge the fault by manual reset with parameter set acceptance. Setting under [Diagnostics] > [Status] > [Fault status] parameter "Manual fault reset".
	Replaceable memory module used by another device. Power, device family, or voltage differs from the current device.	<ul style="list-style-type: none"> – Check whether the configuration is correct and repeat the startup, if necessary. – Acknowledge the fault by manual reset with parameter set acceptance. Setting under [Diagnostics] > [Status] > [Fault status] parameter "Manual fault reset".
	The power section was replaced and differs in its power rating or voltage from the original power section.	<ul style="list-style-type: none"> – Check whether the configuration is correct and repeat the startup, if necessary. – Acknowledge the fault by manual reset with parameter set acceptance. Setting under [Diagnostics] > [Status] > [Fault status] parameter "Manual fault reset".

Subfault: 25.7**Description: NV memory initialization – error**

	Response: Remote – standard fault	
	Cause	Measure
	Error initializing non-volatile memory system.	<ul style="list-style-type: none"> – Reset the device. – If this error occurs repeatedly, replace the device. Contact SEW-EURODRIVE Service.

Subfault: 25.9		
Description: NV memory hardware – fault		
	Response: Remote – standard fault	
	Cause	Measure
	Faulty access to non-volatile memory hardware.	<ul style="list-style-type: none"> – Reset the device. – If this occurs repeatedly, replace the device. Contact SEW-EURODRIVE Service.

Subfault: 25.10		
Description: Power section configuration data – version conflict		
	Response: Remote – standard fault	
	Cause	Measure
	Wrong version of configuration data of power section.	Contact SEW-EURODRIVE Service.

Subfault: 25.12		
Description: Power section configuration data – CRC error		
	Response: Remote – standard fault	
	Cause	Measure
	Faulty configuration data of power section.	Contact SEW-EURODRIVE Service.

10.6.9 Fault 32 Communication

Subfault: 32.6		
Description: Copy parameter set		
	Response: Remote – standard fault	
	Cause	Measure
	Error while downloading parameter set to device.	<ul style="list-style-type: none"> – Check the wiring of the system bus and module bus. – Restart download.

Subfault: 32.13		
Description: Process data timeout		
	Response: Remote – warning with self-reset	
	Cause	Measure
	Process data timeout occurred.	<ul style="list-style-type: none"> – Switch the device off and on again. – If the fault occurs repeatedly, replace the safety card and send it together with the fault number to SEW-EURODRIVE. For further support, contact SEW-EURODRIVE Service.

10.6.10 Fault 33 System initialization

Subfault: 33.2**Description: Firmware CRC check**

Response: Disable rectifier		
Cause	Measure	
Error checking firmware.	Contact SEW-EURODRIVE Service.	

Subfault: 33.8**Description: SW function block configuration**

Response: Remote – standard fault		
Cause	Measure	
Error detected while checking configuration of software function block.	Contact SEW-EURODRIVE Service.	

Subfault: 33.9**Description: Power section hardware compatibility fault**

Response: Remote – critical fault		
Cause	Measure	
Firmware does not match hardware of power section.	Contact SEW-EURODRIVE Service.	

10.6.11 Fault 44 Subcomponent power section

Subfault: 44.1**Description: Power section SMPS fault**

Response: Remote – critical fault		
Cause	Measure	
Switched-mode power supply in power section is faulty. Hardware fault.	Contact SEW-EURODRIVE Service.	

Subfault: 44.2**Description: Overcurrent phase U**

Response: Remote – critical fault		
Cause	Measure	
Overcurrent phase U.	<ul style="list-style-type: none"> – Rectify the short circuit. – Connect a smaller motor. – Increase the ramp time. – If the output stage is defective, contact SEW-EURODRIVE Service. 	

Subfault: 44.3

Description: Overcurrent phase V

	Response: Remote – critical fault	
	Cause	Measure
	Overcurrent phase V.	<ul style="list-style-type: none"> – Rectify the short circuit. – Connect a smaller motor. – Increase the ramp time. – If the output stage is defective, contact SEW-EURODRIVE Service.

Subfault: 44.4

Description: Overcurrent phase W

	Response: Remote – critical fault	
	Cause	Measure
	Overcurrent phase W.	<ul style="list-style-type: none"> – Rectify the short circuit. – Connect a smaller motor. – Increase the ramp time. – If the output stage is defective, contact SEW-EURODRIVE Service.

Subfault: 44.5

Description: Faulty supply voltage for gate drivers

	Response: Remote – critical fault	
	Cause	Measure
	Faulty supply voltage for gate drivers for phases U, V, W.	Switch the power off and on again/perform a re-set.
	Phase module not ready for operation.	If the fault is still present, replace the device. Contact SEW-EURODRIVE Service.

Subfault: 44.6

Description: Faulty supply voltage in gate drivers for brake chopper

	Response: Remote – critical fault	
	Cause	Measure
	Faulty supply voltage in gate drivers for brake chopper.	Switch the power off and on again/perform a re-set.
	Brake chopper not ready for operation.	If the fault is still present, replace the device. Contact SEW-EURODRIVE Service.

Subfault: 44.7**Description: Hardware error signal**

	Response: Remote – critical fault	
	Cause	Measure
	Power section hardware signals a fault. It is not possible to pinpoint the fault.	<ul style="list-style-type: none"> – Switch the power off and on again/perform a re-set. – If the fault is still present, replace the device. Contact SEW-EURODRIVE Service.

10.6.12 Fault 84 Rectifier**Subfault: 84.1****Description: Warning**

	Response: No response	
	Cause	Measure
	Rectifiers of type BG7 or higher signals a warning	Contact SEW-EURODRIVE Service

Subfault: 84.2**Description: Fault**

	Response: No response	
	Cause	Measure
	Rectifiers of type BG7 or higher signals a standard fault	Contact SEW-EURODRIVE Service

Subfault: 84.3**Description: Critical fault**

	Response: No response	
	Cause	Measure
	Rectifiers of type BG7 or higher signals a critical fault	Contact SEW-EURODRIVE Service

10.7 Fieldbus interface fault description

10.7.1 Fault 17 Internal processor fault

Subfault: 17.7		
Description: Exception error		
	Response: Remote – warning	
	Cause	Measure
	Exception trap in CPU.	Contact SEW-EURODRIVE Service.

10.7.2 Fault 18 Software error

Subfault: 18.4		
Description: Task system		
	Response: Remote – warning	
	Cause	Measure
	A fault was detected during the processing of the internal task system. This may be a timeout for cyclical tasks, for example.	<ul style="list-style-type: none"> – Switch the device off and on again. – Contact SEW-EURODRIVE Service if the fault persists.

Subfault: 18.7		
Description: Fatal error		
	Response: Remote – critical fault	
	Cause	Measure
	Fatal software error.	<ul style="list-style-type: none"> – Switch the device off and on again. – If the fault occurs repeatedly, replace the device and send it together with the fault number to SEW-EURODRIVE. For further support, contact SEW-EURODRIVE Service.

Subfault: 18.8		
Description: Invalid fault code		
	Response: Remote – critical fault	
	Cause	Measure
	Invalid fault code requested.	<ul style="list-style-type: none"> – Switch the device off and on again. – Contact SEW-EURODRIVE Service if the fault persists.

10.7.3 Fault 25 Parameter memory monitoring

Subfault: 25.9		
Description: NV memory hardware – fault		
	Response: Remote – standard fault	
	Cause	Measure
	Faulty access to non-volatile memory hardware.	<ul style="list-style-type: none"> – Reset the device. – If this occurs repeatedly, replace the device. Contact the SEW-EURODRIVE Service.

10.7.4 Fault 45 Fieldbus card

Subfault: 45.2		
Description: Fieldbus interface – fault		
	Response: Remote – standard fault	
	Cause	Measure
	Device detected fault on device-internal connection to fieldbus interface.	<ul style="list-style-type: none"> – Switch the device off and on again. – If the fault occurs repeatedly, replace the fieldbus interface or device and send it together with the fault number to SEW-EURODRIVE. For further support, contact SEW-EURODRIVE Service.

Subfault: 45.5		
Description: Engineering interface		
	Response: Remote – warning	
	Cause	Measure
	Engineering via fieldbus interface no longer works, or only works to a limited extent.	<ul style="list-style-type: none"> – Switch the device off and on again. – If the fault occurs repeatedly, replace the fieldbus interface or device and send it together with the fault number to SEW-EURODRIVE. For further support, contact SEW-EURODRIVE Service.

Subfault: 45.6		
Description: Process data exchange faulty		
	Response: Remote – standard fault	
	Cause	Measure
	Fieldbus interface detected disrupted process data exchange.	<ul style="list-style-type: none"> – Switch the device off and on again. – If the fault occurs repeatedly, replace the fieldbus interface or device and send it together with the fault number to SEW-EURODRIVE. For further support, contact SEW-EURODRIVE Service.

Subfault: 45.8

Description: Invalid parameters

	Response: Remote – warning	
	Cause	Measure
	Fieldbus interface detected invalid address parameters. The invalid parameters were replaced with standard parameters.	<ul style="list-style-type: none"> – Check the IP address parameters. – Check the MAC address.

Subfault: 45.9

Description: Fieldbus interface – warning

	Response: Remote – warning	
	Cause	Measure
	Device detected non-critical fault on device-internal connection to fieldbus interface.	<ul style="list-style-type: none"> – Switch the device off and on again. – If the fault occurs repeatedly, replace the fieldbus interface or device and send it together with the fault number to SEW-EURODRIVE. For further support, contact SEW-EURODRIVE Service.

Subfault: 45.10

Description: Port statistics – Rx threshold exceeded

	Response: Remote – warning	
	Cause	Measure
	Port statistics check detected that the number of faulty frames exceeded Rx threshold.	Check the network.

Subfault: 45.11

Description: Port statistics – Tx threshold exceeded

	Response: Remote – warning	
	Cause	Measure
	Port statistics check detected that the number of faulty frames exceeded Tx threshold.	Check the network.

Subfault: 45.12

Description: Address conflict

	Response: Remote – standard fault	
	Cause	Measure
	One or several stations connected to the fieldbus have the same address as the device.	For each fieldbus station, set an address that is unique in the system.

10.8 Responses to fault acknowledgement

10.8.1 Fault acknowledgement

During fault acknowledgement, the final fault status determines which reset type will be executed, see following table.

Final fault status	Responses to fault acknowledgement
System blocked	System restart
System waiting	Warm start: Delete fault code
Only display fault	Warm start: Delete fault code

Software reset

Response	Impact
System restart with start of the CPU	Behavior equal to device start
	Reference is lost
	Fieldbus interface is restarted
	EtherCAT®/SBus ^{PLUS} is restarted
	The active "fault message" is reset (digital output = 1, system status = 0).

Software restart

A software restart is **no** real reset of the micro controller.

Response	Effect
Software restart	The firmware will be restarted, without the boot loader becoming active (no display "b0!").
	Reference positions of incremental encoder systems will be lost.
	Any existing fieldbus interfaces are not affected.
	The interface between options and firmware system is initialized again. A new boot synchronization to the fieldbus or control option takes place.
	The active "fault message" is reset (digital output = 1, system status = 0).

The ready signal is set again depending on the system state after the reset by the system state control.

Warm start

A warm start only resets the fault code.

Response	Effect
Warm start	The firmware system is not rebooted.
	All reference positions will be maintained.
	Communication is not interrupted.
	The active "fault message" is reset (digital output = 1, system status = 0).

Fieldbus timeout

After manual reset of a fault, the fault message is deleted. The system changes to the state "Waiting for data".

10.9 Fault responses

10.9.1 Default fault response

Fault response	Description
No response	The inverter ignores the event.
Warning with self-reset	The inverter sends a warning message with self-reset. The fault is automatically reset after the cause of fault is eliminated.
Warning	The inverter issues a warning message.
Application stop (with output stage inhibit)	The inverter stops with the deceleration set for the application limit. Parameter set 1 Index 8375.0-13 Parameter set 2 Index 8375.8-13
Application stop (with output stage inhibit) with self-reset	For n=0: Brake "applied" and output stage "off".
Emergency stop (with output stage inhibit)	The inverter stops with the set emergency stop deceleration. Parameter set 1 Index 8375.0-20 Parameter set 2 Index 8375.8-20
Emergency stop (with output stage inhibit) with self-reset	
Inhibit output stage with self-reset	The output stage is deactivated and the brake is applied.
Inhibit output stage	

Self-reset means: Eliminating the cause of the fault acknowledges the fault. The inverter automatically resumes the operation performed before the fault. The drive restarts automatically.

10.9.2 Parameterizable faults

Parameterizable faults	Description	Index no.	Possible fault response
Manual mode – timeout response	This parameter is used to set the response to a bus timeout during manual mode.	8504.3	<ul style="list-style-type: none"> • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage
Heat sink overtemperature – prewarning	Here, you can set the device response when the prewarning threshold for heat sink utilization is exceeded (index 8336.1).	8622.2	<ul style="list-style-type: none"> • No response • Warning
Positioning lag fault	This parameter is used to set the device response to a lag error (lag error window exceeded, index 8509.4).	8622.3	<ul style="list-style-type: none"> • No response • Warning • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage
Line phase failure	This parameter is used to set the device response to a line phase failure (values below threshold defined by the user, index 8351.5).	8622.4	<ul style="list-style-type: none"> • No response • Warning • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage
External fault	This parameter is used to set the device response to an external fault (e.g. triggered by terminal or control word).	8622.5	<ul style="list-style-type: none"> • No response • Warning • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage

Parameterizable faults	Description	Index no.	Possible fault response
Fieldbus – timeout	This parameter is used to set the device response to an EtherCAT®/SBus ^{PLUS} timeout (timeout time, index 8455.3).	8622.6	<ul style="list-style-type: none"> • Warning • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage • Warning with self reset • Application stop (with output stage inhibit) with self reset • Emergency stop (with output stage inhibit) with self reset • Inhibit output stage with self reset
External synchronization	This parameter is used to set the device response to loss of external synchronization.	8622.7	<ul style="list-style-type: none"> • No response • Warning • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage • Warning with self reset • Application stop (with output stage inhibit) with self reset • Emergency stop (with output stage inhibit) with self reset • Inhibit output stage with self reset
Motor temperature prewarning – current parameter set	Motor temperature active parameter set – prewarning.	8622.8	<ul style="list-style-type: none"> • No response • Warning • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage
Electromechanical utilization – prewarning	This parameter is used to set the device response to an exceeded prewarning threshold for electromechanical utilization (index 8336.2).	8622.10	<ul style="list-style-type: none"> • No response • Warning • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage
HW limit switches – current parameter set		8622.11	<ul style="list-style-type: none"> • No response • Emergency stop (with output stage inhibit) • Emergency stop (with output stage inhibit) with self reset
SW limit switches – current parameter set		8622.12	<ul style="list-style-type: none"> • No response • Emergency stop (with output stage inhibit) • Emergency stop (with output stage inhibit) with self reset
Encoder – warning	This parameter is used to set the device response to an encoder warning.	8622.13	<ul style="list-style-type: none"> • Warning • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage
Encoder – fault	This parameter is used to set the device response to an encoder fault.	8622.14	<ul style="list-style-type: none"> • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage
Additional encoder	This parameter is used to set the device response to a fault of an encoder that is not used for control (speed or positioning control).	8622.15	<ul style="list-style-type: none"> • Warning • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage
Encoder 1 – latest fault		8622.16	<ul style="list-style-type: none"> • No response
Encoder 2 – latest fault		8622.17	<ul style="list-style-type: none"> • No response

Parameterizable faults	Description	Index no.	Possible fault response
Encoder 1 – latest critical fault		8622.18	<ul style="list-style-type: none"> • No response • Inhibit output stage
Encoder 2 – latest critical fault		8622.19	<ul style="list-style-type: none"> • No response • Inhibit output stage
Response to external braking resistor fault	External braking resistor fault	8622.20	<ul style="list-style-type: none"> • No response • Warning • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage
Application heartbeat timeout	This parameter is used to set the device response to a timeout of the application heartbeat.	8622.21	<ul style="list-style-type: none"> • Warning • Application stop (with output stage inhibit) • Emergency stop (with output stage inhibit) • Inhibit output stage

11 Service

11.1 Electronics Service by SEW-EURODRIVE

If you are unable to rectify a fault, contact SEW-EURODRIVE Service. For addresses, refer to www.sew-eurodrive.com.

When contacting SEW-EURODRIVE Service, always specify the following information so that our service personnel can assist you more effectively:

- Information regarding the device type on the nameplate (e.g. type designation, serial number, part number, product key, purchase order number)
- Brief description of the application
- Fault message on the status display
- Nature of the fault
- Accompanying circumstances
- Any unusual events preceding the problem

11.2 Extended storage

The device is maintenance-free.

11.3 Device replacement

Device replacement without error messages is only possible when using an identical replacement device. Deviating device configurations lead to error E25.06 and can be acknowledged with parameter acceptance. The device can then be used without further startup.

If a device needs to be replaced, the following procedures apply.

11.3.1 Exclusive use of the CMM.. memory module

If the inverter is equipped with a CMM.. memory module, the parameter and configuration settings are stored on the memory module. By plugging the memory module into another inverter, this data is available so that the inverter is immediately ready for operation for the specific application.

Instructions on the use of the memory module when exchanging a device

The prerequisite for the error-free exchange of an inverter is that the same options must be installed in the new device as in the original one.

If this is not the case, the error message "25.70 NV memory initialization" is displayed. You can acknowledge the error by opening the "Error reset with parameter acceptance" menu item in the context menu, and you must ensure that the information that was provided via the previous options (e.g. encoder signals via encoder option) reach the application inverter through different means or are deselected.

Alternatively, the device can also be reset to the delivery state. A new startup is then required.

If a memory module is removed during operation, the following error message is displayed: "33.13 System initialization: Memory module removed".

This fault status can be acknowledged with a fault reset.

SEW-EURODRIVE recommends operating the inverter only with an inserted memory module.

11.3.2 Using a CBG.. keypad

When using a keypad, the parameter and configuration settings can be stored on the keypad. By plugging the keypad into another inverter and activating data transmission, data is transferred to the inverter. After the transmission is complete, the inverter is immediately ready for operation for the specific application.

11.4 Shutdown

To shut down the inverter, de-energize the inverter using appropriate measures.



▲ WARNING

Electric shock due to incompletely discharged capacitors.

Severe or fatal injuries.

- Observe a minimum switch-off time of 10 minutes after disconnecting the power supply.

11.5 Waste disposal

Dispose of the product and all parts separately in accordance with their material structure and the national regulations. Put the product through a recycling process or contact a specialist waste disposal company. If possible, divide the product into the following categories:

- Iron, steel or cast iron
- Stainless steel
- Magnets
- Aluminum
- Copper
- Electronic parts
- Plastics

The following materials are hazardous to health and the environment. These materials must be collected and disposed of separately.

- Oil and grease

Collect used oil and grease separately according to type. Ensure that the used oil is not mixed with solvent. Dispose of used oil and grease correctly.

- Screens
- Capacitors



Waste disposal according to WEEE Directive 2012/19/EU

This product and its accessories may fall within the scope of the country-specific application of the WEEE Directive. Dispose of the product and its accessories according to the national regulations of your country.

For further information, contact the responsible SEW-EURODRIVE branch or an authorized partner of SEW-EURODRIVE.

12 Functional safety

12.1 General information

12.1.1 Underlying standards

The safety assessment of the device is based on the following standards and safety classes:

Underlying standards	
Safety class/ underlying standard	<ul style="list-style-type: none"> • Performance Level (PL) in accordance with EN 13849-1 • Safety Integrity Level (SIL) in accordance with EN 61800-5-2 • Safety Integrity Level Claim Limit (SILCL) in accordance with EN 62061

Note the versions of the relevant standards on the declaration of conformity or on the TÜV certificate.

12.2 Integrated safety technology

The described safety technology of the device has been developed and tested in accordance with the following safety requirements:

- SIL 3 in accordance with IEC 61800-5-2, IEC 61508
- PL e in accordance with ISO 13849-1

This was certified by TÜV Rheinland. A copy of the TÜV certificate can be requested from SEW-EURODRIVE.

12.2.1 Safe condition


For safety-related operation of the device, Safe Torque Off is defined as a safe state (see STO safety subfunction). The safety concept is based on this definition.

12.2.2 Safety concept

The device is supposed to be able to perform the safety subfunction "Safe Torque Off" in accordance with IEC 61800-5-2:

- The device is characterized by the optional connection of an external safety controller/safety relay. This external safety controller/safety relay disconnects the safety-related STO input via a 2-pole 24 V switching signal (sourcing/sinking) when a connected command device (e.g. emergency stop button with latching function) is activated. This activates the STO function of the device. As an alternative to an external safety controller/safety relay, the STO function can also be implemented with the optional MOVISAFE® CS..A safety card.
- An internal, dual-channel structure with diagnostics prevents the generation of pulse trains at the power output stage (IGBT).
- Instead of a galvanic isolation of the drive from the supply system by means of contactors or switches, the disconnection of the STO input described here safely prevents the activation of the power semiconductors in the output stage. The rotary-field generation for the respective motor is deactivated even though the line voltage is still present.
- When the STO safety subfunction is activated, the generated PWM signals from the device are interrupted by the STO circuit and are not transmitted to the IGBTs.
- If the internal diagnostics of the STO circuit detects a discrepancy between the two channels, the PWM signals are locked, i.e. STO is activated. This locking requires a reset by switching the DC 24 V supply voltage of the device or the DC 24 V switching signal at the STO inputs F_STO_P1 and F_STO_P2 off and on.

12.2.3 Schematic representation of the safety concept



23543720971

- [1] STO function
- [2] Drive controller
- [3] Internal safety card/safety option (optional)
- [4] Diagnostics and inhibiting unit
- [5] External safety device (optional)
- [6] Motor

12.2.4 Safety subfunctions


The following drive-related safety functions can be used:

- **STO** (Safe Torque Off in accordance with IEC 61800-5-2) by disconnecting the STO input


When the STO function is activated, the frequency inverter does not supply power to the motor for generating torque. This safety subfunction corresponds to a non-controlled stop according to EN 60204-1, stop category 0.

The STO input must be disabled by a suitable external safety controller/safety relay.

The following figure shows the STO function:



2463228171

v	Velocity
t	Time
t ₁	Point of time when STO is triggered
	Disconnection range


- **SS1-t** (Safe stop 1 with time control by means of suitable external control, e.g. safety relay with delayed disconnection).

The following sequence must be observed:

- Decelerate the drive using an appropriate braking ramp specified via the set-point input.
- Disconnect the STO input (= triggering the STO function) after a specified safety-related time delay.

This safety subfunction corresponds to a controlled stop in accordance with EN 60204-1, stop category 1. The SS1-t function corresponds to the former presentation of the SS1(c) function.

The following figure illustrates the SS1-t function:



2463226251

v	Velocity
t	Time
t_1	Point of time at which the braking ramp is initiated
t_2	Point of time when STO is triggered
Δt	Delay time until STO is triggered
	Safe time delay range
	Disconnection range

12.2.5 Restrictions

- Note that if the drive does not have a mechanical brake or if the brake is defective, the drive may coast to a halt (depending on the friction and mass moment of inertia of the system). In the event of regenerative loads or with axes that are loaded with gravitational forces or driven externally, the drive can even accelerate. This must be taken into account in a risk assessment of the system/machine. Additional safety measures might have to be implemented (e.g. safety brake system).

In the case of application-related safety subfunctions that require stopping the hazardous motion safely, an additional safety brake system may be necessary on an application-specific basis.

- When using the SS1-t function as described in chapter "Safety subfunctions", the brake ramp of the drive is not monitored with respect to safety. In the case of an error, the drive might not be decelerated during the delay time, or it might even be accelerated in the worst case. In this case, the STO function is only activated after the set time delay has elapsed, see chapter "Safety subfunctions". The resulting hazard must be taken into account in the risk assessment of the system/machine. Additional safety measures might have to be implemented.
- The STO function cannot prevent a possible jerk or DC braking.



⚠ WARNING

When the STO signal is disconnected, voltage is still present at the DC link of the device.

Severe or fatal injuries.

- Before working on the electric part of the drive system, disconnect it from the supply voltage using an appropriate external disconnecting device and secure it against unintentional reconnection.



⚠ WARNING

Electric shock due to incompletely discharged capacitors.

Severe or fatal injuries.

- Observe a minimum switch-off time of 10 minutes after disconnecting the power supply.



INFORMATION

In the event of a safety-related disconnection of the DC 24 V supply voltage at the STO connection, the brake control is switched off. The brake control in the device is not safety-related.

12.3 Safety conditions

The requirement for safe operation is that the safety subfunctions of the device are properly integrated into an application-specific, higher-level safety function. A system/machine-specific risk assessment must be carried out without fail by the system/machine manufacturer and taken into account for the use of the drive system with the device.

The system/machine manufacturer and the user are responsible for compliance of the system/machine with the applicable safety regulations.

The following requirements are mandatory when installing and operating the device in safety-related applications:

- Use of the approved devices
- Installation requirements
- Requirements for external safety controllers and safety relays
- Startup requirements
- Operational requirements

12.3.1 Approved devices

The following device versions of MOVIDRIVE® technology are permitted for safety-related applications:

Device	Size
MOVIDRIVE® technology	All sizes

12.3.2 Requirements for the installation

- The components must be protected against conductive dirt, e.g. by installing them in a control cabinet with degree of protection IP54 in accordance with IEC 60529.
Assuming that the presence of conductive dirt can be excluded at the installation site, a control cabinet with a correspondingly lower degree of protection is also permitted if in accordance with the applicable standards, e.g. EN 60204-1.
- The wiring technology used must comply with the standard EN 60204-1.
- The STO control cables must be routed according to EMC guidelines and as follows:
 - Within an installation space, single conductors can be routed up to a cable length of 30 m.
 - Outside a closed installation space: Shielded cables must be routed permanently (fixed) and protected against external damage, or equivalent measures must be taken. The maximum cable length of 100 m must not be exceeded.
 - Adhere to the regulations in force for the application.
 - The sinking and sourcing cables from the external safety controller/safety relay to the device must be routed close to one another.
 - The sinking and sourcing cables from the external safety device to the device must have the same cable length. A difference in length $\leq 3\%$ of the two cables is permitted.
 - You must use suitable measures to ensure that STO control cables are routed separately from the power lines of the drive. This does not apply to cables approved by SEW-EURODRIVE specifically for this application case.
- The STO function does not detect short circuits or interference voltage in the supply line, so you must ensure the following:
 - No parasitic voltage is present in the STO control cables
 - The external safety controller can detect a crossfault from an external potential to the STO control cables
- Observe without fail the values specified for safety components when designing the safety circuits.
- The STO signal (F_STO_P1, F_STO_P2, and F_STO_M) must not be used for feedback.
- For safety controller/safety relays, you must only use grounded voltage sources with protective electrical separation (PELV) in accordance with EN 61131-2 and EN 60204-1.
- If several voltage sources are used, each voltage source must be connected to a PE system.
- When planning the installation, observe the technical data of the device.
- The supply voltages 0V24_Out (X6:4) and 24 V_Out (X6:5) of the device may only be used to supply the STO input (X6). The cable length must not exceed 30 m.
This connection variant is not permitted for STO group disconnection.
- For safety-related applications with the device, the jumpers at the STO input X6 must be removed.

12.3.3 Requirements for external safety controllers

A safety relay can be used as an alternative to a safety controller. The following requirements apply accordingly.

- The safety controller and all other safety-related subsystems must be approved for at least the safety class required in the overall system for the respective application-related safety subfunction.

The following table shows an example of the required safety class of the safety controller:

Application	Safety controller requirements
Performance level d in accordance with ISO 13849-1, SIL 2 in accordance with EN 62061	Performance level d in accordance with ISO 13849-1 SIL 2 in accordance with IEC 61508
Performance level e in accordance with ISO 13849-1, SIL 3 in accordance with EN 62061	Performance level e in accordance with ISO 13849-1, SIL 3 in accordance with EN 61508

- The wiring of the safety controller must be suitable for the required safety class (see manufacturer documentation). The STO input of the device can be switched with 2 poles (sourcing or sourcing/sinking) or with 1 pole (sourcing).
- The values specified for the safety controller must be strictly adhered to when designing the circuit.
- No electro-sensitive protective equipment (such as a light grid or scanner) in accordance with EN 61496-1 or emergency stop buttons may be connected directly to the STO input. The connection must be made via a safety controller or a safety relay.
- To ensure protection against an unintended startup in accordance with EN ISO 14118, the safe control system must be designed and connected in such a way that resetting the command device alone does not lead to a restart. This means that a restart may be carried out only after a manual reset of the safety circuit.
- If no fault exclusion is used for the STO wiring in accordance with ISO 13849-2 or IEC 61800-5-2, the external safety device must detect the following faults in the STO wiring within 20 s depending on the connection type:
 - 2-pole sourcing output:
Short circuit of 24 V at F_STO_P1 or F_STO_P2 (Stuck-at 1)
Crossfault between F_STO_P1 and F_STO_P2
 - 2-pole sourcing/sinking:
Short circuit of 24 V at F_STO_P1 (Stuck-at 1)
Short circuit of 0 V at F_STO_M (Stuck-at 0)
 - 1-pole sourcing output:
In the case of a single-pole connection, a fault exclusion is necessary for the wiring between the safety relay and the STO input.

2-pole sourcing output:

- Test pulses can be present when the device is switched on or off:
 - The test pulses on both sourcing channels must be switched with a time delay. However, additional test pulses may occur simultaneously.
 - The test pulses in both sourcing channels must not exceed 1 ms.

- The next test pulse in one sourcing channel must occur only after a 2 ms time period.
- A maximum packet of 3 switch-on test pulses may be generated in sequence at an interval of 2 ms. Wait for at least 500 ms after any packet before you generate another switch-on test pulse or another switch-on test pulse packet.
- The test pulses must be monitored in the safety device. If a fault is detected, the safety device must initiate a suitable fault response.
- The signal levels may have a maximum temporal discrepancy of 130 ms. In case of a larger temporal discrepancy, the device changes to the STO fault state (F20.11).

2-pole sourcing/sinking:

- Test pulses can be present when the device is switched on or off:
 - The test pulses in the sourcing and sinking channel must not exceed 1 ms.
 - The next test pulse in the sourcing or sinking channel must only occur after a 2 ms time period at the earliest.
 - A maximum packet of 3 switch-on test pulses may be generated in sequence at an interval of 2 ms. Wait for at least 500 ms after any packet before you generate another switch-on test pulse or another switch-on test pulse packet.
 - The test pulses must be monitored in the safety device. If a fault is detected, the safety device must initiate a suitable fault response.

1-pole sourcing output:


- In switched-off state, no switch-on test pulses must occur in the sourcing cable.
- In switched-on state:
 - The switch-off test pulse in the sourcing channel must not exceed 1 ms.
 - The next switch-off test pulse may only occur after a time period of 2 ms at the earliest.
 - A maximum packet of 3 switch-on test pulses may be generated in sequence at an interval of 2 ms. Wait for at least 500 ms after any packet before you generate another switch-on test pulse or another switch-on test pulse packet.
 - The test pulses must be monitored in the safety device. If a fault is detected, the safety device must initiate a suitable fault response.

12.3.4 Requirements for startup

- To validate the implemented safety subfunctions, they must be documented and checked after successful startup (functional test).
- Observe the restrictions for safety subfunctions in chapter "Limitations". Non-safety-related parts and components that affect the result of the functional test (e.g. motor brake) must be deactivated, if necessary.
- For use of the device in safety-related applications, it is essential that you perform and document startup checks for the disconnecting device and the correct electrical connection.

12.3.5 Requirements for operation

- Operation is permitted only within the limits specified in the corresponding documentation. This principle applies to the external safety controller as well as to the device and any approved options.
- The built-in diagnostic function is limited in the case of a permanently enabled or permanently disabled STO input. Advanced diagnostic functions are performed only upon a level change of the STO signal. This is why the STO input of the device must be requested with connected line voltage at least once every 12 months for PL d in accordance with ISO 13849-1 and SIL 2 IEC 61800-5-2, and at least once every 3 months for PL e in accordance with ISO 13849-1 and SIL 3 IEC 61800-5-2 to achieve complete test coverage. Adhere to the following test procedure.



- [1] Maximum 12 months for PL d/SIL 2
Maximum 3 months for PL e/SIL 3
- [2] Internal diagnostics
- [3] High: No STO
- [4] Low: STO active

- To achieve complete test coverage after a device reset (e.g. after connecting the line voltage), the state transition (STO active → not active) can be started only > 700 ms later. The device signals "ready for operation" or "STO – Safe Torque Off" if it is not in fault state.
- A detected hardware fault in the internal switch-off channels for STO will lead to a locking fault state in the device. If the fault is reset (e.g. by switching the line voltage on/off or by a low level at the STO input for at least 30 ms), a complete test with internal diagnostics according to the above-mentioned test procedure must be performed. If the fault occurs again, replace the device or contact SEW-EURODRIVE Service.

12.4 Connection designs

12.4.1 General information

Generally, all the connection designs listed in this documentation are permitted for safety-relevant applications, insofar as the safety conditions arising from this documentation are satisfied. This means that you must ensure without fail that the DC 24 V safety inputs are activated by a safety controller or an external safety relay, so that an independent restart is not possible.

All the safety conditions stipulated in the chapters "Integrated safety technology", "Safety conditions", and "Connection variants" must be satisfied on a primary basis for the basic selection, installation, and application of the safety components such as safety relay, emergency stop switch, and the approved connection variants.

The wiring diagrams are block diagrams whose only purpose is to show the safety subfunction(s) with the relevant components. For reasons of clarity, circuit-related measures that usually always have to be implemented are not shown in the diagram. These measures are e.g.:

- Ensuring the availability of touch guards.
- Handling overvoltages and undervoltages.
- Avoiding insulation faults.
- Detecting ground faults or short circuits in externally installed lines.
- Guaranteeing the required interference immunity against electromagnetic interference.

12.4.2 Requirements

Use of safety relays


The requirements of the manufacturers of safety relays (such as protecting the output contacts against welding) or of other safety components must be strictly observed. The basic requirements for cable routing apply as described in this documentation.

For connecting the device to the safety relays, observe the installation requirements in accordance with the chapter "Installation requirements".

All instructions by the manufacturer of the safety relay used in the particular application must be observed.

Use of safety controllers

The switch-off test pulse of the used safe digital outputs (F-DO) must be ≤ 1 ms and another switch-off test pulse must only occur 2 ms later at the earliest.



15214338827

[1] High

[2] Low

INFORMATION



If the safety-related control voltage at X6 is switched off (STO activated), you must observe the chapter "Requirements for the external safety controller" with regard to the test pulses.

INFORMATION



If F_STO_P1, F_STO_P2 are connected to DC 24 V, and F_STO_M is connected to GND, STO is deactivated.

STO signal for group disconnection

For group drives, the STO signal may be provided for several devices by a single safety relay. The following requirements must be met:


- The total cable length is limited to max. 100 m. Any other instructions published by the manufacturer on the use of the safety device (for the respective application) must also be observed.
- The maximum output current and the maximally permitted contact load of the safety device must be observed (see chapter "Technical data" > "Electronic data – Safety subfunctions").
- You must comply with the permitted signal levels at the STO input and all other technical data of the device. The respective routing of the STO control cables and the voltage drop must be considered.
- Other requirements of the safety device manufacturer (such as protecting the output contacts against welding) must be strictly observed. The basic requirements for cable routing also apply.
- A calculation based on the technical data of the device must be performed separately for each case of group drive disconnection.
- A maximum of 20 devices may be used in a group disconnection.

26860791/EN – 07/2022

12.4.3 Wiring diagrams

Delivery state


In the delivery state, the terminals at the port for safe disconnection X6 are jumpered.



27743538443

[1] STO terminal X6

2-pole sourcing




27743543947

[1] External safety device
[2] STO terminal X6

2-pole sourcing/sinking


Example 1



27743625995

[1] External safety device
[2] STO terminal X6

Example 2



34101943179

[1] External safety device
[2] STO terminal X6


26860791/EN – 07/2022

INFORMATION



The supply voltages 0V24_Out (X6:4) and 24V_Out (X6:5) must not be used to supply the external safety device.


1-pole sourcing



27743633163

- [1] External safety device
[2] STO terminal X6


STO group disconnection, 2-pole, sourcing



27739017995

- [1] External safety controller
[2] STO terminal X6


STO group disconnection, 2-pole, sourcing/sinking



27739021579

- [1] External safety controller
[2] STO terminal X6

STO group disconnection, 1-pole, sourcing




- [1] External safety controller
[2] STO terminal X6

Group disconnection via CS..A

The safety card has an internal safe digital output for switching the inverter's internal STO function as well as 3 additional axes of the MOVIDRIVE® modular/system/technology application inverter. No other components may be connected to the inverter's STO terminal X6.

The following conditions apply for shutting down the 3 additional axes:


- The cable length is limited to a maximum of 3 m up to the last axis.
- Cabling is permitted only within a control cabinet.
- The M-terminal of the individual axes must also be connected.
- No CS..A safety card may be installed in the additional axes.
- F-DO_STO's advanced diagnostics is available only for the device's internal STO circuit of the axis with a plugged CS..A safety card.
- For the additional axes, only short circuits of the cabling are detected.
- A connection according to the following figure is permissible.



- [1] STO terminal X6 of a MOVI-C® MOVIDRIVE® with a CS..A safety card
[2] STO terminal X6 of a MOVI-C® MOVIDRIVE® without a CS..A safety card

12.4.4 Port X6 on the device

The following figure shows the X6 port on the top of the device.



17915451659

[1] X6: Connection for Safe Torque Off (STO)

12.5 Safety characteristics

	Characteristic values in accordance with	
	IEC 61800-5-2	ISO 13849-1
Tested safety class/underlying standards	Safety integrity level 3	Performance level e / category 3
Probability of a dangerous failure per hour (PFH value)	2.5×10^{-9} 1/h	
Service life	20 years, after which the component must be replaced with a new one.	
Proof test interval	> 20 years	-
Safe state	Safe Torque Off (STO)	
Safety subfunction	STO, SS1 ¹⁾ in accordance with IEC 61800-5-2	

1) With suitable external control



INFORMATION

In the case of 1-pole wiring, the achievable performance level in accordance with ISO 13849-1 is reduced to PL d, and the achievable Safety Integrity Level in accordance with IEC 61800-5-2 is reduced to SIL 2. A fault exclusion is necessary for the wiring between the safety relay and the STO input.

13 Appendix

13.1 Abbreviation key

The following table lists the abbreviations that are used in this documentation together with their unit and meaning:

Abbreviation	Information on the nameplate	Unit	Meaning
ASM			Asynchronous motor
BG..			Inverter size
C	C	μF	Capacitance
f_{max}	f	Hz	Maximum output frequency
f_{line}	f	Hz	Line frequency
f_{PWM}		kHz	Frequency of the pulse width modulation
h		m	Installation altitude
HF			High frequency
I_{trip}		A	Tripping current (braking resistor)
I_{max}	I _{max}	A	Max. DC link current (specification on the nameplate)
I_{max}		A	Maximum output current (encoder cards)
I_{peak}		A	Output peak current (encoder cards)
$I_{\text{A max}}$		A	Max. output current
I_{Appl}		A	Total current of the application
I_{N}		A	Nominal output current/nominal current (filter, choke)
I_{line}	I	A	Nominal line current
I_{NDCL}	I	A	Nominal DC link current
L_{N}		mH	Inductance
LSPM			Line Start Permanent Magnet
asl		m	Above sea level, reference for altitudes above sea level
P_{eff}		kW	Effective power (braking resistor)
P_{max}		kW	Maximum power (braking resistor)
P_{Mot}	P(ASM)	kW	Motor power of the asynchronous motor
P_{N}		kW	Nominal motor power (rated power)
P_{V}		W	Power loss
PWM			Pulse width modulation
R_{BW}		Ω	Value of the braking resistance
R_{BWmin}		Ω	Minimum value of the braking resistance
S_{N}	S	kVA	Apparent output power
SM			Synchronous motor
V_{out}	U	V	Motor output voltage
V_{BR}		V	Brake supply voltage

Abbreviation	Information on the nameplate	Unit	Meaning
V_N		V	Nominal line voltage (filter, choke)
V_{line}	U	V	Connection voltage
V_{NDCL}	U	V	Nominal DC link voltage
V_{DCL}		V	DC link voltage
V_{out}		V	DC 24 V to supply STO_P1 and STO_P2
V_S		V	Supply voltage of encoders
V_{S12VG}		V	DC 12 V supply voltage of encoders
V_{S24VG}		V	DC 24 V supply voltage of encoders
V_{I24}		V	Voltage supply for electronics and brake
ϑ_U	T	°C	Ambient temperature
(+ES)			... with output stage inhibit

Index

Numerical

24 V supply voltage 255

A

Abbreviation key 455

Ambient conditions 47

Ambient temperature 47

 MOVIDRIVE® technology 75

 Safety card 75

Approved devices 444

Assembly

 Safety notes 219

B

Brake control 299

Brake output 257

Braking resistor selection 129

Braking resistors 273

 External bimetallic relay 279

 Internal temperature switch 277

 Parallel connection of braking resistors 276

 Permitted installation 273

 Protection against thermal overload 276

BS.. touch guard 92, 150

BW../BW...-T braking resistors

 Assignment to an inverter 79, 139

 Description 78, 138

 Technical data 79, 139

C

Cables

 Encoder cables with connection cover and D-sub 190

Card installation 263

Card slots 232

CES11A multi-encoder card 269

 Encoder connection/cable lengths 258, 269

 Supported encoder types 269

 Terminal assignment EnDat encoder 271

 Terminal assignment of CANopen encoders 272

 Terminal assignment of HIPERFACE® and SEW encoders (RS485) 270

 Terminal assignment of TTL, HTL, sin/cos encoder 270

 Terminal assignment SSI + sin/cos combination encoders 272

 Terminal assignment SSI encoder 271

CFC control mode 35

Checking the disconnection device 447

CIO21A and CID21A input/output card

 Cable lengths and shielding 266

CIP Safety™ 215

CIP™ 215

Connecting braking resistors in parallel 276

Connecting power 315

Connection diagram of digital inputs and outputs 307

Connection to Service interface 319

Connection variants 449

Connections 71

Control cabinet installation 244

Control mode

 CFC 35

 ELSM® 35

 Properties 107

 V/f 33

 VFCPLUS 33

Control modes 33

Cooling

 Derating 219

 Installation altitude 219

Copyright notice 215

Covers

 Safety covers 241

 Touch guards 242

D

DC link choke ZD..

 Dimension drawings 102

DC link choke ZD..

 Technical data 101

Decimal separator 214

Degree of protection 47

Derating 219

Description of the FCBs 27

Designated use 218

Device

 Structure 222

Device replacement 435

Device structure		Limit value classes C1 and C2	283
Card slots	232	Encoder	
Connection variants	222	Electronic nameplate	116
Type code	224	Encoder connection	
Digital inputs/outputs	257	Installation notes	258
Dimension drawings		Prefabricated cables	258
Braking resistors BW	88, 148	Encoder interfaces	77
DC link choke ZD	102, 103	Energy-saving functions	37
HD.. output choke	100	Partial magnetization	37
HF.. output filter	98	Standby operation	37
Line choke ND	96	Engineering accesses of the inverter	329
Line filter NF	94	Error display of the 7-segment display	332
Disconnection of a single device		EtherCAT®	
Requirements	449	Beckhoff trademark	214
Drilling patterns	239	EtherNet/IP™	215
Drive selection	107	EU Ecodesign Regulation	214
E		Explosion-protected AC motors	115
Electrical installation	220, 249	Extended storage	435
24 V supply voltage	255	External bimetallic relay	279
Brake chopper output	256	External safety controller	446
Brake output	257	F	
Covers	241	Fault description	345
Digital inputs and outputs	307	Fault responses	432
Digital inputs/outputs	257	Default fault response	432
Encoder	258	Parameterizable faults	432
Encoder connection	258	FCB concept	26
Fuse types, line fuses	252	Description of the FCBs	27
General information	250	FCB description	27
Installation notes encoder connection	258	Fieldbus interface	
Line connection	253	Connections	71
Line contactor	254	LEDs	71
Line fuses, fuse types	252	Flux optimization	37
Motor connection	253	FS standards	438
Motor output – permitted connection	255	FS validity	438
Permitted voltage supply systems	250	Function control block	26
Safety notes	220	Functional safety technology	
Temperature evaluation of the motor	256	Safety note	218
Terminal assignment	289	Fuse types, line fuses	252
Use in IT systems	250	G	
Electronics connection	305	Group drive and multi-motor drive	113
Electronics Service	435	H	
ELSM® control mode	35	Hazard symbols	
Embedded safety notes	213	Meaning	213
EMC-compliant installation			
Installation example	284		

HD.. output choke	
Assignment to an inverter.....	99
Dimension sheets.....	100
Dimensions.....	100
Part number.....	99
Technical data	99
HD.. output chokes	
Description	99
HF.. output filter	
Assignment to inverter.....	97
Dimension sheets.....	98
Dimensions.....	98
Part number.....	97
Technical data	97
HF.. output filters	
Description	97
I	
Installation	233
Electrical installation.....	249
EMC-compliant installation.....	283
Line filter.....	283
Permitted installation of braking resistors.....	273
Permitted tightening torques	233
Requirements	445
Installation accessories	54
Installation altitude.....	47
Installation notes	
Derating.....	219
Installation altitude > 1000 m	219
Installation options and accessories	
CID21A terminal assignment.....	268
CIO21A terminal assignment	267
CIO21A, CID21A input/output card	266
Installing a card	263
Installing options and accessories	
CES11A multi-encoder card.....	269
Interference immunity, interference emission.....	47
Internal temperature switch	277
Inverter	
Engineering accesses	329
IT systems	250

L

LED displays	
"BE" LED	342

"BF" LED	338
"BS" LED	342
"LNK/ACT" LED.....	339, 341, 343
"MS" LED	340
"NS" LED	340
"RUN" LED	344
"US1" LED	338
LED indicators	
"BF" LED	344
LEDs.....	71
Lifting applications.....	218, 315
Line choke ND..	
Assignment to inverter.....	95
Dimension sheets.....	96
Dimensions.....	96
Line connection	253
Line contactor.....	254
Line filter NF..	
Assignment to an inverter.....	93
Description	93
Dimension sheets.....	94
Dimensions.....	94
Technical data	93
Line fuses, fuse types.....	252

M

Marks.....	42
Memory module.....	22, 331
Minimum clearance and mounting position	240
Module bus and system bus cables	209
Motor connection	253
Motor output – permitted connection	255
Motor protection without temperature sensor	112
Motors that can be connected	110
MOVIDRIVE® technology	
Engineering accesses	329
MOVILINK® DDI.....	295
Installation notes	259
Removing connector	259
MOVISUITE®	37
MOVISUITE® engineering software.....	37
Multi-motor drive and group drive.....	113

N

Nameplates	
Performance data nameplate	223

System nameplate.....	223	Product description	
ND.. line choke		Control modes	33
Technical data	95	Energy-saving functions	37
ND.. line chokes		FCB concept.....	26
Description	95	MOVISUITE®	37
Notes		Product overview of accessories.....	19
Designation in the documentation	212	Product names	214
Meaning of the hazard symbols	213	Product overview accessories	
O		CES11A multi-encoder card	23
ODVA CONFORMANT®	215	CID21A input/output card	23
ODVA®	215	CIO21A input/output card	23
Operating displays and faults		Product overview of accessories	19
Table of displays	333	Project planning.....	105
Operating states of the 7-segment display	332	Braking resistor selection	129
Operation.....	330	Drive selection.....	107
Error display of the 7-segment display	332	Encoder cables.....	154
Fault description	345	Explosion-protected AC motors.....	115
Fault responses.....	432	Group drive and multi-motor drive.....	113
Fieldbus timeout.....	431	Motors that can be connected	110
Memory module.....	22, 331	Requirements for brake control	117
Operating states of the 7-segment display ...	332	SEW-Workbench.....	105
Responses to fault reset.....	430	Signal cables	154
Safety notes	221	Project planning example	162
Software reset	430	Protective separation.....	220
Software restart.....	430	R	
Table of displays	333	Repair	435
Warm start.....	431	Requirements	
Operation, requirements.....	448	External safety controller	446
P		Installation	445
Part number		Operation.....	448
Carrying aid	54	Startup.....	447
Plastic cover	54	Requirements for brake control	117
Safety cards	75	Requirements for startup	317
Shielding.....	54	Responses to fault acknowledgement	
Partial magnetization	37	Software restart	430
Permitted tightening torques	233	Warm start.....	431
Permitted voltage supply systems.....	250	Responses to fault acknowledgment	
Power cable		Fieldbus timeout	431
Overview	164	Software reset	430
Prefabricated cables		Responses to fault reset.....	430
Power cables, fixed installation	165	Restrictions to application	219
Power cables, suitable for cable carrier installation.....	166	Rights to claim under limited warranty	214
System bus and module bus cables.....	209	Rotor adjustment	35
		Rotor position measurement	35

S

Safe digital inputs	75
Safe digital outputs	76
Safe state	438
Safe Torque Off (STO)	441
Safety concept	439
Limitations	443
Safety conditions	444
Safety controller, external	446
Requirements	446
Safety controllers, requirements	450
Safety functions	218
Safety functions - electronics data	57
Safety notes	
Assembly	219
Designation in the documentation	212
Installation	219
Installation altitude > 1000 m	219
Meaning of the hazard symbols	213
Preliminary information	216
Regenerative operation	220
Structure of embedded	213
Structure of section-related	212
Safety over EtherCAT®	
Beckhoff trademark	215
Safety relays, requirements	449
Safety subfunctions verification	447
Safety technology	
Safe state	438
Section-related safety notes	212
Sensor supply	76
Separation, protective	220
Service	435
Extended storage	435
Shutdown	437
Service interface	319
Setting the EtherCAT® ID	316
SEWorkbench	105
SEW-Workbench	105
Short designation in the document	215
Shutdown	437
Signal cable	
Cable carrier installation	168
Fixed installation	168
Signal terminals	56

Signal words in safety notes	212
Standby mode	37
Startup	315
Connecting power	315
Connecting the cables	315
Lifting applications	315
Operating switches	315
Safety notes	221
Setting the EtherCAT® ID	316
Startup requirements	317
Startup with the CBG11A keypad	322
Startup with the CBG21A keypad	324
Startup with the CBG22A keypad	326
Startup, requirements	447
Status LEDs	71
STO (Safe Torque Off)	441
System bus and module bus cables	209

T

Target group	217
Technical data	42
Cards	66
CES11A multi-encoder card	68
CIO21A and CID21A input/output cards	66
DC link choke ZD..	101
Encoder interfaces	77
General technical data	75
HD.. output choke	99
HF.. output filter	97
Line filter NF..	93
ND.. line choke	95
ND.. line chokes	95
Safe digital inputs	75
Safe digital outputs	76
Sensor supply	76
Temperature evaluation of the motor	256
Terminal assignment	
Basic unit	289
CID21A	268
CIO21A	267
HIPERFACE® motor encoder	294
Motor encoder – resolver	293
Motor encoder – sin/cos encoder	293
Motor encoder – TTL encoder	294
MOVILINK® DDI interface	295
SEW-EURODRIVE encoder	294

SEW-EURODRIVE encoder with RS485 inter- face.....	295
Thermal overload	276
Tightening torques.....	233
Topology	
MOVI-C® single-axis automation	8
POWERLINK.....	9
Trademarks	214
Transporting the inverter	236
Type code.....	224

U

Use in IT systems	250
-------------------------	-----

V

V/f control mode	33
------------------------	----

Validation.....	447
VFCPLUS control mode	33

W

Waste disposal	437
----------------------	-----

Wiring diagrams

Brake control	299
Connection diagram of digital inputs	307
General information.....	296
Power connection.....	296

Wiring the control electronics

Bottom	306
Front	305
Top	306

14 Address list

Argentina

Assembly Sales	Buenos Aires	SEW EURODRIVE ARGENTINA S.A. Ruta Panamericana Km 37.5, Lote 35 (B1619IEA) Centro Industrial Garín Prov. de Buenos Aires	Tel. +54 3327 4572-84 Fax +54 3327 4572-21 http://www.sew-eurodrive.com.ar sewar@sew-eurodrive.com.ar
-------------------	--------------	---	--

Australia

Assembly Sales Service	Melbourne	SEW-EURODRIVE PTY. LTD. 27 Beverage Drive Tullamarine, Victoria 3043	Tel. +61 3 9933-1000 Fax +61 3 9933-1003 http://www.sew-eurodrive.com.au enquires@sew-eurodrive.com.au
	Sydney	SEW-EURODRIVE PTY. LTD. 9, Sleigh Place, Wetherill Park New South Wales, 2164	Tel. +61 2 9725-9900 Fax +61 2 9725-9905 enquires@sew-eurodrive.com.au

Austria

Assembly Sales Service	Vienna	SEW-EURODRIVE Ges.m.b.H. Richard-Strauss-Straße 24 1230 Wien	Tel. +43 1 617 55 00-0 Fax +43 1 617 55 00-30 http://www.sew-eurodrive.at sew@sew-eurodrive.at
------------------------------	--------	--	---

Bangladesh

Sales	Bangladesh	SEW-EURODRIVE INDIA PRIVATE LIMITED 345 DIT Road East Rampura Dhaka-1219, Bangladesh	Tel. +88 01729 097309 salesdhaka@seweurodrivebangladesh.com
-------	------------	---	---

Belarus

Sales	Minsk	Foreign unitary production enterprise SEW- EURODRIVE Novodvorskiy village council 145 223016, Minsk region	Tel. +375 17 319 47 56 / +375 17 378 47 58 Fax +375 17 378 47 54 http://www.sew-eurodrive.by sew@sew-eurodrive.by
-------	-------	---	--

Belgium

Assembly Sales Service	Brussels	SEW-EURODRIVE n.v./s.a. Researchpark Haasrode 1060 Evenementenlaan 7 3001 Leuven	Tel. +32 16 386-311 Fax +32 16 386-336 http://www.sew-eurodrive.be info@sew-eurodrive.be
Service Competence Center	Industrial Gears	SEW-EURODRIVE n.v./s.a. Rue du Parc Industriel, 31 6900 Marche-en-Famenne	Tel. +32 84 219-878 Fax +32 84 219-879 http://www.sew-eurodrive.be info@sew.be

Brazil

Production Sales Service	São Paulo	SEW-EURODRIVE Brasil Ltda. Estrada Municipal José Rubim, 205 – Rodovia Santos Dumont Km 49 Indaiatuba – 13347-510 – SP	Tel. +55 19 3835-8000 sew@sew.com.br
Assembly Sales Service	Rio Claro	SEW-EURODRIVE Brasil Ltda. Rodovia Washington Luiz, Km 172 Condomínio Industrial Conpark Caixa Postal: 327 13501-600 – Rio Claro / SP	Tel. +55 19 3522-3100 Fax +55 19 3524-6653 montadora.rc@sew.com.br
	Joinville	SEW-EURODRIVE Brasil Ltda. Jvl / Ind Rua Dona Francisca, 12.346 – Pirabeiraba 89239-270 – Joinville / SC	Tel. +55 47 3027-6886 Fax +55 47 3027-6888 filial.sc@sew.com.br

Bulgaria

Sales	Sofia	BEVER-DRIVE GmbH Bogdanovetz Str.1 1606 Sofia	Tel. +359 2 9151160 Fax +359 2 9151166 bever@bever.bg
-------	-------	---	---

Cameroon			
Sales	Douala	SEW-EURODRIVE SARLU Ancienne Route Bonabéri P.O. Box B.P 8674 Douala-Cameroun	Tel. +237 233 39 12 35 Fax +237 233 39 02 10 www.sew-eurodrive.ci/ info@sew-eurodrive.cm
Canada			
Assembly Sales Service	Toronto	SEW-EURODRIVE CO. OF CANADA LTD. 210 Walker Drive Bramalea, ON L6T 3W1	Tel. +1 905 791-1553 Fax +1 905 791-2999 http://www.sew-eurodrive.ca l.watson@sew-eurodrive.ca
	Vancouver	SEW-EURODRIVE CO. OF CANADA LTD. Tilbury Industrial Park 7188 Honeyman Street Delta, BC V4G 1G1	Tel. +1 604 946-5535 Fax +1 604 946-2513 b.wake@sew-eurodrive.ca
	Montreal	SEW-EURODRIVE CO. OF CANADA LTD. 2001 Ch. de l'Aviation Dorval Quebec H9P 2X6	Tel. +1 514 367-1124 Fax +1 514 367-3677 n.paradis@sew-eurodrive.ca
Chile			
Assembly Sales Service	Santiago de Chile	SEW-EURODRIVE CHILE LTDA Las Encinas 1295 Parque Industrial Valle Grande LAMP Santiago de Chile P.O. Box Casilla 23 Correo Quilicura - Santiago - Chile	Tel. +56 2 2757 7000 Fax +56 2 2757 7001 http://www.sew-eurodrive.cl ventas@sew-eurodrive.cl
China			
Production Assembly Sales Service	Tianjin	SEW-EURODRIVE (Tianjin) Co., Ltd. No. 78, 13th Avenue, TEDA Tianjin 300457	Tel. +86 22 25322612 Fax +86 22 25323273 http://www.sew-eurodrive.cn info@sew-eurodrive.cn
Assembly Sales Service	Suzhou	SEW-EURODRIVE (Suzhou) Co., Ltd. 333, Suhong Middle Road Suzhou Industrial Park Jiangsu Province, 215021	Tel. +86 512 62581781 Fax +86 512 62581783 suzhou@sew-eurodrive.cn
	Guangzhou	SEW-EURODRIVE (Guangzhou) Co., Ltd. No. 9, JunDa Road East Section of GETDD Guangzhou 510530	Tel. +86 20 82267890 Fax +86 20 82267922 guangzhou@sew-eurodrive.cn
	Shenyang	SEW-EURODRIVE (Shenyang) Co., Ltd. 10A-2, 6th Road Shenyang Economic Technological Development Area Shenyang, 110141	Tel. +86 24 25382538 Fax +86 24 25382580 shenyang@sew-eurodrive.cn
	Taiyuan	SEW-EURODRIVE (Taiyuan) Co., Ltd. No.3, HuaZhang Street, TaiYuan Economic & Technical Development Zone ShanXi, 030032	Tel. +86-351-7117520 Fax +86-351-7117522 taiyuan@sew-eurodrive.cn
	Wuhan	SEW-EURODRIVE (Wuhan) Co., Ltd. 10A-2, 6th Road No. 59, the 4th Quanli Road, WEDA 430056 Wuhan	Tel. +86 27 84478388 Fax +86 27 84478389 wuhan@sew-eurodrive.cn
	Xi'An	SEW-EURODRIVE (Xi'An) Co., Ltd. No. 12 Jinye 2nd Road Xi'An High-Technology Industrial Development Zone Xi'An 710065	Tel. +86 29 68686262 Fax +86 29 68686311 xian@sew-eurodrive.cn
	Hong Kong	SEW-EURODRIVE LTD. Unit No. 801-806, 8th Floor Hong Leong Industrial Complex No. 4, Wang Kwong Road Kowloon, Hong Kong	Tel. +852 36902200 Fax +852 36902211 contact@sew-eurodrive.hk

Colombia			
Assembly Sales Service	Bogota	SEW-EURODRIVE COLOMBIA LTDA. Calle 17 No. 132-18 Interior 2 Bodega 6, Manzana B Santafé de Bogotá	Tel. +57 1 54750-50 Fax +57 1 54750-44 http://www.sew-eurodrive.com.co sew@sew-eurodrive.com.co
Croatia			
Sales Service	Zagreb	KOMPEKS d. o. o. Zeleni dol 10 10 000 Zagreb	Tel. +385 1 4613-158 Fax +385 1 4613-158 kompeks@inet.hr
Czech Republic			
Assembly Sales Service	Hostivice	SEW-EURODRIVE CZ s.r.o. Floriánova 2459 253 01 Hostivice	Tel. +420 255 709 601 Fax +420 235 350 613 http://www.sew-eurodrive.cz sew@sew-eurodrive.cz
Denmark			
Assembly Sales Service	Copenhagen	SEW-EURODRIVE A/S Geminivej 28-30 2670 Greve	Tel. +45 43 95 8500 Fax +45 43 9585-09 http://www.sew-eurodrive.dk sew@sew-eurodrive.dk
Service	Vejle	SEW-EURODRIVE A/S Bødkervej 2 7100 Vejle	Tel. +45 43 9585 00 http://www.sew-eurodrive.dk sew@sew-eurodrive.dk
Egypt			
Representation: United Arab Emirates			
Estonia			
Sales	Tallin	ALAS-KUUL AS Loomäe tee 1, Lehmja küla 75306 Rae vald Harjumaa	Tel. +372 6593230 Fax +372 6593231 http://www.alas-kuul.ee info@alas-kuul.ee
Finland			
Assembly Sales Service	Hollola	SEW-EURODRIVE OY Vesimäentie 4 15860 Hollola	Tel. +358 201 589-300 Fax +358 3 780-6211 http://www.sew-eurodrive.fi sew@sew.fi
Service	Hollola	SEW-EURODRIVE OY Keskikankaantie 21 15860 Hollola	Tel. +358 201 589-300 Fax +358 3 780-6211 http://www.sew-eurodrive.fi sew@sew.fi
	Tornio	SEW-EURODRIVE Oy Lossirannankatu 5 95420 Tornio	Tel. +358 201 589 300 Fax +358 3 780 6211 http://www.sew-eurodrive.fi sew@sew.fi
Production Assembly	Karkkila	SEW Industrial Gears Oy Santasalonkatu 6, PL 8 03620 Karkkila, 03601 Karkkila	Tel. +358 201 589-300 Fax +358 201 589-310 http://www.sew-eurodrive.fi sew@sew.fi
France			
Production Sales	Haguenau	SEW USOCOME 48-54 route de Soufflenheim B. P. 20185 67506 Haguenau Cedex	Tel. +33 3 88 73 67 00 http://www.usocom.com sew@usocom.com
Production	Forbach	SEW USOCOME Zone industrielle Technopôle Forbach Sud B. P. 30269 57604 Forbach Cedex	Tel. +33 3 87 29 38 00
	Brumath	SEW USOCOME 1 Rue de Bruxelles 67670 Mommenheim Cedex	Tel. +33 3 88 37 48 00

France			
Assembly Sales Service	Bordeaux	SEW USOCOME Parc d'activités de Magellan 62 avenue de Magellan – B. P. 182 33607 Pessac Cedex	Tel. +33 5 57 26 39 00 dtcbordeaux@usocom.com
	Haguenau	SEW USOCOME 48-54 route de Soufflenheim B. P. 20185 67506 Haguenau Cedex	Tel. +33 3 88 73 67 00 dtchaguenau@usocom.com
	Lyon	SEW USOCOME 75 rue Antoine Condorcet 38090 Vaulx-Milieu	Tel. +33 4 74 99 60 00 dtclyon@usocom.com
	Nantes	SEW USOCOME Parc d'activités de la forêt 4 rue des Fontenelles 44140 Le Bignon	Tel. +33 2 40 78 42 00 dtcnantes@usocom.com
	Paris	SEW USOCOME Zone industrielle 2 rue Denis Papin 77390 Verneuil l'Étang	Tel. +33 1 64 42 40 80 dtcparis@usocom.com
Gabon			
Representation: Cameroon			
Germany			
Headquarters Production Sales	Bruchsal	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 76646 Bruchsal	Tel. +49 7251 75-0 Fax +49 7251 75-1970 http://www.sew-eurodrive.de sew@sew-eurodrive.de
	Bruchsal	SEW-EURODRIVE GmbH & Co KG Christian-Pähr-Str. 10 76646 Bruchsal	Tel. +49 7251 75-0 Fax +49 7251 75-2970
	Bruchsal	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 76646 Bruchsal	Tel. +49 7251 75-0 Fax +49 7251 75-1970 sew@sew-eurodrive.de
	Graben	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 1 76676 Graben-Neudorf	Tel. +49 7251 75-0 Fax +49 7251-2970
Service Competence Center	Mechanics / Mechatronics	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 1 76676 Graben-Neudorf	Tel. +49 7251 75-1710 Fax +49 7251 75-1711 scc-mechanik@sew-eurodrive.de
	Electronics	SEW-EURODRIVE GmbH & Co KG Christian-Pähr-Straße 12 76646 Bruchsal	Tel. +49 7251 75-1780 Fax +49 7251 75-1769 scc-elektronik@sew-eurodrive.de
	MAXOLU- TION® Factory Automation	SEW-EURODRIVE GmbH & Co KG Eisenbahnstraße 11 76646 Bruchsal	Tel. +49 7251 75-0 Fax +49 7251 75-1970 sew@sew-eurodrive.de
	North	SEW-EURODRIVE GmbH & Co KG Alte Ricklinger Straße 43 30823 Garbsen (Hannover)	Tel. +49 5137 8798-30 Fax +49 5137 8798-55 dtc-nord@sew-eurodrive.de
Drive Technology Center	East	SEW-EURODRIVE GmbH & Co KG Dänkritzter Weg 1 08393 Meerane (Zwickau)	Tel. +49 3764 7606-0 Fax +49 3764 7606-20 dtc-ost@sew-eurodrive.de
	South	SEW-EURODRIVE GmbH & Co KG Domagkstraße 5 85551 Kirchheim (München)	Tel. +49 89 909551-21 Fax +49 89 909551-50 dtc-sued@sew-eurodrive.de
	West	SEW-EURODRIVE GmbH & Co KG Siemensstraße 1 40764 Langenfeld (Düsseldorf)	Tel. +49 2173 8507-10 Fax +49 2173 8507-50 dtc-west@sew-eurodrive.de
	Berlin	SEW-EURODRIVE GmbH & Co KG Alexander-Meißner-Straße 44 12526 Berlin	Tel. +49 306331131-30 Fax +49 306331131-36 dc-berlin@sew-eurodrive.de
Drive Center	Bremen	SEW-EURODRIVE GmbH & Co KG Allerkai 4 28309 Bremen	Tel. +49 421 33918-10 Fax +49 421 33918-22 tb-bremen@sew-eurodrive.de

Germany

Hamburg	SEW-EURODRIVE GmbH & Co KG Hasselbinnen 11 22869 Schenefeld	Tel. +49 40298109-60 Fax +49 40298109-70 dc-hamburg@sew-eurodrive.de
Saarland	SEW-EURODRIVE GmbH & Co KG Gottlieb-Daimler-Straße 4 66773 Schwalbach Saar – Hülzweiler	Tel. +49 6831 48946 10 Fax +49 6831 48946 13 dc-saarland@sew-eurodrive.de
Ulm	SEW-EURODRIVE GmbH & Co KG Dieselstraße 18 89160 Dornstadt	Tel. +49 7348 9885-0 Fax +49 7348 9885-90 dc-ulm@sew-eurodrive.de
Würzburg	SEW-EURODRIVE GmbH & Co KG Nürnbergerstraße 118 97076 Würzburg-Lengfeld	Tel. +49 931 27886-60 Fax +49 931 27886-66 dc-wuerzburg@sew-eurodrive.de

Drive Service Hotline / 24 Hour Service

0 800 SEWHELP
0 800 7394357**Great Britain**

Assembly Sales Service	Normanton	SEW-EURODRIVE Ltd. DeVilliers Way Trident Park Normanton West Yorkshire WF6 1GX	Tel. +44 1924 893-855 Fax +44 1924 893-702 http://www.sew-eurodrive.co.uk info@sew-eurodrive.co.uk
------------------------------	-----------	--	--

Greece

Sales	Athens	Christ. Boznos & Son S.A. 12, K. Mavromichali Street P.O. Box 80136 18545 Piraeus	Tel. +30 2 1042 251-34 Fax +30 2 1042 251-59 http://www.boznos.gr info@boznos.gr
-------	--------	--	--

Hungary

Sales Service	Budapest	SEW-EURODRIVE Kft. Csillaghegyi út 13. 1037 Budapest	Tel. +36 1 437 06-58 Fax +36 1 437 06-50 http://www.sew-eurodrive.hu office@sew-eurodrive.hu
------------------	----------	--	---

Iceland

Sales	Reykjavik	Varma & Vélaverk ehf. Knarrarvogi 4 104 Reykjavik	Tel. +354 585 1070 Fax +354 585)1071 https://vov.is/ vov@vov.is
-------	-----------	---	--

India

Registered Office Assembly Sales Service	Vadodara	SEW-EURODRIVE India Private Limited 302, NOTUS IT PARK, Sarabhai Campus, Beside Notus Pride, Genda Circle, Vadodara 390023 Gujarat	Tel. +91 265 3045200 Fax +91 265 3045300 http://www.seweurodriveindia.com salesvadodara@seweurodriveindia.com
Assembly Sales Service	Chennai	SEW-EURODRIVE India Private Limited Plot No. K3/1, Sipcot Industrial Park Phase II Mambakkam Village Sriperumbudur - 602105 Kancheepuram Dist, Tamil Nadu	Tel. +91 44 37188888 Fax +91 44 37188811 saleschennai@seweurodriveindia.com
	Pune	SEW-EURODRIVE India Private Limited Plant: Plot No. D236/1, Chakan Industrial Area Phase- II, Warale, Tal- Khed, Pune-410501, Maharashtra	Tel. +91 21 35 628700 Fax +91 21 35 628715 salespune@seweurodriveindia.com
Sales Service	Gurgaon	SEW-EURODRIVE India Private Limited Drive Center Gurugram Plot no 395, Phase-IV, UdyogVihar Gurugram , 122016 Haryana	Tel. +91 99588 78855 salesgurgaon@seweurodriveindia.com

Indonesia			
Sales	Medan	PT. Serumpun Indah Lestari Jl. Pulau Solor no. 8, Kawasan Industri Medan II Medan 20252	Tel. +62 61 687 1221 Fax +62 61 6871429 / +62 61 6871458 / +62 61 30008041 sil@serumpunindah.com serumpunindah@yahoo.com http://www.serumpunindah.com
	Jakarta	PT. Cahaya Sukses Abadi Komplek Rukan Puri Mutiara Blok A no 99, Sunter Jakarta 14350	Tel. +62 21 65310599 Fax +62 21 65310600 csajkt@cbn.net.id
	Jakarta	PT. Agrindo Putra Lestari Jl. Pantai Indah Selatan, Komplek Sentra Industri Terpadu, Pantai indah Kapuk Tahap III, Blok E No. 27 Jakarta 14470	Tel. +62 21 2921-8899 Fax +62 21 2921-8988 aplindo@indosat.net.id http://www.aplindo.com
	Surabaya	PT. TRIAGRI JAYA ABADI Jl. Sukosemolo No. 63, Galaxi Bumi Permai G6 No. 11 Surabaya 60111	Tel. +62 31 5990128 Fax +62 31 5962666 sales@triagri.co.id http://www.triagri.co.id
	Surabaya	CV. Multi Mas Jl. Raden Saleh 43A Kav. 18 Surabaya 60174	Tel. +62 31 5458589 Fax +62 31 5317220 sianhwa@sby.centrin.net.id http://www.cvmultimas.com
Ireland			
Sales Service	Dublin	Alperton Engineering Ltd. 48 Moyle Road Dublin Industrial Estate Glasnevin, Dublin 11	Tel. +353 1 830-6277 Fax +353 1 830-6458 http://www.alperton.ie info@alperton.ie
Israel			
Sales	Tel Aviv	Liraz Handasa Ltd. Ahofer Str 34B / 228 58858 Holon	Tel. +972 3 5599511 Fax +972 3 5599512 http://www.liraz-handasa.co.il office@liraz-handasa.co.il
Italy			
Assembly Sales Service	Milan	SEW-EURODRIVE S.a.s. di SEW S.r.l. & Co. Via Bernini, 12 20033 Solaro (Milano)	Tel. +39 02 96 980229 Fax +39 02 96 980 999 http://www.sew-eurodrive.it milano@sew-eurodrive.it
Ivory Coast			
Sales	Abidjan	SEW-EURODRIVE SARL Ivory Coast Rue des Pêcheurs, Zone 3 26 BP 916 Abidjan 26	Tel. +225 27 21 21 81 05 Fax +225 27 21 25 30 47 info@sew-eurodrive.ci http://www.sew-eurodrive.ci
Japan			
Assembly Sales Service	Iwata	SEW-EURODRIVE JAPAN CO., LTD 250-1, Shimoman-no, Iwata Shizuoka 438-0818	Tel. +81 538 373811 Fax +81 538 373814 http://www.sew-eurodrive.co.jp sewjapan@sew-eurodrive.co.jp
Kazakhstan			
Sales Service	Almaty	SEW-EURODRIVE LLP 291-291A, Tole bi street 050031, Almaty	Tel. +7 (727) 350 5156 Fax +7 (727) 350 5156 http://www.sew-eurodrive.com kazakhstan@sew-eurodrive.com
	Tashkent	Representative Office SEW-EURODRIVE Representative office in Uzbekistan 95A Amir Temur ave, office 401/3 100084 Tashkent	Tel. +998 97 134 01 99 http://www.sew-eurodrive.uz sew@sew-eurodrive.uz
	Ulaanbaatar	IM Trading LLC Olympic street 28B/3 Sukhbaatar district, Ulaanbaatar 14230, MN	Tel. +976-77109997 Fax +976-77109997 imt@imt.mn

Latvia			
Sales	Riga	SIA Alas-Kuul Katlakalna 11C 1073 Riga	Tel. +371 6 7139253 Fax +371 6 7139386 http://www.alas-kuul.lv info@alas-kuul.com
Lebanon			
Sales (Lebanon)	Beirut	Gabriel Acar & Fils sarl B. P. 80484 Bourj Hammoud, Beirut	Tel. +961 1 510 532 Fax +961 1 494 971 ssacar@inco.com.lb
Sales (Jordan, Kuwait , Beirut Saudi Arabia, Syria)		Middle East Drives S.A.L. (offshore) Sin El Fil. B. P. 55-378 Beirut	Tel. +961 1 494 786 Fax +961 1 494 971 http://www.medrives.com info@medrives.com
Lithuania			
Sales	Alytus	UAB Irseva Statybininku 106C 63431 Alytus	Tel. +370 315 79204 Fax +370 315 56175 http://www.irseva.lt irmantas@irseva.lt
Luxembourg			
Representation: Belgium			
Macedonia			
Sales	Skopje	Boznos DOOEL Dime Anicin 2A/7A 1000 Skopje	Tel. +389 23256553 Fax +389 23256554 http://www.boznos.mk
Malaysia			
Assembly Sales Service	Johor	SEW-EURODRIVE SDN BHD No. 95, Jalan Seroja 39, Taman Johor Jaya 81000 Johor Bahru, Johor West Malaysia	Tel. +60 7 3549409 Fax +60 7 3541404 sales@sew-eurodrive.com.my
Mexico			
Assembly Sales Service	Quéretaro	SEW-EURODRIVE MEXICO S.A. de C.V. SEM-981118-M93 Tequisquiapan No. 102 Parque Industrial Quéretaro C.P. 76220 Querétaro, México	Tel. +52 442 1030-300 Fax +52 442 1030-301 http://www.sew-eurodrive.com.mx scmexico@seweurodrive.com.mx
Sales Service	Puebla	SEW-EURODRIVE MEXICO S.A. de C.V. Calle Zavaleta No. 3922 Piso 2 Local 6 Col. Santa Cruz Buenavista C.P. 72154 Puebla, México	Tel. +52 (222) 221 248 http://www.sew-eurodrive.com.mx scmexico@seweurodrive.com.mx
Mongolia			
Technical Office	Ulaanbaatar	IM Trading LLC Olympic street 28B/3 Sukhbaatar district, Ulaanbaatar 14230, MN	Tel. +976-77109997 Tel. +976-99070395 Fax +976-77109997 http://imt.mn/ imt@imt.mn
Morocco			
Sales Service Assembly	Bouskoura	SEW-EURODRIVE Morocco SARL Parc Industriel CFCIM, Lot. 55/59 27182 Bouskoura Grand Casablanca	Tel. +212 522 88 85 00 Fax +212 522 88 84 50 http://www.sew-eurodrive.ma sew@sew-eurodrive.ma
Namibia			
Sales	Swakopmund	DB MINING & INDUSTRIAL SUPPLIES CC Einstein Street Strauss Industrial Park Unit1 Swakopmund	Tel. +264 64 462 738 Fax +264 64 462 734 anton@dbminingnam.com

Netherlands			
Assembly Sales Service	Rotterdam	SEW-EURODRIVE B.V. Industrieweg 175 3044 AS Rotterdam Postbus 10085 3004 AB Rotterdam	Tel. +31 10 4463-700 Fax +31 10 4155-552 Service: 0800-SEWHELP http://www.sew-eurodrive.nl info@sew-eurodrive.nl
New Zealand			
Assembly Sales Service	Auckland	SEW-EURODRIVE NEW ZEALAND LTD. P.O. Box 58-428 82 Greenmount drive East Tamaki Auckland	Tel. +64 9 2745627 Fax +64 9 2740165 http://www.sew-eurodrive.co.nz sales@sew-eurodrive.co.nz
	Christchurch	SEW-EURODRIVE NEW ZEALAND LTD. 30 Lodestar Avenue, Wigram Christchurch	Tel. +64 3 384-6251 Fax +64 3 384-6455 sales@sew-eurodrive.co.nz
Nigeria			
Sales	Lagos	Greenpeg Nig. Ltd 64C Toyin Street Opebi-Allen Ikeja Lagos-Nigeria	Tel. +234-701-821-9200-1 http://www.greenpeg ltd.com sales@greenpeg ltd.com
Norway			
Assembly Sales Service	Moss	SEW-EURODRIVE A/S Solgaard skog 71 1599 Moss	Tel. +47 69 24 10 20 Fax +47 69 24 10 40 http://www.sew-eurodrive.no sew@sew-eurodrive.no
Pakistan			
Sales	Karachi	Industrial Power Drives Al-Fatah Chamber A/3, 1st Floor Central Com- mercial Area, Sultan Ahmed Shah Road, Block 7/8, Karachi	Tel. +92 21 452 9369 Fax +92-21-454 7365 seweurodrive@cyber.net.pk
Paraguay			
Sales	Fernando de la Mora	SEW-EURODRIVE PARAGUAY S.R.L Nu Guazu No. 642 casi Campo Esperanza Santisima Trinidad Asuncion	Tel. +595 991 519695 Fax +595 21 3285539 sewpy@sew-eurodrive.com.py
Peru			
Assembly Sales Service	Lima	SEW EURODRIVE DEL PERU S.A.C. Los Calderos, 120-124 Urbanizacion Industrial Vulcano, ATE, Lima	Tel. +51 1 3495280 Fax +51 1 3493002 http://www.sew-eurodrive.com.pe sewperu@sew-eurodrive.com.pe
Philippines			
Sales	Makati	P.T. Cerna Corporation 4137 Ponte St., Brgy. Sta. Cruz Makati City 1205	Tel. +63 2 519 6214 Fax +63 2 890 2802 mech_drive_sys@ptcerna.com http://www.ptcerna.com
Poland			
Assembly Sales Service	Łódź	SEW-EURODRIVE Polska Sp.z.o.o. ul. Techniczna 5 92-518 Łódź	Tel. +48 42 293 00 00 Fax +48 42 293 00 49 http://www.sew-eurodrive.pl sew@sew-eurodrive.pl
	Service	Tel. +48 42 293 0030 Fax +48 42 293 0043	24 Hour Service Tel. +48 602 739 739 (+48 602 SEW SEW) serwis@sew-eurodrive.pl
Portugal			
Assembly Sales Service	Coimbra	SEW-EURODRIVE, LDA. Av. da Fonte Nova, n.º 86 3050-379 Mealhada	Tel. +351 231 20 9670 Fax +351 231 20 3685 http://www.sew-eurodrive.pt infosew@sew-eurodrive.pt

Romania			
Sales Service	Bucharest	Sialco Trading SRL str. Brazilia nr. 36 011783 Bucuresti	Tel. +40 21 230-1328 Fax +40 21 230-7170 http://www.sialco.ro sialco@sialco.ro
Russia			
Assembly Sales Service	St. Petersburg	SAO «СЕВ-ЕВРОДРАЙФ» 188660, Russia, Leningrad Region, Vse- volozhsky District, Korabselki, Aleksandra Nevskogo str. building 4, block 1 P.O. Box 36 195220 St. Petersburg	Tel. +7 812 3332522 / +7 812 5357142 Fax +7 812 3332523 http://www.sew-eurodrive.ru sew@sew-eurodrive.ru
Senegal			
Sales	Dakar	SENEMECA Mécanique Générale Km 8, Route de Rufisque B.P. 3251, Dakar	Tel. +221 338 494 770 Fax +221 338 494 771 http://www.senemeca.com senemeca@senemeca.sn
Serbia			
Sales	Belgrade	DIPAR d.o.o. Ustanicka 128a PC Košum, IV floor 11000 Beograd	Tel. +381 11 347 3244 / +381 11 288 0393 Fax +381 11 347 1337 office@dipar.rs
Singapore			
Assembly Sales Service	Singapore	SEW-EURODRIVE PTE. LTD. No 9, Tuas Drive 2 Jurong Industrial Estate Singapore 638644	Tel. +65 68621701 Fax +65 68612827 http://www.sew-eurodrive.com.sg sewsingapore@sew-eurodrive.com
Slovakia			
Sales	Bernolákovo	SEW-Eurodrive SK s.r.o. Priemyselná ulica 6267/7 900 27 Bernolákovo	Tel. +421 2 48 212 800 http://www.sew-eurodrive.sk sew@sew-eurodrive.sk
Slovenia			
Sales Service	Celje	Pakman - Pogonska Tehnika d.o.o. Ul. XIV. divizije 14 3000 Celje	Tel. +386 3 490 83-20 Fax +386 3 490 83-21 pakman@siol.net
South Africa			
Assembly Sales Service	Johannesburg	SEW-EURODRIVE (PROPRIETARY) LIMITED 32 O'Connor Place Eurodrive House Aeroton Johannesburg 2190 P.O.Box 90004 Bertsham 2013	Tel. +27 11 248-7000 Fax +27 11 248-7289 http://www.sew.co.za info@sew.co.za
	Cape Town	SEW-EURODRIVE (PROPRIETARY) LIMITED Rainbow Park Cnr. Racecourse & Omuramba Road Montague Gardens Cape Town P.O.Box 36556 Chempet 7442	Tel. +27 21 552-9820 Fax +27 21 552-9830 Telex 576 062 bgriffiths@sew.co.za
	Durban	SEW-EURODRIVE (PROPRIETARY) LIMITED 48 Prospecton Road Isipingo Durban P.O. Box 10433, Ashwood 3605	Tel. +27 31 902 3815 Fax +27 31 902 3826 cdejager@sew.co.za
	Nelspruit	SEW-EURODRIVE (PROPRIETARY) LIMITED 7 Christie Crescent Vintonia P.O.Box 1942 Nelspruit 1200	Tel. +27 13 752-8007 Fax +27 13 752-8008 robermeyer@sew.co.za

South Korea			
Assembly Sales Service	Ansan	SEW-EURODRIVE Korea Co., Ltd. 7, Dangjaengi-ro, Danwon-gu, Ansan-si, Gyeonggi-do, Zip 425-839	Tel. +82 31 492-8051 Fax +82 31 492-8056 http://www.sew-eurodrive.kr master.korea@sew-eurodrive.com
	Busan	SEW-EURODRIVE Korea Co., Ltd. 28, Noksansandan 262-ro 50beon-gil, Gangseo-gu, Busan, Zip 618-820	Tel. +82 51 832-0204 Fax +82 51 832-0230
Assembly Service	Siheung	SEW-EURODRIVE Korea Co., Ltd. 35, Emtibeui 26-ro 58beon-gil, Siheung-si, Gyeonggi-do	http://www.sew-eurodrive.kr
Spain			
Assembly Sales Service	Bilbao	SEW-EURODRIVE ESPAÑA, S.L. Parque Tecnológico, Edificio, 302 48170 Zamudio (Vizcaya)	Tel. +34 94 43184-70 http://www.sew-eurodrive.es sew.spain@sew-eurodrive.es
Sri Lanka			
Sales	Colombo	SM International (Pte) Ltd 254, Galle Raod Colombo 4, Sri Lanka	Tel. +94 1 2584887 Fax +94 1 2582981
Swaziland			
Sales	Manzini	C G Trading Co. (Pty) Ltd Simunye street Matsapha, Manzini	Tel. +268 7602 0790 Fax +268 2 518 5033 charles@cgtrading.co.sz www.cgtradingswaziland.com
Sweden			
Assembly Sales Service	Jönköping	SEW-EURODRIVE AB Gnejsvägen 6-8 553 03 Jönköping Box 3100 S-550 03 Jönköping	Tel. +46 36 34 42 00 Fax +46 36 34 42 80 http://www.sew-eurodrive.se jonkoping@sew.se
Switzerland			
Assembly Sales Service	Basel	Alfred Imhof A.G. Jurastrasse 10 4142 Münchenstein bei Basel	Tel. +41 61 417 1717 Fax +41 61 417 1700 http://www.imhof-sew.ch info@imhof-sew.ch
Taiwan			
Sales	Taipei	Ting Shou Trading Co., Ltd. 6F-3, No. 267, Sec. 2 Tung Huw S. Road Taipei	Tel. +886 2 27383535 Fax +886 2 27368268 Telex 27 245 sewtwn@ms63.hinet.net http://www.tingshou.com.tw
	Nan Tou	Ting Shou Trading Co., Ltd. No. 55 Kung Yeh N. Road Industrial District Nan Tou 540	Tel. +886 49 255353 Fax +886 49 257878 sewtwn@ms63.hinet.net http://www.tingshou.com.tw
Tanzania			
Sales	Daressalam	SEW-EURODRIVE PTY LIMITED TANZANIA Plot 52, Regent Estate PO Box 106274 Dar Es Salaam	Tel. +255 0 22 277 5780 Fax +255 0 22 277 5788 http://www.sew-eurodrive.co.tz info@sew.co.tz
Thailand			
Assembly Sales Service	Chonburi	SEW-EURODRIVE (Thailand) Ltd. 700/456, Moo.7, Donhuaroh Muang Chonburi 20000	Tel. +66 38 454281 Fax +66 38 454288 sewthailand@sew-eurodrive.com
Tunisia			
Sales	Tunis	T. M.S. Technic Marketing Service Zone Industrielle Mghira 2 Lot No. 39 2082 Fouchana	Tel. +216 79 40 88 77 Fax +216 79 40 88 66 http://www.tms.com.tn tms@tms.com.tn

Turkey

Assembly Sales Service	Kocaeli-Gebze	SEW-EURODRIVE Ana Merkez Gebze Organize Sanayi Böl. 400 Sok No. 401 41480 Gebze Kocaeli	Tel. +90 262 9991000 04 Fax +90 262 9991009 http://www.sew-eurodrive.com.tr sew@sew-eurodrive.com.tr
------------------------------	---------------	---	---

Ukraine

Assembly Sales Service	Dnipropetrovsk	SEW-EURODRIVE, LLC Robochya str., bld. 23-B, office 409 49008 Dnipro	Tel. +380 56 370 3211 Fax +380 56 372 2078 http://www.sew-eurodrive.ua sew@sew-eurodrive.ua
------------------------------	----------------	--	--

United Arab Emirates

Drive Technology Center	Dubai	SEW-EURODRIVE FZE PO Box 263835 Jebel Ali Free Zone – South, P.O. Box Dubai, United Arab Emirates	Tel. +971 (0)4 8806461 Fax +971 (0)4 8806464 info@sew-eurodrive.ae
----------------------------	-------	---	---

Uruguay

Assembly Sales	Montevideo	SEW-EURODRIVE Uruguay, S. A. Jose Serrato 3569 Esquina Corumbe CP 12000 Montevideo	Tel. +598 2 21181-89 Fax +598 2 21181-90 sewuy@sew-eurodrive.com.uy
-------------------	------------	--	---

USA

Production Assembly Sales Service	Southeast Region	SEW-EURODRIVE INC. 220 Finch Rd P.O. Box 518 Wellford SC , 29385	Tel. +1 864 439-7537 Fax Sales +1 864 439-7830 Fax Production +1 864 439-9948 Fax Assembly +1 864 439-0566 Fax Confidential/HR +1 864 949-5557 http://www.seweurodrive.com cslyman@seweurodrive.com
Assembly Sales Service	Northeast Region	SEW-EURODRIVE INC. Pureland Ind. Complex 2107 High Hill Road, P.O. Box 481 Bridgeport, New Jersey 08014	Tel. +1 856 467-2277 Fax +1 856 845-3179 csbridgeport@seweurodrive.com
	Midwest Region	SEW-EURODRIVE INC. 2001 West Main Street Troy, Ohio 45373	Tel. +1 937 335-0036 Fax +1 937 332-0038 cstroy@seweurodrive.com
	Southwest Region	SEW-EURODRIVE INC. 202 W. Daniieldale Rd. DeSoto, TX 75115	Tel. +1 214 330-4824 Fax +1 214 330-4724 csdallas@seweurodrive.com
	Western Region	SEW-EURODRIVE INC. 30599 San Antonio St. Hayward, CA 94544	Tel. +1 510 487-3560 Fax +1 510 487-6433 cshayward@seweurodrive.com
	Wellford	SEW-EURODRIVE INC. 148/150 Finch Rd. Wellford, S.C. 29385	Tel. +1 864 439-7537 Fax +1 864 661 1167 IGOrders@seweurodrive.com


Additional addresses for service provided on request!



Vietnam


Sales	Ho Chi Minh City	SEW-EURODRIVE PTE. LTD. RO at Hochim- inh City Floor 8, KV I, Loyal building, 151-151 Bis Vo Thi Sau street, ward 6, District 3, Ho Chi Minh City, Vietnam	Tel. +84 937 299 700 huytam.phan@sew-eurodrive.com
	Hanoi	MICO LTD Quảng Trị - North Vietnam / All sectors except Construction Materials 8th Floor, Ocean Park Building, 01 Dao Duy Anh St, Ha Noi, Viet Nam	Tel. +84 4 39386666 Fax +84 4 3938 6888 nam_ph@micogroup.com.vn http://www.micogroup.com.vn

Zambia

Representation: South Africa







SEW-EURODRIVE
Driving the world